

WILLAMETTE INDUSTRIES, INC.

P.O. Box 519
Port Hueneme, Ca 93401

Note: This is a reference cited in AP 42, *Compilation of Air Pollutant Emission Factors, Volume I Stationary Point and Area Sources*. AP42 is located on the EPA web site at www.epa.gov/ttn/chief/ap42/

The file name refers to the reference number, the AP42 chapter and section. The file name "ref02_c01s02.pdf" would mean the reference is from AP42 chapter 1 section 2. The reference may be from a previous version of the section and no longer cited. The primary source should always be checked.

AB2588 TOXIC EMISSION TESTING

LM 2500 Cogen
October 21, 1991

Prepared By:

BTC ENVIRONMENTAL, INC.
1536 EASTMAN AVENUE
Ventura, CA 93003

Job Number
23002

Laboratory Report Number
291-168

Test Team Leader
Dan Laren

Results Verified By:
Tom Porter - Vice President Air Test Division

TABLE OF CONTENTS

	<u>Page</u>
Summary of Source Test Results	1
I. Introduction	2
II. Wet Test Methods Data Summaries	5
A. Field Data Summary	6
B. Equations	7
III. Wet Test Methods Calculations	8
A. Formaldehyde	9
B. Propylene	10
IV. Continuous Test Methods Data	12
A. C.A.R.B. Method 100 Data	13
B. Strip Charts	14
C. Continuous Analyzers Sampling System	15
V. Laboratory Analysis	17
A. Benzene (BTC #912037)	18
B. Propylene (BTC #912037)	22
C. Formaldehyde (AtmAA #92941)	27
D. Impinger Weights	27A
VI. Methodology	28
A. Equipment List	29
B. Sample Train Diagrams	32
VII. Raw Data	35
VIII. Quality Assurance	51
A. Dry Gas Meter Calibration	52
B. SKC Air Pump Calibration	53
C. Pyrometer Calibration	54
D. Pitot Tube Calibration	55
E. Continuous Analyzer Linearity Graphs	56
F. Claibration Gases	58
G. Chain of Custodies	59

SUMMARY
LM 2500 Cogen

Constituent	ppmv	lb/hr
<i>Propylene Run #1</i>	<0.1	<0.079
<i>Propylene Run #2</i>	<0.1	<0.079
<i>Propylene Run #3</i>	<0.1	<0.079
<i>Propylene Average</i>	<0.1	<0.079

Formaldehyde Run #1	0.007	0.004
Formaldehyde Run #2	0.050	0.028
Formaldehyde Run #3	0.004	0.002
Formaldehyde Average	0.020	0.011

I. INTRODUCTION

November 21, 1991

Job Number: 23002
Lab Number: 291-168

Willamette Industries Inc.
P.O. Box 519.
Port Hueneme, Ca. 93401

ATTENTION: Rudy Rehbein

REGARDING: Air Toxics testing on The LM 2500 Cogen.

Dear Mr. Rehbein:

On October 21, 1991, BTC Environmental performed air toxics testing on a natural gas fired LM 2500 cogen located at 5936 Perkins Road, Oxnard, California. The following is a summary of the procedures used in that test:

PROPYLENE SAMPLING AND ANALYSIS: Exhaust gas samples were taken into three (3) Tedlar bags. A Teflon tube was attached to the Tedlar bag which was placed into a vacuum chamber. A vacuum was applied to the chamber allowing the exhaust gases to enter the bag directly. The bag was then evacuated and refilled to assure that the probe line was completely purged. The sampling system was leaked check to meet CARB Method 18 requirements.

The bags were labeled and placed into a dark plastic bag and returned to the laboratory for analysis. The propylene was analyzed by GC/MS.

FORMALDEHYDE ANALYSIS: The formaldehyde was sampled according the CARB Method 430. The exhaust gases were withdrawn into midget impingers containing DNPH solution. The resultant impinger solution was retrieved in the field, kept in a charcoal container, refrigerated and returned to the laboratory for analysis. The samples were subcontracted to AtmAA and analyzed by HPLC.

STACK GAS ANALYSIS: Samples of the stack gas were taken through a heated sample line from the exhaust stack to a stack gas conditioner and analyzed for oxygen and carbon dioxide using CARB 100.1. The oxygen was determined by a Teledyne 320 AX electrochemical oxygen analyzer. The carbon dioxide was checked using an ACS (Fuji) 3000 NDIR analyzer. For a description of the sample conditioner and system please refer to the attachments.

STACK GAS FLOW RATE: The stack gas velocity was determined using an "S" type pitot tube connected to an inclined draft gauge or a magnehelic gauge. The stack temperature was determined using a thermocouple and an indicating pyrometer. The proportion of water was determined gravimetrically and the dry molecular weight of the stack gas determined by CARB Method 3.1, equation 3-2. A four (4) point, eight (8) port traverse was conducted on the exhaust stack.

LEAK CHECKS: Leak rates were conducted on the sampling trains and the pitot tubes before and after each test. The leak check for the moisture train was done at the probe. Any leak rate greater than 0.02 cfm was corrected for in the volume calculations.


The stack exhaust calculations for lb/hr were done by using the flow rate of the stack gas which was determined from pitot traverse. All values were calculated by using VCAPCD standard conditions (70°F & 29.92 in. Hg).

Benzene results were not reported due to inadequate detection limits.

If you have any questions concerning this test or if we can be of further assistance, please contact the undersigned at (805) 644-1095.

Respectfully submitted,

BTC Environmental, INC.



Tom Porter

Vice President - Air Test Division

II. WET TEST METHODS DATA SUMMARIES

FIELD DATA & CALCULATIONS SUMMARY

Client: **Willamette**
 Site: **Oxnard**
 Unit: **Cogen LM 2500**

Date: **10/21/91**
 Type: **T std = 68 F**
 Run: **1**

Wlc	Water Condensate Weight	33.3	g			
Vlc	Water Condensate Volume	33.4	ml			
Vm	Metered Sample Gas Volume	16.265	dscf			
Lp	Avg. Leak Rate	0.000	cf			
Vn	Leak Corrected Sample Gas Volume	16.265	dscf			
Y	Dry Gas Meter Calibration Factor	0.997				
Pbar	Barometric Pressure	30.17	In. Hg			
Pg	Static Pressure	0.54	In. H2O			
Ps	Stack Pressure, Absolute	30.21	in. Hg			
Δ H	Dry Gas Meter Press. Differential, Average	1.750	In. H2O			
Tm	Dry Gas Meter Temperature, Average	75.9	deg. F	535.9	deg. R	
Vm(std)	Sample Gas Volume	16.2455	dscf			
Vm(wet)	Sample Gas Volume, Wet	17.8244	scf			
Vw(std)	Water Vapor Volume	1.5788	scf			
Bws	Water Content of Stack Gas	0.089		8.9	%	
CO2	Carbon Dioxide, Dry	3.5	%			
O2	Oxygen, Dry	14.5	%			
N2	Nitrogen, Dry	82.0	%			
Md	Molecular Wt. of Stack Gas, Dry	29.140	lb/lb mole			
Ms	Molecular Wt. of Stack Gas, Wet	28.153	lb/lb mole			
Cp	Pitot Calibration Factor	0.846				
Δ P	Velocity Head, Average Square Root	0.899	In. H2O			
Ts	Stack Gas Temperature, Average	323.5	deg. F	783.5	deg. R	
As	Area of Stack	51.53	sq ft	97.2	in. dia.	
Vs	Stack Gas Velocity	62.40	ft/sec			
Qa	Actual Flow Rate	192,915	cfm			
Qad	Actual Flow Rate, Dry	175,827	dscfm			
Q(std)	Stack Gas Flow Rate	120,090	dscfm			
Theta	Sampling Time	20	min.			

BTC ENVIRONMENTAL
EPA methods 2, 3, 4, 5, 6, 8

CONSTANTS & CONVERSIONS

Tstd = 60, 68, or 70 °F	1 in. Hg = 13.6 in. H ₂ O
Pstd = 29.92 in. Hg	1 lb = 453.6 g
R = 21.85(in. Hg-cu ft/lb mole-°R)	1 lb = 7000 grain
Dw = 0.9982(g/ml)	1 g = 15.432 grain
MW(H ₂ O) = 18.0 lb/lb mole	1 mg = 0.001 g
MW(Sulfur) = 32.03 lb/lb mole	1 hr = 60 min.
M(H ₂ SO ₄) = 98.08 lb/lb mole	1 part/vol X = 1*10 ⁶ ppmv X
MW(SO ₂) = 64.06 lb/lb mole	1 bbl = 42 gal
K(H ₂ SO ₄) = 0.5 mg-g mole/g-meq	M = 1000
K(SO ₂) = 0.5 mg-g mole/g-meq	La = 0.02 cfm
Kp = 85.49(ft/sec(sqrt{lb/lb mole-in.Hg/°R-in. H ₂ O}))	
Kw,[cu ft/g-°R] = R / (453.6*MW(H ₂ O)*Pstd)	
Kf,[scf-ppm/lb mole] = R * (Tstd+460) * (1*10 ⁶) / Pstd	

INTERMEDIATE CALCULATIONS

$$F, [\text{scf/MMBtu}] = F \text{ Factor} * (Tstd + 460) / 528$$

$$Ph, [\text{in. Hg}] = Pbar + (\Delta H / 13.6)$$

$$N_2, [\%] = 100 - (O_2\% + CO_2\%)$$

$$Vlc, [\text{ml}] = Ww / Dw$$

$$Qa, [\text{cfm}] = 60 * Vs * As$$

$$Qad, [\text{dcfm}] = Qa * (1 - Bws)$$

CFR 40 - EPA EQUATIONS

eq. 2-8 $T[°R] = T[°F] + 460$

eq. 2-6 $Ps, [\text{in. Hg}] = Pbar + (Pg/13.6)$

eq. 5-3 $Bws, [\%] = Vw(std) / \{ Vw(std) + Vm(std) \}$

eq. 3-2 $Md, [\text{lb/lb-mole}] = 0.44 * CO_2\% + 0.32 * O_2\% + 0.28 * (N_2\% + CO\%)$

eq. 2-5 $Ms, [\text{lb/lb mol}] = Md * (1 - Bws) + (MW(H_2O) * Bws)$

eq. 5-2 $Vw(std), [\text{scf}] = Ww * Kw * (Tstd + 460)$

eq. 5-1 $Vn, [\text{cf}] = Vm - ((Lp - La) * Theta)$

eq. 5-1 $Vm(std), [\text{sdscf}] = Vm * Y * ((Tstd + 460) / (Tm + 460)) * Ph / Pstd$

eq. 2-9 $Vs, [\text{ft./sec.}] = Kp * Cp * (\Delta P * (Ts + 460)) / (Ps * Ms)^{0.5}$

eq. 2-10 $Qstd, [\text{dscfm}] = Qad * (Tstd + 460) * Ps / ((Ts + 460) * Pstd)$

eq. 5-8 $I, [\%] = 100 * (Ts + 460) * Vm(std) * Pstd / (60 * Vs * Theta * An * Ps * (1 - Bws) * (Tstd + 460))$

eq. 5-6 $Cx, [\text{grain/dscf}] = Wx, g * 15.432 / Vm(std)$

eq. 8-2,3 $Wx, [\text{mg}] = (Vt - Vlb) * N(std) * (Vsoln / Valq) * MWx * Kx$

$Cx, [\text{grain/dscf}] = Wx, \text{mg} * 0.001 * 15.432 / Vm(std)$

$CWx, [\text{grain/scf}] = Cx * (1 - Bws)$

$CCx, [\text{grain/dscf @ 12\% CO}_2] = Cx * 12.0 / CO_2\%$

$CWCx, [\text{grain/scf @ 12\% CO}_2] = CCx$

$CPx, [\text{ppmv dry}] = Cx * Kf / (MWx * 7000)$

$CPCx, [\text{ppmv @ N\% O}_2] = CPx * ((20.9 - N\%) / (20.9 - O_2\%))$

$CFx, [\text{lb/hr}] = Cx * Q(std) * 60 / 7000$

$CEx, [\text{lb/MMBtu}] = F * (Cx / 7000) * (20.9 / (20.9 - O_2\%))$

$CBx, [\text{lb/bbl}] = CEx * (Fuel \text{ Btu/MM}) * (Fuel \text{ lb/gal}) * 42$

$CEsx, [\text{lb S/MMBtu}] = CEx * (MW(S) / MWx)$

Where x represents, Particulate, Sulfuric Acid, Sulfate, or Sulfur Dioxide respectively.

III. WET TEST METHODS CALCULATIONS

FORMALDYHDE

Client : Willamette
 Site : Oxnard
 Unit : Cogen LM 2500

P bar: 30.14 in. Hg
 T std: 70 °F
 Pump #: Speedair

Date : 10/21/91
 Job #: 23002
 Lab #: 291-168

RUN ID	Q ml/min Avg.	Time min	V ml	Tm °F	Vstd dscm	Wd µg less blank	Cf µg/dscm	Cs ppmv
1	578.1	30	17,343	68	1.75E-02	0.15	8.55	0.0069
2	578.1	30	17,343	68	1.75E-02	1.08	61.59	0.0495
3	578.1	30	17,343	67	1.76E-02	0.07	3.98	0.0032
Average								0.020

ppm	Dscfm	lb/hr	Average lb/hr
0.0069	120,090	0.0039	0.0112
0.0495	120,090	0.0278	
0.0032	120,090	0.0018 0.00182	

Equations:

$V = Q \text{ pump, ml/min} \times \text{Time, min}$

$Vstd = V \times (Tstd/Tm) \times (Pbar/Pstd)$

$Cf = Wd / Vstd$

$Cs = Cf \times 0.08205 \times (Tstd, °K) / 30, 30 = \text{MW of HCHO}$

$lb/hr = ppm \times MW \times Dscfm \times 0.0000001 \times 1.885$

BTC Environmental, Inc. - 1990

$$\frac{0.0032 \text{ ppm}}{120,090 \text{ dscfm}} \times \frac{120,090 \text{ dscfm}}{\text{min}} \times \frac{60 \text{ min}}{1 \text{ hr}} \times \frac{1 \text{ lb}}{30 \text{ g}} = 0.00182 \text{ lb/hr}$$

EXHAUST GAS PROPYLENE ANALYSIS

Client : Willamette Date : 10/21/91
Site : Oxnard Job #: 23002
Unit : Cogen LM 2500 Lab #: 291-168
Load: Normal Fuel: So,Cal, Gas

FIELD AND LAB DATA

Exhaust Flow Rate, Q(std): 120,090 dscfm(avg)
Exhaust Outlet O2: 14.5 %
Standard Temperature, T std: 70 ° F

Components	#1		#2		#3	
	<u>8:30 AM</u> time		<u>9:15 AM</u> time		<u>9:45 AM</u> time	
	ppmv	lb/hr	ppmv	lb/hr	ppmv	lb/hr
Propylene	<u>< 0.10</u>	< 0.0785	<u>< 0.10</u>	< 0.0785	<u>< 0.10</u>	< 0.0785
Totals	<u>< 0.10</u>	< 0.0785	<u>< 0.10</u>	< 0.0785	<u>< 0.10</u>	< 0.0785

The above constituents are measured by gas chromatography using FID.

T factor = $60 * 29.92 * 10^{-6} / (21.85 * (460 + T_{std}))$

MQL of Propylene = 0.02 ppmv

lb/hr = Q (std) * [ppmv] * MW * T factor

Mw Propylene = 42

RESULTS

Propylene < 0.10 ppmv
< 0.0785 lb/hr $\Rightarrow \frac{0.0785}{2} = 0.039$

BTC Environmental, Inc. - 1989

IV. CONTINUOUS TEST METHODS DATA

EMISSIONS TEST - C.A.R.B. METHOD 100

**** Test Information ****

Client: Willamette
County: Ventura
Site(s): Port Hueneme
Unit(s): Cogen

**** Personnel ****

BTC: Dan Larin
Client: Rudy Rehdein
APCD: -

**** Instrument Information ****


Instrument	"On"	Unit#	Make/Model	Vacuum	Time Cnst.	Span Set
O2:	2	4	Teledyne 320AX			
CO2:	8	6	ACS 3300			
Recorders:	1	5	Soltec / 6 Cont.-pens	10	cm/hr	

**** Calibration Information ****

	Units	Zero	Span	Range	Gas Cyl.#	Gas Flow
Outlet O2:	%	2.5	3.94	25	CC93021	0.8
CO2:	%	2	14.2	20	CC93021	0.8

**** Recorder Information ****



		Chanl.	Pen Type	Color
Outlet O2:	%	6	Cont.	Brown
CO2:	%	3	Cont.	Purple



Extractive Gas Sampling System

Model EGS-1 (Patent Applied For)

Exemplar's Extractive Gas Sampling System, Model EGS-1 is specifically designed to be a complete, easy to use, portable extractive gas sampling system for use with continuous gas analyzers. By combining individual Exemplar components, a complete system requires only the addition of user specified analyzers and calibration gases. The system is easy to operate and difficult to mis-calibrate.




SPECIAL FEATURES

- Simple to use; only requires connecting to analyzers, cal gases and electrical power.
- Easily portable; system, analyzers and cal gases will fit into and operate from the back of a standard station wagon.
- Highly accurate; both internal and external calibration from probe tip; system is easy to calibrate.
- High capacity and non-scrubbing; powerful thermoelectric coolers with special heat exchanger design removes condensing water as quickly as it is formed.
- Positive pressure design; eliminates concentration errors due to leaks.
- Corrosion and reaction resistant; sample contacts only non-reactive, non-absorbing materials.

APPLICATIONS

- Use where EPA extractive sampling requirements are specified.
- Use where high accuracy is essential.
- Replace older, complex negative pressure systems.
- Complete extractive system without the need for a sampling van.
- Use where space is limited.

ESG-1 4/84



Components

Exemplar's InCal IN-1 series of in-stream calibrating probes are used to provide filtered non-condensing sample gas from a wide range of sources. The probe's in-stream calibration feature allows the entire system (probe tip to analyzer) to be accurately calibrated. The probe's design, size and corrosion resistance make sample extraction easy.

Exemplar's Sample Gas Conditioner PEL-3 provides the distribution panel with sample gas under positive pressure. A vibrating armature pump followed by a double sided, thermoelectrically cooled, flat plate heat exchanger with integral water separation channels, is capable of producing 5 lpm of 40°F dew point sample gas from a 160°F, water saturated (30%) sample stream. The condensing water dump is automatic allowing for continuous operation. The positive pressure nature of the system eliminates sample dilution due to tube fitting leaks. The unit is light weight and easily portable.

Exemplar's Sample Distribution Flow Panel FL-2 distributes dry, positive pressure, non-scrubbed sample gas to the appropriate instruments. The panel allows for both internal and probe tip calibration. Manual, click stop, rotary plug valves and an illustrative front panel provide leak free, fail-safe sample and calibration gas distribution. Flow paths are simple and easy to understand. This unit is small and easily transportable.

V. LABORATORY ANALYSIS

BTC Environmental, Incorporated
1536 Eastman Avenue, Suite B
Ventura, CA. 93003
(805) 644-1095

Prepared For: Air Lab

November 12, 1991

Attention: Tom Porter

Laboratory No: 912037
Date Received: 21-OCT-91
Sample ID: See Below

Job No: 291-168
Sampled By: Dan
Project: Willamette

RESULTS

On October 21, 1991, three (3) samples were received for analysis by BTC Environmental, Inc. The samples were identified and assigned the lab numbers listed below.

<u>SAMPLE IDENTIFICATION</u>	<u>BTCE LAB NUMBERS</u>
Run 1 - Bag	91203701
Run 2 - Bag	91203702
Run 3 - Bag	91203703

Dan Farah
Dan A. Farah, Ph.D.
Director - Analytical Operations

BTC Environmental, Incorporated
1536 Eastman Avenue, Suite B
Ventura, CA. 93003
(805) 644-1095

Client: Airlab (Willamette)
Lab No: 91203701
Sample ID: Run 1-Bag

VOLATILE AROMATIC COMPOUNDS
by ADDL004

COMPOUND	RESULT	PQL	UNITS	DIL.FACTOR	ANALYZED
Benzene	0.17	0.01	ppm(V)	1	24-OCT-91

VOID

PQL: Practical Quantitation Limit
BQL: Below Practical Quantitation Limit


GC Analyst

BTC Environmental, Incorporated
1536 Eastman Avenue, Suite B
Ventura, CA. 93003
(805) 644-1095


Client: Airlab (Willamette)
Lab No: 91203702
Sample ID: Run 2-Bag

VOLATILE AROMATIC COMPOUNDS
by ADDL004

COMPOUND	RESULT	PQL	UNITS	DIL.FACTOR	ANALYZED
Benzene	0.24	0.01	ppm (V)	1	24-OCT-91

VOID

PQL: Practical Quantitation Limit
BQL: Below Practical Quantitation Limit


GC Analyst

BTC Environmental, Incorporated
1536 Eastman Avenue, Suite B
Ventura, CA. 93003
(805) 644-1095


Client: Airlab (Willamette)
Lab No: 91203703
Sample ID: Run 3-Bag

VOLATILE AROMATIC COMPOUNDS
by ADDL004

COMPOUND	RESULT	PQL	UNITS	DIL.FACTOR	ANALYZED
Benzene	BQL	0.01	ppm (V)	1	24-OCT-91

1010

PQL: Practical Quantitation Limit
BQL: Below Practical Quantitation Limit


GC Analyst

BTC

ENVIRONMENTAL
INCORPORATED

BTC Environmental, Incorporated
1536 Eastman Avenue, Suite B
Ventura, CA. 93003
(805) 644-1095

Client: Air Lab (Willamette)
Lab No.: 912037
Sample ID: Method Blank

Date Analyzed: 22-OCT-91
Dilution Factor: 1
Matrix: Air

VOLATILE ORGANIC COMPOUNDS
EPA 624/8240

<u>COMPOUND</u>	<u>Concentration</u> <u>ppm (V)</u>	<u>PQL</u> <u>ppm (V)</u>
Propylene	BQL	.1

BQL: Below Practical Quantitation Limit
PQL: Practical Quantitation Limit

Russell Teague
Russell Teague
Department Supervisor

BTC Environmental, Incorporated
1536 Eastman Avenue, Suite B
Ventura, CA. 93003
(805) 644-1095

Client: Air Lab (Willamette)
Lab No.: 91203701
Sample ID: Run 1 - Bag

Date Analyzed: 22-OCT-91
Dilution Factor: 1
Matrix: Air

VOLATILE ORGANIC COMPOUNDS
EPA 624/8240

<u>COMPOUND</u>	<u>Concentration</u> <u>ppm (V)</u>	<u>PQL</u> <u>ppm (V)</u>
Propylene	BQL	.1

BQL: Below Practical Quantitation Limit
PQL: Practical Quantitation Limit

Russell Teague
Russell Teague
Department Supervisor

BTC Environmental, Incorporated
1536 Eastman Avenue, Suite B
Ventura, CA. 93003
(805) 644-1095

Client: Air Lab (Willamette)
Lab No.: 91203702
Sample ID: Run 2 - Bag

Date Analyzed: 22-OCT-91
Dilution Factor: 1
Matrix: Air

VOLATILE ORGANIC COMPOUNDS
EPA 624/8240

<u>COMPOUND</u>	<u>Concentration</u> <u>ppm(V)</u>	<u>PQL</u> <u>ppm(V)</u>
Propylene	BQL	.1

BQL: Below Practical Quantitation Limit
PQL: Practical Quantitation Limit

Russell Teague
Russell Teague
Department Supervisor

BTC Environmental, Incorporated
1536 Eastman Avenue, Suite B
Ventura, CA. 93003
(805) 644-1095

Client: Air Lab (Willamette)
Lab No.: 91203703
Sample ID: Run 3 - Bag

Date Analyzed: 22-OCT-91
Dilution Factor: 1
Matrix: Air

VOLATILE ORGANIC COMPOUNDS
EPA 624/8240

<u>COMPOUND</u>	<u>Concentration</u> <u>ppm (V)</u>	<u>PQL</u> <u>ppm (V)</u>
Propylene	BQL	.1

BQL: Below Practical Quantitation Limit
PQL: Practical Quantitation Limit

Russell Teague
Russell Teague
Department Supervisor



AtmAA Inc.

21354 Nordhoff St., Suite 113, Chatsworth, CA 91311 (818) 718-6070 • FAX (818) 718-9779

environmental consultants
laboratory services

October 29, 1991

LTR/459/91
3900

Tom Porter
BTC Environmental
1536 Eastman Ave.
Ventura, CA 93003

re: 291-168

Dear Tom:

Please find enclosed the laboratory analysis report four DNPH cartridge samples received on October 21, 1991.

The samples were analyzed for formaldehyde by high performance liquid chromatography (HPLC).

Spike recoveries for two 5 ug (as HCHO) spiked DNPH solutions were 4.99 and 4.94 ug respectively.

Sincerely,

AtmAA, Inc.

Dr. Kochy Fung
Air Programs Director

KF/kp
Encl.



AtmAA Inc.

21354 Nordhoff St., Suite 113, Chatsworth, CA 91311 (818) 718-6070 • FAX (818) 718-9779

environmental consultants
laboratory services

LABORATORY ANALYSIS REPORT

DNPH impinger solutions were analyzed for formaldehyde by high performance liquid chromatography (HPLC).

Report Date : October 28, 1991
Date Received : October 21, 1991
Date Analyzed : October 22, 1991
P.O. No.: Verbal
Client Proj. No.: 291-168

AtmAA Lab. No.	Sample ID	ug/impinger	
		HCHO	Vol,ml
92941-33	Run #1 Formaldehyde	1.62	44.0
92941-34	Run #2 Formaldehyde	2.61	43.0
92941-35	Run #3 Formaldehyde	1.60	43.5
92941-36	Run #4 Formaldehyde	1.53	43.0
92941-33 R	Run #1 Formaldehyde	1.74	44.0

$$\text{Ave of Run \#1} = \frac{1.62 + 1.74}{2} = 1.68$$

$$\left(\frac{\text{Smp}}{\text{R.I.}} \right)_{\text{Run \#2}} = \frac{1.273}{65.19} = 1.705$$

Since $\Sigma 5$

Dr. Kochy Fung
Air Programs Director

Run Set Up Sheet

Client : Willamette
 Site : _____
 Unit : _____

Date : _____
 Job # : _____
 Lab # : _____

Method: H2O

Cold Box: _____

Run No. _____

Hot Box: _____

Impinger Wt's.

Imp. #1:

gross	602.7
tare	578.2
final	24.5

Imp. #2:

gross	616.9
tare	611.9
final	5.0

Imp. #3:

gross	466.0
tare	464.5
final	1.5

Imp. #4:

gross	631.6
tare	629.3
final	2.3

Total 33.3

PM-10 Filter's

Type	No.	Tare Wt.

Large Filter

No. _____
 Tare Wt. _____

Sample Vol

start		ml
-------	--	----

 Imp #1

finsh		ml
final		ml

Sample Vol

start		ml
-------	--	----

 Imp #2

finsh		ml
final		ml

Set up by: _____

Comments: _____

VI. METHODOLOGY

SOURCE EMISSION INSTRUMENTATION LIST

7/3/91

OXYGEN:

Unit No. - 1

Manufacturer:	Taylor/Servomex
Model No.:	0A580
Serial No.:	508/702/497
Method:	Paramagnetic
Range (%):	0-10, 25 & 100

Unit No. - 2

Manufacturer:	Taylor/Servomex
Model No.:	68771/B
Serial No.:	68771/B
Method:	Paramagnetic
Range (%):	0-100

Unit No. - 3

Manufacturer:	Taylor/Servomex
Model No.:	570A
Serial No.:	4212B
Method:	Paramagnetic
Range (%):	0-100

Unit No. - 4

Manufacturer:	Teledyne
Model No.:	320-AX
Serial No.:	107294
Method:	Electrochemical
Range (%):	0-5, 10 & 25

Unit No. - 5

Manufacturer:	Teledyne
Model No.:	320-AX
Serial No.:	108743
Method:	Electrochemical
Range (%):	0-5, 10 & 25

Unit No. - 6

Manufacturer:	Teledyne
Model No.:	320-AX
Serial No.:	110649
Method:	Electrochemical
Range (%):	0-5, 10 & 25

SOURCE EMISSION INSTRUMENTATION LIST

7/3/91

OXYGEN:

Unit No. - 7

Manufacturer:	Teledyne
Model No.:	320-AX
Serial No.:	108742
Method:	Electrochemical
Range (%):	0-5, 10 & 25

Unit No. - 8

Manufacturer:	Teledyne
Model No.:	320-AX
Serial No.:	110647
Method:	Electrochemical
Range (%):	0-5, 10 & 25

SOURCE EMISSION INSTRUMENTATION LIST

7/3/91

CARBON DIOXIDE:

Unit No. - 1

Manufacturer:	Horiba
Model No.:	MEXA - 221
Serial No.:	4726203
Method:	NDIR
Range (%):	0-5 & 20

Unit No. - 2

Manufacturer:	Horiba
Model No.:	MEXA - 211E
Serial No.:	E70019
Method:	NDIR
Range (%):	0-5 & 20

Unit No. - 3

Manufacturer:	ACS (Fuji)
Model No.:	3300
Serial No.:	N8M6611T
Method:	NDIR
Range (%):	0-5 & 20

Unit No. - 4

Manufacturer:	ACS (Fuji)
Model No.:	3300
Serial No.:	N9C5479T
Method:	NDIR
Range (%):	0-5 & 20





Figure 18-9. Integrated bag sampling train.



- | | |
|-----------------------------------|-----------------------------|
| 1. Stack Wall | 8. Filter for Pump |
| 2. Probe | 9. Metering Valve |
| 3. Impinger with 100 ml of H_2O | 10. Vacuum Gauge |
| 4. Empty Bubbler | 11. By-pass Valve |
| 5. Bubbler with Silica Gel | 12. Temperature Compensated |
| 6. Ice Bath | Dry Gas Meter |
| 7. Sealed Pump (Leak Free) | |

Impingement Train For Moisture




FIGURE 1. TYPICAL SAMPLING SYSTEM (13.2)
FORMALDEHYDE CARB METHOD 430

VII. RAW DATA

BTC Environmental, Incorporated
1536 Eastman Avenue, Suite B
Ventura, CA. 93003
(805) 644-1095

645-1444

DATE: 10/20/92

TIME: 9:50

TO: Terri Thomas

COMPANY NAME: VCAPCD

FROM: Mark Patrick, Air Test

Terri, Enclosed are AP readings
from Willamette Toxics Test per
request from Reese Martin. I'm


TOTAL NO. PAGES: 3

(INCLUDING COVER SHEET)

not sure how they got
left out. If you have
any questions, please
call.

Thanks

(M / E)



TRAVERSE POINT NUMBER	DISTANCE INCHES	O ₂ (%)	CO ₂ (%)	SAMPLE TIME MIN.	STACK TEMP. (T _s), F	VELOCITY IN. H ₂ O		PRESSURE DIFF ORIFICE METER (ΔH) IN. H ₂ O	DRY GAS SAMPLE VOLUME (VM), FT. ³	GAS SAMPLE TEMP. @ DRY GAS METER		PUMP VACUUM IN. HG	TEMP. LAST IMPINGER (F)
						ΔP	√ΔP			INLET (Tm),	OUTLET (Tm)		
		14.5	3.5	0	337 ±			1.75	907.105	69	68	12	
		14.5	3.5	5					910.5	71	70		
		14.5	3.5	10					913.5	73	82		
		14.5	3.5	15					916.7	85	77		
		14.5	3.5	20					920.0	88	76		
									923.370				
	ZERO	0.0	0.0										
	SPAN	0.0	0.0										
AVERAGE													

PITOT LEAK CHECK:

BEFORE: TOP ΔP = _____ BOTTOM ΔP = _____

AFTER: TOP ΔP = _____ BOTTOM ΔP = _____

SAMPLE TRAIN LEAK:

BEFORE = 0.001 CFM@ _____ IN. HG.

AFTER = 0.001 CFM@ _____ IN. HG.

COMMENTS: PURGE _____


```

Incr      Flow      Ena
Volume    Rate      Rate
(MCF)     (MCF/H)    (MMBTU)
#         #         #
1         517.5    204.51    222.79
2         .0      .00       .00
          #         #
          3         4
          .0      .00       .00
          5         6
          .0      .00       .00
          7         8
          .0      .00       .00
Incr      Flow      Energy
Energy    Rate      Rate
(MMBTU)   (MCF/H)    (MMBTU)
#         #         #
1         565.2    204.51    222.79
2         .0      .00       .00
{G.C.}
C6+  Prop  I-But  N-But  Neo-C5  I-Pen  N-Pen  N»  Methane  CO»  Ethan
.2010 1.8000 .4010 .7140 .0000 .2470 .1580 .6120 92.637 .9390 2.2910
B.T.U.      1089.4      Sp.Gr.      .6248
Time:       8:19      Date:       10/21/91
[press: |F2 = Screen 2| |F3 = Scan Rate| |F9 = Exit| |Scroll Lock = Hold |]

```

```

Southern California Gas Company COM1:ëCSëRSëCDëëëëRDf
RTU=>Willamette LIVE DATA Time> 9:15:38 Date>10/21/91
[F1 - Meter Set, Meter Run, & G.C. Data]
Time: 8:21:25 èè[Reading]ëf Date:10/21/91
{Meter Set} Pass #1 {Meter Run}
Incr      Flow      Ena
Volume    Rate      Rate
(MCF)     (MCF/H)    (MMBTU)
#         #         #
1         527.0    253.98    276.28
2         .0      .00       .00
          #         #
          3         4
          .0      .00       .00
          5         6
          .0      .00       .00
          7         8
          .0      .00       .00
Incr      Flow      Energy
Energy    Rate      Rate
(MMBTU)   (MCF/H)    (MMBTU)
#         #         #
1         575.5    253.98    276.28
2         .0      .00       .00
{G.C.}
C6+  Prop  I-But  N-But  Neo-C5  I-Pen  N-Pen  N»  Methane  CO»  Ethan
.2020 1.7530 .3920 .6980 .0000 .2430 .1570 .6200 92.728 .9360 2.2710
B.T.U.      1087.8      Sp.Gr.      .6238
Time:       8:25      Date:       10/21/91
[press: |F2 = Screen 2| |F3 = Scan Rate| |F9 = Exit| |Scroll Lock = Hold |]

```

WILLAMETTE INDUSTRIES, INC.
 HUENEME PAPER MILL
 SUPPLIER RECAP REPORT FOR 10/20/91
 10/21/91
 09:15:44

SUPPLIER	#BALES	GROSS WT	ADJ WT	TONS	AVBWT	MTOD AVBWT	MTOD TONS
AB	0	0	0	0.00	0.00	0.00	2,330.33
ABCO	120	78500	78500	39.25	654.17	652.62	514.92

Willamette		8:00													
RTUID	Date/Time	7:00													
Meter	IDS	NC08-R	NC08-T30												
Meter	IDS	55.84	0	60.95	0.79	0	0.29	0.19	0.41	92.87					
SET1&2		0.22	1.81	0.44	0										
GCData		1.76	54.08	0	0										
Volume		1.00	100	0	0										
%Flow		72.4	74.7	0	0										
Temp		249.5	249.2	0	0										
Pres		0	0	0	0										
DP		0.6	1.8	0	0										
Freq		0	0												
Date/Time	10/21/91	7:15													
Meter	IDS	NC08-R	NC08-T30												
Meter	IDS	55.79	0	61.05	0.8	0	0.3	0.19	0.42	92.85					
GCData		0.24	1.81	0.44	0										
Volume		1.76	54.03	0	0										
%Flow		1.00	100	0	0										
Temp		72.4	74.7	0	0										
Pres		249.8	249.5	0	0										

MCF/H
MCF/H
MCF/H

8 AM → 9 AM = 216.16
9 AM → 10 AM = 217.44
10 AM → 10:30 AM = 215.66

Time + 1HR = PST

2.8	8	HHV	
2.2	10.7	BTJ/CFT	
	11.5		SPG.
1.99	1094.7		
	2		
	2.1		
	3.6		
	4.9		
	7.2		
	9.7		
1.96	1095.5		0.6274
			0.6267

[illegible]

HHV BTU/ft³
SG. 6.

1.93 1091.7 0.625

2 1091.6 0.6257

[illegible]

HHV/CET SP.G
✓

1.99 1088.5 0.6237

2.29 1089.4 0.6248

GCData	0.2	1.8	0.4	0.71	0	0.25	0.16	0.61	92.64	0.94
Volume	2:14	54:100	0.0	0.0	0	0.0	0.0	0.0		
%Flow	100	74:8	0.0	0.0	0	0.0	0.0	0.0		
Temp	73	249:8	0.0	0.0	0	0.0	0.0	0.0		
Pres	250.2	0	0.0	0.0	0	0.0	0.0	0.0		
DP	0.7	1:8	0.0	0.0	0	0.0	0.0	0.0		
Freq	0.7	1:30	0.0	0.0	0	0.0	0.0	0.0		
Date/Time	10/21/91	8:30	0.0	0.0	0	0.0	0.0	0.0		
IDS	NC08-R	NC08-T30	0.0	0.0	0	0.0	0.0	0.0		
Meter	IDS		0.0	0.0	0	0.0	0.0	0.0		
SET1f2	56.93	0	61.96	0.7	0	0.24	0.16	0.59	92.84	0.96
GCData	0.2	1.72	0.39	0.0	0	0.0	0.0	0.0		
Volume	2:22	54:100	0.0	0.0	0	0.0	0.0	0.0		
%Flow	100	74:8	0.0	0.0	0	0.0	0.0	0.0		
Temp	73.1	248:8	0.0	0.0	0	0.0	0.0	0.0		
Pres	249.4	0	0.0	0.0	0	0.0	0.0	0.0		
DP	0.7	1:8	0.0	0.0	0	0.0	0.0	0.0		
Freq	0.7	1:45	0.0	0.0	0	0.0	0.0	0.0		
Date/Time	10/21/91	8:45	0.0	0.0	0	0.0	0.0	0.0		
IDS	NC08-R	NC08-T30	0.0	0.0	0	0.0	0.0	0.0		
Meter	IDS		0.0	0.0	0	0.0	0.0	0.0		
IDS			0.0	0.0	0	0.0	0.0	0.0		

HHV
BTV/CFT → SR.G.

2.29 1089.4 0.6248

2.2 1086.8 0.6232

Meter IDs	57:09	61:88	0.68	0.24	0.16	0.6	93.11	0.94
SSET1&2	0	0	0	0	0	0	0	0
GCData	1:639	0:39	0	0	0	0	0	0
GVFlow	54:100	0	0	0	0	0	0	0
%Flow	73:4	0	0	0	0	0	0	0
Temp	74:9	0	0	0	0	0	0	0
Pres	248:7	0	0	0	0	0	0	0
DP	249:3	0	0	0	0	0	0	0
Freq	0:9	10:00	0	0	0	0	0	0
Date/Time10/21/91	0	0	0	0	0	0	0	0
Freq/Time10/21/91	1:00	0	0	0	0	0	0	0
Date/Time10/21/91	9:00	0	0	0	0	0	0	0
Meter IDs NC08-T30	0	0	0	0	0	0	0	0
SSET1&2	0	61:73	0.69	0.25	0.16	0.59	93.21	0.92
GCData	1:58	0:39	0	0	0	0	0	0
GVFlow	54:100	0	0	0	0	0	0	0
%Flow	73:7	0	0	0	0	0	0	0
Temp	74:9	0	0	0	0	0	0	0
Pres	247:8	10:15	0	0	0	0	0	0
DP	248:6	0	0	0	0	0	0	0
Freq	0:9	10:15	0	0	0	0	0	0
Date/Time10/21/91	0	0	0	0	0	0	0	0
Freq/Time10/21/91	1:15	0	0	0	0	0	0	0
Date/Time10/21/91	9:15	0	0	0	0	0	0	0

47

2.08 1083.6 0.6209
↓
AHK/CTA
↓
S.G.

2 1083.9 0.6207

10:15

Date/Time 10/21/91 9:15
 Meter IDs NC08-T30
 SET1&2 0
 GCData 1.67
 Volume 54.08
 %Flow 100
 Temp 175
 Pres 247.6
 DP 248.5
 Freq 0.9
 Date/Time 10/21/91 10:30
 Meter IDs NC08-T30
 SET1&2 1.8
 GCData 1.30
 Volume 53.75
 %Flow 100
 Temp 175
 Pres 248
 DP 249
 Freq 0.8

0.68 0.25 0.16 0.6 92.83 0.97
 0.69 0.25 0.16 0.6 92.8 0.96
 0.68 0.25 0.16 0.6 92.83 0.97
 0.69 0.25 0.16 0.6 92.8 0.96

HHV 30/01/21
S.P.G.
✓

2.26 1085.6 0.6227

2.25 1086.9 0.6233

VIII. QUALITY ASSURANCE

DRY GAS METER CALIBRATION

Date: 7/2/91

Unit: E

Ambient Conditions

Temp: 72 F/C

Baro: 28.91 in.Hg

ORIFICE MANOMETER SETTING D,H	GASVOL WET TEST METER V,w	GASVOL DRY GAS METER Vb,	wet test tw	Temperature				Y	DH@Y
				Dry IN	Dry Out	Ave f	Time e min		
				TD, IN	Tdo,	Td,			
0.5	5	203.701	75	96	84	88.50	15.19	0.7640	2.6405
		197.000	75	87	87				
1.0	5	208.686	75	100	85	91.50	10.64	1.1210	2.5770
		204.100	75	96	85				
1.5	5	215.221	75	101	86	93.00	8.61	1.1630	2.5244
		210.794	75	100	85				
2.0	5	223.436	75	105	86	94.50	7.52	0.9411	2.5606
		217.957	75	102	85				
								0.997	2.575625

Calibration by: STU

Meter Factor: 0.9973

Reviewed by: _____

Delta H: 2.5756

Equations:

$$Y = (V_w * P_b) * (T_d + 460) / (V_d t - V_d b) + (D_e H / 13.6) * (((W_t + w_t) / 2) + 460)$$

$$D_e H = (0.0317 * D_e) * (((((W_t + w_t) / 2) + 460) * e) / V_w)^2 / ((P_b * (T_d + 460))$$

SKC AIR PUMP'S
FLOW CALIBRATION DATA

Pump#: Speedaire 1

Date : 10/21/91

Trial (#)	Volume (ml)	Time (sec)	Flow (L/min)
1	500	51.69	0.58038
2	500	51.56	0.58185
3	500	51.57	0.58173
4	500	52.41	0.57241
5	500	52.06	0.57626
6	500	52.14	0.57537
7	500	51.79	0.57926
8	500	52.08	0.57604
9	500	51.81	0.57904
10	500	51.87	0.57837

Average Flow Rate: 0.5781

Initials : KK

Formulae:

$$\text{Flow(L/min)} = [\text{Vol(ml)}/\text{Time(sec)}] * [(60\text{sec}/1\text{min})/(1000\text{ml}/1\text{L})]$$

Apparatus:

HP 0101-0113 Soap Film Flowmeter

$$\frac{578.1}{50} = 11.56$$

THERMO COUPLE CALIBRATION

Date: 7/23/91

Unit: T-7

Point	* Standard Temperature <i>Tstd</i>		Pyrometer Temperature <i>Tpyr</i>		Error -% ** $(Tstd - Tpyr)/Tstd$
	deg. F		deg. F		
1 Ambient	69.8		72.6		0.53%
2 Ice	32.0		33.0		0.20%
3 Boil	212.0		211.4		0.09%
4 Oil					0.00%

Std. Corr. Factor

0.978

Calibration by: SW

* Standard ID: ASTM #86429 -5+300C

Reviewed by: RTR

* * in deg. K

PITOT TUBE CALIBRATION

Ambient Conditions

DATE: 2/20/91
UNIT NUMBER: 7/C-5'

TEMPERATURE 70 F
RH: %
BAROMETER: 29.87 in. hg.

Run #	Velocity fpm	ΔP (std) in. H ₂ O	ΔP (s) in. H ₂ O		Cp(s) Dev		Cp(s) Dev	
			A	B	A	A	B	B
1	3992	1.00	1.40	1.40	0.837	0.001	0.837	0.003
2		0.99	1.39	1.40	0.835	0.000	0.833	0.001
3		0.99	1.39	1.40	0.835	0.000	0.833	0.001
Avg		0.99	1.39	1.40	~0.836	0.001*	~0.834	0.002*

AVERAGE: (Cp(s)A+Cp(s)B)/2 0.835

| ~Cp(s)A-~Cp(s)B | = 0.002 *

1	4448	1.24	1.66	1.66	0.856	0.001	0.856	0.001
2		1.23	1.65	1.66	0.855	0.000	0.855	0.000
3		1.23	1.65	1.66	0.855	0.000	0.855	0.000
Avg		1.23	1.65	1.66	~0.855	0.000*	~0.855	0.000*

AVERAGE: (Cp(s)A+Cp(s)B)/2 0.855

| ~Cp(s)A-~Cp(s)B | = 0.000 *

1	4596	1.31	1.79	1.79	0.847	0.002	0.847	0.002
2		1.32	1.79	1.79	0.850	0.001	0.850	0.001
3		1.32	1.79	1.80	0.850	0.001	0.850	0.001
Avg		1.32	1.79	1.79	~0.849	0.001*	~0.849	0.001*

AVERAGE: (Cp(s)A+Cp(s)B)/2 0.849

| ~Cp(s)A-~Cp(s)B | = 0.000 *

PITOT CALIBRATION VALUE:

0.846


~ Denotes average value

* Denotes values which must be $\leq$ to 0.01 for calibration to be valid.


Calibrated by: SALLY

Reviewed by:

ACS 3300 #4 - December 5, 1989



Teledyne 320 AX - unit #4
September 19, 1989



57



SCOTT-MARRIN, INC.

2001 THIRD ST. • UNIT H • RIVERSIDE, CA 92507
TELEPHONE (714) 784-1240

REPORT OF ANALYSIS
CALIBRATION GAS MIXTURES

BTCE01

DATE : 07/16/91

TO:

TOM PORTER
BTC ENVIRONMENTAL
1536 EASTMAN AVENUE
VENTURA, CA 93003

PAGE 1

CUSTOMER ORDER NUMBER: 4822

CYLINDER NO.: CC93021

CYLINDER NO.:

COMPONENT	CONCENTRATION (v/v)
Oxygen	3.94 ± 0.04 %
Carbon Dioxide	14.19 ± 0.14 %
Carbon Monoxide	407 ± 4 ppm
Nitrogen	Balance

COMPONENT	CONCENTRATION (v/v)
-----------	---------------------

ppm = umole/mole

% = mole-%

Analyst:

M. S. Calhoun
M.S. Calhoun

Approved:

J. T. Marrin
J.T. Marrin



1536 Eastman Avenue
Ventura, CA 93003
(805) 644-1095

CHAIN OF CUSTODY RECORD

BILL TO COMPANY: 912037

Address:

Phone #: () Contact:

PROJ. NO.

291-168 W. La Metta

NO. OF CONTAINERS

PROJECT NAME

SAMPLES: (Signature)

Handwritten signature

NO.

DATE

TIME

COMP

GRAB

SAMPLE I.D.

1

10-21 8:30

RUN 1 - BAG

2

10-21 9:15

RUN 2 - BAG

3

10-21 9:45

RUN 3 - BAG

ANALYSIS
BAG 2 KLE &
PROPYLENE *

X

X

X

*GC by PID

*GC by MS

CHECK IF RUSH

REMARKS

The undersigned hereby acknowledges having received a copy of the Fee Schedule/General Information and Conditions, the provisions of which are a part of this agreement.

Relinquished by: (Signature)	Date/Time	Received by: (Signature)	Date/Time	Received by: (Signature)	Date/Time
Handwritten signature	10-21 12:00	Handwritten signature			
Relinquished by: (Signature)	Date/Time	Received for Laboratory by: (Signature)	Date/Time	NAME ADDRESS	PHONE NO.
Handwritten signature					

WHITE COPY _____ CANARY COPY _____ PINK COPY _____

1536 Eastman Avenue
Ventura, CA 93003
(805) 644-1095

CHAIN OF CUSTODY RECORD

Address: 1536 EASTMAN AVE

Ventura, CA 93003

Phone #: (405) 644-1095 Contact: _____

[illegible]

The undersigned hereby acknowledges having received a copy of the Fee Schedule/General Information and Conditions, the provisions of which are a part of this agreement.

Relinquished by: (Signature) 	Date/Time 10/21/1507	Received by: (Signature) 	Relinquished by: (Signature)	Date/Time	Received by: (Signature)
Relinquished by: (Signature)	Date/Time	Received for Laboratory by: (Signature)	Date/Time	NAME ADDRESS	
WHITE COPY	CANARY COPY	PINK COPY	PHONE NO.		