

Note: This is a reference cited in AP 42, *Compilation of Air Pollutant Emission Factors, Volume I Stationary Point and Area Sources*. AP42 is located on the EPA web site at www.epa.gov/ttn/chief/ap42/

The file name refers to the reference number, the AP42 chapter and section. The file name "ref02_c01s02.pdf" would mean the reference is from AP42 chapter 1 section 2. The reference may be from a previous version of the section and no longer cited. The primary source should always be checked.

Interpoll Laboratories, Inc.
4500 Ball Road N.E.
Circle Pines, Minnesota 55014-1819

TEL: (612) 786-6020

FAX: (612) 786-7854

**RESULTS OF THE FEBRUARY 20 - 22, 1996
EPA AND STATE AIR EMISSION COMPLIANCE
TESTING AT THE LOUISIANA PACIFIC OSB
PLANT IN HAYWARD, WISCONSIN**

Submitted to:

LOUISIANA-PACIFIC CORPORATION
Route 8, Box 8263
Hayward, Wisconsin 54843

Attention:

Keith Seelig

Reviewed by:



Daniel J. Despen

Manager

Stationary Source Testing Department

Report Number 6-7318

March 14, 1996

SL/sll

Interpoll Laboratories, Inc.
4500 Ball Road N.E.
Circle Pines, Minnesota 55014-1819

TEL: (612) 786-6020
FAX: (612) 786-7854

**RESULTS OF THE FEBRUARY 20 - 22, 1996
EPA AND STATE AIR EMISSION COMPLIANCE
TESTING AT THE LOUISIANA PACIFIC OSB
PLANT IN HAYWARD, WISCONSIN**

Submitted to:

LOUISIANA-PACIFIC CORPORATION
Route 8, Box 8263
Hayward, Wisconsin 54843

Attention:

Keith Seelig

Reviewed by:



Daniel J. Despen
Manager
Stationary Source Testing Department

Report Number 6-7318
March 14, 1996
SL/sil

FILE COPY



INTERPOLL LABORATORIES, INC.
4500 BALL ROAD N.E.
CIRCLE PINES, MINNESOTA 55014-1819
TEL: 612/786-6020
FAX: 612/786-7854

March 19, 1996

Keith Seelig
Louisiana-Pacific Corporation
Route 8, Box 8263
Hayward, Wisconsin 54843

Dear Keith:

Enclosed are three (3) copies of Interpoll Report No. 6-7318 entitled "Results of the February 20 - 22, 1996 EPA and State Air Emission Compliance Testing at the Louisiana Pacific OSB Plant in Hayward, Wisconsin".

If you have any questions please do not hesitate to contact me either by fax or telephone.

Sincerely,
INTERPOLL LABORATORIES, INC.

Kathy Erickstadt
Department Coordinator
Stationary Source Testing Department

KE:kce

Test No. 20
Dryer E - Tube Outlet

Results of Oxides of Nitrogen (NOx) Determinations-----Method 7

	Run 1A	Run 1B	Run 1C	Run 1D
Date of run.....	02-20-96	02-20-96	02-20-96	02-20-96
Time of run.....(HRS)	951	1005	1025	1040
Flask number.....	37	38	39	40
Volume of flask.....(ML)	2054	2056	2062	2093
Data: time of sampling				
flask temperature..(DEG-F)	41.00	41.00	39.00	39.00
bar. press.....(IN.HG)	28.48	28.48	28.48	28.48
flask vacuum.....(IN.HG)	27.01	27.37	27.29	27.26
flask abs. press...(IN.HG)	1.47	1.11	1.19	1.22
Data: Time of Flask Opening				
flask temperature..(DEG-F)	62.00	62.00	62.00	62.00
lab. bar. press....(IN.HG)	28.78	28.78	28.78	28.78
flask static press.(IN.HG)	-0.60	0.30	1.10	-2.50
flask abs. press...(IN.HG)	28.18	29.08	29.88	26.28
Volume gas sampled....(DSML)	1827	1916	1971	1747
Nitrate in gas sample...(JG)	77.5	64.0	50.5	46.5
NO2 in gas sample.....(JG)	57.5	47.5	37.5	34.5
<u>NOx Concentration</u>				
(GR/DSCF).....	0.0138	0.0108	0.0083	0.0086
(MG/DSCM).....	31	25	19	20
(PPM-DRY).....	16	13	10	10
NOX Emission rate....(LB/HR)	7.26	5.71	4.38	4.55

Test No. 20
Dryer E - Tube Outlet

Results of Oxides of Nitrogen (NOx) Determinations-----Method 7

	Run 2A	Run 2B	Run 2C	Run 2D
Date of run.....	02-20-96	02-20-96	02-20-96	02-20-96
Time of run.....(HRS)	1142	1155	1212	1231
Flask number.....	41	42	7	8
Volume of flask.....(ML)	2076	2094	2081	2088
Data: time of sampling				
flask temperature...(DEG-F)	38.00	39.00	39.00	40.00
bar. press.....(IN.HG)	28.48	28.48	28.48	28.48
flask vacuum.....(IN.HG)	27.09	27.05	27.27	27.27
flask abs. press...(IN.HG)	1.39	1.43	1.21	1.21
Data: Time of Flask Opening				
flask temperature...(DEG-F)	62.00	62.00	62.00	63.00
lab. bar. press....(IN.HG)	28.78	28.78	28.78	28.78
flask static press.(IN.HG)	-0.10	1.10	-0.30	1.80
flask abs. press...(IN.HG)	28.68	29.88	28.48	30.58
Volume gas sampled....(DSML)	1887	1985	1891	2040
Nitrate in gas sample...(JG)	50.5	55.0	51.5	42.5
NO2 in gas sample.....(JG)	37.5	40.8	38.2	31.5
<u>NOx Concentration</u>				
(GR/DSCF).....	0.0087	0.0090	0.0088	0.0068
(MG/DSCM).....	20	21	20	15
(PPM-DRY).....	10	11	11	8
NOX Emission rate....(LB/HR)	4.58	4.74	4.66	3.56

Test No. 20
Dryer E - Tube Outlet

Results of Oxides of Nitrogen (NOx) Determinations-----Method 7

	Run 3A	Run 3B	Run 3C	Run 3D
Date of run.....	02-20-96	02-20-96	02-20-96	02-20-96
Time of run.....(HRS)	1322	1340	1355	1410
Flask number.....	9	10	11	12
Volume of flask.....(ML)	2080	2063	2062	2111
Data: time of sampling				
flask temperature..(DEG-F)	46.00	46.00	44.00	44.00
bar. press.....(IN.HG)	28.48	28.48	28.48	28.48
flask vacuum.....(IN.HG)	27.02	27.38	27.38	27.38
flask abs. press...(IN.HG)	1.46	1.10	1.10	1.10
Data: Time of Flask Opening				
flask temperature..(DEG-F)	63.00	63.00	63.00	63.00
lab. bar. press....(IN.HG)	28.78	28.78	28.78	28.78
flask static press.(IN.HG)	1.60	2.00	1.60	-0.80
flask abs. press...(IN.HG)	30.38	30.78	30.38	27.98
Volume gas sampled....(DSML)	2001	2038	2009	1888
Nitrate in gas sample...(JG)	69.5	57.0	55.0	59.0
NO2 in gas sample.....(JG)	51.6	42.3	40.8	43.8
<u>NOx Concentration</u>				
(GR/DSCF).....	0.0113	0.0091	0.0089	0.0101
(MG/DSCM).....	26	21	20	23
(PPM-DRY).....	13	11	11	12
NOX Emission rate....(LB/HR)	5.94	4.79	4.68	5.35

LOUISIANA-PACIFIC CORPORATION
ROUTE 8, BOX 8263 - GEHRTS ROAD
HAYWARD, WI 54843

ROUTE TO:

_____ HAYDEN LAKE, ID
_____ JIM ELLISOR
_____ JIM EVENSEN
_____ LIZ JACOBS

_____ PORTLAND, OR
_____ LIZ SMITH
_____ MICHAEL BRYGGER
_____ SALLY MARTIN
_____ LAURI NEWTON

_____ MIKE RAZZETO - CHILCO, ID
_____ NORM HANSON - DAWSON CREEK
✓ _____ JIM LAKE - HAYWARD
_____ GERRY NASON - HOULTON
_____ JEFF SCHULTZ - MONTROSE
_____ JEFF POTOCHNIK - NEWBERRY
✓ _____ AL LAWRENCE - SAGOLA
_____ TODD MAKI - SAGOLA
_____ CHRIS FORSLUND - TOMAHAWK
_____ PETE WAINER - TWO HARBORS
_____ DICK HANSON - TWO HARBORS
_____ JIM HEINEMANN - MINITONAS
_____ WATERFORD, IRELAND
_____ LLOYD GEORGE - PT HAWKESBURY
_____ GARY MATTSON - MELLEN

_____ MATT HOLMQUIST
_____ KIM POON
✓ _____ ~~DEL SALQUIST~~ BRENT K.
_____ MARK STILE
_____ DICK KLOPSHINSKE
_____ BRIAN KAVEN

_____ WARD JOHNSON
_____ JAMIE DICKSON

_____ MIKE ANDERSON
_____ KEVIN WARKENTIN

_____ GREG CORMIER
_____ JOE KOPNICK

_____ HAYWARD, WI
_____ TONY CAVADEAS
_____ BOB SCHULTZ
_____ MARK BECKER
_____ ROB MITTLESDORF

_____ KEITH SEELIG
_____ SUE SOMERS
_____ MIKE HARE

COMMENTS:

DATE: 3/22/96

FROM: KEITH SEELIG

TABLE OF CONTENTS

	ABBREVIATIONS	iii
1	INTRODUCTION	1
2	SUMMARY AND DISCUSSION	4
3	RESULTS	23
3.1	Results of Orsat and Moisture Analyses	24
3.2	Results of Particulate Loading Determinations	34
3.3	Results of Oxides of Nitrogen Determinations	38
3.4	Results of Opacity Observations	45
3.5	Results of Carbon Monoxide Determinations	49
3.6	Results of Total Hydrocarbons Determinations	58
3.7	Results of Formaldehyde Determinations	64
3.8	Results of Phenol Determinations	68
3.9	Results of Benzene Determinations	71
3.10	Results of PAH Determinations	74
3.11	Results of MDI Determinations	77

APPENDICES:

A	-	Results of Volumetric Flow Rate Determinations
B	-	Location of Test Ports
C	-	Field Data Sheets
D	-	Interpoll Laboratories Analytical Data
E	-	THC Stripcharts
F	-	NOx and CO Datalogger Printouts
G	-	Measurement System Performance Specifications
H	-	Gas Analyzer Specifications
I	-	Calibration Gas Certification Sheets
J	-	Procedures
K	-	Calculation Equations
L	-	Operational Data
M	-	Sampling Train Calibration Data

ABBREVIATIONS

ACFM	actual cubic feet per minute
cc (ml)	cubic centimeter (milliliter)
DSCFM	dry standard cubic foot of dry gas per minute
DSML	dry standard milliliter
DEG-F (°F)	degrees Fahrenheit
DIA.	diameter
FP	finished product for plant
FT/SEC	feet per second
g	gram
GPM	gallons per minute
GR/ACF	grains per actual cubic foot
GR/DSCF	grains per dry standard cubic foot
g/dscm	grams per dry standard cubic meter
HP	horsepower
HRS	hours
IN.	inches
IN.HG.	inches of mercury
IN.WC.	inches of water
LB	pound
LB/DSCF	pounds per dry standard cubic foot
LB/HR	pounds per hour
LB/10 ⁶ BTU	pounds per million British Thermal Units heat input
LB/MMBTU	pounds per million British Thermal Units heat input
LTPD	long tons per day
MW	megawatt
mg/Nm ³	milligrams per dry standard cubic meter
ug/Nm ³	micrograms per dry standard cubic meter
microns (um)	micrometer
MIN.	minutes
ng	nanograms
ohm-cm	ohm-centimeter
PM	particulate matter
PPH	pounds per hour
PPM	parts per million
ppmC	parts per million carbon
ppm,d	parts per million, dry
ppm,w	parts per million, wet
ppt	parts per trillion
PSI	pounds per square inch
SQ.FT.	square feet
TPD	tons per day
ug	micrograms
v/v	percent by volume
w/w	percent by weight
<	≤ (when following a number)

Standard conditions are defined as 68°F (20°C) and 29.92 IN. of mercury pressure.

1 INTRODUCTION

During February 20 - 22, 1996, Interpoll Laboratories conducted EPA and State air emission compliance tests at the Louisiana Pacific OSB Plant in Hayward, Wisconsin on the following sources:

Source	Parameters
✓ Dryer RTO Stack	PM, NO _x , VE, CO, CH ₂ O, Benzene, THC's, Phenol, PAH's
✓ Line 1 Core Dryer Duct	NO _x , CO, THC's
✓ Line 1 Surface Dryer Duct	NO _x , CO, THC's
Press Vent RTO Stack	PM, NO _x , VE, CO, THC's, MDI, CH ₂ O
Line 1 Press RTO Inlet	NO _x , CO, THC's
Line 1 Thermal Oil Heater	PM, NO _x , VE, CO, CH ₂ O, Benzene, Phenol, PAH's
✓ Dryer E-Tube Outlet	NO _x

On-site testing was performed by Ed Trowbridge, Mark Kaehler, Duane Van Hoefer, Ed Juers, Steve Kelker, Jim Lorenz, Jamie Bainville, Lee Hanson, Dan Despen, and Sheryl Bergeron. Coordination between testing activities and plant operation was provided by Keith Selig of Louisiana-Pacific. The tests were witnessed by Jim Ross of the Wisconsin Department of Natural Resources.

Particulate determinations were performed in accordance with EPA Methods 1 - 5, CFR Title 40, Part 60, Appendix A (revised July 1, 1995). Preliminary volumetric flow rate determinations were used to select the appropriate nozzle diameter for isokinetic sample withdrawal. Interpoll Labs Model 3 M5 sampling trains which meet or exceed specifications in the above-cited reference were used to extract particulate samples by means of heated stainless steel probe. Wet catch samples were collected in the back half of the Method 5 sampling train at the stack test site and analyzed as per Wisconsin DNR protocol.

Oxides of nitrogen, carbon monoxide, oxygen, and carbon dioxide concentrations were determined in accordance with Methods 7E, 10, and 3A (Ibid). A slip stream of sample gas was withdrawn from the exhaust gas stream using a heated stainless steel probe equipped with a filter to remove interfering particulate material. The particulate-free gas was transported to the analyzers by means of a heat-traced probe and filter assembly. After passing

through the filter, the gas passed through a chilled condenser-type moisture removal system. The particulate-free dry gas was then transported to the analyzers with the excess exhausted to the atmosphere through a calibrated orifice which was used to ensure that the flow from the stack exceeds the requirements of the analyzers. A three-way valve on the probe was used to introduce standard gas for the "system bias check".

The analog response of each analyzer was recorded with a computer datalogger and backed up with a strip chart recorder. The NO_x, CO, O₂ and CO₂ analyzers were calibrated with National Specialty Gases and Air Products and Chemicals standard gases. The instrument was calibrated before and after each run as per EPA Method 7E, 10, and 3A. The sample probe was moved through a three-point traverse (1/6, 3/6, 5/6 of the stack diameter) to measure oxides of nitrogen and carbon monoxide concentrations.

Formaldehyde samples were collected using EPA Method 0011 (SW 846 3rd Ed.). The samples were collected isokinetically using a Method 5 sampling train with an aqueous acidic 2,4-dinitrophenylhydrazine absorbing solution and analyzed by high performance liquid chromatography.

Benzene samples were collected in the accordance with EPA Method 18 (Section 7.4 - Absorption Tube Procedure) using 800/200 mg charcoal tubes. The samples were returned to the laboratory and analyzed by Modified NIOSH 1501.

Total gaseous hydrocarbon concentrations were determined instrumentally using a Ratfisch Model RS 55 heated flame ionization detector (HFID) calibrated against propane in air standards. The THC concentration was continuously monitored by extracting a slipstream of exhaust gas by means of a heated probe and filter holder. A heat-traced teflon line was used to transport the sample gas from the filter holder outlet to the analyzer inlet.

MDI concentrations were determined in accordance with the 1,2-PP Method as developed by Radian Corporation under contract to USEPA. This method employs collection of MDI with 1,2-PP in toluene reagent, with analysis by HPLC.

Phenol concentrations were determined using a Method 5 sampling train with a neutral buffered absorbing reagent followed by extraction with methylene chloride and direct

analysis by GC/MS with no concentration (EPA Method 8270). The samples were field spiked with 5.33 mg of phenol d5.

Polyaromatic hydrocarbons sampling was conducted using the EPA Modified Method 5 sampling procedure as per EPA Method 010 SW 846. The four-part sample and field blank were extracted, concentrated to 1000 ul and cleaned up as required (column chromatography as per Interpoll Labs Method II-8904-2 or GPC) prior to final concentration and analysis. The samples were then further concentrated to 100 ul and analyzed in accordance with EPA Method 8270 by HRGC/LRMS using electron impact (EI) with total ion monitoring (TIM). Quantification was performed using the six standard M-8270 internal standards. Each XAD-2 resin cartridge was field spiked with 20 ug of d₁₀-fluoroanthene in order to document overall collection and analytical efficiency and recovery. Analytical accuracy and recovery for extraction and cleanup was documented using the six m-8270-recommended surrogate standards.

Integrated flue gas samples were extracted simultaneously with each of the above-referenced sample trains from the sampling train exhaust ports as part of the overall project quality assurance using a specially designed gas sampling system. Integrated flue gas samples were collected in 44-liter Tedlar bags. Prior to sampling, the Tedlar bags are leak checked at 15 IN.HG. vacuum with an in-line rotameter. Bags with any detectable inleakage are discarded. After sampling was complete, the bags were sealed and returned to the laboratory for Orsat analysis.

A summary and discussion of all of the important results of this compliance test is given in the following section. More detailed results of the various samplings are presented in Section 3, together with pertinent sampling parameters. Supplemental information such as field data sheets, laboratory results, procedures and calculation equations are presented in the appendices.

2 SUMMARY AND DISCUSSION

The results of the air emission compliance tests are presented in Tables 1 - 12. An overview of the results is presented in the table below:

PARAMETER	MEASURED
<u>DRYER RTO STACK</u>	
✓ Particulate	
✓ <i>DRY + WET CATCH</i>	
..... (GR/DSCF)	0.0039
..... (LB/HR)	2.4
✓ <i>DRY CATCH ONLY</i>	
..... (GR/DSCF)	0.0030
..... (LB/HR)	1.9
✓ Oxides of Nitrogen	
..... (ppm,d)	20
..... (LB/HR)	10.1
Opacity	(%) 0
Carbon Monoxide	
✓	(ppm,d) 202
.....	(LB/HR) 63
Formaldehyde	
✓	(ppm,d) 6.6
.....	(LB/HR) 2.3
Benzene	
.....	(ppm,d) 0.081
.....	(LB/HR) 0.071
✓ TGNMO's	
.....	(ppmC,w) 11.7
.....	(LB/HR) 2.0
Phenol	
✓	(ppb,d) < 173
.....	(10 ⁻³ LB/HR) < 174
<u>LINE 1 CORE DRYER DUCT</u>	
✓ Oxides of Nitrogen	
.....	(ppm,d) 36
.....	(LB/HR) 5.9
✓ Carbon Monoxide	
.....	(ppm,d) 786
.....	(LB/HR) 78
✓ TGNMO's	
.....	(ppmC,w) 362
.....	(LB/HR) 20.7

PARAMETER	MEASURED
<u>LINE 1 SURFACE DRYER DUCT</u>	
✓ Oxides of Nitrogen	
..... (ppm,d)	54
..... (LB/HR)	8.4
✓ Carbon Monoxide	
..... (ppm,d)	1250
..... (LB/HR)	354 117.87
✓ TGNMO's	
..... (ppmC,w)	614
..... (LB/HR)	35.8
<u>PRESS VENT RTO STACK</u>	
Particulate	
<u>DRY + WET CATCH</u>	
✓	0.0045
..... (LB/HR)	2.9
✓ <u>DRY CATCH ONLY</u>	
..... (GR/DSCF)	0.0026
..... (LB/HR)	1.7
✓ Oxides of Nitrogen	
..... (ppm,d)	24
..... (LB/HR)	12.9
✓ Opacity	0
Carbon Monoxide	
..... (ppm,d)	24
..... (LB/HR)	7.7
✓ Formaldehyde	
..... (ppm,d)	0.37
..... (LB/HR)	0.13
✓ TGNMO's	
..... (ppmC,w)	< 1
..... (LB/HR)	< 0.14
✓ MDI	
..... (ppm,d)	< 0.00065
..... (LB/HR)	< 0.0019
<u>LINE 1 PRESS RTO INLET</u>	
✓ Oxides of Nitrogen	
..... (ppm,d)	7
..... (LB/HR)	3.5
✓ Carbon Monoxide	
..... (ppm,d)	6.9
..... (LB/HR)	2.3
✓ TGNMO's	
..... (ppmC,w)	30.5
..... (LB/HR)	4.3

PARAMETER**MEASURED****LINE 1 THERMAL OIL HEATER****Particulate****X DRY + WET CATCH**

..... (GR/DSCF) 0.15
..... (LB/10⁶BTU) 0.67

✓ DRY CATCH ONLY

..... (GR/DSCF) 0.14
..... (LB/10⁶BTU) 0.60

✓ Oxides of Nitrogen

..... (ppm,d) 92
..... (LB/HR) 8.0

X Opacity (%) 5.4**Carbon Monoxide**

..... (ppm,d) 278
..... (LB/HR) 14.1

X Formaldehyde

..... (ppm,d) 0.08
..... (LB/HR) 0.0043

X Benzene

..... (ppm,d) < 0.012
..... (LB/HR) < 0.0017

✓ Phenol

..... (ppb,d) < 170
..... (10⁻³LB/HR) < 30

The PAH results are summarized in Tables 11 and 12. No difficulties were encountered in the field or in the laboratory evaluation of the samples. On the basis of these facts and a complete review of the data and results, it is our opinion that the concentrations and emission rates reported herein are accurate and closely reflect the actual values which existed at the time the tests were performed.

Table 1a Summary of the Results of tk. February 20, 1996 Particulate Emission Compliance Test of the Dryer RTO Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	02-20-96	02-20-96	02-20-96
Time runs were done (HRS)	950/1057	1140/1248	1320/1430
Volumetric flow actual (ACFM) standard (DSCFM)	132569 71993	133714 70905	133572 71496
Gas temperature (DEG-F)	258	263	257
Moisture content (%V/V)	22.29	23.60	23.48
Gas composition (%V/V, dry) carbon dioxide oxygen nitrogen	4.20 16.20 79.60	3.50 16.90 79.60	4.20 16.30 79.50
Isokinetic variation (%)	101.0	101.5	100.2
Particulate concentration actual (GR/ACF) standard (GR/DSCF)	.003293 .006067	.001528 .002883	.001451 .002713
Part. emission rate (LB/HR)	3.74	1.75	1.66

$\bar{x} = 133,285$
 $\bar{s} = 71,465$

0.33

Note: Dry + Organic/Inorganic Wet Catch

Table 1b Summary of the Results of the February 20, 1996 Particulate Emission Compliance Test of the Dryer RTO Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	02-20-96	02-20-96	02-20-96
Time runs were done (HRS)	950/1057	1140/1248	1320/1430
Volumetric flow actual standard	132569 71993	133714 70905	133572 71496
Gas temperature (ACFM) (DSCFM)	258	263	257
Moisture content (%V/V)	22.29	23.60	23.48
Gas composition (%V/V, dry) carbon dioxide oxygen nitrogen	4.20 16.20 79.60	3.50 16.90 79.60	4.20 16.30 79.50
Isokinetic variation (%)	101.0	101.5	100.2
Particulate concentration actual standard	.002254 .004153	.001296 .002445	.001314 .002456
Part. emission rate (LB/HR)	2.56	1.49	1.51

133285

1.85

Note: Dry Catch Only

Table 2a Summary of the Results of the February 21, 1996 Particulate Emission Compliance Test of the Press RTO Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	02-21-96	02-21-96	02-21-96
Time runs were done (HRS)	1215/1316	1400/1501	1535/1636
Volumetric flow actual standard (ACFM) (DSCFM)	102862 74155	105533 75440	103860 74754
Gas temperature (DEG-F)	242	249	243
Moisture content (%V/V)	1.81	1.60	1.88
Gas composition (%V/V, dry) carbon dioxide oxygen nitrogen	0.03 20.90 79.07	0.03 20.90 79.07	0.03 20.90 79.07
Isokinetic variation (%)	99.6	99.6	99.9
Particulate concentration actual standard (GR/ACF) (GR/DSCF)	.004349 .006035	.002901 .004060	.002554 .003550
Part. emission rate (LB/HR)	3.84	2.63	2.27

Note: Dry + Organic/Inorganic Wet Catch

Table 2b Summary of the Results of the February 21, 1996 Particulate Emission Compliance Test of the Press RTO Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	02-21-96	02-21-96	02-21-96
Time runs were done (HRS)	1215/1316	1400/1501	1535/1636
Volumetric flow actual standard (ACFM) (DSCFM)	102862 74155	105533 75440	103860 74754
Gas temperature (DEG-F)	242	249	243
Moisture content (%V/V)	1.81	1.60	1.88
Gas composition (%V/V.dry) carbon dioxide oxygen nitrogen	0.03 20.90 79.07	0.03 20.90 79.07	0.03 20.90 79.07
Isokinetic variation (%)	99.6	99.6	99.9
Particulate concentration actual standard (GR/ACF) (GR/DSCF)	.001740 .002414	.002276 .003185	.001650 .002294
Part. emission rate (LB/HR)	1.53	2.06	1.47

Note: Dry Catch Only

Table 3a. Summary of the Results of the February 21, 1996 Particulate Emission Compliance Test of the Line 1 Thermal Oil Heater Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	02-21-96	02-21-96	02-21-96
Time runs were done (HRS)	1535/1651	1725/1829	1900/2004
Volumetric flow actual (ACFM) standard (DSCFM)	21684 12014	21755 11940	21474 12113
Gas temperature (DEG-F)	384	383	375
Moisture content (%V/V)	9.28	10.28	8.70
Gas composition (%V/V, dry) carbon dioxide oxygen nitrogen	5.90 14.80 79.30	7.30 13.30 79.40	5.90 14.80 79.30
Isokinetic variation (%)	99.5	100.7	98.7
Particulate concentration actual (GR/ACF) standard (GR/DSCF)	.0904 0.163	.0902 0.164	.0736 0.131
part. emission rate (LB/HR)	16.81	16.82	13.55
Emission factor (LB/MMBTU)	0.767	0.620	0.613

5.73

Note: Dry + Organic/Inorganic Wet Catch

Table 3b. Summary of the Results of the February 21, 1996 Particulate Emission Compliance Test of the Line 1 Thermal Oil Heater Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	02-21-96	02-21-96	02-21-96
Time runs were done (HRS)	1535/1651	1725/1829	1900/2004
Volumetric flow actual (ACFM)	21684	21755	21474
standard (DSCFM)	12014	11940	12113
Gas temperature (DEG-F)	384	383	375
Moisture content (%V/V)	9.28	10.28	8.70
Gas composition (%V/V, dry)			
carbon dioxide	5.90	7.30	5.90
oxygen	14.80	13.30	14.80
nitrogen	79.30	79.40	79.30
Isokinetic variation (%)	99.5	100.7	98.7
Particulate concentration actual (GR/ACF)	.0722	.0849	.0733
standard (GR/DSCF)	0.130	0.155	0.130
Part. emission rate (LB/HR)	13.42	15.85	13.49
Emission factor (LB/MMBTU)	0.613	0.584	0.610

Note: Dry Catch Only

Table 4. Summary of the Results of the February 20 - 22, 1996 **Oxides of Nitrogen Determinations** at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppm,d)	Emission Rate (LB/HR)
(Dryer RTO Stack)			
2-20-96	0920-1057	21	10.7
2-20-96	1140-1248	18	9.2
2-20-96	1320-1420	20	10.3
Avg		20	10.1
(Line 1 Core Dryer Duct)			
2-20-96	0950-1050	35	5.6
2-20-96	1140-1240	38	6.4
2-20-96	1320-1420	36	5.7
Avg		36	5.9
(Line 1 Surface Dryer Duct)			
2-20-96	0950-1050	21	3.2
2-20-96	1140-1240	68	10.9
2-20-96	1320-1420	74	11.2
Avg		54	8.4
(Press Vent RTO Stack)			
2-21-96	1215-1316	24	13.0
2-21-96	1400-1501	24	13.0
2-21-96	1535-1636	24	12.6
Avg		24	12.9
(Line 1 Press RTO Inlet)			
2-21-96	1215-1315	11	6.0
2-21-96	1400-1500	5	2.6
2-21-96	1535-1635	3	1.8
Avg		7	3.5
(Line 1 Thermal Oil Heater Stack)			
2-22-96	0900-1005	90	8.2
2-22-96	1053-1157	98	8.1
2-22-96	1303-1403	89	7.6
Avg		92	8.0

Table 5a.

Summary of the Results of the February 20 - 22, 1996 Carbon Monoxide Determinations at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppm,d)	Emission Rate (LB/HR)
(Dryer RTO Stack)			
2-20-96	0920-1057	179	56
2-20-96	1140-1248	225	70
2-20-96	1320-1420	203	63
Avg		202	63
(Line 1 Core Dryer Duct)			
2-20-96	0950-1050	669	65
2-20-96	1140-1240	910	93
2-20-96	1320-1420	778	75
Avg		786	78
(Line 1 Surface Dryer Duct)			
2-20-96	0950-1050	983	92
2-20-96	1140-1240	1424	138
2-20-96	1320-1420	1342	124
Avg		1250	124 118
(Press Vent RTO Stack)			
2-21-96	1215-1316	16	5.0
2-21-96	1400-1501	24	8.0
2-21-96	1535-1636	31	10.1
Avg		24	7.7
(Line 1 Press RTO Inlet)			
2-21-96	1215-1315	10.2	3.3
2-21-96	1400-1500	7.6	2.5
2-21-96	1535-1635	3.0	1.0
Avg		6.9	2.3

Table 5b. Summary of the Results of the February 20 - 22, 1996 Carbon Monoxide Determinations at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppm.d)	Emission Rate (LB/HR)
(Line 1 Thermal Oil Heater Stack)			
2-20-96	1550-1905	764	36.2
2-21-96	0835-1130	126	6.4
2-21-96	1329-1618	86	4.4
Avg		325	15.7
2-21-96	1535-1651	120	6.3
2-21-96	1725-1829	595	31.0
2-21-96	1900-2004	271	14.3
Avg		329	17.2
2-22-96	0900-1005	177	9.8
2-22-96	1053-1157	248	12.6
2-22-96	1303-1403	114	5.9
Avg		180	9.4

Table 6.

Summary of the Results of the February 20 & 21, 1996 *TGNMO Determinations at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppmC,w)	Emission Rate (LB/HR)
(Dryer RTO Stack)			
2-20-96	0920-1057	8.7	1.5
2-20-96	1140-1248	12.3	2.1
2-20-96	1320-1420	14.0	2.4
Avg		11.7	2.0
(Line 1 Core Dryer Duct)			
2-20-96	0950-1050	312	18.0
2-20-96	1140-1240	399	22.4
2-20-96	1320-1420	375	21.6
Avg		362	20.7
(Line 1 Surface Dryer Duct)			
2-20-96	0950-1050	740	42.9
2-20-96	1140-1240	541	32.5
2-20-96	1320-1420	560	32.0
Avg		614	35.8
(Press Vent RTO Stack)			
2-21-96	1215-1316	< 1	< 0.14
2-21-96	1400-1501	< 1	< 0.14
2-21-96	1535-1636	< 1	< 0.14
Avg		< 1	< 0.14
(Line 1 Press RTO Inlet)			
2-21-96	1215-1315	23.4	3.3
2-21-96	1400-1500	29.4	4.2
2-21-96	1535-1635	38.7	5.4
Avg		30.5	4.3

* TGNMO = Total Gaseous Non-Methane Organics

Table 7. Summary of the Results of the February 21 & 22, 1996 **Formaldehyde Determinations** at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppm,d)	Emission Rate (LB/HR)
(Dryer RTO Stack)			
2-21-96	0830-0938	5.9	2.0
2-21-96	1020-1127	6.4	2.2
2-21-96	1205-1310	7.4	2.6
Avg		6.6	2.3
(Press Vent RTO Stack)			
2-22-96	1335-1436	0.40	0.14
2-22-96	1450-1551	0.32	0.11
2-22-96	1608-1708	0.38	0.14
Avg		0.37	0.13
(Line 1 Thermal Oil Heater Stack)			
2-22-96	0900-1003	0.07	0.0042
2-22-96	1053-1157	0.09	0.0047
2-22-96	1303-1406	0.07	0.0041
Avg		0.08	0.0043

Table 9. Summary of the Results of the February 20 & 21, 1996 Phenol Determinations at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppb.d)	Emission Rate (10 ³ LB/HR)
(Dryer RTO Stack)			
2-20-96	1520-1620	< 172	< 174
2-20-96	1635-1735	< 174	< 174
2-20-96	1750-1850	< 173	< 175
Avg		< 173	< 174
(Line 1 Thermal Oil Heater Stack)			
2-21-96	0934-1038	< 169	< 31
2-21-96	1056-1158	< 171	< 29
2-21-96	1341-1441	< 169	< 29
Avg		< 170	< 30

Table 8. Summary of the Results of the February 20 & 22, 1996 Benzene Determinations at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppm.d)	Emission Rate (LB/HR)
(Dryer RTO Stack)			
2-20-96	0950-1050	0.074	0.065
2-20-96	1149-1249	0.084	0.072
2-20-96	1320-1420	0.086	0.075
Avg		0.081	0.071
(Line 1 Thermal Oil Heater Stack)			
2-22-96	0900-1005	< 0.012	< 0.0019
2-22-96	1053-1157	< 0.011	< 0.0015
2-22-96	1303-1403	< 0.012	< 0.0017
Avg		< 0.012	< 0.0017

Table 10. Summary of the Results of the February 20 - 21, 1996 MDI Determinations at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppm,d)	Emission Rate (LB/HR)
(Press Vent RTO Stack)			
2-22-96	0800-0913	< 0.00065	< 0.0019
2-22-96	0941-1052	< 0.00066	< 0.0019
2-22-96	1117-1229	< 0.00065	< 0.0019
Avg		< 0.00065	< 0.0019

Table 11 Summary of the Results of the February 21 & 22, 1996 PAH Determinations of the Dryer RTO Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

Item	RUN 1	RUN 2	RUN 3
(Concentration ug/Nm ³)			
Benzo-a-anthracene	.56<	.56<	.56<
Benzo-b-fluoranthene	.31<	.31<	.31<
Benzo-a-pyrene	.37<	.38<	.37<
Dibenzo-a,h-anthracene	.27<	.28<	.27<
Indeno,1,2,3-pyrene	.28<	.28<	.28<
Dibenzo-a,i-pyrene	6.2<	6.3<	6.2<
Dibenzo-a,h-acridine	4.7<	4.7<	4.7<
Dibenzo-a,j-acridine	.5<	.50<	.5<
7H-Dibenzo-c,g-carbazole	.37<	.38<	.37<
Dibenzo-a,h-pyrene	6.2<	6.3<	6.2<
(Emission Rate 10 ⁻⁶ g/sec)			
Benzo-a-anthracene	19<	19<	19<
Benzo-b-fluoranthene	11<	11<	11<
Benzo-a-pyrene	13<	13<	13<
Dibenzo-a,h-anthracene	9.5<	9.5<	9.4<
Indeno,1,2,3-pyrene	9.7<	9.7<	9.6<
Dibenzo-a,i-pyrene	215<	215<	213<
Dibenzo-a,h-acridine	161<	162<	160<
Dibenzo-a,j-acridine	17<	17<	17<
7H-Dibenzo-c,g-carbazole	13<	13<	13<
Dibenzo-a,h-pyrene	215<	215<	213<

Table 12 Summary of the Results of the February 20 & 21, 1996 PAH Determinations of the Line 1 Thermal Oil Heater at the Louisiana Pacific Plant in Hayward, Wisconsin.

Item	RUN 1	RUN 2	RUN 3
(Concentration ug/Nm ³)			
Benzo-a-anthracene	.48<	.49<	.49
Benzo-b-fluoranthene	.26<	1.4	1.6
Benzo-a-pyrene	.32<	1.4	1.6
Dibenzo-a,h-anthracene	.23<	.24<	.24<
Indeno,1,2,3-pyrene	.24<	2.7	2.3
Dibenzo-a,i-pyrene	5.3<	5.5<	5.4<
Dibenzo-a,h-acridine	4<	4.1<	4.1<
Dibenzo-a,j-acridine	.42<	.44<	.44<
7H-Dibenzo-c,g-carbazole	.32<	.33<	.33<
Dibenzo-a,h-pyrene	5.3<	5.5<	5.4<
(Emission Rate 10- ⁶ g/sec)			
Benzo-a-anthracene	2.4<	2.7<	2.7
Benzo-b-fluoranthene	1.3<	7.6	8.8
Benzo-a-pyrene	1.6<	7.9	8.8
Dibenzo-a,h-anthracene	1.2<	1.3<	1.3<
Indeno,1,2,3-pyrene	1.2<	15	13
Dibenzo-a,i-pyrene	27<	30<	30<
Dibenzo-a,h-acridine	20<	23<	23<
Dibenzo-a,j-acridine	2.2<	2.4<	2.4<
7H-Dibenzo-c,g-carbazole	1.6<	1.8<	1.8<
Dibenzo-a,h-pyrene	27<	30<	30<

3 RESULTS

The results of all field and laboratory evaluations are presented in this section. Gas composition results (Orsat and moisture) are presented first followed by the computer printout of the gas composition, particulate, oxides of nitrogen, opacity, carbon monoxide, total hydrocarbons, formaldehyde, phenol, benzene, PAH, and MDI determinations. Preliminary measurements including test port locations are given in the appendices.

The results have been calculated on a personal computer using programs written in Extended BASIC specifically for source testing calculations. EPA-published equations have been used as the basis of the calculation techniques in these program. Emission rates have been calculated using the product of the concentration times flow method.

3.1 Results of Orsat and Moisture Analyses

Test No. 1
Dryer RTO Stack

(Particulate)

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

	Run 1	Run 2	Run 3
Date of run	02-20-96	02-20-96	02-20-96

Dry basis (orsat)

carbon dioxide.....	4.20	3.50	4.20
oxygen.....	16.20	16.90	16.30
nitrogen.....	79.60	79.60	79.50

Wet basis (orsat)

carbon dioxide.....	3.26	2.67	3.21
oxygen.....	12.59	12.91	12.47
nitrogen.....	61.85	60.81	60.83
water vapor.....	22.29	23.60	23.48
Dry molecular weight.....	29.32	29.24	29.32
Wet molecular weight.....	26.80	26.58	26.66
Specific gravity.....	0.926	0.918	0.921

FO	1.119	1.143	1.095
----	-------	-------	-------

Test No. 2
Dryer RTO Stack

(Formaldehyde)

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

	Run 1	Run 2	Run 3
Date of run	02-21-96	02-21-96	02-21-96

Dry basis (orsat)

carbon dioxide.....	3.80	3.80	3.80
oxygen.....	16.90	16.90	16.90
nitrogen.....	79.30	79.30	79.30

Wet basis (orsat)

carbon dioxide.....	2.95	2.96	2.97
oxygen.....	13.10	13.17	13.22
nitrogen.....	61.47	61.82	62.05
water vapor.....	22.49	22.05	21.75
Dry molecular weight.....	29.28	29.28	29.28
Wet molecular weight.....	26.75	26.80	26.83
Specific gravity.....	0.924	0.926	0.927

FO	1.053	1.053	1.053
----	-------	-------	-------

Test No. 4
Dryer RTO Stack

(PAH's)

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

	Run 1	Run 2	Run 3
Date of run	02-21-96	02-22-96	02-22-96

Dry basis (orsat)

carbon dioxide.....	3.70	3.80	3.80
oxygen.....	16.90	16.90	16.90
nitrogen.....	79.40	79.30	79.30

Wet basis (orsat)

carbon dioxide.....	2.87	2.95	2.91
oxygen.....	13.10	13.13	12.95
nitrogen.....	61.54	61.62	60.75
water vapor.....	22.49	22.30	23.40
Dry molecular weight.....	29.27	29.28	29.28
Wet molecular weight.....	26.73	26.77	26.64
Specific gravity.....	0.923	0.925	0.920

FO	1.081	1.053	1.053
----	-------	-------	-------

Test No. 9
Press Vent RTO Stack
(Particulate)

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

	Run 1	Run 2	Run 3
Date of run	02-21-96	02-21-96	02-21-96

Dry basis (orsat)

carbon dioxide.....	0.03	0.03	0.03
oxygen.....	20.90	20.90	20.90
nitrogen.....	79.07	79.07	79.07

Wet basis (orsat)

carbon dioxide.....	0.03	0.03	0.03
oxygen.....	20.52	20.57	20.51
nitrogen.....	77.64	77.81	77.58
water vapor.....	1.81	1.60	1.88
Dry molecular weight.....	28.84	28.84	28.84
Wet molecular weight.....	28.64	28.67	28.64
Specific gravity.....	0.989	0.990	0.989
Water mass flow.....(LB/HR)	3836	3433	4026

Test No. 11
Press Vent RTO Stack
(MDI)

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

Date of run	Run 1 02-22-96	Run 2 02-22-96	Run 3 02-22-96
Dry basis (orsat)			
carbon dioxide.....	0.40	0.40	0.40
oxygen.....	20.50	20.50	20.50
nitrogen.....	79.10	79.10	79.10
Wet basis (orsat)			
carbon dioxide.....	0.39	0.39	0.39
oxygen.....	19.76	20.17	20.06
nitrogen.....	76.23	77.83	77.42
water vapor.....	3.63	1.60	2.13
Dry molecular weight.....	28.88	28.88	28.88
Wet molecular weight.....	28.49	28.71	28.65
Specific gravity.....	0.984	0.992	0.990
FO	1.000	1.000	1.000

Test No. 12
Press Vent RTO Stack
(Formaldehyde)

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

Date of run	Run 1 02-22-96	Run 2 02-22-96	Run 3 02-22-96
Dry basis (orsat)			
carbon dioxide.....	0.40	0.40	0.40
oxygen.....	20.50	20.50	20.50
nitrogen.....	79.10	79.10	79.10
Wet basis (orsat)			
carbon dioxide.....	0.40	0.40	0.40
oxygen.....	20.36	20.27	20.29
nitrogen.....	78.57	78.21	78.29
water vapor.....	0.67	1.12	1.02
Dry molecular weight.....	28.88	28.88	28.88
Wet molecular weight.....	28.81	28.76	28.77
Specific gravity.....	0.995	0.994	0.994
FO	1.000	1.000	1.000

Test No. 14
Line 1 Thermal Oil Heater Stack

(PAH's)

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

Date of run	Run 1 02-20-96	Run 2 02-21-96	Run 3 02-21-96
-------------	-------------------	-------------------	-------------------

Dry basis (orsat)

carbon dioxide.....	8.20	6.50	6.60
oxygen.....	12.40	14.20	14.00
nitrogen.....	79.40	79.30	79.40

Wet basis (orsat)

carbon dioxide.....	7.41	5.90	6.04
oxygen.....	11.20	12.89	12.81
nitrogen.....	71.71	72.00	72.67
water vapor.....	9.68	9.21	8.48
Dry molecular weight.....	29.81	29.61	29.62
Wet molecular weight.....	28.66	28.54	28.63
Specific gravity.....	0.990	0.986	0.989

FO	1.037	1.031	1.045
----	-------	-------	-------

Test No. 16
Line 1 Thermal Oil Heater Stack

(Formaldehyde)

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

	Run 1	Run 2	Run 3
Date of run	02-22-96	02-22-96	02-22-96

Dry basis (orsat)

carbon dioxide.....	6.00	8.50	8.00
oxygen.....	14.60	12.10	12.60
nitrogen.....	79.40	79.40	79.40

Wet basis (orsat)

carbon dioxide.....	5.44	7.47	7.09
oxygen.....	13.24	10.63	11.17
nitrogen.....	71.99	69.78	70.39
water vapor.....	9.34	12.12	11.34

Dry molecular weight.....	29.54	29.84	29.78
---------------------------	-------	-------	-------

Wet molecular weight.....	28.47	28.41	28.45
---------------------------	-------	-------	-------

Specific gravity.....	0.983	0.981	0.983
-----------------------	-------	-------	-------

FO	1.050	1.035	1.037
----	-------	-------	-------

Test No. 17
Line 1 Thermal Oil Heater Stack

(Particulate)

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

	Run 1	Run 2	Run 3
Date of run	02-21-96	02-21-96	02-21-96

Dry basis (orsat)

carbon dioxide.....	5.90	7.30	5.90
oxygen.....	14.80	13.30	14.80
nitrogen.....	79.30	79.40	79.30

Wet basis (orsat)

carbon dioxide.....	5.35	6.55	5.39
oxygen.....	13.43	11.93	13.51
nitrogen.....	71.94	71.24	72.40
water vapor.....	9.28	10.28	8.70

Dry molecular weight.....	29.54	29.70	29.54
Wet molecular weight.....	28.47	28.50	28.53
Specific gravity.....	0.983	0.984	0.986
Water mass flow.....(LB/HR)	3447	3838	3238

FO	1.034	1.041	1.034
----	-------	-------	-------

3.2 Results of Particulate Loading Determinations

Test No. 1
Dryer RTO Stack

Results of Particulate Loading Determinations-----Method 5

	Run 1 02-20-96	Run 2 02-20-96	Run 3 02-20-96
Date of run			
Time run start/end.....(HRS)	950/1057	1140/1248	1320/1430
Static pressure.....(IN.WC)	-0.62	-0.62	-0.62
Cross sectional area (SQ.FT)	36.23	36.23	36.23
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	248.0	266.0	261.0
desiccant.....(GRAMS)	12.0	11.0	13.0
total.....(GRAMS)	260.0	277.0	274.0
Total particulate material..			
.....collected(grams)	0.0168	0.0079	0.0074
Gas meter coefficient.....	1.0004	1.0004	1.0004
Barometric pressure...(IN.HG)	28.48	28.48	28.48
Avg. orif.pres.drop...(IN.WC)	1.61	1.59	1.57
Avg. gas meter temp...(DEF-F)	65.6	68.9	73.1
Volume through gas meter....			
at meter conditions...(CF)	44.50	44.31	44.47
standard conditions.(DSCF)	42.73	42.28	42.09
Total sampling time....(MIN)	64.00	64.00	64.00
Nozzle diameter.....(IN)	.247	.247	.247
Avg.stack gas temp ..(DEG-F)	258	263	257
Volumetric flow rate.....			
actual.....(ACFM)	132569	133714	133572
dry standard.....(DSCFM)	71993	70905	71496
Isokinetic variation.....(%)	101.0	101.5	100.2
Particulate concentration...			
actual.....(GR/ACF)	0.00329	0.00153	0.00145
dry standard.....(GR/DSCF)	0.00607	0.00288	0.00271
Particle mass rate...(LB/HR)	3.744	1.752	1.662

Test No. 9
Press Vent RTO Stack

Results of Particulate Loading Determinations-----Method 5

	Run 1 02-21-96	Run 2 02-21-96	Run 3 02-21-96
Date of run			
Time run start/end.....(HRS)	1215/1316	1400/1501	1535/1636
Static pressure.....(IN.WC)	-0.48	-0.48	-0.48
Cross sectional area (SQ.FT)	31.09	31.09	31.09
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	8.0	7.0	8.0
desiccant.....(GRAMS)	11.0	10.0	12.0
total.....(GRAMS)	19.0	17.0	20.0
Total particulate material..			
.....collected(grams)	0.0190	0.0130	0.0113
Gas meter coefficient.....	1.0051	1.0051	1.0051
Barometric pressure..(IN.HG)	29.24	29.24	29.24
Avg. orif.pres.drop..(IN.WC)	2.23	2.32	2.30
Avg. gas meter temp..(DEF-F)	84.1	86.9	88.9
Volume through gas meter....			
at meter conditions...(CF)	50.70	51.82	51.70
standard conditions.(DSCF)	48.58	49.41	49.11
Total sampling time....(MIN)	60.00	60.00	60.00
Nozzle diameter.....(IN)	.250	.250	.250
Avg.stack gas temp ..(DEG-F)	242	249	243
Volumetric flow rate.....			
actual.....(ACFM)	102862	105533	103860
dry standard.....(DSCFM)	74155	75440	74754
Isokinetic variation.....(%)	99.6	99.6	99.9
Particulate concentration...			
actual.....(GR/ACF)	0.00435	0.00290	0.00255
dry standard.....(GR/DSCF)	0.00603	0.00406	0.00355
Particle mass rate...(LB/HR)	3.836	2.625	2.275

Test No. 17
Line 1 Thermal Oil Heater Stack

Results of Particulate Loading Determinations-----Method 5

	Run 1 02-21-96	Run 2 02-21-96	Run 3 02-21-96
Date of run	02-21-96	02-21-96	02-21-96
Time run start/end.....(HRS)	1535/1651	1725/1829	1900/2004
Static pressure.....(IN.WC)	-0.21	-0.21	-0.21
Cross sectional area (SQ.FT)	14.75	14.75	14.75
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	93.0	120.0	97.0
desiccant.....(GRAMS)	25.0	13.0	13.0
total.....(GRAMS)	118.0	133.0	110.0
Total particulate material..			
.....collected(grams)	0.5755	0.5829	0.4603
Gas meter coefficient.....	0.9997	0.9997	0.9997
Barometric pressure..(IN.HG)	29.24	29.24	29.24
Avg. orif.pres.drop..(IN.WC)	2.75	2.80	2.77
Avg. gas meter temp..(DEF-F)	75.9	77.5	74.2
Volume through gas meter....			
at meter conditions...(CF)	56.15	56.65	55.99
standard conditions.(DSCF)	54.40	54.73	54.42
Total sampling time....(MIN)	60.00	60.00	60.00
Nozzle diameter.....(IN)	.453	.453	.453
Avg.stack gas temp ..(DEG-F)	384	383	375
Volumetric flow rate.....			
actual.....(ACFM)	21684	21755	21474
dry standard.....(DSCFM)	12014	11940	12113
Isokinetic variation.....(%)	99.5	100.7	98.7
Particulate concentration...			
actual.....(GR/ACF)	0.09040	0.09016	0.07359 ^{.084}
dry standard.....(GR/DSCF)	0.16323	0.16434	0.13051 ^{.1527}
Particle mass rate...(LB/HR)	16.810	16.820	13.550 ^{15.23}
F-factor(DSCF/MMBTU)	< 9600	9600	9600
Emission factor...(LB/MMBTU)	0.767	0.620	0.613 ^{.6667}

15.73/.6667 = F

3.3 Results of Oxides of Nitrogen Determinations

Interpoll Labs Report No. 6-7318
Louisiana Pacific Corporation
Hayward, Wisconsin

Test No. 6
Dryer RTO Stack

Results of Oxides of Nitrogen Determinations Method 7E

	Run 1	Run 2	Run 3
Date of run	2-20-96	2-20-96	2-20-96
Time run start/end (HRS)	0950-1057	1140-1248	1320-1430
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	22.29	23.60	23.48
Oxygen content (%V/V)	16.2	16.9	16.3
Volumetric flow rate (DSCFM)	71990	70905	71495
NO _x concentration (ppm,d)	20.7	18.1	20.2
NO _x emission rate (LB/HR)	10.7	9.2	10.3

Test No. 7

Line 1 Core Dryer Duct

Results of Oxides of Nitrogen Determinations **Method 7E**

	Run 1	Run 2	Run 3
Date of run	2-20-96	2-20-96	2-20-96
Time run start/end (HRS)	0950-1050	1140-1240	1320-1420
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	28	29	29
Oxygen content (%V/V)	16.4	16.2	16.0
Volumetric flow rate (DSCFM)	22252	23520	22216
NO _x concentration (ppm,d)	35.3	37.9	35.7
NO _x emission rate (LB/HR)	5.6	6.4	5.7

Interpoll Labs Report No. 6-7318
Louisiana Pacific Corporation
Hayward, Wisconsin

Test No. 8
Line 1 Surface Dryer Duct

Results of Oxides of Nitrogen Determinations Method 7E

	Run 1	Run 2	Run 3
Date of run	2-20-96	2-20-96	2-20-96
Time run start/end (HRS)	0950-1050	1140-1240	1320-1420
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	30.8	30.9	31.0
Oxygen content (%V/V)	5.2	5.3	5.5
Volumetric flow rate (DSCFM)	21479	22195	21107
NO _x concentration (ppm,d)	20.6	68.3	74.0
NO _x emission rate (LB/HR)	3.2	10.9	11.2

Interpoll Labs Report No. 6-7318
Louisiana Pacific Corporation
Hayward, Wisconsin

Test No. 10
Press Vent RTO Stack

Results of Oxides of Nitrogen Determinations Method 7E

	Run 1	Run 2	Run 3
Date of run	2-21-96	2-21-96	2-21-96
Time run start/end (HRS)	1215-1316	1400-1501	1535-1636
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	1.81	1.60	1.88
Oxygen content (%V/V)	20.9	20.9	20.9
Volumetric flow rate (DSCFM)	74155	75440	74754
NO _x concentration (ppm,d)	24.4	24.1	23.6
NO _x emission rate (LB/HR)	13.0	13.0	12.6

74,783

Test No. 13
Line 1 Press RTO Inlet

Results of Oxides of Nitrogen Determinations ~~Method 7E~~

	Run 1	Run 2	Run 3
Date of run	2-21-96	2-21-96	2-21-96
Time run start/end (HRS)	1215-1315	1400-1500	1535-1635
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	1.26	1.25	1.28
Oxygen content (%V/V)	20.9	20.9	20.9
Volumetric flow rate (DSCFM)	74064	74787	74063
NO _x concentration (ppm,d)	11.4	4.9	3.3
NO _x emission rate (LB/HR)	6.0	2.6	1.8

Test No. 18
Line 1 Thermal Oil Heater Stack

Results of Oxides of Nitrogen Determinations **Method 7E**

	Run 1	Run 2	Run 3
Date of run	2-22-96	2-22-96	2-22-96
Time run start/end (HRS)	0900-1005	1053-1157	1303-1403
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	9.34	12.12	11.34
Oxygen content (%V/V)	14.2	11.8	13.0
Volumetric flow rate (DSCFM)	12735	11660	11910
NO _x concentration (ppm,d)	89.9	97.5	89.3
NO _x emission rate (LB/HR)	8.2	8.1	7.6

3.4 Results of Opacity Observations

Test No. 1
Line 1 Dryer RTO Stack

Results of Opacity Observations ----- EPA Method 9

PERCENT OPACITY	OPTICAL DENSITY	RELATIVE FREQUENCY (%)
0	0.0000	100.00
5	0.0223	0.00
10	0.0458	0.00
15	0.0706	0.00
20	0.0969	0.00
25	0.1249	0.00
30	0.1549	0.00
35	0.1871	0.00
40	0.2219	0.00
45	0.2596	0.00
50	0.3010	0.00
55	0.3468	0.00
60	0.3979	0.00
65	0.4559	0.00
70	0.5229	0.00
75	0.6021	0.00
80	0.6690	0.00
85	0.8239	0.00
90	1.0000	0.00
95	1.3010	0.00
99	2.0000	0.00
Avg Opac 0.00	Avg OD 0.0000	Time average

Observer: Sheryl Bergeron
Cert. Date: 10-04-95
Date of Observation: 02-20-96
Time of Observation: 0950/1050

Test No. 9
Line 1 Press Vent Stack

Results of Opacity Observations ----- EPA Method 9

PERCENT OPACITY	OPTICAL DENSITY	RELATIVE FREQUENCY (%)
0	0.0000	100.00
5	0.0223	0.00
10	0.0458	0.00
15	0.0706	0.00
20	0.0969	0.00
25	0.1249	0.00
30	0.1549	0.00
35	0.1871	0.00
40	0.2219	0.00
45	0.2596	0.00
50	0.3010	0.00
55	0.3468	0.00
60	0.3979	0.00
65	0.4559	0.00
70	0.5229	0.00
75	0.6021	0.00
80	0.6690	0.00
85	0.8239	0.00
90	1.0000	0.00
95	1.3010	0.00
99	2.0000	0.00
Avg Opac 0.00	Avg OD 0.0000	Time average

Observer: Sheryl Bergeron
Cert. Date: 10-04-95
Date of Observation: 02-21-96
Time of Observation: 1215/1315

Test No. 17
Line 1 Thermal Oil Heater Stack

Results of Opacity Observations ----- EPA Method 9

PERCENT OPACITY	OPTICAL DENSITY	RELATIVE FREQUENCY (%)
0	0.0000	0.00
5	0.0223	91.70
10	0.0458	8.30
15	0.0706	0.00
20	0.0969	0.00
25	0.1249	0.00
30	0.1549	0.00
35	0.1871	0.00
40	0.2219	0.00
45	0.2596	0.00
50	0.3010	0.00
55	0.3468	0.00
60	0.3979	0.00
65	0.4559	0.00
70	0.5229	0.00
75	0.6021	0.00
80	0.6690	0.00
85	0.8239	0.00
90	1.0000	0.00
95	1.3010	0.00
99	2.0000	0.00
Avg Opac 5.42	Avg OD 0.0243	Time average

Observer: Sheryl Bergeron
Cert. Date: 10-04-95
Date of Observation: 02-21-96
Time of Observation: 1535/1651

3.5 Results of Carbon Monoxide Determinations

Test No. 6
Dryer RTO Stack

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	2-20-96	2-20-96	2-20-96
Time run start/end.....(HRS)	0950-1057	1140-1248	1320-1430
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	22.29	23.60	23.48
O2 Concentration.....(%V/V)	16.20	16.90	16.30
Volumetric flow rate (DSCFM)	71990	70905	71495
CO concentration.....			
(GR/DSCF).....	0.0911	0.1145	0.1033
(MG/DSCM).....	208.53	262.13	236.50
(PPM-WET).....	139.10	171.90	155.34
(PPM-DRY).....	179.00	225.00	203.00
(PPM-DRY @ 7% O2).....	522.08	768.29	604.68
CO emission rate.....(LB/HR)	56.201	69.579	63.298

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value is less than or equal to the reported value

Test No. 7
Line 1 Core Dryer Duct

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	2-20-96	2-20-96	2-20-96
Time run start/end.....(HRS)	0950-1050	1140-1240	1320-1420
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	28.00	29.00	29.00
O2 Concentration.....(%V/V)	16.40	16.20	16.00
Volumetric flow rate (DSCFM)	22252	23520	22216
CO concentration.....			
(GR/DSCF).....	0.3403	0.4630	0.3957
(MG/DSCM).....	779.04	1059.	905.90
(PPM-WET).....	481.46	645.96	552.10
(PPM-DRY).....	668.70	909.80	777.60
(PPM-DRY @ 7% O2).....	2035.17	2653.	2177.
CO emission rate.....(LB/HR)	64.897	93.326	75.343

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 8
Line 1 Surface Dryer Duct

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	2-20-96	2-20-96	2-20-96
Time run start/end.....(HRS)	0950-1050	1140-1240	1320-1420
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	30.84	30.87	31.01
O2 Concentration.....(%V/V)	5.20	5.30	5.50
Volumetric flow rate (DSCFM)	21479	22195	21107
CO concentration.....			
(GR/DSCF).....	0.5004	0.7247	0.6833
(MG/DSCM).....	1145.	1659.	1564.
(PPM-WET).....	680.12	984.55	926.40
(PPM-DRY).....	983.40	1424.	1342.
(PPM-DRY @ 7% O2).....	871.37	1269.	1212.
CO emission rate.....(LB/HR)	92.122	137.863	123.612

86367
117.87

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value is less than or equal to the reported value

Test No. 10
Press Vent RTO Stack

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	2-21-96	2-21-96	2-21-96
Time run start/end.....(HRS)	1215-1316	1400-1501	1535-1636
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	1.81	1.60	1.88
O2 Concentration.....(%V/V)	20.90	20.90	20.90
Volumetric flow rate (DSCFM)	74155	75440	74754
CO concentration.....			
(GR/DSCF).....	0.0079	0.0124	0.0158
(MG/DSCM).....	18.06	28.43	36.23
(PPM-WET).....	15.22	24.01	30.52
(PPM-DRY).....	15.50	24.40	31.10
CO emission rate.....(LB/HR)	5.013	8.028	10.139

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 13
Line 1 Press RTO Inlet

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	2-21-96	2-21-96	2-21-96
Time run start/end.....(HRS)	1215-1315	1400-1500	1535-1635
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	1.26	1.25	1.28
O2 Concentration.....(%V/V)	20.90	20.90	20.90
Volumetric flow rate (DSCFM)	74064	74787	74063
CO concentration.....			
(GR/DSCF).....	0.0052	0.0039	0.0015
(MG/DSCM).....	11.88	8.85	3.50
(PPM-WET).....	10.07	7.50	2.96
(PPM-DRY).....	10.20	7.60	3.00
CO emission rate.....(LB/HR)	3.295	2.479	0.969

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 14
Line 1 Thermal Oil Heater Stack

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	02-20-96	02-21-96	02-21-96
Time run start/end.....(HRS)	1550/1905	0835/1130	1329/1618
Total sampling time....(MIN)	160.0	160.0	160.0
Moisture content.....(%V/V)	9.68	9.21	8.48
O2 Concentration.....(%V/V)	12.40	14.20	14.00
Volumetric flow rate (DSCFM)	10862	11696	11836
CO concentration.....			
(GR/DSCF).....	0.3888	0.0641	0.0438
(MG/DSCM).....	890.06	146.79	100.19
(PPM-WET).....	690.04	114.40	78.71
(PPM-DRY).....	764.00	126.00	86.00
(PPM-DRY @ 7% O2).....	1243.	259.41	172.00
CO emission rate.....(LB/HR)	36.193	6.427	4.439

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 17
Line 1 Thermal Oil Heater Stack

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	02-21-96	02-21-96	02-21-96
Time run start/end.....(HRS)	1535/1651	1725/1829	1900/2004
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	9.28	10.28	8.70
O2 Concentration.....(%V/V)	14.80	13.30	14.80
Volumetric flow rate (DSCFM)	12014	11940	12113
CO concentration.....			
(GR/DSCF).....	0.0611	0.3028	0.1379
(MG/DSCM).....	139.80	693.18	315.72
(PPM-WET).....	108.86	533.83	247.42
(PPM-DRY).....	120.00	595.00	271.00
(PPM-DRY @ 7% O2).....	270.97	1081.	611.94
CO emission rate.....(LB/HR)	6.288	30.984	14.317

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 18
Line 1 Thermal Oil Heater Stack

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	2-22-96	2-22-96	2-22-96
Time run start/end.....(HRS)	0900-1005	1053-1157	1303-1403
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	9.34	12.12	11.34
O2 Concentration.....(%V/V)	14.20	11.80	13.00
Volumetric flow rate (DSCFM)	12735	11660	11910
CO concentration.....			
(GR/DSCF).....	0.0901	0.1261	0.0581
(MG/DSCM).....	206.20	288.69	133.04
(PPM-WET).....	160.47	217.77	101.25
(PPM-DRY).....	177.00	247.80	114.20
(PPM-DRY @ 7% O2).....	364.41	377.09	199.85
CO emission rate.....(LB/HR)	9.831	12.601	5.932

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

3.6 Results of Total Hydrocarbons Determinations

Interpoll Labs Report No. 6-7318
Louisiana Pacific Corporation
Hayward, Wisconsin

Test No. 6
Dryer RTO Stack

Results of Total Hydrocarbons Determinations-----**Method 25A**

	Run 1	Run 2	Run 3
Date of run	2-20-96	2-20-96	2-20-96
Time run start/end (HRS)	0950-1057	1140-1248	1320-1430
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	22.29	23.60	23.48
Oxygen content (%V/V)	16.2	16.9	16.3
Volumetric flow rate (DSCFM)	71993	70905	71496
THC concentration (ppmC,w)	8.7	12.3	14.0
THC emission rate (LB/HR)	1.51	2.13	2.44

71,465

Interpoll Labs Report No. 6-7318
Louisiana Pacific Corporation
Hayward, Wisconsin

Test No. 7
Line 1 Core Dryer Duct

Results of Total Hydrocarbons Determinations—————**Method 25A**

	Run 1	Run 2	Run 3
Date of run	2-20-96	2-20-96	2-20-96
Time run start/end (HRS)	0950-1050	1140-1240	1320-1420
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	28	29	29
Oxygen content (%V/V)	16.4	16.2	16.0
Volumetric flow rate (DSCFM)	22252	23520	22216
THC concentration (ppmC,w)	312	399	375
THC emission rate (LB/HR)	18.0	22.4	21.6

Interpoll Labs Report No. 6-7318
Louisiana Pacific Corporation
Hayward, Wisconsin

Test No. 8
Line 1 Surface Dryer Duct

Results of Total Hydrocarbons Determinations ~~Method 25A~~

	Run 1	Run 2	Run 3
Date of run	2-20-96	2-20-96	2-20-96
Time run start/end (HRS)	0950-1050	1140-1240	1320-1420
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	30.8	30.9	31.0
Oxygen content (%V/V)	5.2	5.3	5.5
Volumetric flow rate (DSCFM)	21479	22195	21107
THC concentration (ppmC,w)	740	541	560
THC emission rate (LB/HR)	42.9	32.5	32.0

Interpoll Labs Report No. 6-7318
Louisiana Pacific Corporation
Hayward, Wisconsin

Test No. 10
Press Vent RTO Stack

Results of Total Hydrocarbons Determinations **Method 25A**

	Run 1	Run 2	Run 3
Date of run	2-21-96	2-21-96	2-21-96
Time run start/end (HRS)	1215-1316	1400-1501	1535-1636
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	1.81	1.60	1.88
Oxygen content (%V/V)	20.9	20.9	20.9
Volumetric flow rate (DSCFM)	74155	75440	74754
THC concentration (ppmC,w)	< 1	< 1	< 1
THC emission rate (LB/HR)	< 0.14	< 0.14	< 0.14

Test No. 13
Line 1 Press RTO Inlet

Results of Total Hydrocarbons Determinations ~~Method 25A~~

	Run 1	Run 2	Run 3
Date of run	2-21-96	2-21-96	2-21-96
Time run start/end (HRS)	1215-1315	1400-1500	1535-1635
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	1.26	1.25	1.28
Oxygen content (%V/V)	20.9	20.9	20.9
Volumetric flow rate (DSCFM)	74064	74787	74063
THC concentration (ppmC,w)	23.4	29.4	38.7
THC emission rate (LB/HR)	3.28	4.16	5.43

3.7 Results of Formaldehyde Determinations

Test No. 2
Dryer RTO Stack

Results of Formaldehyde Tests ----- EPA Method 0011

	Run 1	Run 2	Run 3
Date of run	02-21-96	02-21-96	02-21-96
Time run start/end.....(HRS)	830/ 938	1020/1127	1205/1310
Static pressure.....(IN.WC)	-0.72	-0.72	-0.72
Cross sectional area (SQ.FT)	36.23	36.23	36.23
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	316.0	309.0	305.0
desiccant.....(GRAMS)	13.0	13.0	14.0
total.....(GRAMS)	329.0	322.0	319.0
Formaldehyde in sample..(uG)	11000	12000	14000
Gas meter coefficient.....	1.0004	1.0004	1.0004
Barometric pressure..(IN.HG)	29.24	29.24	29.24
Avg. orif.pres.drop..(IN.WC)	2.42	2.51	2.53
Avg. gas meter temp..(DEF-F)	61.4	73.9	72.5
Volume through gas meter....			
at meter conditions...(CF)	53.71	55.20	55.48
standard conditions.(DSCF)	53.48	53.69	54.10
Total sampling time....(MIN)	64.00	64.00	64.00
Nozzle diameter.....(IN)	.275	.275	.275
Avg.stack gas temp ..(DEG-F)	257	258	265
Volumetric flow rate.....			
actual.....(ACFM)	132800	133593	133908
dry standard.....(DSCFM)	73922	74682	74407
Isokinetic variation.....(%)	99.3	98.7	99.8
CH2O concentration.....			
(MG/DSCM).....	7.31	7.95	9.20
(PPM-DRY).....	5.86	6.36	7.37
(PPM-WET).....	4.54	4.96	5.77
CH2O emission rate...(LB/HR)	2.02246	2.22083	2.56166

CH2O = Formaldehyde

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 12
Press Vent RTO Stack

Results of Formaldehyde Tests ----- EPA Method 0011

	Run 1	Run 2	Run 3
Date of run	02-22-96	02-22-96	02-22-96
Time run start/end.....(HRS)	1335/1436	1450/1551	1608/1708
Static pressure.....(IN.WC)	-0.49	-0.49	-0.49
Cross sectional area (SQ.FT)	31.09	31.09	31.09
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	-6.0	10.0	6.0
desiccant.....(GRAMS)	13.0	2.0	5.0
total.....(GRAMS)	7.0	12.0	11.0
Formaldehyde in sample..(uG)	690	560	670
Gas meter coefficient.....	1.0051	1.0051	1.0051
Barometric pressure..(IN.HG)	28.91	28.91	28.91
Avg. orif.pres.drop..(IN.WC)	2.30	2.44	2.43
Avg. gas meter temp..(DEF-F)	88.5	94.9	95.4
Volume through gas meter....			
at meter conditions...(CF)	52.04	53.80	53.96
standard conditions.(DSCF)	48.92	50.00	50.11
Total sampling time....(MIN)	60.00	60.00	60.00
Nozzle diameter.....(IN)	.250	.250	.250
Avg.stack gas temp ..(DEG-F)	239	240	240
Volumetric flow rate.....			
actual.....(ACFM)	103837	105677	105664
dry standard.....(DSCFM)	75191	76107	76165
Isokinetic variation.....(%)	98.9	99.9	100.1
CH2O concentration.....			
(MG/DSCM).....	0.50	0.40	0.48
(PPM-DRY).....	0.40	0.32	0.38
(PPM-WET).....	0.40	0.32	0.38
CH2O emission rate...(LB/HR)	0.14104	0.11338	0.13547

CH2O = Formaldehyde

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 16
Line 1 Thermal Oil Heater Stack

Results of Formaldehyde Tests ----- EPA Method 0011

	Run 1 02-22-96	Run 2 02-22-96	Run 3 02-22-96
Date of run			
Time run start/end.....(HRS)	900/1003	1053/1157	1303/1406
Static pressure.....(IN.WC)	-0.21	-0.21	-0.21
Cross sectional area (SQ.FT)	14.75	14.75	14.75
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	95.0	127.0	119.0
desiccant.....(GRAMS)	20.0	18.0	18.0
total.....(GRAMS)	115.0	145.0	137.0
Formaldehyde in sample..(uG)	130	150	130
Gas meter coefficient.....	1.0054	1.0054	1.0054
Barometric pressure..(IN.HG)	29.01	29.01	29.01
Avg. orif.pres.drop..(IN.WC)	2.66	2.45	2.49
Avg. gas meter temp..(DEF-F)	64.2	80.0	74.2
Volume through gas meter....			
at meter conditions...(CF)	53.28	51.72	52.10
standard conditions.(DSCF)	52.65	49.58	50.49
Total sampling time....(MIN)	60.00	60.00	60.00
Nozzle diameter.....(IN)	.434	.434	.434
Avg.stack gas temp ..(DEG-F)	378	383	380
Volumetric flow rate.....			
actual.....(ACFM)	22996	21863	22056
dry standard.....(DSCFM)	12735	11663	11906
Isokinetic variation.....(%)	99.0	101.8	101.5
CH2O concentration.....			
(MG/DSCM).....	0.09	0.11	0.09
(PPM-DRY).....	0.07	0.09	0.07
(PPM-WET).....	0.06	0.08	0.06
CH2O emission rate...(LB/HR)	0.00419	0.00469	0.00408

CH2O = Formaldehyde

A trailing '<' symbol indicates that the true value is less than or equal to the reported value

3.8 Results of Phenol Determinations

Test No. 3
Dryer RTO Stack

Results of Phenol Determinations -----

	Run 1	Run 2	Run 3
Date of run	02-20-96	02-20-96	02-20-96
Time run start/end.....(HRS)	1520/1620	1635/1735	1750/1850
Barometric pressure..(IN.HG)	28.68	28.68	28.68
Meter temperature....(DEG-F)	69.95	72.70	72.75
Meter correction coefficient	1.0004	1.0004	1.0004
Volume through gas meter.... at meter conditions...(CF)	45.850	45.700	45.950
standard conditions (DSCF)	44.024	43.654	43.889
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	23.69	24.02	23.80
Volumetric flow rate (DSCFM)	69019	68433	69057
Phenol in sample.....(uG)	840.00<	840.00<	840.00<
Phenol concentration..... (GR/10 ³ DSCF).....	0.2944<	0.2969<	0.2953<
(uG/DSCM).....	674.30<	680.02<	676.39<
(PPB-DRY).....	172.31<	173.77<	172.84<
(PPB-WET).....	131.49<	132.03<	131.71<
Phenol emis. rate(10 ⁻³ LB/HR)	174.161<	174.148<	174.797<

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Analysis performed according to NIOSH Method 3502

Test No. 19
Line 1 Thermal Oil Heater Stack

Results of Phenol Determinations -----

	Run 1	Run 2	Run 3
Date of run	02-21-96	02-21-96	02-21-96
Time run start/end.....(HRS)	0934/1038	1056/1158	1341/1441
Barometric pressure...(IN.HG)	29.24	29.24	29.24
Meter temperature....(DEG-F)	63.62	72.00	66.88
Meter correction coefficient	0.9997	0.9997	0.9997
Volume through gas meter....			
at meter conditions...(CF)	45.470	45.500	45.630
standard conditions (DSCF)	44.997	44.318	44.876
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	9.34	12.12	11.34
Volumetric flow rate (DSCFM)	12735	11663	11906
Phenol in sample.....(uG)	840.00<	840.00<	840.00<
Phenol concentration.....			
(GR/10 ³ DSCF).....	0.2880<	0.2925<	0.2888<
(uG/DSCM).....	659.72<	669.83<	661.50<
(PPB-DRY).....	168.58<	171.17<	169.04<
(PPB-WET).....	152.84<	150.42<	149.87<
Phenol emis. rate(10 ⁻³ LB/HR)	31.440<	29.235<	29.473<

A trailing '<' symbol indicates that the true value is less than or equal to the reported value

Analysis performed according to NIOSH Method 3502

3.9 Results of Benzene Determinations

Interpoll Labs Report No. 6-7318
Louisiana Pacific Corporation
Hayward, Wisconsin

Test No. 5
Dryer RTO Stack

Results of Benzene Determinations **Method 18**

	Run 1	Run 2	Run 3
Date of run	2-20-96	2-20-96	2-20-96
Time run start/end (HRS)	0950-1050	1149-1249	1320-1420
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	22.29	23.60	23.48
Oxygen content (%V/V)	16.2	16.9	16.3
Volumetric flow rate (DSCFM)	71993	70905	71496
Benzene concentration (ppm,d)	0.074	0.084	0.086
Benzene emission rate (LB/HR)	0.065	0.072	0.075

Interpoll Labs Report No. 6-7318

Louisiana Pacific Corporation

Hayward, Wisconsin

Test No. 15

Line 1 Thermal Oil Heater Stack

Results of Benzene Determinations ~~Method 18~~

	Run 1	Run 2	Run 3
Date of run	2-22-96	2-22-96	2-22-96
Time run start/end (HRS)	0900-1005	1053-1157	1303-1406
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	9.34	12.12	11.34
Oxygen content (%V/V)	14.6	12.1	12.6
Volumetric flow rate (DSCFM)	12735	11663	11906
Benzene concentration (ppm,d)	< 0.012	< 0.011	< 0.012
Benzene emission rate (LB/HR)	< 0.0019	< 0.0015	< 0.0017

3.10 PAH Sampling Data

Test No. 4
Dryer RTO Stack

Sampling Data for PAH Determinations-----SW846 Method 0010

	Run 1	Run 2	Run 3
Date of run	02-21-96	02-22-96	02-22-96
Time run start/end.....(HRS)	1730/2037	800/1102	1300/1556
Static pressure.....(IN.WC)	-0.72	-0.72	-0.72
Cross sectional area (SQ.FT)	36.23	36.23	36.23
Pitot tube coefficient.....	0.840	0.840	0.840
Water in sample gas			
condenser.....(ML)	661.0	660.0	699.0
impingers.....(GRAMS)	0.0	0.0	0.0
desiccant.....(GRAMS)	37.0	28.0	37.0
total.....(GRAMS)	698.0	688.0	736.0
Gas meter coefficient.....	1.0004	1.0004	1.0004
Barometric pressure..(IN.HG)	29.03	29.01	29.01
Avg. orif.pres.drop..(IN.WC)	1.59	1.62	1.65
Avg. gas meter temp..(DEF-F)	61.6	74.4	76.5
Volume through gas meter....			
at meter conditions...(CF)	114.85	117.34	118.39
standard conditions.(DSCF)	113.26	112.87	113.44
standard conditions..(NM ³)	3.207	3.196	3.212
Total sampling time....(MIN)	168.00	168.00	168.00
Nozzle diameter.....(IN)	.247	.247	.247
Avg.stack gas temp ..(DEG-F)	255	259	258
Volumetric flow rate.....			
actual.....(ACFM)	132019	132044	133239
dry standard.....(DSCFM)	73160	72971	72600
Isokinetic variation.....(%)	100.4	100.3	101.3

Test No. 14
Line 1 Thermal Oil Heater Stack

Sampling Data for PAH Determinations-----SW846 Method 0010

	Run 1	Run 2	Run 3
Date of run	02-20-96	02-21-96	02-21-96
Time run start/end.....(HRS)	1550/1905	835/1130	1329/1618
Static pressure.....(IN.WC)	-0.21	-0.21	-0.21
Cross sectional area (SQ.FT)	14.75	14.75	14.75
Pitot tube coefficient.....	0.840	0.840	0.840
Water in sample gas			
condenser.....(ML)	261.0	228.0	198.0
impingers.....(GRAMS)	0.0	0.0	0.0
desiccant.....(GRAMS)	43.0	49.0	57.0
total.....(GRAMS)	304.0	277.0	255.0
Gas meter coefficient.....	0.9985	1.0054	1.0054
Barometric pressure..(IN.HG)	28.48	29.24	29.24
Avg. orif.pres.drop..(IN.WC)	2.28	2.20	2.28
Avg. gas meter temp..(DEG-F)	66.9	64.0	72.5
Volume through gas meter....			
at meter conditions...(CF)	139.45	129.25	132.36
standard conditions.(DSCF)	133.54	128.62	129.64
standard conditions..(NM ³)	3.782	3.642	3.671
Total sampling time....(MIN)	160.00	160.00	160.00
Nozzle diameter.....(IN)	.453	.434	.434
Avg.stack gas temp ..(DEG-F)	349	359	378
Volumetric flow rate.....			
actual.....(ACFM)	19376	20449	21001
dry standard.....(DSCFM)	10862	11696	11836
Isokinetic variation.....(%)	101.3	98.7	98.3

3.11 Results of MDI Determinations

Test No. 11

Press Vent RTO Stack

Results of MDI Determinations

	Run 1	Run 2	Run 3
Date of run	2-22-96	2-22-96	2-22-96
Time run start/end (HRS)	0800-0913	0940-1052	1117-1229
Static Pressure (IN.WC)	-0.49	-0.49	-0.49
Cross Sectional area (SQ.FT)	31.09	31.09	31.09
Pitot tube coefficient	0.840	0.840	0.840
Water in sample gas			
condenser (ML)	0.0	39.0	41.0
impingers (GRAMS)	-37.0	-39.0	-39.0
desiccant (GRAMS)	63.0	11.0	13.0
total (GRAMS)	26.0	11.0	15.0
MDI in sample (ug)	< 6.2	< 6.2	< 6.2
Gas meter coefficient	1.0051	1.0051	1.0051
Barometric pressure (IN.HG)	28.91	28.91	28.91
Avg. orif.pres.drop (IN.WC)	0.73	0.70	0.75
Avg. gas meter temp (DEG-F)	75.1	87.2	93.6
Volume through gas meter			
at meter conditions (CF)	33.88	33.80	34.91
standard conditions (DSCF)	32.51	31.72	32.38
Total sampling time (MIN)	70.00	70.00	70.00
Nozzle diameter (IN)	0.187	0.187	0.187
Avg.stack gas temp (DEG-F)	234	233	234
Volumetric flow rate			
actual (ACFM)	105479	103456	104584
dry standard (DSCFM)	74678	74857	75110
Isokinetic variation (%)	101.4	98.7	100.5
MDI Concentration (ppm,d)	< 0.00065	< 0.00066	< 0.00065
MDI Emission Rate (LB/HR)	< 0.0019	< 0.0019	< 0.0019

APPENDIX A

RESULTS OF VOLUMETRIC FLOW RATE DETERMINATIONS

Test No. 1
Dryer RTO Stack

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-20-96
Time of Determination.....(HRS)	806
Barometric pressure.....(IN.HG)	28.48
Pitot tube coefficient.....	.84
Number of sampling ports.....	1
Total number of points.....	8
Shape of duct.....	Round
Stack diameter.....(IN)	81.5
Duct area.....(SQ.FT)	36.23
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.62
Avg. gas temp.....(DEG-F)	242
Moisture content.....(% V/V)	23.00
Avg. linear velocity.....(FT/SEC)	60.0
Gas density.....(LB/ACF)	.04959
Molecular weight.....(LB/LBMOLE)	29.32
Mass flow of gas.....(LB/HR)	388023
Volumetric flow rate.....	
actual.....(ACFM)	130405
dry standard.....(DSCFM)	71774

Test No. 3
Dryer RTO Stack

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-20-96
Time of Determination.....(HRS)	1532
Barometric pressure.....(IN.HG)	28.68
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	16
Shape of duct.....	Round
Stack diameter.....(IN)	81.5
Duct area.....(SQ.FT)	36.23
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.81
Avg. gas temp.....(DEG-F)	260
Moisture content.....(% V/V)	23.69
Avg. linear velocity.....(FT/SEC)	59.3
Gas density.....(LB/ACF)	.04854
Molecular weight.....(LB/LBMOLE)	29.33
Mass flow of gas.....(LB/HR)	375533
Volumetric flow rate.....	
actual.....(ACFM)	128935
dry standard.....(DSCFM)	69019

Test No. 3
Dryer RTO Stack

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-20-96
Time of Determination.....(HRS)	1753
Barometric pressure.....(IN.HG)	28.68
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	16
Shape of duct.....	Round
Stack diameter.....(IN)	81.5
Duct area.....(SQ.FT)	36.23
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.84
Avg. gas temp.....(DEG-F)	260
Moisture content.....(% V/V)	23.80
Avg. linear velocity.....(FT/SEC)	59.4
Gas density.....(LB/ACF)	.04853
Molecular weight.....(LB/LBMOLE)	29.34
Mass flow of gas.....(LB/HR)	376235
Volumetric flow rate.....	
actual.....(ACFM)	129203
dry standard.....(DSCFM)	69057

Test No. 7
Line 1 Core Dryer Duct

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-20-96
Time of Determination.....(HRS)	950
Barometric pressure.....(IN.HG)	28.48
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	42
Duct area.....(SQ.FT)	9.62
Direction of flow.....	UP
Static pressure.....(IN.WC)	-8
Avg. gas temp.....(DEG-F)	216
Moisture content.....(% V/V)	27.75
Avg. linear velocity.....(FT/SEC)	73.3
Gas density.....(LB/ACF)	.04958
Molecular weight.....(LB/LBMOLE)	29.38
Mass flow of gas.....(LB/HR)	125834
Volumetric flow rate.....	
actual.....(ACFM)	42299
dry standard.....(DSCFM)	22252

Test No. 7
Line 1 Core Dryer Duct

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-20-96
Time of Determination.....(HRS)	1140
Barometric pressure.....(IN.HG)	28.48
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	42
Duct area.....(SQ.FT)	9.62
Direction of flow.....	UP
Static pressure.....(IN.WC)	-8.7
Avg. gas temp.....(DEG-F)	223
Moisture content.....(% V/V)	21.64
Avg. linear velocity.....(FT/SEC)	72.3
Gas density.....(LB/ACF)	.05030
Molecular weight.....(LB/LBMOLE)	29.39
Mass flow of gas.....(LB/HR)	125932
Volumetric flow rate.....	
actual.....(ACFM)	41727
dry standard.....(DSCFM)	23520

Test No. 7
Line 1 Core Dryer Duct

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-20-96
Time of Determination.....(HRS)	1320
Barometric pressure.....(IN.HG)	28.48
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	42
Duct area.....(SQ.FT)	9.62
Direction of flow.....	UP
Static pressure.....(IN.WC)	-9
Avg. gas temp.....(DEG-F)	250
Moisture content.....(% V/V)	28.00
Avg. linear velocity.....(FT/SEC)	77.3
Gas density.....(LB/ACF)	.04707
Molecular weight.....(LB/LBMOLE)	29.41
Mass flow of gas.....(LB/HR)	126023
Volumetric flow rate.....	
actual.....(ACFM)	44627
dry standard.....(DSCFM)	22216

Test No. 8
Line 1 Surface Dryer Duct

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-20-96
Time of Determination.....(HRS)	950
Barometric pressure.....(IN.HG)	28.48
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	42
Duct area.....(SQ.FT)	9.62
Direction of flow.....	UP
Static pressure.....(IN.WC)	-9.5
Avg. gas temp.....(DEG-F)	210
Moisture content.....(% V/V)	30.84
Avg. linear velocity.....(FT/SEC)	73.5
Gas density.....(LB/ACF)	.04916
Molecular weight.....(LB/LBMOLE)	29.38
Mass flow of gas.....(LB/HR)	125186
Volumetric flow rate.....	
actual.....(ACFM)	42442
dry standard.....(DSCFM)	21479

Test No. 8
Line 1 Surface Dryer Duct

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-20-96
Time of Determination.....(HRS)	1140
Barometric pressure.....(IN.HG)	28.48
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	42
Duct area.....(SQ.FT)	9.62
Direction of flow.....	UP
Static pressure.....(IN.WC)	-9.5
Avg. gas temp.....(DEG-F)	224
Moisture content.....(% V/V)	30.87
Avg. linear velocity.....(FT/SEC)	77.6
Gas density.....(LB/ACF)	.04816
Molecular weight.....(LB/LBMOLE)	29.39
Mass flow of gas.....(LB/HR)	129444
Volumetric flow rate.....	
actual.....(ACFM)	44793
dry standard.....(DSCFM)	22195

Test No. 8
Line 1 Surface Dryer Duct

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-20-96
Time of Determination.....(HRS)	1320
Barometric pressure.....(IN.HG)	28.48
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	42
Duct area.....(SQ.FT)	9.62
Direction of flow.....	UP
Static pressure.....(IN.WC)	-9.5
Avg. gas temp.....(DEG-F)	232
Moisture content.....(% V/V)	31.01
Avg. linear velocity.....(FT/SEC)	74.8
Gas density.....(LB/ACF)	.04759
Molecular weight.....(LB/LBMOLE)	29.41
Mass flow of gas.....(LB/HR)	123320
Volumetric flow rate.....	
actual.....(ACFM)	43184
dry standard.....(DSCFM)	21107

Test No. 9
Press Vent RTO Stack

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-21-96
Time of Determination.....(HRS)	800
Barometric pressure.....(IN.HG)	29.24
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	20
Shape of duct.....	Round
Stack diameter.....(IN)	75.5
Duct area.....(SQ.FT)	31.09
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.48
Avg. gas temp.....(DEG-F)	245
Moisture content.....(% V/V)	1.81
Avg. linear velocity.....(FT/SEC)	53.9
Gas density.....(LB/ACF)	.05438
Molecular weight.....(LB/LBMOLE)	28.84
Mass flow of gas.....(LB/HR)	327849
Volumetric flow rate.....	
actual.....(ACFM)	100483
dry standard.....(DSCFM)	72126

Test No. 13
Line 1 Press RTO Inlet

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-21-96
Time of Determination.....(HRS)	1215
Barometric pressure.....(IN.HG)	29.24
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	24
Shape of duct.....	Round
Stack diameter.....(IN)	53.125
Duct area.....(SQ.FT)	15.39
Direction of flow.....	UP
Static pressure.....(IN.WC)	-6
Avg. gas temp.....(DEG-F)	115
Moisture content.....(% V/V)	1.26
Avg. linear velocity.....(FT/SEC)	91.9
Gas density.....(LB/ACF)	.06593
Molecular weight.....(LB/LBMOLE)	28.86
Mass flow of gas.....(LB/HR)	335699
Volumetric flow rate.....	
actual.....(ACFM)	84866
dry standard.....(DSCFM)	74064

Test No. 13
Line 1 Press RTO Inlet

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-21-96
Time of Determination.....(HRS)	1400
Barometric pressure.....(IN.HG)	29.24
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	24
Shape of duct.....	Round
Stack diameter.....(IN)	53.125
Duct area.....(SQ.FT)	15.39
Direction of flow.....	UP
Static pressure.....(IN.WC)	-6
Avg. gas temp.....(DEG-F)	113
Moisture content.....(% V/V)	1.25
Avg. linear velocity.....(FT/SEC)	92.5
Gas density.....(LB/ACF)	.06617
Molecular weight.....(LB/LBMOLE)	28.86
Mass flow of gas.....(LB/HR)	339001
Volumetric flow rate.....	
actual.....(ACFM)	85388
dry standard.....(DSCFM)	74787

Test No. 13
Line 1 Press RTO Inlet

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	02-21-96
Time of Determination.....(HRS)	1535
Barometric pressure.....(IN.HG)	29.24
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	24
Shape of duct.....	Round
Stack diameter.....(IN)	53.125
Duct area.....(SQ.FT)	15.39
Direction of flow.....	UP
Static pressure.....(IN.WC)	-6.5
Avg. gas temp.....(DEG-F)	111
Moisture content.....(% V/V)	1.28
Avg. linear velocity.....(FT/SEC)	91.4
Gas density.....(LB/ACF)	.06632
Molecular weight.....(LB/LBMOLE)	28.87
Mass flow of gas.....(LB/HR)	335830
Volumetric flow rate.....	
actual.....(ACFM)	84400
dry standard.....(DSCFM)	74063

Test No. 14
Line 1 Thermal Oil Heater Stack


Results of Volumetric Flow Rate Determination-----Method 2



Date of Determination.....	02-20-96
Time of Determination.....(HRS)	1545
Barometric pressure.....(IN.HG)	29.24
Pitot tube coefficient.....	.84
Number of sampling ports.....	1
Total number of points.....	10
Shape of duct.....	Round
Stack diameter.....(IN)	52
Duct area.....(SQ.FT)	14.75
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.21
Avg. gas temp.....(DEG-F)	349
Moisture content.....(% V/V)	9.70
Avg. linear velocity.....(FT/SEC)	22.3
Gas density.....(LB/ACF)	.04745
Molecular weight.....(LB/LBMOLE)	29.81
Mass flow of gas.....(LB/HR)	56140
Volumetric flow rate.....	
actual.....(ACFM)	19719
dry standard.....(DSCFM)	11351

APPENDIX B


LOCATION OF TEST PORTS


U.S. 401110





TYPICAL TEST PORT PLATFORM





HAYWARD, WI
 DRAWING 10
 LINE 1
 THERMAL OIL HEATER
 STACK
 ELEVATION

RELOCATE EXISTING SUPPORT
STAND FROM BETWEEN COLS. 38 & 39
TO BETWEEN COLS. 39 & 40
(PROVIDE DUCT SADDLES)

10'-0"
PLAN VIEW

P1
NOTE TWO TEST LOCATIONS
LINE 1 DRYER OUTLETS
N1
17'-6"


NEW DUCT TIE-IN POINT


CL PRIMARY
CYCLONE

CL PRIMARY
CYCLONE

30'-0"

~ 10'
RELOCATE EXISTING SUPPORT
STAND FROM BETWEEN COLS. 38 & 39
TO BETWEEN COLS. 39 & 40






HAYWARD, WI
DRAWING 7
PRESS RTO STACK
TYPICAL FOR BOTH LINES
ELEVATION

APPENDIX C

FIELD DATA SHEETS

TABLE OF CONTENTS


Dryer RTO Stack	1
Line 1 Core Dryer Duct	38
Line 1 Surface Dryer Duct	44
Press Vent RTO Stack	50
Line 1 Press RTO Inlet	72
Line 1 Thermal Oil Heater Stack	78
VE Observer Certification Sheet	112



EPA Method 2 Field Data Sheet

Drawing of Test Site

Job L.P. Hayward
Source Dryer RTO / Stack
Test 1 Run 0 Date 2-20-96
Stack Dimen. 81.5 IN.
Dry Bulb °F Wet bulb °F
Manometer ☒ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 28.48 IN.HG
Static Pressure -7.62 IN.WC
Operators E. J. Vers + J. Lorenz
Pitot No. 29V-8 C. 1840

[illegible]

Temp. Meas. Device & S/N: <u>PDT 42</u>	Time End: <u>0810</u> HRS
---	---------------------------

R or nothing - reg. manometer; S - expanded; E - electronic

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. / Hayward Date 2-20-96 Test 1 Run 1
Source Dryer RTO / Stack No. of traverse points 16
Method S Filter holder: Glass Filter type: 4" GF Filter

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: 0 cfm at 3 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

2352

☒ Acetone
☐ other(s)

No. of probe wash bottles:

1
EJ

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	7441	496	248
Impinger No. 3			
Condenser			
Desiccant	1481	1469	12
Total			260

Integrated Gas Sampling Data:

Bag Pump No. 29A Box No. S Bag No. 1
Bag Material: 5-layer Aluminized Tedlar Size: 44 L
Pretest leak check: 0 cc/min at 22 IN.HG
Time start: 0930 (HRS) Time end: 1057 (HRS)
Sampling rate: 400 cc/min Operator: EJ

S/N of O₂ Analyzer used to monitor train outlet:

36A

052394-G:\STACK\WPA\FORMS\S-0046RR

EPA Method 5 Field Data Sheet

Print No. 445-8

038.840

$$\frac{2}{2}$$

2-4

247

2000

2021

Nozzle No. _____

Nozzle Dia.

7 ml

13

in.WC

27

2

56.7

Operators

Meter Box

1.

丁

575

144

2

421

1000

[illegible]

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job C.P. Hayward
Source Dryer RTD /stock
Method 5 Filter holder: Glass

Date 2-20-96 Test 1 Run 2
No. of traverse points 16
Filter type: 4" G.F.

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: 0 cfm at 10 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

8353

☒ Acetone
☐ other(s)

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	766	500	266
Impinger No. 3			
Condenser			
Desiccant	1461	1450	11
Total			277

Integrated Gas Sampling Data:

Bag Pump No.

Bag Material:

Pretest leak check:

Time start:

Sampling rate:

29 A
5-layer Aluminized Tedlar
0
1140
400

Box No.

Size:

cc/min at

(HRS) Time end:

cc/min Operator:

5 Bag No. 2
44 L
22 IN.HG
1248 (HRS)
EJ

S/N of O₂ Analyzer used to monitor train outlet:

36A

052394-GASTACKWPF-FORMS5-0046RR

EPA Method 5, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125, 126, 127, 128, 129, 130, 131, 132, 133, 134, 135, 136, 137, 138, 139, 140, 141, 142, 143, 144, 145, 146, 147, 148, 149, 150, 151, 152, 153, 154, 155, 156, 157, 158, 159, 160, 161, 162, 163, 164, 165, 166, 167, 168, 169, 170, 171, 172, 173, 174, 175, 176, 177, 178, 179, 180, 181, 182, 183, 184, 185, 186, 187, 188, 189, 190, 191, 192, 193, 194, 195, 196, 197, 198, 199, 200, 201, 202, 203, 204, 205, 206, 207, 208, 209, 210, 211, 212, 213, 214, 215, 216, 217, 218, 219, 220, 221, 222, 223, 224, 225, 226, 227, 228, 229, 230, 231, 232, 233, 234, 235, 236, 237, 238, 239, 240, 241, 242, 243, 244, 245, 246, 247, 248, 249, 250, 251, 252, 253, 254, 255, 256, 257, 258, 259, 260, 261, 262, 263, 264, 265, 266, 267, 268, 269, 270, 271, 272, 273, 274, 275, 276, 277, 278, 279, 280, 281, 282, 283, 284, 285, 286, 287, 288, 289, 290, 291, 292, 293, 294, 295, 296, 297, 298, 299, 300, 301, 302, 303, 304, 305, 306, 307, 308, 309, 310, 311, 312, 313, 314, 315, 316, 317, 318, 319, 320, 321, 322, 323, 324, 325, 326, 327, 328, 329, 330, 331, 332, 333, 334, 335, 336, 337, 338, 339, 340, 341, 342, 343, 344, 345, 346, 347, 348, 349, 350, 351, 352, 353, 354, 355, 356, 357, 358, 359, 360, 361, 362, 363, 364, 365, 366, 367, 368, 369, 370, 371, 372, 373, 374, 375, 376, 377, 378, 379, 380, 381, 382, 383, 384, 385, 386, 387, 388, 389, 390, 391, 392, 393, 394, 395, 396, 397, 398, 399, 400, 401, 402, 403, 404, 405, 406, 407, 408, 409, 410, 411, 412, 413, 414, 415, 416, 417, 418, 419, 420, 421, 422, 423, 424, 425, 426, 427, 428, 429, 430, 431, 432, 433, 434, 435, 436, 437, 438, 439, 440, 441, 442, 443, 444, 445, 446, 447, 448, 449, 450, 451, 452, 453, 454, 455, 456, 457, 458, 459, 460, 461, 462, 463, 464, 465, 466, 467, 468, 469, 470, 471, 472, 473, 474, 475, 476, 477, 478, 479, 480, 481, 482, 483, 484, 485, 486, 487, 488, 489, 490, 491, 492, 493, 494, 495, 496, 497, 498, 499, 500, 501, 502, 503, 504, 505, 506, 507, 508, 509, 510, 511, 512, 513, 514, 515, 516, 517, 518, 519, 520, 521, 522, 523, 524, 525, 526, 527, 528, 529, 530, 531, 532, 533, 534, 535, 536, 537, 538, 539, 540, 541, 542, 543, 544, 545, 546, 547, 548, 549, 550, 551, 552, 553, 554, 555, 556, 557, 558, 559, 560, 561, 562, 563, 564, 565, 566, 567, 568, 569, 570, 571, 572, 573, 574, 575, 576, 577, 578, 579, 580, 581, 582, 583, 584, 585, 586, 587, 588, 589, 590, 591, 592, 593, 594, 595, 596, 597, 598, 599, 600, 601, 602, 603, 604, 605, 606, 607, 608, 609, 610, 611, 612, 613, 614, 615, 616, 617, 618, 619, 620, 621, 622, 623, 624, 625, 626, 627, 628, 629, 630, 631, 632, 633, 634, 635, 636, 637, 638, 639, 640, 641, 642, 643, 644, 645, 646, 647, 648, 649, 650, 651, 652, 653, 654, 655, 656, 657, 658, 659, 660, 661, 662, 663, 664, 665, 666, 667, 668, 669, 670, 671, 672, 673, 674, 675, 676, 677, 678, 679, 680, 681, 682, 683, 684, 685, 686, 687, 688, 689, 690, 691, 692, 693, 694, 695, 696, 697, 698, 699, 700, 701, 702, 703, 704, 705, 706, 707, 708, 709, 710, 711, 712, 713, 714, 715, 716, 717, 718, 719, 720, 721, 722, 723, 724, 725, 726, 727, 728, 729, 730, 731, 732, 733, 734, 735, 736, 737, 738, 739, 740, 741, 742, 743, 744, 745, 746, 747, 748, 749, 750, 751, 752, 753, 754, 755, 756, 757, 758, 759, 760, 761, 762, 763, 764, 765, 766, 767, 768, 769, 770, 771, 772, 773, 774, 775, 776, 777, 778, 779, 780, 781, 782, 783, 784, 785, 786, 787, 788, 789, 790, 791, 792, 793, 794, 795, 796, 797, 798, 799, 800, 801, 802, 803, 804, 805, 806, 807, 808, 809, 810, 811, 812, 813, 814, 815, 816, 817, 818, 819, 820, 821, 822, 823, 824, 825, 826, 827, 828, 829, 830, 831, 832, 833, 834, 835, 836, 837, 838, 839, 840, 841, 842, 843, 844, 845

121-602

File No. M5-5

Nozzle No. 247 in. 28.48 in. 116

Operators ES JK
Meter Box No. LO 411 @ 1.95 in. WC
Gas meter Coeff. 1.0004

Job L.P. Hayward
Source DR of ATO/stock
Date 3-20-96 Test 1 Run 2

Date 2-20-96 Test 1 Run 2

[illegible]

INTERPOL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job C.P. HaywardDate 2-20-96 Test 1 Run 3Source Dryer RTD /stackNo. of traverse points 16Method S Filter holder: GlassFilter type: 4" GFF

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0 cfm at 7 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

8354☒ Acetone☐ other(s)

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	757	496	261
Impinger No. 3			
Condenser			
Desiccant	1494	1481	13
Total			274

Integrated Gas Sampling Data:

Bag Pump No.

29A

Box No.

5 Bag No. 3

Bag Material:

5-layer Aluminized Tedlar

Size:

44 L

Pretest leak check:

0

cc/min at

22 IN.HG

Time start:

1320

(HRS) Time end:

1430 (HRS)

Sampling rate:


400

cc/min Operator:

ESS/N of O₂ Analyzer used to monitor train outlet:36A

052394-G:STACKWPF:FORMS-0046RR

Drawing of Test Site

Cross-section View 	Elevation View
---	-----------------------

R or nothing = reg. manometer; S = expanded; E = electronic

C-8

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 2-21-96 Test 2 Run 1
 Source Dryer RTO / stack No. of traverse points 16
 Method 2011 Filter holder: — Filter type: —

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: 0 cfm at 9 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☐ acetone —
☒ Other(s) MeCl₂

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	785	469	316
Impinger No. 3			
Condenser			
Desiccant	1417	1404	13
Total			329

Integrated Gas Sampling Data:

Bag Pump No. 29A
 Bag Material: 5-layer Aluminized Tedlar
 Pretest leak check: 0
 Time start: 0830
 Sampling rate: 900

Box No. 7 Bag No. 1
 Size: 44 L
 cc/min at 22 IN.HG
 (HRS) Time end: 0938 (HRS)
 cc/min Operator: ES

S/N of O₂ Analyzer used to monitor train outlet:36A

052394-C:STACK\WP\FORMS\5-0046RR

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job CP Hayward
 Source Dryer RTO/stack
 Method 0011 Filter holder: —

Date 2-21-96 Test 2 Run 2
 No. of traverse points 16
 Filter type: —

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0 cfm at 8 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used: —

Recovery solvent(s)

☐ acetone —
☒ other(s) meclz

No. of probe wash bottles: —Sample recovered by: EJ

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	785	476	309
Impinger No. 3			
Condenser			
Desiccant	1468	1455	13
Total			322

Integrated Gas Sampling Data:

Bag Pump No. 29A
 Bag Material: 5-layer Aluminized Tedlar
 Pretest leak check: 0
 Time start: 1020
 Sampling rate: 400

Box No. 7 Bag No. 2
 Size: 44 L
 cc/min at 22 IN.HG
 (HRS) Time end: 1127 (HRS)
 cc/min Operator: EJ

S/N of O₂ Analyzer used to monitor train outlet: —

052394-G:STACK\WP\FORMS\5-0046RR

EPA Method 5 Field Data Sheet

(612) 706-6020

Pistol No.	ans-1-8
C _p	840
H ₂ O	23
	%

Nozzle No.	Gloss
Nozzle Dia.	.275
Bar Press.	29.24

EPA Method 3 Field Data

Operators ES JL

Meter Box No. 10 All@ 1.95 In WC

Job _____
Source 6.P. Hayward
Date Dryer RTO / stock
2-21-96 Test 2 Run 2

[illegible]

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. HaywardDate 2-21-96 Test 2 Run 3Source Dryer RTO/stackNo. of traverse points 16Method 0011 Filter holder: —Filter type: —

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0 cfm at 2 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used: —

Recovery solvent(s)

☐ acetone —☒ other(s) MeCl₂No. of probe wash bottles: —Sample recovered by: —1 P.W., 1 Imp. Rinse
ES JL

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	784	479	305
Impinger No. 3			
Condenser			
Desiccant	1384	1370	14
Total			319

Integrated Gas Sampling Data:

Bag Pump No. 29ABox No. —Bag Material: 5-layer Aluminized TedlarSize: 44 LPretest leak check: 0

cc/min at

Time start: 1205(HRS) Time end: 1310Sampling rate: 400cc/min Operator: ES7 Bag No. 3S/N of O₂ Analyzer used to monitor train outlet: 36 A

052394-C:\STACK\WP\FORMSS-0046RR

EPA Method 5 Field Data Sheet

(612) 786-6020

Job L.P. Hayward
Source DYRC RTO / stock
Date 2-21-96 Test 2 Run 3

**Operators
Meter Box
Gasmeter**

Operators
Meter Box No.
Gasmeter Coeff.

75 JL
 1110 @ 1.95
 1.0004

2 in. WC

Nozzle No.
Nozzle Dia.
Bar. Press.

29.24

in

0.11

018.
22

[illegible]

INTERPOLL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Source

Test

Stack Dimen.

Dry Bulb

Manometer


Barometric Pressure

Static Pressure

Operators

Pitot No.

L.P. Hayward
Dryer RTD / Stack
3 Run Date 2-20-96
31.5 IN.
°F Wet bulb °F
☒ Reg. ☐ Exp ☐ Elec.
28.68 IN.HG
-81 IN.WC
E. J. Jurs + J. Lorenz
29V8 C-840



Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas (°F)
		Port Length: <u>6.25</u> IN.	Time Start: <u>1532</u> HRS		
<u>1</u>	<u>.4 m</u>	<u>15.75</u>	<u>22</u>		
<u>2</u>	<u>1.2 m</u>	<u>47.25</u>	<u>53.50</u>		
<u>3</u>	<u>2 m</u>	<u>78.75</u>	<u>85</u>		
		↑ Phenol Probe ↑			
		Flow Probe			
<u>E 1</u>	<u>.072</u>	<u>2.61</u>	<u>8.85</u>	<u>.68</u>	
<u>2</u>	<u>.105</u>	<u>8.56</u>	<u>14.8</u>	<u>.70</u>	
<u>3</u>	<u>.194</u>	<u>15.81</u>	<u>22.06</u>	<u>.74</u>	
<u>4</u>	<u>.323</u>	<u>26.32</u>	<u>32.51</u>	<u>.74</u>	
<u>5</u>	<u>.677</u>	<u>45.17</u>	<u>61.42</u>	<u>.73</u>	
<u>6</u>	<u>.806</u>	<u>65.68</u>	<u>71.93</u>	<u>.75</u>	
<u>7</u>	<u>.895</u>	<u>72.94</u>	<u>79.19</u>	<u>.69</u>	
<u>8</u>	<u>.968</u>	<u>78.89</u>	<u>85.14</u>	<u>.68</u>	
<u>B 1</u>				<u>.67</u>	<u>260</u>
<u>2</u>				<u>.69</u>	
<u>3</u>				<u>.72</u>	
<u>4</u>				<u>.72</u>	
<u>5</u>				<u>.76</u>	
<u>6</u>				<u>.77</u>	
<u>7</u>				<u>.79</u>	
<u>8</u>				<u>.74</u>	
Temp. Meas. Device & S/N: <u>PIT 42 & 47</u>				Time End: <u>1540</u> HRS	

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:\STACK\WP\FORMS\S-392.1

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 2-20-96 Test 3 Run 1
 Source Dryer RTO /stack No. of traverse points 3
 Method 5270 Filter holder: Glass Filter type: 4" GFFHR

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0 cfm at 9 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used: _____

Recovery solvent(s) _____

☐ acetone _____☐ other(s) _____

No. of probe wash bottles: _____

Sample recovered by: _____

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1 A	434	281	153
Impinger No. 2 A	242	175	67
Impinger No. 3 B	335	279	56
Condenser			
Desiccant	1414	1400	14
Total			290

Integrated Gas Sampling Data:

Bag Pump No. 29A
 Bag Material: 5-layer Aluminized Tedlar
 Pretest leak check: 0
 Time start: 1520
 Sampling rate: 400

Box No. 19 Bag No. 1
 Size: 44 L
 cc/min at 22 IN.HG
 (HRS) Time end: 1620 (HRS)
 cc/min Operator: EJ


S/N of O₂ Analyzer used to monitor train outlet: _____

052394-G:\STACK\WP\FORMS\S-0046RR

INTERPOL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Job L.P. Hayward
Source Dryer RTO stack
Test 3 Run 2 Date 2-20-96
Stack Dimen. 81.5 IN.
Dry Bulb — °F Wet bulb — °F
Manometer ☒ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 28.68 IN.HG
Static Pressure -.81 IN.WC
Operators E. Sifers & J. Lorenz.
Pitot No. 29V-E C_p .840



Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas (°F)
		Port Length:	6.25 IN.	Time Start:	1642 HRS
B 1				.66	
2				.70	
3				.70	
4				.72	
5				.74	
6				.77	
7				.77	
8				.74	
C 1				.68	
2				.70	
3				.74	
4				.72	
5				.72	
6				.72	
7				.71	
8				.67	
Temp. Meas. Device & S/N: PDT 42 + 47				Time End: 1649 HRS	

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:\STACK\WP\FORMS\S-392.1

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward
 Source Dryer RTO /stack
 Method 8270 Filter holder: Glass

Date 2-20-96 Test 3 Run 2
 No. of traverse points 3
 Filter type: 4" C.F.F.

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: 0 cfm at 11 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used: _____

Recovery solvent(s) _____

☐ acetone _____☐ other(s) _____

No. of probe wash bottles: _____

Sample recovered by: _____

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1 <u>A</u>	<u>448</u>	<u>281</u>	<u>167</u>
Impinger No. 2 <u>A</u>	<u>246</u>	<u>189</u>	<u>57</u>
Impinger No. 3 <u>B</u>	<u>335</u>	<u>279</u>	<u>56</u>
Condenser			
Desiccant	<u>1500</u>	<u>1487</u>	<u>13</u>
Total			<u>293</u>

Integrated Gas Sampling Data:


Bag Pump No. 29A
 Bag Material: 5-layer Aluminized Tedlar
 Pretest leak check: 0
 Time start: 1635
 Sampling rate: 900

Box No. 19 Bag No. 2
 Size: 44 L
 cc/min at 22 IN.HG
 (HRS) Time end: 1735 (HRS)
 cc/min Operator: EJ

S/N of O₂ Analyzer used to monitor train outlet: _____

052394-G:STACKWPAFORMSS-0046RR

Drawing of Test Site

Cross-section View 	Elevation View
---	-----------------------

[illegible]

032594-G:STACK/WP/FORMS-392.1

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP/HaywardDate 2-20-96 Test 3 Run 3Source Oryx RTO/StackNo. of traverse points 3Method 8270 Filter holder: GlassFilter type: 4" GFF

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0 cfm at 11 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used: _____

Recovery solvent(s) _____

☐ acetone _____☐ other(s) _____

No. of probe wash bottles: _____

Sample recovered by: _____

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. <u>1</u> A	<u>343</u>	<u>281</u>	<u>62</u>
Impinger No. <u>2</u> A	<u>338</u>	<u>184</u>	<u>154</u>
Impinger No. <u>3</u> B	<u>341</u>	<u>278</u>	<u>63</u>
Condenser			
Desiccant	<u>1460</u>	<u>1448</u>	<u>12</u>
Total			<u>291</u>

Integrated Gas Sampling Data:

Bag Pump No. 29 ABox No. 19Bag No. 3Bag Material: 5-layer Aluminized TedlarSize: 44 LPretest leak check: 0cc/min at 27 IN.HGTime start: 1730(HRS) Time end: 1850 (HRS)Sampling rate: 400cc/min Operator: ETS/N of O₂ Analyzer used to monitor train outlet: _____

052394-GASTACKIWP\FORMS\S-0046RR

EPA Method 4 and 6 Field Data Sheet

Job L.P. Hayward
 Date Dryer RTO/Stack
2-20-96 Test 3 Run 1
 Wet Bulb _____
 Dry Bulb _____

Operator(s) EJ JL
 Meter Box No. 10 Gasmeter Coef. 1.000%
 $\Delta H@$ 1.95 in.WC Bar.Press 28.68 in.Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 9 in.WC ☒

* M-8270 Phenol *

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	(1520)	(839.90)									
3	5	847.70	1.95	6	257	232	228	44	66	66	
	10	847.51	1.95	6	-	240	236	45	65	64	
	15	851.31	1.95	6	260	244	235	45	70	63	
	20	855.16	1.95	6	259	249	229	47	72	63	
2	25	858.97	1.95	6	256	227	230	49	75	62	
	30	862.78	1.95	6	249	230	229	51	76	63	
	35	866.60	1.95	6	251	232	227	53	78	63	
	40	870.43	1.95	6	271	226	231	53	80	65	
1	45	874.28	1.95	6	-	229	233	51	82	67	
	50	878.08	1.95	6	252	237	236	50	81	68	
	55	881.90	1.95	6	255	240	232	46	80	66	
	60	885.75	1.95	6	245	227	228	52	79	65	
	(1620)										
	0-60	V _m = 45.85	ΔH = 1.95		E = 255				E _m = 69.95		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers A	434	281	153
Condenser A	242	175	67
B	335	279	56
Desiccant	1414	1400	14
	Total		290

Preliminary Results of SO ₂ Concentration Determination	
V _m = 43.98	DSCF
Moisture Gravimetric = 23.69	%v/v
Moisture Psychrometric =	%v/v
SO ₂ , DRY =	PPM
SO ₂ , WET =	PPM
LB/MMBtu =	

EPA Method 4 and 6 Field Data Sheet

Job C.P. Hayward
 Source Dryer RTB / Stack
 Date 2-20-96 Test 3 Run 3
 Wet Bulb _____
 Dry Bulb _____

Operator(s) ES JL
 Meter Box No. 10 Gasmeter Coef. 1.000-1
 $\Delta H@$ 1.95 in.WC Bar.Press 28.68 in.
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 11 in.WC ☒

* M-8270 Phenol *

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	(1635)	(886.00)									
3	5	889.81	1.95	6	260	225	228	54	69	66	
	10	893.58	1.95	6	264	226	231	51	76	65	
	15	897.41	1.95	6	261	230	236	50	77	65	
	20	901.21	1.95	6	263	234	228	47	80	67	
2	25	905.04	1.95	6	256	229	228	52	80	67	
	30	908.85	1.95	6	265	228	234	49	80	66	
	35	912.67	1.95	6	249	229	228	50	80	67	
	40	916.45	1.95	6	248	238	228	50	82	69	
1	45	920.30	1.95	6	251	237	229	49	81	68	
	50	924.10	1.95	6	260	239	231	50	79	67	
	55	927.92	1.95	6	263	236	229	51	80	67	
	60	931.71	1.95	6	271	249	226	51	80	67	
	(1735)										
	0-60	V _m - 45.71	ΔP - 1.95		260.8					E - 727	

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers A	448	281	167
Condenser A	246	189	57
B	335	279	56
Desiccant	1500	1487	13
	Total		293

Preliminary Results of SO ₂ Concentration Determination		
V _m -	43.66	DSCF
Moisture Gravimetric -	24.02	%v/v
Moisture Psychrometric -		%v/v
SO ₂ , DRY -		PPM
SO ₂ , WET -		PPM
LB/MMBtu -		

EPA Method 4 and 6 Field Data Sheet

Lab C.P. Hayward
 Site Dryer RTO/Stack
 Date 2-20-96 Test 3 Run 3
 Wet Bulb _____
 Dry Bulb _____

Operator(s) EJ JL
 Meter Box No. 10 Gasmeter Coef. 10004
 $\Delta H@$ 1.95 in.WC Bar.Press 28.68 in.Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 11 in.WC ☒

m-8270 Phenol

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	(1750)	(932.10)									
3	5	935.97	1.95	6	249	231	228	47	69	68	
	10	939.75	1.95	6	260	245	230	46	73	66	
	15	943.59	1.95	6	247	246	228	48	76	66	
	20	947.45	1.95	6	248	246	226	49	77	66	
2	25	951.25	1.95	6	272	242	233	49	78	66	
	30	954.08	1.95	6	268	-	-	-	80	67	
	35	958.89	1.95	6	260	242	226	48	80	67	
	40	962.75	1.95	6	252	242	230	49	80	68	
1	45	966.58	1.95	6	262	249	239	49	81	68	
	50	970.40	1.95	6	264	246	234	49	80	68	
	55	974.22	1.95	6	255	251	232	51	81	68	
	60	978.05	1.95	6	251	247	234	51	83	70	
	(1850)										
	$t = 60$	$V_m = 95.95$	$\Delta H = 1.95$		$\bar{t} = 247.3$				$\bar{t}_m = 72.75$		

Condensate Data:


Item	Weight (g)		
	Final	Tare	Difference
Impingers A	343	281	62
Condenser A	338	181	154
B	341	278	63
Desiccant	1460	1448	12
		Total	291

Preliminary Results of SO ₂ Concentration Determination		
$V_m =$	43.889	DSCF
Moisture Gravimetric =	23.80	%v/v
Moisture Psychrometric =		%v/v
SO ₂ DRY =		PPM
SO ₂ WET =		PPM
LB/MMBtu =		

INTERPOL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Job L.P. Hayward
Source Dryer RTO / Stack
Test 4 Run 0 Date 2-21-96
Stack Dimen. 81.5 IN.
Dry Bulb °F Wet bulb °F
Manometer ☒ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 29.03 IN.HG
Static Pressure -72 IN.WC
Operators E. J. & J. Lorenz
Pitot No. 22V-B C .840

Drawing of Test Site

[illegible]

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:\STACK\WP\FORMS\S-392.1

INTERPOL LABORATORIES, INC.

(612) 786-6020

EPA Modified Method 5 Sample Log Sheet

Job L.P. Hayward
 Source Dryer Rto Stack
 Cyclone ☐ Yes ☒ No
 Analytes PAH's
 Field Recovery Spike Added

Date 2-21-96
 No. Of Traverse Points
 Filter Holder MMS
 XAD - 2 Resin g
☒ Yes ☐ No

Test 4 Run 1
16 x 3
 Filter Type 4" Glass Fiber
 Batch No.
 Ref. EPA SW-846 Method 0010

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: 0 cfm at 16 IN.HG (vac) ☒

Semivolatile Catch Data:

No. of filters used:

690

Recovery solvent(s)

☒ MeCl₂ * MeOH (50:50 v/v)
☒ Other(s) Acetone

No. of bottles for condensate trap catch
 Samples recovered by

2
ES

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Condensate Trap	758	266	492
Condensate Trap	435	266	169
Condensate Trap			
Impingers			
Desiccant	1414	1477	37
Total			699

Integrated Gas Sampling Data:

Bag Pump No. 29A
 Bag Material: 4-layer Aluminized Tedlar
 Pretest Leak Check: 0 cc/min at
 Time Start: 1730 (HRS)
 Sampling Rate: 150 cc/min

Box No. 15

Bag No. 1
 Size: 44 L
22 INHG
 Time End: 2037 (HRS)
 O₂ Analyzer S/N 4

032194-G:STACK\WP\FORMS\S-393

INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Modified Method 5 Field Data Sheet

Job C.P. Hayward Operators ES JZ Nozzle No. 3-4 Pilot No. 22V-8
 Source Dryer HTO / Stack Meter Box No. 10 ΔH@ 1.95 in. WC Nozzle Dia. .247 in. C_p .810
 Date 2-21-96 Test 4 Run 1 Gasmer Coeff. 1.0004 Bar. Pres. 29.03 in. Hg H₂O 22 %

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)						Oxygen (% v/v)	
							Stack	Probe	Oven	XAD-2	Imp.	Meter (In/Out)		
	(1730)	(154.20)												
8	35	156.60	.82	1.67	6.64	10	260	227	225	358	37	38		16.2
8	7	158.95	.82	1.61	8.99	11	254					40	37	16.3
8	10.5	161.30	.80	1.89	1.32	12	250	232	226	36		42	37	16.2
7	14	163.65	.83	1.64	3.69	13	254					45	37	16.6
7	17.5	166.05	.84	1.65	6.08	13	259	236	230	38	37	47	37	15.0
7	21	168.46	.84	1.68	8.49	13	247					49	38	16.7
6	24.5	170.54	.83	1.66	0.88	13	252	235	227	38	37	51	37	16.4
6	28	173.31	.84	1.67	3.29	13	255					51	35	17.6
6	31.5	175.71	.82	1.64	5.67	13	249	240	225	38	36	54	36	17.1
5	35	178.07	.80	1.58	8.01	13	262					56	38	16.9
5	38.5	180.43	.80	1.59	0.36	13	261	233	226	37	35	59	39	16.9
5	42	182.78	.78	1.55	2.69	13	262					60	40	17.0
4	45.5	185.09	.73	1.49	4.98	13	245	237	230	38	36	62	42	16.8
4	49	187.40	.74	1.50	7.28	13	252			3	35	63	43	17.0
4	52.5	189.73	.75	1.52	9.60	13	255	252	230	36	35	62	43	16.8
3	56	192.03	.73	1.47	1.87	13	257					67	46	16.7
3	59.5	194.31	.72	1.47	4.16	13	256	238	226	36	35	69	49	16.3
3	63	196.66	.72	1.48	6.46	13	252					70	50	15.8
2	66.5	198.91	.73	1.50	8.77	13	255	241	234	37	34	71	52	15.8
2	70	201.17	.70	1.44	1.04	12.5	256					72	53	16.3
2	73.5	203.45	.69	1.45	3.32	12.5	243	232	231	36	35	73	54	16.1
1	77	205.65	.65	1.35	5.53	12	253					73	57	15.9
1	80.5	207.93	.66	1.37	7.75	12	255	237	229	37	35	74	59	16.0
1	84	210.13	.63	1.31	9.93	12	252					74	59	16.0
over														
	θ = -	V _m = -		ΔH = -									AVG. = -	

Paul 1 OF 2

INTERPOLL LAB SERVICES, INC.

(612) 780-6020

EPA Modified Method 5 Field Data Sheet

Pilot No. 22 V-8
 C_p 810
 H₂O 22 %

Nozzle No. 3-4
 Nozzle Dia. .247 in.
 Bar. Pres. 29.03 in. Hg

Operators C.P. Hayward
 Meter Box No. 10 ΔH@ 1.95 in. WC
 Gas Meter Coeff. 1.0001

Job Dryer RPD/Stack
 Source 2-2-96 Test 4 Run 1
 Date

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)						Oxygen (% v/v)	
							Stack	Probe	Oven	XAD-2	Imp.	Meter (In/Out)		
	(cont-)	(cont-)												
A 8	87.5	212.50	.77	1.60	2.34	13	255	241	232	36	34	67	56	16.8
8	91	214.80	.81	1.66	4.78	14	258					72	57	16.4
8	94.5	217.25	.80	1.64	7.21	14	261	240	232	38	37	73	58	16.2
7	98	219.70	.82	1.70	9.69	14	256					75	60	16.5
7	101.5	222.15	.80	1.65	2.14	14	260	252	229	38	37	74	59	16.7
7	105	224.64	.82	1.68	4.60	15	265					76	61	16.1
6	108.5	227.15	.82	1.70	7.09	15	259	244	233	39	38	77	63	16.2
6	112	229.61	.80	1.68	9.56	15	253					78	66	15.7
6	115.5	232.11	.82	1.72	2.07	15	255	256	226	39	37	78	67	15.7
5	119	234.60	.81	1.69	4.56	15	259					78	67	15.8
5	122.5	237.10	.79	1.65	7.02	15	260	249	234	38	37	77	67	16.3
5	126	239.58	.80	1.69	9.50	15	251					77	67	16.0
4	129.5	241.40	.77	1.62	1.94	14	252	254	231	34	33	73	69	16.8
4	133	244.83	.76	1.60	4.35	14	253					76	69	16.7
4	136.5	247.28	.78	1.64	6.80	14	253	242	230	38	36	79	70	16.5
3	140	249.69	.80	1.67	9.28	14	261					79	70	16.5
3	143.5	251.14	.81	1.70	1.78	14	260	262	235	37	35	80	71	16.5
3	147	254.60	.80	1.69	4.27	15	257					80	72	16.5
2	150.5	257.10	.80	1.70	6.78	15	250	264	231	36	35	79	71	16.7
2	154	259.59	.79	1.68	9.26	15	251					79	71	16.7
2	157.5	262.07	.79	1.67	1.74	15	254	260	235	37	35	79	71	16.9
1	161	264.54	.74	1.56	4.14	15	254					78	70	16.8
1	164.5	266.98	.72	1.51	6.49	15	257	249	231	39	36	79	71	17.0
1	168	269.44	.74	1.55	8.88	14	260					80	72	16.7
	(20.37)	235.05												
	0-168	V _m = 114.85		1.59								AVG. =	61.6	

C-27

Note
 * Bottom
 stop
 156
 start

* Empty Condensate Trap
 Check check - 0 cfm at 15 in Hg
 Page 2 of 2

INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Modified Method 5 Sample Log Sheet

Job C.P. Hayward Date 2-22-96 Test 4 Run 2
 Source Dryer RTO/Stack No. Of Traverse Points 16
 Cyclone ☐ Yes ☒ No Filter Holder MM5 Filter Type 4" Glass Fiber
 Analytes PAH's XAD - 2 Resin g Batch No. _____
 Field Recovery Spike Added ☒ Yes ☐ No Ref. EPA SW-846 Method 0010

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: 0 cfm at 14 IN.HG (vac) ☒

Semivolatile Catch Data:

No. of filters used:

693

Recovery solvent(s)

☒ MeCl₂ * MeOH (50:50 v/v)
☒ Other(s) Aceton?

No. of bottles for condensate trap catch
 Samples recovered by

2
ET

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Condensate Trap	591	266	325
Condensate Trap	602	267	335
Condensate Trap			
Impingers			
Desiccant	1445	1417	28
Total			688

Integrated Gas Sampling Data:

Bag Pump No. 29A Box No. 15 Bag No. 2
 Bag Material: 4-layer Aluminized Tedlar Size: 44 L
 Pretest Leak Check: 0 cc/min at 22 INHG
 Time Start: 0900 (HRS) Time End: 1102 (HRS)
 Sampling Rate: 150 cc/min O₂ Analyzer S/N 9

032194-G\STACK\WP\FORMS\S-393

EPA Modified Method 5 Field Data Sheet

Pilot No. 22V-6
C₀ 840
H₂O 22

Nozzle No. 3-4
Nozzle Dia. 2.47 in.
Bar. Pres. 24.01 in. Hg

Operators E.S. J.L.
Meter Box No. 10 AH@ 1.95 in. WC
Gas meter Coeff. 1.0004

Job L.P. Hayward
Source Digger RTO / Stack
Date 2-22-96 Test 4 Run 2

Date 2-22-96 Test 4 Run 2 Gasmeter Cdn.														
Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)					Meter (In/Out)	Oxygen (% v/v)	
							Stack	Probe	Oven	XAD-2	Imp.			
	(0800)	(280.80)												
A 8	3.5	283.08	.76	1.55	3.15	8	260	234	231	34	32	42	34	17.4
8	7	285.34	.79	1.54	5.44	8	263					50	34	17.1
8	10.5	287.69	.78	1.52	7.74	9	267	232	227	37	36	54	37	16.7
7	14	290.10	.82	1.62	0.11	9	264					60	40	16.3
7	17.5	292.41	.84	1.67	2.52	9	266	233	227	38	37	64	42	16.4
7	21	294.79	.81	1.63	4.92	9.5	261					66	42	17.0
6	24.5	297.21	.80	1.63	7.31	10	256	233	230	38	36	68	43	16.8
6	28	299.60	.81	1.62	9.71	10	267					69	46	17.1
6	31.5	302.04	.80	1.61	2.11	10	264	229	232	37	37	71	48	17.2
5	35	304.40	.77	1.57	4.48	10	257					72	49	16.7
5	38.5	306.75	.78	1.59	6.87	10	260	234	234	37	36	75	53	16.5
5	42	309.23	.79	1.61	9.28	10	265					76	54	16.2
4	45.5	311.63	.77	1.60	1.69	10	252	238	237	36	35	76	54	16.3
4	49	314.06	.77	1.60	4.09	10	255					77	55	16.6
4	52.5	316.48	.79	1.64	6.52	10	254	237	236	35	35	79	58	16.6
3	56	318.89	.77	1.58	8.92	10	269					81	54	16.6
3	59.5	321.28	.81	1.66	1.38	10	268	233	237	36	37	81	60	16.6
3	63	323.72	.80	1.66	3.84	10	262					82	61	17.0
2	66.5	326.13	.77	1.60	6.26	10	261	234	229	38	37	84	63	16.5
2	70	328.55	.77	1.60	8.69	10	264					84	64	16.6
2	73.5	330.96	.75	1.56	1.08	10	266	237	231	37	36	85	65	16.4
1	77	333.34	.72	1.52	3.45	10	254					85	66	17.0
1	80.5	334.77	.75	1.59	5.86	10	255	230	233	38	37	86	67	16.7
1	84	338.15	.72	1.53	8.29	10	253					87	68	16.9
		Cont.												
	0 - -	V _m - -		ΔH -								Avg. -	-	

Pg. 2 of 2

INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Modified Method 5 Field Data Sheet

Job L.P. Hayward Operators ES JCL Nozzle No. 3-4 Pilot No. 22V-8
 Source Dryer RTO/stack Meter Box No. 10 ΔH @ 1.95 in.WC Nozzle Dia. .297 in. C_p .840
 Date 2-28-96 Test 4 Run 2 Gas Meter Coeff. 1.0004 Bar. Pres. 29.01 in.Hg H_2O 22 %

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)						Oxygen (% v/v)	
							Stack	Probe	Oven	XAD-2	Imp.	Meter (In/Out)		
	(-)	(-)												
B 8	87.5	340.48	.83	1.76	0.79	10	256	242	234	36	34	79	73	16.9
8	91	343.36	.84	1.77	3.34	11	257					84	72	16.9
8	94.5	345.45	.83	1.75	5.88	11	261	237	236	37	36	87	73	16.8
7	98	348.51	.85	1.82	8.48	11.5	253					89	77	16.6
7	101.5	341.18	.85	1.82	1.09	11.5	256	258	235	37	36	89	77	16.7
7	105	353.79	.85	1.83	3.70	11.5	252					91	78	16.6
C	108.5	346.41	.83	1.78	6.28	11	256	253	250	38	36	90	78	16.5
6	112	358.03	.82	1.76	8.85	11	255					92	79	16.7
6	115.5	361.69	.83	1.79	1.44	11	252	261	252	39	38	91	79	16.7
5	119	364.21	.81	1.74	4.00	11	255					91	80	16.5
5	122.5	366.71	.79	1.70	6.52	11	257	261	256	38	37	93	80	16.7
5	126	369.34	.78	1.68	9.03	11	258					92	80	16.8
4	129.5	371.71	.73	1.56	1.45	10.5	262	255	250	38	37	93	81	16.3
4	133	374.35	.75	1.60	3.90	10.5	264					94	83	16.6
4	136.5	376.85	.74	1.59	6.35	10.5	260	252	251	37	35	94	82	16.8
3	140	378.35	.74	1.59	8.80	10.5	258					94	83	16.5
3	143.5	381.82	.74	1.60	1.26	10	255	256	242	38	37	94	83	16.7
3	147	384.27	.73	1.58	3.70	10	255					95	84	16.4
2	150.5	386.67	.72	1.57	6.14	10	253	245	248	39	38	95	84	16.3
2	154	388.98	.69	1.51	8.52	10	251					96	86	16.3
2	157.5	390.52	.69	1.49	0.90	10	260	242	250	37	36	95	85	16.4
1	161	393.83	.65	1.42	3.22	9	252					95	84	16.4
1	164.5	396.15	.64	1.39	5.51	9	255	245	244	38	37	94	84	16.8
1	168	398.37	.63	1.37	7.78	9	253					94	84	16.5
	(1102)	398.14												
	0 - 168	$V_m = 117.34$		$\Delta H = 1.62$								Avg. = 74.5		

INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Modified Method 5 Sample Log Sheet

Job C.P. Hayward
 Source Dryer RTO /stack
 Cyclone ☐ Yes ☒ No
 Analytes PAH's
 Field Recovery Spike Added

Date 2-22-96
 No. Of Traverse Points
 Filter Holder MM5
 XAD - 2 Resin g
☒ Yes ☐ No

Test 4 Run 3
16
 Filter Type 4" Glass Fiber
 Batch No.
 Ref. EPA SW-846 Method 0010

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: 0 cfm at 13 IN.HG (vac) ☒

Semivolatile Catch Data:

No. of filters used:

694

Recovery solvent(s)

☒ MeCl₂ * MeOH (50:50 v/v)
☒ Other(s) Acetone

No. of bottles for condensate trap catch
 Samples recovered by

2
ES

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Condensate Trap	<u>603</u>	<u>266</u>	<u>337</u>
Condensate Trap	<u>626</u>	<u>264</u>	<u>362</u>
Condensate Trap			
Impingers			
Desiccant	<u>1523</u>	<u>1486</u>	<u>37</u>
Total			<u>736</u>

Integrated Gas Sampling Data:

Bag Pump No. 29A
 Bag Material: 4-layer Aluminized Tedlar
 Pretest Leak Check: 0 cc/min at
 Time Start: 1300 (HRS)
 Sampling Rate: 150 cc/min

Box No. 15

Bag No. 3
 Size: 44 L

22 INHG
 Time End: 1556 (HRS)
 O₂ Analyzer S/N 4

032194-GASTACK\WP\FORMS\S-393

EPA Modified Method 5 Field Data Sheet

Pilot No.	22V-8
C _p	.840
H ₂ O	23%

Nozzle No. 3-4
Nozzle Dia. .247 in.
Bar. Pres. 29.01 in.Hg

Operators ES JL
Meter Box No. 10 ΔH@ 1.95 in.WC
Gasmeter Coeff. 1.0004

Job	C.P. Hayward
Source	Dryer RTO / Stack
Date	2-22-96 Test 4 Run 3

[illegible]

Emotab, condensate

$$V_{\text{out}} = 0.5 V_{\text{in}} = 12 \text{ in. Hg}$$

EPA Modified Method 5 Field Data Sheet

Job

Source

Date

L.P. Hayward
Dryer Rto / Stack
2-22-96 Test 4 Run 3

Operators ES JZ
 Meter Box No. 10 $\Delta H @$ 1.95 in. WC
 Gas meter Coeff. 1.0004

Nozzle No. 3-4
 Nozzle Dia. .247 in.
 Bar. Pres. 29.01 in. Hg

Pitot No. 22V-8
 C_p .840
 H_2O 22 %

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)				Imp.	Meter (In/Out)	Oxygen (% v/v)
							Stack	Probe	Oven	XAD-2			
	(cont.)	(cont.)											
A 8	87.5	459.46	.79	1.67	9.19	10	260	234	236	35	33	79	16.3
8	91	461.92	.78	1.64	1.66	8.5	258					86	16.2
8	94.5	464.35	.77	1.64	4.12	8.5	255	238	229	37	36	87	15.9
7	98	466.83	.81	1.73	6.65	8.5	258					89	16.2
7	101.5	469.33	.82	1.75	9.20	9	258	239	226	37	36	89	15.9
7	105	471.84	.80	1.69	1.71	9	264					90	16.1
6	108.5	474.39	.85	1.80	4.30	10	263	245	251	37	36	90	16.1
6	112	476.98	.85	1.81	6.90	10	257					90	16.2
6	115.5	479.65	.87	1.83	9.52	10	267	237	242	38	36	90	16.3
5	119	482.21	.81	1.72	2.05	10	262					90	16.3
5	122.5	484.82	.82	1.74	4.60	9.5	261	236	226	38	37	90	16.3
5	126	487.36	.80	1.72	7.13	9.5	255					90	16.6
4	129.5	489.94	.80	1.73	9.67	9.5	251	235	232	37	36	90	16.7
4	133	492.50	.80	1.71	2.20	9.5	257					90	16.7
4	136.5	494.99	.77	1.64	4.68	9	260	241	234	36	34	91	16.6
3	140	497.59	.79	1.70	7.20	9	253					91	16.7
3	143.5	499.50	.78	1.68	9.71	9	251	236	220	39	37	91	16.5
3	147	502.68	.79	1.69	2.23	9	258					92	16.5
2	150.5	504.71	.78	1.65	4.71	9	268	232	227	37	37	92	16.4
2	154	507.20	.79	1.67	7.22	9	267					92	16.7
2	157.5	509.19	.79	1.70	9.74	9	254	228	231	38	37	92	16.9
1	161	512.57	.72	1.53	2.14	8	266					91	16.5
1	164.5	514.90	.75	1.60	4.58	8.5	260	230	231	38	37	91	16.7
1	168	517.28	.76	1.63	7.05	8.5	258					92	16.8
	(1556)	517.09											
	0 - 108	$V_m = 118.39$		$\Delta H = 1.65$								Avg. = 76.5	

INTERPOLL LABORATORIES

Benzene - 18 Field Data Sheet

Job L.P. HaywardOperator(s) E. J. JURS & J. LOMINZSource Driver RTO / stackMeter Box No. 65 Meter coef. 1.0036Date 2-20-96 Test 5 Run 1Barometric Pressure 28.48 in.Hg

Sample Train Leak Check:

Pretest: 0 cc/min at 15 in.HgPosttest: 0 cc/min at 15 in.Hg

Trav. Point No.	Samp. Time (min)	Sample Volume (cf)	Sample Rate (cc/min)	VAC. (inHg)	Temperature (oF)		
					Stack	Probe	Gasmeter
	(0950)	(466.403)					
	5	466.584	1000	3	257	—	58
	10	466.755	1000	3	247	—	58
	15	466.910	1000	3	245	—	58
	20	467.100	1000	4	261	—	59
	25	467.302	1000	5	258	—	60
	30	467.499	1000	7	262	—	60
	35	467.695	1000	7	259	—	61
	40	467.897	1000	7.5	260	—	62
	45	468.091	1000	8	268	—	68
	50	468.292	1000	8	265	—	69
	55	468.487	1000	8	265	—	70
	60	468.683	1000	8	255	—	72
	$\theta = 60$	$V_m = 2.28$					$t_m = 63$

(1040)

 $V_{STD} = 2.20$

S-476

INTERPOLL LABORATORIES

Benzene-18 Field Data SheetJob G.P. HaywardOperator(s) EJ JLSource Dryer RTO / StackMeter Box No. 65 Meter coef. 10036Date 2-20-90 Test 5 Run 2Barometric Pressure 28.40 in.Hg

Sample Train Leak Check:

Pretest: 0 cc/min at 15 in.HgPosttest: 0 cc/min at 15 in.Hg

Trav. Point No.	Samp. Time (min)	Sample Volume (cf)	Sample Rate (cc/min)	VAC. (inHg)	Temperature (oF)		
					Stack	Probe	Gasmeter
	(1149)	(462.712)					
	5	468.910	1000	3	262	—	69
	10	469.100	1000	5	264	—	69
	15	469.291	1000	7	256	—	69
	20	469.483	1000	8	272	—	69
	25	469.675	1000	9	272	—	69
	30	469.870	1000	9	261	—	70
	35	470.064	1000	9	247	—	70
	40	470.261	1000	9	258	—	71
	45	470.459	1000	9.5	269	—	71
	50	470.657	1000	10	268	—	72
	55	470.845	1000	10	269	—	76
	60	471.040	1000	10	260	—	78
	$\phi = 60$	$V_m = 2.326$					$t_m = 71$

(1249)

 $V_{STD} = 2.21$

S-476

INTERPOLL LABORATORIES

Benzene - 18 Field Data Sheet

Job LP Hayward Operator(s) ES JL
 Source Dryer RTD / Stack Meter Box No. 65 Meter coef. 1.0036
 Date 2-20-96 Test 5 Run 3 Barometric Pressure 28.48 in.Hg

Sample Train Leak Check:

Pretest: 0 cc/min at 15 in.HgPosttest: 0 cc/min at 15 in.Hg

Trav. Point No.	Samp. Time (min)	Sample Volume (cf)	Sample Rate (cc/min)	VAC. (inHg)	Temperature (oF)		
					Stack	Probe	Gasmeter
	(1320)	(471.071)					
	5	471.265	1000	4	263	—	80
	10	471.456	1000	5	284	—	80
	15	471.642	1000	7	269	—	79
	20	471.828	1000	9	265	—	80
	25	472.026	1000	11	256	—	80
	30	472.225	1000	12	251	—	80
	35	472.420	1000	12	262	—	80
	40	472.615	1000	12	269	—	80
	45	472.801	1000	12	265	—	80
	50	472.990	1000	12	256	—	83
	55	473.185	1000	12	247	—	86
	60	473.379	1000	12	252	—	86
	$\theta = 60$	$V_m = 2.306$					$t_m = 8.16$

(1420)

 $V_{STD} = 2.15$

S-476

Visible Emissions Form

SOURCE NAME <u>Louisiana-Pacific Corp</u>		OBSERVATION DATE <u>Feb. 20, 1996</u>		START TIME <u>0950</u>		STOP TIME <u>1050</u>	
ADDRESS <u>Hwy 163</u>		SEC MIN		SEC MIN		SEC MIN	
		0 15 30 45		0 15 30 45		0 15 30 45	
CITY <u>Hayward</u>		STATE <u>WI</u>		ZIP			
PHONE		SOURCE ID NUMBER					
PROCESS EQUIPMENT <u>Line 1 Drier Stack</u>		OPERATING MODE					
CONTROL EQUIPMENT <u>RTO</u>		OPERATING MODE					
DESCRIBE EMISSION POINT <u>Round metal stack</u>		STOP <u>Same</u>					
HEIGHT ABOVE GROUND LEVEL <u>START ~ 100' STOP Same</u>		HEIGHT RELATIVE TO OBSERVER <u>START ~ 100' STOP Same</u>					
DISTANCE FROM OBSERVER <u>START ~ 300' STOP Same</u>		DIRECTION FROM OBSERVER <u>START W STOP W</u>					
DESCRIBE EMISSIONS <u>START none STOP none</u>							
EMISSION COLOR <u>START NA STOP NA</u>		PLUME TYPE <u>CONTINUOUS</u>					
		FUGITIVE <u>INTERMITTENT</u>					
WATER DROPLETS PRESENT: <u>NO YES</u>		IF WATER DROPLET PLUME: <u>ATTACHED DETACHED</u>					
POINT IN THE PLUME AT WHICH OPACITY WAS DETERMINED <u>START Stack exit STOP Same</u>							
DESCRIBE BACKGROUND <u>START Sky STOP Same</u>							
BACKGROUND COLOR <u>START blue STOP Same</u>		SKY CONDITIONS <u>START clear STOP Same</u>					
WIND SPEED <u>START ~ 10 mph STOP Same</u>		WIND DIRECTION <u>START F/NNW STOP F/NW</u>					
AMBIENT TEMP. <u>START 30°F STOP 31°F</u>		WET BULB TEMP <u>*</u>		RH. percent <u>*</u>			
Source Layout Sketch Draw North Arrow		1 0 0 0 0 31 0 0 0 0					
		2 0 0 0 0 32 0 0 0 0					
		3 0 0 0 0 33 0 0 0 0					
		4 0 0 0 0 34 0 0 0 0					
		5 0 0 0 0 35 0 0 0 0					
		6 0 0 0 0 36 0 0 0 0					
		7 0 0 0 0 37 0 0 0 0					
		8 0 0 0 0 38 0 0 0 0					
		9 0 0 0 0 39 0 0 0 0					
		10 0 0 0 0 40 0 0 0 0					
11 0 0 0 0 41 0 0 0 0							
12 0 0 0 0 42 0 0 0 0							
13 0 0 0 0 43 0 0 0 0							
14 0 0 0 0 44 0 0 0 0							
15 0 0 0 0 45 0 0 0 0							
16 0 0 0 0 46 0 0 0 0							
17 0 0 0 0 47 0 0 0 0							
18 0 0 0 0 48 0 0 0 0							
19 0 0 0 0 49 0 0 0 0							
20 0 0 0 0 50 0 0 0 0							
21 0 0 0 0 51 0 0 0 0							
22 0 0 0 0 52 0 0 0 0							
23 0 0 0 0 53 0 0 0 0							
24 0 0 0 0 54 0 0 0 0							
25 0 0 0 0 55 0 0 0 0							
26 0 0 0 0 56 0 0 0 0							
27 0 0 0 0 57 0 0 0 0							
28 0 0 0 0 58 0 0 0 0							
29 0 0 0 0 59 0 0 0 0							
30 0 0 0 0 60 0 0 0 0							
AVERAGE OPACITY FOR HIGHEST PERIOD		0		NUMBER OF READINGS ABOVE % WERE			
RANGE OF OPACITY READINGS MINIMUM		0		MAXIMUM		0	
OBSERVER'S NAME (PRINT)		Shirley Bergeron					
OBSERVER'S SIGNATURE		Shirley Bergeron		DATE		2/20/96	
ORGANIZATION		Interpoll Labs					
I HAVE RECEIVED A COPY OF THESE OPACITY OBSERVATIONS SIGNATURE		CERTIFIED BY		ETA		DATE 10/4/95	
TITLE		DATE		VERIFIED BY		DATE	

INTERPOL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Job LP/HAYWARD
Source LINE / CORE DRIVER
Test 7 Run / Date _____
Stack Dimen. _____ 42" IN.
Dry Bulb _____ °F Wet bulb _____ °F
Manometer ☐ Reg. ☐ Exp. ☐ Elec.
Barometric Pressure 28.48 IN.HG
Static Pressure -8.0 IN.WC
Operators ET-LH
Pitot No. V29-6 C. .84

Cross-section View	Elevation View
-----------------------	-------------------

[illegible]

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:\STACK\WP\FORMS\S-392.1

Drawing of Test Site

Cross-section View	Elevation View
--------------------	----------------

[illegible]

032594-G:\STACK\WP\FORMS\5-392.1

INTERPOL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Job _____
Source LINE 1 CORE DRYER
Test 7 Run 3 Date 2-20-96
Stack Dimen. _____ IN.
Dry Bulb _____ °F Wet bulb _____ °F
Manometer ☐ Reg. ☐ Exp ☐ Elec.
Barometric Pressure _____ IN.HG
Static Pressure -5.0 IN.WC
Operators ET
Pitot No. V-29-6 C 184

Cross-section View	Elevation View
-----------------------	-------------------

[illegible]

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:\STACK\WP\FORMS\S-392.1

EPA Method 4 and 6 Field Data Sheet

Job LP/HAYWARD
 Source LINE NO. 1 CORE DEVEL OUTLET
 Date 2-20-96 Test 7 Run 1
 Wet Bulb _____
 Dry Bulb _____

Operator(s) J. BARNVILLE L. HANSON
 Meter Box No. _____ Gas Meter Coef. .9976
 $\Delta H@$ _____ in. WC Bar. Press 28.48 in. Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in. WC ☒
 Post Test: 0 cfm at 15 in. WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in. WC) (cc/min)	Vac. in. Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	950	932.823	1								
	5	933.002	1000	2	224					68	
	10	933.179	1000	2							
	15	933.356	1000	2							
	20	933.533	1000	2							
	25	933.710	1000	2							
	30	933.888	1000	2	216						
	35	934.065	1000	2	218						
	40	934.242	1000	2							
	45	934.419	1000	2							
	50	934.588	1000	2							
	55	934.765	1000	2							
	60	934.945	1000	2	223						
	0.60	2.122	cc/min 1000		220.25					68	

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
4 Desiccant	71.0082	71.0682	0
6 Desiccant	86.8053	70.3725	16.4310
		Total	16.4310

Preliminary Results of SO ₂ Concentration Determination		
V _{std} =	2.015	DSCF
Moisture Gravimetric =	27.75	%v/v
Moisture Psychrometric =		%v/v
SO ₂ , DRY =		PPM
SO ₂ , WET =		PPM
LB/MMBtu =		

EPA Method 4 and 6 Field Data Sheet

Job LP/HAYWARD
 Source LINE NO 1 CONC DRYER OUTLET
 Date 2-20-96 Test 7 Run 2
 Wet Bulb _____
 Dry Bulb _____

Operator(s) J. BAINVILLE L. HANSON
 Meter Box No. _____ Gasometer Coef. -9976
 ΔH@ _____ in.WC Bar.Press 28.48
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 15 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC) 1000cc/min	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	1140	934.086									
	5	934.365	1000	2	220					68	
	10	935.373	1000	2							
	15	935.555	1000	2							
	20	935.737	1000	2							
	25	935.919	1000	2							
	30	936.101	1000	2	223						
	35	936.282	1000	2	222						
	40	936.466	1000	2							
	45	936.646	1000	2							
	50	936.828	1000	2							
	55	937.010	1000	2							
	60	937.192	1000	2	215						
	0 =	V _m = 3.106	cc/min 1000		220					-60	

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	93.0524	75.2008	17.2516
Desiccant	74.1679	74.1319	.0360
	Total		17.2876

Preliminary Results of SO ₂ Concentration Determination		
V _{sd} =	2.95	DSCF
Moisture Gravimetric =	21.64	%v/v
Moisture Psychrometric =		%v/v
SO ₂ , DRY =		PPM
SO ₂ , WET =		PPM
LB/MMBtu =		

EPA Method 4 and 6 Field Data Sheet

Job LP / HAYWARD
 Source LINE NO 1 CONC DRYER OUTLET
 Date 2-20-96 Test 7 Run 3
 Wet Bulb _____
 Dry Bulb _____

Operator(s) S. BARNVILLE L. HANSON
 Meter Box No. _____ Gasometer Coef. 9976
 ΔH@ _____ in.WC Bar.Press 28.40 in.Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 15 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC) CL/MF	Vac. in.Hg	Temperatures (°F)						O ₂
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	(%v/v)
	1320	937.225									
	5	937.402	1000	2	223					68	
	10	937.582	1000	2							
	15	937.762	1000	2							
	20	937.942	1000	2							
	25	938.122	1000	2							
	30	938.302	1000	2	222						
	35	938.482	1000	2	220						
	40	938.662	1000	2							
	45	938.842	1000	2							
	50	937.022	1000	2							
	55	939.202	1000	2							
	60	939.382	1000	2	214						
	60	V _m = 2.157	CL/MF 1000		219.75					68	

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
5	88.6913	71.8411	16.8502
10	78.0267	77.9678	0.0589
		Total	16.9091

Preliminary Results of SO₂
Concentration Determination

V _{ad} =	2.048	DSCF
Moisture Gravimetric =	28.00	%v/v
Moisture Psychrometric =		%v/v
SO ₂ DRY =		PPM
SO ₂ WET =		PPM
LB/MMBtu =		

EPA Method 2 Field Data Sheet

Job LP/HAYWARD
Source LINE SURFACE DRYER
Test Run 1 Date 2-20-46
Stack Dimen. 42" IN.
Dry Bulb °F Wet bulb °F
Manometer ☐ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 28.48 IN.HG
Static Pressure -0.5 IN.WC
Operators ET-
Pitot No. V29-6 C. 84

Cross-section View	Elevation View
-----------------------	-------------------

[illegible]

032594-G:\STACK\WP\FORMS\S-392.1

Drawing of Test Site

Cross-section View	Elevation View
-----------------------	-------------------

[illegible]

032594-G:STACK/WP/FORMS/5-392.1

INTERPOL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Job _____
Source LINCOLN SURFACE DRIVER
Test 8 Run 3 Date 2-20-66
Stack Dimen. _____ IN.
Dry Bulb _____ °F Wet bulb _____ °F
Manometer ☐ Reg. ☐ Exp. ☐ Elec.
Barometric Pressure 28.48 IN.HG
Static Pressure -9.5 IN.WC
Operators ET-LH
Pitot No. V29-6 C. 84

Cross-section View	Elevation View
-----------------------	-------------------

[illegible]

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:\STACK\WP\FORMS\S-392.1

EPA Method 4 and 6 Field Data Sheet

Job LP/HAYWARD
 Source WEST LINE 1 SURFACE DRYER
 Date 2-20-96 Test 8 Run 1
 Wet Bulb _____
 Dry Bulb _____

Operator(s) ET-SK-LH
 Meter Box No. 6 Gasmeter Coef. 1.0054
 $\Delta H@$ 1.89 in.WC Bar.Press. 29.98 in.Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 5 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	<u>0950</u>	<u>997.00</u>									
	<u>5</u>	<u>1000.70</u>	<u>1.89</u>	<u>3</u>	<u>210</u>				<u>45</u>	<u>44</u>	
	<u>10</u>	<u>1004.40</u>	<u>1.89</u>	<u>3</u>					<u>54</u>	<u>44</u>	
	<u>15</u>	<u>1008.10</u>	<u>1.89</u>	<u>3</u>					<u>55</u>	<u>44</u>	
	<u>20</u>	<u>1011.80</u>	<u>1.89</u>	<u>3</u>					<u>60</u>	<u>45</u>	
	<u>25</u>	<u>1015.50</u>	<u>1.87</u>	<u>3</u>					<u>57</u>	<u>45</u>	
	<u>30</u>	<u>1019.30</u>	<u>1.87</u>	<u>3</u>					<u>58</u>	<u>45</u>	
	<u>35</u>	<u>1023.03</u>	<u>1.87</u>	<u>3</u>					<u>58</u>	<u>45</u>	
	<u>40</u>	<u>1026.84</u>	<u>1.87</u>	<u>3</u>					<u>58</u>	<u>46</u>	
	<u>45</u>	<u>1030.64</u>	<u>1.87</u>	<u>3</u>					<u>59</u>	<u>46</u>	
	<u>50</u>	<u>1034.40</u>	<u>1.87</u>	<u>3</u>					<u>60</u>	<u>46</u>	
	<u>55</u>	<u>1038.15</u>	<u>1.87</u>	<u>3</u>					<u>61</u>	<u>47</u>	
	<u>60</u>	<u>1041.85</u>	<u>1.87</u>	<u>3</u>					<u>61</u>	<u>47</u>	
	<u>(1050)</u>										
	<u>0 - 60</u>	<u>V_m 44.85</u>	<u>ΔP - 1.87</u>		<u>5 -</u>				<u>5 - 50.8</u>		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			<u>352</u>
Desiccant	<u>1477</u>	<u>1407</u>	<u>70</u>
	Total		<u>420</u>

Preliminary Results of SO ₂ Concentration Determination		
V _m -	<u>44.58</u>	DSCF
Moisture Gravimetric -	<u>30.84</u>	%v/v
Moisture Psychrometric -		%v/v
SO ₂ , DRY -		PPM
SO ₂ , WET -		PPM
LB/MMBtu -		

EPA Method 4 and 6 Field Data Sheet

Job LP/HAYWARD
 Source LINE 1 SURFACE DRYER
 Date 2-20-96 Test 8 Run 2
 Wet Bulb _____
 Dry Bulb _____

Operator(s) ET
 Meter Box No. 6 Gasmeter Coef. 1.0054
 $\Delta H@$ 1.89 in.WC Bar.Press 29.48 in.
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC X
 Post Test: 0 cfm at 5 in.WC X

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	1140	42.00									
	5	45.80	1.87	3					51	45	
	10		1.89	3					54	45	
	15	53.00	1.89	3					57	46	
	20	56.75	1.89	3					60	45	
	25	60.60	1.89	3.5					60	45	
	30		1.89	3.5					60	45	
	35		1.89	3.5					60	45	
	40	71.70	1.89	3.5					60	45	
	45	75.30	1.89	3.8					60	45	
	50	79.05	1.89	3.8					60	45	
	55	82.84	1.89	3.8					60	45	
	60	86.65	1.89	3.8					60	45	
	(1240)										
	0 - 60	V _m = 44.65	ΔH = 1.89		E =				E = 51.8		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			356
Desiccant	1538	1074	64
	Total		420

Preliminary Results of SO ₂ Concentration Determination		
V _m =	44.30	DSCF
Moisture Gravimetric =	30.87	%v/v
Moisture Psychrometric =		%v/v
SO ₂ DRY =		PPM
SO ₂ WET =		PPM
LB/MMBtu =		

EPA Method 4 and 6 Field Data Sheet

Job LP/HAYWARD
 Source LINE 1 SARECO PARK
 Date 2-20-96 Test 8 Run 3
 Wet Bulb _____
 Dry Bulb _____

Operator(s) ET
 Meter Box No. 6 Gasmeter Coef. 1.0052
 $\Delta H@$ 1.89 in.WC Bar.Press 28.49 in.Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 5 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	1320	86.80									
	5	90.60	1.89	3					49	45	
	10		1.89	3					53	45	
	15	98.05	1.89	3.2					57	46	
	20	101.50	1.89	3.2					59	47	
	25	105.32	1.89	3.6					60	47	
	30	109.10	1.89	3.7					60	47	
	35	112.90	1.89	3.7					61	47	
	40	116.67	1.89	3.8					61	48	
	45	120.50	1.89	4.0					61	49	
	50	124.20	1.89	4.0					62	49	
	55	128.00	1.89	4.0					62	49	
	60	131.70	1.89	4.0					62	49	
	(1420)										
	0-60	V _m = 144.90	$\Delta H = 1.89$							$\bar{t}_m = 53.1$	

Condensate Data:


Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			350
Desiccant	1582	1508	74
		Total	424

Preliminary Results of SO ₂ Concentration Determination	
V _{ad} =	44.43 DSCF
Moisture Gravimetric =	31.01 %v/v
Moisture Psychrometric =	%v/v
SO ₂ DRY =	PPM
SO ₂ WET =	PPM
LB/MMBtu =	

INTERPOLL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Job L.P. / Hayward, W
Source Press RTO / Stack
Test 9 Run 0 Date 2-21-96
Stack Dimen. 25.5 IN.
Dry Bulb 24.5 °F Wet bulb 11.0 °F
Manometer ☒ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 29.24 IN.HG
Static Pressure -.46 IN.WC
Operators M. Kuchler & L. Hansen
Pitot No. 232-B C_p .04

Drawing of Test Site



Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas (°F)
		Port Length: <u>6.25</u> IN.	Time Start: <u>0900</u> HRS		
A-1	.026	1.96	8.21	.155	
2	.092	6.19	12.44	.53	
3	.146	11.02	17.27	.50	
4	.226	17.06	23.31	.53	
5	.342	25.02	32.07	.60	
6	.653	49.68	55.93	.65	
7	.774	58.44	64.69	.73	
8	.854	64.48	70.73	.78	↑
9	.918	69.31	75.56	.85	
10	.974	73.54	79.79	.94	245
B-1				.53	↓
2				.68	
3				.84	
4				.78	
5				.75	
6				.64	
7				.65	
8				.64	
9				.59	
10				.55	

Temp. Meas. Device & S/N: PDT-45 / TC Time End: 0907 HRS

R or nothing = reg. manometer; S = expanded; E = electronic

INTERPOL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. / Hayward, Cal.
 Source Press. RTO / Stack
 Method 5 Filter holder: Glass

Date 2-21-96 Test 9 Run 1
 No. of traverse points 20
 Filter type: 4" G/F

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.02 cfm at 0 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

9326☒ Acetone☐ Other(s)

No. of probe wash bottles:

1

Sample recovered by:

M. Kuehler & L. Hansen

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	<u>504</u>	<u>496</u>	<u>8</u>
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	<u>1442</u>	<u>1431</u>	<u>11</u>
Total			<u>19</u>

Integrated Gas Sampling Data:

Bag Pump No. 36B
 Bag Material: 5-layer Aluminized Tedlar
 Pretest leak check: 0
 Time start: 1215
 Sampling rate: 400

Box No. 9 Bag No. 1
 Size: 44 L
 cc/min at 15 IN.HG
 (HRS) Time end: 1316 (HRS)
 cc/min Operator: M. Kuehler

S/N of O₂ Analyzer used to monitor train outlet:7

052394-G:STACK\WP\FORMS\55-0046RR

(612) 786-6020

EPA Method 5 Field Data Sheet

Operators
Meter Box No.
Gasmeter Coeff.

n. Kaehler F. L. Hansen
1/E AH@ 1.61 in.WC
150051

2.4
2.50 in.
29.24 in.Hg

Pilot No. C_p H_2O

220-8
P14
2

[illegible]

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. / Hayward, WIDate 2-21-96 Test 9 Run 2Source Pross RD / StauchNo. of traverse points 20Method 5 Filter holder: GlassFilter type: 4" G/F

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.06 cfm at 0 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

0327☒ Acetone☐ other(s)

No. of probe wash bottles:

1

Sample recovered by:

M. Kachler & L. Hansen

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	<u>514</u>	<u>507</u>	<u>7</u>
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	<u>1435</u>	<u>1425</u>	<u>10</u>
Total			<u>17</u>

Integrated Gas Sampling Data:

Bag Pump No.

36 B

Box No.

9 Bag No. 2

Bag Material:

5-layer Aluminized Tedlar

Size:

44 L

Pretest leak check:

0

cc/min at

15 IN.HG

Time start:

1400

(HRS) Time end:

1501 (HRS)

Sampling rate:

400

cc/min Operator:

M. KachlerS/N of O₂ Analyzer used to monitor train outlet:1

052394-C:\STACK\WPF\FORMS\S-0046RR

EPA Method 5 Field Data Sheet

1000

[illegible]

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward, WI Date 2-21-96 Test 9 Run 3
 Source Press RTG / Stack No. of traverse points 20
 Method 5 Filter holder: Glass Filter type: 4" G/F

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.02 cfm at 8 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

932A☒ Acetone☐ Other(s)

No. of probe wash bottles:

1

Sample recovered by:

M. Kachler + L. Hansen

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	<u>512</u>	<u>504</u>	<u>8</u>
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	<u>1554</u>	<u>1542</u>	<u>12</u>
Total			<u>20</u>

Integrated Gas Sampling Data:

Bag Pump No. 36B Box No. 9 Bag No. 3
 Bag Material: 5-layer Aluminized Tedlar Size: 44 L
 Pretest leak check: 0 cc/min at 15 IN.HG
 Time start: 1535 (HRS) Time end: 1636 (HRS)
 Sampling rate: 400 cc/min Operator: M. Kachler

S/N of O₂ Analyzer used to monitor train outlet:2

052394-G:\STACK\WPF\FORMS\S-0046RR

EPA Method 5 Field Data Sheet

$$\frac{20-13}{4} = 1.8$$
[illegible]

Drawing of Test Site

R or nothing = reg. manometer; S = expanded; E = electronic

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. / Hayward, Cal Date 2-22-96 Test 11 Run 1Source Press ASD / Stack No. of traverse points 20Method MD1 Filter holder: NA Filter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.02 cfm at 5 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

NA☐ acetone☒ Other(s) Toluene + Acetonitrile

No. of probe wash bottles:

Combined with Impinger

Sample recovered by:

M. Kaehler + L. Hansen

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	497	577	(80)
Impinger No. 2	516	473	43
Impinger No. 3			
Condenser Charcoal	1541	1491	50
Desiccant	1454	1454	-
Charcoal	1453	1440	13
Total			26

Integrated Gas Sampling Data:

Bag Pump No. 31 BBox No. 19 Bag No. 1Bag Material: 5-layer Aluminized TedlarSize: 44 LPretest leak check: 0cc/min at 15 IN.HGTime start: 0800(HRS) Time end: 0913 (HRS)Sampling rate: 400cc/min Operator: M. KaehlerS/N of O₂ Analyzer used to monitor train outlet: 7

052394-G:\STACK\WP\FORMS\S-0046RR

EPA Method 5 Field Data Sheet

Job	L.P. / Hayward, all
Source	Press NFO / stack
Date	1-22-96 Test // Run 1

Operators M. Kachker, P. L. Kasser
Meter Box No. 13 ΔH@ 1.01 in WC
Gas meter Coeff. 1.0051

Glass - 3
in. 107
20.91 in. Hg

Pilot No.	2215-B
C _p	.04
11.0	1.8%

[illegible]

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. / Hayward, CADate 2-22-96 Test 11 Run 1Source Press RTD / StackNo. of traverse points 20Method MDI Filter holder: NAFilter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.01 cfm at 8 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

NA☐ acetone☒ Other(s) Toluene + Acetone + n.c.

No. of probe wash bottles:

Added to Impinger

Sample recovered by:

Michael R. Hansen

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	522	573	(51)
Impinger No. 2	480	468	12
Impinger No. 3			
Condenser	1492	1453	39
Desiccant	1455	1454	1
	1510	1500	10
Total			11

Integrated Gas Sampling Data:

Bag Pump No. 31 BBox No. 19 Bag No. 2Bag Material: 5-layer Aluminized TedlarSize: 44 LPretest leak check: 0cc/min at 15 IN.HGTime start: 0940(HRS) Time end: 1052 (HRS)Sampling rate: 400cc/min Operator: M. KaehlerS/N of O₂ Analyzer used to monitor train outlet: 2

052394-G:\STACK\WP\FORMS\S-0046RR

INTERPOL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. / Hayward, WIDate 2-22-98 Test 11 Run 3Source Pine Rtd / StuckNo. of traverse points 20Method ND1 Filter holder: NAFilter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.02 cfm at 7 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

NA☐ acetone☒ other(s) toluene + Acetonitrile

No. of probe wash bottles:

Added to Impinger

Sample recovered by:

M. Kuebler - L. Hunsley

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	525	589	(36)
Impinger No. 2	494	470	24
Impinger No. 3	508	535	(27)
Condenser	1533	1492	41
Desiccant	1457	1455	2
	1511	1510	11
Total			15

Integrated Gas Sampling Data:

Bag Pump No. 31 BBox No. 19 Bag No. 3Bag Material: 5-layer Aluminized TedlarSize: 44 LPretest leak check: 0cc/min at 15 IN.HGTime start: 1117(HRS) Time end: 1229 (HRS)Sampling rate: 400cc/min Operator: M. KueblerS/N of O₂ Analyzer used to monitor train outlet: 7

052394-G:STACK\WP\FORMS\SS-0046RR

EPA Method 5 Field Data Sheet

Pistol No. 24-115-8
 C_p , 04
 H_2O 16 %

Nozzle No. Class - 3
Nozzle Dia. .107 in.
Bar. Press. 20.91 in Hg

Operators M. A. Schellen Th. H. H. H. H. H.
Meter Box No. 18 $\Delta H @$ 18 in WC
Gas meter Coeff. 1.0051

Job L.P. / Heyward, WI
Source Press RPO / Stuck
Date 1-23-91 Loc 11 Run 3

[illegible]

Drawing of Test Site

Cross-section View	Elevation View
-----------------------	-------------------

R or nothing = reg. manometer; S = expanded; E = electronic

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. / Hayward, WI Date 2-22-96 Test 12 Run 1
 Source Pres NTD / Street No. of traverse points 20
 Method 0011 Filter holder: NA Filter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.02 cfm at IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

8

Recovery solvent(s)

☐ acetone ☒ Other(s) MeCl₂

No. of probe wash bottles:

Sample recovered by:

Added to Impingers
Mike Kuebler & L. Hemerson

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	469	475	(6)
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1470	1457	13
Total			7

Integrated Gas Sampling Data:

Bag Pump No. 36 B Box No. 20 Bag No. 1
 Bag Material: 5-layer Aluminized Tedlar Size: 44 L
 Pretest leak check: 0 cc/min at 15 IN.HG
 Time start: 1335 (HRS) Time end: 1436 (HRS)
 Sampling rate: 400 cc/min Operator: Mike Kuebler

S/N of O₂ Analyzer used to monitor train outlet: 7

052394-G:STACK\WP\FORMS\S-0046RR

(612) 786-6020

EPA Method 5 Field Data Sheet

Job L.P. / Hayward, Ill
Source Press 170 / Stach
Date 2-22-96 Test 12 Run 1

Operators M. Kaphler & L. Hansen
Meter Box No. 1A ΔH@ 1.01 in.WC
Gasimeter Coeff. 10051

Nozzle No. 61415-7
Nozzle Dia. 1.50 in.
Bar. Press. 20.91 in.Hg

Pilot No. 21-15-H
C_p .84
H₂O 2 %

[illegible]

EPA Method 5 Field Data Sheet

Job	<u>L.P. / Highway, Ill</u>
Source	<u>Press NFO / Stack</u>
Date	<u>2-22-96 Test 12- Run 2</u>

Operators Mr. Leebert L. Hansen
Meter Box No. 1B Δ110 1.01 in. WC
Gasimeter Coeff. 1.0051

Nozzle No. 6less-4
Nozzle Dia. .250 in.
Bar. Press. 20.91 in. Hg

Pilot No.
C_p
H₂O

1
58
8-5144

[illegible]

EPA Method 5 Field Data Sheet

Job L.P. / Hargreaves, all
Source press at 153rd
2000 at 17. Run 2

Operators Mr. Michael L. Hansen
Meter Box No. 1B $\Delta H @$ 1.01 in. WC
Nozzle No. Glass - 4
Nozzle Dia. 2.10 in.
Bar. Press. 20.91 in. Hg
Cassimeter Coeff 1.0051

Pilot No. M415-B
 C_p 0.04
 H_2O 1 %

[illegible]

INTERPOL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. / Hayward, WI Date 2-22-96 Test 12 Run 3
 Source Press LTD / Stack No. of traverse points 20
 Method 0011 Filter holder: NA Filter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test 0.02 cfm at 10 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

NA
NA

Recovery solvent(s)

☐ acetone _____
☒ other(s) MeCl₂

No. of probe wash bottles:

Added to Impingers
M. Kachler + E. Hansen

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	480	474	6
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1444	1439	5
Total			11

Integrated Gas Sampling Data:

Bag Pump No. 36B Box No. 20 Bag No. 3
 Bag Material: 5-layer Aluminized Tedlar Size: 44 L
 Pretest leak check: _____ cc/min at 15 IN.HG
 Time start: 1600 (HRS) Time end: 1700 (HRS)
 Sampling rate: 400 cc/min Operator: M. Kachler

S/N of O₂ Analyzer used to monitor train outlet:

7

052394-G:\STACK\WP\FORMS\S-0046RR

(612) 786-6020

EPA Method 5 Field Data Sheet

Job _____
Source Press ATD / Stacks 12 2
Operators _____
Meter Box No. _____
Caculator Coeff _____
Nozzle No. Class - 4
Nozzle Dia. 2.50 in.
Bar. Press. 28.91 in. Hg
Pilot No. 1115-B
 C_p .04
 H_2O 1.2 %

[illegible]


Visible Emissions Form

SOURCE NAME			OBSERVATION DATE				START TIME		STOP TIME					
Louisiana Pacific Corporation			Feb. 21, 1996				1215		1315					
ADDRESS			SEC		MIN		SEC		MIN		SEC			
Hwy 63			0		15		30		45		0			
CITY			STATE		ZIP		1		2		3			
Hayward			WI		53024		31		32		33			
PHONE			SOURCE ID NUMBER		4		5		6		7			
PROCESS EQUIPMENT			OPERATING MODE		34		35		36		37			
Line 1 Press Stack					0		0		0		0			
CONTROL EQUIPMENT			OPERATING MODE		38		39		40		41			
BTD					0		0		0		0			
DESCRIBE EMISSION POINT			8		9		10		11		12			
START Round Metal Stack STOP Same			0		0		0		0		0			
HEIGHT ABOVE GROUND LEVEL			HEIGHT RELATIVE TO OBSERVER		39		40		41		42			
START ~100' STOP Same			START ~100' STOP Same		0		0		0		0			
DISTANCE FROM OBSERVER			DIRECTION FROM OBSERVER		43		44		45		46			
START ~350' STOP Same			START W STOP W		0		0		0		0			
DESCRIBE EMISSIONS			12		13		14		15		16			
START None STOP Same			0		0		0		0		0			
EMISSION COLOR			PLUME TYPE		43		44		45		46			
START NA STOP NA			CONTINUOUS ☒ FUGITIVE ☐ INTERMITTENT ☐		0		0		0		0			
WATER DROPLETS PRESENT:			IF WATER DROPLET PLUME:		45		46		47		48			
NO ☒ YES ☐			ATTACHED ☐ DETACHED ☐		0		0		0		0			
POINT IN THE PLUME AT WHICH OPACITY WAS DETERMINED			16		17		18		19		20			
START ~1.3 diam above stack STOP Same			0		0		0		0		0			
DESCRIBE BACKGROUND			18		19		20		21		22			
START Sky STOP Sky			0		0		0		0		0			
BACKGROUND COLOR			SKY CONDITIONS		48		49		50		51			
START blue STOP Same			START Clear STOP Same		0		0		0		0			
WIND SPEED			WIND DIRECTION		50		51		52		53			
START 0-5 mph STOP Same			START F/NE STOP Same		0		0		0		0			
AMBIENT TEMP.			WET BULB TEMP		52		53		54		55			
START 45°F STOP 38°F			* * RH. percent		0		0		0		0			
Source Layout Sketch Draw North Arrow			24		25		26		27		28			
			0		0		0		0		0		0	
			25		26		27		28		29		30	
			0		0		0		0		0		0	
			26		27		28		29		30		31	
			0		0		0		0		0		0	
			27		28		29		30		31		32	
			0		0		0		0		0		0	
			28		29		30		31		32		33	
			0		0		0		0		0		0	
AVERAGE OPACITY FOR HIGHEST PERIOD			NUMBER OF READINGS ABOVE % WERE			31			32					
0			0			0			0					
RANGE OF OPACITY READINGS			MINIMUM			MAXIMUM			33					
0			0			0			0					
OBSERVER'S NAME (PRINT)			OBSERVER'S SIGNATURE			DATE			34					
Sheryl Bergeron			Sheryl Bergeron			2/21/96			35					
COMMENTS			ORGANIZATION			DATE			36					
* Not determined w/ sling psychrometer due to low temps			Interpoll Labs.			10/4/95			37					
I HAVE RECEIVED A COPY OF THESE OPACITY OBSERVATIONS			CERTIFIED BY			DATE			38					
SIGNATURE			ETA			10/4/95			39					
TITLE			DATE			VERIFIED BY			DATE					

INTERPOLL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Job AP/HAWARD
Source LIND 1 PRESS RTD INLET
Test 13 Run 1 Date 02-21-96
Stack Dimen. 53.125 IN.
Dry Bulb _____ °F Wet bulb _____ °F
Manometer ☒ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 29.24 IN.HG
Static Pressure -6.0 IN.WC
Operators ET-JB
Pitot No. 41V-6 C_p .84



Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas (°F)
		Port Length:	IN.	Time Start: <u>1215</u>	HRS
A 1				1.70	
2				2.70	
3				2.75	
4				3.00	
5				3.00	115
6				3.10	
7				2.20	
8				2.70	
9				2.60	
10				1.90	
11				1.90	
12				2.00	
B 1				3.10	
2				3.20	
3				3.00	
4				2.50	
5				1.50	115
6				1.50	
7				2.10	
8				2.30	
9				2.30	
10				2.50	
11				2.00	
12				1.70	
Temp. Meas. Device & S/N:				Time End:	HRS

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:STACKWPIFORMS-392.1

INTERPOLL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Job 2 P / HAYWALT
Source LINE 1 PRESS KTA INLET
Test 13 Run 2 Date 2-21-96
Stack Dimen. 53.125 IN.
Dry Bulb _____ °F Wet bulb _____ °F
Manometer ☒ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 29.24 IN.HG
Static Pressure -6.0 IN.WC
Operators ET-JB
Pitot No. 41V-6 C_p .840

Cross-section View	Elevation View
-----------------------	-------------------

Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas (°F)
		Port Length: _____ IN.	Time Start: <u>1400</u> HRS		
B 1				<u>2.40</u>	
2				<u>2.80</u>	
3				<u>3.20</u>	
4				<u>3.00</u>	
5				<u>2.70</u>	<u>113</u>
6				<u>2.50</u>	
7				<u>1.70</u>	
8				<u>1.60</u>	
9				<u>2.30</u>	
10				<u>2.20</u>	
11				<u>2.10</u>	
12				<u>1.80</u>	
A 1				<u>1.7</u>	
2				<u>2.8</u>	
3				<u>2.8</u>	
4				<u>3.0</u>	
5				<u>2.8</u>	<u>113</u>
6				<u>2.9</u>	
7				<u>2.5</u>	
8				<u>2.3</u>	
9				<u>2.3</u>	
10				<u>2.2</u>	
11				<u>2.1</u>	
12				<u>1.8</u>	
Temp. Meas. Device & S/N: _____				Time End: _____ HRS	

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:STACKWP\FORMS\S-392.1

INTERPOL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Job 1P/HAYWARD
Source LINE 1 PRESS RD INLET
Test 13 Run 3 Date 2-21-96
Stack Dimen. 53.125 IN.
Dry Bulb _____ °F Wet bulb _____ °F
Manometer ☒ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 29.24 IN.HG
Static Pressure -6.5 IN.WC
Operators ET-JB
Pitot No. 010-6 C_p .85

Cross-section View	Elevation View
-----------------------	-------------------

Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas (°F)
		Port Length:	IN.	Time Start:	1535 HRS
A 1				2.7	
2				2.6	
3				2.7	
4				2.5	
5				2.6	
6				2.1	111
7				2.0	
8				2.1	
9				2.0	
10				1.80	
11				1.80	
B 12				1.90	
1				2.6	
2				2.5	
3				2.4	
4				2.8	
5				2.6	
6				2.6	111
7				2.8	
8				2.2	
9				2.3	
10				2.5	
11				2.4	
12				2.0	
Temp. Meas. Device & S/N:				Time End:	HRS

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:STACKWPAFORMSS-392.1

EPA Method 4 and 6 Field Data Sheet

Job LP/HAWAII
 Source LINE1 PRESS RTD INLET
 Date 2-21-96 Test 13 Run 1
 Wet Bulb _____
 Dry Bulb _____

Operator(s) ET-JB
 Meter Box No. TR 1 Gasmeter Coef. 9976
 $\Delta H@$ 0 in.WC Bar.Press 29.24 in.Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 15 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	1215	939.410									
	5	939.550	1000	+						68	
	10	939.750	1000	+						68	
	15	939.920	1000	+						68	
	20	940.100	1000	+						68	
	25	940.260	1000	1						68	
	30	940.448	1000	1						68	
	35	940.630	1000	1						68	
	40	940.780	1000	1						68	
	45	940.970	1000	1						68	
	50	941.150	1000	1						68	
	55	941.312	1000	1						68	
	60	941.520	1000	1						68	
	(1315)										
	0-60	V _m = 2.110	ΔH = 1000 cc		$\bar{c}$ =					$\bar{c}_m$ = 68	

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	77.7453	77.2203	.5750
	Total		.5750

Preliminary Results of SO ₂ Concentration Determination		
V _{sd} =	2.11	DSCF
Moisture Gravimetric =	1.26	%v/v
Moisture Psychrometric =		%v/v
SO ₂ , DRY =		PPM
SO ₂ , WET =		PPM
LB/MMBtu =		

EPA Method 4 and 6 Field Data Sheet

Job LP/HANNA
 Source LINE 1 PULL RTD AND SET
 Date 2-21-96 Test 13 Run 2
 Wet Bulb _____
 Dry Bulb _____

Operator(s) ET-TB
 Meter Box No. TR1 Gasmeter Coef. 19976
 $\Delta H@$ 0 in.WC Bar.Press 29.24
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0.2 cfm at 15 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	1400	941.800									
	5	941.985	1000cc	1					68		
	10	942.170	1000	1					68		
	15	942.352	1000	1					68		
	20	942.540	1000	1					68		
	25	942.716	1000	1					68		
	30	942.911	1000	1					68		
	35	943.180	1000	1					68		
	40	943.275	1000	1					68		
	45	943.450	1000	1					68		
	50	943.639	1000	1					68		
	55	943.814	1000	1					68		
	60	944.005	1000	1					68		
	(1500)								68		
	0 - 60	V _m = 2.205	ΔH = 1000							68	

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	78.5457	77.9690	0.5767
		Total	0.5767

Preliminary Results of SO ₂ Concentration Determination	
V _m =	2.15 DSCF
Moisture Gravimetric =	1.25 %v/v
Moisture Psychrometric =	%v/v
SO ₂ , DRY =	PPM
SO ₂ , WET =	PPM
LB/MMBtu =	

EPA Method 4 and 6 Field Data Sheet

Job LP/HAYWARD
 Source LINE 1 PRESS HTO INLET
 te 2-21-96 Test 13 Run 3
 Wet Bulb _____
 Dry Bulb _____

Operator(s) ET-JB
 Meter Box No. TR1 Gasmeter Coef. 9476
 ΔH@ _____ in.WC Bar.Press 28.24 in.Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 15 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (ci)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	1535	944.070									
	5	944.215	1000	1					68		
	10	944.412		1					68		
	15	944.596		1					68		
	20	944.778		1					68		
	25	944.960		1					68		
	30	945.118		1					68		
	35	945.276		1					68		
	40	945.434		1					68		
	45	945.592		1					68		
	50	945.750		1					68		
	55	946.065		1					68		
	60	946.262		1					68		
	(1635)										
	0-60	V _s = 2.192	ΔH = 1000		E =				E = 68		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	88.6436	88.5879	1.5902
		Total	1.5902


Preliminary Results of SO ₂ Concentration Determination	
V _m =	2.136 DSCF
Moisture Gravimetric =	1.28 %v/v
Moisture Psychrometric =	%v/v
SO ₂ , DRY =	PPM
SO ₂ , WET =	PPM
LB/MMBtu =	

(612) 786-6020

Drawing of Test Site

Pitot No.

Umm5-6 C. 84

Temp. of Gas (°F)

Port Length: 6.5 IN.

Time Start: 1545 HRS

A	1	1.35	7.85	.05
	2	4.26	10.76	.07
	3	7.59	14.09	.08
	4	11.75	18.25	.08
	5	17.78	24.28	.10
	6	34.22	40.71	.12
	7	40.24	46.74	.14
	8	44.4	50.90	.14
	9	47.74	54.24	.12
	10	50.64	57.14	.12

B	1
	2
	3
	4
	5
	6
	7
	8
	9
	10

Temp. Meas. Device & S/N:

Time End: 5

032594G:STACK\WP\FORMS\5-392.1

INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Modified Method 5 Sample Log Sheet

Job L.P. Hayward Date 2/20/96 Test 14 Run 1
 Source Line 1 Thermal Oil Lbl No. Of Traverse Points 20
 Cyclone ☐ Yes ☒ No Filter Holder MM5 Filter Type 4" Glass Fiber
 Analytes PAL XAD - 2 Resin g Batch No.
 Field Recovery Spike Added ☒ Yes ☐ No Ref. EPA SW-846 Method 0010

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: 0 cfm at 15 IN.HG (vac) ☒

Semivolatile Catch Data:

No. of filters used:

Recovery solvent(s)

☒ MeCl₂ * MeOH (50:50 v/v)☒ Other(s) Acetone

No. of bottles for condensate trap catch
 Samples recovered by 1
port

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Condensate Trap	<u>261</u>	<u>0</u>	<u>261</u>
Condensate Trap			
Condensate Trap			
Impingers			
Desiccant	<u>1447</u>	<u>1404</u>	<u>43</u>
Total			<u>304</u>

Integrated Gas Sampling Data:

Bag Pump No. 234 Box No. 20 Bag No. 1
 Bag Material: 4-layer Aluminized Tedlar Size: 44 L
 Pretest Leak Check: 0 cc/min at 15 INHG
 Time Start: 1555 (HRS) Time End: 1905 (HRS)
 Sampling Rate: 400 cc/min O₂ Analyzer S/N 4

052194-G:STACKIWP:FORMSIS-393

EPA Modified Method 5 Field Data Sheet

Pilot No. mm 5-4
 C_p .87
 H₂O 9

Nozzle No. 453
 Nozzle Dia. 7.8 in.
 Bar. Pres. 28.48 in. Hg

Operators Devil & S.K.
 Meter Box No. 17 ΔH @ 1.74 in. WC
 Gas Meter Coeff. 5985

Job L.P. Hayward
 Source 1000 Thermo 1 Oil Heater
 Date 2/20/96 Test 14 Run 1

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)						Oxygen (% v/v)	
							Stack	Probe	Oven	XAD-2	Imp.	Meter (In/Out)		
	1550	222.00												
A 10	4	225.16	.10	2.46	5.38	12	342	271	253	48	46	55	53	71.3
10	8	228.90	.09	2.13	8.95	12	342					59	54	14.1
9	12	232.40	.11	2.61	2.00	14	344	268	260	39	37	62	54	73.4
9	16	236.64	.11	2.61	8.08	14	344					65	55	11.1
8	20	240.01	.11	2.63	0.93	14	341	260	232	31	37	66	56	11.4
8	24	243.75	.11	2.64	3.08	14	341	249	233	42	40	68	57	10.5
7	28	247.53	.11	2.65	7.05	15	341					68	57	10.7
7	32	251.31	.12	2.89	1.58	16	341					68	57	11.1
6	36	255.20	.11	2.64	5.35	15	345	252	225	39	38	67	57	11.3
6	40	259.03	.11	2.64	9.11	15	345					66	59	11.0
5	44	262.43	.085	2.27	2.60	14	347	255	246	38	37	67	59	12.0
5	48	266.01	.09	2.15	6.00	14	347					68	60	11.1
4	52	269.23	.085	2.05	9.32	14	341	254	252	38	37	68	61	11.2
4	56	272.41	.08	1.93	2.55	13	341					69	61	11.2
3	60	275.60	.07	1.70	5.58	12	340	253	250	39	37	69	62	10.8
3	64	278.80	.07	1.70	8.61	12	340					69	62	11.0
3	68	281.49	.06	1.46	1.41	11	340	238	255	45	42	74	62	11.1
2	72	284.40	.05	1.46	4.22	11	340					77	63	9.8
2	76	286.87	.055	1.23	6.80	11	336	240	254	45	42	79	64	9.6
1	80	289.62	.055	1.35	4.52	11	336					79	64	9.9
B 10	84	293.44	.06	1.48	8.37	11	336	253	253	45	42	76	65	12.0
10	88	295.24	.06	1.48	5.21	11	336					80	66	12.4
9	92	298.44	.07	1.70	8.26	12	351	253	274	41	40	80	65	12.3
9	96	301.30	.075	1.82	1.42		351					81	65	13.1
	Over													
	0 -	V _m =		ΔH =								AVG. =		

INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Modified Method 5 Sample Log Sheet

Job L.P. Hayward Date 2/2/96 Test 14 Run 2
 Source Line 1 Thermal Oil Heater Stack No. Of Traverse Points 20 / 40
 Cyclone ☐ Yes ☒ No Filter Holder MM5 Filter Type 4" Glass Fiber
 Analytes P.A.H XAD - 2 Resin g Batch No.
 Field Recovery Spike Added ☒ Yes ☐ No Ref. EPA SW-846 Method 0010

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: 0 cfm at 18 IN.HG (vac) ☒

Semivolatile Catch Data:

No. of filters used:

Recovery solvent(s)

☒ MeCl₂ * MeOH (50:50 v/v)☒ Other(s) Acetone

No. of bottles for condensate trap catch
 Samples recovered by

2012

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Condensate Trap	<u>228</u>	<u>0</u>	<u>228</u>
Condensate Trap			
Condensate Trap			
Impingers			
Desiccant	<u>1493</u>	<u>1444</u>	<u>49</u>
Total			<u>277</u>

Integrated Gas Sampling Data:

Bag Pump No. 23A Box No. 20 Bag No. 2
 Bag Material: 4-layer Aluminized Tedlar Size: 44 L
 Pretest Leak Check: 0 cc/min at 15 INHG
 Time Start: 0840 (HRS) Time End: 1130 (HRS)
 Sampling Rate: 100 cc/min O₂ Analyzer S/N 4

032194-G:STACK\WP\FORMS\S-393

Py. of 2

IN '01 BOI DRH 'NC.
(612) 78 320

EPA Modified Method 3 Field Data Sheet

Pilot No. mm5-4
C_p 84
H₂O 10

Nozzle No. 8-8
Nozzle Dia. 434 in.
Bar. Pres. 29.24 in. Hg

Operators D.V.H. & S.K.
Meter Box No. 6 AH@ 1.89 in. WC
Gas meter Coeff. 1.0054

Job L.P. Hayward
Source Line 1 Thermal Oil Heater Stack
Date 2/21/96 Test 14 Run 2

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)				Meter (In/Out)	Oxyge (% v/v)
							Stack	Probe	Oven	XAD-2	Imp.	
	0835	174.70										
B 10	4	178.01	.11	2.40	8.09	11	334	246	225	40	48	19.0
10	8	181.10	.10	2.09	4.19	11	334				58	18.7
9	12	184.37	.11	2.32	4.49	11	340	253	231	40	57	19.5
9	16	187.70	.11	2.30	7.76	12	340				66	16.5
8	20	192.20	.12	2.54	1.21	13	336	241	235	35	65	17.3
8	24	194.47	.11	2.33	4.52	13	336				63	16.4
7	28	197.83	.11	2.30	7.80	13	343	244	237	35	70	16.1
7	32	201.04	.11	2.34	1.13	13	343				72	16.0
6	36	204.43	.11	2.33	4.46	13	347	249	238	36	73	16.3
6	40	207.81	.12	2.55	7.95	13	347				74	12.9
5	44	211.20	.11	2.32	1.28	13	357	253	248	37	69	13.7
5	48	214.48	.11	2.29	4.58	13	360				69	13.4
4	52	217.81	.11	2.30	7.88	13	359	256	249	38	69	13.8
4	56	221.17	.11	2.30	1.19	13	359				68	15.4
3	60	224.50	.12	2.50	4.64	14	360	251	253	40	71	15.7
3	64	228.02	.12	2.51	8.10	14	360				74	13.9
2	68	231.34	.11	2.31	1.43	14	363	258	253	41	75	15.3
2	72	234.51	.11	2.32	4.77	13	363				74	15.4
1	76	238.03	.11	2.32	8.12	13	360	257	257	41	72	14.3
1	80	241.50	.11	2.32	1.46	13	360				71	15.0
A 10	84	244.84	.115	2.42	4.86	14	360	261	259	41	68	14.9
10	88	248.24	.12	2.48	8.31	15	374				68	13.3
9	92	251.60	.12	2.47	1.74	15	376	264	260	43	68	14.0
9	96	255.07	.12	2.47	5.18	15	376				69	15.4
(over)												
0 -												
Avg. -												

Leak Check (70)

EPA Modified Method 5 Field Data Sheet

Pilot No. _____
 C_p _____
 H₂O _____
 % _____

Nozzle No. _____
 Nozzle Dia. _____ in.
 Bar. Pres. _____ in. Hg.

Operators Dent & SA
Meter Box No. ΔH@ in WC
Gasmeter Coeff

Job _____
Source _____
Date _____
L.P. Hayward
Line 1 Thermal Oil Heater
Test 14 Run 2
2/21/01
Operators _____
Meter Box No. _____
Sinec Gas Meter Coeff. _____

[illegible]

INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Modified Method 5 Sample Log Sheet

Job L.P. Hayward.
 Source Line 1 Ther.
 Cyclone ☐ Yes ☒ No
 Analytes _____
 Field Recovery Spike Added _____

Date 2/2/96
 No. Of Traverse Points _____
 Filter Holder MM5
 XAD - 2 Resin g
☐ Yes ☐ No

Test 14 Run 3
20
 Filter Type 4" Glass Fiber
 Batch No. _____
 Ref. EPA SW-846 Method 0010

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: 0 cfm at 15 IN.HG (vac) ☒

Semivolatile Catch Data:

No. of filters used:

Recovery solvent(s)

☐ MeCl₂ * MeOH (50:50 v/v)☐ Other(s) _____

No. of bottles for condensate trap catch
 Samples recovered by _____

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Condensate Trap	<u>198</u>	<u>0</u>	<u>198</u>
Condensate Trap			
Condensate Trap			
Impingers			
Desiccant	<u>1458</u>	<u>1401</u>	<u>57</u>
Total			<u>255</u>

Integrated Gas Sampling Data:

Bag Pump No. 23A
 Bag Material: 4-layer Aluminized Tedlar
 Pretest Leak Check: 0 cc/min at
 Time Start: 1335 (HRS)
 Sampling Rate: 100 cc/min

Box No. 20

Bag No. 3
 Size: 44 L

15 INHG
 Time End: 1615 (HRS)
 O₂ Analyzer S/N 4

032194-GASTACKIWPFORMSIS-393

pg 1 of 2

INTERPOL LABORATORIES, INC.

(612) 786-6020

EPA Modified Method 5 Field Data Sheet

Job L.P. Hayward Operators Dut a S.K Nozzle No. 8-8 Pilot No. MMS-6
 Source Line 1 Thermal oil Heater Stack Meter Box No. 6 ΔH @ 1.89 in. WC Nozzle Dia. .434 in. C_p .84
 Date 2/21/96 Test 14 Run 3 Gas meter Coeff. 1.0054 Bar. Pres. 29.24 in. Hg H_2O 10 %

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)				Meter (In/Out)	Oxygen (% v/v)
							Stack	Probe	Oven	XAD-2	Imp.	
10	1329	304.30	.13	2.73	7.90	11	355	261	258	50	48	13.9
10	4	307.91	.12	2.44	1.29	11	371					13.6
9	8	311.24	.13	2.66	4.83	12	370	265	260	45	43	14.2
9	12	314.80	.13	2.66	8.37	12	370					15.0
9	16	318.41	.13	2.66	1.94	12	377	264	260	46	44	14.8
8	20	321.66	.13	2.67	5.51	13	378					15.0
8	24	325.57	.13	2.67	9.09	13	375	263	257	42	40	15.2
7	28	328.91	.13	2.68	2.68	13	375					15.1
7	32	332.71	.13	2.69	2.68	13	374	264	261	43	41	14.8
6	36	336.40	.13	2.69	6.28	13	374					13.5
6	40	339.90	.13	2.69	9.87	13	374	266	264	44	41	12.6
5	44	343.40	.11	2.70	3.48	13	374					13.1
5	48	346.71	.095	2.79	6.80	13	371	264	265	44	42	13.7
4	52	349.86	.095	1.96	9.87	12	376					12.6
4	56	352.93	.085	1.98	2.97	11	376	265	263	44	42	12.4
3	60	355.91	.085	1.77	5.90	11	376					12.3
3	64	358.77	.08	1.67	8.15	11	360	264	264	44	42	14.9
2	68	361.55	.065	1.39	1.35	11	360					14.5
2	72	364.25	.08	1.71	4.23	10	360	258	262	44	42	13.7
1	76	366.90	.07	1.50	6.94	10	360					12.3
1	80	369.53	.065	1.40	9.56	10	360	257	260	42	40	14.1
10	84	373.08	.12	2.57	3.11	15	360					14.0
10	88	376.44	.105	2.24	6.40	14	391	257	260			14.1
9	92	379.80	.11	2.27	9.74	14	391					14.1
9	96	383.11	.11	2.27	3.07	14	391					14.1
		V _m =		ΔH =							Avg. =	

EPA Modified Method 3 Field Data Sheet

Job L.P. Hayward Operators _____ Nozzle No. _____ Pilot No. _____
 Source Line 1 Thermal Oil Heater Stack Meter Box No. _____ Nozzle Dia. _____ C_p _____
 Date 2/21/96 Test 14 Run 3 Bar. Pres. _____ in. Hg _____ H₂O _____ % _____
 ΔH@ _____ in. WC _____

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)						Meter (In/Out)	Oxyge (% v/v)
							Stack	Probe	Oven	XAD-2	Imp.			
B 8	100	386.43	.11	2.28	8.41	14		254				80	70	13.7
8	104	389.75	.11	2.28	9.75	14						82	73	13.9
7	108	393.28	.12	2.53	3.26	15		261				82	73	11.1
7	112	396.72	.12	2.48	6.74	15						81	73	16.1
6	116	400.16	.12	2.46	0.21	15		254				78	70	12.1
6	120	403.49	.11	2.27	3.67	15						78	73	13.2
5	124	406.71	.11	2.26	6.99	14		257				77	73	13.9
5	128	410.34	.11	2.29	0.30	15						76	72	14.0
4	132	413.51	.12	2.47	3.62	15		258				75	72	14.9
4	136	417.16	.12	2.46	7.08	15						75	72	14.9
3	140	420.56	.11	2.27	0.53	15		256				76	72	13.8
3	144	423.84	.11	2.27	3.85	15						75	71	14.0
2	148	427.35	.11	2.26	7.17	15		257				75	71	14.7
2	152	430.54	.11	1.96	0.48	15						75	71	15.1
1	156	433.60	.095	1.96	3.56							74	71	14.8
1	160	436.66	.095		6.64									
	168													

INTERPOL LABORATORIES, INC.
(612) 786-6020

Benzene Field Data Sheet

Job L.P. Hayward
Source Line 1 Thermal Oil Heater Stack
Date 2/22/96 Test 15 Run 1

Operator(s) DVA
Meter Box No. 15 Meter Coef. -8883
Barometric Pressure 29.01 IN.HG

Sample Train Leak Check:

Pretest: 0 cc/min at 15 IN.HG
Post test: 0 cc/min at 5 IN.HG

Trav. point No.	Sample Time (min)	Sample Volume (cf)	Sample Rate (cc/min)	Vac. (IN.HG)	Temperatures (°F)		
					Stack	Probe	Gasmeter
	0900	861.736					
	5	861.902	1000	5	319		72
	10	862.051	1000	6			76
	15	862.260	1000	6	386		78
	20	862.434	1000	6			80
	25	862.596	1000	6			84
	30	862.767	1000	6			84
	35	862.928	1000	6			90
	40	863.082	1000	6			92
	45	863.225	1000	6			94
	50	863.370	1000	6			94
	55	863.530	1000	8			96
	60	863.695	1000	9			96
	$\theta = 60$	$V_m = 1.959$					$t_m = 86.33$

(1005)

$$V_{STD} = 1.834$$

121693-G:STACKWPAFORMS-47L

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Benzene Field Data Sheet

Job L.P. Hayward
Source Line 1 Thermal / Oil Heater Stack
Date 2/22/96 Test 15 Run 2

Operator(s) DUT & S.K.
Meter Box No. 15 Meter Coef. 9993
Barometric Pressure 29.02 IN.HG

Sample Train Leak Check:

Pretest: 0 cc/min at 5 IN.HG
Post test: 0 cc/min at 5 IN.HG

Trav. point No.	Sample Time (min)	Sample Volume (cf)	Sample Rate (cc/min)	Vac. (IN.HG)	Temperatures (°F)		
					Stack	Probe	Gasmeter
	1053	863.723					
	5	863.934	1000	5			106
	10	864.136	1000	5			108
	15	864.318	1000	5			108
	20	864.515	1000	5	388		108
	25	864.681	1000	6			108
	30	864.842	1000	8			108
	35	865.085	1000	8			108
	40	865.271	1000	8			108
	45	865.458	1000	8			108
	50	865.640	1000	8			108
	55	865.817	1000	8			109
	60	866.068	1000	8			109
	$\theta = 60$	$V_m = 2.345$					$t_m = 108$

(1157)

$V_{STD} = 2.11$

121693-G:STACKWPAFORMSS-476

INTERPOL LABORATORIES, INC.
(612) 786-6020

Benzene Field Data Sheet

Job L.P. Hayward
Source Line 1 Oil Heater Stack
Date 2/22/66 Test 15 Run 3

Operator(s) D.L.H. & S.K.
Meter Box No. 15 Meter Coef. 9993
Barometric Pressure 29.01 IN.HG

Sample Train Leak Check:

Pretest: 0 cc/min at 16 IN.HG
Post test: 0 cc/min at 16 IN.HG

Trav. point No.	Sample Time (min)	Sample Volume (cf)	Sample Rate (cc/min)	Vac. (IN.HG)	Temperatures (°F)		
					Stack	Probe	Gasmeter
	<u>1303</u>	<u>866.096</u>					
	<u>5</u>	<u>866.277</u>	<u>1000</u>	<u>5</u>			<u>104</u>
	<u>10</u>	<u>866.454</u>	<u>1000</u>	<u>5</u>			<u>104</u>
	<u>15</u>	<u>866.627</u>	<u>1000</u>	<u>5</u>			<u>104</u>
	<u>20</u>	<u>866.817</u>	<u>1000</u>	<u>5</u>			<u>104</u>
	<u>25</u>	<u>867.003</u>	<u>1000</u>	<u>5</u>			<u>104</u>
	<u>30</u>	<u>867.199</u>	<u>1000</u>	<u>5</u>			<u>104</u>
	<u>35</u>	<u>867.390</u>	<u>1000</u>	<u>6</u>			<u>104</u>
	<u>40</u>	<u>867.548</u>	<u>1000</u>	<u>6</u>			<u>106</u>
	<u>45</u>	<u>867.71</u>	<u>1000</u>	<u>6</u>			<u>106</u>
	<u>50</u>	<u>867.88</u>	<u>1000</u>	<u>6</u>			<u>106</u>
	<u>55</u>	<u>868.061</u>	<u>1000</u>	<u>6</u>			<u>106</u>
	<u>60</u>	<u>868.220</u>	<u>1000</u>	<u>6</u>			<u>106</u>
	<u>θ =</u>	<u>V_m = 2.124</u>					<u>t_m = 104.8</u>

V_{STD} = 1.92

121693-G:STACK/WP/FORMS-476

Drawing of Test Site

Cross-section View	Elevation View
-----------------------	-------------------

R or nothing - reg. manometer; S - expanded; E - electronic

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 2/22/96 Test 16 Run 1
Source Line 1 Thermal Oil Heater Stack No. of traverse points 20
Method 5 Filter holder: glass Filter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: 0 cfm at 11 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

NA

Recovery solvent(s)

☐ acetone
☒ other(s) MeCL₂ + DI H₂O

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	295	200	95
Impinger No. 3			
Condenser			
Desiccant	1395	1375	20
Total			115

Integrated Gas Sampling Data:

Bag Pump No. 23A
Bag Material: 5-layer Aluminized Tedlar
Pretest leak check: 0
Time start: 0905
Sampling rate: 400

Box No. 26 Bag No. 1
Size: 44 L
cc/min at 15 IN.HG
(HRS) Time end: 1003 (HRS)
cc/min Operator: JWH

S/N of O₂ Analyzer used to monitor train outlet:

7

052394-C:STACKWP\FORMS\0046RR

(b)(7), (b)(1), (b)(2)

101b f.p. they were 10.1 Hunter Street

C-93

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 2/22/96 Test 16 Run 2
 Source Line 1 Thermal Oil Heater Stack No. of traverse points 20
 Method ED11 Filter holder: NR Filter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0 cfm at 12 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

NA

Recovery solvent(s)

☐ acetone☒ other(s) MECL₂ & INKNO₃

No. of probe wash bottles:

Pill

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	327	200	127
Impinger No. 3			
Condenser			
Desiccant	1458	1440	18
Total			145

Integrated Gas Sampling Data:

Bag Pump No. 23A
 Bag Material: 5-layer Aluminized Tedlar
 Pretest leak check: 0
 Time start: 1058
 Sampling rate: 400

Box No. 26 Bag No. 2
 Size: 44 L
 cc/min at 15 IN.HG
 (HRS) Time end: 1157 (HRS)
 cc/min Operator: P.H.

S/N of O₂ Analyzer used to monitor train outlet:7

052394-C:\STACK\WP\FORMS\S-0046RR

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job A.P. Hayward Date 2/22/96 Test 16 Run 3
 Source Line 1 Thermal Oil Heater Stack No. of traverse points 20
 Method DD11 Filter holder: NA Filter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0 cfm at 13 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☐ acetone☒ Other(s) MeCL₂ & C₆H₆ DI

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	319	200	119
Impinger No. 3			
Condenser			
Desiccant	1413	1395	18
Total			137

Integrated Gas Sampling Data:

Bag Pump No. 23ABag Material: 5-layer Aluminized TedlarPretest leak check: 0Time start: 1305Sampling rate: 400

Box No.

Size: 44 Lcc/min at 15(HRS) Time end: 1406cc/min Operator: DeHBag No. 3

IN.HG

(HRS)

S/N of O₂ Analyzer used to monitor train outlet: 7

052394-C:STACKWPF:FORMS:0046RR

(612) 786-6020

Cross-section View	Elevation View
-----------------------	-------------------

R or nothing = reg. manometer; S = expanded; E = electronic

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 2/21/96 Test 17 Run 1
Source Line 1 Thermal Oil Heater Stack No. of traverse points 20
Method 5 Filter holder: glass Filter type: glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: 0 cfm at 14 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

8281

☒ acetone
☐ other(s)

No. of probe wash bottles:

Sample recovered by:

1
DUL

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	293	200	93
Impinger No. 3			
Condenser			
Desiccant	1524	1501	25
Total			118

Integrated Gas Sampling Data:

Bag Pump No. 23B
Bag Material: 5-layer Aluminized Tedlar
Pretest leak check: 0
Time start: 1540
Sampling rate: 400

Box No. 29 Bag No. 1
Size: 14 L
cc/min at 15 IN.HG
(HRS) Time end: 1651 (HRS)
cc/min Operator: DUL

S/N of O₂ Analyzer used to monitor train outlet:

7

Job	L.P. Hayward				Operators
Source	King Thermal Oil Heater				Meter Box
Date	3/2/1966	Test	17	Run	1 Stack Gasmeter

7-8

Pitel No.

in.

۲۳

in. 1-18

$$\text{H}_2\text{O}$$
 H_2O

7

0

[illegible]

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 2/21/96 Test 17 Run 2
Source Line 1 Thermal Oil Heater No. of traverse points 20
Method 5 Filter holder: glass stack Filter type: glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: 0 cfm at 11 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☒ Acetone _____
☐ Other(s) _____

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	320	200	120
Impinger No. 3			
Condenser			
Desiccant	1440	1427	13
Total			133

Integrated Gas Sampling Data:

Bag Pump No. 23B Box No. 29 Bag No. 2
Bag Material: 5-layer Aluminized Tedlar Size: 44 L
Pretest leak check: 0 cc/min at 15 IN.HG
Time start: 1730 (HRS) Time end: 1829 (HRS)
Sampling rate: 400 cc/min Operator: DHL

S/N of O₂ Analyzer used to monitor train outlet:

7

052394-CASTACKIWP\FORMSS-0046RR

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 2/21/96 Test 17 Run 3
Source Line 1 Thermal Oil Heater Stack No. of traverse points 20
Method 5 Filter holder glass Filter type: glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: 0 cfm at 14 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

8282

☒ Acetone _____
☐ Other(s) _____

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

1
DVA

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	297	200	97
Impinger No. 3			
Condenser			
Desiccant	1539	1526	13
Total			110

Integrated Gas Sampling Data:

Bag Pump No.

Bag Material:

Pretest leak check:

Time start:

Sampling rate:

235
5-layer Aluminized Tedlar
0
1904
400

Box No.

Size:

cc/min at

(HRS) Time end:

cc/min Operator:

29 Bag No. 3
44 L
15 IN.HG
2004 (HRS)
DVA

S/N of O₂ Analyzer used to monitor train outlet:

7

052394-CASTACKIWPFORMSS-0046RR

EPA Method 5 Field Data Sheet

7-8

Pilot No. V23-5

453

C₂ 184

29.24

H₂O 10

Nozzle No.

in.

Bar. Press.

in. Hg

Operators

Meter Box No.

Gasmeter Coeff.

Job L.P. Hayward

Source Line 1 Thermal Oil Heater Stack

Date 2/2/96

Test 17

Run 3

Orifice Meter (in. WC)

Velocity Head (in. WC)

Sample Vol. (cc)

Sampling Time (min)

Traverse Point No.

Des. Vol. (cc)

VAC. (in. Hg)

Temperatures (°F)

Stack

Probe

Oven

Inp.

Gas/In

Gas/Out

Oxygen (% v/v)

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

1

10

9

8

7

6

5

4

3

2

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 2/21/96 Test 19 Run 1
Source Line 1 Thermal Oil Heater No. of traverse points 3
Method 3+4 Filter holder: glass stack Filter type: glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: _____ cfm at _____ IN. HG (vac) ☐

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☐ acetone _____

☐ other(s) _____

No. of probe wash bottles: _____

Sample recovered by: _____

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant			
Total			

Integrated Gas Sampling Data:

Bag Pump No. 23 B Box No. 15 Bag No. 1
Bag Material: 5-layer Aluminized Tedlar Size: 44 L
Pretest leak check: 0 cc/min at 15 IN.HG
Time start: 0440 (HRS) Time end: 1038 (HRS)
Sampling rate: 400 cc/min Operator: DVH

S/N of O₂ Analyzer used to monitor train outlet: 7

052394-CASTACKIWPFORMSS-00462R

EPA Method 4 and 6 Field Data Sheet

Job L.P. Hayward
 Source Line 1 Thermal Oil Heater Stack
 Date 2/21/96 Test 19 Run 1
 Wet Bulb _____
 Dry Bulb _____

Operator(s) D.V.H. & S.K.
 Meter Box No. 5 Gasmeter Coef. .9997
 $\Delta H@$ 1.82 in.WC Bar.Press 29.24 in.Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 11 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	(%v/v)
	0934	709.40									
H 3	5	712.80	1.80	5		257	228	41	56	54	16.0
3	10	716.27	1.80	5					60	53	8.8
3	15	720.70	1.80	5		261	238	41	63	55	11.9
3	20	724.59	1.80	5					65	56	12.3
2	25	728.37	1.80	5		257	251	42	67	57	10.5
2	30	732.21	1.80	5					71	58	13.1
B 2	35	736.08	1.80	5	374	258	254	43	67	60	10.3
2	40	739.84	1.80	5					72	61	13.
1	45	743.61	1.80	5		259	256	44	73	61	14.4
1	50	747.50	1.80	5					81	62	13.9
1	55	751.18	1.80	5		258	253	44	75	62	11.9
1	60	754.87	1.80	5					76	62	11.7
	(1038)										
	0-60	V _m 45.47	$\Delta P = 1.80$		E -				E - 63.62		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers	280	200	80
Condenser			
Desiccant	1465	1458	7
	Total		87

Preliminary Results of SO ₂ Concentration Determination		
V _m =	45.00	DSCF
Moisture Gravimetric =	8.35	%v/v
Moisture Psychrometric =		%v/v
SO ₂ , DRY =		PPM
SO ₂ , WET =		PPM
LB/MMBtu =		

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 2/21/96 Test 19 Run 2
Source Line 1 Thermal Oil Heater No. of traverse points 3
Method 3 Filter holder: glass Filter type: glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☐
Post test: cfm at IN. HG (vac) ☐

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☐ acetone

☐ other(s)

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant			
Total			

Integrated Gas Sampling Data:

Bag Pump No. 23 B Box No. 15 Bag No. 2
Bag Material: 5-layer Aluminized Tedlar Size: 44 L
Pretest leak check: 0 cc/min at 15 IN.HG
Time start: 1100 (HRS) Time end: 1158 (HRS)
Sampling rate: 400 cc/min Operator: DWH

S/N of O₂ Analyzer used to monitor train outlet: 7

052394-GASTACKWPAFORMS-0046RR

EPA Method 4 and 6 Field Data Sheet

Job L.P. Hayward
 Source Line 1 Thermal Oil Heater Stack
 Date 2/21/96 Test 19 Run 2
 Wet Bulb _____
 Dry Bulb _____

Operator(s) DVM & S.K.
 Meter Box No. 5 Gasmeter Coef. 9997
 $\Delta H@$ 1.82 in.WC Bar.Press 29.24 in.
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 10 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	1056	755.20									
3	5	759.09	1.80	6		250	253	44	68	67	15.3
3	10	762.91	1.80	6					72	66	10.9
3	15	766.73	1.80	6		258	257	45	75	65	10.0
3	20	770.56	1.80	7					77	66	11.0
2	25	774.40	1.80	7		261	253	45	78	66	12.0
2	30	777.89	1.80	7					78	66	12.1
2	35	781.20	1.80	7		264	254	46	79	67	11.1
2	40	785.55	1.80	8					80	67	11.1
	45	789.32	1.80	8		264	258	46	80	67	11.0
1	50	793.15	1.80	8					79	69	10.8
1	55	796.95	1.80	8		261	260	46	79	69	9.1
1	60	799.	1.80	8					79	69	11.4
	(1158)	800.70									
	0-60	V _m = 45.50	ΔH = 1.80		E =				E = 72		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers	301	200	101
Condenser			
Desiccant	1490	1501	11
		Total	111

Preliminary Results of SO ₂ Concentration Determination	
V _{std} =	44.32 DSCF
Moisture Gravimetric =	10.55 %v/v
Moisture Psychrometric =	%v/v
SO ₂ DRY =	PPM
SO ₂ WET =	PPM
LB/MMBtu =	

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 2/21/96 Test 14 Run 3
 Source Line 1 Thermal Oil Heater Stack No. of traverse points 3
 Method 3 Filter holder: glass Filter type: glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☐Post test: cfm at IN. HG (vac) ☐

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☐ acetone ☐ other(s) No. of probe wash bottles: Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant			
Total			

Integrated Gas Sampling Data:

Bag Pump No. 23 B
 Bag Material: 5-layer Aluminized Tedlar
 Pretest leak check: 0
 Time start: 1345
 Sampling rate: 400

Box No. 15 Bag No. 3
 Size: 44 L
 cc/min at 14 IN.HG
 (HRS) Time end: 1441 (HRS)
 cc/min Operator: DUH

S/N of O₂ Analyzer used to monitor train outlet: 7

052394-C:\STACK\WP\FORMS\5-00462R

Visible Emissions Form

SOURCE NAME			OBSERVATION DATE				START TIME				STOP TIME				STOP
Louisiana Pacific Corp			Feb 21, 1996				1535				1605				*1605
ADDRESS			SEC				SEC				SEC				RE-START
			MIN	0	15	30	45	MIN	0	15	30	45	1602		
			1	10	10	10	10	31	5	5	5	5			
			2	10	10	10	10	32	5	5	5	5			
			3	10	10	10	10	33	5	5	5	5			
			4	10	10	10	10	34	5	5	5	5			
			5	10	10	10	10	35	5	5	5	5			
			6	5	5	5	5	36	5	5	5	5			
			7	5	5	5	5	37	5	5	5	5			
			8	5	5	5	5	38	5	5	5	5			
			9	5	5	5	5	39	5	5	5	5			
			10	5	5	5	5	40	5	5	5	5			
			11	5	5	5	5	41	5	5	5	5			
			12	5	5	5	5	42	5	5	5	5			
			13	5	5	5	5	43	5	5	5	5			
			14	5	5	5	5	44	5	5	5	5			
			15	5	5	5	5	45	5	5	5	5			
			16	5	5	5	5	46	5	5	5	5			
			17	5	5	5	5	47	5	5	5	5			
			18	5	5	5	5	48	5	5	5	5			
			19	5	5	5	5	49	5	5	5	5			
			20	5	5	5	5	50	5	5	5	5			
			21	5	5	5	5	51	5	5	5	5			
			22	5	5	5	5	52	5	5	5	5			
			23	5	5	5	5	53	5	5	5	5			
			24	5	5	5	5	54	5	5	5	5			
			25	5	5	5	5	55	5	5	5	5			
			26	5	5	5	5	56	5	5	5	5			
			27	5	5	5	5	57	5	5	5	5			
			28	5	5	5	5	58	5	5	5	5			
			29	5	5	5	5	59	5	5	5	5			
			30	5	5	5	5	60	5	5	5	5			
PROCESS EQUIPMENT			OPERATING MODE												
Thermal Oil Heater Stack															
CONTROL EQUIPMENT			OPERATING MODE												
C.P.B.															
DESCRIBE EMISSION POINT															
START Gray cylindrical stack															
STOP Same															
HEIGHT ABOVE GROUND LEVEL			HEIGHT RELATIVE TO OBSERVER												
START ~71'			START ~71'												
STOP Same			STOP Same												
DISTANCE FROM OBSERVER			DIRECTION FROM OBSERVER												
START ~230'			START NE												
STOP Same			STOP Same												
DESCRIBE EMISSIONS															
START Penning			STOP Same												
EMISSION COLOR			PLUME TYPE: CONTINUOUS ☒												
START Blue w/ STOP			FUGITIVE ☐ INTERMITTENT ☐												
WATER DROPLETS PRESENT:			IF WATER DROPLET PLUMES ☒												
NO ☒ YES ☐			ATTACHED ☐ DETACHED ☐												
POINT IN THE PLUME AT WHICH OPACITY WAS DETERMINED															
START 3 stack diameter			STOP Same												
DESCRIBE BACKGROUND															
START Sky			STOP Same												
BACKGROUND COLOR			SKY CONDITIONS												
START Blue			START Clear												
STOP Same			STOP Same												
WIND SPEED			WIND DIRECTION												
START 0.5 mph			START FINE												
STOP Same			STOP Same												
AMBIENT TEMP.			WET BULB TEMP				RH, percent								
START 32°F			STOP 31°F				RH, percent								
STOP 31°F															
Source Layout Sketch			AVERAGE OPACITY FOR HIGHEST PERIOD 9.2				NUMBER OF READINGS ABOVE % WERE								
RANGE OF OPACITY READINGS MINIMUM 5 MAXIMUM 10			OBSERVER'S NAME (PRINT)				Sheryl Bergeron								
COMMENTS			OBSERVER'S SIGNATURE				DATE								
PM & VE test was conducted while the PAH was finishing - Had to stop for 30 min until next			Sheryl Bergeron				2/21/96								
I HAVE RECEIVED A COPY OF THESE OPACITY OBSERVATIONS			ORGANIZATION				Interpoll Labs								
SIGNATURE			CERTIFIED BY				DATE								
TITLE			VERIFIED BY				DATE								
DATE			DATE				DATE								

* Not determined w/ slurry psychrom. due to low temps.

VISIBLE EMISSIONS EVALUATOR

This is to certify that

Cheryl L. Ferguson

met the specifications of Federal Reference Method 9 and qualified as a visible emissions evaluator. Maximum deviation on white and black smoke did not exceed 7.5% opacity and no single error exceeding 15% opacity was incurred during the certification test conducted by Eastern Technical Associates of Raleigh, North Carolina. This certificate is valid for six months from date of issue.

Theresa Hare
President

W. L. Hare
Vice President

David B. Savage, Jr.
Program Manager

250593
Certificate Number

Metropolitan

October 4, 1995
Date of Issue

APPENDIX D

INTERPOLL LABORATORIES ANALYTICAL DATA

TABLE OF CONTENTS

Orsat	1
Carbon Monoxide	12
Particulate	15
Methane	24
Benzene	27
Formaldehyde	35
Phenol	36
MDI	37
PAH's	38
Spike Data	39
Sample Deposition Sheets	41

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job
Team Leader
ate Submitted
est No.
Date of Analysis

LP-HAYWARD
ET
2-28-96

Source
Test Site
Date of Test
No. of Runs Completed
Technician

LINE 1 DRYER RTD
STACK
2-21-96
3
ET

Test/ Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
2-1	73A-13	1	0.00	3.8	20.7	3.8	16.9	
		2	0.00	3.8	20.7	3.8	16.9	
		Avg				3.8	16.9	
2-2	73A-14	1	0.00	3.8	20.7	3.8	16.9	
		2	0.00	3.8	20.7	3.8	16.9	
		Avg				3.8	16.9	
2-3	73A-15	1	0.00	3.8	20.7	3.8	16.9	
		2	0.00	3.8	20.7	3.8	16.9	
		Avg				3.8	16.9	
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						

- ☒ Ambient Air QA Check
☒ Orsat Analyzer System Leak Check
☒ F₀ Within EPA M-3 Guidelines
for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet
Orsat Analysis

Job L.P. / Hayward, WI
Team Leader E. Rivers
Date Submitted 2-21-96
Test No. 3
Date of Analysis 2-21-96

Source Dryer #10
Test Site Stack
Date of Test 2-21-96
No. of Runs Completed 3
Technician Mark Sessler

Test/ Run	Sample Log Number and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F _o
			Zero Pt.	After CO ₂	After O ₂			
3/1	□ B □ F	1	0.00	4.30	20.40	4.30	16.10	
		2	0.00	4.30	20.40	4.30	16.10	
		Avg				4.30	16.10	
3/2	□ B □ F	1	0.00	4.40	20.40	4.40	16.00	
		2	0.00	4.40	20.40	4.40	16.00	
		Avg				4.40	16.00	
3/3	□ B □ F	1	0.00	4.40	20.40	4.40	16.00	
		2	0.00	4.40	20.40	4.40	16.00	
		Avg				4.40	16.00	
	□ B □ F	1						
		2						
		Avg						
	□ B □ F	1						
		2						
		Avg						
	□ B □ F	1						
		2						
		Avg						
	□ B □ F	1						
		2						
		Avg						
	□ B □ F	1						
		2						
		Avg						
	□ B □ F	1						
		2						
		Avg						
	□ B □ F	1						
		2						
		Avg						

- ☐ Ambient Air QA Check
☐ Orsat Analyzer System Leak Check
☐ F_o Within EPA M-3 Guidelines
for fuel type.

Where $F_o = \frac{20.9 - O_2}{CO_2}$

F=Flask (250 cc all glass)
B=Tedlar Bag (5-layer)

D-2

EPA Method 3 Guidelines	
Fuel Type	F _o Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.936
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

LSC-04-BR

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job LP/HAYWARD
 Team Leader E-T
 Date Submitted _____
 Test No. 4
 Date of Analysis 2-28-96

Source LINE 1 DRYER RTD
 Test Site STACK
 Date of Test 2-21-96-22-96
 No. of Runs Completed 3
 Technician ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
4-1	7318-28	1	0.00	3.7	20.6	3.7	16.9	1.08
		2	0.00	3.7	20.6	3.7	16.9	
		☒ B ☐ F Avg				3.7	16.9	
4-2	7318-29	1	0.00	3.8	20.7	3.8	16.9	1.05
		2	0.00	3.8	20.7	3.8	16.9	
		☒ B ☐ F Avg				3.8	16.9	
4-3	7318-30	1	0.00	3.8	20.7	3.8	16.9	1.05
		2	0.00	3.8	20.7	3.8	16.9	
		☒ B ☐ F Avg				3.8	16.9	
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						

- ☒ Ambient Air QA Check
☒ Orsat Analyzer System Leak Check
☒ F₀ Within EPA M-3 Guidelines for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job LP/HAYWARD
 Team Leader ET
 Date Submitted _____
 Test No. 8
 Date of Analysis 2-27-86

Source LINE 1 SURFACE PLANT
 Test Site _____
 Date of Test 2-20-86
 No. of Runs Completed 3
 Technician ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
8-1	7318-07	1	0.00	15.6	20.8	15.6	5.2	1.00
		2	0.00	15.6	20.8	15.6	5.2	
		Avg				15.6	5.2	
8-2	7318-08	1	0.00	15.5	20.8	15.5	5.3	1.01
		2	0.00	15.5	20.8	15.5	5.3	
		Avg				15.5	5.3	
8-3	7318-09	1	0.00	15.3	20.8	15.3	5.5	1.01
		2	0.00	15.3	20.8	15.3	5.5	
		Avg				15.3	5.5	
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						

- ☒ Ambient Air QA Check
☒ Orsat Analyzer System Leak Check
☒ F₀ Within EPA M-3 Guidelines for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job
Team Leader
are Submitted
Test No.
Date of Analysis

LP/HAYWARD
MR
11
2-23-96

Source
Test Site
Date of Test
No. of Runs Completed
Technician

LINE 1 PRESS RD
STACK
2-22-96
3
ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
11-1	738-51	1	0.00	.4	20.9	.4	20.5	
		2	0.00	.4	20.9	.4	20.5	
		☒ B ☐ F Avg				.4	20.5	
11-2	52	1	0.00	.4	20.9	.4	20.5	
		2	0.00	.4	20.9	.4	20.5	
		☒ B ☐ F Avg				.4	20.5	
11-3	53	1	0.00	.4	20.9	.4	20.5	
		2	0.00	.4	20.9	.4	20.5	
		☒ B ☐ F Avg				.4	20.5	
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						

Ambient Air QA Check
Orsat Analyzer System Leak Check
F₀ Within EPA M-3 Guidelines
for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F - Flask (250 cc all glass)

B - Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job
Team Leader
Date Submitted
Test No.
Date of Analysis

LP/HAYWARD
MR
12
2-22-96

Source
Test Site
Date of Test
No. of Runs Completed
Technician

LINE 1 PRESS RTD
STACK
2-22-96
3
ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
12-1	7318-60	1	0.00	.4	20.9	.4	20.5	
		2	0.00	.4	20.9	.4	20.5	
		Avg				.4	20.5	
12-2	7318-61	1	0.00	.4	20.9	.4	20.5	
		2	0.00	.4	20.9	.4	20.5	
		Avg				.4	20.5	
12-3	7318-62	1	0.00	.4	20.9	.4	20.5	
		2	0.00	.4	20.9	.4	20.5	
		Avg				.4	20.5	
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						

- ☒ Ambient Air QA Check
☒ Orsat Analyzer System Leak Check
☒ F₀ Within EPA M-3 Guidelines for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

(612) 786-6020

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job
Team Leader
ate Submitted
Test No.
Date of Analysis

L.P. HAYWARD
DVH
2-22-96
14
2-22-96

Source
Test Site
Date of Test
No. of Runs Completed
Technician

LINE 1 THERMAL OIL HEATER
STACK
2-20-96
3
ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
14/1	7318	1				8.2	12.4	
		2						
		Avg						
14/2	X B O F	1				6.5	14.2	
		2						
		Avg						
14/3	X B O F	1				6.6	14.0	
		2						
		Avg						
	B O F	1						
		2						
		Avg						
	B O F	1						
		2						
		Avg						
	B O F	1						
		2						
		Avg						
	B O F	1						
		2						
		Avg						
	B O F	1						
		2						
		Avg						
	B O F	1						
		2						
		Avg						



interpoll INTEGRATED BAG GAS SAMPLES

Job L.P. Hayward Date 2/20, 21/96

Log #

Source Line 1 Thermal Oil HeaterTest Site STACKCollected for test type: O₂ & CO₂ Tech DVHTest/Run 14/1, 2, 31 of 1

- ☐ Ambient Air QA Check
☐ Orsat Analyzer System L₀
☐ F₀ Within EPA M-3 Guide
for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

Bituminous 1.083-1.230
Oil:
Distillate 1.260-1.413
Residual 1.210-1.370
Gas:
Natural 1.600-1.836
Propane 1.434-1.586
Butane 1.405-1.553
Wood/Wood Bark 1.000-1.130

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job
Team Leader
Date Submitted
Test No.
Date of Analysis

LPHAYWARD
DVH
16
2-23-90

Source
Test Site
Date of Test
No. of Runs Completed
Technician

LIQUID THERMAL OIL HEATER
STARK
2-22-90
3
DET ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
16-1	73B-79	1	0.00	6.0	20.6	6.0	14.6	1.05
		2	0.00	6.0	20.6	6.0	14.6	1.05
		Avg				6.0	14.6	
16-2	73B-80	1	0.00	8.5	20.6	8.5	12.1	1.04
		2	0.00	8.5	20.6	8.5	12.1	1.04
		Avg				8.5	12.1	
16-3	73B-81	1	0.00	8.0	20.6	8.0	12.6	1.04
		2	0.00	8.0	20.6	8.0	12.6	1.04
		Avg				8.0	12.6	
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						

- ☒ Ambient Air QA Check
☒ Orsat Analyzer System Leak Check
☒ F₀ Within EPA M-3 Guidelines for fuel type.

Where $F_0 = \frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job L.P. HAYWARD
 Team Leader DVM
 Date Submitted 2-22-96
 Test No. 17
 Date of Analysis 2-22-96

Source Line 1 Thermal Oil Heater
 Test Site Stack
 Date of Test 2-21-96
 No. of Runs Completed 3
 Technician ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
17/1	7318 B□F	1				5.9	14.8	
		2						
		Avg						
17/2	B□F	1				7.3	13.3	
		2						
		Avg						
17/3	B□F	1				5.9	14.8	
		2						
		Avg						
	B□F	1						
		2						
		Avg						
	B□F	1						
		2						
		Avg						
	B□F	1						
		2						
		Avg						
	B□F	1						
		2						
		Avg						

Interpoll INTEGRATED BAG GAS SAMPLES

Job L.P. Hayward Date 2/21/96

Source Line 1 Thermal Oil Heater Log # 7318

Test Site Stack

Collected for test type: O₂ CO₂ Tech DVM

2 CO Test/Run 17/1, 2, 3

1 of 1

- ☐ Ambient Air QA Check
☐ Orsat Analyzer System Leak Check
☐ F₀ Within EPA M-3 Guidelines for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet
Orsat Analysis

Job L.P. / Hayward, WI
Team Leader D. Van Hise
Date Submitted 2-21-96
Test No. 19
Date of Analysis 2-21-96

Source Line 1 Thermal Oil Heater
Test Site Stack
Date of Test 2-21-96
No. of Runs Completed 3
Technician Mark Rashler

Test/ Run	Sample Log Number and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂	Conc. O ₂	F _o
			Zero Pt.	After CO ₂	After O ₂	%v/v Dry	%v/v Dry	
19/1	☒ B ☐ F	1	0.00	6.60	20.30	6.60	13.70	
		2	0.00	6.60	20.30	6.60	13.70	
		Avg				6.60	13.70	
19/2	☒ B ☐ F	1	0.00	8.00	20.50	8.00	12.50	
		2	0.00	8.00	20.50	8.00	12.50	
		Avg				8.00	12.50	
19/3	☒ B ☐ F	1	0.00	4.50	20.40	4.50	15.90	
		2	0.00	4.50	20.40	4.50	15.90	
		Avg				4.50	15.90	
	☐ B ☐ F	1						
		2						
		Avg						
	☐ B ☐ F	1						
		2						
		Avg						
	☐ B ☐ F	1						
		2						
		Avg						
	☐ B ☐ F	1						
		2						
		Avg						
	☐ B ☐ F	1						
		2						
		Avg						
	☐ B ☐ F	1						
		2						
		Avg						

- ☐ Ambient Air QA Check
☐ Orsat Analyzer System Leak Check
☐ F_o Within EPA M-3 Guidelines
for fuel type.

Where $F_o = \frac{20.9 - O_2}{CO_2}$

F=Flask (250 cc all glass)
B=Tedlar Bag (5-layer)

EPA Method 3 Guidelines	
Fuel Type	F _o Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.250
Oil:	
Distillate	1.260-1.415
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130
D-10	

EPA Method 3 Data Reporting Sheet
Orsat Analysis

Job L.P. / Hayward, WI
Team Leader D. VanHoever
Date Submitted 2-20-96
Test No. 20
Date of Analysis 2-20-96

Source Line 1 Dryer
Test Site E. Tube Outlet
Date of Test 2-20-96
No. of Runs Completed 3
Technician Mark Bachler

Test/ Run	Sample Log Number and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂	Conc. O ₂	F _o
			Zero Pt.	After CO ₂	After O ₂	%v/v Dry	%v/v Dry	
20/1	☐ B ☐ F	1	0.00	4.10	20.50	4.10	16.40	
		2	0.00	4.10	20.50	4.10	16.40	
		Avg				4.10	16.40	
20/2	☐ B ☐ F	1	0.00	4.20	20.50	4.20	16.30	
		2	0.00	4.20	20.50	4.20	16.30	
		Avg				4.20	16.30	
20/3	☐ B ☐ F	1	0.00	4.20	20.50	4.20	16.30	
		2	0.00	4.20	20.50	4.20	16.30	
		Avg				4.20	16.30	
	☐ B ☐ F	1						
		2						
		Avg						
	☐ B ☐ F	1						
		2						
		Avg						
	☐ B ☐ F	1						
		2						
		Avg						
	☐ B ☐ F	1						
		2						
		Avg						
	☐ B ☐ F	1						
		2						
		Avg						
	☐ B ☐ F	1						
		2						
		Avg						
	☐ B ☐ F	1						
		2						
		Avg						
	☐ B ☐ F	1						
		2						
		Avg						

- ☐ Ambient Air QA Check
☐ Orsat Analyzer System Leak Check
☐ F_o Within EPA M-3 Guidelines
for fuel type.

Where $F_o = \frac{20.9 - O_2}{CO_2}$

F=Flask (250 cc all glass)
B=Tedlar Bag (5-layer)

EPA Method 3 Guidelines	
Fuel Type	F _o Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 10 NDIR Analysis

Job Name LP/Hayward
 Source Line 1 Surface Dwyer
 Date of Analysis 3-12-96
 Technician SF

NDIR Analyzer: ☒ Fugro ACS Model 3300
☐ Mon. Lab Model 8310
☐ Dasibi Model 3003
 Range: 0 - 1000 PPM
 Flow rate: 1000 cc/min

Pretest Calibration				
	Concentration		Reading	
Zero Gas	0 PPM		0 PPM	
Upscale Gas	300.8 PPM		300.8 PPM	Scott
Upscale Gas	590 PPM		590 PPM	and Fiberglass
Upscale Gas	PPM		PPM	

Sample Description Test/Run	Sample Log No.	CO Conc. (PPM, Dry)		
		Dilution Factor	Reading	Actual PPM
8/1	7318-107	6.782	145	983.39
8/2	7318-108	6.782	210	1424.22
8/3	7318-109	6.782	198	1342.84

Post-Test Calibration			
	Conc.		Reading
Zero Gas	0 PPM		0 PPM
Upscale Gas	590 PPM		583.25 PPM
Upscale Gas	PPM		PPM
Upscale Gas	PPM		PPM

Note 1: If sample dilution is required, the sample is diluted with CO-free gas prior to analysis.

Note 2: The Fugro ACS model 3300 has a rejection ratio for CO to CO₂ greater than 100,000: 1 and the Mon. Labs Model 8310 and Dasibi Model 3003 have rejection ratios greater than 200,000: 1 and thus CO₂ removal prior to analysis is not required.

Note 3: The analyzer must be zeroed and spanned immediately before and after sample analysis. Additional checks may be performed between sample analyses if required.

EPA Method 10 NDIR Analysis

Job Name
Source
Date of Analysis
Technician

LP/HAYWARD
LIND / THERMAL OIL HEATER STAK NDIR
2-22-96
ET

NDIR Analyzer:

Fuji ACS Model 3300
Mon. Lab Model 8310
Dasibi Model 3003
000 PPM
000 cc/min

Range: 0 - 1000 PPM
Flow rate: 1000 cc/min

Pretest Calibration				
	Concentration	Reading	Vendor	Cyl. No.
Zero Gas	PPM	PPM		
Upscale Gas	PPM	PPM		
Upscale Gas	PPM	PPM		
Upscale Gas	PPM	PPM		

[illegible]

Post-Test Calibration		
	Conc.	Reading
Zero Gas	PPM	PPM
Upscale Gas	PPM	PPM
Upscale Gas	PPM	PPM
Upscale Gas	PPM	PPM

Note 1: If sample dilution is required, the sample is diluted with CO-free gas prior to analysis.

Note 2: The Fugti ACS model 3300 has a rejection ratio for CO to CO₂ greater than 100,000: 1 and the Mon. Labs Model 8310 and Dasibi Model 3003 have rejection ratios greater than 200,000: 1 and thus CO₂ removal prior to analysis is not required.

Note 3: The analyzer must be zeroed and spanned immediately before and after sample analysis. Additional checks may be performed between sample analyses if required.

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Impinger Catch Data Reporting Sheet

Protocol: ☐ Minnesota ☒ Wisconsin ☐ Iowa ☐ EPA Method 202 ☐ Other _____
 Job: LP / Haywood Source/Site: Dryer RTD / Stack
 Date Submitted: 2-23-96 Test No.: 1
 Date of Analysis: 2-26-96 Technician: B.D.

		Solvent Phase		Aqueous Phase	
Test: 1	Run: 0	Dish No: 751		Dish No: 98	
Log No: 7318-01E		Dish + Sample Wt: 44.2536 g		Dish + Sample Wt: 42.7034 g	
Color & Appearance:		Dish Tare Wt: 44.2536 g		Dish Tare Wt: 42.7039 g	
		Fraction Wt: 0.0000 g		Fraction Wt: 0.0000 g	
Comments:		Smpl Vol: 200 ml, Alqt: 200 ml, Factor: 1.000		Smpl Vol: 200 ml, Alqt: 100 ml, Factor: 2.000	
		Sample Wt: 0.0000 g		Sample Wt: 0.0000 g	
Test: 1	Run: 1	Dish No: 755		Dish No: 106	
Log No: -02I		Dish + Sample Wt: 46.0032 g		Dish + Sample Wt: 43.0176 g	
Color & Appearance:		Dish Tare Wt: 46.0030 g		Dish Tare Wt: 43.0165 g	
		Fraction Wt: 0.0002 g		Fraction Wt: 0.0011 g	
Comments:		Smpl Vol: 460 ml, Alqt: 460 ml, Factor 1.000		Smpl Vol: 460 ml, Alqt: 100 ml, Factor 4.600	
		Sample Wt: 0.0002 g		Sample Wt: 0.0051 g	
Test: 1	Run: 2	Dish No: 758		Dish No: 436	
Log No: -03E		Dish + Sample Wt: 45.3020 g		Dish + Sample Wt: 46.2474 g	
Color & Appearance:		Dish Tare Wt: 45.3017 g		Dish Tare Wt: 46.2472 g	
		Fraction Wt: 0.0003 g		Fraction Wt: 0.0002 g	
Comments:		Smpl Vol: 470 ml, Alqt: 470 ml, Factor 1.000		Smpl Vol: 470 ml, Alqt: 100 ml, Factor 4.700	
		Sample Wt: 0.0003 g		Sample Wt: 0.0009 g	
Test: 1	Run: 3	Dish No: 760		Dish No: 721	
Log No: -04E		Dish + Sample Wt: 44.0705 g		Dish + Sample Wt: 46.9088 g	
Color & Appearance:		Dish Tare Wt: 44.0703 g		Dish Tare Wt: 46.9087 g	
		Fraction Wt: 0.0002 g		Fraction Wt: 0.0001 g	
Comments:		Smpl Vol: 470 ml, Alqt: 470 ml, Factor 1.000		Smpl Vol: 470 ml, Alqt: 100 ml, Factor 4.700	
		Sample Wt: 0.0002 g		Sample Wt: 0.0005 g	

Note: Factor = Sample Volume/Aliquot Volume

Blank Solvent Wt: 0.0000 g

	RUN 0	RUN 1	RUN 2	RUN 3
Results of Solvent Phase g	0.0000	0.0002	0.0003	0.0002
Results of Aqueous Phase g	0.0000 D-15	0.0051	0.0009	0.0005

INTERPOL LABORATORIES, INC.
(612) 786-6020
Solvent Rinse Data Reporting Sheet

☒ EPA Method 5 Probe Wash ☐ EPA Method 29 Probe Wash ☐ EPA Method 202 Cup & Tube Wash

Job L.P. Hayward Source/Site DRYER RTD STACK
Date Submitted 2/23/96 Test No. 1
Date of Analysis 2/26/96 Technician D. VAN HOOVER

Transport Leakage ☐ None ☒ ml Solvent

Test:	1	Run: 0	Dish No:	63
Log No:	73.8 - 01P		Dish + Sample Wt:	50.4268 g
Volume of Solvent	100	ml	Dish Tare Wt:	50.4264 g
*Solvent Residue	4	ug/ml	Sample Wt:	.0004 g
Test:	1	Run: 1	Dish No:	310
Vol. of Solvent	100	ml	Dish + Sample Wt:	45.0735 g
Log Number	02P		Dish Tare Wt:	45.0626 g
Comments	2		Sample Wt:	.0109 g
Test:	1	Run: 2	Dish No:	306
Vol. of Solvent	100	ml	Dish + Sample Wt:	42.8412 g
Log Number	03P		Dish Tare Wt:	42.8345 g
Comments			Sample Wt:	.0067 g
Test:	1	Run: 3	Dish No:	867
Vol. of Solvent	100		Dish + Sample Wt:	45.6107 g
Log Number	04P		Dish Tare Wt:	45.6046 g
Comments			Sample Wt:	.0061 g

*Solvent Residue ug/ml = [(Sample Wt. .0004 g) (10⁶)] / Vol. of Sol. 100 ml

EPA-M5 Acetone Residue Blank Spec. ≤ 7.8 ug/ml

		RUN	RUN	RUN	RUN
Results of Solvent Rinse	g	D-16	.0105	.0067	.0057

INTERPOLL LABORATORIES, INC.
(612) 786-6020
Filter Gravimetrics Reporting Sheet

Filter Type: ☒ EPA Method 5 ☐ EPA Method 29 ☐ EPA Method 202 ☐ Other _____

Job: L.P. Hayward Source/Site: DRIVER RTO STACK
Date Submitted: 2/23/96 Test No.: _____
Date of Analysis: 2/27/96 Technician: D. VanHoover

Test: <u>1</u> Run: <u>0</u>	Filter No: <u>8355</u>
Field Blank:	Filter Type: <u>9F</u>
Log No: <u>7318-01F</u>	Filter + Sample Wt: <u>.9311</u> g
Color:	Filter Tare Wt: <u>.9307</u> g
	Sample Wt: <u>.0004</u> g
Test: <u>1</u> Run: <u>1</u>	Filter No: <u>8352</u>
Log No: <u>-02F</u>	Filter Type: <u>9F</u>
Color:	Filter + Sample Wt: <u>.9364</u> g
	Filter Tare Wt: <u>.9354</u> g
	Sample Wt: <u>.0010</u> g
Test: <u>1</u> Run: <u>2</u>	Filter No: <u>8353</u>
Log No: <u>-03F</u>	Filter Type: <u>9F</u>
Color:	Filter + Sample Wt: <u>.9359</u> g
	Filter Tare Wt: <u>.9355</u> g
	Sample Wt: <u>.0004</u> g
Test: <u>1</u> Run: <u>3</u>	Filter No: <u>8354</u>
Log No: <u>-04F</u>	Filter Type: <u>9F</u>
Color:	Filter + Sample Wt: <u>.9404</u> g
	Filter Tare Wt: <u>.9394</u> g
	Sample Wt: <u>.0010</u> g

	RUN	RUN	RUN	RUN
Results of Filter Analysis g		<u>.0010</u>	<u>.0004</u>	<u>.0010</u>

	RUN	RUN	RUN	RUN
Total Mass g		<u>0.0168</u>	<u>0.0079</u>	<u>0.0074</u>

INTERPOL LABORATORIES, INC.

(612) 786-6020

Impinger Catch Data Reporting Sheet

Protocol: ☐ Minnesota ☒ Wisconsin ☐ Iowa ☐ EPA Method 202 ☐ Other _____
 Job: LP1 Hayward Source/Site: Pres RTU / Stack
 Date Submitted: 2-23-96 Test No.: 9
 Date of Analysis: 2-29-96 Technician: B.O.

		Solvent Phase		Aqueous Phase	
Test: <u>9</u>	Run: <u>0</u>	Dish No: <u>745</u>		Dish No: <u>772</u>	
Log No: <u>7318-38I</u>		Dish + Sample Wt: <u>44.0310</u>	g	Dish + Sample Wt: <u>48.1620</u>	g
Color & Appearance:		Dish Tare Wt: <u>44.0310</u>	g	Dish Tare Wt: <u>48.1620</u>	g
		Fraction Wt: <u>0.0000</u>	g	Fraction Wt: <u>0.0000</u>	g
Comments:		Smpl Vol: <u>200</u> ml, Alqt: <u>200</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>200</u> ml, Alqt: <u>100</u> ml, Factor: <u>2.000</u>	
		Sample Wt: <u>0.0000</u>	g	Sample Wt: <u>0.0000</u>	g
Test: <u>9</u>	Run: <u>1</u>	Dish No: <u>746</u>		Dish No: <u>781</u>	
Log No: <u>-39I</u>		Dish + Sample Wt: <u>44.7978</u>	g	Dish + Sample Wt: <u>44.1026</u>	g
Color & Appearance:		Dish Tare Wt: <u>44.7972</u>	g	Dish Tare Wt: <u>44.0972</u>	g
		Fraction Wt: <u>0.0006</u>	g	Fraction Wt: <u>0.0054</u>	g
Comments:		Smpl Vol: <u>200</u> ml, Alqt: <u>200</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>200</u> ml, Alqt: <u>100</u> ml, Factor: <u>2.000</u>	
		Sample Wt: <u>0.0006</u>	g	Sample Wt: <u>0.0108</u>	g
Test: <u>9</u>	Run: <u>2</u>	Dish No: <u>797</u>		Dish No: <u>783</u>	
Log No: <u>-40I</u>		Dish + Sample Wt: <u>43.0493</u>	g	Dish + Sample Wt: <u>43.0887</u>	g
Color & Appearance:		Dish Tare Wt: <u>43.0486</u>	g	Dish Tare Wt: <u>43.0877</u>	g
		Fraction Wt: <u>0.0007</u>	g	Fraction Wt: <u>0.0010</u>	g
Comments:		Smpl Vol: <u>210</u> ml, Alqt: <u>210</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>210</u> ml, Alqt: <u>100</u> ml, Factor: <u>2.100</u>	
		Sample Wt: <u>0.0007</u>	g	Sample Wt: <u>0.0021</u>	g
Test: <u>9</u>	Run: <u>3</u>	Dish No: <u>894</u>		Dish No: <u>789</u>	
Log No: <u>-41I</u>		Dish + Sample Wt: <u>36.2138</u>	g	Dish + Sample Wt: <u>44.6898</u>	g
Color & Appearance:		Dish Tare Wt: <u>36.2121</u>	g	Dish Tare Wt: <u>44.6887</u>	g
		Fraction Wt: <u>0.0017</u>	g	Fraction Wt: <u>0.0011</u>	g
Comments:		Smpl Vol: <u>210</u> ml, Alqt: <u>210</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>210</u> ml, Alqt: <u>100</u> ml, Factor: <u>2.100</u>	
		Sample Wt: <u>0.0017</u>	g	Sample Wt: <u>0.0023</u>	g

Note: Factor = Sample Volume/Aliquot Volume

Blank Solvent Wt. 0.0000 g

	RUN <u>0</u>	RUN <u>1</u>	RUN <u>2</u>	RUN <u>3</u>
Results of Solvent Phase g	<u>0.0000</u>	<u>0.0006</u>	<u>0.0007</u>	<u>0.0017</u>
Results of Aqueous Phase g	<u>0.0000 D-18</u>	<u>0.0108</u>	<u>0.0021</u>	<u>0.0023</u>

INTERPOL LABORATORIES, INC.
(612) 786-6020
Solvent Rinse Data Reporting Sheet

☒ EPA Method 5 Probe Wash ☐ EPA Method 29 Probe Wash ☐ EPA Method 202 Cup & Tube Wash

Job L.P. Hayward Source/Site Press Rto Stack
Date Submitted 2/23/96 Test No. _____
Date of Analysis 2/26/96 Technician J. Van Hoever
Transport Leakage ☐ None ☒ _____ ml Solvent Acetone

Test:	9 Run: 0	Dish No:	618
Log No:	7318-38P	Dish + Sample Wt:	46.5690 g
Volume of Solvent	100 ml	Dish Tare Wt:	46.5686 g
*Solvent Residue	ug/ml	Sample Wt:	.0004 g
Test:	9 Run: 1	Dish No:	622
Vol. of Solvent	100 ml	Dish + Sample Wt:	48.8519 g
Log Number	39P	Dish Tare Wt:	48.8442 g
Comments		Sample Wt:	.0077 g
Test:	9 Run: 2	Dish No:	700
Vol. of Solvent	100 ml	Dish + Sample Wt:	43.0605 g
Log Number	40P	Dish Tare Wt:	43.0547 g
Comments		Sample Wt:	.0058 g
Test:	9 Run: 3	Dish No:	702
Vol. of Solvent	100	Dish + Sample Wt:	46.2288 g
Log Number	41P	Dish Tare Wt:	46.2220 g
Comments		Sample Wt:	.0068 g

*Solvent Residue 4 ug/ml = [(Sample Wt. .0004 g) (10⁶)]/Vol. of Sol. 100 ml
EPA-M5 Acetone Residue Blank Spec. ≤ 7.8 ug/ml

	RUN	RUN	RUN	RUN
Results of Solvent Rinse g	D-19	.0073	.0054	.0064

INTERPOLL LABORATORIES, INC.
(612) 786-6020
Filter Gravimetrics Reporting Sheet

Filter Type: ☒ EPA Method 5 ☐ EPA Method 29 ☐ EPA Method 202 ☐ Other _____

Job: L.P. Hayward Source/Site: Press RTO STACK
Date Submitted: 2/23/96 Test No.: 9
Date of Analysis: 2/26/96 Technician: D. Van Hoever

Test: <u>9</u> Run: <u>0</u>	Filter No: <u>8469</u>
Field Blank:	Filter Type:
Log No: <u>7318-38E</u>	Filter + Sample Wt: <u>9502</u> g
Color:	Filter Tare Wt: <u>9502</u> g
	Sample Wt: <u>0</u> g
Test: <u>9</u> Run: <u>1</u>	Filter No: <u>8326</u>
Log No: <u>039E</u>	Filter Type:
Color:	Filter + Sample Wt: <u>9267</u> g
	Filter Tare Wt: <u>.9264</u> g
	Sample Wt: <u>.0003</u> g
Test: <u>9</u> Run: <u>2</u>	Filter No: <u>8327</u>
Log No: <u>040F</u>	Filter Type:
Color:	Filter + Sample Wt: <u>.9372</u> g
	Filter Tare Wt: <u>.9324</u> g
	Sample Wt: <u>.0048</u> g
Test: <u>9</u> Run: <u>3</u>	Filter No: <u>8328</u>
Log No: <u>041F</u>	Filter Type:
Color:	Filter + Sample Wt: <u>.9323</u> g
	Filter Tare Wt: <u>.9314</u> g
	Sample Wt: <u>.0009</u> g

	RUN	RUN	RUN	RUN
Results of Filter Analysis g		<u>.0003</u>	<u>.0048</u>	<u>.0009</u>

	RUN	RUN	RUN	RUN
Total Mass g		<u>0.0190</u>	<u>0.0130</u>	<u>0.0113</u>

INTERPOL LABORATORIES, INC.

(612) 786-6020

Impinger Catch Data Reporting Sheet

tocol:

☐ Minnesota ☒ Wisconsin ☐ Iowa☐ EPA Method 202 ☐ Other

Source/Site

Line / Thermal Oil Heater / Stack

Test No.

17

Technician

B.D.

Date Submitted

2-23-96

Date of Analysis

2-29-96

		Solvent Phase		Aqueous Phase	
Test: 17	Run: 0	Dish No: 800		Dish No: 811	
Log No: 7318-82I		Dish + Sample Wt: 45.6110 g		Dish + Sample Wt: 43.3631 g	
Color & Appearance:		Dish Tare Wt: 45.6110 g		Dish Tare Wt: 43.3631 g	
		Fraction Wt: 0.0000 g		Fraction Wt: 0.0000 g	
Comments:		Smpl Vol: 200 ml, Alqt: 200 ml, Factor: 1.000		Smpl Vol: 200 ml, Alqt: 100 ml, Factor: 2.000	
		Sample Wt: 0.0000 g		Sample Wt: 0.0000 g	
Test: 17	Run: 1	Dish No: 803		Dish No: 812	
Log No: -83I		Dish + Sample Wt: 47.5197 g		Dish + Sample Wt: 45.2472 g	
Color & Appearance:		Dish Tare Wt: 47.5186 g		Dish Tare Wt: 45.2062 g	
		Fraction Wt: 0.0011 g		Fraction Wt: 0.0410 g	
Comments:		Smpl Vol: 280 ml, Alqt: 280 ml, Factor: 1.000		Smpl Vol: 280 ml, Alqt: 100 ml, Factor: 2.800	
		Sample Wt: 0.0011 g		Sample Wt: 0.1148 g	
Test: 17	Run: 2	Dish No: 804		Dish No: 813	
Log No: -84I		Dish + Sample Wt: 46.6849 g		Dish + Sample Wt: 45.5796 g	
Color & Appearance:		Dish Tare Wt: 46.6838 g		Dish Tare Wt: 45.5691 g	
		Fraction Wt: 0.0011 g		Fraction Wt: 0.0105 g	
Comments:		Smpl Vol: 310 ml, Alqt: 310 ml, Factor: 1.000		Smpl Vol: 310 ml, Alqt: 100 ml, Factor: 3.100	
		Sample Wt: 0.0011 g		Sample Wt: 0.0326 g	
Test: 17	Run: 3	Dish No: 805		Dish No: 814	
Log No: -85I		Dish + Sample Wt: 45.1098 g		Dish + Sample Wt: 45.1017 g	
Color & Appearance:		Dish Tare Wt: 45.1086 g		Dish Tare Wt: 45.1014 g	
		Fraction Wt: 0.0012 g		Fraction Wt: 0.0003 g	
Comments:		Smpl Vol: 290 ml, Alqt: 290 ml, Factor: 1.000		Smpl Vol: 290 ml, Alqt: 100 ml, Factor: 2.900	
		Sample Wt: 0.0012 g		Sample Wt: 0.0009 g	

Note: Factor = Sample Volume/Aliquot Volume

Blank Solvent Wt: 0.0000 g

	RUN 0	RUN 1	RUN 2	RUN 3
Results of Solvent Phase g	0.0000	0.0011	0.0011	0.0012
Results of Aqueous Phase g	0.0000 D-21	0.1148	0.0326	0.0009

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Solvent Rinse Data Reporting Sheet

☒ EPA Method 5 Probe Wash☐ EPA Method 29 Probe Wash☐ EPA Method 202 Cup & Tube Wash

Job

L.P. Hayward

Source/Site

Thermal Oil Heater

Date Submitted

2/23/96

Test No.

17

Date of Analysis

2/26/96

Technician

D. Van HoeverTransport Leakage ☐None ☐

ml

Solvent

Acetone

Test:	<u>17</u> Run: <u>0</u>	Dish No:	<u>855</u>
Log No:	<u>7318-82P</u>	Dish + Sample Wt:	<u>44.2649</u> g
Volume of Solvent	<u>205</u> ml	Dish Tare Wt:	<u>44.2638</u> g
*Solvent Residue	ug/ml	Sample Wt:	<u>.0011</u> g
Test:	<u>17</u> Run: <u>1</u>	Dish No:	<u>209</u>
Vol. of Solvent	<u>150</u> ml	Dish + Sample Wt:	<u>43.4208</u> g
Log Number	<u>-83P</u>	Dish Tare Wt:	<u>42.2097</u> g
Comments		Sample Wt:	<u>.2111</u> g
Test:	<u>17</u> Run: <u>2</u>	Dish No:	<u>105</u>
Vol. of Solvent	<u>150</u> ml	Dish + Sample Wt:	<u>47.9327</u> g
Log Number	<u>-84P</u>	Dish Tare Wt:	<u>47.8654</u> g
Comments		Sample Wt:	<u>.0673</u> g
Test:	<u>17</u> Run: <u>3</u>	Dish No:	<u>93</u>
Vol. of Solvent	<u>150</u>	Dish + Sample Wt:	<u>54.1993</u> g
Log Number	<u>-85P</u>	Dish Tare Wt:	<u>53.9840</u> g
Comments		Sample Wt:	<u>.2153</u> g

*Solvent Residue 5.36 ug/ml = [(Sample Wt. .0011 g) (10⁶)]/Vol. of Sol. 205 ml

EPA-M5 Acetone Residue Blank Spec. ≤ 7.8 ug/ml

	RUN	RUN	RUN	RUN	
Results of Solvent Rinse	8	D-22	.2103	.0665	.2145

INTERPOLL LABORATORIES, INC.
(612) 786-6020
Filter Gravimetrics Reporting Sheet

Filter Type: ☒ EPA Method 5 ☐ EPA Method 29 ☐ EPA Method 202 ☐ Other _____

Job: L.P. Hayward Source/Site: Thermal Oil Heater Stack
Date Submitted: 2/23/96 Test No.: 17
Date of Analysis: 2/27/96 Technician: D. Van Hoever

Test:	17 Run: 0	Filter No:	8283
Field Blank:		Filter Type:	9. F
Log No:	7318-82F	Filter + Sample Wt:	.9321 g
Color:		Filter Tare Wt:	.9316 g
		Sample Wt:	.0005 g
Test:	17 Run: 1	Filter No:	8281
Log No:	7318-83F	Filter Type:	9. F
Color:		Filter + Sample Wt:	1.1714 g
		Filter Tare Wt:	.9221 g
		Sample Wt:	.2493 g
Test:	17 Run: 2	Filter No:	8387
Log No:	7318-84F	Filter Type:	9. F
Color:		Filter + Sample Wt:	1.4148 g
		Filter Tare Wt:	.9321 g
		Sample Wt:	.4827 g
Test:	17 Run: 3	Filter No:	8282
Log No:	7318-85F	Filter Type:	9. F
Color:		Filter + Sample Wt:	1.1724 g
		Filter Tare Wt:	.9284 g
		Sample Wt:	.2437 g

	RUN	RUN	RUN	RUN
Results of Filter Analysis g		.2493	.4827	.2437

	RUN	RUN	RUN	RUN
Total Mass g		0.5755	0.5829	0.4603

3/8/96

Data Reporting Sheet

1D020/LP Hayward

CLIENT NO:

P.O. NO:

PROJECT MGR:

PHONE:

DATE:

CONTACT:

LABORATORY REPORT #:

SAMPLES COLLECTED:

SAMPLES RECEIVED:

Invoicing	Signature	Report Routing
-----------	-----------	-------------------

SAMPLE ID:

PL
Lab Mgr
Ino Mgr
Org Mgr

100

□ □ □ □

四三二一

SAMPLE TYPE:

LOS NO:

Dryer RTO Stack			
1/1	1/2	1/3	
1.G.S.	→		
7318-05	-06	-07	-

[illegible]

Footnotes:

In-House Comments:

Interpoll Laboratories
(612) 786-6020

Data Reporting Sheet

CLIENT: 1D020/LP Hayward

JOB: _____
CLIENT NO: _____
P.O. NO: _____
PROJECT MGR: _____

PHONE: _____

DATE: _____

CONTACT: _____

LABORATORY REPORT #: _____
SAMPLES COLLECTED: _____
SAMPLES RECEIVED: _____

Invoicing		Signature	Report Routing

SAMPLE ID:

PL			
Lab Mgr			
Ino Mgr			
Org Mgr			

SAMPLE TYPE:

LOS NO:

Line / Surface Dryer Duct			
8/1	8/2	8/3	
1.6.5.	→		
7318-107	-108	-109	

[illegible]

Footnotes:

In-House Comments:

3/8/96

Data Reporting Sheet

PROJECT MGR: _____

DATE: _____

SAMPLES RECEIVED: _____

LOS NO:

Press Up at RTD Stack

9/1	9/2	9/3	
1.G.5.			
7318-42	-43	-44	-

[illegible]

In-House Comments:

Interpoll Laboratories, Inc.
(612)786-6020

Client: 1D020 / LP Hayward

Sample Collected: _____

Sample Received: _____

Sample Log #: 7318-31

Sample Description: 5/0

Parameter	Units	Analysis Date & Initials	FRONT			BACK		
			Detection Limit Front	Analytical Result Front	Method Blank Front	Detection Limit Back	Analytical Result Back	Method Blank Back
Benzene	Total ug	MMN	2.1	Box	Box	0.61	Box	Box
	Total ug	2-2796						
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
Dilution factor								

Footnotes: _____

In-House Comments: _____

LCI-136

Interpoll Laboratories, Inc.
(612)786-6020

Client: 1D020 / LP Hayward

Sample Received: _____

Sample Log #: 7318-34

Sample Description: 5/2

			FRONT			BACK		
Parameter	Units	Analysis Date & Initials	Detection Limit Front	Analytical Result Front	Method Blank Front	Detection Limit Back	Analytical Result Back	Method Blank Back
Benzene	Total ug	JMMW	0.1	17	RX	0.101	PALL	RX
	Total ug	2296						
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
Dilution factor								

Footnotes: _____

In-House Comments: _____

LCI-136

Interpoll Laboratories, Inc.
(612)786-6020

Air Samples (Charcoal Tubes) by NIOSH Method 1501 Data Reporting Sheet

Client: 1D020 / LP Hayward

Sample Collected: _____

Sample Received: _____

Sample Log #: 7318-36

Sample Description: 5/3

		Analysis	FRONT			BACK		
		Date &	Detection	Analytical	Method	Detection	Analytical	Method
		(Initials)	Limit	Result	Blank	Limit	Result	Blank
Parameter	Units		Front	Front	Front	Back	Back	Back
Benzene	Total ug	MN	2.1	17	RK	N.LOI	BK	RK
	Total ug	ZAFV6						
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
Dilution factor								

Footnotes: _____

In-House Comments: _____

2003/2/12

Interpoll Laboratories, Inc.
(612)786-6020

Air Samples (Charcoal Tubes) by NIOSH Method 1501 Data Reporting Sheet

Client: 10020 / LP Hayward

Sample Collected: _____
Sample Received: _____
Sample Log #: 7318-68
Sample Description: 15/1

Parameter	Units	Analysis Date & Initials	FRONT			BACK		
			Detection Limit Front	Analytical Result Front	Method Blank Front	Detection Limit Back	Analytical Result Back	Method Blank Back
Benzene	Total ug	<u>MMX</u>	<u>2.1</u>	<u>BDL</u>	<u>BDL</u>	<u>0.101</u>	<u>BDL</u>	<u>BDL</u>
	Total ug	<u>2.2710</u>						
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
Dilution factor								

Footnotes: _____

In-House Comments: _____

INTERPOLL LABORATORIES INC.

Formaldehyde Results Using EPA Method 0011
For Dept. 20/LP Hayward
Collected 2/21-22/96


	Field Spike #1			Test: 2		Source: Dryer RTO Stack	
	Actual	Found	% Recovery	Run 0	Run 1	Run 2	Run 3
Log #		(7318-09)		(7318-08)	(7318-10)	(7318-11)	(7318-12)
Mass (ug)*	750	490	65.3	< 0.50	11000	12000	14000

	Field Spike #2			Test: 12		Source: Press Vent RTO Stack	
	Actual	Found	% Recovery	Run 0	Run 1	Run 2	Run 3
Log #		(7318-55)		(7318-56)	(7318-57)	(7318-58)	(7318-59)
Mass (ug)*	750	630	84.0	< 0.50	690	560	670

	Field Spike #3			Test: 16		Source: Line 1 Thermal Oil Heater Stack	
	Actual	Found	% Recovery	Run 0	Run 1	Run 2	Run 3
Log #		(7318-75)		(7318-74)	(7318-76)	(7318-77)	(7318-78)
Mass (ug)*	750	640	85.3	< 0.50	130	150	130

* = Total Mass of formaldehyde in the sample in ug. The laboratory method blanks contained 1.1ug and 0.66ug.

Reviewed by:



David J. Schneider, Manager
Chemistry Department

INTERPOLL LABORATORIES INC.

Phenol Result By EPA Method 8270
For Dept. 20/ LP Hayward
Collected 2/20-21/96

	Test 3				Source: Dryer RTO Stack
	Run 0	Run 1	Run 2	Run 3	
Log #	7318-16/17	7318-18/19	7318-20/21	7318-22/23	
Analysis Date	3/07/96	3/07/96	3/07/96	3/07/96	
Phenol*	< 840	< 840	< 840	< 840	
2-Fluorophenol**	55.0	16.2	18.1	18.5	
D6-Phenol**	44.7	27.5	26.7	28.7	
2,4,6-Tribromophenol***	69.4	93.1	72.8	89.9	


	Test 19				Source: Line 1 Thermal Oil Heater Stack
	Run 0	Run 1	Run 2	Run 3	
Log #	7318-86/87	7318-88/89	7318-90/91	7318-92/93	
Analysis Date	3/07/96	3/07/96	3/07/96	3/07/96	
Phenol*	< 840	< 840	< 840	< 840	
2-Fluorophenol**	65.8	32.0	39.3	39.7	
D6-Phenol**	48.7	44.7	50.9	51.5	
2,4,6-Tribromophenol***	76.3	81.2	94.5	94.2	

* = Total mass of the specified compound in the sample in ug.

** = Percent recovery of the field surrogate. (59800 ug 2-Fluorophenol and
5002 ug Phenol-D6 was added to the impinger solution before sampling.)

*** = Percent recovery of the lab surrogates.

Reviewed by:



David J. Schneider, Manager
Chemistry Department

INTERPOLL LABORATORIES INC.

4,4-Methylenebis(phenyl isocyanate) Results
For Dept. 20/LP Hayward
Collected 2/22/96

Item	Field Spike 1			Field Spike 2			Test: 11	Source: Press Vent RTO Stack			
	Actual	Found	% Rec.	Actual	Found	% Rec.	Run 0	Run 1	Run 2	Run 3	
EPA Draft Method 1,2-PP											
Log #		7318-46			7318-47		7318-45	7318-48	7318-49	7318-50	
MDI (ug)*	323	319	98.8	323	316	97.8	< 6.2	< 6.2	< 6.2	< 6.2	

* = Total mass of MDI in the sample in ug.

Reviewed by:



David J. Schneider, Manager
Chemistry Department

INTERPOLL LABORATORIES INC.

Polycyclic Organic Matter Results By EPA Method 8270
For Dept. 20/LP Hayward, Collected 2/19-22/96

	Test : 4				Source: Dryer RTO Stack			
	Run 0	Run 1	Run 2	Run 3				
Log #	7318-24	7318-25	7318-26	7318-26				
Compounds of Interest								
Benz(a)anthracene*	< 1.8	< 1.8	< 1.8	< 1.8				
Benzo(b)fluoranthene*	< 0.99	< 0.99	< 0.99	< 0.99				
Benzo(a)pyrene*	< 1.2	< 1.2	< 1.2	< 1.2				
Dibenz(a,h)acridine*	< 15	< 15	< 15	< 15				
Dibenz(a,j)acridine*	< 1.6	< 1.6	< 1.6	< 1.6				
Dibenz(a,h)anthracene*	< 0.88	< 0.88	< 0.88	< 0.88				
7H-Dibenzo(c,g)carbazole*	< 1.2	< 1.2	< 1.2	< 1.2				
Dibenzo(a,h)pyrene*	< 20	< 20	< 20	< 20				
Dibenzo(a,i)pyrene*	< 20	< 20	< 20	< 20				
Indeno(1,2,3-cd)pyrene*	< 0.90	< 0.90	< 0.90	< 0.90				
Field Surrogate Recovery								
D10-Fluoranthene**	66.0	102	80.3	69.2				
Lab Surrogate Recovery								
D5-Nitrobenzene***	59.0	97.8	76.8	58.7				
2-Fluorobiphenyl***	74.7	96.8	83.3	67.3				
D14-Terphenyl***	83.6	107	92.5	75.7				

	Test : 14				Source: Line 1 Thermal Oil Heater Stack			
	Run 0	Run 1	Run 2	Run 3				
Log #	7318-63	7318-64	7318-65	7318-66				
Compounds of Interest								
Benz(a)anthracene*	< 1.8	< 1.8	< 1.8	1.8				
Benzo(b)fluoranthene*	< 0.99	< 0.99	5.0	5.8				
Benzo(a)pyrene*	< 1.2	< 1.2	5.2	5.8				
Dibenz(a,h)acridine*	< 15	< 15	< 15	< 15				
Dibenz(a,j)acridine*	< 1.6	< 1.6	< 1.6	< 1.6				
Dibenz(a,h)anthracene*	< 0.88	< 0.88	< 0.88	< 0.88				
7H-Dibenzo(c,g)carbazole*	< 1.2	< 1.2	< 1.2	< 1.2				
Dibenzo(a,h)pyrene*	< 20	< 20	< 20	< 20				
Dibenzo(a,i)pyrene*	< 20	< 20	< 20	< 20				
Indeno(1,2,3-cd)pyrene*	< 0.90	< 0.90	9.9	8.4				
Field Surrogate Recovery								
D10-Fluoranthene**	62.1	42.3	86.6	71.3				
Lab Surrogate Recovery								
D5-Nitrobenzene***	51.9	47.3	70.4	60.8				
2-Fluorobiphenyl***	67.8	47.0	89.5	75.6				
D14-Terphenyl***	80.0	50.4	99.2	84.2				

* = Total mass of the specified compound in the sample in ug.

** = Percent recovery of the field surrogate.

*** = Percent recovery of the lab surrogates.

Reviewed by:

David J. Schneider

David J. Schneider, Manager
Chemistry Department

Interpoll Laboratories
(612) 786-6020

XAD-2 & VOST Trap Preparation Work
Order Form

Project Name: CP Hayward Order Date: 2-16-96
Date Required: 2-16-96 Delivery Date: 2-16-96

Number of XAD-2 Traps Required: 8

Number of VOST Tubes Required: _____ Tenax
_____ Tenax/Charcoal

XAD-2 TRAP HISTORY

XAD-2 Lot Number: 2077 Date of Spiking: 2-16-96
XAD-2 Lot Date: _____ Technician: MRR/ED
XAD-2 Lot Technician: All tech

Nature of Spiking Material	Spike Concentration	Spike Volume	Total Mass of Spike
D ₁₀ -Fluorathene <u>95078-9-1</u>	<u>4.0ug/ml</u>	<u>5.0uL</u>	<u>20.0ug</u>

VOST TUBE HISTORY

Date of Thermal Desorption: _____ Technician: _____
Total Hydrocarbon Analysis: _____ ppm

SPECIAL REQUIREMENTS

****Please return this form with the samples.**

LOA-10RR

Interpoll Laboratories
(612) 786-6020

IMPINGER CATCHES

Project Name: LP/Hayward Order Date: 2-12-96
Date Required: 2-16-96 Delivery Date: 2-16-96 B.D.

Nature of Spiking Material	Spike Concentration	Spike Volume	Total Mass of Spike
D-6 Phenol	5.002 mg/ml	1.0 mL	5.002 mg
2-fluorophenol	50.096 mg/ml	1.2 mL	60.115 mg

SPECIAL REQUIREMENTS

**Please return this form with the samples.

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job Field Engineer LP Hayward Source Stack Log No. 7318
ESUS Date of Test 2-20-96 Site 1 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
4	Probe Wash: ☒ Acetone ☐ MeCl ₂	☒ EPA M-5 ☐ EPA M-29		
4	Filter: ☒ 4" Glass ☐ 1 SS Thimble	☒ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
4	Impingers: ☒ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ IMN Protocol ☒ IAWI Protocol ☐ EPA M-202 ☐ EPA M6,8 ☐ Acid Gases		
3	Integrated Gas: ☒ Recirc Bag	☒ EPA M-3 <u>for methane</u>		
—	Oxides of Nitrogen:	☐ EPA M-7A		
—	Fuel Lab: ☐ Fuel Sample	☐ Per S-0163		
—	Particle Sizing:	☐ X-Ray Sdgraph ☐ Cascade Imp		
—	Miscellaneous:	☐		

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
 Wood: ☐ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☒ Natural Gas ☐ RDF ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>ESUS / Interpoll</u>	<u>Stack / Interpoll</u>	<u>2-23-96</u>

INTERPOL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody


Job Field Engineer L.P. Hayward Source Dryer RTO Date of Test 2-21-96

Log No. 2318
No. of Runs 3

Site Stacks
Test No. 2

No. Items	Sample Type	Analysis	Sequence No.	Comments
5	Probe Wash: ☐ Acetone ☒ MeCl ₂	☐ EPA M-5 ☐ EPA M-29	☐ EPA M-201A ☒ 0011	
—	Filter: ☐ 4" Glass ☐ SS Thimble	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A	☐ EPA M-17	
5	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☒ 2.4-DNPH	☐ IMN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases	☐ IIA Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☒ 0011	
3	Integrated Gas: ☒ Tedlar Bag	☒ EPA M-3 ☐ EPA M-7A	☐ EPA M-10	
—	Oxides of Nitrogen:			
—	Fuel Lab: ☐ Fuel Sample	☐ Per S-0163		
—	Particle Sizing:	☐ X-Ray Scatgraph ☐ Cascade Imp		
5	Miscellaneous: ☒ mecl ₂ (sp. spec)			

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
Wood: ☐ Wood Waste ☐ Dust ☐ Bark
Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
Misc: ☒ Natural Gas ☐ RDF ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
	<u>CLD / Interpoll</u>	<u>0830 2/23/96</u>

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Sample Chain of Custody

Job L. P. Hayward Source Dryer RTO Site Stack Log No. 7318
Field Engineer ESJS Date of Test 2-20-96 Test No. 3 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
—	Probe Wash: ☐ DI Water ☐ Acetone ☐ MeCl ₂	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
—	Filter: ☐ 4" Glass ☐ SS Thimble	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
11	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH ☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☒ KMnO ₄ /H ₂ SO ₄ ☒ Phenol	☐ MN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases ☐ IA Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☒ 8270		
—	Integrated Gas: ☐ Tedlar Bag	☐ EPA M-3 ☐ EPA M-10		
—	Oxides of Nitrogen:	☐ EPA M-7A ☐ Per S-0163		
—	Fuel Lab: ☐ Fuel Sample ☐ Aggregate	☐ X-Ray Sdgraph ☐ Cascade Imp		
—	Particle Sizing:			
—	Miscellaneous:			

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
Misc: ☒ Natural Gas ☐ RDF ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>ESJS</u> <u>Interpoll</u>	<u>CL</u> <u>Interpoll</u>	<u>0830</u> <u>2-23-96</u>

INTERPOL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Log No. 7318
No. of Runs 3

Job L.P. Hayward Source Dryer RTO Site Stack

Field Engineer E. J. Vers Date of Test 2-21-96 Test No. 4

No. Items	Sample Type	Analysis	Sequence No.	Comments
<u>54</u>	Probe Wash: ☒ Acetone ☒ MeCl ₂	☐ DI Water ☐ _____	☐ EPA M-5 ☐ EPA M-29	☐ EPA M-201A ☒ <u>0010</u>
<u>4</u>	Filter: ☒ 4" Glass ☐ 55 Thimble	☐ Pallflex ☐ 2.5" Glass	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A	☐ EPA M-17 ☒ <u>0010</u>
<u>6</u>	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☐ KMnO ₄ /H ₂ SO ₄ ☒ Condenser	☐ MN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M6.8 ☐ Acid Gases	☐ IA Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☒ <u>0010</u>
<u>3</u>	Integrated Gas: ☒ Tedlar Bag	☐ _____	☒ EPA M-3 ☐ _____	☐ EPA M-10
	Oxides of Nitrogen:		☐ EPA M-7A ☐ _____	
	Fuel Lab: ☐ Fuel Sample	☐ Aggregate	☐ Per S-0163	
	Particle Sizing:		☐ X-Ray Scdgraph ☐ _____	☐ Cascade Imp
<u>4</u>	Miscellaneous:	☒ Resin Cartridge	☒ <u>0010</u>	

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
Wood: ☐ Wood Waste ☐ Dust ☐ Bark
Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
Misc: ☒ Natural Gas ☐ RDF ☐ _____

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>[Signature]</u> <u>Interpoll</u>	<u>Chad</u> <u>Interpoll</u>	<u>2-23-96</u>

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job Field Engineer C.P. Hayward Source Dyer RTO Date of Test 12-20-96 Site Stack Log No. 7318
ESJers Test No. 5 No. of Runs 6

No. Items	Sample Type	Analysis	Sequence No.	Comments
—	Probe Wash: ☐ Acetone ☐ MeCl ₃	☐ DI Water ☐ _____	☐ EPA M-5 ☐ EPA M-29	☐ EPA M-201A ☐ _____
—	Filters: ☐ 4" Glass ☐ SS Thimble	☐ Pallflex ☐ 2.5" Glass	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A	☐ EPA M-17 ☐ _____
—	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☐ KMnO ₄ /H ₂ SO ₄ ☐ _____	☐ MN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases	☐ IIA Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☐ _____
—	Integrated Gas: ☐ Tedlar Bag	☐ _____	☐ EPA M-3 ☐ _____	☐ EPA M-10 ☐ _____
—	Oxides of Nitrogen:		☐ EPA M-7A ☐ _____	☐ _____
—	Fuel Lab: ☐ Fuel Sample	☐ Aggregate	☐ Per S-0163	☐ _____
—	Particle Sizing:		☐ X-Ray Scograph ☐ _____	☐ Cascade Imp ☐ _____
<u>4</u>	Miscellaneous:	<u>4 Charcoal tubes</u>	<u>4 M-18 Benzene</u>	☐ _____

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
 Wood: ☐ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☒ Natural Gas ☐ RDF ☐ _____

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>[Signature]</u> / Interpoll Labs	<u>[Signature]</u> / Interpoll 0850	2-23-96

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Sample Chain of Custody

Job Field Engineer L.P. / Highway Source MS / Caehler Date of Test 2-21-96

Site Spach Log No. 7310
Test No. 9 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
3 + 1	Probe Wash: ☒ DI Water ☐ MeCl ₂	☒ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
3 + 1	Filler: ☒ 4" Glass ☐ SS Thimble	☒ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
3 + 1	Impingers: ☒ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ MN Protocol ☒ SWI Protocol ☐ EPA M-202 ☐ EPA M-29 ☐ EPA M-26 ☐ Acid Gases ☐ IA Protocol ☐ Formaldehyde ☐ EPA M-10		
3	Integrated Gas: ☒ Medlar Bag	☒ EPA M-3 ☒ Methane ☐ EPA M-7A ☐ Per 5-0163		
-	Oxides of Nitrogen:			
-	Fuel Lab: ☐ Fuel Sample ☐ Aggregate			
-	Particle Sizing:	☐ X-Ray Sdgraph ☐ Cascade Imp		
-	Miscellaneous:			

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
Misc: ☒ Natural Gas ☐ RDF ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>Mark Gaehler / Interpoll Labs</u>	<u>OWS / Interpoll</u>	<u>0830 2/23/96</u>

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Sample Chain of Custody

Job Field Engineer L.P. / Hayward, WI Source W. Koehler Date of Test 1-22-96 Site Steeb Test No. 11 Log No. 7318 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
-	Probe Wash: ☐ Acetone ☐ MeCl ₂	☐ EPA M-5 ☐ EPA M-29		
-	DI Water ☐	☐ EPA M-201A ☐		
-	Filter: ☐ 4" Glass ☐ 55 Thimble	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
6	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ MN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases		
3	Integrated Gas: ☐ Acetone	☐ EPA M-3 ☐		
-	Oxides of Nitrogen:	☐ EPA M-7A ☐		
-	Fuel Lab: ☐ Fuel Sample	☐ Per S-0163		
-	Particle Sizing:	☐ X-Ray Sdgraph ☐		
-	Miscellaneous: ☐	☐		

Misc: ☒ Natural Gas
☐ IRDF
☐

Oil: ☐ Waste Oil
☐ No. 2
☐ No. 6

Wood: ☐ Wood Waste
☐ Dust
☐ Bark

Fuel Type: Coal: ☐ Bituminous
☐ Anthracite
☐ Lignite

Relinquished by/Affiliation	Accepted by/Affiliation	Date
Mark Koehler / Interpoll Labs	Ans / Interpoll	0830 2/23/96

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job 4. P. / August, WI Source Mr. Koehler Date of Test 2-22-96 Site Stack Log No. 7319
Field Engineer Mr. Koehler Test No. 12 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
1	Probe Wash: ☐ Acetone ☐ MeCl ₃	☐ DI Water ☐ _____		<u>Added to Impinger</u>
1	Filter: ☐ 4" Glass ☐ SS Thimble	☐ Pallflex ☐ 2.5" Glass		
3 + + + + +	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☒ H ₂ SO ₄ ☐ 4-DNPH	☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☐ KMnO ₄ /H ₂ SO ₄ ☐ _____		
1	Integrated Gas: ☐ Tedlar Bag	☐ _____		
1	Oxides of Nitrogen:			
1	Fuel Lab: ☐ Fuel Sample	☐ Aggregate		
1	Particle Sizing:			
1	Miscellaneous: ☐ _____			

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
Misc: ☒ Natural Gas ☐ RDF ☐ _____

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>Mark Koehler / Interpoll Labs</u>	<u>Ch. Koehler / Interpoll</u>	<u>02/23/96</u>

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job L.P. Hayward Source Line 1 Thermal Oil Site Stack Log No. 7318
 Field Engineer D.A. Date of Test 2/22/96 Test No. 15 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
	Probe Wash: ☐ Acetone ☐ MeCl ₃	☐ DI Water ☐ _____	☐ EPA M-5 ☐ EPA M-29	☐ EPA M-201A ☐ _____
	Filter: ☐ 4" Glass ☐ SS Thimble	☐ Pallflex ☐ 2.5" Glass	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A	☐ EPA M-17
	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☐ KMnO ₄ /H ₂ SO ₄ ☐ _____	☐ MN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases	☐ I/A Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☐ _____
	Integrated Gas: ☐ Tedlar Bag	☐ _____	☐ EPA M-3 ☐ _____	☐ EPA M-10
	Oxides of Nitrogen:		☐ EPA M-7A ☐ _____	
	Fuel Lab: ☐ Fuel Sample	☐ Aggregate	☐ Per S-0163	
	Particle Sizing:		☐ X-Ray Sdgraph ☐ _____	☐ Cascade Imp
4	Miscellaneous:	<u>Chemical</u>	<u>2/22/96</u>	

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
 Wood: ☐ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☐ Natural Gas ☐ RDF ☐ _____

Relinquished by/Affiliation <u>L.P. Hayward</u>	Accepted by/Affiliation <u>WJ Interpoll</u>	Date <u>2/22/96</u>
		<u>1000 2/23/96</u>

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job L.P. Hayward Source Line 1 Oil Heater Stack Site Log No. 7318
 Field Engineer D.W. Date of Test 2/22/96 Test No. 16 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
3	Probe Wash: ☐ Acetone ☒ DI Water ☐ MeCl ₄	☐ EPA M-5 ☐ EPA M-29		
	Filter: ☐ 4" Glass ☐ 55 Thimble	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
5	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☒ 2,4-DNPH	☐ MN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases		3 + 1 blank OK 1 Spike
1	Integrated Gas: ☒ Tedlar Bag	☒ EPA M-3 ☐ EPA M-10		
	Oxides of Nitrogen:	☐ EPA M-7A ☐		
	Fuel Lab: ☐ Fuel Sample	☐ Per S-0163		
	Particle Sizing:	☐ X-Ray Scdgraph ☐ Cascade Imp		
	Miscellaneous:	☐		

Fuel Type: Coal: ☐ Bituminous ☐ Wood Waste: ☐ Wood ☐ Wood Waste
☐ Anthracite ☐ Dust ☐ Bark
☐ Lignite ☐ Misc: ☐ Natural Gas ☐ RDF ☐

Retrieved by/Affiliation	Accepted by/Affiliation	Date
<u>Diane Van Hoey</u>	<u>Chad Interpol</u>	<u>2/22/96</u>
		<u>2/23/96</u>

INTERPOL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job Field Engineer L.R. Hayward

Source Line 1, Thermal Oil Heater Stack

Log No. 7318

No. of Runs 3

Date of Test 2/21/96

Test No. 17

No. Items	Sample Type	Analysis	Sequence No.	Comments
4	Probe Wash: ☒ Acetone ☐ MeCl ₂	☒ DI Water ☐ _____	☐ EPA M-5 ☐ EPA M-29	
4	Filter: ☒ 4" Glass ☐ SS Thimble	☐ Pallflex ☐ 2.5" Glass	☒ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A	
4	Impingers: ☒ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☐ KMnO ₄ /H ₂ SO ₄ ☐ _____	☐ MN Protocol ☒ FWI Protocol ☐ EPA M-202 ☐ EPA M6,8 ☐ Acid Gases	
3	Integrated Gas: ☒ Tedlar Bag	☐ _____	☒ EPA M-3 ☐ _____	
	Oxides of Nitrogen:	☐ _____	☐ EPA M-7A ☐ _____	
	Fuel Lab: ☐ Fuel Sample	☐ Aggregate	☐ Per S-0163	
	Particle Sizing:	☐ _____	☐ X-Ray Sdgraph ☐ Cascade Imp	
	Miscellaneous:	☐ _____	☐ _____	

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
 Wood: ☐ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☐ Natural Gas ☐ RDF ☐ _____

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>Dwaine Van Haver</u>	<u>Chad Interpoll</u>	<u>2/22/96</u>
		<u>2/23/96 1500</u>

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job Field Engineer L.P. Hayward Source Stack Date of Test 2/21/96 Site Line 1 Thermal Log No. 7318 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
	Probe Wash: ☐ Acetone ☐ MeCl ₂	☐ EPA M-5 ☐ EPA M-29		
	Filler: ☐ 4" Glass ☐ 5" Thimble	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
4	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH <u>H₂SO₄</u> <u>HNO₃/H₂O₂</u> <u>KMnO₄/H₂SO₄</u> <u>7 A + B Sp. Phenol</u>	☐ MN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M-6, B ☐ Acid Gases ☐ 1A Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☒ X		
	Integrated Gas: ☐ Tedlar Bag	☐ EPA M-3 ☐ EPA M-10		
	Oxides of Nitrogen:	☐ EPA M-7A ☐ Per S-0163		
	Fuel Lab: ☐ Fuel Sample ☐ Aggregate	☐ X-Ray Sdgraph ☐ Cascade Imp		
	Particle Sizing:			
	Miscellaneous: ☐			

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
Misc: ☐ Natural Gas ☐ RDF ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>Diane Van Haver</u>	<u>Chris Interpoll</u>	<u>2/21/96</u>
		<u>2/22/96 1000</u>

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Sample Chain of Custody

Job Field Engineer W.P. Hayward Source Ames, Dyer Site E. Lake Outlet Log No. 7318
Date of Test 2/20/96 Test No. 20 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
	Probe Wash: ☐ DI Water ☐ Acetone ☐ MeCl ₂	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
	Filter: ☐ 4" Glass ☐ 55 Thimble	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ IMN Protocol ☐ IWI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases ☐ IIA Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26		
	Integrated Gas: ☐ Tedlar Bag	☐ EPA M-3 ☐ EPA M-10		
13	Oxides of Nitrogen:	☒ EPA M-7A ☐ Per S-0163		
	Fuel Lab: ☐ Fuel Sample ☐ Aggregate			
	Particle Sizing:	☐ X-Ray Scdgraph ☐ Cascade Imp		
	Miscellaneous:	☐		

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
Misc: ☐ Natural Gas ☐ RDF ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>W.P. Hayward</u>	<u>Chad J. Taylor</u>	<u>2/23/96</u>

Interpoll Laboratories
(612)786-6020

Field Sample Chain Of Custody Sheet

Job L.P. Hayward
Date of Sampling 2/19/96 Site Line 1 Thermal Oil Heater Stack
Test 14 Run 0 Team Leader DWH

Type of Sample Train: PAH

Sample Collection/Recovery

Person performing sample recovery:

Signature Quane Van Hoener

Title Field Engineer

Location at which recovery was done Hayward Waste

Special transport/storage requirements

	Sample Description	No. of Items	Assigned Log Number
1.	<u>Solvent Rinse</u>	<u>1 of 3</u>	
2.	<u>Filter</u>	<u>2 of 3</u>	
3.	<u>Resin Cartridge</u>	<u>3 of 3</u>	
4.			
5.			
6.			
7.			
8.			
9.			
10.			
11.			
12.			
13.			
14.			
15.			
16.			
17.			
18.			

Sample Transport

Method of transport Truck 38

Recipient of samples upon recovery (if not recovery person):

Signature

Title

Date of receipt

Time of receipt

HRS

Sample Check-In at Interpoll Labs

Laboratory person receiving samples:

Signature OK Title Sample Custodian

Date of receipt 2/23/96 Time of receipt 1000 HRS

Sample storage location Walk in Cooler

Special storage conditions? 4°C

Analysis

	Sample Log No.	Date of Analysis	Method of Analysis	Initials of Analyst
1.				
2.				
3.				
4.				
5.				
6.				
7.				
8.				
9.				
10.				
11.				
12.				
13.				
14.				
15.				
16.				
17.				
18.				

Signature of each analyst:

Initials

Signature

Interpoll Laboratories
(612)786-6020

Field Sample Chain Of Custody Sheet

Job L.P. Hayward
Date of Sampling 2/20/96 Site Line 1 Thermal O.I. Heater Stack
Test 14 Run 1 Team Leader DUT

Type of Sample Train: DAT

Sample Collection/Recovery

Person performing sample recovery:

Signature Jane VanHousen

Title Field Engineer

Location at which recovery was done Hayward Waste

Special transport/storage requirements? _____

	Sample Description	No. of Items	Assigned Log Number
1.	<u>Solvent Rinse</u>	<u>1 of 4</u>	
2.	<u>Filter</u>	<u>2 of 2</u>	
3.	<u>Resin Cartridge</u>	<u>3 of 4</u>	
4.	<u>Condensate Trap</u>	<u>4 of 4</u>	
5.			
6.			
7.			
8.			
9.			
10.			
11.			
12.			
13.			
14.			
15.			
16.			
17.			
18.			

Sample Transport

Method of transport Truck 38

Recipient of samples upon recovery (if not recovery person):

Signature _____ Title _____

Date of receipt _____ Time of receipt _____ HRS

S-0157RR-1

Sample Check-In at Interpoll Labs

Laboratory person receiving samples:

Signature Title Sample Custodian
 Date of receipt 2/23/96 Time of receipt 1600 HRS
 Sample storage location Walk in Cooler
 Special storage conditions? 4°C

Analysis

	Sample Log No.	Date of Analysis	Method of Analysis	Initials of Analyst
1.				
2.				
3.				
4.				
5.				
6.				
7.				
8.				
9.				
10.				
11.				
12.				
13.				
14.				
15.				
16.				
17.				
18.				

Signature of each analyst:

Initials	Signature
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____

Interpoll Laboratories
(612)786-6020

Field Sample Chain Of Custody Sheet

Job L.P. Hayward
Date of Sampling 2/21/96 Site Line 1 Thermal Oil Heater Stack
Test 17 Run 2 Team Leader D.H.

Type of Sample Train: PAH

Sample Collection/Recovery

Person performing sample recovery:

Signature Daniel J. Hoover

Title Field Engineer

Location at which recovery was done Hayward

Special transport/storage requirements? _____

	Sample Description	No. of Items	Assigned Log Number
1.	<u>Solvent Rinse</u>	<u>1 of 4</u>	
2.	<u>Filter</u>	<u>2 of 4</u>	
3.	<u>Resin Cartridge</u>	<u>3 of 4</u>	
4.	<u>Condensate Trap</u>	<u>4 of 4</u>	
5.			
6.			
7.			
8.			
9.			
10.			
11.			
12.			
13.			
14.			
15.			
16.			
17.			
18.			

Sample Transport

Method of transport Truck 38

Recipient of samples upon recovery (if not recovery person):

Signature _____

Title _____

Date of receipt _____

Time of receipt _____

HRS

S-0157RR-1

Sample Check-In at Interpoll Labs

Laboratory person receiving samples:

Signature SC Q Title Sample Custodian
 Date of receipt 2/23/96 Time of receipt 1000 HRS
 Sample storage location Walk in Cooler
 Special storage conditions? 4° C

Analysis

Sample Log No.	Date of Analysis	Method of Analysis	Initials of Analyst
1.			
2.			
3.			
4.			
5.			
6.			
7.			
8.			
9.			
10.			
11.			
12.			
13.			
14.			
15.			
16.			
17.			
18.			

Signature of each analyst:

Initials	Signature
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____

Interpoll Laboratories
(612)786-6020

Field Sample Chain Of Custody Sheet

Job L.P. Hayward
Date of Sampling 2/21/96 Site Line 1 Thermal Oil Heater Stack
Test 14 Run 3 Team Leader PAH

Type of Sample Train: PAH

Sample Collection/Recovery

Person performing sample recovery:

Signature James Van Haver

Title Field Engineer

Location at which recovery was done Hayward

Special transport/storage requirements? _____

	Sample Description	No. of Items	Assigned Log Number
1.	<u>Solvent Rinse</u>	<u>1 of 4</u>	
2.	<u>Filter</u>	<u>2 of 4</u>	
3.	<u>Resin Cartridge</u>	<u>3 of 4</u>	
4.	<u>Condensate Trap</u>	<u>4 of 4</u>	
5.			
6.			
7.			
8.			
9.			
10.			
11.			
12.			
13.			
14.			
15.			
16.			
17.			
18.			

Sample Transport

Method of transport Truck 38

Recipient of samples upon recovery (if not recovery person):

Signature _____ Title _____

Date of receipt _____ Time of receipt _____ HRS

S-0157RR-1

Sample Check-In at Interpoll Labs

Laboratory person receiving samples:

Signature Title Sample Custodian

Date of receipt 2/23/96 Time of receipt 1000 HRS

Sample storage location Walk in Cooler

Special storage conditions? 4° C

Analysis


	Sample Log No.	Date of Analysis	Method of Analysis	Initials of Analyst
1.				
2.				
3.				
4.				
5.				
6.				
7.				
8.				
9.				
10.				
11.				
12.				
13.				
14.				
15.				
16.				
17.				
18.				

Signature of each analyst:

Initials	Signature

S-0157RR-2

APPENDIX E
THC STRIPCHART



- 11:00:00
0% O₂ Cal. Drift
- 10:59:00

0% O₂ Cal. Drift
20 FEB 1996

0 ppm THC
Cal. Drift 400 MM/HOUR
282 ppm CO Cal. Drift

PAPER 70

* 10:55:00

20 FEB 1996

PRINT INHIBIT MODE

142 ppm NO_x Cal. Drift
400 MM/HOUR

PAPER 70

- 10:54:00

20 FEB 1996

* 10:51:00

20 FEB 1996

PRINT INHIBIT MODE

EVD. T421
1050 HRS

(3) 02
0.00 (3)

25.00

3

(2) NOX PPM 500

(1) THC PPM 100

THC's

- 10:40:00

20 FEB 1996

400 MM/HOUR PAPER 70

3

(5) CO2 20.00
0.00 (5)

(4) CO PPM 1000

(3) 02
0.00 (3)

25.00

(2) NOX PPM 500

(1) THC PPM 100


- 10:20:00


20 FEB 1996


400 MM/HOUR PAPER 70

THC's

J.P. Hayward
Ingr RTO Stack
THC's
2-20-96







* LP DS T6R3 1320 HRS *

* 13:03:00	20 FEB 1996	PRINT INHIBIT MODE	13000 DU Cal Drift	10.99 CO Cal Drift	0ppm CO Cal Drift	400 MM/HOUR	PAPER	70
* 12:59:00	20 FEB 1996	PRINT INHIBIT MODE	0ppm NOX Cal Drift	100ppm THC Cal Drift	400 MM/HOUR	PAPER	70	
* 12:55:00	20 FEB 1996	PRINT INHIBIT MODE	0ppm CO Cal Drift	100ppm CO Cal Drift	400 MM/HOUR	PAPER	70	
* 12:52:00	20 FEB 1996	PRINT INHIBIT MODE	0ppm NOX Cal Drift	100ppm THC Cal Drift	400 MM/HOUR	PAPER	70	
* 12:41:00	20 FEB 1996	PRINT INHIBIT MODE	End T6R2 1240	2	400 MM/HOUR	PAPER	70	

JP Hayward
2.20-96
THC'S

14:31:00 20 FEB 1996 400 MM/HOUR PAPER 70

* 14:29:00 20 FEB 1996 PRINT INHIBIT MODE
0.00 CO₂ Cal Drift *0.00 TH₄ Cal Drift* *12.00 PM CO₂ Cal Drift*


14:28:00 20 FEB 1996 400 MM/HOUR PAPER 70

* 14:25:00 20 FEB 1996 PRINT INHIBIT MODE
14.00 PPM NO_x Cal Drift


14:24:00 20 FEB 1996 400 MM/HOUR PAPER 70

* 14:21:00 20 FEB 1996 PRINT INHIBIT MODE * *END 161R3 1430HRS **

14:20:00



*LP Hayward
 Dryer RTD Stack
 22096*



← The's

~~THE CASE OF THE SPIN~~

7/1/74

WEEK

CD	0-1000	PRM
MAZ	0-550	PRM
THS	0-5000	

Max also says

THC 0-10,000

1-24-96
E. RICHARDSON
1-24-96
-24-96

1. 100% 100% 100% 100% 100%

$\mu = 24.9\%$

2041X P/FRO

2000

287 AMMADUWANG

TAC - green

~~-12, 14, 20, 22~~

Max
FEM B. 15

20 ~~200~~ 2060
HARRIS CO

212 ~~213~~ 214 215

42 43

NOX COL EL NOR
9-250 PM

Asplenium platyneuron

SURFACE DATA

72578

LP-Hayward

2-28-96

TEST 8

THC's and NOx

Line / Surface

Dyer Duct




CHART NO. 9886A/WH

CHART NO. 9886A/WH

End Run 1
1050 HRS

LP- Hayward
Line Surface
Dryer Duct
2-20-96


NOx
(Scale 0-250)

THC's
(Scale 0-1000)

Run 1 Start 0950 HRS

0.0 0-1000 0.00
0.0 0-1000 0.00
0.0 0-1000 0.00

LP- Hayward
Line Surface
Dryer Duct
2-20-96



NOX

CO

CALC

Run 2 End 1240 HRS

THCS →

← NOX


Run Start 1140 HRS

NOX

CO

Run 1140 HRS


JP-Hayward
Line 1 Surface
Dryer Duct
2-20-96



CAL 3 END 1420HRS*

LP-Hayward
Line Surface Dyer
2-20-96

*AM 3 Start IP
1320HRS*



0.00 (3) 2 25.00

- 13:57:00 21 FEB 1996 400 MM/HOUR PAPER 70

LP-T10R2-1400

* 13:38:00 21 FEB 1996 PRINT INHIBIT MODE
 15.0% O₂ Cal. Drift
 10.9% CO₂ Cal. Drift
 0 ppm NO_x Cal. Drift

- 13:37:00 21 FEB 1996 400 MM/HOUR PAPER 70

* 13:36:00 21 FEB 1996 PRINT INHIBIT MODE
 30 ppm THC

- 13:35:00 21 FEB 1996 400 MM/HOUR PAPER 70

* 13:33:00 21 FEB 1996 PRINT INHIBIT MODE

0% O₂ Cal. Drift
 0% CO₂ Cal. Drift
 0 ppm NO_x Cal. Drift
 26 ppm CO₂ Cal. Drift


- 13:32:00 21 FEB 1996 400 MM/HOUR PAPER 70

* 13:30:00 21 FEB 1996 PRINT INHIBIT MODE

- 13:29:00 21 FEB 1996 400 MM/HOUR PAPER 70

* 13:16:00 21 FEB 1996 PRINT INHIBIT MODE
 * END T10R2-1511 hrs *

(3) 02
 0.00 (3) 2 25.00



- 13:00:00 21 FEB 1996 400 MM/HOUR PAPER 70

5
 (3) 002
 0.00 (3) 2 20.00

3

(4) CO PPM 500

(3) 02
 0.00 (3) 2 25.00


(2) NOX PPM 500

(1) THC PPM 100

5

- 12:40:00 21 FEB 1996 400 MM/HOUR PAPER 70

22126
 Hayward
 Fred R. Stank



0.00 (3) 02 2 25.00
 13.29:00 21 FEB 1996 400 MM/HOUR PAPER 70
 (2) NOX PPM 500

LOTIONS 1555

* 15:24:00 21 FEB 1996 PRINT INHIBIT MODE
 15.22:00 21 FEB 1996 400 MM/HOUR PAPER 70
 * 15:21:00 21 FEB 1996 PRINT INHIBIT MODE
 15:20:00 21 FEB 1996 400 MM/HOUR PAPER 70
 15:19:00 21 FEB 1996 400 MM/HOUR PAPER 70
 * 15:17:00 21 FEB 1996 PRINT INHIBIT MODE
 15:16:00 21 FEB 1996 400 MM/HOUR PAPER 70
 * 15:14:00 21 FEB 1996 PRINT INHIBIT MODE
 15:13:00 21 FEB 1996 400 MM/HOUR PAPER 70
 * 15:01:00 21 FEB 1996 PRINT INHIBIT MODE
 15:00:00 21 FEB 1996 400 MM/HOUR PAPER 70

0.00 (3) 02 2 25.00
 (3) 02 (3) 2 25.00
 (4) 3 CO PPM 500
 (2) NOX PPM 500
 14:40:00 21 FEB 1996 400 MM/HOUR PAPER 70

(THC's were
 21)

Hayward
 Fred R. Stock
 2-21-96

15:20:00 21 FEB 1996 400 MM/HOUR PAPER 70

(2) NOX PPM 500
(1) THC PPM 100

(5) CO2
0.00 (5) % 20.00
15:00:00 21 FEB 1996 400 MM/HOUR PAPER 70
(4) CO PPM 500
(3) 02
0.00 (3) % 25.00

(2) NOX PPM 500
(1) THC PPM 100

15:40:00 21 FEB 1996 400 MM/HOUR PAPER 70
(5) CO2
0.00 (5) % 20.00
(4) CO PPM 500
(3) 02
0.00 (3) % 25.00

THC's are
21

(2) NOX PPM 500
15:29:00 21 FEB 1996 400 MM/HOUR PAPER 70

* 15:24:00 21 FEB 1996 PRINT INHIBIT MODE
13.0% O2 Cal. Profile
10.9% CO Cal. On/Off
0 ppm NO₂ Cal. On/Off
0 ppm CO Cal. On/Off

Up-Hayward
Line 1 PROORTO Stack
2-21-96
THC's

* 16:50:00	21 FEB 1996	PRINT INHIBIT MODE	0.0% CO ₂ Cal Onlt		
- 16:48:00	21 FEB 1996	400 MM/HOUR	0.0% CO ₂ Cal Onlt	PAPER	70
* 16:47:00	21 FEB 1996	PRINT INHIBIT MODE	0.0% CO ₂ Cal Onlt		
- 16:45:00	21 FEB 1996	400 MM/HOUR	0.0% CO ₂ Cal Onlt	PAPER	70
* 16:44:00	21 FEB 1996	PRINT INHIBIT MODE	0.0% CO ₂ Cal Onlt		
- 16:42:00	21 FEB 1996	400 MM/HOUR	0.0% CO ₂ Cal Onlt	PAPER	70
* 16:40:00	21 FEB 1996	PRINT INHIBIT MODE	0.0% CO ₂ Cal Onlt		
- 16:39:00	21 FEB 1996	400 MM/HOUR	0.0% CO ₂ Cal Onlt	PAPER	70
* 16:37:00	21 FEB 1996	PRINT INHIBIT MODE	0.0% CO ₂ Cal Onlt		

1 2
NO LPT 12.3

(3) 02	21 FEB 1996	400 MM/HOUR	0.0% CO ₂ Cal Onlt	PAPER	70
- 16:20:00	21 FEB 1996	400 MM/HOUR	0.0% CO ₂ Cal Onlt	PAPER	70
(3) 02	21 FEB 1996	400 MM/HOUR	0.0% CO ₂ Cal Onlt	PAPER	70
- 16:20:00	21 FEB 1996	400 MM/HOUR	0.0% CO ₂ Cal Onlt	PAPER	70
(3) 02	21 FEB 1996	400 MM/HOUR	0.0% CO ₂ Cal Onlt	PAPER	70
- 16:20:00	21 FEB 1996	400 MM/HOUR	0.0% CO ₂ Cal Onlt	PAPER	70
(3) 02	21 FEB 1996	400 MM/HOUR	0.0% CO ₂ Cal Onlt	PAPER	70
- 16:20:00	21 FEB 1996	400 MM/HOUR	0.0% CO ₂ Cal Onlt	PAPER	70

THC's

THC'S WORK
C1

Hayward
Price RTO Stack
2-21-96

APPENDIX F
NO_x AND CO DATALOGGER PRINTOUTS

LP/HAYWARD
Line 1 Dryer RTO Stack
Test 6 Run 1

DATE	TIME	NOX	O2	CO	CO2
2/20/96	9:51:27 AM	22.732	16.248	155.156	4.106
2/20/96	9:52:27 AM	21.85	16.459	138.594	4.009
2/20/96	9:53:27 AM	22.365	16.429	164.531	4.032
2/20/96	9:54:27 AM	22.438	16.187	147.5	4.167
2/20/96	9:55:27 AM	22.585	16.196	174.531	4.167
2/20/96	9:56:27 AM	21.923	16.381	172.812	4.073
2/20/96	9:57:27 AM	22.438	16.248	163.75	4.16
2/20/96	9:58:27 AM	22.365	16.226	165.781	4.125
2/20/96	9:59:27 AM	22.659	16.269	159.219	4.106
2/20/96	10:00:27 AM	22.291	16.364	187.812	4.07
2/20/96	10:01:27 AM	21.997	16.36	150.469	4.054
2/20/96	10:02:27 AM	22.217	16.209	176.875	4.164
2/20/96	10:03:27 AM	22.07	16.403	154.062	3.974
2/20/96	10:04:27 AM	22.217	16.476	184.687	3.99
2/20/96	10:05:27 AM	22.144	16.295	141.25	4.122
2/20/96	10:06:27 AM	22.438	16.135	178.281	4.17
2/20/96	10:07:27 AM	21.923	16.334	162.969	4.102
2/20/96	10:08:27 AM	22.806	16.291	198.594	4.186
2/20/96	10:09:27 AM	22.07	16.187	169.375	4.202
2/20/96	10:10:27 AM	22.217	16.261	190.469	4.115
2/20/96	10:11:27 AM	21.702	16.42	250.156	3.986
2/20/96	10:12:27 AM	21.629	16.343	259.375	4.093
2/20/96	10:13:27 AM	21.482	16.222	224.219	4.093
2/20/96	10:14:27 AM	21.555	16.312	171.562	4.067
2/20/96	10:15:27 AM	20.967	16.545	175.625	3.941
2/20/96	10:16:27 AM	21.187	16.368	152.031	4.077
2/20/96	10:17:27 AM	21.04	16.261	182.969	4.151
2/20/96	10:18:27 AM	21.187	16.243	169.375	4.099
2/20/96	10:19:27 AM	20.599	16.416	211.094	4.054
2/20/96	10:20:27 AM	20.673	16.261	157.969	4.131
2/20/96	10:21:27 AM	20.746	16.282	186.094	4.054
2/20/96	10:22:27 AM	20.452	16.481	155.781	3.98
2/20/96	10:23:27 AM	20.305	16.528	202.187	3.967
2/20/96	10:24:27 AM	20.746	16.343	162.187	4.102
2/20/96	10:25:27 AM	20.673	16.286	200.781	4.119
2/20/96	10:26:27 AM	20.305	16.394	185.625	4.048
2/20/96	10:27:27 AM	20.673	16.282	202.656	4.151
2/20/96	10:28:27 AM	20.231	16.183	184.062	4.144
2/20/96	10:29:27 AM	21.04	16.222	189.531	4.206
2/20/96	10:30:27 AM	20.084	16.506	201.094	3.99
2/20/96	10:31:27 AM	20.305	16.459	177.656	4.006
2/20/96	10:32:27 AM	20.231	16.429	196.094	4.015
2/20/96	10:33:27 AM	20.893	16.381	177.187	4.032
2/20/96	10:34:27 AM	20.746	16.399	218.437	4.035
2/20/96	10:35:27 AM	20.525	16.274	165.781	4.119
2/20/96	10:36:27 AM	20.673	16.265	193.125	4.093
2/20/96	10:37:27 AM	20.673	16.489	160.625	3.941

LP/HAYWARD
Line 1 Dryer RTO Stack
Test 6 Run 1

2/20/96	10:38:27 AM	20.746	16.472	211.25	4.022
2/20/96	10:39:27 AM	20.746	16.317	178.281	4.131
2/20/96	10:40:27 AM	20.525	16.351	211.875	4.054
2/20/96	10:41:27 AM	20.746	16.463	183.75	4.022
2/20/96	10:42:27 AM	20.82	16.274	211.562	4.157
2/20/96	10:43:27 AM	20.746	16.135	181.562	4.164
2/20/96	10:44:27 AM	21.335	16.261	199.219	4.112
2/20/96	10:45:27 AM	20.452	16.511	198.906	3.951
2/20/96	10:46:27 AM	20.378	16.485	184.531	3.99
2/20/96	10:47:27 AM	20.673	16.386	199.219	4.054
2/20/96	10:48:27 AM	21.187	16.334	191.25	4.051
2/20/96	10:49:27 AM	20.967	16.412	218.906	4.044
2/20/96	10:50:27 AM	20.967	16.196	176.094	4.196
AVERAGES		21.3	16.3	183.3	4.1

LP/HAYWARD
Line 1 Dryer RTO Stack
Test 6 Run 2

DATE	TIME	NOX	O2	CO	CO2
2/20/96	11:41:47 AM	18.245	16.821	220.469	3.468
2/20/96	11:42:47 AM	17.803	16.847	272.812	3.422
2/20/96	11:43:47 AM	17.803	16.882	290.625	3.429
2/20/96	11:44:47 AM	17.73	16.843	304.062	3.445
2/20/96	11:45:47 AM	17.73	16.89	282.031	3.413
2/20/96	11:46:47 AM	17.509	16.916	262.344	3.384
2/20/96	11:47:47 AM	17.583	16.856	241.719	3.403
2/20/96	11:48:47 AM	17.362	16.821	228.75	3.416
2/20/96	11:49:47 AM	17.362	16.826	220.469	3.384
2/20/96	11:50:47 AM	17.656	16.912	224.844	3.358
2/20/96	11:51:47 AM	17.068	16.851	218.75	3.41
2/20/96	11:52:47 AM	17.583	16.86	226.875	3.416
2/20/96	11:53:47 AM	17.068	16.92	216.094	3.368
2/20/96	11:54:47 AM	17.141	16.933	230	3.381
2/20/96	11:55:47 AM	17.509	16.787	221.094	3.477
2/20/96	11:56:47 AM	17.068	16.748	230.469	3.477
2/20/96	11:57:47 AM	16.994	16.895	226.562	3.364
2/20/96	11:58:47 AM	16.7	16.895	230.156	3.303
2/20/96	11:59:47 AM	16.773	16.834	212.812	3.364
2/20/96	12:00:47 PM	17.362	16.774	221.25	3.435
2/20/96	12:01:47 PM	17.215	16.8	218.75	3.387
2/20/96	12:02:47 PM	16.626	16.86	226.875	3.319
2/20/96	12:03:47 PM	16.921	16.895	192.344	3.29
2/20/96	12:04:47 PM	17.288	16.834	194.844	3.297
2/20/96	12:05:47 PM	16.921	16.864	202.344	3.31
2/20/96	12:06:47 PM	17.362	16.864	214.687	3.332
2/20/96	12:07:47 PM	17.215	16.817	213.281	3.368
2/20/96	12:08:47 PM	17.509	16.795	217.656	3.377
2/20/96	12:09:47 PM	17.436	16.813	229.375	3.374
2/20/96	12:10:47 PM	17.362	16.8	215.625	3.384
2/20/96	12:11:47 PM	17.141	16.817	214.219	3.371
2/20/96	12:12:47 PM	17.362	16.908	206.25	3.332
2/20/96	12:13:47 PM	16.847	17.015	220.312	3.255
2/20/96	12:14:47 PM	17.288	16.946	198.75	3.261
2/20/96	12:15:47 PM	17.803	16.869	213.437	3.281
2/20/96	12:16:47 PM	17.215	16.942	220	3.245
2/20/96	12:17:47 PM	16.847	16.994	271.875	3.226
2/20/96	12:18:47 PM	17.288	16.869	206.406	3.261
2/20/96	12:19:47 PM	16.921	16.826	211.406	3.323
2/20/96	12:20:47 PM	17.215	16.791	218.75	3.419
2/20/96	12:21:47 PM	17.215	16.774	294.219	3.468
2/20/96	12:22:47 PM	16.847	16.791	378.437	3.387
2/20/96	12:23:47 PM	16.773	16.83	363.437	3.377
2/20/96	12:24:47 PM	17.141	16.8	299.844	3.403
2/20/96	12:25:47 PM	17.141	16.757	249.062	3.4
2/20/96	12:26:47 PM	17.141	16.679	234.062	3.432
2/20/96	12:27:47 PM	17.509	16.739	225.781	3.448

LP/HAYWARD
Line 1 Dryer RTO Stack
Test 6 Run 2

2/20/96	12:28:47 PM	17.362	16.808	218.281	3.432
2/20/96	12:29:47 PM	16.921	16.839	225.781	3.374
2/20/96	12:30:47 PM	17.509	16.808	223.906	3.342
2/20/96	12:31:47 PM	16.994	16.839	225.781	3.335
2/20/96	12:32:47 PM	16.921	16.877	228.594	3.313
2/20/96	12:33:47 PM	17.215	16.821	210.156	3.316
2/20/96	12:34:47 PM	17.362	16.864	215.312	3.31
2/20/96	12:35:47 PM	16.847	16.972	210.469	3.248
2/20/96	12:36:47 PM	16.847	17.024	213.125	3.232
2/20/96	12:37:47 PM	17.288	16.951	209.062	3.248
2/20/96	12:38:47 PM	17.73	16.895	215.469	3.258
2/20/96	12:39:47 PM	18.245	16.89	219.219	3.297
2/20/96	12:40:47 PM	18.171	16.843	217.187	3.297
AVERAGES		17.3	16.9	232.8	3.4

LP/HAYWARD
Line 1 Dryer RTO Stack
Test 6 Run 3

DATE	TIME	NOX	O2	CO	CO2
2/20/96	1:21:43 PM	20.305	16.187	197.344	4.215
2/20/96	1:22:43 PM	20.525	16.105	184.062	4.254
2/20/96	1:23:43 PM	20.967	16.114	223.906	4.28
2/20/96	1:24:43 PM	21.261	15.937	176.719	4.357
2/20/96	1:25:43 PM	21.261	16.364	179.219	4.038
2/20/96	1:26:43 PM	19.937	16.118	162.969	4.247
2/20/96	1:27:43 PM	19.863	16.239	230.156	4.244
2/20/96	1:28:43 PM	20.305	16.097	183.437	4.305
2/20/96	1:29:43 PM	20.158	16.135	212.5	4.228
2/20/96	1:30:43 PM	19.569	16.274	182.656	4.148
2/20/96	1:31:43 PM	19.863	16.183	210.469	4.247
2/20/96	1:32:43 PM	19.495	15.881	188.594	4.399
2/20/96	1:33:43 PM	20.305	15.954	206.25	4.389
2/20/96	1:34:43 PM	19.495	16.261	203.594	4.189
2/20/96	1:35:43 PM	19.275	16.282	185.781	4.183
2/20/96	1:36:43 PM	19.79	16.187	201.406	4.257
2/20/96	1:37:43 PM	19.495	16.123	197.5	4.318
2/20/96	1:38:43 PM	19.569	16.11	243.125	4.334
2/20/96	1:39:43 PM	19.422	16.002	185.625	4.405
2/20/96	1:40:43 PM	20.673	15.937	218.281	4.421
2/20/96	1:41:43 PM	18.833	16.153	246.094	4.173
2/20/96	1:42:43 PM	18.465	16.317	433.75	4.173
2/20/96	1:43:43 PM	18.465	16.2	315	4.264
2/20/96	1:44:43 PM	19.569	16.123	300.937	4.273
2/20/96	1:45:43 PM	19.716	16.239	176.406	4.238
2/20/96	1:46:43 PM	19.275	16.157	211.406	4.293
2/20/96	1:47:43 PM	18.686	16.131	176.25	4.222
2/20/96	1:48:43 PM	18.465	16.23	182.031	4.183
2/20/96	1:49:43 PM	18.245	16.455	180.156	4.057
2/20/96	1:50:43 PM	18.613	16.338	175.156	4.183
2/20/96	1:51:43 PM	18.907	16.265	198.281	4.231
2/20/96	1:52:43 PM	18.318	16.213	186.875	4.222
2/20/96	1:53:43 PM	18.613	16.338	221.562	4.141
2/20/96	1:54:43 PM	18.613	16.304	167.812	4.193
2/20/96	1:55:43 PM	18.098	16.295	192.812	4.17
2/20/96	1:56:43 PM	18.171	16.424	162.812	4.067
2/20/96	1:57:43 PM	18.392	16.537	210	4.067
2/20/96	1:58:43 PM	19.275	16.317	162.5	4.202
2/20/96	1:59:43 PM	18.907	16.217	204.219	4.209
2/20/96	2:00:43 PM	18.98	16.347	180	4.151
2/20/96	2:01:43 PM	18.76	16.373	212.656	4.183
2/20/96	2:02:43 PM	19.201	16.058	183.125	4.351
2/20/96	2:03:43 PM	19.643	16.144	206.875	4.322
2/20/96	2:04:43 PM	19.128	16.373	202.656	4.209
2/20/96	2:05:43 PM	19.422	16.265	195.469	4.312
2/20/96	2:06:43 PM	19.275	16.213	213.281	4.318
2/20/96	2:07:43 PM	19.422	16.2	200.937	4.302

LP/HAYWARD
Line 1 Dryer RTO Stack
Test 6 Run 3

2/20/96	2:08:43 PM	19.128	16.317	234.219	4.247
2/20/96	2:09:43 PM	18.98	16.157	187.812	4.344
2/20/96	2:10:43 PM	19.054	16.153	220.625	4.37
2/20/96	2:11:43 PM	18.907	16.321	189.844	4.206
2/20/96	2:12:43 PM	18.392	16.424	235.312	4.189
2/20/96	2:13:43 PM	19.348	16.157	184.219	4.305
2/20/96	2:14:43 PM	18.98	16.028	223.281	4.299
2/20/96	2:15:43 PM	18.465	16.157	200.625	4.228
2/20/96	2:16:43 PM	18.539	16.2	225.781	4.193
2/20/96	2:17:43 PM	18.833	16.101	185.469	4.212
2/20/96	2:18:43 PM	19.054	16.166	192.344	4.164
2/20/96	2:19:43 PM	18.465	16.355	202.656	4.083
2/20/96	2:20:43 PM	19.054	16.33	185.781	4.109
AVERAGES		19.3	16.2	205.7	4.2

LP/HAYWARD
Line 1 Core Dryer Outlet

Test 7 Run 1

DATE	TIME	THC	NOX	O2	CO	CO2
2/20/96	9:50:59 AM	87.484	36.743	16.29	621.989	4.644
2/20/96	9:51:59 AM	90.413	36.418	16.273	636.068	4.67
2/20/96	9:52:59 AM	85.449	36.723	16.377	618.164	4.561
2/20/96	9:53:59 AM	85.937	36.479	16.309	633.789	4.632
2/20/96	9:54:59 AM	83.984	36.54	16.432	616.211	4.502
2/20/96	9:55:59 AM	87.24	36.051	16.419	583.984	4.513
2/20/96	9:56:59 AM	90.007	36.601	16.309	615.723	4.639
2/20/96	9:57:59 AM	88.135	36.723	16.335	627.441	4.587
2/20/96	9:58:59 AM	88.867	36.357	16.424	582.031	4.528
2/20/96	9:59:59 AM	97.493	36.112	16.263	648.519	4.73
2/20/96	10:00:59 AM	92.692	36.011	16.263	688.151	4.639
2/20/96	10:01:59 AM	93.424	36.54	16.388	645.02	4.575
2/20/96	10:02:59 AM	90.82	35.929	16.303	664.307	4.587
2/20/96	10:03:59 AM	88.135	35.238	16.557	579.346	4.365
2/20/96	10:04:59 AM	91.715	35.97	16.481	569.01	4.504
2/20/96	10:05:59 AM	93.506	34.851	16.337	657.715	4.582
2/20/96	10:06:59 AM	100.667	35.116	16.258	660.645	4.683
2/20/96	10:07:59 AM	99.528	35.441	16.248	711.914	4.683
2/20/96	10:08:59 AM	108.236	35.197	16.138	736.409	4.805
2/20/96	10:09:59 AM	99.04	34.912	16.364	731.527	4.539
2/20/96	10:10:59 AM	99.202	35.522	16.396	649.577	4.517
2/20/96	10:11:59 AM	97.005	36.092	16.436	621.175	4.494
2/20/96	10:12:59 AM	97.982	35.706	16.447	639.486	4.495
2/20/96	10:13:59 AM	95.622	35.055	16.476	628.581	4.463
2/20/96	10:14:59 AM	90.332	34.465	16.578	636.23	4.338
2/20/96	10:15:59 AM	101.644	34.729	16.517	608.561	4.471
2/20/96	10:16:59 AM	107.91	34.79	16.282	719.564	4.645
2/20/96	10:17:59 AM	114.909	34.627	16.29	743.815	4.655
2/20/96	10:18:59 AM	109.375	34.261	16.398	726.318	4.53
2/20/96	10:19:59 AM	111.898	34.648	16.322	749.593	4.626
2/20/96	10:20:59 AM	103.516	34.566	16.504	741.943	4.396
2/20/96	10:21:59 AM	107.503	33.712	16.595	656.169	4.37
2/20/96	10:22:59 AM	101.807	34.607	16.572	656.413	4.393
2/20/96	10:23:59 AM	103.19	33.366	16.51	653.971	4.414
2/20/96	10:24:59 AM	110.433	34.831	16.424	699.056	4.486
2/20/96	10:25:59 AM	110.026	35.421	16.514	694.987	4.448
2/20/96	10:26:59 AM	120.768	35.583	16.301	742.757	4.639
2/20/96	10:27:59 AM	126.058	37.109	16.21	802.653	4.718
2/20/96	10:28:59 AM	114.827	37.191	16.385	750.488	4.593
2/20/96	10:29:59 AM	114.014	36.458	16.388	752.767	4.505
2/20/96	10:30:59 AM	108.968	36.214	16.531	688.639	4.401
2/20/96	10:31:59 AM	108.968	36.601	16.468	685.954	4.427
2/20/96	10:32:59 AM	110.352	37.252	16.504	641.276	4.417
2/20/96	10:33:59 AM	110.596	37.292	16.404	672.526	4.492
2/20/96	10:34:59 AM	113.688	37.476	16.487	691.976	4.453
2/20/96	10:35:59 AM	109.701	38.696	16.398	689.616	4.499
2/20/96	10:36:59 AM	106.527	38.472	16.574	647.868	4.39

LP/HAYWARD
Line 1 Core Dryer Outlet

Test 7 Run 1

2/20/96	10:37:59 AM	112.386	37.354	16.479	636.556	4.458
2/20/96	10:38:59 AM	115.723	36.947	16.453	688.802	4.489
2/20/96	10:39:59 AM	111.003	36.316	16.504	700.114	4.398
2/20/96	10:40:59 AM	109.538	36.112	16.576	638.021	4.355
2/20/96	10:41:59 AM	122.152	36.133	16.424	650.146	4.52
2/20/96	10:42:59 AM	119.629	36.235	16.44	703.288	4.481
2/20/96	10:43:59 AM	111.084	36.58	16.586	661.702	4.328
2/20/96	10:44:59 AM	113.851	36.336	16.578	625.732	4.36
2/20/96	10:45:59 AM	111.654	36.54	16.544	662.923	4.375
2/20/96	10:46:59 AM	117.432	36.56	16.508	649.821	4.45
2/20/96	10:47:59 AM	119.059	36.133	16.504	677.246	4.414
2/20/96	10:48:59 AM	115.804	35.807	16.495	664.062	4.438
2/20/96	10:49:59 AM	116.374	36.011	16.479	666.911	4.486
AVERAGES		104.1	36	16.4	667.4	4.5
ppmc,w =		312.3				

LP/HAYWARD
Line 1 Core Dryer Outlet
Test 7 Run 2

DATE	TIME	THC	NOX	O2	CO	CO2
2/20/96	11:39:57 AM	120.85	35.889	16.197	889.242	4.754
2/20/96	11:40:57 AM	122.884	35.746	16.222	876.221	4.712
2/20/96	11:41:57 AM	128.825	36.235	16.108	926.025	4.86
2/20/96	11:42:57 AM	131.836	36.377	16.125	993.896	4.827
2/20/96	11:43:57 AM	124.919	35.868	16.229	954.346	4.699
2/20/96	11:44:57 AM	126.383	35.38	16.216	928.955	4.723
2/20/96	11:45:57 AM	129.964	35.36	16.246	941.162	4.699
2/20/96	11:46:57 AM	125.163	36.011	16.284	939.372	4.668
2/20/96	11:47:57 AM	129.069	36.031	16.248	919.596	4.704
2/20/96	11:48:57 AM	132.975	37.272	16.14	981.12	4.819
2/20/96	11:49:57 AM	128.743	37.211	16.14	1022.298	4.801
2/20/96	11:50:57 AM	125.244	36.377	16.25	966.553	4.686
2/20/96	11:51:57 AM	123.535	36.275	16.307	925.781	4.644
2/20/96	11:52:57 AM	126.383	36.499	16.252	920.573	4.71
2/20/96	11:53:57 AM	130.941	35.706	16.214	969.727	4.733
2/20/96	11:54:57 AM	132.568	36.967	16.174	998.861	4.775
2/20/96	11:55:57 AM	133.138	36.845	16.165	994.466	4.79
2/20/96	11:56:57 AM	132.975	36.845	16.227	999.023	4.697
2/20/96	11:57:57 AM	134.033	38.066	16.267	959.147	4.702
2/20/96	11:58:57 AM	128.906	38.879	16.299	941.243	4.653
2/20/96	11:59:57 AM	135.661	39.429	16.178	979.411	4.797
2/20/96	12:00:57 PM	130.534	38.554	16.28	1001.546	4.678
2/20/96	12:01:57 PM	128.988	37.903	16.265	955.729	4.679
2/20/96	12:02:57 PM	132.812	38.371	16.252	932.21	4.736
2/20/96	12:03:57 PM	138.997	38.879	16.053	1036.458	4.914
2/20/96	12:04:57 PM	143.717	38.676	16.098	1092.529	4.863
2/20/96	12:05:57 PM	140.462	38.656	16.112	1086.589	4.855
2/20/96	12:06:57 PM	136.556	39.001	16.275	1011.882	4.689
2/20/96	12:07:57 PM	138.509	39.53	16.222	974.609	4.702
2/20/96	12:08:57 PM	133.789	39.876	16.201	983.643	4.736
2/20/96	12:09:57 PM	129.639	39.286	16.366	952.474	4.58
2/20/96	12:10:58 PM	118.164	38.208	16.553	851.074	4.398
2/20/96	12:11:57 PM	112.793	38.249	16.612	810.872	4.344
2/20/96	12:12:57 PM	113.688	38.188	16.531	773.682	4.408
2/20/96	12:13:57 PM	113.2	38.269	16.527	798.991	4.421
2/20/96	12:14:57 PM	118.408	38.31	16.504	787.435	4.466
2/20/96	12:15:57 PM	121.826	38.249	16.472	810.791	4.551
2/20/96	12:16:57 PM	120.524	38.737	16.402	877.523	4.543
2/20/96	12:17:57 PM	126.953	38.432	16.354	859.538	4.603
2/20/96	12:18:57 PM	132.08	38.676	16.297	903.727	4.66
2/20/96	12:19:57 PM	130.452	38.005	16.343	922.282	4.626
2/20/96	12:20:57 PM	132.812	37.516	16.265	945.231	4.674
2/20/96	12:21:57 PM	128.255	37.577	16.39	924.479	4.569
2/20/96	12:22:57 PM	134.928	38.432	16.235	942.79	4.717
2/20/96	12:23:57 PM	134.115	38.371	16.254	970.378	4.692
2/20/96	12:24:58 PM	137.858	38.656	16.235	971.029	4.71
2/20/96	12:25:58 PM	139.242	38.615	16.208	983.154	4.73

LP/HAYWARD
Line 1 Core Dryer Outlet
Test 7 Run 2

2/20/96	12:26:57 PM	131.185	38.595	16.347	942.301	4.565
2/20/96	12:27:57 PM	123.617	38.696	16.481	846.68	4.442
2/20/96	12:28:58 PM	127.116	39.429	16.419	801.514	4.533
2/20/96	12:29:57 PM	130.859	39.185	16.413	840.413	4.52
2/20/96	12:30:57 PM	119.629	38.94	16.578	862.874	4.333
2/20/96	12:31:57 PM	127.116	39.408	16.466	783.854	4.513
2/20/96	12:32:57 PM	119.059	39.429	16.618	832.275	4.294
2/20/96	12:33:57 PM	119.71	39.632	16.54	756.673	4.429
2/20/96	12:34:57 PM	104.574	39.042	16.76	772.949	4.163
2/20/96	12:35:57 PM	109.131	38.371	16.764	678.874	4.224
2/20/96	12:36:57 PM	104.574	38.249	16.832	686.035	4.22
2/20/96	12:37:57 PM	115.885	38.981	16.603	696.452	4.368
2/20/96	12:38:58 PM	133.138	38.31	16.542	763.102	4.406
AVERAGES		127.3	37.9	16.3	907.5	4.6
ppmc,w =		399.4				

LP/HAYWARD
Line 1 Core Dryer Outlet
Test 7 Run 3

DATE	TIME	THC	NOX	O2	CO	CO2
2/20/96	1:21:00 PM	113.118	34.546	16.426	759.603	4.572
2/20/96	1:22:00 PM	113.444	34.648	16.479	735.352	4.523
2/20/96	1:22:59 PM	111.979	34.444	16.481	707.031	4.51
2/20/96	1:23:59 PM	116.374	34.424	16.409	712.484	4.629
2/20/96	1:24:59 PM	120.524	34.322	16.288	755.697	4.727
2/20/96	1:25:59 PM	116.699	34.973	16.385	753.255	4.647
2/20/96	1:26:59 PM	123.779	34.241	16.303	778.483	4.709
2/20/96	1:27:59 PM	119.71	34.037	16.352	761.637	4.64
2/20/96	1:29:00 PM	119.059	34.302	16.375	747.233	4.635
2/20/96	1:30:00 PM	118.083	34.22	16.381	713.949	4.624
2/20/96	1:31:00 PM	116.211	34.668	16.424	731.283	4.614
2/20/96	1:31:59 PM	125.488	35.095	16.352	730.713	4.661
2/20/96	1:32:59 PM	126.79	35.929	16.178	795.41	4.852
2/20/96	1:33:59 PM	130.208	36.621	16.1	837.402	4.94
2/20/96	1:35:00 PM	130.859	35.604	16.208	844.971	4.824
2/20/96	1:35:59 PM	133.382	35.217	16.203	854.818	4.792
2/20/96	1:36:59 PM	128.499	34.363	16.421	771.403	4.582
2/20/96	1:37:59 PM	128.581	34.831	16.307	747.152	4.701
2/20/96	1:39:00 PM	135.579	35.034	16.235	783.366	4.779
2/20/96	1:40:00 PM	135.335	37.048	16.11	810.14	4.919
2/20/96	1:41:00 PM	133.626	36.865	16.155	815.267	4.85
2/20/96	1:41:59 PM	135.254	36.764	16.214	791.016	4.81
2/20/96	1:43:00 PM	140.381	35.645	16.21	782.389	4.81
2/20/96	1:44:00 PM	137.614	35.238	16.189	816.732	4.816
2/20/96	1:45:00 PM	131.104	36.011	16.231	773.112	4.79
2/20/96	1:45:59 PM	137.614	36.316	16.212	768.717	4.816
2/20/96	1:47:00 PM	138.346	35.624	16.216	812.744	4.792
2/20/96	1:48:00 PM	128.092	35.441	16.354	757.975	4.632
2/20/96	1:49:00 PM	124.268	34.871	16.413	683.512	4.578
2/20/96	1:50:00 PM	120.524	34.363	16.432	681.722	4.595
2/20/96	1:50:59 PM	122.314	34.078	16.33	682.454	4.687
2/20/96	1:51:59 PM	125.326	34.302	16.396	693.848	4.629
2/20/96	1:52:59 PM	126.628	33.915	16.324	718.262	4.714
2/20/96	1:53:59 PM	125	34.546	16.36	718.506	4.678
2/20/96	1:54:59 PM	125.977	34.546	16.288	708.984	4.72
2/20/96	1:56:00 PM	122.314	34.078	16.417	699.219	4.588
2/20/96	1:57:00 PM	121.257	34.465	16.29	714.681	4.717
2/20/96	1:58:00 PM	124.105	35.116	16.297	712.321	4.762
2/20/96	1:59:00 PM	126.546	35.095	16.121	770.915	4.894
2/20/96	2:00:00 PM	121.419	35.421	16.273	759.684	4.779
2/20/96	2:01:00 PM	116.862	33.752	16.307	729.899	4.678
2/20/96	2:01:59 PM	117.106	34.078	16.267	730.957	4.727
2/20/96	2:02:59 PM	118.083	34.342	16.167	743.734	4.678
2/20/96	2:03:59 PM	112.142	34.749	16.199	729.248	4.691
2/20/96	2:05:00 PM	119.792	35.522	16.064	751.383	4.819
2/20/96	2:06:00 PM	122.396	36.336	15.924	841.878	4.948
2/20/96	2:07:00 PM	119.303	35.868	16.083	806.234	4.81

LP/HAYWARD

Line 1 Core Dryer Outlet

Test 7 Run 3

2/20/96	2:08:00 PM	121.175	36.275	16.024	825.439	4.834
2/20/96	2:08:59 PM	123.291	35.421	16.127	778.239	4.748
2/20/96	2:09:59 PM	130.046	36.214	15.99	831.38	4.891
2/20/96	2:11:00 PM	129.883	36.112	16.047	871.826	4.803
2/20/96	2:11:59 PM	128.906	36.641	16.106	828.206	4.748
2/20/96	2:12:59 PM	125.488	36.458	16.1	822.021	4.744
2/20/96	2:14:00 PM	128.662	36.743	16.019	906.982	4.844
2/20/96	2:15:00 PM	133.382	37.17	16.015	908.529	4.863
2/20/96	2:16:00 PM	128.662	36.56	16.062	901.286	4.79
2/20/96	2:17:00 PM	121.745	36.56	16.201	840.169	4.647
2/20/96	2:18:00 PM	119.141	36.296	16.153	792.155	4.717
2/20/96	2:19:00 PM	124.919	37.17	16.161	809.489	4.723
2/20/96	2:20:00 PM	121.175	37.821	16.07	834.88	4.784
AVERAGES		124.9	35.4	16.2	774.6	4.7
ppmc.w =		374.7				

LP/HAYWARD
Line 1 Press RTO Stack

Test 10 Run 1

DATE	TIME	NOX	O2	CO	CO2
2/21/96	12:16:04 PM	28.23	20.156	21.891	0.562
2/21/96	12:17:04 PM	27.852	20.03	27.303	0.601
2/21/96	12:18:04 PM	25.543	20.05	16.235	0.581
2/21/96	12:19:04 PM	23.008	20.105	16.317	0.534
2/21/96	12:20:04 PM	29.29	20.116	22.705	0.575
2/21/96	12:21:04 PM	27.587	19.995	24.455	0.625
2/21/96	12:22:04 PM	27.208	20.035	14.486	0.612
2/21/96	12:23:04 PM	22.932	20.184	16.235	0.514
2/21/96	12:24:04 PM	29.971	20.156	23.682	0.583
2/21/96	12:25:04 PM	26.641	20.019	20.63	0.62
2/21/96	12:26:04 PM	23.008	20.129	13.265	0.544
2/21/96	12:27:04 PM	24.749	20.224	18.229	0.534
2/21/96	12:28:04 PM	30.841	20.085	25.106	0.605
2/21/96	12:29:04 PM	25.695	20.054	16.805	0.586
2/21/96	12:30:04 PM	23.992	20.162	12.98	0.547
2/21/96	12:31:04 PM	27.133	20.221	19.002	0.55
2/21/96	12:32:04 PM	27.246	20.107	24.78	0.588
2/21/96	12:33:04 PM	25.278	20.136	14.282	0.57
2/21/96	12:34:04 PM	22.251	20.182	14.201	0.518
2/21/96	12:35:04 PM	28.798	20.186	20.711	0.547
2/21/96	12:36:04 PM	26.981	20.076	23.722	0.602
2/21/96	12:37:04 PM	23.878	20.129	12.614	0.571
2/21/96	12:38:04 PM	21.267	20.254	14.608	0.492
2/21/96	12:39:04 PM	29.138	20.175	22.217	0.56
2/21/96	12:40:04 PM	25.657	20.065	20.142	0.599
2/21/96	12:41:04 PM	22.932	20.158	12.207	0.535
2/21/96	12:42:04 PM	24.635	20.257	16.317	0.531
2/21/96	12:43:04 PM	30.273	20.131	23.844	0.601
2/21/96	12:44:04 PM	24.9	20.12	16.032	0.566
2/21/96	12:45:04 PM	21.986	20.23	11.597	0.518
2/21/96	12:46:04 PM	26.641	20.254	17.375	0.544
2/21/96	12:47:04 PM	27.889	20.125	24.902	0.586
2/21/96	12:48:04 PM	25.354	20.149	13.346	0.563
2/21/96	12:49:04 PM	21.683	20.217	12.695	0.503
2/21/96	12:50:04 PM	27.927	20.241	18.758	0.539
2/21/96	12:51:04 PM	27.057	20.131	22.38	0.604
2/21/96	12:52:04 PM	24.03	20.14	11.475	0.557
2/21/96	12:53:04 PM	21.873	20.265	13.062	0.496
2/21/96	12:54:04 PM	29.1	20.206	20.671	0.57
2/21/96	12:55:04 PM	26.3	20.072	19.694	0.605
2/21/96	12:56:04 PM	22.554	20.199	10.579	0.535
2/21/96	12:57:04 PM	23.689	20.301	14.893	0.509
2/21/96	12:58:04 PM	29.63	20.156	23.071	0.592
2/21/96	12:59:04 PM	24.976	20.145	15.055	0.568
2/21/96	1:00:04 PM	22.592	20.213	10.376	0.537
2/21/96	1:01:04 PM	26.83	20.23	15.747	0.545
2/21/96	1:02:04 PM	27.927	20.136	23.397	0.586

LP/HAYWARD
Line 1 Press RTO Stack

Test 10 Run 1

2/21/96	1:03:04 PM	25.089	20.184	12.329	0.571
2/21/96	1:04:04 PM	21.608	20.243	11.719	0.509
2/21/96	1:05:04 PM	28.268	20.239	17.782	0.539
2/21/96	1:06:04 PM	27.36	20.116	21.851	0.607
2/21/96	1:07:04 PM	23.008	20.171	10.783	0.547
2/21/96	1:08:04 PM	20.851	20.342	12.207	0.48
2/21/96	1:09:04 PM	29.971	20.215	20.386	0.568
2/21/96	1:10:04 PM	26.111	20.09	19.979	0.588
2/21/96	1:11:04 PM	22.516	20.226	10.091	0.527
2/21/96	1:12:04 PM	24.332	20.314	14.608	0.514
2/21/96	1:13:04 PM	31.447	20.149	23.234	0.601
2/21/96	1:14:04 PM	25.013	20.158	15.218	0.566
2/21/96	1:15:04 PM	21.418	20.285	10.295	0.503
AVERAGES		25.7	20.2	17.4	0.6

LP/HAYWARD
Line 1 Press RTO Stack

Test 10 Run 2

DATE	TIME	NOX	O2	CO	CO2
2/21/96	2:00:20 PM	17.18	20.109	28.158	0.526
2/21/96	2:01:20 PM	23.84	20.006	21.81	0.602
2/21/96	2:02:20 PM	31.03	19.885	28.849	0.662
2/21/96	2:03:20 PM	24.9	19.989	36.214	0.579
2/21/96	2:04:20 PM	17.067	20.112	23.885	0.532
2/21/96	2:05:20 PM	25.808	19.956	22.095	0.622
2/21/96	2:06:20 PM	30.273	19.931	29.256	0.641
2/21/96	2:07:20 PM	22.667	19.982	33.244	0.615
2/21/96	2:08:20 PM	24.067	19.868	21.484	0.64
2/21/96	2:09:20 PM	29.592	19.879	22.786	0.697
2/21/96	2:10:20 PM	30.992	19.956	29.338	0.643
2/21/96	2:11:20 PM	15.288	20.114	28.727	0.518
2/21/96	2:12:20 PM	18.164	20.105	19.491	0.537
2/21/96	2:13:20 PM	27.435	19.96	23.397	0.645
2/21/96	2:14:20 PM	27.776	19.962	32.756	0.609
2/21/96	2:15:20 PM	22.705	19.945	26.164	0.643
2/21/96	2:16:20 PM	24.673	19.958	19.491	0.643
2/21/96	2:17:20 PM	31.257	19.835	25.269	0.68
2/21/96	2:18:20 PM	24.976	20.01	31.576	0.57
2/21/96	2:19:20 PM	15.515	20.129	22.38	0.503
2/21/96	2:20:20 PM	23.916	19.989	20.833	0.589
2/21/96	2:21:20 PM	30.652	19.958	27.71	0.627
2/21/96	2:22:20 PM	20.208	20.037	32.878	0.56
2/21/96	2:23:20 PM	18.694	20.052	21.2	0.549
2/21/96	2:24:20 PM	28.722	19.936	23.275	0.643
2/21/96	2:25:20 PM	31.598	19.94	30.518	0.638
2/21/96	2:26:20 PM	16.726	20.065	30.518	0.526
2/21/96	2:27:20 PM	19.753	20.079	20.06	0.55
2/21/96	2:28:20 PM	29.365	19.927	23.722	0.661
2/21/96	2:29:20 PM	29.781	19.914	32.633	0.62
2/21/96	2:30:20 PM	16.158	20.112	27.873	0.506
2/21/96	2:31:20 PM	22.97	20.008	20.549	0.597
2/21/96	2:32:20 PM	31.068	19.883	27.669	0.653
2/21/96	2:33:20 PM	26.906	19.973	35.156	0.584
2/21/96	2:34:20 PM	18.051	20.079	24.862	0.522
2/21/96	2:35:20 PM	26.868	19.96	22.42	0.614
2/21/96	2:36:20 PM	34.436	19.936	30.192	0.641
2/21/96	2:37:20 PM	21.532	20.032	34.749	0.55
2/21/96	2:38:20 PM	18.959	20.059	23.153	0.537
2/21/96	2:39:20 PM	28.608	19.956	24.251	0.623
2/21/96	2:40:20 PM	33.566	19.938	32.186	0.643
2/21/96	2:41:20 PM	18.77	20.019	32.552	0.542
2/21/96	2:42:20 PM	20.397	20.046	21.2	0.553
2/21/96	2:43:20 PM	30.992	19.898	24.74	0.674
2/21/96	2:44:20 PM	31.901	19.925	34.505	0.646
2/21/96	2:45:20 PM	16.688	20.105	29.012	0.513
2/21/96	2:46:20 PM	23.121	20.026	21.606	0.576

LP/HAYWARD
Line 1 Press RTO Stack
Test 10 Run 2

2/21/96	2:47:20 PM	31.749	19.872	28.402	0.666
2/21/96	2:48:20 PM	27.511	19.982	35.522	0.597
2/21/96	2:49:20 PM	17.937	20.035	25.024	0.531
2/21/96	2:50:20 PM	27.095	19.881	22.664	0.63
2/21/96	2:51:20 PM	33.49	19.811	30.436	0.648
2/21/96	2:52:20 PM	21.835	19.885	36.499	0.573
2/21/96	2:53:20 PM	19.753	19.874	24.902	0.566
2/21/96	2:54:20 PM	30.046	19.745	26.978	0.671
2/21/96	2:55:20 PM	33.944	19.767	35.197	0.664
2/21/96	2:56:20 PM	19.224	19.813	35.685	0.553
2/21/96	2:57:20 PM	21.418	19.839	24.699	0.578
2/21/96	2:58:20 PM	31.219	19.668	28.809	0.688
2/21/96	2:59:20 PM	30.652	19.718	38.534	0.61
AVERAGES		25.0	20.0	27.5	0.6

LP/HAYWARD
Line 1 Press RTO Stack

Test 10 Run 3

DATE	TIME	NOX	O2	CO	CO2
2/21/96	3:35:57 PM	20.00	19.50	24.00	0.60
2/21/96	3:36:57 PM	19.80	19.80	33.00	0.40
2/21/96	3:37:57 PM	20.10	19.60	22.00	0.50
2/21/96	3:38:57 PM	28.00	19.60	25.00	0.60
2/21/96	3:39:57 PM	20.00	19.80	34.00	0.50
2/21/96	3:40:57 PM	21.00	19.60	30.00	0.50
2/21/96	3:41:57 PM	27.00	19.50	22.00	0.60
2/21/96	3:42:57 PM	25.00	19.50	34.00	0.40
2/21/96	3:43:57 PM	31.787	19.958	31.779	0.64
2/21/96	3:44:56 PM	20.851	20.145	39.266	0.54
2/21/96	3:45:56 PM	22.554	20.076	25.92	0.599
2/21/96	3:46:56 PM	29.517	19.94	27.913	0.643
2/21/96	3:47:56 PM	30.576	20.074	34.058	0.605
2/21/96	3:48:56 PM	19.072	20.167	36.662	0.534
2/21/96	3:49:56 PM	24.938	20.006	25.024	0.612
2/21/96	3:50:56 PM	29.29	20.008	28.32	0.612
2/21/96	3:51:56 PM	28.608	20.092	36.906	0.579
2/21/96	3:52:56 PM	19.602	20.129	32.023	0.539
2/21/96	3:53:56 PM	27.322	20	25.269	0.622
2/21/96	3:54:56 PM	30.917	20.017	30.192	0.632
2/21/96	3:55:56 PM	24.219	20.107	38.574	0.532
2/21/96	3:56:56 PM	20.624	20.118	27.262	0.545
2/21/96	3:57:56 PM	28.041	19.991	25.065	0.641
2/21/96	3:58:56 PM	30.5	20.028	29.948	0.596
2/21/96	3:59:56 PM	22.327	20.16	38.818	0.532
2/21/96	4:00:56 PM	23.765	20.061	24.862	0.589
2/21/96	4:01:56 PM	28.76	19.986	26.001	0.623
2/21/96	4:02:56 PM	29.479	20.085	31.698	0.575
2/21/96	4:03:56 PM	19.148	20.173	35.807	0.527
2/21/96	4:04:56 PM	24.635	20.037	24.251	0.591
2/21/96	4:05:56 PM	28.722	20.032	26.733	0.605
2/21/96	4:06:56 PM	27.776	20.116	35.075	0.566
2/21/96	4:07:56 PM	19.905	20.138	32.023	0.527
2/21/96	4:08:56 PM	27.511	19.997	24.577	0.628
2/21/96	4:09:56 PM	29.744	20.024	28.605	0.62
2/21/96	4:10:56 PM	23.5	20.171	37.313	0.513
2/21/96	4:11:56 PM	21.154	20.16	27.059	0.55
2/21/96	4:12:56 PM	27.7	19.971	23.885	0.64
2/21/96	4:13:56 PM	28.306	20.074	28.158	0.581
2/21/96	4:14:56 PM	22.024	20.188	38.086	0.514
2/21/96	4:15:56 PM	23.538	20.074	24.902	0.597
2/21/96	4:16:56 PM	27.397	20.05	24.984	0.596
2/21/96	4:17:56 PM	29.138	20.129	30.355	0.581
2/21/96	4:18:56 PM	20.889	20.153	36.458	0.54
2/21/96	4:19:56 PM	25.392	20.057	24.089	0.604
2/21/96	4:20:56 PM	28.949	20.063	25.431	0.605
2/21/96	4:21:56 PM	26.224	20.136	33.407	0.547

LP/HAYWARD
Line 1 Press RTO Stack
Test 10 Run 3

2/21/96	4:22:56 PM	20.435	20.142	31.82	0.524
2/21/96	4:23:56 PM	26.906	20.035	24.089	0.623
2/21/96	4:24:56 PM	28.533	20.035	27.425	0.604
2/21/96	4:25:56 PM	24.635	20.162	36.906	0.524
2/21/96	4:26:56 PM	22.251	20.14	26.774	0.568
2/21/96	4:27:56 PM	27.057	20	23.356	0.617
2/21/96	4:28:56 PM	27.625	20.127	27.425	0.571
2/21/96	4:29:56 PM	22.629	20.21	38.045	0.513
2/21/96	4:30:56 PM	24.181	20.072	24.74	0.596
2/21/96	4:31:56 PM	27.17	20.041	24.089	0.594
2/21/96	4:32:56 PM	28.987	20.138	29.744	0.566
2/21/96	4:33:56 PM	20.927	20.169	36.255	0.537
2/21/96	4:34:56 PM	25.43	20.072	23.6	0.594
AVERAGES		25.2	20.0	29.6	0.6

LP/HAYWARD
Line 1 Press RTO Inlet

Test 13 Run 1

DATE	TIME	THC	NOX	O2	CO	CO2
2/21/96	12:16:20 PM	15.161	11.727	21.199	14.852	0.127
2/21/96	12:17:20 PM	6.877	10.368	20.714	13.672	0.094
2/21/96	12:18:20 PM	4.346	10.303	20.859	12.98	0.091
2/21/96	12:19:20 PM	8.325	11.108	21.008	14.282	0.107
2/21/96	12:20:20 PM	14.697	11.621	21.037	14.893	0.122
2/21/96	12:21:20 PM	5.558	10.539	21.051	14.364	0.103
2/21/96	12:22:20 PM	4.15	10.872	21.043	13.672	0.103
2/21/96	12:23:20 PM	9.106	11.768	21.021	12.736	0.119
2/21/96	12:24:20 PM	14.185	11.89	21.033	12.777	0.117
2/21/96	12:25:20 PM	4.655	10.905	21.031	12.248	0.101
2/21/96	12:26:20 PM	5.103	11.548	21.023	13.102	0.098
2/21/96	12:27:20 PM	12.435	12.459	20.959	14.486	0.129
2/21/96	12:28:20 PM	10.327	11.816	20.959	16.52	0.101
2/21/96	12:29:20 PM	4.24	11.344	20.962	16.642	0.094
2/21/96	12:30:20 PM	6.047	12.28	20.98	16.968	0.096
2/21/96	12:31:20 PM	14.494	13.241	20.955	16.642	0.12
2/21/96	12:32:20 PM	6.901	11.784	20.962	15.218	0.094
2/21/96	12:33:20 PM	3.882	11.963	20.959	13.916	0.099
2/21/96	12:34:20 PM	7.658	12.785	20.955	15.015	0.098
2/21/96	12:35:20 PM	14.144	13.452	20.949	15.299	0.117
2/21/96	12:36:20 PM	5.298	12.118	20.978	13.59	0.091
2/21/96	12:37:20 PM	3.768	12.378	20.943	12.288	0.091
2/21/96	12:38:20 PM	8.049	13.184	20.941	12.37	0.104
2/21/96	12:39:20 PM	13.883	13.363	20.941	12.533	0.109
2/21/96	12:40:20 PM	4.395	12.321	20.931	11.963	0.096
2/21/96	12:41:20 PM	4.313	12.76	20.957	11.637	0.096
2/21/96	12:42:20 PM	10.254	13.745	20.964	11.515	0.107
2/21/96	12:43:20 PM	10.628	13.102	20.959	11.353	0.101
2/21/96	12:44:20 PM	3.597	12.581	20.98	10.254	0.096
2/21/96	12:45:20 PM	5.192	12.996	20.976	9.806	0.101
2/21/96	12:46:20 PM	13.721	14.054	20.962	9.277	0.127
2/21/96	12:47:20 PM	6.763	12.508	20.964	9.562	0.101
2/21/96	12:48:20 PM	3.483	12.606	20.968	8.83	0.093
2/21/96	12:49:20 PM	6.795	13.192	20.955	8.789	0.099
2/21/96	12:50:20 PM	13.826	13.639	20.949	8.301	0.12
2/21/96	12:51:20 PM	5.062	12.28	20.966	7.365	0.098
2/21/96	12:52:20 PM	3.215	12.451	20.945	7.324	0.091
2/21/96	12:53:20 PM	7.479	13.216	20.909	7.568	0.101
2/21/96	12:54:20 PM	13.77	13.298	20.927	7.69	0.112
2/21/96	12:55:20 PM	4.02	12.248	20.931	4.801	0.081
2/21/96	12:56:20 PM	4.053	12.614	20.925	6.104	0.091
2/21/96	12:57:20 PM	9.66	13.656	20.941	5.656	0.116
2/21/96	12:58:20 PM	11.556	12.899	20.931	5.778	0.104
2/21/96	12:59:20 PM	3.516	12.313	20.931	5.493	0.093
2/21/96	1:00:20 PM	4.85	12.939	20.9	7.039	0.099
2/21/96	1:01:20 PM	13.411	14.087	20.941	7.853	0.122
2/21/96	1:02:20 PM	7.21	12.508	20.937	7.284	0.093

LP/HAYWARD
Line 1 Press RTO Inlet

Test 13 Run 1

2/21/96	1:03:20 PM	3.288	12.557	20.937	6.592	0.093
2/21/96	1:04:20 PM	6.852	13.281	20.953	5.493	0.099
2/21/96	1:05:20 PM	13.737	14.087	20.931	5.371	0.111
2/21/96	1:06:20 PM	4.907	12.467	20.943	4.598	0.103
2/21/96	1:07:20 PM	3.06	12.736	20.941	6.022	0.091
2/21/96	1:08:20 PM	7.422	13.615	20.937	6.673	0.117
2/21/96	1:09:20 PM	14.771	13.761	20.9	6.999	0.111
2/21/96	1:10:20 PM	4.207	12.492	20.925	6.185	0.09
2/21/96	1:11:20 PM	4.126	13.029	20.919	5.9	0.091
2/21/96	1:12:20 PM	10.278	14.079	20.927	6.063	0.116
2/21/96	1:13:20 PM	12.581	13.298	20.915	5.656	0.104
2/21/96	1:14:20 PM	3.654	12.606	20.898	4.924	0.08
2/21/96	1:15:20 PM	5.526	13.298	20.87	4.761	0.091
AVERAGES		7.8	12.6	21	10.1	0.1
ppmc.w =		23.4				

LP/HAYWARD
Line 1 Press RTO Inlet
Test 13 Run 2

DATE	TIME	THC	NOX	O2	CO	CO2
2/21/96	2:01:00 PM	4.639	2.979	21.462	7.812	0.06
2/21/96	2:02:00 PM	8.252	3.76	21.47	8.016	0.073
2/21/96	2:03:00 PM	17.521	4.46	21.493	8.789	0.094
2/21/96	2:04:00 PM	6.812	2.808	21.48	8.667	0.06
2/21/96	2:05:00 PM	4.932	2.979	21.47	8.057	0.054
2/21/96	2:06:00 PM	9.505	3.841	21.466	8.301	0.073
2/21/96	2:07:00 PM	15.275	3.971	21.446	9.033	0.078
2/21/96	2:08:00 PM	5.404	2.913	21.46	8.952	0.06
2/21/96	2:09:00 PM	5.518	3.312	21.446	9.277	0.055
2/21/96	2:10:00 PM	11.092	4.199	21.458	9.074	0.08
2/21/96	2:11:00 PM	13.322	3.809	21.456	8.545	0.068
2/21/96	2:12:00 PM	4.663	3.06	21.46	7.853	0.054
2/21/96	2:13:00 PM	5.688	3.491	21.478	7.243	0.054
2/21/96	2:14:00 PM	15.324	4.769	21.442	7.324	0.088
2/21/96	2:15:00 PM	9.163	3.377	21.464	6.632	0.059
2/21/96	2:16:00 PM	4.468	3.524	21.499	6.104	0.049
2/21/96	2:17:00 PM	7.275	4.134	21.46	6.348	0.068
2/21/96	2:18:00 PM	16.512	4.883	21.456	6.388	0.083
2/21/96	2:19:00 PM	6.877	3.442	21.458	6.388	0.049
2/21/96	2:20:00 PM	4.793	3.646	21.464	5.208	0.06
2/21/96	2:21:00 PM	9.147	4.541	21.444	4.842	0.08
2/21/96	2:22:00 PM	16.178	4.679	21.448	5.534	0.083
2/21/96	2:23:00 PM	5.599	3.597	21.44	4.801	0.063
2/21/96	2:24:00 PM	5.77	4.061	21.452	4.761	0.054
2/21/96	2:25:00 PM	11.597	5.037	21.448	5.086	0.091
2/21/96	2:26:00 PM	14.119	4.631	21.438	5.493	0.085
2/21/96	2:27:00 PM	4.997	3.931	21.44	5.168	0.059
2/21/96	2:28:00 PM	5.892	4.451	21.417	5.33	0.067
2/21/96	2:29:00 PM	16.243	5.672	21.409	5.819	0.094
2/21/96	2:30:00 PM	10.563	4.289	21.407	5.819	0.072
2/21/96	2:31:00 PM	5.135	4.248	21.409	5.127	0.063
2/21/96	2:32:00 PM	8.512	4.98	21.448	5.168	0.085
2/21/96	2:33:00 PM	18.156	5.868	21.45	6.836	0.103
2/21/96	2:34:00 PM	8.122	4.557	21.446	8.464	0.068
2/21/96	2:35:00 PM	5.754	4.81	21.44	10.417	0.065
2/21/96	2:36:00 PM	10.482	5.754	21.411	11.922	0.08
2/21/96	2:37:00 PM	17.668	5.916	21.417	12.126	0.086
2/21/96	2:38:00 PM	6.372	4.94	21.421	10.62	0.057
2/21/96	2:39:00 PM	6.079	5.339	21.289	9.603	0.06
2/21/96	2:40:00 PM	12.215	6.234	21.171	9.033	0.085
2/21/96	2:41:00 PM	15.194	5.68	21.159	8.748	0.067
2/21/96	2:42:00 PM	5.371	4.94	21.2	7.731	0.065
2/21/96	2:43:00 PM	6.299	5.404	21.155	7.284	0.076
2/21/96	2:44:00 PM	16.699	6.543	21.155	7.121	0.096
2/21/96	2:45:00 PM	11.385	5.233	21.171	7.08	0.063
2/21/96	2:46:00 PM	5.501	5.119	21.177	6.429	0.068
2/21/96	2:47:00 PM	8.781	5.957	21.143	7.65	0.08

LP/HAYWARD
Line 1 Press RTO Inlet

Test 13 Run 2

2/21/96	2:48:00 PM	18.197	6.689	21.161	8.83	0.099
2/21/96	2:49:00 PM	7.812	5.111	21.145	8.586	0.067
2/21/96	2:50:00 PM	5.566	5.412	21.183	8.301	0.054
2/21/96	2:51:00 PM	10.62	6.185	21.149	8.179	0.093
2/21/96	2:52:00 PM	17.684	6.396	21.155	8.789	0.073
2/21/96	2:53:00 PM	6.616	5.192	21.163	8.708	0.059
2/21/96	2:54:00 PM	6.624	5.648	21.161	8.911	0.067
2/21/96	2:55:00 PM	13.232	6.51	21.167	8.911	0.096
2/21/96	2:56:00 PM	15.454	5.957	21.149	8.219	0.078
2/21/96	2:57:00 PM	5.615	5.176	21.155	6.795	0.057
2/21/96	2:58:00 PM	6.608	5.623	21.153	6.429	0.067
2/21/96	2:59:00 PM	17.301	6.86	21.139	6.226	0.094
2/21/96	3:00:00 PM	12.101	5.566	21.136	5.981	0.063
AVERAGES		9.8	4.8	21.3	7.5	0.1
ppmc,w =		29.4				

LP/HAYWARD
Line 1 Press RTO Inlet
Test 13 Run 3

DATE	TIME	THC	NOX	O2	CO	CO2
2/21/96	3:36:38 PM	21.126	4.191	21.236	5.412	0.103
2/21/96	3:37:38 PM	10.75	2.344	21.257	4.72	0.073
2/21/96	3:38:38 PM	5.697	2.458	21.259	4.191	0.057
2/21/96	3:39:38 PM	11.174	3.605	21.244	4.801	0.078
2/21/96	3:40:38 PM	21.916	4.134	21.248	5.615	0.096
2/21/96	3:41:38 PM	7.878	2.563	21.224	5.046	0.065
2/21/96	3:42:38 PM	5.77	2.848	21.263	4.354	0.083
2/21/96	3:43:38 PM	12.85	3.988	21.273	4.232	0.104
2/21/96	3:44:38 PM	23.242	4.232	21.263	4.069	0.112
2/21/96	3:45:38 PM	7.08	2.686	21.285	3.377	0.08
2/21/96	3:46:38 PM	7.373	3.141	21.259	3.784	0.086
2/21/96	3:47:38 PM	16.447	4.427	21.254	4.557	0.101
2/21/96	3:48:38 PM	19.922	3.597	21.254	5.046	0.098
2/21/96	3:49:38 PM	6.266	2.694	21.244	4.476	0.08
2/21/96	3:50:38 PM	8.577	3.296	21.254	4.476	0.081
2/21/96	3:51:38 PM	22.925	4.574	21.246	4.883	0.104
2/21/96	3:52:38 PM	12.459	3.027	21.254	4.883	0.08
2/21/96	3:53:38 PM	6.356	2.865	21.24	4.15	0.075
2/21/96	3:54:38 PM	11.548	3.524	21.23	3.988	0.076
2/21/96	3:55:38 PM	23.722	4.232	21.214	4.272	0.099
2/21/96	3:56:38 PM	8.683	2.604	21.23	4.15	0.057
2/21/96	3:57:38 PM	5.924	2.783	21.214	3.784	0.063
2/21/96	3:58:38 PM	12.362	3.646	21.228	4.15	0.09
2/21/96	3:59:38 PM	24.959	4.012	21.244	4.191	0.09
2/21/96	4:00:38 PM	7.365	2.596	21.24	3.703	0.067
2/21/96	4:01:38 PM	7.121	2.938	21.214	2.93	0.067
2/21/96	4:02:38 PM	15.885	3.866	21.232	2.93	0.088
2/21/96	4:03:38 PM	21.908	3.434	21.228	2.889	0.085
2/21/96	4:04:38 PM	6.592	2.515	21.234	2.238	0.063
2/21/96	4:05:38 PM	8.545	3.084	21.216	2.36	0.072
2/21/96	4:06:38 PM	22.811	4.224	21.208	2.726	0.096
2/21/96	4:07:38 PM	14.079	2.873	21.216	2.808	0.078
2/21/96	4:08:38 PM	6.527	2.604	21.212	1.912	0.062
2/21/96	4:09:38 PM	11.239	3.296	21.21	2.035	0.078
2/21/96	4:10:38 PM	24.479	4.028	21.226	1.79	0.094
2/21/96	4:11:38 PM	9.399	2.515	21.21	1.79	0.07
2/21/96	4:12:38 PM	5.99	2.637	21.216	1.383	0.063
2/21/96	4:13:38 PM	11.41	3.361	21.204	1.465	0.076
2/21/96	4:14:38 PM	25.708	3.971	21.198	1.668	0.096
2/21/96	4:15:38 PM	7.959	2.441	21.198	1.953	0.065
2/21/96	4:16:38 PM	7.259	2.816	21.208	1.79	0.072
2/21/96	4:17:38 PM	14.982	3.695	21.191	1.668	0.076
2/21/96	4:18:38 PM	21.883	3.459	21.2	1.994	0.083
2/21/96	4:19:38 PM	6.828	2.62	21.189	1.383	0.072
2/21/96	4:20:38 PM	8.081	3.068	21.212	1.383	0.065
2/21/96	4:21:38 PM	20.809	3.931	21.21	1.587	0.09
2/21/96	4:22:38 PM	14.998	3.092	21.185	2.116	0.076

LP/HAYWARD
Line 1 Press RTO Inlet

Test 13 Run 3

2/21/96	4:23:38 PM	6.527	2.873	21.2	2.035	0.057
2/21/96	4:24:38 PM	10.352	3.556	21.195	2.97	0.072
2/21/96	4:25:38 PM	23.503	4.329	21.193	3.337	0.096
2/21/96	4:26:38 PM	9.595	2.84	21.193	2.563	0.065
2/21/96	4:27:38 PM	5.851	3.019	21.198	2.116	0.062
2/21/96	4:28:38 PM	10.994	3.743	21.173	2.238	0.08
2/21/96	4:29:38 PM	24.202	4.183	21.202	2.238	0.094
2/21/96	4:30:38 PM	7.764	2.759	21.187	1.75	0.055
2/21/96	4:31:38 PM	6.519	3.133	21.202	1.261	0.065
2/21/96	4:32:38 PM	13.558	4.102	21.2	1.831	0.091
2/21/96	4:33:38 PM	21.387	3.743	21.198	2.319	0.083
2/21/96	4:34:38 PM	6.437	2.686	21.169	0.977	0.059
2/21/96	4:35:38 PM	7.658	3.174	21.185	1.139	0.063
AVERAGES		12.9	3.3	21.2	3	0.1
ppmc,w =		38.7				

LP/HAYWARD
Line 1 Thermal Oil Heater
Test 18 Run 1

DATE	TIME	NOX	O2	CO	CO2
2/22/96	9:00:20 AM	98.612	12.651	40.812	8.013
2/22/96	9:01:20 AM	97.799	12.919	40.568	7.816
2/22/96	9:02:20 AM	90.535	12.437	100.464	8.252
2/22/96	9:03:20 AM	85.693	12.124	212.118	8.569
2/22/96	9:05:00 AM	90.983	12.97	479.167	7.653
2/22/96	9:06:00 AM	88.969	13.934	106.934	6.696
2/22/96	9:07:00 AM	84.839	14.518	114.095	6.19
2/22/96	9:08:00 AM	82.703	15.074	197.591	5.685
2/22/96	9:09:00 AM	82.987	15.186	248.291	5.563
2/22/96	9:10:00 AM	75.358	15.719	327.311	5.005
2/22/96	9:11:00 AM	74.707	15.928	489.909	4.824
2/22/96	9:12:00 AM	79.325	15.651	440.104	5.133
2/22/96	9:13:00 AM	85.856	14.939	321.696	5.884
2/22/96	9:14:00 AM	89.925	13.824	141.764	6.865
2/22/96	9:15:02 AM	87.992	13.588	114.909	6.971
2/22/96	9:16:02 AM	91.349	14.087	109.863	6.593
2/22/96	9:17:02 AM	91.349	13.999	81.299	6.667
2/22/96	9:18:02 AM	86.995	14.311	93.424	6.367
2/22/96	9:19:02 AM	87.667	14.577	159.017	6.147
2/22/96	9:20:02 AM	88.623	14.585	125.326	6.117
2/22/96	9:21:02 AM	83.944	15.096	140.381	5.64
2/22/96	9:22:02 AM	82.214	15.12	181.234	5.695
2/22/96	9:23:02 AM	86.324	14.838	181.315	5.952
2/22/96	9:24:02 AM	89.437	14.606	187.826	6.087
2/22/96	9:25:02 AM	86.182	15.106	195.557	5.664
2/22/96	9:26:02 AM	96.7	14.229	264.974	6.522
2/22/96	9:27:02 AM	95.601	13.67	101.969	6.956
2/22/96	9:28:02 AM	93.608	13.731	121.501	6.912
2/22/96	9:29:02 AM	91.39	14.183	160.726	6.491
2/22/96	9:30:02 AM	89.742	14.276	257.08	6.462
2/22/96	9:31:02 AM	92.651	13.357	253.255	7.345
* 2/22/96	9:32:02 AM	22.746	19.371	124.268	1.683
2/22/96	9:33:02 AM	85.449	14.665	136.23	6.125
2/22/96	9:34:02 AM	83.13	14.903	257.975	5.84
2/22/96	9:35:02 AM	82.072	15.255	231.934	5.527
2/22/96	9:36:02 AM	86.629	14.836	245.687	5.973
2/22/96	9:37:02 AM	91.634	13.812	151.204	6.87
2/22/96	9:38:02 AM	91.512	13.936	130.29	6.706
2/22/96	9:39:02 AM	87.728	14.51	152.588	6.143
2/22/96	9:40:02 AM	83.049	15.442	188.395	5.335
2/22/96	9:41:02 AM	84.005	15.363	257.324	5.402
2/22/96	9:42:02 AM	79.793	15.562	282.796	5.21
2/22/96	9:43:02 AM	79.224	15.576	322.184	5.187
2/22/96	9:44:02 AM	82.581	15.558	306.966	5.257
2/22/96	9:45:02 AM	88.114	15.324	198.161	5.496
2/22/96	9:46:02 AM	98.694	14.292	168.701	6.504
2/22/96	9:47:02 AM	101.807	13.312	73.324	7.282

LP/HAYWARD
Line 1 Thermal Oil Heater
Test 18 Run 1

2/22/96	9:48:02 AM	97.961	13.93	88.46	6.639
2/22/96	9:49:02 AM	92.631	14.779	128.662	5.949
2/22/96	9:50:02 AM	96.334	14.577	208.903	6.172
2/22/96	9:51:02 AM	91.41	14.901	190.592	5.807
2/22/96	9:52:02 AM	94.889	14.156	255.941	6.621
2/22/96	9:53:02 AM	90.495	13.536	96.273	7.051
2/22/96	9:54:02 AM	93.262	13.936	94.401	6.74
2/22/96	9:55:02 AM	99.731	13.574	90.007	7.064
2/22/96	9:56:02 AM	101.664	13.595	98.145	7.031
2/22/96	9:57:02 AM	105.103	13.255	86.751	7.384
2/22/96	9:58:02 AM	98.165	13.548	97.412	7.07
2/22/96	9:59:02 AM	93.852	14.103	94.808	6.584
2/22/96	10:00:02 AM	99.264	14.052	90.82	6.629
2/22/96	10:01:02 AM	96.212	14.178	95.866	6.514
2/22/96	10:02:02 AM	102.458	13	89.925	7.772
2/22/96	10:03:02 AM	100.932	12.392	81.217	8.317
2/22/96	10:04:02 AM	96.395	11.991	167.074	8.732
AVERAGES		90.3	14.2	177.0	6.5
* Port Change - Data Not Used in Calculation of Averages					

LP/HAYWARD
Line 1 Thermal Oil Heater
Test 18 Run 2

DATE	TIME	NOX	O2	CO	CO2
2/22/96	10:53:30 AM	83.476	13.942	55.013	6.313
2/22/96	10:54:30 AM	88.013	13.405	66.488	6.88
2/22/96	10:55:30 AM	91.288	12.506	83.577	7.76
2/22/96	10:56:30 AM	92.529	12.712	77.148	7.539
2/22/96	10:57:30 AM	95.154	12.02	76.009	8.332
2/22/96	10:58:30 AM	94.137	11.912	139.811	8.343
2/22/96	10:59:30 AM	100.444	11.452	253.581	8.887
2/22/96	11:00:30 AM	100.749	10.848	194.661	9.427
2/22/96	11:01:30 AM	99.121	10.718	194.255	9.52
2/22/96	11:02:30 AM	84.961	10.846	1003.906	9.25
2/22/96	11:03:30 AM	80.566	11.194	2009.603	8.823
2/22/96	11:04:30 AM	96.069	11.886	1348.389	8.324
2/22/96	11:05:30 AM	100.301	12.28	154.053	7.899
2/22/96	11:06:30 AM	104.533	11.8	71.94	8.587
2/22/96	11:07:30 AM	102.987	11.058	106.283	9.211
2/22/96	11:08:30 AM	102.478	11.41	152.588	8.768
2/22/96	11:09:30 AM	100.199	12.406	70.638	7.775
2/22/96	11:10:30 AM	103.455	12.335	86.995	8.032
2/22/96	11:11:30 AM	103.048	11.051	330.16	9.183
2/22/96	11:12:30 AM	105.042	11.31	170.41	8.984
2/22/96	11:13:30 AM	105.896	11.503	81.787	8.714
2/22/96	11:14:30 AM	106.588	11.072	83.74	9.194
2/22/96	11:15:30 AM	98.348	11.279	157.715	8.867
2/22/96	11:16:30 AM	94.584	11.743	118.083	8.527
2/22/96	11:17:30 AM	92.428	12.567	94.808	7.443
2/22/96	11:18:30 AM	101.379	13.013	97.738	7.241
2/22/96	11:19:30 AM	103.088	12.614	92.773	7.588
2/22/96	11:20:30 AM	102.437	12.683	68.604	7.454
2/22/96	11:21:30 AM	103.516	12.596	77.393	7.765
2/22/96	11:22:30 AM	107.259	11.058	105.794	9.22
2/22/96	11:23:30 AM	101.664	10.168	96.598	10.07
2/22/96	11:24:30 AM	95.683	10.077	283.61	10.05
2/22/96	11:25:30 AM	19.328	16.99	1009.521	2.692
2/22/96	11:26:30 AM	97.778	13.865	86.67	7.116
2/22/96	11:27:30 AM	88.603	12.878	110.921	7.214
2/22/96	11:28:30 AM	89.823	13.208	76.497	6.943
2/22/96	11:29:30 AM	95.133	12.531	55.42	7.798
2/22/96	11:30:30 AM	96.497	12.201	71.615	8.021
2/22/96	11:31:30 AM	104.614	11.542	69.824	8.781
2/22/96	11:32:30 AM	104.899	11.416	84.229	8.783
2/22/96	11:33:30 AM	99.223	12.197	97.005	7.868
2/22/96	11:34:30 AM	95.459	12.61	110.352	7.664
2/22/96	11:35:30 AM	96.069	12.225	65.837	7.876
2/22/96	11:36:30 AM	99.569	12.488	84.798	7.775
2/22/96	11:37:30 AM	102.478	11.631	76.904	8.581
2/22/96	11:38:30 AM	102.234	12.244	70.719	7.952
2/22/96	11:39:30 AM	102.437	11.646	73.975	8.639

LP/HAYWARD
Line 1 Thermal Oil Heater
Test 18 Run 2

2/22/96	11:40:30 AM	97.168	10.445	399.333	9.85
2/22/96	11:41:30 AM	101.929	10.687	377.686	9.357
2/22/96	11:42:30 AM	101.156	11.359	93.831	8.895
2/22/96	11:43:30 AM	103.231	11.473	64.046	8.74
2/22/96	11:44:30 AM	102.336	11.251	83.333	8.963
2/22/96	11:45:30 AM	103.658	11.076	251.872	9.199
2/22/96	11:46:30 AM	101.44	10.626	84.391	9.578
2/22/96	11:47:30 AM	102.254	11.043	126.709	9.102
2/22/96	11:48:30 AM	101.99	11.558	79.997	8.59
2/22/96	11:49:30 AM	100.199	12.122	60.547	8.097
2/22/96	11:50:30 AM	99.325	11.914	55.257	8.325
2/22/96	11:51:30 AM	100.118	10.836	67.627	9.471
2/22/96	11:52:30 AM	100.932	10.439	318.115	9.652
2/22/96	11:53:30 AM	92	10.671	1491.862	9.321
2/22/96	11:54:30 AM	100.586	10.659	1880.778	9.502
2/22/96	11:55:30 AM	105.123	11.279	357.585	8.893
2/22/96	11:56:30 AM	99.386	12.044	83.415	8.055
2/22/96	11:57:30 AM	100.728	12.484	72.184	7.733
AVERAGES		97.7	11.8	247.6	8.4

LP/HAYWARD
Line 1 Thermal Oil Heater

Test 18 Run 3


DATE	TIME	NOX	O2	CO	CO2
2/22/96	1:03:44 PM	71.94	15.057	93.343	5.719
2/22/96	1:04:44 PM	69.906	15.23	91.553	5.557
2/22/96	1:05:44 PM	72.225	15.19	92.041	5.649
2/22/96	1:06:44 PM	70.618	15.2	83.496	5.583
2/22/96	1:07:44 PM	71.96	15.42	107.666	5.443
2/22/96	1:08:44 PM	77.677	15.035	107.666	5.773
2/22/96	1:09:44 PM	78.023	14.921	89.274	5.851
2/22/96	1:10:44 PM	78.918	14.96	93.587	5.881
2/22/96	1:11:44 PM	82.967	14.421	79.102	6.367
2/22/96	1:12:44 PM	77.189	14.671	60.059	6.061
2/22/96	1:13:44 PM	84.249	14.463	81.299	6.382
2/22/96	1:14:44 PM	88.684	13.662	78.695	7.15
2/22/96	1:15:44 PM	88.562	12.148	352.865	8.543
2/22/96	1:16:44 PM	88.46	13.017	282.064	7.505
2/22/96	1:17:44 PM	83.618	13.863	72.021	6.8
2/22/96	1:18:44 PM	90.495	13.143	62.256	7.699
2/22/96	1:19:44 PM	96.639	11.979	73.812	8.669
2/22/96	1:20:44 PM	91.227	12.667	64.372	7.979
2/22/96	1:21:44 PM	93.811	12.233	110.352	8.522
2/22/96	1:22:44 PM	89.722	12.762	93.587	7.837
2/22/96	1:23:44 PM	90.759	12.933	56.396	7.79
2/22/96	1:24:44 PM	90.312	12.988	71.777	7.707
2/22/96	1:25:44 PM	87.992	13.133	62.174	7.513
2/22/96	1:26:44 PM	85.164	13.507	68.115	7.126
2/22/96	1:27:44 PM	87.321	13.552	75.195	7.134
2/22/96	1:28:44 PM	91.064	13.188	52.653	7.505
2/22/96	1:29:44 PM	92.021	12.644	49.723	8.029
2/22/96	1:30:44 PM	96.008	12.887	61.849	7.842
2/22/96	1:31:44 PM	93.933	12.168	148.763	8.53
2/22/96	1:32:44 PM	90.963	13.017	230.713	7.643
2/22/96	1:33:44 PM	88.481	13.098	91.797	7.541
2/22/96	1:34:44 PM	43.62	15.843	96.68	4.396
2/22/96	1:35:44 PM	78.084	15.761	41.341	6.025
2/22/96	1:36:44 PM	96.415	11.619	167.725	9.132
2/22/96	1:37:44 PM	96.354	11.637	857.015	8.856
2/22/96	1:38:44 PM	89.05	13.082	230.225	7.531
2/22/96	1:39:44 PM	92.244	13.021	77.962	7.669
2/22/96	1:40:44 PM	93.689	12.828	68.278	7.904
2/22/96	1:41:44 PM	98.287	12.17	68.441	8.547
2/22/96	1:42:44 PM	98.124	11.963	67.22	8.781
2/22/96	1:43:44 PM	95.479	11.613	259.766	8.978
2/22/96	1:44:44 PM	90.698	12.201	109.782	8.499
2/22/96	1:45:44 PM	93.018	11.961	63.558	8.77
2/22/96	1:46:44 PM	99.487	11.945	61.279	8.765
2/22/96	1:47:44 PM	101.054	11.326	134.277	9.386
2/22/96	1:48:44 PM	97.026	11.652	433.024	8.931
2/22/96	1:49:44 PM	94.442	11.82	108.724	8.869

LP/HAYWARD
Line 1 Thermal Oil Heater
Test 18 Run 3

2/22/96	1:50:44 PM	94.686	11.934	129.15	8.7
2/22/96	1:51:44 PM	98.674	12.433	71.208	8.201
2/22/96	1:52:44 PM	95.072	13.131	63.639	7.585
2/22/96	1:53:44 PM	97.921	12.394	75.114	8.312
2/22/96	1:54:44 PM	98.124	12.433	58.675	8.304
2/22/96	1:55:44 PM	97.717	11.851	59.001	8.88
2/22/96	1:56:44 PM	98.999	11.568	57.699	9.115
2/22/96	1:57:44 PM	94.666	12.164	52.165	8.449
2/22/96	1:58:44 PM	96.598	12.268	59.896	8.429
2/22/96	1:59:44 PM	96.517	12.413	62.174	8.289
2/22/96	2:00:44 PM	97.209	12.309	68.522	8.496
2/22/96	2:01:44 PM	100.301	10.895	78.613	9.744
2/22/96	2:02:44 PM	103.109	11.422	62.581	9.124
2/22/96	2:03:44 PM	103.943	11.753	71.859	8.952
AVERAGES		89.7	13.0	114.0	7.7

APPENDIX G

MEASUREMENT SYSTEM PERFORMANCE SPECIFICATIONS



INTERPOLL LABORATORIES, INC

(612) 786-6020

EPA Method 25 A

Calibration Error Check & Drift Determination

Job L.P. / Hayward, WI
 Test 1 Run 0 Date 2-19-96
 Operator M. Kaehler

THC Calibration (Low Range):

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0	0	100	0
Low Level	30.4	30	.4	100	.4
Mid Level	300	295	5	1,000	.5
High Level	2990	3029	39	10,000	.39

THC Calibration (High Range):

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0				
Span					

O₂ Calibration:

Time (HRS) _____

***	Cylinder Value (%)	Analyzer Response (%)	Difference (%)	Span Value (%)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

CO₂ Calibration:

Time: (HRS) _____

***	Cylinder Value (%)	Analyzer Response (%)	Difference (%)	Span Value (%)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

Must be within 2% of the span for each calibration gas.

052394-G:\STACK\WP\FORMS\S-420-14

EPA Method 2 Field Data Sheet

Drawing of Test Site

Job K.P. / Hayward, WI
Source ATO Drier / Stack
Test 6 Run Date 2-20-96
Stack Dimen. 81.5 IN.
Dry Bulb °F Wet bulb °F
Manometer ☐ Reg. ☐ Exp ☐ Elec.
Barometric Pressure IN.HG
Static Pressure IN.WC
Operators M. Kuebler & J. Lorenz
Pitot No. INST C NA

Cross-section View	Elevation View
-----------------------	-------------------

[illegible]

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:STACK/WP/FORMS/392.1

INTERPOL LABORATORIES, INC

(612) 786-6020

N/Ox Cal Drift Check

Job

L.P. / Hayward, CA

Source

Dryer RTO

Test

6

Run

1, 2, 3

Date

2-20-96

Site

Stack

Operator

M. K. L. L. L.

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_m	C_{gas}
				Initial	Final			
1	21.3	Zero Gas	0	0	2	1		20.7
		Upscale	142	142	139		140.5	
2	17.3	Zero Gas	0	2	1	1.5		18.1
		Upscale	142	139	140		139.5	
3	19.3	Zero Gas	0	1	142 -1	0		20.2
		Upscale	142	142 140	144		142	
4		Zero Gas	0					
		Upscale						
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

CO Cal Drift Check

Job

L.P. / Hazardous W!

Source

Dryer RTO

Test

6Run 1, 2, 3Date 2-20-96

Site

Stack

Operator

M. Kessler

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1	193.3	Zero Gas	0	0	6	3	XXXX	179
		Upscale	289	290	298	XXXX	294	
2	232.8	Zero Gas	0	6	2	4	XXXX	225
		Upscale	289	298	302	XXXX	300	
3	205.7	Zero Gas	0	2	4	3	XXXX	203
		Upscale	289	296	290	XXXX	293	
4		Zero Gas	0				XXXX	
		Upscale				XXXX		
5		Zero Gas	0				XXXX	
		Upscale				XXXX		
6		Zero Gas	0				XXXX	
		Upscale				XXXX		
7		Zero Gas	0				XXXX	
		Upscale				XXXX		
8		Zero Gas	0				XXXX	
		Upscale				XXXX		
9		Zero Gas	0				XXXX	
		Upscale				XXXX		
10		Zero Gas	0				XXXX	
		Upscale				XXXX		
11		Zero Gas	0				XXXX	
		Upscale				XXXX		
12		Zero Gas	0				XXXX	
		Upscale				XXXX		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

CO₂ Cal Drift Check

Job

L.P. / Hagerstown, MD

Source

Dryer RTO

Test

G Run 1, 2, 3 Date 2-20-96

Site

Stack

Operator

M. Knekkles

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C ₀	C _m	C _{gas}
				Initial	Final			
1	4.1	Zero Gas	0	0.0	0.2	0.1	████	4.2
		Upscale	10.9	10.9	10.8	████	10.65	
2	3.4	Zero Gas	0	0.2	0.1	0.15	████	3.5
		Upscale	10.9	10.8	10.7	████	10.75	
3	4.2	Zero Gas	0	0.1	0.2	0.15	████	4.2
		Upscale	10.9	10.7	11.2	████	10.95	
4		Zero Gas	0				████	
		Upscale				████		
5		Zero Gas	0				████	
		Upscale				████		
6		Zero Gas	0				████	
		Upscale				████		
7		Zero Gas	0				████	
		Upscale				████		
8		Zero Gas	0				████	
		Upscale				████		
9		Zero Gas	0				████	
		Upscale				████		
10		Zero Gas	0				████	
		Upscale				████		
11		Zero Gas	0				████	
		Upscale				████		
12		Zero Gas	0				████	
		Upscale				████		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

02 Cal Drift Check

Job

L.P. / Hayward, WI

Source

Dyer RD / 4th

Test

6 Run 1, 2, 3 Date 2-20-96

Site

Stack

Operator

M. Kuebler

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_a	C_m	C_{gas}
				Initial	Final			
1	16.3	Zero Gas	0	0.0	-0.2	-0.1		16.2
		Upscale	13.0	13.0	13.2		13.1	
2	16.9	Zero Gas	0	0.0	0.0	0.0		16.9
		Upscale	13.0	13.1	12.9		13.0	
3	16.2	Zero Gas	0	0.0	0.0 ^{-0.1}	-0.05		16.3
		Upscale	13.0	12.9	13.0		12.95	
4		Zero Gas	0					
		Upscale						
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

System Bias Check

Job L.P. / Hazardous, WI
 Test 6 Run 0 Date 2-20-96
 Operator M. Kuchler

Source Dryer RTD / Stack
 Site Stack

Instrument	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		Diff. CE-SB (PPM)	Span Val. (PPM)	% of Span
			Cal. Err.	Sys. Bias			
O ₂	Zero Gas	0	0.0	.1	.1	25.0	.40
	Upscale	13.0	13.0	13.0	0	25.0	0
CO ₂	Zero Gas	0	0.0	.1	.1	20.0	.50
	Upscale	10.9	11.0	11.0	0	20.0	0
CO	Zero Gas	0	0	0	0	1000	0
	Upscale	289	289	286	3	1.000	.30
NO _x	Zero Gas	0	1	2	1	500	.20
	Upscale	142	142	135	7	500	1.40
THC	Zero Gas	0	0	0	0	100	0
	Upscale	30.4	30	29	1	100	.1
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

Calibration Error Check

Job LP HAYWARD
Test 7 Run _____ Date 2-20-96
Operator S. BAINVILLE

SO₂ Calibration:

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

NO_x Calibration:

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	.41	.41	1000	.0008
Mid Level	145	149.34	.66	1000	.0013
High Level	240	239.66	.34	1000	.0067

O₂ Calibration:

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	.08	.08	25	.003
Mid Level	13.1	13.0	.1	25	.004
High Level	21.0	20.96	.04	25	.002

CO₂ Calibration

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	.02	.02	20	.001
Mid Level	10.5	10.35	.15	20	.008
High Level	16.8	16.83	.03	20	.002

CO Calibration

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	.51	.51	1000	.0005
Mid Level	147.	143.30	3.7	1000	.0037
High Level	299.	300.5	1.5	1000	.0015

INTERPOL LABORATORIES, INC.
(6120 786-6020)

EPA Method 6C/7E Response Time

Job L.P. / Hayward, WI
Source RTO Dryer / Stack
Date of Test 2-20-96

Technician Mark Gachler
System Flow Rate 4000 cc/min

Moisture removal: Via Model MK-1 Condenser

	Response Time (secs)		
Analyzer Type	SO ₂ /NO _x	O ₂	CO ₂
Analyzer S/N			
Analyzer Range	500	25.0	20.0
High Level Span Gas Conc. (PPM or %)	142	13.0	10.9
Upscale 1	57	59	63
Upscale 2	55	52	65
Upscale 3	61	55	60
Average	57.67	55.33	62.67
Downscale 1	51	58	63
Downscale 2	60	50	68
Downscale 3	64	55	65
Average	58.33	54.33	65.33

System response time 58.94 seconds

1. Introduce gases at the 3-way valve on the probe. Use zero and stack gas for the upscale tests and high-level span gas and stack gas for the downscale tests. Alternatively, use zero and high-level gases for a more stringent test. Record the time in seconds from the moment of introduction until a stable response is achieved.
2. The response time test need only be conducted prior to the initial field use of the measurement system.
3. Attach a copy of the flow system schematic to this test.

Calibration Error Check

Job L.P. / Hayward, WI
Test 6 Run 0 Date 2-19-96
Operator M. Kaehler

SO₂ Calibration:

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

NO₂ Calibration:

Time (HRS) 2000

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	1.0	1	500	.20
Mid Level	142	142	0	500	0
High Level	239	242	3	500	.60

O₂ Calibration:

Time (HRS) 2000

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0.0	0	25.0	0
Mid Level	13.0	13.0	0	25.0	0
High Level	21.0	21.0	0	25.0	0

CO₂ Calibration

Time (HRS) 2000

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0.0	0	20.0	0
Mid Level	10.9	11.0	.1	20.0	.01
High Level	17.0	17.0	0	20.0	0

CO Calibration

Time (HRS) 2000

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0	0	1,000	0
Mid Level	289	289	0	1,000	0
High Level	620	612	8	1,000	.80

INTERPOL LABORATORIES, INC

(612) 786-6020

T/C Cal Drift Check

Job

L.P. / Hayward, W.

Source

Dryer RTO

Test

6 Run 1, 2, 3 Date 2-20-96

Site

Stack

Operator

M. Kuehler

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _s	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	0	0	0	██████	
		Upscale	30.4	30	32	██████	31	
2		Zero Gas	0	0	-1	-0.5	██████	
		Upscale	30.4	30	32	██████	31	
3		Zero Gas	0	0	-1	-0.5	██████	
		Upscale	30.4	30	31	██████	30.5	
4		Zero Gas	0				██████	
		Upscale				██████		
5		Zero Gas	0				██████	
		Upscale				██████		
6		Zero Gas	0				██████	
		Upscale				██████		
7		Zero Gas	0				██████	
		Upscale				██████		
8		Zero Gas	0				██████	
		Upscale				██████		
9		Zero Gas	0				██████	
		Upscale				██████		
10		Zero Gas	0				██████	
		Upscale				██████		
11		Zero Gas	0				██████	
		Upscale				██████		
12		Zero Gas	0				██████	
		Upscale				██████		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC
(612) 786-6020

NOK Cal Drift Check

Job LP/HAYWARD Source LINE No. 1 CORE DRYED
Test 7 Run 2-20-78 Site OUTLET
Operator _____

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{av}
				Initial	Final			
1	36.0	Zero Gas	0	2.14	2.54	2.34	XXXX	35.3
		Upscale	240	239.87	247.03	XXXX	243.45	
2	37.9	Zero Gas	0	2.54	1.22	1.88	XXXX	37.9
		Upscale	240	240.46	245.97	XXXX	243.23	
3	35.4	Zero Gas	0	1.22	0	.61	XXXX	35.7
		Upscale	240	241.70	241.70	XXXX	241.70	
4		Zero Gas	0				XXXX	
		Upscale				XXXX		
5		Zero Gas	0				XXXX	
		Upscale				XXXX		
6		Zero Gas	0				XXXX	
		Upscale				XXXX		
7		Zero Gas	0				XXXX	
		Upscale				XXXX		
8		Zero Gas	0				XXXX	
		Upscale				XXXX		
9		Zero Gas	0				XXXX	
		Upscale				XXXX		
10		Zero Gas	0				XXXX	
		Upscale				XXXX		
11		Zero Gas	0				XXXX	
		Upscale				XXXX		
12		Zero Gas	0				XXXX	
		Upscale				XXXX		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC
(612) 786-6020

CO Cal Drift Check

Job
Test
Operator

LP/HAYWARD

Run

Date 2-20-96

Source

2-2-2 NO1 CONC DRYER

Site

OUTLET

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_o	C_m	C_{gas}
				Initial	Final			
1	667.4	Zero Gas	0	1.02	1.22	1.12		668.7
		Upscale	299	299.07	297.85		298.46	
2	907.5	Zero Gas	0	1.22	0	.61		909.8
		Upscale	299	297.85	297.85		297.85	
3	774.6	Zero Gas	0	0	0	0		777.6
		Upscale	299	297.85	297.85		297.85	
4		Zero Gas	0					
		Upscale						
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

C02 Cal Drift Check

Job

LP / HAYWARD

Source

LENG MOI CONC DRUGS

Test

7

Run

Date 2-20-96

Site

OUTLET

Operator

S. BAINVILLE

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C ₀	C _m	C _{gas}
				Initial	Final			
1	4.5	Zero Gas	0	0	.02	.01	XXXX	4.5
		Upscale	10.5	10.50	10.45	XXXX	10.47	
2	4.6	Zero Gas	0	.02	0	.01	XXXX	4.6
		Upscale	10.5	10.45	10.45	XXXX	10.45	
3	4.7	Zero Gas	0	0	0	0	XXXX	4.7
		Upscale	10.5	10.45	10.45	XXXX	10.45	
4		Zero Gas	0				XXXX	
		Upscale				XXXX		
5		Zero Gas	0				XXXX	
		Upscale				XXXX		
6		Zero Gas	0				XXXX	
		Upscale				XXXX		
7		Zero Gas	0				XXXX	
		Upscale				XXXX		
8		Zero Gas	0				XXXX	
		Upscale				XXXX		
9		Zero Gas	0				XXXX	
		Upscale				XXXX		
10		Zero Gas	0				XXXX	
		Upscale				XXXX		
11		Zero Gas	0				XXXX	
		Upscale				XXXX		
12		Zero Gas	0				XXXX	
		Upscale				XXXX		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

02 Cal Drift Check

Job

20 HAYWARD

Source

LINE NO. 1 CINCINNATI

Test

7 RunDate 2-20-96

Site

OUTLET

Operator

S. BAI-VELLE

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1	16.4	Zero Gas	0	.02	.08	.05	XXXX	16.4
		Upscale	13.1	13.11	13.11	XXXX	13.11	
2	16.3	Zero Gas	0	.08	0	.04	XXXX	16.2
		Upscale	13.1	13.11	13.17	XXXX	13.14	
3	16.2	Zero Gas	0	0	0	0	XXXX	16.0
		Upscale	13.1	13.17	13.39	XXXX	13.28	
4		Zero Gas	0				XXXX	
		Upscale				XXXX		
5		Zero Gas	0				XXXX	
		Upscale				XXXX		
6		Zero Gas	0				XXXX	
		Upscale				XXXX		
7		Zero Gas	0				XXXX	
		Upscale				XXXX		
8		Zero Gas	0				XXXX	
		Upscale				XXXX		
9		Zero Gas	0				XXXX	
		Upscale				XXXX		
10		Zero Gas	0				XXXX	
		Upscale				XXXX		
11		Zero Gas	0				XXXX	
		Upscale				XXXX		
12		Zero Gas	0				XXXX	
		Upscale				XXXX		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

6121 786-6020

THL System Bias Check

Job

LP HAYWARD

Source

DRYCH E TUBE INLET

Test

Run

Date 2-20-96

Site

INLET

Operator

S BAINVILLE L. HANSON

Instrument	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		Diff. CE-SB (PPM)	Span Val. (PPM)	% of Span
			Cal. Err.	Sys. Bias			
	Zero Gas	0	1.18	8.54	7.36	1000	0.74
	Upscale	286	289	282	7.00	1000	0.70
	Zero Gas	0	2.44	.98	1.46	1000	0.14
	Upscale	286	281.98	280.27	1.71	1000	0.17
	Zero Gas	0	.98	0	.98	1000	0.1
	Upscale	286	280.27	281.98	1.71	1000	0.17
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

070595-GASTACK.WP.FORMS-362

INTERPOL LABORATORIES, INC

(612) 786-6020

THC Cal Drift Check

Job

LP/HAYWARD

Test

7 RunDate 2-20-98

Source

LINE No. 1 CORE

Operator

J.B.

Site

DRYER OUTLET

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	<u>6.5</u>	<u>8.54</u>	<u>7.52</u>	<u>XXXX</u>	
		Upscale	<u>286</u>	<u>286</u>	<u>281.98</u>	<u>XXXX</u>	<u>283.99</u>	
2		Zero Gas	0	<u>2.44</u>	<u>.98</u>	<u>1.71</u>	<u>XXXX</u>	
		Upscale	<u>286</u>	<u>281.98</u>	<u>280.27</u>	<u>XXXX</u>	<u>281.13</u>	
3		Zero Gas	0	<u>.98</u>	<u>0</u>	<u>.49</u>	<u>XXXX</u>	
		Upscale	<u>286</u>	<u>280.27</u>	<u>281.98</u>	<u>XXXX</u>	<u>281.13</u>	
4		Zero Gas	0				<u>XXXX</u>	
		Upscale				<u>XXXX</u>		
5		Zero Gas	0				<u>XXXX</u>	
		Upscale				<u>XXXX</u>		
6		Zero Gas	0				<u>XXXX</u>	
		Upscale				<u>XXXX</u>		
7		Zero Gas	0				<u>XXXX</u>	
		Upscale				<u>XXXX</u>		
8		Zero Gas	0				<u>XXXX</u>	
		Upscale				<u>XXXX</u>		
9		Zero Gas	0				<u>XXXX</u>	
		Upscale				<u>XXXX</u>		
10		Zero Gas	0				<u>XXXX</u>	
		Upscale				<u>XXXX</u>		
11		Zero Gas	0				<u>XXXX</u>	
		Upscale				<u>XXXX</u>		
12		Zero Gas	0				<u>XXXX</u>	
		Upscale				<u>XXXX</u>		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

EPA Method 25 A

Calibration Error Check & Drift Determination

Job

LP HAYWARD

Test

#7

Run

Date

2-20-96

Operator

S. BAINVILLE

THC Calibration (Low Range):

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	1.18	1.18	100	1.18
Low Level	30.5	31.29	.79	100	.79
Mid Level	286	289	3	1600	.3
High Level	2960	2991	31	10,000	.31

THC Calibration (High Range):

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	1.18	1.18	10,000	.01
Span	2960	2991	31	10,000	.31

O₂ Calibration:

Time (HRS)

***	Cylinder Value (%)	Analyzer Response (%)	Difference (%)	Span Value (%)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

CO₂ Calibration:

Time: (HRS)

***	Cylinder Value (%)	Analyzer Response (%)	Difference (%)	Span Value (%)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

Must be within 2% of the span for each calibration gas.

052394-G:\STACK\WP\FORMS\S-420-14

INTERPOLL LABORATORIES, INC

6121 786-6020

NOX System Bias Check

Job

L.P. HAYWARD

Source

LINSEI SURFACE DRYER

Test

Q

Run

Date 2-20-96

Site

DUCT

Operator

E. TRIMBLING

Instrument	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		Diff. CE-SB (PPM)	Span Val. (PPM)	% of Span
			Cal. Err.	Sys. Bias			
	Zero Gas	0		0		250	
	Upscale	72.1		72		250	
	Zero Gas	0		.5		250	
	Upscale	72.1		71.5		250	
	Zero Gas	0		1		250	
	Upscale	72.1		71.2		250	
	Zero Gas	0		1		250	
	Upscale	72.1		71.4		250	
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

070595-G:STACK.WP\FORMS\S-562

INTERPOL LABORATORIES, INC

6121 786-6020

CO System Bias Check

Job

LY/HAYWARD

Source

LINE 1 SURFACE DRYER

Test

8 RunDate 2-20-96

Site

DULT

Operator

DET

Instrument	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		Diff. CE-SB (PPM)	Span Val. (PPM)	% of Span
			Cal. Err.	Sys. Bias			
	Zero Gas	0		0		1000	
	Upscale	600		595		1000	
	Zero Gas	0		12		1000	
	Upscale	600		590		1000	
	Zero Gas	0		1		1000	
	Upscale	600		597		1000	
	Zero Gas	0		2		1000	
	Upscale	600		599		1000	
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

070595-Q:STACK:WP:FORMSIS-362

THC System Bias Check

Job

Test

Operator

LP/HAYWARD46

Run

Date 2-20-96

Source

Site

Line 1 Surface Drags
Alus

Instrument	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		Diff. CE-SB (PPM)	Span Val. (PPM)	% of Span
			Cal. Err.	Sys. Bias			
	Zero Gas	0	0	0		1000	
	Upscale	287	289	288		1000	
	Zero Gas	0	0	2		1000	
	Upscale	287	288	284			
	Zero Gas	0	2	0		1000	
	Upscale	287	284	286		1000	
	Zero Gas	0	0	0			
	Upscale	287	286	284			
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

EPA Method 25 A

Calibration Error Check & Drift Determination

Job

LP/HAYWARD

Test

Run

Date

2-19-96

Operator

E.T. ROWBIDGE

THC Calibration (Low Range):

Time (HRS)

1845

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0	0	100	0
Low Level	27.9	27.2	.7	120	.07
Mid Level	287	289	.02	10000	.12
High Level	3150	3138	2138	10,000	.01

THC Calibration (High Range):

Time (HRS)

12

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0				
Span					

O₂ Calibration:

Time (HRS)

***	Cylinder Value (%)	Analyzer Response (%)	Difference (%)	Span Value (%)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

CO₂ Calibration:

Time: (HRS)

***	Cylinder Value (%)	Analyzer Response (%)	Difference (%)	Span Value (%)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

Must be within 2% of the span for each calibration gas.

052394-GASTACKWPFORMSLS-420-14

INTERPOL LABORATORIES, INC

(612) 786-6020

N₂O_x System Bias Check

Job

RP/HAYWARD

Source

Line 1 Surface Driller

Test

6 RunDate 2-20-96 Site

Operator

ET

Instrument	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		Diff. CE-SB (PPM)	Span Val. (PPM)	% of Span
			Cal. Err.	Sys. Bias			
<u>N₂O_x</u>	Zero Gas	0	<u>.2</u>	<u>0</u>			
	Upscale	<u>72.1</u>	<u>72.1</u>	<u>71.6</u>			
<u>THC</u>	Zero Gas	0	<u>1</u>	<u>0</u>			
	Upscale	<u>287</u>	<u>289</u>	<u>284</u>			
<u>CO</u>	Zero Gas	0	<u>1</u>	<u>0</u>			
	Upscale	<u>147</u>	<u>146.6</u>	<u>145.4</u>			
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

070595-G:STACK\WP\FORMS\S-562

Calibration Error Check

Job

LP/HAYWARD

Test

2 Run

Date

2-19-96

Operator

E. TRUMBIDGESO₂ Calibration:

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

NO_x Calibration:

Time (HRS)

2000

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	12	12	250	
Mid Level	72.1	72.1	0	250	0
High Level	250	239	1	250	

O₂ Calibration:

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

CO₂ Calibration

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

CO Calibration

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	1	1	1000	
Mid Level	147	146.6		1000	
High Level	299	290.2		1000	

600599G-24 1

Drawing of Test Site

Cross-section View	Elevation View
-----------------------	-------------------

R or nothing = reg. manometer; S = expanded; E = electronic

INTERPOLL LABORATORIES, INC

(612) 786-6020

NOx Cal Drift Check

Job

L.P. / Hazardous, CO

Source

Press RTO

Test

10

Run

1, 2, 3

Date

2-21-96

Site

Stueh

Operator

M. Kachler

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
10		Zero Gas	0	0				
		Upscale	142	142				
21	25.7	Zero Gas	0	2	3	2.5		
		Upscale	142	144	150		147	24.4
22	25.0	Zero Gas	0	3	2	2.5		
		Upscale	142	150	150		150	24.1
23	25.2	Zero Gas	0	2	2	2		
		Upscale	142	150	153		151.5	23.6
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC
(612) 786-6020

CO Cal Drift Check

Job L.P. / Hayward, WI Source Press RIO
Test 10 Run 1, 2, 3 Date 2-21-98 Site Stack
Operator N. Kuchler

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1	17.4	Zero Gas	0	3			██████	
		Upscale	289	291		██████		
2	17.4	Zero Gas	0	1	4	2.5	██████	15.5
		Upscale	289	294	301	██████	297.5	
3	27.5	Zero Gas	0	4	9	6.5	██████	24.4
		Upscale	289	298	300	██████	299	
4	29.6	Zero Gas	0	9	3	6	██████	31.1
		Upscale	289	300	299	██████	299.5	
5		Zero Gas	0				██████	
		Upscale				██████		
6		Zero Gas	0				██████	
		Upscale				██████		
7		Zero Gas	0				██████	
		Upscale				██████		
8		Zero Gas	0				██████	
		Upscale				██████		
9		Zero Gas	0				██████	
		Upscale				██████		
10		Zero Gas	0				██████	
		Upscale				██████		
11		Zero Gas	0				██████	
		Upscale				██████		
12		Zero Gas	0				██████	
		Upscale				██████		

Must be within 5% or the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

CO₂ Cal Drift Check

Job

L.P. / Hayward, WI

Source

Press. RTO

Test

10 Run 1, 2, 3 Date 2-21-96

Site

Stack

Operator

M. Kuehler

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	0.0				
		Upscale	10.9	10.9				
2	0.6	Zero Gas	0	0.0	-0.1	-0.05		0.7
		Upscale	10.9	10.9	10.7		10.8	
3	0.6	Zero Gas	0	0.0	10.7 0.0	0.0		0.6
		Upscale	10.9	10.9	10.8		10.85	
4	0.6	Zero Gas	0	0.0	-0.1	-0.05		0.7
		Upscale	10.9	10.8	10.9		10.8	
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

02 Cal Drift Check

Job

L.P. / Hayward, WI

Source

Press. AFD

Test

10 Run 1, 2, 3 Date 2-21-96

Site

Stack

Operator

M. Kachler

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_m	C_{25}
				Initial	Final			
1		Zero Gas	0	0.0				
		Upscale	13.0	13.0				
2	20.2	Zero Gas	0	0.0	0.2	0.1		
		Upscale	13.0	13.0	12.9		12.95	20.3
3	20.0	Zero Gas	0	0.0	-0.1	-0.05		
		Upscale	13.0	12.9	13.0		12.95	20.1
4	20.0	Zero Gas	0	0.0	0.0	0.0		
		Upscale	13.0	13.0	13.1		13.05	19.9
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

THC Cal Drift Check

Job

L.P. / Hazard, WI

Source

Press. LTD

Test

10 Run 1, 2, 3 Date 2-21-96

Site

Stech

Operator

M. Kachler

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_m	C_{gas}
				Initial	Final			
1		Zero Gas	0	0				
		Upscale	30.4	30				
2		Zero Gas	0	0	0	0		
		Upscale	30.4	30	32		31	
3		Zero Gas	0	0	0	0		
		Upscale	30.4	30	30		30	
4		Zero Gas	0	0	0	0		
		Upscale	30.4	30	30		30	
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

Drawing of Test Site

Job LP/HAY/WOOD
Source LINE 1 PRESS RTD INLET
Test 13 Run 221-96 Date 2-21-96
Stack Dimen. 53.125 IN.
Dry Bulb °F Wet bulb °F
Manometer ☐ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 29.24 IN.HG
Static Pressure IN.WC
Operators
Pitot No. C

Cross-section View	Elevation View
--------------------	----------------

[illegible]

R or nothing = reg. manometer; S = expanded; E = electronic

INTERPOL LABORATORIES, INC

(612) 786-6020

Nox Cal Drift Check

Job

Test

Operator

1 P HANNUAL13

Run

Date

2-21-96

Source

Line 1 Press

Site

RTD INLET

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_o	C_m	C_{gas}
				Initial	Final			
1		Zero Gas	0	0	0			
		Upscale	72.1	72.1	72.33			
2	12.6	Zero Gas	0	0	2.69			
		Upscale	72.1	72.33	72.14			11.4
3	4.8	Zero Gas	0	.37	0			
		Upscale	72.1	72.14	74			4.9
4	3.3	Zero Gas	0	0	0			
		Upscale	72.1	72.75	71			3.3
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC
(612) 786-6020

C0 Cal Drift Check

Job

Test

Operator

L P HAYWARD

13 Run

Date 2-21-86

Source

Site

LINE 1 PRESS RTD

INLET

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	0	0			
		Upscale	299	299	298			
2	10.1	Zero Gas	0	0	0			
		Upscale	299	298	296.63			10.2
3	7.5	Zero Gas	0	0	0			
		Upscale	299	296.63	292			7.6
4	3.1	Zero Gas	0	0	0			
		Upscale	299	292	298			3.0
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

CO2 Cal Drift Check

Job

201 Hayward

Test

13 RunDate 2-21-96

Source

Line 1 Pkss

Operator

ETC

Site

RTD Inlet

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	0	0			
		Upscale	10.5	10.5	10.45			
2	0.1	Zero Gas	0	0	.02			
		Upscale	10.5	10.5	10.45			0.1
3	0.1	Zero Gas	0	.0	0			
		Upscale	10.5	10.45	10.4			0.1
4	0.1	Zero Gas	0	0	0			
		Upscale	10.5	10.4	10.3			0.1
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

02 Cal Drift Check

Job

LP/HAWARD

Source

Line 1 Press

Test

13 Run

Date 2-21-96

Site

RTO Unit

Operator

P. HAWARD

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_m	C_{gas}
				Initial	Final			
1		Zero Gas	0	0	0			
		Upscale	13.1	13.1	13.12			
2	21.0	Zero Gas	0	0	103			
		Upscale	13.1	13.12	13.00			21.1
3	21.3	Zero Gas	0	.03	0			
		Upscale	13.1	13.18	13.1			21.2
4	21.2	Zero Gas	0	0	0			
		Upscale	13.1	13.1	13.02			21.3
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

TAC Cal Drift Check

Job

Test

Operator

AP HAYWARD

13 Run

Date 2-21-96

Source

Site

Line 1 Press

PTD INLET

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_m	C_{gas}
				Initial	Final			
1		Zero Gas	0	0	0			
		Upscale	30.0	30	30			
2		Zero Gas	0	0	0			
		Upscale	30.0	30	30			
3		Zero Gas	0	0	0			
		Upscale	30.0	30	31			
4		Zero Gas	0	0	0			
		Upscale	30.0	30	29			
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

NOX Cal Drift Check

Job

Test

Operator

LP/HAYWARDSRun 1-3 Date 2-22-96

Source

Site

LINE 1 KANULSSTACK

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1	90.3	Zero Gas	0	0	2.44			89.9
		Upscale	145	145	144.65			
2	97.7	Zero Gas	0	.31	1			97.5
		Upscale	145	144.65	145.57			
3	89.7	Zero Gas	0	1	1.22			89.3
		Upscale	145	145.57	145.57			
4		Zero Gas	0					
		Upscale						
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

LO Cal Drift Check

Job

LP/HARDWARD

Test

18

Run

1-3

Date

2-22-96

Source

CINE 1 KONUS

Site

STACK

Operator

ST

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1	177.0	Zero Gas	0	0	1.22			177.0
		Upscale	299	298	299.07			
2	247.6	Zero Gas	0	0	2			247.8
		Upscale	299	299.07	298			
3	114.0	Zero Gas	0	2	2			114.2
		Upscale	299	298	299.07			
4		Zero Gas	0					
		Upscale						
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

CO₂ Cal Drift Check

Job

Test

Operator

LP/HAYWARD18 RunDate 2-22-96

Source

Site

Line 1 KromeStack

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1	6.5	Zero Gas	0	0	0			6.5
		Upscale	10.5	10.5	10.45			
2	8.4	Zero Gas	0	0	0			8.5
		Upscale	10.5	10.45	10.4			
3	7.7	Zero Gas	0	0	0			7.8
		Upscale	10.5	10.4	10.4			
4		Zero Gas	0					
		Upscale						
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

02 Cal Drift Check

Job

CP/HAYWARD

Test

18 Run 1-3 Date 2-27-91

Source

LINCOLN KODAKS

Operator

Site

STARK

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1	14.2	Zero Gas	0	0	1			14.2
		Upscale	13.1	13.1	13.2			
2	11.8	Zero Gas	0	1	1			11.8
		Upscale	13.1	13.1	13.1			
3	13.0	Zero Gas	0	1	1			13.0
		Upscale	13.1	13.1	13.1			
4		Zero Gas	0					
		Upscale						
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% or the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

ALL System Bias Check

Job

LP/HAYWARD

Source

LINE 1 ROMUS

Test

18 RunDate 8-23-96 SiteSTALK

Operator

ET

Instrument	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		Diff. CE-SB (PPM)	Span Val. (PPM)	% of Span
			Cal. Err.	Sys. Bias			
<u>NOx</u>	Zero Gas	0	0	0	0	250	0
	Upscale	145	145	145	0	250	0
<u>CO</u>	Zero Gas	0	0	0	0	1000	0
	Upscale	298	298	298	1	1000	.1
<u>O2</u>	Zero Gas	0	0	0	0	25	0
	Upscale	13.1	13.1	13.1	0	25	0
<u>CO2</u>	Zero Gas	0	0	0	0	20	0
	Upscale	10.5	10.5	10.5	0	20	0
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

070595-G:STACK\WPA\FORMS\S-562

APPENDIX H

GAS ANALYZER SPECIFICATIONS

Servomex

INTERPOL LABORATORIES
4500 BALL ROAD N.E.
CIRCLE PINES, MN 55014-1819
(612) 786-6020

1420 Oxygen Analyser Instruction Manual

Ref : 01420/001A/0

Order as part No. 01420001A

was (7982-2842)

INTERPOL LABORATORIES
4500 BALL ROAD N.E.
CIRCLE PINES, MN 55014-1819
(612) 786-6020

1.3 Sampling System

The sampling system of the analyser includes a combination filter/automatic flow control device, designed to keep a constant flow of sample gas through the measuring cell for varying input pressures and to prevent the entrance of particulate matter into the measuring cell. Excess flow is vented to the by-pass.

1.4 Specification

Performance Specification (typical)

Repeatability: Better than $\pm 0.2\%$ O₂ under constant conditions.

Drift: Less than 0.2% O₂ per week under constant conditions. (Excluding variation due to barometric pressure changes; reading is proportional to barometric pressure.)

Outputs

Display: 3 1/2 digit LCD reading 0.0 to 100.0% oxygen with overrange capability.

Output: 0 to 1V (non-isolated) for 0 to 100% oxygen available on 'D' type connector located on the back panel of the instrument. Output impedance is less than 10 ohms.

Option: 4 - 20mA isolated, Max impedance 500 ohms.

Flow alarm output: Change over relay contact rated at 3A/115V ac, 1A/240V ac or 1A/28V dc. 4 sets of single pole changeover contacts. Alarm becomes active when sample gas flow through the analyser fails.

Sample requirements

Condition: Clean, dry gas with dew point 5 deg C below ambient temperature.

Inlet pressure: 0.5 to 3psig (3.5 to 21kPa). Inlet pressure changes within this range will change the reading by less than 0.1% O₂. May be operated up to 10psig (70kPa) with degraded stability.

Flowrate: 1.5 to 6 litres/minute approximately depending on sample pressure.

Filtering: 0.6 micron replaceable filter integral to the automatic flow control device.

Response time: Less than 15 secs. to 90% at an inlet pressure of 3psig (21kPa).

Inlet/vent connections: 1/4 inch OD tube (stainless steel) suitable for 6mm ID flexible tubing or 1/4 inch OD compression fittings.

Materials exposed to the sample: Stainless steel, Pyrex glass, brass, platinum, epoxy resin, Viton, polypropylene and glass fibre filter.

Physical Characteristics

Case: Steel and aluminium finished in epoxy powder paint.

Case classification: IP 20 (IEC 529) when fitted into the Servomex 1400 series 19 inch case.

Dimensions: See Figure 2.1.

Weight: 10Kg (22lb) approximately.

Electrical

AC Supply: 110 to 120V AC or 220 to 240V AC, +/-10%, 48 to 62Hz. Voltage selected by a voltage selector integral to the IEC supply plug.

Power required: 15VA maximum.

Environmental Limits

Operating ambient temperature: 0 to +40 deg C (32 to 104 deg F)

Storage temp. range: -20 to +70 deg C (-4 to 158 deg F)

Relative humidity: 0-85%, non-condensing.

SPECIFICATIONS FOR ACS MODEL 3300 CO₂ NDIR

Measuring principle	NDIR single beam method
Measurable gas components and measuring range	0 - 20%
Reproducibility	±0.5% of full scale
Stability	Zero drift; ±% of full scale/24H Span drift; ±% of full scale/24H
Noise	0.5% of full scale
Ambient temperature	-5 to 45°C
Ambient humidity	Less than 90% RH
Response time (90% of final reading)	Electrical system; 2 sec, 3 sec, 5 sec (selectable with connector) Response of actual gas; Within 15 sec (depending on cell length)
Indicator	100 linear division
Output signal	OUTPUT 1; DC 0 - 1 V OUTPUT 2; DC 0 - 10 mV or DC 0 - 100 mV or DC 0 - 1 V or DC 4 - 20 mA (Allowable load resistance 500Ω max.)
Linearity	Better than ±2% of full scale (when linearizer is used)
Power supply	AC 115 V ± 10%, 60 Hz

Power consumption	Approx. 30 VA
Materials of gas- contacting parts	Measuring cell; SUS304 Window; CaF ₂ Piping; Polyethylene
Sample gas flow rate	1ℓ/min ± 0.5ℓ/min
Sample gas temperature	0 to 55°C
Purging gas flow rate	1ℓ/min (to be flowed as occasion demands)
Warmup time	Approx. 2 hours
External dimensions	200 x 250 x 541 (H x W x D) mm
Weight	Approx. 11 kg
Finish Color	MUNSELL N1.5
Remarks:	For combinations of measuring ranges for the dualcomponent analyzer, inquiry should be made to the manufacturer.

SPECIFICATIONS FOR MODEL 10A
ROCK MOUNTED CHEMILUMINESCENT
NO-NO_x GAS ANALYZER

Sensitivity	Each instrument is equipped with the following ranges: 0 - 2.5 ppm 0 - 10 ppm 0 - 25 ppm 0 - 100 ppm 0 - 250 ppm 0 - 1000 ppm 0 - 2500 ppm 0 - 10000 ppm
Accuracy	Derived from the NO or NO ₂ calibration gas, $\pm 1\%$ of fullscale
Response time (0-90%) Typical	1.5 seconds - NO Mode 1.7 seconds - NO _x Mode
Output	0 - 10mV and 0 - 10V
Zero Drift	Negligible after 1/2-hour warm-up
Linearity	$\pm 1\%$ of full scale
Input Power Requirements	115v/50Hz; 115v/60Hz

SPECIFICATIONS FOR ACS MODEL 3300 CO NDIR

Measuring principle	NDIR single beam method
Operating ranges	0 - 500 ppm 0 - 1000 ppm
Reproducibility	±0.5% of full scale
Stability	Zero drift; ±% of full scale/24H Span drift; ±% of full scale/24H
Noise	0.5% of full scale
Ambient temperature	-5 to 45°C
Ambient humidity	Less than 90% RH
Response time (90% of final reading)	Electrical system; 2 sec, 3 sec, 5 sec (selectable with connector) Response of actual gas; Within 15 sec (depending on cell length)
Indicator	100 linear division
Output signal	OUTPUT 1; DC 0 - 1 V OUTPUT 2; DC 0 - 10 mV or DC 0 - 100 mV or DC 0 - 1 V or DC 4 - 20 mA (Allowable load resistance 500Ω max.)
Linearity	Better than ±2% of full scale (when linearizer is used)
Power supply	AC 115 V ± 10%, 60 Hz

Power consumption	Approx. 30 VA
Materials of gas- contacting parts	Measuring cell; SUS304 Window; CaF ₂ Piping; Polyethylene
Sample gas flow rate	1ℓ/min ± 0.5ℓ/min
Sample gas temperature	0 to 55°C
Purging gas flow rate	1ℓ/min (to be flowed as occasion demands)
Warmup time	Approx. 2 hours
External dimensions	200 x 250 x 541 (H x W x D) mm
Weight	Approx. 11 kg
Finish Color	MUNSELL N1.5

Remarks: For combinations of measuring ranges for the dualcomponent analyzer, inquiry should be made to the manufacturer.



TOTAL HYDROCARBON ANALYZER (FLAME IONIZATION)
Model RS 55

TECHNICAL DATA

MAINS : 115V/60H

RECORDER OUTPUT : 0 - 5 V / 4-20mA

MODEL: X Manual switching
 — Solenoid valves

HOUSING: — Case, — 19"- Rack

MEASURING RANGES:	1 = 0 — 10	C ₁ -
	2 = 0 — 100	C ₁
	3 = 0 — 1,000	C ₁
	4 = 0 — 10,000	C ₁

SPECIAL OPTIONS :

Flame out alarm
1 Alarm
Sample line
.....

ANALYZER CONDITIONS :

Temperature : ..160.°C

Zero Point : ..3,90....

Gain :7,70....

Pressure Setting: Sample/Spangas/Zerogas: 200 mbar


Fuel: Hydrogen :... ..0,35 bar


Combustion Air :... ..0,80 bar

Span Gases : ..300. ppm C₁

24.000. ppm C₁

CALIBRATION DIAGRAM





1. Inlet regulator
2. Pressure regulator
3. Flowmeter
4. Solenoid valve
5. 3 Way valve
6. Turbine
7. Solenoid valve
8. Turbine
9. Back pressure regulator

Zündventil
Ignition valve
F-A angeordnet
E-A abmontiert

Rallisch
Inventar
Inventar

FLAMMEN IONISATIONS DETECTOR
Flame Ionization Detector


KS 33

13.01.11

Handumstellung
Manual switching

Interpoll Laboratories
(612) 786-6020

CEM TRAILER



E = EXHAUST
FC = FLOW CONTROL
I = IMPINGER (METHOD 10s)

CEMTRAIL

APPENDIX I
CALIBRATION GAS CERTIFICATION SHEETS

CERTIFICATE OF ANALYSIS-EPA PROTOCOL MIXTURES

REFERENCE #: 88-45046
 EXPIRATION DATE: 1/5/98
 METHOD: ANALYZED ACCORDING TO EPA TRACEABILITY PROTOCOL FOR ASSAY AND CERTIFICATION OF GASEOUS CALIBRATION STANDARDS-SEPTEMBER 1993-G-1.
 THIS STANDARD SHOULD NOT BE USED WHEN ITS GAS PRESSURE IS BELOW 1.0 MEGAPASCALS (150PSIG).

CYLINDER #: CC104374
 LAST ANALYSIS DATE: 1/5/96
 CYL. PRESSURE: 2000PSIG
 CUSTOMER: TWIN CITY OXYGEN
 P.O.#: 309089

COMPONENT: NO
 STANDARD: 1684B
 SRM #: CLM8177
 CYL. #: 96.5PPM
 CONG.: INSTRUMENT: BECK CHEM
 MODEL #: 951A
 SERIAL #: 0101572
 LAST CAL.: 1/2/96

MEAN CONC: 72.1PPM +/- 0.72 PPM
 REPLICATE CONC. DATE: 1/5/96
 MEAN CONC: NO2 1.04PPM
 REPLICATE CONC. DATE:

BALANCE GAS: N2

REPLICATE DATA
 DATE: 12/29/95
 Z 0 R 310 C 251.9
 R 311 Z 0 C 253.3
 Z 0 C 251.2 R 310
 DATE: 1/5/96
 Z 0 R 311.5 C 253.4
 R 312 Z 0 C 253.5
 Z 0 C 252.3 R 311

REPLICATE DATA
 DATE: 1/5/96
 Z 0 R 311.5 C 253.4
 R 312 Z 0 C 253.5
 Z 0 C 252.3 R 311

Z=ZERO C=CANDIDATE R=REFERENCE

ANALYST: *Jane Howe*

APPROVED BY: *Laura J. Hartman*

"THIS REPORT STATED ACCURATELY THE RESULTS OF THE INVESTIGATION MADE UPON THE MATERIAL SUBMITTED TO THE ANALYTICAL LABORATORY. EVERY EFFORT HAS BEEN MADE TO DETERMINE OBJECTIVELY THE INFORMATION REQUESTED; HOWEVER, IN CONNECTION WITH ITS RENDERING OF THIS REPORT, NATIONAL SPECIALTY GASES SHALL HAVE NO LIABILITY IN EXCESS OF ITS ESTABLISHED CHARGE FOR THE SERVICE."

Air Products and Chemicals, Inc.
SPECIALTY G. DEPARTMENT
12722 S. WENTWORTH AVENUE
CHICAGO, IL 60628

Certificate of Analysis - EPA Protocol Gas Standard

Page 1 of 1

PERFORMED ACCORDING TO EPA TRACEABILITY PROTOCOL FOR ASSAY AND CERTIFICATION OF GASEOUS CALIBRATION STANDARDS (PROCEDURE #G1)

Customer:

AIR PRODUCTS & CHEMICALS, INC.
373 CANTERBURY ROAD
SHAKOPEE MN 55379

Notes:

Order No:

CSS-320132-01

Batch No:

861-29294

Cylinder No:

SG9168051BAL

Cylinder Pressure:

2000 psig

Certification Date:

12/11/95

Expiration Date:

12/11/97

PO: Rel:

*** Certified Concentration ***
Certified

***** Reference Standards *****
Standard

Instrument

Serial

Last Measurement

Component

Concentration

Cylinder #

Number

Make/Model

Calibration

Principal

NITRIC OXIDE

240 $\pm$ 1.0

PPM

SG9151438BAL

GMIS

244.8000

PPM

Rosemount

951a

0101877

11/20/95

CHEMILUMINESCENCE

Balance Gas: NITROGEN

Contaminant

Nitrogen Dioxide

3.80

PPM

* Standard should not be used below 150 psig

Analyst:

Joe Estafanous

Approved By:

Richard Fry

AMAQUA, PA 18252

Page 1 of 1

Customer:

PA 15030

Cylinder No:

SG9120705BAL

Cylinder pressure*: 2000 psig

Certification Date: 11/13/94

Expiration Date: 11/13/96

PO: 055-94 Rel:

PO: 055-94 Rel:

*** Certified Concentration ***

Certified

concentration

299 ± 1.47 PPM SG9113535BAL

GMIS

Standard

Number

GMIS

***** Reference standards *****

Standard

Concentration

506,500 PP

北京大學出版社

Instrument

Make/Model

506,5000 PPM Hewlett Pa

***** Analytical

Serial

Number

506.5000 PPM Hewlett Packar 2518A05

Electric Instrument

Last

libration

2518A052 10/14/94

Optical instrumentation

Measuremen

Principal

2518A052 10/14/94 GC-FID

balance Gas: Nitrogen

* standard should not be used below 150 psig

I-3

Michael Wagner

Micha Wagner

Approved By:

Yen Roubik

NATIONAL SPECIALTY GASES
630 UNITED DRIVE
DURHAM, NC
27713

(919)544-3772
CERTIFICATE OF ANALYSIS - EPA PROTOCOL MIXTURES

REFERENCE #:	88-44358	CYLINDER #:	CC117373	CYL. PRESSURE:	2000 PSIG	P. O./CODE #	20388
EXP. DATE:	11/30/98	LAST ANALYSIS DATE:	11/30/95	CUSTOMER:	TWIN CITY OXYGEN		
METHOD:	ANALYZED ACCORDING TO EPA TRACEABILITY PROTOCOL FOR ASSAY AND CERTIFICATION OF GASEOUS CALIBRATION STANDARDS-SEPTEMBER 1993-G-1 THIS STANDARD SHOULD NOT BE USED WHEN ITS GAS PRESSURE IS BELOW 1.0 MEGAPASCALS (150 PSIG).						

COMPONENT:	CARBON MONOXIDE
STANDARD	
SRM #:	168JB
CYL. #:	CC117373
CONC:	975 PPM
INSTRUMENT:	ROSEMOUNT NDIR
MODEL #:	880A
SERIAL #:	2000172
LAST CAL:	11/8/95

MEAN CONC:	600 PPM	+/-	4.80 PPM
REPLICATE CONC.			
DATE:	11/23/95	DATE:	11/30/95
600 PPM	599 PPM	600 PPM	600 PPM
600 PPM	599 PPM	600 PPM	600 PPM
600 PPM	600 PPM	600 PPM	600 PPM

BALANCE GAS: NITROGEN		REPLICATE DATA	
REPLICATE DATA		REPLICATE DATA	
DATE:	11/23/95	DATE:	11/30/95
Z 0	R 975	C 600.0	
R 975	Z 0	C 600.0	
Z 0	C 600.6	R 976	
DATE:	11/30/95		
Z 0	R 974	C 598.4	
R 974	Z 0	C 598.4	
Z 0	C 600.0	R 975	

ANALYST: July A. Savory Z= ZERO C=CANDIDATE R=REFERENCE APPROVED BY: Jim Moore
 THIS REPORT STATED ACCURATELY THE RESULTS OF THE INVESTIGATION MADE UPON THE MATERIAL SUBMITTED TO THE ANALYTICAL LABORATORY. EVERY EFFORT HAS BEEN MADE TO DETERMINE OBJECTIVELY THE INFORMATION REQUESTED. HOWEVER, IN CONNECTION WITH THIS REPORT, NATIONAL SPECIALTY GASES SHALL HAVE NO LIABILITY IN EXCESS OF ITS ESTABLISHED CHARGE FOR THIS SERVICE.
 ASSAYED AT: NATIONAL SPECIALTY GASES, 630 UNITED DRIVE, DURHAM, NC 27713 (919)544-3772

NATIONAL SPECIALTY GASES
630 UNITED DRIVE
DURHAM, NC 27713
(919) 544-3772

CERTIFICATE OF ANALYSIS-EPA PROTOCOL MIXTURES

REFERENCE #: 88-28604 CYLINDER #:CC92831 CYL. PRESSURE:2000PSIG
EXPIRATION DATE:12/29/96 LAST ANALYSIS DATE:12/29/93
CUSTOMER:TWIN CITY OXYGEN P.O.# 7980
METHOD: ANALYZED ACCORDING TO
EPA TRACEABILITY PROTOCOL FOR
ASSAY AND CERTIFICATION OF
GASEOUS CALIBRATION STANDARDS-
SEPTEMBER 1993:G-1

STANDARD:
SRM #:1667B

CYL #:CLM5046

CONC.:47.3PPM

INSTRUMENT:
BECKMAN
COMPONENT: THC

MODEL #: 400

SERIAL #: 1003052

LAST CAL.: 12/1/93

COMPONENT: C3H8
MEAN CONC: 27.9PPM

REPLICATE CONC.
DATE: 12/29/93 DATE:
27.8PPM
27.9PPM
28.0PPM

COMPONENT:
MEAN CONC:

REPLICATE CONC.
DATE: DATE:

COMPONENT:
MEAN CONC:

REPLICATE CONC.
DATE: DATE:

BALANCE GAS:AIR

Air Products and Chemicals, Inc.
SPECIALTY GAS DEPARTMENT
12722 S. WENTWORTH AVENUE
CHICAGO, IL 60628

Certificate of Analysis - EPA Protocol Gas Standard

Page 1 of 1

PERFORMED ACCORDING TO EPA TRACEABILITY PROTOCOL FOR ASSAY AND CERTIFICATION OF GASEOUS CALIBRATION STANDARDS (PROCEDURE #G1)
CSS-320133-01

Customer:

AIR PRODUCTS & CHEMICALS, INC.
373 CANTERBURY ROAD
SHAKOPEE MN 55379

Notes:

Order No: 861-29310
Batch No:

Cylinder No: SG9165627BAL
Cylinder Pressure*: 2000 psig
Certification Date: 12/04/95
Expiration Date: 12/04/98

PO: Rel:

*** Certified Concentration ***
Certified
Concentration 287 ±3.2 PPM SG9128611BAL
Component PROPANE

***** Reference Standards *****
Standard
Number
Concentration 351.5000 PPM Gow-Mac 750
GMIS

***** Analytical Instrumentation *****

Instrument
Make/Model
Concentration 351.5000 PPM Gow-Mac 750
GMIS

Serial Last Measurement
Number Calibration Principal
59405U 11/14/95 GC-FID

Balance Gas: AIR
Oxygen Concentration 20.2 %

* Standard should not be used below 150 psig

1.6

Analyst:

Richard Van Dyke
Richard VanDyke

Approved By:

Richard Fry

NATIONAL SPECIALTY GASES
630 UNITED DRIVE
DURHAM, NC 27713
(919)544-3772

CERTIFICATE OF ANALYSIS-EPA PROTOCOL MIXTURES

REFERENCE #: 88-33698 CYLINDER #:CC97981 CYL. PRESSURE:2000PSIG
EXPIRATION DATE: 9/9/97 LAST ANALYSIS DATE:9/9/94
CUSTOMER: TWIN CITY OXYGEN P.O.# 12399

METHOD: ANALYZED ACCORDING TO EPA TRACEABILITY PROTOCOL FOR ASSAY AND CERTIFICATION
OF GASEOUS CALIBRATION STANDARDS-SEPTEMBER 1993:G-1

STANDARD: INSTRUMENT:VARIAN
SRM #: 2649 MODEL #:3400
CYL #: CAL2624 SERIAL #:3400-10056
CONC.: 9814PPM LAST CAL:8/1/94

COMPONENT:C3H8
MEAN CONC:3150PPM
REPLICATE CONC.
DATE:9/9/94 DATE:
3150PPM
3151PPM
3150PPM

COMPONENT:
MEAN CONC:
REPLICATE CONC.
DATE: DATE:

COMPONENT:
MEAN CONC:
REPLICATE CONC.
DATE: DATE:

BALANCE GAS:AIR

REPLICATE DATA

DATE: 9/9/94

Z	0	R	500.1	C	160.5
R	500.2	Z	0	C	160.6
Z	0	C	160.6	R	500.3

REPLICATE DATA

DATE:

Z		R		C
R		Z		C
Z		C		R

REPLICATE DATA

DATE:

Z		R		C
R		Z		C
Z		C		R

COMPONENT:C3H8

DATE:

Z		R		C
R		Z		C
Z		C		R

COMPONENT:

DATE:

Z		R		C
R		Z		C
Z		C		R

COMPONENT:

DATE:

Z		R		C
R		Z		C
Z		C		R

Z=ZERO C=CANDIDATE R=REFERENCE

ANALYST:

APPROVED BY:

"THIS REPORT STATED ACCURATELY THE RESULTS OF THE INVESTIGATION MADE UPON THE MATERIAL SUBMITTED TO THE ANALYTICAL LABORATORY. EVERY EFFORT HAS BEEN MADE TO DETERMINE OBJECTIVELY, THE INFORMATION REQUESTED; HOWEVER, IN CONNECTION WITH ITS RENDERING OF THIS REPORT, NATIONAL SPECIALTY GASES SHALL HAVE NO LIABILITY IN EXCESS OF ITS ESTABLISHED CHARGE FOR THE SERVICE."

NATIONAL SPECIALTY GASES
630 UNITED DRIVE
DURHAM, NC
27713

CERTIFICATE OF ANALYSIS

CERTIFIED MIXTURE

CUSTOMER: TWIN CITY OXYGEN

REFERENCE #: 88-43732

CYLINDER #: CC47482

DATE REPORTED: 11/1/95

MATERIAL SUBMITTED: OXYGEN AND CARBON DIOXIDE IN NITROGEN

INFORMATION REQUESTED: RATIO ANALYSIS

COMPONENT	SPECIFICATION	CONCENTRATION	METHOD
OXYGEN	13.5%	13.1%	OXYGEN ANALYZER
CARBON DIOXIDE	11%	10.5%	INFRARED ANALYZER
NITROGEN	BALANCE		


AUTHORIZED SIGNATURE

"THIS REPORT STATED ACCURATELY THE RESULTS OF THE INVESTIGATION MADE UPON THE MATERIAL SUBMITTED TO THE ANALYTICAL LABORATORY. EVERY EFFORT HAS BEEN MADE TO DETERMINE OBJECTIVELY THE INFORMATION REQUESTED; HOWEVER, IN CONNECTION WITH ITS RENDERING OF THIS REPORT, NATIONAL SPECIALTY GASES SHALL HAVE NO LIABILITY IN EXCESS OF THE ESTABLISHED CHARGE FOR THE SERVICE."

ir Products and Chemicals, Inc.

.O. BOX 351

.D. #1

AMAQUA, PA 18252

Certificate of Analysis - EPA Protocol Gas Standard

Page 1 of 1

PERFORMED ACCORDING TO EPA TRACEABILITY PROTOCOL FOR ASSAY AND CERTIFICATION OF GASEOUS CALIBRATION STANDARDS (PROCEDURE #G1)

Customer: Order No: 148-012359-03
AIR PRODUCTS & CHEMICALS Batch No: 255-58321
CAROL PORTER

Notes:

FREEMPORT RD, ROUTE 28
CREIGHTON PA 15030

Cylinder No: SG9120705BAL
Cylinder Pressure*: 2000 psig
Certification Date: 11/13/94
Expiration Date: 11/13/96

PO: 055-94 Rel:

** Certified Concentration *** ***** Reference Standards ***** Analytical Instrumentation *****
Certified Standard Instrument Serial Last Measurement

Component Concentration Cylinder # Number Calibration Principal
CARBON MONOXIDE 299 ±1.47 PPM SG9113535BAL GMIS 506.5000 PPM Hewlett Packar 2518A052 10/14/94 GC-FID

Balance Gas: Nitrogen

* Standard should not be used below 150 psig

10

Analyst:

Michael Wagner
Michael Wagner

Approved By:

Ken Roubik
Ken Roubik

APPENDIX J

PROCEDURES

Particulate Loading and Emission Rates

The particulate emission rates were determined per EPA Methods 1 - 5, CFR Title 40, Part 60, Appendix A (revised July 1, 1992). In this procedure, a preliminary velocity profile of the gases in the flue is obtained by means of a temperature and velocity traverse. On the basis of these values, sampling nozzles of appropriate diameter are selected to allow isokinetic sampling, a necessary prerequisite for obtaining a representative sample.

The sampling train consists of a heated glass or stainless steel-lined sampling probe equipped with a Type S pitot and a thermocouple. The probe is attached to a sampling module which houses the all-glass in line filter holder in a temperature controlled oven. In addition, the sampling module also houses the impinger case and a Drierite drying column. The sampling module is connected by means of an umbilical cord to the control module which houses the dry test gas meter, the calibrated orifice, a leakless pump, two inclined manometers, and all controls required for operating the sampling train.

Particulate samples were collected as follows: The sample gas was drawn in through the sampling probe isokinetically and passed through a 4-inch diameter Gelman Type A/E glass fiber filter. The particulates were removed at this point and collected on the filter. The gases then passed through an ice-cooled impinger train and a desiccant-packed drying column which quantitatively absorb all moisture from the sample gas stream after which the sample gas passes through the pump and the dry test gas meter which integrates the sample gas flow throughout the course of the test. A calibrated orifice attached to the outlet of the gas meter provides instantaneous flow rate data.

A representative particulate sample was acquired by sampling for equal periods of time at the centroid of a number of equal area regions in the duct. The sampling rate is adjusted at each site such that an isokinetic sampling condition prevails. Nomographs are used to aid in the rapid determination of the sampling rate.

Particulate Loading and Emission Rates

After sampling is complete, the filter is removed and placed in a clean container. The nozzle and inlet side of the filter holder are quantitatively washed with acetone and the washings are stored in a second container. A brush is often used in the cleaning step to help dislodge deposits. The samples are returned to the laboratory where they are logged in and analyzed. The volume of the acetone rinse ("probe wash") is noted and then the rinse is quantitatively transferred to a tared 120 cc porcelain evaporating dish and the acetone evaporated off at 97-105 °F. This temperature is used to prevent condensation of atmospheric moisture due to the cooling effect induced by the evaporation of acetone. The acetone-free sample is then transferred to an oven and dried at 105 °C for 30 minutes, cooled in a desiccator over Drierite, and then weighed to the nearest .01 mg. The filter sample is quantitatively transferred to a 6-inch watch glass and dried in an oven at 105 °C for two hours. The filter and watch glass are then cooled in a desiccator and the filter weighed to the nearest .01 mg. All weighings are performed in a balance room where the relative humidity is hydrostatted to less than 50% relative humidity. Microscopic examination of the samples is performed if any unusual characteristics are observed. The weight of the acetone rinse is corrected for the acetone blank. The Drierite column is weighed on-site and the water collected by Drierite is added to the condensate so that the total amount of absorbed water may be ascertained.

Integrated flue gas samples for Orsat analysis were collected simultaneously with each pollutant sample. The samples were collected in 15-liter gas sampling bags at a constant flow rate throughout each particulate run. The bags were at a constant flow rate throughout each particulate run. The bags were then returned to the laboratory and analyzed by Orsat analysis. Standard commercially prepared solutions were used in the Orsat analyzer (sat. KOH for carbon dioxide and reduced methylene blue for oxygen).

Condensible Organic Compounds Analysis

(State of Wisconsin - EPA Method 5)

Method II-8672-WI

Equipment: Separatory funnel - 500 cc with Teflon stopcock

Powder funnel - 75 mm ID with a glass wool plug

Evaporating dish(es) - 200 cc or 250 cc beaker

Reagents: Methylene chloride

Sodium sulfate - (ACS) granular anhydrous (purified by heating for four hours in a shallow tray)

SAMPLING

An all-glass impinger assembly is used in the back half of the EPA Method 5 sampling train when an organic wet catch is to be collected. The impinger assembly consists of a modified impinger, a Greenburg Smith impinger followed by another modified impinger. The third impinger should have a temperature measuring device at the outlet upstream of a final impinger or desiccant column to monitor the temperature of the outlet gas stream. Prior to the start of the test, each of the first two impingers should be charged with 100 g of Class I water. The Method 5 train should be operated as provided for in EPA Method 5. Ice should be added to the impinger bath to keep the temperature of the gas at the outlet at or less than 68°F. After the post test leak check, the impinger train is removed and impinger contents poured into a tared all-glass sample bottle and closed with a Teflon-lined cap. The sample bottle is then weighed and the total condensate calculated by subtraction of the bottle tare weight and the weight of initial water added to the impingers (200 g). A label is affixed and the sample is returned to the laboratory for analysis. The sample should be stored at 4°C if the analysis is not conducted within 48 hours.

030894-G:\STACK\WP\METHODS\II-8672.WI

ANALYSIS

1. Sample bottles are removed from storage and the contents quantitatively transferred to a clean 500 cc separatory funnel equipped with a Teflon stopcock.
2. Rinse the sample container with distilled water and add to separatory funnel.
3. Then rinse the sample container with acetone and pour through sodium sulfate into a tare beaker marked A.
4. The sample is then extracted consecutively with three 50 cc aliquots of methylene chloride. The extraction is performed according to normal laboratory practice observing the customary safety precaution of releasing excess pressure after each shaking.
5. After each of the three extractions are completed, the organic solvent should be dried by passing it through a funnel containing anhydrous sodium sulfate and collecting it and two 50 cc rinses in the tared beaker marked A (the same one used to catch the acetone container rinse).
6. Evaporate to dryness in a hood at 70°F or less. Do not evaporate so quickly as to allow evaporative cooling to lower the temperature of the container below the dew point otherwise water will be condensed in the container.
7. Desiccate for two hours in a sealed desiccator and final weigh. Report all results in grams. All weighings should be made to nearest 0.1 mg (four places).
8. The remaining liquid in the separatory funnel is then transferred to a tared beaker marked B and is evaporated to dryness at $220^{\circ}\text{F} \pm 10^{\circ}\text{F}$. The analyst may take an aliquot of the sample, transferring it to a tared beaker and evaporate to dryness at $220^{\circ}\text{F} \pm 10^{\circ}\text{F}$. If an aliquot is used, the weight of the sample and aliquot will have to be taken to correct for the total sample weight.

030894-G:STACKWPMETHODSII-8672.WI

9. After the drying step, the sample is cooled in a desiccator and weighted to a constant weight to the nearest 0.1 mg.


Calculation (if aliquot is taken):

$$\text{grams} = \frac{(\text{grams recovered from aliquot}) \times (\text{total volume (ml) or grams of sample})}{(\text{aliquot volume (ml) or grams used})}$$

If volume is used, it must be used for both the aliquot and sample. The same goes for using weight.

10. A field blank should be analyzed in an identical manner. If a field blank is not submitted, take an aliquot of Class I water equal in volume to the samples and analyze in a similar manner.
11. The results for container A are to be marked in the organic section of Interpoll Form #LSC-03G.
12. The results for container B are to be marked in the inorganic section of Interpoll Form #LSC-03G.

PARTICULATE SAMPLING TRAIN



Method 3A—Determination of Oxygen and Carbon Dioxide Concentrations in Emissions From Stationary Sources (Instrumental Analyzer Procedure)

1. Applicability and Principle

1.1 Applicability. This method is applicable to the determination of oxygen (O_2) and carbon dioxide (CO_2) concentrations in emissions from stationary sources only when specified within the regulations.

1.2 Principle. A sample is continuously extracted from the effluent stream: a portion of the sample stream is conveyed to an instrumental analyzer(s) for determination of O_2 and CO_2 concentration(s). Performance specifications and test procedures are provided to ensure reliable data.

2. Range and Sensitivity

Same as Method 6C, Sections 2.1 and 2.2, except that the span of the monitoring system shall be selected such that the average O_2 or CO_2 concentration is not less than 20 percent of the span.

3. Definitions

3.1 Measurement System. The total equipment required for the determination of the O_2 or CO_2 concentration. The measurement system consists of the same major subsystems as defined in Method 6C, Sections 3.1.1, 3.1.2, and 3.1.3.

3.2 Span, Calibration Gas, Analyzer Calibration Error, Sampling System Bias, Zero Drift, Calibration Drift, Response Time, and Calibration Curve. Same as Method 6C, Sections 3.2 through 3.8, and 3.10.

3.3 Interference Response. The output response of the measurement system to a component in the sample gas, other than the gas component being measured.

4. Measurement System Performance Specifications

Same as Method 6C, Sections 4.1 through 4.4.

5. Apparatus and Reagents

5.1 Measurement System. Any measurement system for O_2 or CO_2 that meets the specifications of this method. A schematic of an acceptable measurement system is shown in Figure 6C-1 of Method 6C. The essential components of the measurement system are described below:

5.1.1 Sample Probe. A leak-free probe, of sufficient length to traverse the sample points.

5.1.2 Sample Line. Tubing, to transport the sample gas from the probe to the moisture removal system. A heated sample line is not required for systems that measure the O_2 or CO_2 concentration on a dry basis, or transport dry gases.

5.1.3 Sample Transport Line, Calibration Value Assembly, Moisture Removal System, Particulate Filter, Sample Pump, Sample Flow Rate Control, Sample Gas Manifold, and Data Recorder. Same as Method 6C, Sections 5.1.3 through 5.1.9, and 5.1.11, except that the requirements to use stainless steel, Teflon, and nonreactive glass filters do not apply.

5.1.4 Gas Analyzer. An analyzer to determine continuously the O₂ or CO₂ concentration in the sample gas stream. The analyzer shall meet the applicable performance specifications of Section 4. A means of controlling the analyzer flow rate and a device for determining proper sample flow rate (e.g., precision rotameter, pressure gauge downstream of all flow controls, etc.) shall be provided at the analyzer. The requirements for measuring and controlling the analyzer flow rate are not applicable if data are presented that demonstrate the analyzer is insensitive to flow variations over the range encountered during the test.

5.2 Calibration Gases. The calibration gases for CO₂ analyzers shall be CO₂ in N₂ or CO₂ in air. Alternatively, CO₂/SO₂, O₂/SO₂, or O₂/CO₂/SO₂ gas mixtures in N₂ may be used. Three calibration gases, as specified Section 5.3.1 through 5.3.3 of Method 6C, shall be used. For O₂ monitors that cannot analyze zero gas, a calibration gas concentration equivalent to less than 10 percent of the span may be used in place of zero gas.

6. Measurement System Performance Test Procedures

Perform the following procedures before measurement of emissions (Section 7).

6.1 Calibration Concentration Verification. Follow Section 6.1 of Method 6C, except if calibration gas analysis is required, use Method 3 and change the acceptance criteria for agreement among Method 3 results to 5 percent (or 0.2 percent by volume, whichever is greater).

6.2 Interference Response. Conduct an interference response test of the analyzer prior to its initial use in the field. Thereafter, recheck the measurement system if changes are made in the instrumentation that could alter the interference response (e.g., changes in the type of gas detector). Conduct the interference response in accordance with Section 5.4 of Method 20.

6.3 Measurement System Preparation, Analyzer Calibration Error, and Sampling System Bias Check. Follow Sections 6.2 through 6.4 of Method 6C.

7. Emission Test Procedure

7.1 Selection of Sampling Site and Sampling Points. Select a measurement site and sampling points using the same criteria that are applicable to tests performed using Method 3.

7.2 Sample Collection. Position the sampling probe at the first measurement point, and begin sampling at the same rate as used during the sampling system bias check. Maintain constant rate sampling (i.e., ± 10 percent) during the entire run. The sampling time per run shall be the same as for tests conducted using Method 3 plus twice the system response time. For each run, use only those measurements obtained after twice the response time of the measurement system has elapsed to determine the average effluent concentration.

7.3 Zero and Calibration Drift Test. Follow Section 7.4 of Method 6C.

8. Quality Control Procedures

The following quality control procedures are recommended when the results of this method are used for an emission rate correction factor, or excess air determination. The tester should select one of the following options for validating measurement results:

8.1 If both O₂ and CO₂ are measured using Method 3A, the procedures described in Section 4.4 of Method 3 should be followed to validate the O₂ and CO₂ measurement results.

8.2 If only O₂ is measured using Method 3A, measurements of the sample stream CO₂ concentration should be obtained at the sample by-pass vent discharge using an Orsat or Fyrite analyzer, or equivalent. Duplicate samples should be obtained concurrent with at least one run. Average the duplicate Orsat or Fyrite analysis results for each run. Use the average CO₂ values for comparison with the O₂ measurements in accordance with the procedures described in Section 4.4 of Method 3.

8.3 If only CO₂ is measured using Method 3A, concurrent measurements of the sample stream CO₂ concentration should be obtained using an Orsat or Fyrite analyzer as described in Section 8.2. For each run, differences greater than 0.5 percent between the Method 3A results and the average of the duplicate Fyrite analysis should be investigated.

9. Emission Calculation

For all CO₂ analyzers, and for O₂ analyzers that can be calibrated with zero gas, follow Section 8 of Method 6C, except express all concentrations as percent, rather than ppm.

For O₂ analyzers that use a low-level calibration gas in place of a zero gas, calculate the effluent gas concentration using Equation 3A-1.

$$C_{gas} = \frac{C_{ma} - C_{oa}}{C_m - C_o} - (\bar{C} - C_m) + C_{ma} \text{ Eq. 3A-1}$$

Where:

- C_{gas} = Effluent gas concentration, dry basis, percent.
- C_{ma} = Actual concentration of the upscale calibration gas, percent.
- C_{oa} = Actual concentration of the low-level calibration gas, percent.
- C_m = Average of initial and final system calibration bias check responses for the upscale calibration gas, percent.
- C_o = Average of initial and final system calibration bias check responses for the low-level gas, percent.
- $\bar{C}$ = Average gas concentration indicated by the gas analyzer, dry basis, percent.

10. Bibliography

Same as bibliography of Method 6C.

Method 7E—Determination of Nitrogen Oxides Emissions From Stationary Sources (Instrumental Analyzer Procedure)

1. Applicability and Principle

1.1 **Applicability.** This method is applicable to the determination of nitrogen oxides (NO_x) concentrations in emissions from stationary sources only when specified within the regulations.

1.2 **Principle.** A gas sample is continuously extracted from a stack, and a portion of the sample is conveyed to an instrumental chemiluminescent analyzer for determination of NO_x concentration. Performance specifications and test procedures are provided to ensure reliable data.

2. Range and Sensitivity

Same as Method 6C, Sections 2.1 and 2.2.

3. Definitions

3.1 **Measurement System.** The total equipment required for the determination of NO_x concentration. The measurement system consists of the following major subsystems:

3.1.1 **Sample Interface, Gas Analyzer, and Data Recorder.** Same as Method 6C, Sections 3.1.1, 3.1.2, and 3.1.3.

3.1.2 **NO_2 to NO Converter.** A device that converts the nitrogen dioxide (NO_2) in the sample gas to nitrogen oxide (NO).

3.2 **Span, Calibration Gas, Analyzer Calibration Error, Sampling System Bias, Zero Drift, Calibration Drift, and Response Time.** Same as Method 6C, Sections 3.2 through 3.8.

3.3 **Interference Response.** The output response of the measurement system to a component in the sample gas, other than the gas component being measured.

4. Measurement System Performance Specifications

Same as Method 6C, Sections 4.1 through 4.4.

5. Apparatus and Reagents

5.1 **Measurement System.** Any measurement system for NO_x that meets the specifications of this method. A schematic of an acceptable measurement system is shown in Figure 6C-1 of Method 6C. The essential components of the measurement system are described below:

5.1.1 Sample Probe, Sample Line, Calibration Valve Assembly, Moisture Removal System, Particulate Filter, Sample Pump, Sample Flow Rate Control, Sample Gas Manifold, and Data Recorder. Same as Method 6C, Sections 5.1.1 through 5.1.9, and 5.1.11.

5.1.2 NO₂ to NO Converter. That portion of the system that converts the nitrogen dioxide (NO₂) in the sample gas to nitrogen oxide (NO). An NO₂ to NO converter is not necessary if data are presented to demonstrate that the NO₂ portion of the exhaust gas is less than 5 percent of the total NO_x concentration.

5.1.3 NO_x Analyzer. An analyzer based on the principles of chemiluminescence, to determine continuously the NO_x concentration in the sample gas stream. The analyzer shall meet the applicable performance specifications of Section 4. A means of controlling the analyzer flow rate and a device for determining proper sample flow rate (e.g., precision rotameter, pressure gauge downstream of all flow controls, etc.) shall be provided at the analyzer.

5.2 NO_x Calibration Gases. The calibration gases for the NO_x analyzer shall be NO in N₂. Three calibration gases, as specified in Sections 5.3.1 through 5.3.3. of Method 6C, shall be used. Ambient air may be used for the zero gas.

6. Measurement System Performance Test Procedures

Perform the following procedures before measurement of emissions (Section 7).

6.1 Calibration Gas Concentration Verification. Follow Section 6.1 of Method 6C, except if calibration gas analysis is required, use Method 7, and change all 5 percent performance values to 10 percent (or 10 PPM, whichever is greater).

6.2 Interference Response. Conduct an interference response test of the analyzer prior to its initial use in the field. Thereafter, recheck the measurement system if changes are made in the instrumentation that could alter the interference response (e.g., changes in the gas detector). Conduct the interference response in accordance with Section 5.4 of Method 20.

6.3 Measurement System Preparation, Analyzer Calibration Error, and Sample System Bias Check. Follow Sections 6.2 through 6.4 of Method 6C.

6.4 NO₂ to NO Conversion Efficiency. Unless data are presented to demonstrate that the NO₂ concentration within the sample stream is not greater than 5 percent of the NO_x concentration, conduct an NO₂ to NO conversion efficiency test in accordance with Section 5.6 of Method 20.

7. Emission Test Procedure

7.1 Selection of Sampling Site and Sampling Points. Select a measurement site and sampling points using the same criteria that are applicable to tests performed using Method 7.

7.2 Sample Collection. Position the sampling probe at the first measurement point, and begin sampling at the same rate as used during the system calibration drift test. Maintain constant rate sampling (i.e., ± 10 percent) during the entire run. The sampling time per run shall be the same as the total time required to perform a run using Method 7, plus twice the system response time. For each run, use only those measurements obtained after twice the response time of the measurement system has elapsed, to determine the average effluent concentration.

7.3 Zero and Calibration Drift Test. Follow Section 7.4 of Method 6C.

8. Emission Calculation

Follow Section 8 of Method 6C.

9. Bibliography

Same as bibliography of Method 6C.

Method 10—Determination of Carbon Monoxide Emissions From Stationary Sources

1. Principle and Applicability

1.1 Principle. An integrated or continuous gas sample is extracted from a sampling point and analyzed for carbon monoxide (CO) content using a Luft-type nondispersive infrared analyzer (NDIR) or equivalent.

1.2 Applicability. This method is applicable for the determination of carbon monoxide emissions from stationary sources only when specified by the test procedures for determining compliance with new source performance standards. The test procedure will indicate whether a continuous or an integrated sample is to be used.

2. Range and Sensitivity

2.1 Range. 0 to 1,000 PPM.

2.2 Sensitivity. Minimum detectable concentration is 20 PPM for a 0 to 1,000 PPM span.

3. Interferences

Any substance having a strong absorption of infrared energy will interfere to some extent. For example, discrimination ratios for water (H₂O) and carbon dioxide (CO₂) are 3.5 percent H₂O per 7 PPM CO and 10 percent CO₂ per 10 PPM CO, respectively, for devices measuring in the 1,500 to 3,000 PPM range. For devices measuring in the 0 to 100 PPM range, interference ratios can be as high as 3.5 percent H₂O per 25 PPM CO and 10 percent CO₂ per 50 PPM CO. The use of silica gel and ascarite traps will alleviate the major interference problems. The measured gas volume must be corrected if these traps are used.

4. Precision and Accuracy

4.1 Precision. The precision of most NDIR analyzers is approximately ± 2 percent of span.

4.2 Accuracy. The accuracy of most NDIR analyzers is approximately ± 5 percent of span after calibration.

5. Apparatus

5.1 Continuous Sample (Figure 10-1).

5.1.1 Probe. Stainless steel or sheathed Pyrex\1\ glass, equipped with a filter to remove particulate matter.

5.1.2 Air-Cooled Condenser or Equivalent. To remove any excess moisture.

5.2 Integrated Sample (Figure 10-2).

042694-G:STACKWPMETHODSS-METH.10

5.2.1 Probe. Stainless steel or sheathed Pyrex glass, equipped with a filter to remove particulate matter.

5.2.2 Air-Cooled Condenser or Equivalent. To remove any excess moisture.

5.2.3 Valve. Needle valve, or equivalent, to adjust flow rate.

5.2.4 Pump. Leak-free diaphragm type, or equivalent, to transport gas.

5.2.5 Rate Meter. Rotameter, or equivalent, to measure a flow range from 0 to 1.0 liter per min (0.035 cfm).

5.2.6 Flexible Bag. Tedlar, or equivalent, with a capacity of 60 to 90 liters (2 to 3 ft³). Leak-test the bag in the laboratory before using by evacuating bag with a pump followed by a dry gas meter. When evacuation is complete, there should be no flow through the meter.

5.2.7 Pitot Tube. Type S, or equivalent, attached to the probe so that the sampling rate can be regulated proportional to the stack gas velocity when velocity is varying with the time or a sample traverse is conducted.

5.3 Analysis (Figure 10-3).

5.3.1 Carbon Monoxide Analyzer. Nondispersive infrared spectrometer, or equivalent. This instrument should be demonstrated, preferably by the manufacturer, to meet or exceed manufacturer's specifications and those described in this method.

5.3.2 Drying Tube. To contain approximately 200 g of silica gel.

5.3.3 Calibration Gas. Refer to section 6.1.

5.3.4 Filter. As recommended by NDIR manufacturer.

|_See_CFR_paper_publication_for_illustration_18A

5.3.5 CO₂ Removal Tube. To contain approximately 500 g of ascarite.

5.3.6 Ice Water Bath. For ascarite and silica gel tubes.

5.3.7 Valve. Needle valve, or equivalent, to adjust flow rate

5.3.8 Rate Meter. Rotameter or equivalent to measure gas flow rate of 0 to 1.0 liter per min (0.035 cfm) through NDIR.

5.3.9 Recorder (optional). To provide permanent record of NDIR readings.

6. Reagents

6.1 Calibration Gases. Known concentration of CO in nitrogen (N₂) for instrument span, prepurified grade of N₂ for zero, and two additional concentrations corresponding approximately to 60 percent and 30 percent span. The span concentration shall not exceed 1.5 times the applicable source performance standard. The calibration gases shall be certified by the manufacturer to be within ± 2 percent of the specified concentration.

|_See_CFR_paper_publication_for_illustration_19A

6.2 Silica Gel. Indicating type, 6 to 16 mesh, dried at 175°C (347°F) for 2 hours.

6.3 Ascarite. Commercially available.

7. Procedure

7.1 Sampling.

7.1.1 Continuous Sampling. Set up the equipment as shown in Figure 10-1 making sure all connections are leak free. Place the probe in the stack at a sampling point and purge the sampling line. Connect the analyzer and begin drawing sample into the analyzer. Allow 5 minutes for the system to stabilize, then record the analyzer reading as required by the test procedure. (See section 7.2 and 8). CO₂ content of the gas may be determined by using the Method 3 integrated sample procedure, or by weighing the ascarite CO₂ removal tube and computing CO₂ concentration from the gas volume sampled and the weight gain of the tube.

7.1.2 Integrated Sampling. Evacuate the flexible bag. Set up the equipment as shown in Figure 10-2 with the bag disconnected. Place the probe in the stack and purge the sampling line. Connect the bag, making sure that all connections are leak free. Sample at a rate proportional to the stack velocity. CO₂ content of the gas may be determined by using the Method 3 integrated sample procedures, or by weighing the ascarite CO₂ removal tube and computing CO₂ concentration from the gas volume sampled and the weight gain of the tube.

7.2 CO Analysis. Assemble the apparatus as shown in Figure 10-3, calibrate the instrument, and perform other required operations as described in section 8. Purge analyzer with N₂ prior to introduction of each sample. Direct the sample stream through the instrument for the test period, recording the readings. Check the zero and span again after the test to assure that any drift or malfunction is detected. Record the sample data on Table 10-1.

042694-G:STACK\WP\METHODS\METH.10

8. Calibration

Assemble the apparatus according to Figure 10-3. Generally an instrument requires a warm-up period before stability is obtained. Follow the manufacturer's instructions for specific procedure. Allow a minimum time of 1 hour for warm-up. During this time check the sample conditioning apparatus, i.e., filter, condenser, drying tube, and CO₂ removal tube, to ensure that each component is in good operating condition. Zero and calibrate the instrument according to the manufacturer's procedures using, respectively, nitrogen and the calibration gases.

Table 10-1—Field data

Comments	
Location	
Test	
Date	
Operator	
Clock time	Rotameter setting, liters per minute (cubic feet per minute)

9. Calculation

Calculate the concentration of carbon monoxide in the stack using Equation 10-1.

$$\text{CCO stack} = \text{CCO NDIR}(1 - \text{FCO}_2) \quad \text{Eq. 10-1}$$

Where:

CCO stack = Concentration of CO in stack, PPM by volume (dry basis).

CCO NDIR = Concentration of CO measured by NDIR analyzer, PPM by volume (dry basis).

FCO₂ = Volume fraction of CO₂ in sample, i.e., percent CO₂ from Orsat analysis divided by 100.

10. Alternative Procedures

10.1 **Interference Trap.** The sample conditioning system described in Method 10A, sections 2.1.2 and 4.2, may be used as an alternative to the silica gel and ascarite traps.

11. Bibliography

1. McElroy, Frank, The Intertech NDIR-CO Analyzer, Presented at 11th Methods Conference on Air Pollution, University of California, Berkeley, CA. April 1, 1970.
2. Jacobs, M. B., et al., Continuous Determination of Carbon Monoxide and Hydrocarbons in Air by a Modified Infrared Analyzer, J. Air Pollution Control Association, 9(2): 110-114. August 1959.
3. MSA LIRA Infrared Gas and Liquid Analyzer Instruction Book, Mine Safety Appliances Co., Technical Products Division, Pittsburgh, PA.
4. Models 215A, 315A, and 415A Infrared Analyzers, Beckman Instruments, Inc., Beckman Instructions 1635-B, Fullerton, CA. October 1967.
5. Continuous CO Monitoring System, Model A5611, Intertech Corp., Princeton, NJ.
6. UNOR Infrared Gas Analyzers, Bendix Corp., Ronceverte, WV

Agenda

A. Performance Specifications for NDIR Carbon Monoxide Analyzers

Range (minimum)	0—1000 PPM.
Output (minimum)	0—10mV.
Minimum detectable sensitivity	20 PPM.
Rise time, 90 percent (maximum)	30 seconds.
Fall time, 90 percent (maximum)	30 seconds.
Zero drift (maximum)	10% in 8 hours.
Span drift (maximum)	10% in 8 hours.
Precision (minimum)	± 2% of full scale.
Noise (maximum)	± 1% of full scale.
Linearity (maximum deviation)	2% of full scale.
Interference rejection ratio	CO ₂ —1000 to 1, H ₂ O—500 to 1.

B. Definitions of Performance Specifications.

Range—The minimum and maximum measurement limits.

Output—Electrical signal which is proportional to the measurement; intended for connection to readout or data processing devices. Usually expressed as millivolts or milliamps full scale at a given impedance.

Full scale—The maximum measuring limit for a given range.

Minimum detectable sensitivity—The smallest amount of input concentration that can be detected as the concentration approaches zero.

Accuracy—The degree of agreement between a measured value and the true value; usually expressed as $\pm$ percent of full scale.

Time to 90 percent response—The time interval from a step change in the input concentration at the instrument inlet to a reading of 90 percent of the ultimate recorded concentration.

Rise Time (90 percent)—The interval between initial response time and time to 90 percent response after a step increase in the inlet concentration.

Fall Time (90 percent)—The interval between initial response time and time to 90 percent response after a step decrease in the inlet concentration.

Zero Drift—The change in instrument output over a stated time period, usually 24 hours, of unadjusted continuous operation when the input concentration is zero; usually expressed as percent full scale.

Span Drift—The change in instrument output over a stated time period, usually 24 hours, of unadjusted continuous operation when the input concentration is a stated upscale value; usually expressed as percent full scale.

Precision—The degree of agreement between repeated measurements of the same concentration, expressed as the average deviation of the single results from the mean.

Noise—Spontaneous deviations from a mean output not caused by input concentration changes.

Linearity—The maximum deviation between an actual instrument reading and the reading predicted by a straight line drawn between upper and lower calibration points.

Method 10A—Determination of Carbon Monoxide Emissions in Certifying Continuous Emission Monitoring Systems at Petroleum Refineries

1. Applicability and Principle

1.1 Applicability. This method applies to the measurement of carbon monoxide (CO) at petroleum refineries. This method serves as the reference method in the relative accuracy test for nondispersive infrared (NDIR) CO continuous emission monitoring systems (CEMS's) that are required to be installed in petroleum refineries on fluid catalytic cracking unit catalyst regenerators [40 CFR Part 60.105(a)(2)].

1.2 Principle. An integrated gas sample is extracted from the stack, passed through an alkaline permanganate solution to remove sulfur and nitrogen oxides, and collected in a Tedlar bag. The CO concentration in the sample is measured spectrophotometrically using the reaction of CO with p-sulfaminobenzoic acid.

1.3. Range and Sensitivity.

1.3.1 Range. Approximately 3 to 1800 PPM CO. Samples having concentrations below 400 PPM are analyzed at 425 nm, and samples having concentrations above 400 PPM are analyzed at 600 nm.

1.3.2 Sensitivity. The detection limit is 3 PPM based on three times the standard deviation of the mean reagent blank values.

042694-G:\STACK\WPMETHODSS-METH.10

7.4 Adsorption Tube Procedure (Alternative Procedure). It is suggested that the tester refer to the National Institute of Occupational Safety and Health (NIOSH) method for the particular organics to be sampled. The principal interferent will be water vapor. If water vapor is present at concentrations above 3 percent, silica gel should be used in front of the charcoal. Where more than one compound is present in the emissions, then develop relative adsorptive capacity information.

7.4.1 Additional Apparatus. In addition to the equipment listed in the NIOSH method for the particular organic(s) to be sampled, the following items (or equivalent) are suggested.

7.4.1.1 Probe (Optional). Borosilicate glass or stainless steel, approximately 6-mm ID, with a heating system if water condensation is a problem, and a filter (either in-stack or out-stack heated to stack temperature) to remove particulate matter. In most instances, a plug of glass wool is a satisfactory filter.

7.4.1.2 Flexible Tubing. To connect probe to adsorption tubes. Use a material that exhibits minimal sample adsorption.

7.4.1.3 Leakless Sample Pump. Flow controlled, constant rate pump, with a set of limiting (sonic) orifices to provide pumping rates from approximately 10 to 100 cc/min.

7.4.1.4 Bubble-Tube Flowmeter. Volume accuracy within ± 1 percent, to calibrate pump.

7.4.1.5 Stopwatch. To time sampling and pump rate calibration.

7.4.1.6 Adsorption Tubes. Similar to ones specified by NIOSH, except the amounts of adsorbent per primary/backup sections are 800/200 mg for charcoal tubes and 1040/260 mg for silica gel tubes. As an alternative, the tubes may contain a porous polymer adsorbent such as Tenax GC or XAD-2.

7.4.1.7 Barometer. Accurate to 5 mm Hg, to measure atmospheric pressure during sampling and pump calibration.

7.4.1.8 Rotameter. 0 to 100 cc/min, to detect changes in flow rate during sampling.

7.4.2 Sampling and Analysis. It is suggested that the tester follow the sampling and analysis portion of the respective NIOSH method section entitled "Procedure." Calibrate the pump and limiting orifice flow rate through adsorption tubes with the bubble tube flowmeter before sampling. The sample system can be operated as a "recirculating loop" for this operation. Record the ambient temperature and barometric pressure. Then, during sampling, use the ro-

tameter to verify that the pump and orifice sampling rate remains constant.

Use a sample probe, if required, to obtain the sample at the centroid of the duct, or at a point no closer to the walls than 1 m. Minimize the length of flexible tubing between the probe and adsorption tubes. Several adsorption tubes can be connected in series, if the extra adsorptive capacity is needed. Provide the gas sample to the sample system at a pressure sufficient for the limiting orifice to function as a sonic orifice. Record the total time and sample flow rate (or the number of pump strokes), the barometric pressure, and ambient temperature. Obtain a total sample volume commensurate with the expected concentration(s) of the volatile organic(s) present, and recommended sample loading factors (weight sample per weight adsorption media). Laboratory tests prior to actual sampling may be necessary to predetermine this volume. When more than one organic is present in the emissions, then develop relative adsorptive capacity information. If water vapor is present in the sample at concentrations above 2 to 3 percent, the adsorptive capacity may be severely reduced. Operate the gas chromatograph according to the manufacturer's instructions. After establishing optimum conditions, verify and document these conditions during all operations. Analyze the audit samples (see Section 7.4.4.3), then the emission samples. Repeat the analysis of each sample until the relative deviation of two consecutive injections does not exceed 5 percent.

7.4.3 Standards and Calibration. The standards can be prepared according to the respective NIOSH method. Use a minimum of three different standards; select the concentrations to bracket the expected average sample concentration. Perform the calibration before and after each day's sample analyses. Prepare the calibration curve by using the least squares method.

7.4.4 Quality Assurance.

7.4.4.1 Determination of Desorption Efficiency. During the testing program, determine the desorption efficiency in the expected sample concentration range for each batch of adsorption media to be used. Use an internal standard. A minimum desorption efficiency of 50 percent shall be obtained. Repeat the desorption determination until the relative deviation of two consecutive determinations does not exceed 5 percent. Use the average desorption efficiency of these two consecutive determinations for the correction specified in Section 7.4.4.5. If the desorption efficiency of the compound(s) of interest is questionable under actual sampling conditions, use of the Method of Standard Additions may be helpful to determine this value.

7.4.4.2 Determination of Sample Collection Efficiency. For the source samples, ana-

lyze the primary and backup portions of the adsorption tubes separately. If the backup portion exceeds 10 percent of the total amount (primary and backup), repeat the sampling with a larger sampling portion.

7.4.4.3 Analysis Audit. Immediately before the sample analyses, analyze the two audits in accordance with Section 7.4.2. The analysis audit shall agree with the audit concentration within 10 percent.

7.4.4.4 Pump Leak Checks and Volume Flow Rate Checks. Perform both of these checks immediately after sampling with all sampling train components in place. Perform all leak checks according to the manufacturer's instructions, and record the results. Use the bubble-tube flowmeter to measure the pump volume flow rate with the orifice used in the test sampling, and the result. If it has changed by more than 5 but less than 20 percent, calculate an average flow rate for the test. If the flow rate has changed by more than 20 percent, recalibrate the pump and repeat the sampling.

7.4.4.5 Calculations. All calculations can be performed according to the respective NIOSH method. Correct all sample volumes to standard conditions. If a sample dilution system has been used, multiply the results by the appropriate dilution ratio. Correct all results by dividing by the desorption efficiency (decimal value). Report results as ppm by volume, dry basis.

7.5 Reporting of Results. At the completion of the field analysis portion of the study, ensure that the data sheets shown in Figure 18-11 have been completed. Summarize this data on the data sheets shown in Figure 18-15.

8. Bibliography

1. American Society for Testing and Materials. C, Through C, Hydrocarbons in the Atmosphere by Gas Chromatography. ASTM D 2820-72, Part 23. Philadelphia, Pa. 23:950-958. 1973.
2. Corazon, V. V. Methodology for Collecting and Analyzing Organic Air Pollutants. U.S. Environmental Protection Agency. Publication No. EPA-600/2-79-042. February 1979.
3. Dravnieks, A., B. K. Krotoszynski, J. Whitfield, A. O'Donnell, and T. Burgwald. Environmental Science and Technology. 5(12):1200-1222. 1971.
4. Eggertsen, F. T., and F. M. Nelsen. Gas Chromatographic Analysis of Engine Exhaust and Atmosphere. Analytical Chemistry. 30(6): 1040-1043. 1958.
5. Fearheller, W. R., P. J. Marn, D. H. Harris, and D. L. Harris. Technical Manual for Process Sampling Strategies for Organic Materials. U.S. Environmental Protection Agency. Research Triangle Park, NC. Publication No. EPA 600/2-76-122. April 1976. 172 p.

Sampling Equipment. Environmental Protection Agency. Research Triangle Park, N.C. APTD-0576. March, 1972.

4. Smith, W. S., R. T. Shigehara, and W. F. Todd. A Method of Interpreting Stack Sampling Data. Paper Presented at the 63rd Annual Meeting of the Air Pollution Control Association, St. Louis, Mo. June 14-19, 1970.

5. Smith, W. S., et al., Stack Gas Sampling Improved and Simplified with New Equipment. APCA Paper No. 67-119. 1967.

6. Specifications for Incinerator Testing at Federal Facilities. PHS, NCAPC. 1967.

7. Shigehara, R. T., Adjustments in the EPA Nomograph for Different Pitot Tube Coefficients and Dry Molecular Weights. Stack Sampling News 2:4-11. October, 1974.

8. Vollaro, R. F., A Survey of Commercially Available Instrumentation for the Measurement of Low-Range Gas Velocities. U.S. Environmental Protection Agency, Emission Measurement Branch. Research Triangle Park, N.C. November, 1976 (unpublished paper).

9. Annual Book of ASTM Standards. Part 26. Gaseous Fuels; Coal and Coke; Atmospheric Analysis. American Society for Testing and Materials. Philadelphia, Pa. 1974. pp. 617-622.

10. Vollaro, R. F., Recommended Procedure for Sample Traverses in Ducts Smaller than 12 Inches in Diameter. U.S. Environmental Protection Agency, Emission Measurement Branch. Research Triangle Park, N.C. November, 1976.

METHOD 18—MEASUREMENT OF GASEOUS ORGANIC COMPOUND EMISSIONS BY GAS CHROMATOGRAPHY

Introduction

This method should not be attempted by persons unfamiliar with the performance characteristics of gas chromatography, nor by those persons who are unfamiliar with source sampling. Particular care should be exercised in the area of safety concerning choice of equipment and operation in potentially explosive atmospheres.

1. Applicability and Principle

1.1 Applicability. This method applies to the analysis of approximately 90 percent of the total gaseous organics emitted from an industrial source. It does not include techniques to identify and measure trace amounts of organic compounds, such as those found in building air and fugitive emission sources.

This method will not determine compounds that (1) are polymeric (high molecular weight), (2) can polymerize before analysis, or (3) have very low vapor pressures at stack or instrument conditions.

1.2 Principle.

The major organic components of a gas mixture are separated by gas chromatography (GC) and individually quantified by flame ionization, photoionization, electron capture, or other appropriate detection principles.

The retention times of each separated component are compared with those of known compounds under identical conditions. Therefore, the analyst confirms the identity and approximate concentrations of the organic emission components beforehand. With this information, the analyst then prepares or purchases commercially available standard mixtures to calibrate the GC under conditions identical to those of the samples. The analyst also determines the need for sample dilution to avoid detector saturation, gas stream filtration to eliminate particulate matter, and prevention of moisture condensation.

2. Range and Sensitivity

2.1 Range. The range of this method is from about 1 part per million (ppm) to the upper limit governed by GC detector saturation or column overloading. The upper limit can be extended by diluting the stack gases with an inert gas or by using smaller gas sampling loops.

2.2 Sensitivity. The sensitivity limit for a compound is defined as the minimum detectable concentration of that compound, or the concentration that produces a signal-to-noise ratio of three to one. The minimum detectable concentration is determined during the presurvey calibration for each compound.

3. Precision and Accuracy

Gas chromatographic techniques typically provide a precision of 5 to 10 percent relative standard deviation (RSD), but an experienced GC operator with a reliable instrument can readily achieve 5 percent RSD. For this method, the following combined GC/operator values are required.

(a) Precision. Duplicate analyses are within 5 percent of their mean value.

(b) Accuracy. Analysis results of prepared audit samples are within 10 percent of preparation values.

4. Interferences

Resolution interferences that may occur can be eliminated by appropriate GC column and detector choice or by shifting the retention times through changes in the column flow rate and the use of temperature programming.

The analytical system is demonstrated to be essentially free from contaminants by periodically analyzing blanks that consist of hydrocarbon-free air or nitrogen.

Sample cross-contamination that occurs when high-level and low-level samples or standards are analyzed alternately, is best

Method 25A-Determination of Total Gaseous Organic Concentration Using a Flame Ionization Analyzer

1. Applicability and Principle

1.1 Applicability. This method applies to the measurement of total gaseous organic concentration of vapors consisting primarily of alkanes, alkenes, and/or arenes (aromatic hydrocarbons). The concentration is expressed in terms of propane (or other appropriate organic calibration gas) or in terms of carbon.

1.2 Principle. A gas sample is extracted from the source through a heated sample line, if necessary, and glass fiber filter to a flame ionization analyzer (FIA). Results are reported as volume concentration equivalents of the calibration gas or as carbon equivalents.

2. Definitions

2.1 Measurement Systems. The total equipment required for the determination of the gas concentration. The system consists of the following major subsystems:

2.1.1 Sample Interface. That portion of the system that is used for one or more of the following: sample acquisition, sample transportation, sample conditioning, or protection of the analyzer from the effects of the stack effluent.

2.1.2 Organic Analyzer. That portion of the system that senses organic concentration and generates an output proportional to the gas concentration.

2.2 Span Value. The upper limit of a gas concentration measurement range that is specified for affected source categories in the applicable part of the regulations. The span value is established in the applicable regulation and is usually 1.5 to 2.5 times the applicable emission limit. If no span value is provided, use a span value equivalent to 1.5 to 2.5 times the expected concentration. For convenience, the span value should correspond to 100 percent of the recorder scale.

2.3 Calibration Gas. A known concentration of a gas in an appropriate diluent gas.

2.4 Zero Drift. The difference in the measurement system response to a zero level calibration gas before and after a stated period of operation during which no unscheduled maintenance, repair, or adjustment took place.

2.5 Calibration drift. The difference in the measurement system response to a midlevel calibration gas before and after a stated period of operation during which no unscheduled maintenance, repair or adjustment took place.

2.6 Response Time. The time interval from a step change in pollutant concentration at the inlet to the emission measurement system to the time at which 95 percent of the corresponding final value is reached as displayed on the recorder.

2.7 Calibration Error. The difference between the gas concentration indicated by the measurement system and the known concentration of the calibration gas.

3. Apparatus

A schematic of an acceptable measurement system is shown in Figure 25A-1. The essential components of the measurement system are described below:

3.1 Organic Concentration Analyzer. A flame ionization analyzer (FIA) capable of meeting or exceeding the specifications in this method.

3.2 Sample Probe. Stainless steel, or equivalent, three-hole rake type. Sample holes shall be 4 mm in diameter or smaller and located at 16.7, 50, and 83.3 percent of the equivalent stack diameter. Alternatively, a single opening probe may be used so that a gas sample is collected from the centrally located 10 percent area of the stack cross-section.

3.3 Sample Line. Stainless steel or Teflon * tubing to transport the sample gas to the analyzer. The sample line should be heated, if necessary, to prevent condensation in the line.

3.4 Calibration Valve Assembly. A three way valve assembly to direct the zero and calibration gases to the analyzers is recommended. Other methods, such as quick-connect lines, to route calibration gas to the analyzers are applicable.

3.5 Particulate Filter. An in-stack or an out-of-stack glass fiber filter is recommended if exhaust gas particulate loading is significant. An out-of-stack filter should be heated to prevent any condensation.

* Mention of trade names or specific products does not constitute endorsement by the Environmental Protection Agency.

3.6 Recorder. A strip-chart recorder, analog computer, or digital recorder for recording measurement data. The minimum data recording requirement is one measurement value per minute. Note: This method is often applied in highly explosive areas. Caution and care should be exercised in choice of equipment and installation.

4. Calibration and Other Gases.

Gases used for calibrations, fuel, and combustion air (if required) are contained in compressed gas cylinders. Preparation of calibration gases shall be done according to the procedure in Protocol No. 1, listed in Citation 2 of Bibliography. Additionally, the manufacturer of the cylinder should provide a recommended shelf life for each calibration gas cylinder over which the concentration does not change more than ± 2 percent from the certified value. For calibration gas values not generally available (i.e., organics between 1 and 10 percent by volume), alternative methods for preparing calibration gas mixtures, such as dilution systems, may be used with prior approval of the Administrator.

Calibration gases usually consist of propane in air or nitrogen and are determined in terms of the span value. Organic compounds other than propane can be used following the above guidelines and making the appropriate corrections for response factor.

4.1 **Fuel.** A 40 percent H₂/60 percent N₂ gas mixture is recommended to avoid an oxygen synergism effect that reportedly occurs when oxygen concentration varies significantly from a mean value.

4.2 **Zero Gas.** High purity air with less than 0.1 parts per million by volume (PPMv) of organic material (propane or carbon equivalent) or less than 0.1 percent of the span value, whichever is greater.

4.3 **Low-level Calibration Gas.** An organic calibration gas with a concentration equivalent to 25 to 35 percent of the applicable span value.

4.4 **Mid-level Calibration Gas.** An organic calibration gas with a concentration equivalent to 45 to 55 percent of the applicable span value.

4.5 **High-level Calibration Gas.** An organic calibration gas with a concentration equivalent to 80 to 90 percent of the applicable span value.

5. Measurement System Performance Specifications

5.1 **Zero Drift.** Less than ± 3 percent of the span value.

5.2 **Calibration Drift.** Less than ± 3 percent of span value.

5.3 **Calibration Error.** Less than ± 5 percent of the calibration gas value.

6. Pretest Preparations

6.1 **Selection of Sampling Site.** The location of the sampling site is generally specified by the applicable regulation or purpose of the test; i.e., exhaust stack, inlet line, etc. The sample port shall be located at least 1.5 meters or 2 equivalent diameters upstream of the gas discharge to the atmosphere.

6.2 **Location of Sample Probe.** Install the sample probe so that the probe is centrally located in the stack, pipe, or duct and is sealed tightly at the stack port connection.

6.3 **Measurement System Preparation.** Prior to the emission test, assemble the measurement system following the manufacturer's written instructions in preparing the sample interface and the organic analyzer. Make the system operable.

FIA equipment can be calibrated for almost any range of total organics concentrations. For high concentrations of organics (> 1.0 percent by volume as propane) modifications to most commonly available analyzers are necessary. One accepted method of equipment modification is to decrease the size of the sample to the analyzer through the use of a smaller diameter sample capillary. Direct and continuous measurement of organic concentration is a necessary consideration when determining any modification design.

6.4 Calibration Error Test. Immediately prior to the test series, (within 2 hours of the start of the test) introduce zero gas and high-level calibration gas at the calibration valve assembly. Adjust the analyzer output to the appropriate levels, if necessary. Calculate the predicted response for the low-level and mid-level gases based on a linear response line between the zero and high-level responses. Then introduce low-level and mid-level calibration gases successively to the measurement system. Record the analyzer responses for low-level and mid-level calibration gases and determine the differences between the measurement system responses and the predicted responses. These differences must be less than 5 percent of the respective calibration gas value. If not, the measurement system is not acceptable and must be replaced or repaired prior to testing. No adjustments to the measurement system shall be conducted after the calibration and before the drift check (Section 7.3). If adjustments are necessary before the completion of the test series, perform the drift checks prior to the required adjustments and repeat the calibration following the adjustments. If multiple electronic ranges are to be used, each additional range must be checked with a mid-level calibration gas to verify the multiplication factor.

6.5 Response Time Test. Introduce Zero gas into the measurement system at the calibration valve assembly. When the system output has stabilized, switch quickly to the high-level calibration gas. Record the time from the concentration change to the measurement system response equivalent to 95 percent of the step change. Repeat the test three times and average the results.

7. Emission Measurement Test Procedure

7.1 Organic Measurement. Begin sampling at the start of the test period, recording time and any required process information as appropriate. In particular, note on the recording chart periods of process interruption or cyclic operation.

7.2 Drift Determination. Immediately following the completion of the test period and hourly during the test period, reintroduce the zero and mid-level calibration gases, one at a time, to the measurement system at the calibration valve assembly. (Make no adjustments to the measurement system until after both the zero and calibration drift checks are made.) Record the analyzer response. If the drift values exceed the specified limits, invalidate the test results preceding the check and repeat the test following corrections to the measurement system. Alternatively, recalibrate the test measurement system as in Section 6.4 and report the results using both sets of calibration data (i.e., data determined prior to the test period and data determined following the test period).

8. Organic Concentration calculations

Determine the average organic concentration in terms of PPMv as propane or other calibration gas. The average shall be determined by the integration of the output recording over the period specified in the applicable regulation. If results are required in terms of PPMv as carbon, adjust measured concentrations using Equation 25A-1.

$$C_c = K C_{\text{meas}}$$

Eq. 25A-1

Where:

C_c = Organic concentration as carbon, PPMv.

C_{meas} = Organic concentration as measured, PPMv.

K = Carbon equivalent correction factor.

$K = 2$ for ethane.

$K = 3$ for propane.

$K = 4$ for butane.

K = Appropriate response factor for other organic calibration gases.

9. Bibliography

1. Measurement of Volatile Organic Compounds-Guideline Series. U.S. Environmental Protection Agency. Research Triangle Park, NC. Publication No. EPA-450/2-78-041. June 1978. p. 46-54.
2. Traceability Protocol for Establishing True Concentrations of Gases Used for Calibration and Audits of Continuous Source Emission Monitors (Protocol No. 1). U.S. Environmental Protection Agency, Environmental Monitoring and Support Laboratory. Research Triangle Park, NC. June 1978.
3. Gasoline Vapor Emission Laboratory Evaluation-Part 2. U.S. Environmental Protection Agency, Office of Air Quality Planning and Standards. Research Triangle Park, NC. EMB Report No. 75-GAS-6. August 1975.

PHENOL

Phenol samples were collected using a Method 5 sampling train at 0.75 CFM using neutral-buffered absorbing reagent. The first impinger in each sampling was spiked with isotopically-labeled phenol (phenol- d_5) and 2-fluorophenol for sampling and recovery efficiency surrogates. The recovered samples were extracted and the extracts analyzed by GC/MS for phenol, phenol- d_5 and 2-fluorophenol as per EPA Method 8270. The recoveries of phenol- d_5 and 2-fluorophenol were used to adjust the measured phenol concentrations.

DRAFT

DCN No.: 93-275-065-55-07
Radian No.: 275-065-55
EPA NO.: 68-D1-0010

This document is a preliminary draft.
It has not been formally released by EPA
and should not at this stage be construed
to represent Agency policy. It is being
circulated for comment on its technical
accuracy and for any implications.

FIELD TEST OF A GENERIC METHOD FOR SAMPLING AND ANALYSIS OF ISOCYANATES

Interim Report
(Work Assignment 55)

Prepared for:

Frank Wilshire
Atmospheric Research and Exposure Assessment Laboratory
Methods Research and Development Division
Source Methods Research Branch
U.S. Environmental Protection Agency
Research Triangle Park, NC 27711

Prepared by:

J. F. McGaughey
S. C. Foster
R. G. Merrill

RADIAN
CORPORATION

P.O. Box 13000
Research Triangle Park, NC 27709

July 1993

DRAFT

This document is a preliminary draft
It has not been formally released by EPA
and should not at this stage be construed
to represent Agency policy. It is being
circulated for comment on its technical
accuracy and policy implications.

DISCLAIMER

The information in this document has been funded wholly by the United States Environmental Protection Agency under EPA Contract Number 68-D1-0010 to Radian. It has been subjected to the Agency's peer and administrative review, and it has been approved for publication as an EPA document. Mention of trade names or commercial products does not constitute endorsement or recommendation for use.

ACKNOWLEDGEMENT

We wish to acknowledge the contributions of the following individuals to the success of this program: Mark Owens, Danny Harrison, Darrell Doerlé and Jim Southerland

EXECUTIVE SUMMARY

Isocyanates are used extensively in the production of polyurethane materials such as flexible foam, enamel wire coatings, paint formulations and in binders for the pressed board industry. Because of their widespread use and known adverse physiological effects, several isocyanates have been listed in Title III of the Clean Air Act Amendments of 1990. The isocyanates of interest are: 2,4-toluene diisocyanate (TDI), methylene diphenyl diisocyanate (MDI), 1,6-hexamethylene diisocyanate (HDI) and methyl isocyanate (MI). Previously, no validated sampling and analytical methodology for these compounds relative to stationary sources existed.

The field validation study presented in this report is a culmination of laboratory investigations, performed under previous work assignments, which were designed to develop and evaluate a viable approach for the determination of isocyanate emissions from stationary sources. After the successful completion of the laboratory studies, the sampling and analysis approach was formulated and a field validation test was initiated. At the direction of the EPA, TDI was selected as the primary analyte.

The test site selected was a flexible foam manufacturing facility in High Point, North Carolina, which used TDI in the manufacturing process. The approximate level of TDI in the emission stream was determined by the analysis of samples collected during a presurvey. A sampling scheme was then designed to ensure the collection of sufficient samples to yield statistically valid data. Following the EPA Method 301 protocol, quadruplicate trains (QUAD) were operated simultaneously with four co-located probes. Two of the trains were spiked with TDI and two were unspiked. Samples from eight QUAD runs (minimum of six valid runs required by Method 301) were returned to the laboratory and analyzed according to the analytical procedure developed in laboratory studies. These data were statistically evaluated following Method 301 protocol to determine the performance of the method relative to bias and precision. These results are summarized in the following table. The precision for both the spiked and unspiked trains was less than 5% RSD, which is well within the precision criteria (% RSD < 50)

Method Validation Statistical Summary

Precision ^a	
% RSD for Spiked Samples	3.55 ^b
% RSD for Unspiked Samples	4.72 ^b
Accuracy ^a	
Bias:	-295 μ g
Significant?	No
Correction Factor	1.0 ^c
Recovery ^a	
Amount Spiked (as TDI)	7828 μ g
Average Percent Recovered	95

^aResults are based on the average of seven QUAD runs (14 spiked trains and 14 unspiked trains). TDI was present in the stack emissions and was therefore collected as background in the unspiked trains as well as in the spiked trains.

^bEPA Method 301 requires the precision to be <50% RSD for the method to be acceptable.

^cEPA Method 301 requires the calculated Correction Factor to be between 0.7 and 1.3 for the method to be acceptable.

for an acceptable method as tested. Using the data from all eight runs, the bias was found to be significant at the 95% level of confidence thus requiring the use of a correction factor of 1.053. Using the data from only seven runs (eliminating run number eight due to a questionable leak check for one of the trains) the bias was not significant and therefore did not require the calculation of a correction factor. In either case, the method was well within the bias acceptance criteria (correction factor between 0.7 and 1.3) for an acceptable method as tested.

TABLE OF CONTENTS

	Page
1.0 INTRODUCTION	1-1
2.0 CONCLUSIONS AND RECOMMENDATIONS	2-1
3.0 FIELD TEST	3-1
3.1 Site Description	3-1
3.2 Sampling Location	3-1
3.3 Test Schedule	3-3
3.4 Sample Collection	3-3
3.4.1 Quad Probe	3-3
3.4.2 Quad-Train Assembly	3-6
3.5 Sampling Preparation	3-6
3.5.1 Glassware Preparation	3-6
3.5.2 Preparation of Impinger Absorbing Solution	3-8
3.5.3 Preparation of TDI Spiking Solution	3-8
3.5.4 Sampling Equipment Preparation	3-9
3.5.5 Sampling Operations	3-10
3.5.6 Sample Recovery	3-13
3.6 Quality Control	3-16
4.0 ANALYTICAL PROCEDURES	4-1
4.1 Sample Preparation	4-1
4.2 Chromatographic Analyses	4-1
4.2.1 Standard Preparation	4-1
4.2.2 Analysis	4-2
4.3 Qualitative Identification	4-3
4.4 Calculations	4-3
4.4.1 Calculation of the Amount of Isocyanate Collected	4-3
4.4.2 Normalization of the Amount of Isocyanate Collected	4-6
4.5 Quality Control	4-12

TABLE OF CONTENTS, continued

	Page
5.0 RESULTS AND DISCUSSION	5-1
5.1 Bias and Precision	5-1
5.2 Breakthrough and Recovery	5-3
5.2.1 Breakthrough	5-3
5.2.2 Recovery	5-6
5.3 Quality Assurance/Quality Control	5-6
5.3.1 Overview of Data Quality	5-8
5.3.2 Sampling Quality Control	5-10
5.3.3 Sample Storage and Holding Time	5-10
5.3.4 Analytical Quality Control	5-10

LIST OF TABLES

		Page
1-1	Isocyanates Listed in the Clean Air Act Amendments of 1990	1-2
3-1	Test Schedule	3-4
3-2	Sampling Train Test Matrix	3-7
3-3	Quad Train Sample Volumes	3-14
4-1	2,4-TDI Detected in Unspiked Trains, μg	4-7
4-2	2,4-TDI Detected in Spiked Trains, μg	4-9
4-3	Normalized Amount of 2,4-TDI Detected in Unspiked Trains, μg	4-13
4-4	Normalized Amount of 2,4-TDI Detected in Spiked Trains, μg	4-14
5-1	Summary of Method 301 Statistical Calculations	5-2
5-2	Distribution of 2,4-TDI Within the Spiked Trains	5-4
5-3	Distribution of 2,4-TDI Within the Unspiked Trains	5-5
5-4	Percent Recovery of the Spiked 2,4-TDI	5-7
5-5	Data Quality Acceptance Criteria and Results	5-9
5-6	Sampling Train Leak Check Summary	5-11
5-7	Summary of Analytical Quality Control Results	5-12

LIST OF FIGURES

	Page
3-1 Sample Location	3-2
3-2 Schematic of Quad Train Setup	3-5
3-3 Sampling Train for Isocyanate	3-12
4-1 Chromatogram of Unspiked Train	4-4
4-2 Chromatogram of Spiked Train	4-5

Sampling and analytical methods for a particular analyte or group of analytes can be evaluated and validated by demonstrating their performance in field tests, thereby establishing the precision and bias of the methods experimentally. Few methods have been fully validated for sampling and analyzing the organic compounds listed in Title III of the Clean Air Act Amendments of 1990. For some analytes, methods have been validated for sample analysis, but not for sample collection. Full validation for both sampling and analytical methods, for both field and laboratory operations, is available for fewer than 10 percent of the analytes listed in Title III of the Clean Air Act Amendments at any source category. Field validation may be performed by side-by-side comparison of a candidate method to a validated method to establish comparable performance for the same analytes in the same matrix (same source category). Another procedure for validation of a method is to spike known quantities of analytes into the collection apparatus in the field so that the precision and bias of the method can be demonstrated from sample collection through analysis.

EPA, under the authority of Title III of the Clean Air Act Amendments (CAAA) of 1990, requires the identification and validation of sampling and analytical methods for the isocyanate compounds which are listed among the 189 hazardous air pollutants identified in Title III. These isocyanate compounds are listed in Table 1-1. Development of sampling and analytical methods for these four compounds was accomplished under Work Assignments 11, 21, and 40 on EPA Contract No. 68-D1-0010. At the direction of EPA, initial efforts were directed to the measurement of 2,4-toluene diisocyanate (TDI) emissions.

The objective of this work assignment was to validate the isocyanate sampling and analytical test method through field testing at an operating stationary source. The method was validated by collecting flue gas samples for the analysis of 2,4-TDI, and evaluating the data for bias and precision. EPA Method 301, "Field Validation of Pollutant Measurement Methods from Various Waste Media," was used as

Table 1-1

Isocyanates Listed in the Clean Air Act Amendments of 1990

Hexamethylene-1,6-diisocyanate (HDI)

2,4-Toluene diisocyanate (TDI)*

Methylene diphenyl diisocyanate (MDI)

Methyl isocyanate (MI)

***The 2,6 TDI isomer may also be present but is not listed in the CAAA.**

a model for the validation protocol. Analyte spiking was used with quadruplicate sampling trains to generate the required data. The field validation was performed at an industrial facility which manufactures flexible foam products. Only two of the quadruplicate trains were spiked for each run. The two unspiked trains were used to establish the background level of target compound in the stack gas.

The sampling method utilizes a Method 5-type sampling train, which operates with a solution of 1-(2-pyridyl) piperazine and toluene in the impingers. Stack gas is extracted from the source through a heated probe and drawn through the impingers. TDI present in the stack gas reacts with the piperazine to form an isocyanate derivative. The quantity of isocyanate is determined by solvent exchange of the toluene solution with acetonitrile followed by high pressure liquid chromatographic (HPLC) analysis.

This report discusses the details of the field validation study. Section 2.0, Conclusions and Recommendations, summarizes the results and provides recommendations for future work. Sections 3.0 and 4.0 provide details of the sampling and analysis procedures respectively. Section 5.0 is a detailed discussion of the procedures, calculations and quality control.

CONCLUSIONS AND RECOMMENDATIONS

Based on the results presented in Section 6.0 of this report, the following conclusions can be made concerning the validity of the method as tested under the conditions described in this report:

- The calculated values for precision (%RSD) for both the spiked and unspiked trains, 3.55 and 4.72 respectively, are both well within the acceptance criteria of less than 50% RSD found in Section 6.3 of the EPA Method 301. Therefore, the method as tested at the source category described meets the precision requirements;
- The method bias, at the concentration levels tested, was found to be significantly different from zero at the 95% level of confidence when the data from all eight runs (minimum of six runs required) were used in the calculations. A correction factor of 1.053 would be required if all eight runs are included in the bias calculation. Good technical reasons exist for excluding one of eight QUAD runs. If this run is eliminated, no bias correction is required. In either case the correction factor is well within the acceptance criteria of 0.7 to 1.3 found in Section 1.2 of the EPA Method 301. Therefore, the method as tested at the source category described meets the bias and correction factor requirements; and
- The method as tested is sufficiently robust to allow testing at sources similar to the source tested in this study where the stack gas moisture is less than 1% by volume, the stack temperature is less than 30 degrees C and the presence of other compounds that may interfere with the analysis are minimal.

Recommendations for future testing and validation of the method for the sampling and analysis of isocyanates include the following:

- Identify a source for testing that has more than one isocyanate present in the stack gas;
- Spike as many of the four CAAA target isocyanates as possible into the train before sampling in order to gain as much information as possible from the field test; and

- Design the condenser between the first and second impinger of the train to more efficiently reduce the loss of toluene from the first impinger and minimize compound breakthrough due entrained aerosols.

3.0

FIELD TEST

The objective of this program was to perform a field test to establish the bias and precision of a sampling and analytical method for isocyanate compounds listed in Title III of the Clean Air Act Amendments of 1990. The method evaluation in this test series resulted from extensive literature reviews, industry consultation and laboratory development. To achieve the test objective, an industrial source with known emissions of TDI was selected as a field test site. Factors in the site selection were easy access, ample space for the quadruple sampling trains and proximity to Radian's office and laboratory in Research Triangle Park, North Carolina.

3.1

Site Description

The field validation test was performed at a flexible foam production plant located in High Point, North Carolina. In the manufacturing process starting materials (TDI, water, a polyether resin, methylene chloride, an amine catalyst, and coloring additives) are blended and continuously fed onto a conveyer belt. The TDI reacts with water and releases CO_2 , which causes foaming in the resin material. Dichloromethane (DCM) can be added as a supplemental "blowing" or foaming agent. The heat from the reaction of TDI and water causes the DCM to vaporize, resulting in increased foaming. The density of the foam is controlled by the amount of TDI, water and DCM added. The foaming action continues as the material proceeds down the conveyer belt. Finished product is then allowed to cure and degas for 24 to 48 hours.

3.2

Sampling Location

Figure 3-1 presents a schematic view of the sampling location. Three induced draft (ID) fans are used to exhaust TDI and DCM vapors from the production process through three separate uninsulated sheet metal ducts that extend through the roof. Two of the ducts are connected by a 30-foot horizontal duct, 34 inches in diameter, which then extends vertically to a height of 25 feet above the roof top. A 6 inch




Figure 3-1. Sample Location

diameter sampling port is located in the horizontal duct midway between vertical ducts number 2 and 3, approximately 5 feet above the roof level. The roof level is approximately 15 feet above the ground.

A recovery trailer was located on the ground immediately in front of the sampling area, allowing easy communication between the sampling crew and recovery area. Two-way radio communication between the facility production personnel and the sampling crew allowed coordination between production startup and the start of each sampling run.

3.3 Test Schedule

The recovery trailer and test equipment were mobilized on Saturday, February 20, 1993. Equipment setup took place Saturday afternoon and Sunday, and testing began Monday morning.

The sampling schedule is shown in Table 3-1. Eight runs were completed, which included two extra runs above the required minimum of six.

3.4 Sample Collection

3.4.1 Quad Probe

Sampling was performed by withdrawing stack gas from a single port in the stack through a quad probe, then directing the sampled gas simultaneously to four independently operated sampling trains. The quad probe contains four similar heated sampling probes that were inserted into the stack as one unit, as shown in Figure 3-2. The front end of the quad probe was positioned in the center of the stack and remained

Table 3-1

Test Schedule

Run	Date	Start Time	Stop Time
1	2-22-93	1215	1300
2	2-22-93	1330	1410
3	2-23-93	0945	1085
4	2-23-93	1335	1415
5	2-24-93	1010	1110
6	2-24-93	1335	1420
7	2-25-93	1215	1255
8	2-25-93	1315	1355




Figure 3-2. Schematic of Quad Train Setup

in that location during each test. The stack was not traversed nor were stack gas velocity measurements made, because determination of the true concentration and emission rate of the target compound in the stack gas was not required to meet the objectives of this program.

Method 301 of 40 CFR Part 63 describes field validation procedures and details the criteria for the quadruple sampling probe tip arrangement. This method requires the inside edge of sampling probe tips to be situated in a 6.0 cm x 6.0 cm square area. The area encompassed by the probe tip arrangement should occupy less than 5% of the stack cross-sectional area. The cross-sectional area of the probe tip arrangement used in this test was 5.8 square inches as measured from the probe/nozzle centerlines. This area is less than 1% of the stack cross-sectional area of 908 square inches, which satisfies the Method 301 criterion.

3.4.2 Quad-Train Assembly

Four independent sampling trains made up the quad-train assembly. Although four meter boxes were required, the velocity head (ΔP) was determined using only one set of pitot tubes. The sampling trains were identified as Train A, B, C, and D. Two of the four trains were spiked before each run. The spiking compound was added to the first impinger of these trains in the field for bias determination. The sampling train test matrix is given in Table 3-2.

3.5 Sampling Preparation

3.5.1 Glassware Preparation

All glassware used for sampling was thoroughly cleaned prior to use. This included the probe, impingers, all sample bottles and all utensils used during sample recovery. All glassware was washed with hot soapy water, rinsed with hot tap water, rinsed with distilled water and baked in a oven at 300 °C for four hours. The glassware

Table 3-2

Sampling Train Test Matrix

Run #	Train Designation	
	Spiked	Unspiked
1	A, B	C, D
2	C, D	A, B
3	A, B	C, D
4	C, D	A, B
5	A, B	C, D
6	C, D	A, B
7	A, B	C, D
8	C, D	A, B

was then triple-rinsed with HPLC grade acetonitrile, followed by triple-rinsing with HPLC grade toluene. Open ends of glassware were covered with aluminum foil to minimize potential contamination during transportation and set-up.

3.5.2 Preparation of Impinger Absorbing Solution

Historical data available from the host test site facility and data resulting from the collection of preliminary samples by Radian indicated that the concentration of TDI in the process exhaust was 1 ppm or less, depending on the density of foam being produced on any given day. At this concentration, a 30 cubic foot sample size would result in the collection of approximately 7 mg of TDI. Using the reaction stoichiometry of two moles of 1,2-PP per mole of TDI, the piperazine in toluene solution was then prepared at a concentration level three times the calculated minimum needed, or 133 $\mu\text{g/mL}$. This would provide a total of approximately 40 mg of 1,2-PP in 300 mL of impinger solution in the first impinger available for reaction with TDI. At this concentration, approximately 22 mg of TDI could be collected in the first impinger before the reagent was exhausted. This solution was prepared in the laboratory just prior to use in the field, and was used within 10 days of preparation.

3.5.3 Preparation of TDI Spiking Solution

The TDI spiking solution was prepared at a concentration of 1.5 mg of the derivatized TDI per 1 mL of acetonitrile. Fifteen mL of this spiking solution was spiked into the first impinger of two of the four trains prior to each QUAD run. This spiking scheme resulted in a total spike amount of derivatized TDI of 22.5 mg, which is equivalent to 7.83 mg of underivatized TDI. This is an amount equivalent to the amount of TDI expected to be collected in the train from the stack gas based on presurvey samples. Therefore, the amount present in the two spiked trains was designed to be at least twice the amount present in the two unspiked trains.

3.5.4 Sampling Equipment Preparation

Final sampling train preparations included calibration and leak checking of all the train equipment, including meter boxes, thermocouples, nozzles, pitot tubes, and umbilicals. Reference calibration procedures were followed when available, and the results were properly documented and archived. If a referenced calibration technique for a particular piece of apparatus was not available, then a state-of-the-art technique was used. A discussion of the techniques used to calibrate this equipment is presented below.

S-Type Pitot Tube Calibration

The EPA has specified guidelines concerning the construction and geometry of an acceptable S-Type pitot tube. If the specified design and construction guidelines are met, a pitot tube coefficient of 0.84 can be used. Information pertaining to the design and construction of the Type-S pitot tube is presented in detail in Section 4.1.1 of EPA Document 600/4-77027b. Only S-Type pitot tubes meeting the required EPA specifications were used. Pitot tubes were inspected and documented as meeting EPA specifications prior to field sampling.

Sampling Nozzle Calibration

Glass nozzles were used for sampling. All nozzles were thoroughly cleaned, visually inspected for damage, and calibrated according to the procedure outlined in Section 4.4.2 of EPA Document 600/4-77-027b.

Dry Gas Meter Calibration

Dry gas meters (DGMs) were used in the sample trains to measure the sample volume and sampling rate. All DGMs were calibrated to document the volume correction factor prior to the departure of the equipment to the field. Post-test

calibration checks were performed after the equipment was returned to Radian's laboratory. Pre- and post-test calibrations agreed to within 5 percent.

Prior to calibration, a positive pressure leak check of the system was performed using the procedure outlined in Section 4.3.2 of EPA Document 600/4-77-23b. The system was placed under approximately 10 inches of water pressure and an oil manometer was used to determine if the pressure decreased over a one-minute period.

After the sampling console was assembled and leak checked, the pump was allowed to run for 15 minutes to allow the pump and DGM to warm up. The valve was then adjusted to obtain the desired flow rate. For the pre-test calibrations, data were collected at the orifice manometer settings (ΔH) of 0.5, 1.0, 1.5, 2.0, 3.0, and 4.0 inches of water. Gas volumes of 5 ft³ were used for the two lower orifice settings, and volumes of 10 ft³ were used for the higher settings. The individual gas meter correction factors (γ_i) were calculated for each orifice setting and averaged. The method requires that each of the individual correction factors fall within $\pm 2\%$ of the average correction factor or the meter must be cleaned, adjusted, and recalibrated. In addition, Radian requires that the average correction factor be 1.00 ± 1 percent. For the post-test calibration, the meter was calibrated three times at the average orifice setting and vacuum which were used during the actual test.

Dry gas meter calibrations were performed at Radian's laboratory using an American® wet test meter as an intermediate standard. The intermediate standard is calibrated every six months against the EPA spirometer at EPA's Emission Measurement Laboratory in Research Triangle Park (RTP), North Carolina.

3.5.5 Sampling Operations

Vent gas samples were collected isokinetically from a single sampling point located in the center of the duct. Preliminary information about the stack gas velocity useful in selecting nozzle size and calculating the K-factor was obtained during the

pre-site survey. Prior to testing, a leak check of pitot lines was performed according to EPA Method 2. Oxygen (O₂) and carbon dioxide (CO₂) concentrations were ambient levels as determined by EPA Method 3. The stack gas moisture data was measured by the host facility as the relative humidity.

Preparation of Sampling Train

The four sampling trains for each QUAD run were charged and assembled in the recovery trailer. The impinger buckets were marked as Train A, B, C, or D. Tared impingers were used. Approximately 300 mL of the absorbing reagent was transferred to the first impinger and 200 mL to the second impinger. The first impinger of each train was of a Greenburg-Smith design and all remaining impingers were of the modified Greenburg-Smith design. The third impinger was empty, 200 to 300 g of silica gel was placed in the fourth impinger and 400 g of charcoal was placed in the fifth impinger. A water jacketed condenser was placed between the outlet of the first impinger and the inlet to the second impinger to promote cooling and minimize evaporative losses of toluene from the first impinger. Fifteen (15) mL of the spiking solution was pipetted into the first impinger of Trains A and B. Openings were covered with Teflon® film or aluminum foil after the assembly of the trains.

Final assembly of the sampling trains occurred at the sampling location. The complete train configuration is shown in Figure 3-3. Thermocouples were attached to measure the stack temperature and probe outlet and impinger outlet temperatures. Crushed ice was added to each impinger bucket, and the probe heaters were turned on and allowed to stabilize at $120^{\circ} \pm 12^{\circ}\text{C}$ ($248^{\circ} \pm 25^{\circ}\text{F}$).

The isocyanate trains were leak checked before and after each sampling run, as required in EPA Method 5. To leak check the assembled train, the nozzle end was capped off and the sampling train evacuated to a vacuum of 15 inches of Hg. After the system was evacuated and the pump isolated from the train, the volume of gas flowing through the system was timed for 60 seconds. The leak rate is required to be




Figure 3-3. Sampling Train for Isocyanate

less than 0.02 acfm or 4% of the average sampling rate, whichever is less. After the leak rate was determined, the cap was slowly removed from the nozzle end until the vacuum in the train returned to atmospheric pressure and then the pump was turned off.

The leak rates and sampling start and stop times were recorded on the sampling task log. Also, any other events that occur during sampling were recorded on the task log (such as pitot cleaning, thermocouple malfunctions, heater malfunctions, and any other unusual occurrences). A nominal sample size of 30 cubic feet was collected in all sampling train. This was accomplished by sampling at a flowrate of 0.5 cubic feet per minute for 60 minutes. The sample volumes for each train by QUAD run are presented in Table 3-3.

3.5.6 Sample Recovery

The sample bottles containing the probe and nozzle washings and the impinger portion of the sampling trains were moved to the recovery trailer.

Each impinger was carefully removed from the impinger bucket, the outside was wiped dry, and the final impinger weight was determined and recorded to calculate stack moisture. The isocyanate sample was then collected in the following two fractions:

- First impinger contents, toluene rinses from the nozzle/probe liner and toluene/acetonitrile rinses of the first impinger and connecting glassware; and
- Contents and toluene/acetonitrile rinses from the second and third impingers and the condenser.

Recovery procedures are detailed in this section. All recovery bottles were wide mouth amber glass with Teflon® lined lids.

Table 3-3.

Quad Train Sample Volumes

Date	Run Number	Train A Vm @ 68° (ft ³)	Train B Vm @ 68° (ft ³)	Train C Vm @ 68° (ft ³)	Train D Vm @ 68° (ft ³)
2/22/93	1	33.42	33.89	33.02	33.04
2/22/93	2	29.07	29.65	28.67	28.40
2/23/93	3	34.24	35.15	33.75	33.01
2/23/93	4	30.60	31.17	30.35	29.54
2/24/93	5	34.14	34.70	34.46	32.59
2/24/93	6	35.10	35.17	34.49	33.78
2/25/93	7	31.11	31.94	30.14	29.91
2/25/93	8	30.89	29.73	30.49	31.95

Container 1 - Probe and First Impinger Contents

The contents and rinses of each of the first impingers and first impinger connectors were combined with the corresponding probe/nozzle washing solution. The entire contents of the first impinger were recovered as a single sample, even if two phases were present. The first impinger and connecting tubing were rinsed three times with 15 mL aliquots of toluene. A final rinse of the impinger with acetonitrile was also necessary to remove any water left on the impinger wall and to recover any remaining derivatized TDI.

Container 2 - Second and Third Impinger Contents/Condenser Rinse

The contents and toluene/acetonitrile rinses of the second and third impingers and the condenser of each train were collected in the same manner used for the first impinger described above. The contents of these impingers were analyzed separately from the contents collected in the first impinger to check for breakthrough; therefore, care was taken to avoid physical carryover from the first impinger to the second. The contents of the fourth and fifth impingers were weighed as previously described and then discarded.

Field Blanks

Four field blanks were prepared and recovered during the test, one on each day of testing. The four field blanks were prepared using Trains A, B, C, and D from the two sets of glassware used during the testing. A sampling train was assembled in the staging area, taken to the sampling location, and leak-checked. The probe of the blank train was heated during the generation of the field blank, but no gas sample was passed through the sampling train. The sampling train for the field blank was recovered with the same procedure described for authentic source samples.

Reagent Blank(s)

Aliquots of each lot of toluene, acetonitrile and absorbing reagent were collected daily to be analyzed as reagent blanks.

Sample Storage and Shipping

Sample containers were checked to ensure that complete labels had been affixed. The labels identified Trains A, B, C, or D, as appropriate. Teflon® lids were tightened and secured with Teflon® tape. The sample bottles were stored in a cooler packed with ice and were returned to Radian's laboratory in these coolers at the end of the field test.

3.6 Quality Control

The following quality control measures were implemented during the field testing phase of this program:

- All dry gas meters were calibrated. Calibration procedures were followed for the pitot tube/probe assembly and all thermocouple readout devices.
- Temperatures of the sampling train were maintained at the specified setting ($120 \pm 12^{\circ}\text{C}$) during each sampling run at levels prescribed in the test plan.
- Sampling trains were leak-checked both prior to and after sampling.
- All glassware was washed and oven-baked following appropriate method protocol, given in the test plan.
- All recovery solvents were HPLC grade and an aliquot of each was collected daily as reagent blanks.
- One field blank was collected for every two sampling runs.

- Chain of Custody forms and log books were filled in at the completion of each day of sampling.

4.0 ANALYTICAL PROCEDURES

4.1 Sample Preparation

The samples were received in the laboratory in screw-capped glass bottles with Teflon®-lined caps, sealed with Teflon® tape and stored in coolers packed with ice. Samples were logged into the laboratory sample tracking system and stored in a secure, refrigerated (4°C) sample storage area prior to analysis. Samples were prepared for analysis within 30 days of collection and analyzed within 30 days of preparation.

All labware was washed with detergent and water and rinsed with hot tap water, rinsed with deionized water, baked at 300°C, rinsed with acetonitrile and toluene prior to use. Solvents used were HPLC grade or equivalent.

Each of the two recovered samples from each train was transferred along with rinses to separate 500 mL round bottom flasks and then evaporated to dryness under vacuum in a 65°C water bath. Each round-bottom flask was then rinsed three times with separate two (2) mL aliquots of acetonitrile (ACN) and the rinses transferred to a 10-mL volumetric flask. The sample was then brought to volume with ACN and transferred to a 15-mL vial and sealed with a Teflon®-lined lid. The vial was stored in a refrigerated sample storage area at 4°C until analysis.

4.2 Chromatographic Analyses

The procedures for the HPLC analyses of the samples are described in the following sections.

4.2.1 Standard Preparation

A 300 µg/mL stock solution of TDI piperazine urea derivative was prepared by dissolving 7.5 mg of the purified crystals of the derivatized TDI in 25 mL of

ACN. [The derivatized TDI was previously prepared by adding 1 g of the neat TDI to a solution of 1-(2-pyridyl) piperazine in ACN, evaporating to dryness and recrystallizing the urea derivative three times from ACN.] Working standards for the calibration curve were made from this stock at six concentration levels in ACN ranging from 0 to 50 $\mu\text{g/mL}$. This concentration range covered the amount of TDI expected to be collected at the host facility. This stock solution was also used to prepare the field spiking solution. A check standard was prepared from a separately prepared stock solution. This check standard fell in the middle of the calibration curve.

4.2.2 Analysis

HPLC System

The HPLC system operating parameters for analysis of standards and samples were as follows:

Instrument:	RAININ HPXL Delivery System Waters 710B WISP autosampler
Data System:	Nelson 2600 (1 volt)
Column:	Zorbax ODS (4.6 mm ID x 25 cm)
Mobile Phase:	Acetonitrile/0.1M Ammonium Acetate Buffer
Gradient:	25:75 ACN/0.1 m ammonium acetate buffer, pH 6.2, hold 2 minutes, then to 60:40 by 19.5 minutes.
Detector:	RAININ Dynamax Dual-Wavelength, Ultraviolet at 254 nm
Flow Rate:	2 mL/min
Injector Volume:	50 μL
Retention Time:	2,4-TDI, 10.2 min.; 2,6-TDI 8.5 min.

Instrument Calibration

Calibration standards were prepared at seven levels as described in Section 4.2.1. Each calibration standard was injected in duplicate. Linear regression analysis of peak area response versus concentrations of TDI was used to prepare a calibration curve. Linearity of the calibration curve was confirmed by visual inspection and verified by a correlation coefficient of 0.9995. After an initial calibration curve was obtained, the calibration check standard described in Section 4.2.1 was analyzed. This standard was injected after every 3 samples, and was used for daily calibration. This check standard consistently agreed to within 10% of the true value.

All samples were analyzed in triplicate on the HPLC. An acetonitrile blank was analyzed once per day to ensure that the system was not contaminated. A check standard was analyzed prior to sample analysis, after every 3 samples, and at the end of the sample analysis each day.

4.3 Qualitative Identification

Analytes were identified by retention time. The retention time for 2,4-TDI was 10.2 min and 8.5 min for 2,6-TDI. Figures 4-1 and 4-2 show chromatograms from the analysis of first impinger contents from QUAD run number 4 for the unspiked and spiked trains respectively. As seen in the chromatograms, the TDI peaks are well separated from the peak for unreacted 1-2 PP. The peak at 17.5 min. was not identified.

4.4 Calculations

4.4.1 Calculation of the Amount of Isocyanate Collected

A least squares linear regression analysis of the calibration data was used to calculate a correlation coefficient, slope, and intercept. Concentration was used as the independent or X-variable and response was used as the dependent or Y-variable.

Unspiked Train
Quad Run Number 4




Figure 4-1. Chromatogram of Unspiked Train




Figure 4-2. Chromatogram of Spiked Train
J-64

The concentration of isocyanate (as the derivative) in the concentrated samples was then calculated as follows:

$$\text{Concentration} = \frac{(\text{Sample Response} - \text{Intercept})}{\text{Slope}} \quad 4-1$$

The total amount (μg) collected in a sample was then calculated by multiplying the concentration ($\mu\text{g/mL}$) times the final volume (10 mL) of ACN used to redissolve the concentrated sample.

$$\text{Amount TDI derivative} = \text{Concentration } (\mu\text{g/mL}) \times \text{Final Volume (10 mL)} \quad 4-2$$

The equivalent amount of TDI required to generate this much derivative was calculated by multiplying the ratio of the molecular weights of TDI (174) and the TDI derivative (501) times the amount of TDI derivative (determined by using equation 4-2).

The total amount of 2,4-TDI (underivatized) collected in the unspiked and spiked trains is given in Table 4-1 and Table 4-2 respectively.

4.4.2 Normalization of the Amount of Isocyanate Collected

In order to simplify the comparison of the analytical results of the four trains in each QUAD run for subsequent calculations of bias and precision, the test plan called for the collected of 30 ft³ of sample in each train. Due to operational variabilities inherent to each train, accurate but slightly differing sample volumes resulted as shown in Table 3-3. Therefore, it was necessary to normalize the data presented in Tables 4-1 and 4-2 to a common sample volume. The sample volume to which all data were normalized was selected to be 35.31 ft³ which is equivalent to 1m³. The following stepwise calculations were used to normalize the data. The data from QUAD run number 1 are used as an example.

SENT BY:


0-21-01 0-0/MS

0-0/MS

0-0/MS

Data File = E:\S3253F6.PTS Printed on 09-10-1993 at 12:29:41
Start time: 0.00 min. Stop time: 20.00 min. Offset: 0 cts
Full Range: 50 K-Counts

Preliminary Data



Prelim Rin # I

Impinge 1

*Radiar
13 checks
10*

below in file

SEMI DI:


07-21-03 7 0-01:00

00:00:00

00:00:00

Areas, times, and heights stored in: E:\S3253F7.ATB
Data File = E:\S3253F7.PTS Printed on 09-10-1993 at 13:01:05
Start time: 0.00 min. Stop time: 20.00 min. Offset: 0 cts
Full Range: 50 K-Counts


Preliminary Data



SENT BY: 07-100 7-0-0/100 07-100 7-0-0/100
Data File = E:\S3256F7.PTS Printed on 09-13-1993 at 14:43:55
Start time: 0.00 min. Stop time: 20.00 min. Offset: 0 ota
Full Range: 50 K-Counts

Preliminary Data

Toluene Blank



*Unknown
Impurity*

SENT BY: Data File: 2:1532507 1.1 10 3-21-03 0-0/415 0.00 min. Stop time: 20.00 min. Offset: 0 cts
Full Range: 50 K-Counts

110050120107 0 0

Preliminary Data

Quantitative Standard
23 ug each




Table 4-1

2,4-TDI Detected in Unspiked Trains, μg

Train ¹	QUAD Run No.											
	1			2			3			4		
	Imp 1	Imp 2	Total	Imp 1	Imp 2	Total	Imp 1	Imp 2	Total	Imp 1	Imp 2	Total
A	--	--	--	5114	61	5175	--	--	--	1832	16	1848
B	--	--	--	5224	40	5264	--	--	--	1864	24	1888
C	4409 ²	18	4427	--	--	--	3281	32	3313	--	--	--
D	4416	85	4501	--	--	--	2928	33	2960	--	--	--

¹The unspiked trains alternated from run to run, C and D then A and B.

²All values are in micrograms of underivatized TDI.

Table 4-1 (Continued)

Train ^t	QUAD Run No.											
	5			6			7			8		
	Imp 1	Imp 2	Total	Imp 1	Imp 2	Total	Imp 1	Imp 2	Total	Imp 1	Imp 2	Total
A	--	--	--	7880	105	7993	--	--	--	3521	53	3574
B	--	--	--	7488	89	7577	--	--	--	3805	50	3855
C	4810	17	4827	--	--	--	2160	23	2183	--	--	--
D	5054	42	5096	--	--	--	2180	36	2216	--	--	--

The unspiked trains alternated from run to run, C and D then A and B.

²All values are in micrograms of underivatized TDI.

Table 4-2
2,4-TDI Detected in Spiked Trains, µg

Train ¹	QUAD Run No.									
	1			2			3			4
	Imp 1	Imp 2	Total	Imp 1	Imp 2	Total	Imp 1	Imp 2	Total	Imp 1
A	11943 ²	64	12007	--	--	--	11488	36	11524	--
B	11301	28	11329	--	--	--	12024	38	12062	--
C	--	--	--	12045	35	12080	--	--	--	9329
D	--	--	--	12454	49	12503	--	--	--	9429
										9387
										9455

¹The spiked trains alternated from run to run, A and B then C and D.

²All values are in micrograms of underivatized TDI.

Table 4-2 (Continued)

Train ¹	QUAD Run No.											
	5			6			7			8		
	Imp 1	Imp 2	Total	Imp 1	Imp 2	Total	Imp 1	Imp 2	Total	Imp 1	Imp 2	Total
A	12014	45	12059	--	--	--	10094	46	10140	--	--	--
B	12588	37	12625	--	--	--	9003	40	9043	--	--	--
C	--	--	--	15201	88	15289	--	--	--	10561	45	10606
D	--	--	--	15173	96	15269	--	--	--	10315	44	10359

¹The spiked trains alternated from run to run, A and B then C and D.

²All values are in micrograms of underivatized TDI.

Step 1 Normalize unspiked Trains C and D first impinger amounts (μg) to the sample volume collected (cubic feet) in spiked Train A;

$$\text{Train C} \quad \frac{33.42 \text{ ft}^3}{33.02 \text{ ft}^3} \times 4409 \mu\text{g} = 4462 \mu\text{g} \quad 4-3A$$

$$\text{Train D} \quad \frac{33.42 \text{ ft}^3}{33.04 \text{ ft}^3} \times 4416 \mu\text{g} = 4467 \mu\text{g} \quad 4-3B$$

Step 2 Average the normalized, unspiked train amounts from step 1 above. Assuming the collection efficiency of all trains to be the same, this value would also be the amount of TDI that would be collected by Train A due to sampling the stack gas;

$$\frac{4462 \mu\text{g} + 4467 \mu\text{g}}{2} = 4465 \mu\text{g} \quad 4-4$$

Step 3 Subtract the average value (step 2) from the uncorrected amount (sampled amount plus spike) for spiked Train A, first impinger, to get recovered spike amount;

$$11943 \mu\text{g} - 4465 \mu\text{g} = 7478 \mu\text{g} \quad 4-5$$

Step 4 Normalize the amount collected in spiked Train A, first impinger to 35.31 ft^3 using the sample volume for Train A and the value obtained in step 2;

$$\frac{35.31 \text{ ft}^3}{33.42 \text{ ft}^3} \times 4465 \mu\text{g} = 4718 \mu\text{g} \quad 4-6$$

Step 5 Normalize the amount collected in the second impinger of spiked Train A to 35.31 ft^3 using the sample volume for Train A and the amount determined by HPLC;

$$\frac{35.31 \text{ ft}^3}{33.42 \text{ ft}^3} \times 63.9 \text{ } \mu\text{g} = 67.5 \text{ } \mu\text{g} \quad 4-7$$

Step 6 Sum the values determined from steps 3, 4 and 5 to get the total amount of TDI found in spiked Train A, normalized to 35.31 ft³;

$$7478 \text{ } \mu\text{g} + 4718 \text{ } \mu\text{g} + 67.5 \text{ } \mu\text{g} = 12264 \text{ } \mu\text{g} \quad 4-8$$

Steps 1-6 can be repeated for similar calculations for spiked Train B. The total amount of TDI collected in each of the unspiked trains can be determined by first normalizing the amounts found in the two impingers of each train to 1m³ and then summing the two values. The raw and normalized data for all analysis results are presented in Appendix A. The resulting normalized values are summarized in Tables 4-3 and 4-4.

4.5 Quality Control

Quality control procedures that were implemented for this program include:

- Adhering to applicable sampling and analysis protocols;
- Collecting and analyzing field blanks, trip blanks, reagent blanks, and laboratory blanks;
- Tracking samples from collection to analysis;
- Calibrating all analytical equipment prior to use;
- Maintaining accurate and complete written documentation;
- If any changes were made to the analytical system (i.e., column changed, column maintenance), a calibration check was performed to verify the validity of the calibration curve. If the calibration check did not meet acceptance criteria, the analytical system was recalibrated.

Table 4-3

Normalized Amount of 2,4-TDI Detected in Unspiked Trains, μg

Train ¹	QUAD Run No.							
	1	2	3	4	5	6	7	8
A	--	6287	--	2132	--	8042	--	4086
B	--	6270	--	2139	--	7608	--	4579
C	4735 ²	--	3466	--	4947	--	2557	--
D	4811	--	3166	--	5522	--	2616	--

¹The unspiked trains alternated from run to run, C and D then A and B.

²All values are in micrograms of underivatized TDI, normalized to a sample volume of 35.31 ft³ (1m³).

Table 4-4

Normalized Amount of 2,4-TDI Detected in Spiked Trains, μg

Train ¹	QUAD Run No.							
	1	2	3	4	5	6	7	8
A	12264 ²	--	11625	--	12233	--	10450	--
B	11520	--	12078	--	12717	--	9290	--
C	--	13258	--	9694	--	15471	--	11197
D	--	13733	--	9805	--	15610	--	10947

¹The spiked trains alternated from run to run, A and B then C and D.

²All values are in micrograms of underivatized TDI, normalized to a sample volume of 35.31 ft³ (1m³).

- Analysis of field spiked QC samples; and
- Analysis of check standards every 3 samples.

This section presents the results of the eight sampling runs relative to the criteria for method precision and bias. Fractional results are also presented to show the amount of isocyanate breakthrough occurring in the impinger train. All sample fractions were prepared and analyzed for toluene diisocyanate at Radian's Research Triangle Park laboratory.

5.1

Bias and Precision

Table 5-1 is a summary table which presents the results of the statistical evaluation of the test data following the EPA Method 301 criteria showing the method precision and bias for 2-4 TDI. Method 301 requires valid data from a minimum of six QUAD runs. Table 5-1 presents data from all eight runs. Precision is shown as the percent relative standard deviation of the measured amounts of TDI in the samples. Results for precision of both the spiked and unspiked samples were less than 5 percent RSD, which is well within the limits of acceptable precision (upper limit of 50%) given in EPA Method 301.

Using the data from all eight QUAD runs, method bias was measured at -395 micrograms. This value was determined to be statistically significant at the 95% confidence level, using the t statistic calculated for the analytical data. A correction factor of 1.053 was calculated for use with the method to compensate for the bias should the method be used to measure TDI emissions from similar sources.

Using the data from only seven QUAD runs (eliminating run 8 because this run had the lowest average % recovery and the final leak check for one of the trains was questionable), the method bias was -295 micrograms. This bias was not statistically significant and therefore no correction factor was calculated. In either case, the criteria for an acceptable method were met (i.e., a correction factor between 0.7 and 1.3).

Table 5-1

Summary of Method 301 Statistical Calculations

Parameter	Spiked Trains		Unspiked Trains	
	7 Runs	8 Runs	7 Runs	8 Runs
Spiked Amount ¹	7828	7828	--	--
RSD, %	3.6	3.4	4.7	5.2
Average Bias ¹	-295	-395	--	--
Bias Significant?	No	Yes	--	--
Correction Factor	1.0	1.053	--	--

¹Values are presented as μg of underivatized TDI

This section presents details of the breakthrough and recovery results for the field samples, as well as recovery information for the spiked compound (2,4-TDI).

5.2.1

Breakthrough

Tables 4-1 and 4-2 provide a summary of the combined total mass of 2,4-TDI collected in the probe/first impinger and second/third impinger samples for the unspiked and spiked trains, respectively. These totals are used as a basis for calculating breakthrough of the TDI from the first impinger to the second impinger. The mass of compound found in the probe/first impinger fraction and in the second impinger fraction were each divided by the total mass of TDI for that train and then multiplied by 100 to yield the percent of the total TDI found in the separate train sections. The results are presented in Table 5-2 and 5-3 for the spiked and unspiked trains respectively.

The average breakthrough for the spiked trains was 1.5% and for the unspiked trains 1.1%. More than 98% of the TDI was collected in the first impinger under the sampling conditions used in this study.

The amount of the toluene contained in the first impingers of each of the trains was reduced by approximately 25% (by weight) during the sampling run due to evaporation. The second impingers showed, on the average, a net gain of approximately 5%. The remainder was collected in the silica gel and the charcoal, both of which showed net weight gains. The total weight gained in the train components following the first impinger more than compensate for losses from the first impinger, probably due to the collection of a small amount of moisture. The loss of toluene from the first impinger was minimized by keeping the impingers in an ice bath and placing a water cooled condenser between the outlet of the first impinger and the inlet of the second impinger.

Table 5-2

Distribution of 2,4-TDI Within the Spiked Trains

Train ¹	Impinger No.	QUAD Run No.							
		1	2	3	4	5	6	7	8
A	1	98.5 ²	--	99.0	--	99.0	--	98.0	--
	2	1.5	--	1.0	--	1.0	--	2.0	--
B	1	99.2	--	99.1	--	99.2	--	97.0	--
	2	0.8	--	0.9	--	0.8	--	3.0	--
C	1	--	99.2	--	96.4	--	98.8	--	98.4
	2	--	0.8	--	3.6	--	1.2	--	1.6
D	1	--	99.0	--	98.5	--	98.7	--	98.4
	2	--	1.0	--	1.5	--	1.3	--	1.6
Average/ % RSD	1	98.5/0.81							
	2	1.5/54.4							

¹Spiked Trains alternate from run to run, A and B, then C and D.²Values are a percentage of the total amount of 2-4 TDI determined to be in each train.

Table 5-3
Distribution of 2,4-TDI Within the Unspiked Trains

Train ¹	Impinger No.	QUAD Run No.							
		1	2	3	4	5	6	7	8
A	1	--	98.8	--	99.1	--	98.7	--	98.5
	2	--	1.2	--	0.9	--	1.3	--	1.5
B	1	--	99.2	--	98.8	--	98.8	--	98.7
	2	--	0.8	--	1.2	--	1.2	--	1.3
C	1	99.6 ²	--	99.0	--	99.6	--	99.0	--
	2	0.4	--	1.0	--	0.4	--	1.0	--
D	1	99.1	--	98.9	--	99.2	--	98.4	--
	2	1.9	--	1.1	--	0.8	--	1.6	--
Average/ % RSD	1	98.9/0.41							
	2	1.1/37.1							

¹Unspiked Trains alternate from run to run, C and D, then A and B.

²Values are a percentage of the total amount of 2,4-TDI determined to be in each train.

One of the objectives of this test program was to obtain bias and precision data to validate the proposed test method for isocyanates. Samples from two of the four trains of each quad assembly were spiked with TDI before each sampling run. The estimation of method bias is based on the percentage of the TDI spikes recovered. Analytical results used for this calculation are the averages of the triplicate analysis results for each spiked sample. A summary of the spiked TDI recovery percentages is presented in Table 5-4.

The percent recovery was calculated for each spiked train for each run following the calculation procedures outlined in steps 1-3 of Section 5.0. The value obtained at step 3, the amount of spike recovered, is divided by the actual amount of TDI spiked, 7827 μg , multiplied by 100. An average recovery was determined by averaging the 16 individual run recoveries.

The recovery for TDI ranged between 83 and 112 percent and averaged 95 percent with a %RSD of 8.2.

Quality Assurance/Quality Control

As a part of the testing for Work Assignment No. 55, Radian designed and implemented a quality assurance/quality control (QA/QC) effort tailored to meet the specific needs of this project. The testing was conducted in accordance with QA/QC procedures described in the Quality Assurance Project Plan (QAPP). The results of the QA/QC effort demonstrate that the data are reliable and meet project objectives for completeness and representativeness. The data met the QA objectives for precision and accuracy and there are no data quality issues that effect conclusions regarding the objectives of this project.

Table 5-4

Percent Recovery of the Spiked 2,4-TDI

Train ¹	QUAD Run No.							
	1	2	3	4	5	6	7	8
A	96 ²	--	106	--	89	--	100	--
B	86	--	112	--	96	--	86	--
C	--	89	--	97	--	98	--	88
D	--	95	--	98	--	99	--	83
Average	95							
% RSD	8.2							

¹Spiked Trains alternated from run to run, A and B, then C and D.

²Values are a percentage based upon a spiked amount of 7827.8 µg as 2,4-TDI.

The primary objectives of the QA/QC effort were to control, assess, and document data quality. In order to accomplish these objectives, the QA/QC approach consisted of the following key elements:

- Definition of data quality objectives that reflect the overall technical objectives of the project;
- Design of a sampling, analytical, QA/QC, and data analysis system to meet these objectives; and
- Initiation of corrective action when measurement system performance did not meet the specifications.

These elements include the use of selected standard sampling and analytical procedures as components of the overall approach in addition to, specified calibration requirements, QC checks, data reduction and validation procedures, and sample tracking.

A summary of analysis results for QA/QC samples, which includes measures of precision and accuracy and limitations in the use of these data is presented in this section.

5.3.1 Overview of Data Quality

The QAPjP established specific QA objectives for precision (15% RSD), accuracy ($\pm 30\%$), and completeness (100%) for the determination of TDI emissions. The statistical results presented in Table 5-1 and the % recovery values given in Table 5-4 show that the objectives were met. The data quality acceptance criteria and the experimental results are summarized in Table 5-5. Results for spike/spike duplicates and triplicate analyses were compared with the criteria. In all cases the criteria were met. Other data quality indicators for each type of analysis are also presented throughout the remainder of Section 5.3.

There are no cases where data quality issues impair the study's conclusions with respect to the validity of the sampling and analytical test method procedures. With

Table 5-5**Data Quality Acceptance Criteria and Results**

Parameter	Criteria	Results
TDI Spike Recovery	70 - 130%	83 - 112%
TDI Analysis Results QUAD Train, % RSD	15%	5%
Individual DGM Correction Factor Agreement	$\pm 2\%$ of Avg	$< 2\%$
Analytical Balance	≤ 0.1 g of Class S Weights	< 0.1 g
HPLC Linearity Correlation Coeff.	> 0.995	0.9995
HPLC Retention Time Variation	$\pm 15\%$	$\pm 10\%$
HPLC Calibration Check	$\pm 10\%$ of Curve	$\pm 9\%$
HPLC System Blank	$< 0.1\%$ Analyte level	$< 0.1\%$
HPLC Replicate Analyses	$\pm 10\%$ of 1st injection	$\pm 2\%$
HPLC Method Spikes	$\pm 20\%$ of theoretical	$\pm 5\%$

exception of a limited number of samples, the quality of measurement data generated for the test parameters fully meets the data quality objectives outlined in the QAPjP.

5.3.2 Sampling Quality Control

Quality control activities associated with the field sampling are described in the QAPjP. These activities include adherence to accepted reference method protocols, use of standardized data recording sheets, equipment calibration, and collection of field blanks.

Stack sampling QC data, including sampling rates, sample volume collected, maximum recorded leak rate, and maximum allowable leak rate, are summarized in Table 5-6 for each run. All of the data quality indicators are within acceptable limits, with the exception of a slightly high leak rate value for Train C Run 8. However, this train was leak checked at a vacuum of 7 inches of mercury which was almost twice that achieved during sampling and the leak would therefore have very little, if any, effect on the data. The leak rate criterion is $<4\%$ of the average sampling rate or 0.02 dscf, whichever is less.

5.3.3 Sample Storage and Holding Time

Sample hold times specified in the QAPP were met for all samples. All samples were prepared within 30 days of collection and analyzed within 30 days of preparation.

5.3.4 Analytical Quality Control

Results for method spikes, field spikes, field blanks, reagent blanks and method blanks are summarized in Table 5-7. These samples served the dual purpose of controlling and assessing measurement data quality, and providing the basis for precision and accuracy estimates. The QC acceptance criteria for each of these types of samples

Table 5-6

Sampling Train Leak Summary

Run Number	Std. Metered Volume (dscf)	Average Sampling Rate (dscfm)	Maximum Leak Check (dscf @ in Hg)	4% Sample Rate (dscfm)	Acceptable ^a Leak Rate?
1A	33.42	0.743	0.010 @ 10	0.030	Yes
1B	33.89	0.753	0.010 @ 15	0.030	Yes
1C	33.02	0.734	0.010 @ 8	0.029	Yes
1D	33.04	0.734	0.020 @ 10	0.029	Yes
2A	29.07	0.727	0.016 @ 8	0.029	Yes
2B	29.65	0.741	0.009 @ 8	0.030	Yes
2C	28.67	0.717	0.010 @ 7	0.029	Yes
2D	28.40	0.710	0.010 @ 8	0.028	Yes
3A	34.24	0.571	0.012 @ 10	0.023	Yes
3B	35.15	0.586	0.010 @ 8	0.023	Yes
3C	33.75	0.563	0.009 @ 8	0.023	Yes
3D	33.01	0.550	0.020 @ 5	0.022	Yes
4A	30.60	0.765	0.012 @ 8	0.031	Yes
4B	31.17	0.779	0.012 @ 7	0.031	Yes
4C	30.35	0.759	0.008 @ 7	0.030	Yes
4D	29.54	0.739	0.015 @ 10	0.030	Yes
5A	34.14	0.569	0.014 @ 10	0.023	Yes
5B	34.70	0.578	0.012 @ 8	0.023	Yes
5C	34.46	0.574	0.012 @ 8	0.023	Yes
5D	32.59	0.543	0.016 @ 7	0.022	Yes
6A	35.10	0.780	0.007 @ 7	0.031	Yes
6B	35.17	0.782	0.010 @ 8	0.031	Yes
6C	34.49	0.766	0.008 @ 7	0.031	Yes
6D	33.78	0.751	0.008 @ 10	0.030	Yes
7A	31.11	0.778	0.015 @ 9	0.031	Yes
7B	31.94	0.799	0.011 @ 8	0.032	Yes
7C	30.14	0.754	0.009 @ 7	0.030	Yes
7D	29.91	0.748	0.014 @ 10	0.030	Yes
8A	30.89	0.772	0.009 @ 10	0.031	Yes
8B	29.73	0.743	0.011 @ 8	0.030	Yes
8C	30.49	0.762	0.021 @ 7	0.030	No
8D	31.95	0.799	0.018 @ 8	0.032	Yes

^aThe maximum acceptable leak rate is the lesser of 0.020 dscfm or 4% of the average sampling rate.

Table 5-7

Summary of Analytical Quality Control Results

Sample ID	Total Detected μg	Theoretical μg	Percent Error %
Field Blank A	2.5	NA ⁴	NA
Field Blank B	8.3	NA	NA
Field Blank C	6.4	NA	NA
Field Spike 1	7570	7828	96.7
Field Spike 2	7686	7828	98.2
Method Spike 1	8120	7828	104
Method Spike 2	7838	7828	100
Method Spike 3	7890	7828	101
Method Spike 4	7945	7828	101
Toluene Reagent Blank ¹	0.5	NA	NA
ACN Reagent Blank ²	0.4	NA	NA
Method Blank ³	10.2	NA	NA

¹Average of four, ranging from 0.1 to 1.2 μg

²Average of four, ranging from 0.1 to 0.8 μg

³Average of three, ranging from 0.3 to 20.7 μg

⁴NA, Not Applicable

were met as shown in Table 5-5. Field blanks were collected by assembling a sampling train as if to collect a sample, transporting to the sampling location, leak checking and returning the train to the onsite laboratory for recovery. Field spikes and method spikes were prepared by spiking approximately 300 mL of the toluene 1,2-PP solution with 15 mL of the field spiking solution. Method and reagent blanks were prepared by evaporating approximately 300 mL of solvent to dryness and dissolving any residue with 10 mL of ACN. All spikes and blanks met the data acceptance criteria listed in Table 5-5.

No blank contamination problems were identified during the analysis of field and laboratory blanks and no blank corrections were performed for the reported data. All blank analysis data are presented along with other QC and field sample results in Appendix A.

APPENDIX A

Analytical Data for Samples, Blanks, Spikes and Quality Control Samples

Sample Name	AREA	AMOUNT ug/mL	QC Con ug/mL	QC Bias %	Dilution Factor	Amount Sample ug	Avg Amt Sample ug	Volume Sampled Cu ft	Sampling Factor	Adjusted Avg ug	Total Train ug	Amount Spiked ug	Spike Recovery %	Train ID
ISO-SCF-32293-4	1263013	5.90	5.40641	9%										
ISO-SCF-32293-4	1253783	5.86	5.40641	8%										
ISO-SCF-32293-4	1249399	5.84	5.40641	8%										
ARL-1	1277072	5.97			2000	11931.6	11942.9	33.42	1.05669	12196.0	12263.5	7827.81	95.69%	I-A-1
ARL-1	1276918	5.97			2000	11930.1								
ARL-1	1280852	5.98			2000	11966.8								
ARL-2	135291	0.64			100	64.1	63.9	33.42	1.05669	67.5				I-A-2
ARL-2	135913	0.64			100	64.4								
ARL-2	133152	0.63			100	63.1								
ARL-3	1196354	5.59			2000	11178.7	11300.8	33.89	1.04204	11491.1	11520.1	7827.81	86.19%	I-B-1
ARL-3	1214532	5.67			2000	11348.3								
ARL-3	1217429	5.69			2000	11375.3								
ARL-4	59159	0.29			100	28.6	27.8	33.89	1.04204	29.0				I-B-2
ARL-4	57134	0.28			100	27.7								
ARL-4	56201	0.27			100	27.2								
ISO-SCF-32293-4	1255771	5.87	5.40641	9%										
ISO-SCF-32293-4	1251918	5.85	5.40641	8%										
ISO-SCF-32293-4	1242330	5.80	5.40641	7%										
ARL-5	471546	2.21			2000	4418.4	4409.3	33.02	1.06949	4715.7	4735.0			I-C-1
ARL-5	470785	2.21			2000	4411.3								
ARL-5	469380	2.20			2000	4398.2								
ARL-6	35898	0.18			100	17.8	18.1	33.02	1.06949	19.3				I-C-2
ARL-6	37029	0.18			100	18.3								
ARL-6	36906	0.18			100	18.2								
ARL-7	469526	2.20			2000	4399.5	4416.1	33.04	1.06885	4720.1	4811.1			I-D-1
ARL-7	461467	2.16			2000	4324.4								
ARL-7	482909	2.26			2000	4524.4								
ARL-8	180144	0.85			100	85.0	85.1	33.04	1.06885	90.9				I-D-2
ARL-8	179633	0.85			100	84.8								
ARL-8	181047	0.85			100	85.4								
ISO-SCF-32293-4	1238919	5.79	5.40641	7%										
ISO-SCF-32293-4	1245039	5.82	5.40641	8%										
ISO-SCF-32293-4	1235673	5.77	5.40641	7%										

Sample Name	AREA	AMOUNT ug/mL	QC Con ug/mL	QC Bias %	Dilution Factor	Amount Sample ug	Avg Amt Sample ug	Volume Sampled Cu Ft	Sampling Factor	Adjusted Avg ug	Total Train ug	Amount Spiked ug	Spike Recovery %	Train ID
ARL-9	544346	2.55			2000	5097.4	5114.2	29.07	1.21481	6212.9	6287.4			2-A-1
ARL-9	548157	2.57			2000	5132.9								
ARL-9	545954	2.56			2000	5112.4								
ARL-10	130306	0.62			100	61.8	61.4	29.07	1.21481	74.6				2-A-2
ARL-10	130940	0.62			100	62.1								
ARL-10	127140	0.60			100	60.3								
ARL-11	567669	2.66			2000	5314.9	5224.4	29.65	1.19105	6222.5	6269.9			2-B-1
ARL-11	561460	2.64			2000	5275.7								
ARL-11	542754	2.54			2000	5082.6								
ARL-12	83414	0.40			100	39.9	39.8	29.65	1.19105	47.4				2-B-2
ARL-12	83620	0.40			100	40.0								
ARL-12	82237	0.39			100	39.4								
ISO-SCF-32293-4	1220899	5.70	5.40641	6%	1	5.7								
ISO-SCF-32293-4	1232005	5.76	5.40641	6%	1	5.8								
ISO-SCF-32293-4	1210936	5.75	5.40641	6%	1	5.8								
ARL-13	1287864	6.02			2000	12032.2	12045.3	28.67	1.23176	13215.1	13258.2	7827.81	89.16%	2-C-1
ARL-13	1288870	6.02			2000	12011.6								
ARL-13	1291043	6.03			2000	12061.9								
ARL-14	71522	0.34			100	34.4	35.0	28.67	1.23176	43.1				2-C-2
ARL-14	73423	0.35			100	35.3								
ARL-14	73513	0.35			100	35.3								
ARL-15	1335291	6.24			2000	12474.6	12454.1	28.40	1.24347	13671.5	13732.6	7827.81	95.22%	2-D-1
ARL-15	1334709	6.23			2000	12469.2								
ARL-15	1329284	6.21			2000	12418.6								
ARL-16	103190	0.49			100	49.1	49.1	28.40	1.24347	61.1				2-D-2
ARL-16	103848	0.49			100	49.4								
ARL-16	102349	0.49			100	48.7								
ISO-SCF-32293-4	1246426	5.82	5.40641	8%	1	5.8								
ISO-SCF-32293-4	1237852	5.78	5.40641	7%	1	5.8								
ISO-SCF-32293-4	1239959	5.79	5.40641	7%	1	5.8								

Sample Name	AREA	AMOUNT ug/mL	QC Con ug/mL	QC Bias %	Dilution Factor	Amount Sample ug	Avg Amt Sample ug	Volume Sampled Cu Ft	Sampling Factor	Adjusted Avg ug	Total Train ug	Amount Spiked ug	Spike Recovery %	Train ID
ARL-17	1229990	5.75			2000	11492.4	11487.9	34.24	1.03139	11587.8	11624.8	7827.81	106.14%	3-A-1
ARL-17	1214060	5.67			2000	11343.9								
ARL-17	1244450	5.81			2000	11627.3								
ARL-18	75825	0.36			100	36.4	35.9	34.24	1.03139	37.0				3-A-2
ARL-18	74917	0.36			100	36.0								
ARL-18	73672	0.35			100	35.4								
ARL-19	1282836	5.99			2000	11985.3	12024.4	35.15	1.00468	12039.7	12077.7	7827.81	111.93%	3-B-1
ARL-19	1289518	6.02			2000	12017.7								
ARL-19	1288725	6.02			2000	12040.3								
ARL-20	79007	0.38			100	37.9	37.8	35.15	1.00468	38.0				3-B-2
ARL-20	78713	0.38			100	37.7								
ARL-20	79021	0.38			100	37.9								
ISO-SCF-32293-4	1263449	5.90	5.40641	9%	1	5.9								
ISO-SCF-32293-4	1253499	5.86	5.40641	8%	1	5.9								
ISO-SCF-32293-4	1260480	5.89	5.40641	9%	1	5.9								
ARL-21	351376	1.65			2000	3297.6	3281.0	33.75	1.04636	3433.1	3466.4			3-C-1
ARL-21	343323	1.61			2000	3222.4								
ARL-21	354099	1.66			2000	3323.0								
ARL-22	65492	0.32			100	31.6	31.8	33.75	1.04636	33.3				3-C-2
ARL-22	66002	0.32			100	31.8								
ARL-22	66603	0.32			100	32.1								
ARL-23	319713	1.50			2000	3002.2	2927.6	33.01	1.06982	3132.0	3165.7			3-D-1
ARL-23	310818	1.46			2000	2919.3								
ARL-23	304609	1.43			2000	2861.4								
ARL-24	65115	0.31			100	31.4	31.5	33.01	1.06982	33.7				3-D-2
ARL-24	66054	0.32			100	31.8								
ARL-24	64767	0.31			100	31.2								
ISO-SCF-32293-4	1223529	5.72	5.40641	6%	1	5.7								
ISO-SCF-32293-4	1220297	5.70	5.40641	5%	1	5.7								
ISO-SCF-32293-4	1183133	5.70	5.40641	5%										

Sample Name	AREA	AMOUNT ug/mL	QC Con ug/mL	QC Bias %	Dilution Factor	Amount Sample ug	Avg Amt Sample ug	Volume Sampled Cu Ft	Sampling Factor	Adjusted Avg ug	Total Train ug	Amount Spiked ug	Spike Recovery %	Train ID
ARL-25	198810	0.94			2000	1874.6	1831.7	30.60	1.15407	2113.9	2132.1			4-A-1
ARL-25	195931	0.92			2000	1847.7								
ARL-25	187888	0.89			2000	1772.7								
ARL-26	33336	0.17			100	16.6	15.8	30.60	1.15407	18.3				4-A-2
ARL-26	32875	0.16			100	16.3								
ARL-26	29079	0.15			100	14.6								
ARL-27	200805	0.95			2000	1893.2	1864.2	31.17	1.13297	2112.1	2138.7			4-B-1
ARL-27	200538	0.95			2000	1890.7								
ARL-27	191767	0.90			2000	1808.9								
ARL-28	48281	0.24			100	23.5	23.5	31.17	1.13297	26.6				4-B-2
ARL-28	49506	0.24			100	24.1								
ARL-28	46705	0.23			100	22.8								
ISO-SCF-32293-4	1202635	5.62	5.40641	4%	1	5.6								
ISO-SCF-32293-4	1219147	5.70	5.40641	5%	1	5.7								
ARL-29	1001159	4.68			2000	9358.1	9329.4	30.35	1.16358	9626.4	9693.9	7827.81	96.56%	4-C-1
ARL-29	987039	4.61			2000	9226.4								
ARL-29	1006035	4.70			2000	9403.6								
ARL-30	124507	0.59			100	59.1	58.0	30.35	1.16358	67.5				4-C-2
ARL-30	122754	0.58			100	58.3								
ARL-30	119182	0.57			100	56.6								
ARL-31	1004933	4.70			2000	9393.3	9428.7	29.54	1.19549	9774.2	9804.7	7827.81	97.97%	4-D-1
ARL-31	1018359	4.76			2000	9518.5								
ARL-31	1002870	4.69			2000	9374.1								
ARL-32	53598	0.26			100	26.0	25.5	29.54	1.19549	30.5				4-D-2
ARL-32	53113	0.26			100	25.8								
ARL-32	50832	0.25			100	24.7								
ISO-SCF-32293-4	1200453	5.61	5.40641	4%	1	5.6								
ISO-SCF-32293-4	1204115	5.63	5.40641	4%	1	5.6								
ISO-SCF-32293-4	1180454	5.56	5.40641	3%	1	5.6								

Sample Name	AREA	AMOUNT ug/mL	QC Con ug/mL	QC Bias %	Dilution Factor	Amount Sample ug	Avg Amt Sample ug	Volume Sampled Cu ft	Sampling Factor	Adjusted Avg ug	Total Train ug	Amount Spiked ug	Spike Recovery %	Train ID
ARL-33	1309769	6.12			2000	12236.5	12014.2	34.14	1.03441	12187.3	12233.3	7827.81	89.41%	5-A-1
ARL-33	1323802	6.18			2000	12367.4								
ARL-33	1224229	5.72			2000	11438.7								
ARL-34	101486	0.49			100	49.3	44.5	34.14	1.03441	46.1				5-B-1
ARL-34	103816	0.49			100	49.4								
ARL-34	72585	0.35			100	34.9								
ARL-35	1369996	6.40			2000	12798.3	12588.1	34.70	1.01771	12678.6	12716.7	7827.81	95.59%	5-B-1
ARL-35	1382908	6.46			2000	12918.7								
ARL-35	1289467	6.02			2000	12047.2								
ARL-36	81360	0.40			100	40.4	37.4	34.70	1.01771	38.0				5-B-2
ARL-36	85164	0.41			100	40.7								
ARL-36	84482	0.31			100	31.1								
ISO-SCF-32293-4	1198549	5.60	5.40641	4%	1	5.6								
ISO-SCF-32293-4	1178529	5.51	5.40641	2%	1	5.5								
ARL-37	511915	2.40			2000	4794.9	4809.8	34.46	1.02480	4929.1	4946.9			5-C-1
ARL-37	520867	2.44			2000	4876.5								
ARL-37	507945	2.38			2000	4757.9								
ARL-38	36452	0.18			100	18.0	17.4	34.46	1.02480	17.8				5-C-2
ARL-38	36462	0.18			100	18.0								
ARL-38	32321	0.16			100	16.1								
ARL-39	532851	2.50			2000	4990.2	5054.0	32.59	1.08360	5476.5	5521.9			5-D-1
ARL-39	544154	2.55			2000	5095.6								
ARL-39	542066	2.54			2000	5076.1								
ARL-40	90692	0.43			100	43.3	41.9	32.59	1.08360	45.4				5-D-2
ARL-40	82975	0.40			100	39.7								
ARL-40	89246	0.43			100	42.6								
ISO-SCF-32293-4	1187611	5.55	5.40641	3%	1	5.5								
ISO-SCF-32293-4	1199464	5.60	5.40641	4%	1	5.6								
ISO-SCF-32293-4	1183133	5.53	5.40641	2%	1	5.5								

Sample Name	AREA	AMOUNT ug/mL	QC Con ug/mL	QC Bias %	Dilution Factor	Amount Sample ug	Avg Amt Sample ug	Volume Sampled Cu Ft	Sampling Factor	Adjusted Avg ug	Total Train ug	Amount Spiked ug	Spike Recovery %	Train ID
ARL-41	861252	4.03			2000	8053.2	7887.9	35.10	1.00612	7936.1	8041.6			6-A-1
ARL-41	860232	4.02			2000	8043.7								
ARL-41	809094	3.78			2000	7566.7								
ARL-42	227095	1.07			100	106.9	104.8	35.10	1.00612	105.4				6-A-2
ARL-42	228142	1.07			100	107.4								
ARL-42	212430	1.00			100	100.1								
ARL-43	815730	3.81			2000	7628.6	7488.0	35.17	1.00411	7518.8	7607.6			6-B-1
ARL-43	825689	3.86			2000	7721.5								
ARL-43	760533	3.56			2000	7113.8								
ARL-44	193894	0.91			100	91.4	88.5	35.17	1.00411	88.8				6-B-2
ARL-44	197908	0.93			100	93.3								
ARL-44	170746	0.81			100	80.6								
ISO-SCF-32293-4	1189088	5.56	5.40641	3%	1	5.6								
ISO-SCF-32293-4	1190921	5.56	5.40641	3%	1	5.6								
ARL-45	1656820	7.74			2000	15473.5	15201.1	34.49	1.02391	15381.5	15471.2	7827.81	97.69%	6-C-1
ARL-45	1652121	7.71			2000	15429.7								
ARL-45	1573883	7.35			2000	14700.0								
ARL-46	187832	0.89			100	88.6	87.6	34.49	1.02391	89.7				6-C-2
ARL-46	195647	0.92			100	92.3								
ARL-46	173379	0.82			100	81.9								
ARL-47	1649873	7.70			2000	15408.7	15173.2	33.78	1.04543	15509.0	15609.8	7827.81	99.46%	6-D-1
ARL-47	1634325	7.63			2000	15263.7								
ARL-47	1589878	7.42			2000	14847.3								
ARL-48	220417	1.04			100	103.8	96.3	33.78	1.04543	100.7				6-D-2
ARL-48	206802	0.97			100	97.5								
ARL-48	186023	0.88			100	87.8								
ISO-SCF-32293-4	1205054	5.63	5.40641	4%	1	5.6								
ISO-SCF-32293-4	1195876	5.59	5.40641	3%	1	5.6								
ISO-SCF-32293-4	1183664	5.53	5.40641	2%	1	5.5								

Sample Name	AREA	AMOUNT ug/mL	QC Con ug/mL	QC Bias %	Dilution Factor	Amount Sample ug	Avg Amt Sample ug	Volume Sampled Cu Ft	Sampling Factor	Adjusted Avg ug	Total Train ug	Amount Spiked ug	Spike Recovery %	Train ID
ARL-49	1081312	5.05			2000	10105.7	10094.4	31.11	1.13515	10398.3	10450.0	7827.81	100.45%	7-A-1
ARL-49	1074952	5.02			2000	10016.4								
ARL-49	1084020	5.07			2000	10131.0								
ARL-50	98427	0.47			100	46.9	45.6	31.11	1.13515	51.8				7-A-2
ARL-50	96270	0.46			100	45.9								
ARL-50	92145	0.44			100	44.0								
ARL-51	963232	4.50			2000	9004.6	9002.6	31.94	1.10566	9246.5	9290.2	7827.81	85.63%	7-B-1
ARL-51	970463	4.54			2000	9071.8								
ARL-51	955412	4.47			2000	8931.4								
ARL-52	83965	0.40			100	40.2	39.5	31.94	1.10566	41.6				7-B-2
ARL-52	83998	0.40			100	40.2								
ARL-52	79455	0.38			100	38.1								
ISO-SCF-32293-4	1194001	5.58	5.40641	3%	1	5.6								
ISO-SCF-32293-4	1201282	5.61	5.40641	4%	1	5.6								
ARL-53	230346	1.08			2000	2168.7	2159.8	30.14	1.17169	2530.6	2557.9			7-C-1
ARL-53	232911	1.10			2000	2192.6								
ARL-53	224911	1.06			2000	2118.0								
ARL-54	49290	0.24			100	24.0	23.3	30.14	1.17169	27.3				7-C-2
ARL-54	49749	0.24			100	24.2								
ARL-54	44499	0.22			100	21.8								
ARL-55	237247	1.12			2000	2233.1	2180.2	29.91	1.18070	2574.2	2616.4			7-D-1
ARL-55	228829	1.08			2000	2154.5								
ARL-55	228680	1.08			2000	2153.0								
ARL-56	75486	0.36			100	36.2	35.8	29.91	1.18070	42.3				7-D-2
ARL-56	75034	0.36			100	36.0								
ARL-56	73273	0.35			100	35.2								
ISO-SCF-32293-4	1201622	5.61	5.40641	4%	1	5.6								
ISO-SCF-32293-4	1192039	5.57	5.40641	3%	1	5.6								
ISO-SCF-32293-4	1184261	5.53	5.40641	2%	1	5.5								

Sample Name	AREA	AMOUNT ug/mL	QC Con ug/mL	QC Bias %	Dilution Factor	Amount Sample ug	Avg Amt Sample ug	Volume Sampled Cu Ft	Sampling Factor	Adjusted Avg ug	Total Train ug	Amount Spiked ug	Spike Recovery %	Train ID
ARL-57	374801	1.76			2000	3516.0	3520.7	30.89	1.14324	4025.0	4086.0			8-A-1
ARL-57	377410	1.77			2000	3540.4								
ARL-57	373681	1.75			2000	3505.6								
ARL-58	111353	0.53			100	52.9	53.4	30.89	1.14324	61.0				8-A-2
ARL-58	112493	0.53			100	53.5								
ARL-58	113066	0.54			100	53.7								
ARL-59	406883	1.91			2000	3815.3	3805.4	29.73	1.18785	4520.2	4579.2			8-B-1
ARL-59	401924	1.88			2000	3769.0								
ARL-59	408657	1.92			2000	3811.8								
ARL-60	105005	0.50			100	50.0	49.7	29.73	1.18785	59.0				8-B-2
ARL-60	104950	0.50			100	50.0								
ARL-60	102971	0.49			100	49.0								
ISO-SCF-32293-4	1197542	5.59	5.40641	3%	1	5.6								
ISO-SCF-32293-4	1200088	5.61	5.40641	4%	1	5.6								
ISO-SCF-32293-4	1190471	5.56	5.40641	3%	1	5.6								
ARL-61	1137017	5.31			2000	10625.3	10561.2	30.49	1.15824	11144.9	11197.4	7827.81	88.46%	8-C-1
ARL-61	1120589	5.24			2000	10471.9								
ARL-61	1132853	5.29			2000	10586.4								
ARL-62	94847	0.45			100	45.2	45.3	30.49	1.15824	52.5				8-C-2
ARL-62	95991	0.46			100	45.8								
ARL-62	94335	0.45			100	45.0								
ARL-63	1108755	5.18			2000	10361.7	10314.5	31.95	1.10531	10721.6	10770.2	7827.81	83.01%	8-D-1
ARL-63	1096270	5.12			2000	10245.2								
ARL-63	1108072	5.17			2000	10336.7								
ARL-64	92259	0.44			100	44.0	44.0	31.95	1.10531	48.6				8-D-2
ARL-64	92558	0.44			100	44.2								
ARL-64	91667	0.44			100	43.8								
ISO-SCF-32293-4	1186551	5.54	5.40641	3%	1	5.5								
ISO-SCF-32293-4	1187157	5.55	5.40641	3%	1	5.5								
ISO-SCF-32293-4	1198473	5.59	5.40641	3%	1	5.6								

Sample Name	FILE	AREA	AMOUNT ug/mL	QC Con ug/mL	QC Bias %	Dilution Factor	Amount Sample	Avg Amt Sample	Amount Spiked	Spike Recovery	Train ID
ISO-SCF-32293-4	S3083F4	1263013	5.90	5.41	9%	1	5.9	5.9			QC
ISO-SCF-32293-4	S3083F5	1253783	5.86	5.41	8%	1	5.9				
ISO-SCF-32293-4	S3083F6	1249399	5.84	5.41	8%	1	5.8				
ARL-81	S3083F19	30452	0.15			10	1.5	1.6			FBA
ARL-81	S3083F20	31446	0.16			10	1.6				
ARL-81	S3083F21	33523	0.17			10	1.7				
ARL-104	S3083F22	809699	3.79			2000	7572.4	7569.9	7827.81	97%	FS-1
ARL-104	S3083F23	808659	3.78			2000	7562.7				
ARL-104	S3083F24	809952	3.79			2000	7574.7				
ISO-SCF-32293-4	S3083F25	1253771	5.87	5.41	9%	1	5.9	5.8			QC
ISO-SCF-32293-4	S3083F26	1251918	5.85	5.41	8%	1	5.8				
ISO-SCF-32293-4	S3083F27	1242330	5.80	5.41	7%	1	5.8				
ARL-82	S3083F40	16055	0.08			10	0.8	0.9			FBA
ARL-82	S3083F41	16397	0.09			10	0.9				
ARL-82	S3083F42	16113	0.09			10	0.9				
ARL-105	S3083F43	832058	3.89			2000	7780.9	7686.3	7827.81	98%	FS-2
ARL-105	S3083F44	822507	3.85			2000	7691.8				
ARL-105	S3083F45	811167	3.79			2000	7586.1				
ISO-SCF-32293-4	S3083F46	1238919	5.79	5.41	7%	1	5.8	5.8			QC
ISO-SCF-32293-4	S3083F47	1245019	5.82	5.41	8%	1	5.8				
ISO-SCF-32293-4	S3083F48	1235673	5.77	5.41	7%	1	5.8				
ARL-83	S3084F13	163746	0.77			10	7.7	7.7			FBB
ARL-83	S3084F14	162706	0.77			10	7.7				
ARL-83	S3084F15	164806	0.78			10	7.8				
ARL-106	S3084F16	869707	4.07			2000	8132.1	8120.1	7827.81	104%	MS-1
ARL-106	S3084F17	867360	4.06			2000	8110.2				
ARL-106	S3084F18	868206	4.06			2000	8118.1				
ISO-SCF-32293-4	S3084F19	1220899	5.70	5.41	6%	1	5.7	5.7			QC
ISO-SCF-32293-4	S3084F20	1232005	5.76	5.41	6%	1	5.8				
ISO-SCF-32293-4	S3084F21	1230936	5.75	5.41	6%	1	5.8				
ARL-84	S3084F34	33054	0.16			10	1.6	1.6			FBB
ARL-84	S3084F35	32381	0.16			10	1.6				
ARL-84	S3084F36	32300	0.16			10	1.6				

Sample Name	FILE	AREA	AMOUNT ug/mL	QC Con ug/mL	QC Bias %	Dilution Factor	Amount Sample	Avg Amt Sample	Amount Spiked	Spike Recovery	Train ID
ARL-107	S3084F37	829745	3.88			2000	7759.3	7837.5	7827.81	100%	MS-2
ARL-107	S3084F38	838117	3.92			2000	7837.4				
ARL-107	S3084F39	846508	3.96			2000	7915.7				
ISO-SCF-32293-4	S3084F40	1246426	5.82	5.41	8%	1	5.8	5.8			QC
ISO-SCF-32293-4	S3084F41	1237852	5.78	5.41	7%	1	5.8				
ISO-SCF-32293-4	S3084F42	1239959	5.79	5.41	7%	1	5.8				
ARL-85	S3085F19	75475	0.36			10	3.6	3.6			FBC
ARL-85	S3085F20	75608	0.36			10	3.6				
ARL-85	S3085F21	72681	0.35			10	3.5				
ARL-108	S3085F22	847084	3.96			2000	7921.1	7890.2	7827.81	101%	MS-3
ARL-108	S3085F23	836897	3.91			2000	7826.0				
ARL-108	S3085F24	847337	3.96			2000	7923.4				
ISO-SCF-32293-4	S3085F25	1263449	5.90	5.41	9%	1	5.9	5.9			QC
ISO-SCF-32293-4	S3085F26	1253499	5.86	5.41	8%	1	5.9				
ISO-SCF-32293-4	S3085F27	1260480	5.89	5.41	9%	1	5.9				
ARL-86	S3085F40	59577	0.29			10	2.9	2.8			FBC
ARL-86	S3085F41	56343	0.27			10	2.7				
ARL-86	S3085F42	59626	0.29			10	2.9				
ARL-109	S3085F43	851309	3.98			2000	7960.5	7944.8	7827.81	101%	MS-4
ARL-109	S3085F44	850793	3.98			2000	7955.6				
ARL-109	S3085F45	846800	3.96			2000	7918.4				
ISO-SCF-32293-4	S3085F46	1243663	5.82	5.41	8%	1	5.8	4.0			QC
ISO-SCF-32293-4	S3085F47	0	0.01	5.41	-100%	1	0.0				
ISO-SCF-32293-4	S3085F48	1296988	6.06	5.41	12%	1	6.1				
ISO-SCF-32293-4	S3098F1	1158548	5.41	5.41	0%	1	5.4				
ARL-89	S3098F2	0	0.01			10	0.1	0.1			T-RB1
ARL-89	S3098F3	0	0.01			10	0.1				
ARL-89	S3098F4	0	0.01			10	0.1				
ARL-90	S3098F5	0	0.01			10	0.1	0.3			T-RB2
ARL-90	S3098F6	5758.5	0.04			10	0.4				
ARL-90	S3098F7	5867.5	0.04			10	0.4				
ARL-91	S3098F8	0	0.01			10	0.1	0.2			
ARL-91	S3098F9	3273	0.03			10	0.3				T-RB3
ARL-91	S3098F10	0	0.01			10	0.1				

Sample Name	FILE	AREA	AMOUNT ug/mL	QC Con ug/mL	QC Bias %	Dilution Factor	Amount Sample	Avg Amt Sample	Amount Spiked	Spike Recovery	Train ID
ARL-92	S3098F11	26248	0.13			10	1.3	1.2			T-RB4
ARL-92	S3098F12	22909.08	0.12			10	1.2				
ARL-92	S3098F13	22154	0.11			10	1.1				
ISO-SCF-32293-4	S3098F14	1202.86	5.62	5.41	4%	1	5.6	5.7			QC
ISO-SCF-32293-4	S3098F15	1212015	5.66	5.41	5%	1	5.7				
ISO-SCF-32293-4	S3098F16	1220989	5.70	5.41	6%	1	5.7				
ARL-94	S3098F17	0	0.01			10	0.1	0.2			A-RB1
ARL-94	S3098F18	5431	0.04			10	0.4				
ARL-94	S3098F19	0	0.01			10	0.1				
ARL-95	S3098F20	0	0.01			10	0.1	0.1			A-RB2
ARL-95	S3098F21	0	0.01			10	0.1				
ARL-95	S3098F22	0	0.01			10	0.1				
ARL-96	S3098F23	6352.5	0.04			10	0.4	0.4			A-RB3
ARL-96	S3098F24	6436	0.04			10	0.4				
ARL-96	S3098F25	5886	0.04			10	0.4				
ARL-97	S3098F26	25608	0.13			10	1.3	0.8			A-RB4
ARL-97	S3098F27	21934	0.11			10	1.1				
ARL-97	S3098F28	0	0.01			10	0.1				
ISO-SCF-32293-4	S3098F29	1164624	5.44	5.41	1%	1	5.4	5.4			QC
ISO-SCF-32293-4	S3098F30	1159319	5.42	5.41	0%	1	5.4				
ISO-SCF-32293-4	S3098F31	1149310	5.37	5.41	-1%	1	5.4				
ARL-99	S3098F32	0	0.01			10	0.1	0.1			ABS-RB
ARL-99	S3098F33	0	0.01			10	0.1				
ARL-99	S3098F34	0	0.01			10	0.1				
ARL-100	S3098F35	0	0.01			10	0.1	0.1			ABS-RB
ARL-100	S3098F36	0	0.01			10	0.1				
ARL-100	S3098F37	0	0.01			10	0.1				
ARL-101	S3098F38	15010.13	0.08			10	0.8	0.9			ABS-RB
ARL-101	S3098F39	15923	0.08			10	0.8				
ARL-101	S3098F40	23127	0.12			10	1.2				
ARL-102	S3098F41	0	0.01			10	0.1	0.1			ABS-RB
ARL-102	S3098F42	0	0.01			10	0.1				
ARL-102	S3098F43	0	0.01			10	0.1				

Sample Name	FILE	AREA	AMOUNT ug/mL	QC Con ug/mL	QC Bias %	Dilution Factor	Amount Sample	Avg Amt Sample	Amount Spiked	Spike Recovery	Train ID
ISO-SCF-32293-4	S3098F44	1187727	5.55	5.41	3%	1	5.5	5.6			QC
ISO-SCF-32293-4	S3098F45	1199251	5.60	5.41	4%	1	5.6				
ISO-SCF-32293-4	S3098F46	1206008	5.63	5.41	4%	1	5.6				
ARL-117	S3098F47	4701	0.03			10	0.3	0.3			MB-1
ARL-117	S3098F48	4680.5	0.03			10	0.3				
ARL-117	S3098F49	5001	0.03			10	0.3				
ARL-118	S3098F50	204900	0.96			10	9.6	9.7			MB-2
ARL-118	S3098F51	207157	0.98			10	9.8				
ARL-118	S3098F52	207481	0.98			10	9.8				
ARL-119	S3098F53	446217.5	2.09			10	20.9	20.7			MB-3
ARL-119	S3098F54	427833.1	2.01			10	20.1				
ARL-119	S3098F55	452112	2.12			10	21.2				
ISO-SCF-4893-1	S3098F56	1164164	5.44	5.41	1%	1	5.4	5.5			QC
ISO-SCF-4893-1	S3098F57	1176245	5.50	5.41	2%	1	5.5				
ISO-SCF-4893-3	S3098F58	1160212	5.42	5.41	0%	1	5.4				

2,4-TDI Summary Information

Amount of 2,4-TDI Spiked into the trains: 7827.01 ug

Percent Recovery for Spiked Quad Trains

Quad No. Train ID	1		2		3		4		5		6		7		8		Average	RSD
	A	B	C	D	A	B	C	D	A	B	C	D	A	B	C	D		
% Recovery	85.69%	86.19%	89.18%	85.22%	106.14%	111.93%	96.56%	97.97%	89.41%	85.59%	97.69%	99.48%	100.45%	85.63%	88.46%	83.01%	95%	8%
Total ug	12263	11520	13258	13733	11625	12078	9694	9805	12233	12717	15471	15810	10450	9290	11197	10770	11862	16%

Amount Collected in Unspiked Quad Trains

Quad No. Train ID	1		2		3		4		5		6		7		8		Average	RSD
	C	D	A	B	C	D	A	B	C	D	A	B	C	D	A	B		
Total ug	4735	4811	6287	6270	3466	3166	2132	2139	4947	5522	8042	7608	2558	2618	4088	4579	4560	41%

Percent Carry over from 1st Impinger in Spiked Quad Trains

Quad No. Train ID	1		2		3		4		5		6		7		8		Average	RSD
	A	B	C	D	A	B	C	D	A	B	C	D	A	B	C	D		
1st Impinger	98.48%	99.21%	99.21%	98.97%	99.02%	99.11%	96.38%	98.46%	98.95%	99.22%	98.83%	98.71%	98.03%	97.02%	98.44%	98.35%	98.52%	0.81%
2nd Impinger	1.52%	0.79%	0.79%	1.03%	0.98%	0.89%	3.62%	1.54%	1.05%	0.78%	1.17%	1.20%	1.97%	2.98%	1.58%	1.65%	1.48%	54.38%

Percent Carry over from 1st Impinger in Unspiked Quad Trains

Quad No. Train ID	1		2		3		4		5		6		7		8		Average	RSD
	C	D	A	B	C	D	A	B	C	D	A	B	C	D	A	B		
1st Impinger	99.59%	98.11%	98.61%	99.24%	99.04%	98.94%	99.14%	98.76%	99.64%	99.18%	98.69%	98.83%	98.93%	98.30%	98.51%	98.71%	98.91%	0.41%
2nd Impinger	0.41%	1.89%	1.19%	0.76%	0.96%	1.06%	0.86%	1.24%	0.36%	0.82%	1.31%	1.17%	1.07%	1.62%	1.49%	1.20%	1.09%	37.05%

AREAL WA 55 -- Method 301 Results
Using Modified Data

Run #	Train			Amount		Precision of UNSpiked Samples			
	A	B	C	D	Spiked	Diff	STDu	STDm	RSD
1	12263.0	11520.0	4735.0	4811.0	7827.81	-76.00	216.596	30.942	4.721
2	6287.0	6270.0	13258.0	13733.0	7827.81	17.00			
3	11625.0	12078.0	3466.0	3166.0	7827.81	300.00			
4	2132.0	2139.0	9694.0	9805.0	7827.81	-7.00			
5	12233.0	12717.0	4947.0	5522.0	7827.81	-575.00			
6	8084.0	7608.0	15471.0	15610.0	7827.81	476.00			
7	10450.0	9290.0	2557.0	2616.0	7827.81	-59.00			

AREAL WA 55 -- Method 301 Results
Using Modified Data

Run #	Train			Amount			Precision of Spiked Samples				Bias		
	A	n	C	D	Spiked	Diff	SDs	SDm	RSD	Run	Compound	SD	t-Test CF
1	12263.0	11520.0	4735.0	4811.0	7827.81	743.00	430.48	162.71	3.55	-709.31	-295.41	481.90	-1.622 N/A
2	6287.0	6270.0	13258.0	13733.0	7827.81	-475.00				-610.81			critical Value is 2.160
3	11625.0	12078.0	3466.0	3166.0	7827.81	-453.00				707.69			
4	2132.0	2139.0	9694.0	9805.0	7827.81	-111.00				-213.81			
5	12233.0	12717.0	4947.0	5322.0	7827.81	-484.00				-587.31			
6	8084.0	7608.0	15471.0	15610.0	7827.81	-139.00				-133.31			
7	10450.0	9290.0	2557.0	2616.0	7827.81	1160.00				-544.31			

AREAL WA 55 -- Method 301 Results
Using Modified Data

Run #	Train			Amount		Precision of UNSpiked Samples			
	A	B	C	D	Spiked	Diff	STDu	STDm	RSD
1	12263.0	11520.0	4735.0	4811.0	7827.81	-76.00	237.150	29.644	5.205
2	6287.0	6270.0	13238.0	13733.0	7827.81	17.00			
3	11625.0	12078.0	3466.0	3166.0	7827.81	300.00			
4	2132.0	2139.0	9694.0	9805.0	7827.81	-7.00			
5	12233.0	12717.0	4947.0	5522.0	7827.81	-575.00			
6	8084.0	7608.0	15471.0	15610.0	7827.81	476.00			
7	10450.0	9290.0	2557.0	2616.0	7827.81	-59.00			
8	4086.0	4579.0	11197.0	10947.0	7827.81	-493.00			

AREAL WA 55 -- Method 301 Results
Using Modified Data

Run #	Train			Amount			Precision of Spiked Samples				Bias		
	A	B	C	D	Spiked	Diff	SDs	SDm	RSD	Run	Compound	SD	t Test
1	12263.0	11520.0	4735.0	4811.0	7827.81	743.00	407.50	144.07	3.40	-709.31	-394.53	471.48	-2.367
2	6287.0	6270.0	13258.0	13733.0	7827.81	-475.00				-610.81			^
3	11625.0	12078.0	3466.0	3166.0	7827.81	-453.00				707.69			
4	2132.0	2139.0	9694.0	9805.0	7827.81	-111.00				-213.81			critical Value
5	12233.0	12717.0	4947.0	5522.0	7827.81	-484.00				-587.31			ls 2.131
6	8084.0	7608.0	15471.0	15610.0	7827.81	-139.00				-133.31			
7	10450.0	9290.0	2557.0	2616.0	7827.81	1160.00				-544.31			
8	4086.0	4579.0	11197.0	10947.0	7827.81	250.00				-1088.31			

EPA
METHOD 0011

RECEIVED

SAMPLING FOR FORMALDEHYDE EMISSIONS FROM STATIONARY SOURCES JUL 16 1990

INTERPOL LABORATORIES

1.0 SCOPE AND APPLICATION

1.1 This method is applicable to the determination of Destruction and Removal Efficiency (DRE) of formaldehyde, CAS Registry number 50-00-0, and possibly other aldehydes and ketones from stationary sources as specified in the regulations. The methodology has been applied specifically to formaldehyde; however, many laboratories have extended the application to other aldehydes and ketones. Compounds derivatized with 2,4-dinitrophenylhydrazine can be detected as low as 6.4×10^{-8} lbs/cu ft (1.8 ppbv) in stack gas over a 1 h sampling period, sampling approximately 45 cu ft.

2.0 SUMMARY OF METHOD

2.1 Gaseous and particulate pollutants are withdrawn isokinetically from an emission source and are collected in aqueous acidic 2,4-dinitrophenylhydrazine. Formaldehyde present in the emissions reacts with the 2,4-dinitrophenylhydrazine to form the formaldehyde dinitrophenylhydrazone derivative. The dinitrophenylhydrazone derivative is extracted, solvent-exchanged, concentrated, and then analyzed by high performance liquid chromatography.

3.0 INTERFERENCES

3.1 A decomposition product of 2,4-dinitrophenylhydrazine, 2,4-dinitroaniline, can be an analytical interferent if concentrations are high. 2,4-dinitroaniline can coelute with the 2,4-dinitrophenylhydrazone of formaldehyde under high performance liquid chromatography conditions which may be used for the analysis. High concentrations of highly oxygenated compounds, especially acetone, that have the same retention time or nearly the same retention time as the dinitrophenylhydrazone of formaldehyde and that also absorb at 360 nm will interfere with the analysis.

Formaldehyde, acetone, and 2,4-dinitroaniline contamination of the aqueous acidic 2,4-dinitrophenylhydrazine (DNPH) reagent is frequently encountered. The reagent must be prepared within five days of use in the field and must be stored in an uncontaminated environment both before and after sampling in order to minimize blank problems. Some level of acetone contamination is unavoidable, because acetone is ubiquitous in laboratory and field operations. However, the acetone contamination must be minimized.

4.0 APPARATUS AND MATERIALS

4.1 A schematic of the sampling train is shown in Figure 1. This sampling train configuration is adapted from EPA Method 5 procedures. The sampling train consists of the following components: Probe Nozzle, Pitot Tube, Differential Pressure Gauge, Metering System, Barometer, and Gas Density Determination Equipment.

4.1.1 Probe Nozzle: Quartz or glass with sharp, tapered (30° angle) leading edge. The taper shall be on the outside to preserve a constant inner diameter. The nozzle shall be buttonhook or elbow design. A range of nozzle sizes suitable

INTERPOL LABORATORIES
4500 BALL ROAD N.E.
CIRCLE PINES, MN 55014-1819
(612) 786-8020

J-110

configuration such that the tip of the sensor extends beyond the leading edge of the probe sheath and does not touch any metal. Alternatively, the sensor may be attached just prior to use in the field. Note, however, that if the temperature sensor is attached in the field, the sensor must be placed in an interference-free arrangement with respect to the Type S pitot tube openings (see EPA Method 2, Figure 2-7). As a second alternative, if a difference of no more than 1% in the average velocity measurement is to be introduced, the temperature gauge need not be attached to the probe or pitot tube.

4.2 Sample Recovery

4.2.1 Probe Liner: Probe nozzle and brushes; Teflon® bristle brushes with stainless steel wire handles are required. The probe brush shall have extensions of stainless steel, Teflon®, or inert material at least as long as the probe. The brushes shall be properly sized and shaped to brush out the probe liner, the probe nozzle, and the impingers.

4.2.2 Wash Bottles: Three wash bottles are required. Teflon® or glass wash bottles are recommended; polyethylene wash bottles should not be used because organic contaminants may be extracted by exposure to organic solvents used for sample recovery.

4.2.3 Graduated Cylinder and/or Balance: A graduated cylinder or balance is required to measure condensed water to the nearest 1 mL or 1 g. Graduated cylinders shall have divisions not >2 mL. Laboratory balances capable of weighing to ± 0.5 g are required.

4.2.4 Amber Glass Storage Containers: One-liter wide-mouth amber flint glass bottles with Teflon®-lined caps are required to store impinger water samples. The bottles must be sealed with Teflon® tape.

4.2.5 Rubber Policeman and Funnel: A rubber policeman and funnel are required to aid in the transfer of materials into and out of containers in the field.

5.0 REAGENTS

Reagent grade chemicals or better grades shall be used in all tests. Unless otherwise indicated, all reagents shall conform to the specifications of the Committee on Analytical Reagents of the American Chemical Society, where such specifications are available.

5.1 Water: HPLC-grade water is used in preparation of DNPH reagent and in all other applications in the sampling train.

5.2 Silica Gel: Silica gel shall be indicating type, 6-16 mesh. If the silica gel has been used previously, dry at 175°C (350°F) for 2 h before using. New silica gel may be used as received. Alternatively, other types of desiccants (equivalent or better) may be used.

5.3 Crushed Ice: Quantities ranging from 10-50 lb may be necessary during a sampling run, depending upon ambient temperature. Samples which have been taken must be stored and shipped cold; sufficient ice for this purpose must be allowed.

for isokinetic sampling should be available in increments of 0.16 cm (1/16 in), e.g., 0.32 to 1.27 cm (1/8 to 1/2 in), or larger if higher volume sampling trains are used. Each nozzle shall be calibrated according to the procedures outlined in Section 8.1.

4.1.2 Probe Liner: Borosilicate glass or quartz shall be used for the probe liner. The tester should not allow the temperature in the probe to exceed $120 \pm 14^{\circ}\text{C}$ ($248 \pm 25^{\circ}\text{F}$).

4.1.3 Pitot Tube: The Pitot tube shall be Type S, as described in Section 2.1 of EPA Method 2, or any other appropriate device. The pitot tube shall be attached to the probe to allow constant monitoring of the stack gas velocity. The impact (high pressure) opening plane of the pitot tube shall be even with or above the nozzle entry plane (see EPA Method 2, Figure 2-6b) during sampling. The Type S pitot tube assembly shall have a known coefficient, determined as outlined in Section 4 of EPA Method 2.

4.1.4 Differential Pressure Gauge: The differential pressure gauge shall be an inclined manometer or equivalent device as described in Section 2.2 of EPA Method 2. One manometer shall be used for velocity-head readings and the other for orifice differential pressure readings.

4.1.5 Impingers: The sampling train requires a minimum of four impingers, connected as shown in Figure 1, with ground glass (or equivalent) vacuum-tight fittings. For the first, third, and fourth impingers, use the Greenburg-Smith design, modified by replacing the tip with a 1.3-cm inside diameter (1/2 in) glass tube extending to 1.3 cm (1/2 in) from the bottom of the flask. For the second impinger, use a Greenburg-Smith impinger with the standard tip. Place a thermometer capable of measuring temperature to within 1°C (2°F) at the outlet of the fourth impinger for monitoring purposes.

4.1.6 Metering System: The necessary components are a vacuum gauge, leak-free pump, thermometers capable of measuring temperature within 3°C (5.4°F), dry-gas meter capable of measuring volume to within 1%, and related equipment as shown in Figure 1. At a minimum, the pump should be capable of 4 cfm free flow, and the dry gas meter should have a recording capacity of 0-999.9 cu ft with a resolution of 0.005 cu ft. Other metering systems may be used which are capable of maintaining sampling rates within 10% of isokinetic collection and of determining sample volumes to within 2%. The metering system may be used in conjunction with a pitot tube to enable checks of isokinetic sampling rates.

4.1.7 Barometer: The barometer may be mercury, aneroid, or other barometer capable of measuring atmospheric pressure to within 2.5 mm Hg (0.1 in Hg). In many cases, the barometric reading may be obtained from a nearby National Weather Service Station, in which case the station value (which is the absolute barometric pressure) is requested and an adjustment for elevation differences between the weather station and sampling point is applied at a rate of minus 2.5 mm Hg (0.1 in Hg) per 30 m (100 ft) elevation increase (vice versa for elevation decrease).

4.1.8 Gas Density Determination Equipment: Temperature sensor and pressure gauge (as described in Sections 2.3 and 2.4 of EPA Method 2), and gas analyzer, if necessary (as described in EPA Method 3). The temperature sensor ideally should be permanently attached to the pitot tube or sampling probe in a fixed

5.4 2,4-Dinitrophenylhydrazine Reagent: The 2,4-dinitrophenylhydrazine reagent must be prepared in the laboratory within five days of sampling use in the field. Preparation of DNPH can also be done in the field, with consideration of appropriate procedures required for safe handling of solvent in the field. When a container of prepared DNPH reagent is opened in the field, the contents of the opened container should be used within 48 hours. All laboratory glassware must be washed with detergent and water and rinsed with water, methanol, and methylene chloride prior to use.

NOTE: The glassware must not be rinsed with acetone or unacceptable levels of acetone contamination will be introduced. If field preparation of DNPH is performed, caution must be exercised in avoiding acetone contamination.

Reagent bottles for storage of cleaned DNPH derivatizing solution must be rinsed with acetonitrile and dried before use. Baked glassware is not essential for preparation of DNPH reagent.

NOTE: DNPH crystals or DNPH solution should be handled with plastic gloves at all times, with prompt and extensive use of running water in case of skin exposure.

5.4.1 Preparation of Aqueous Acidic DNPH: The following materials and reagents are required for preparation of the reagent.

5.4.1.1 Bottles/Caps: amber 1- or 4 L bottles with Teflon®-lined caps are required for storing cleaned DNPH solution. Additional 4-L bottles are required to collect waste organic solvents.

5.4.1.2 Large Glass Container: at least one large glass container (8 to 16 L) is required for mixing the aqueous acidic DNPH solution.

5.4.1.3 Stir Plate/Large Stir Bars/Stir Bar Retriever: a magnetic stir plate and large stir bar are required for the mixing of the aqueous acidic DNPH solution. A stir bar retriever is needed for removing the stir bar from the large container holding the DNPH solution.

5.4.1.4 Buchner Filter/Filter Flask/Filter Paper: a large filter flask (2-4 L) with a buchner filter, appropriate rubber stopper, filter paper, and connecting tubing are required for filtering the aqueous acidic DNPH solution prior to cleaning.

5.4.1.5 Separatory Funnels: at least one large separatory funnel (2 L) is required for cleaning the DNPH prior to use.

5.4.1.6 Beakers: beakers (150 mL, 250 mL, and 400 mL) are useful for holding/measuring organic liquids when cleaning the aqueous acidic DNPH solution and for weighing DNPH crystals.

5.4.1.7 Funnels: at least one large funnel is needed for pouring the aqueous acidic DNPH into the separatory funnel.

5.4.1.8 Graduated Cylinders: at least one large graduated cylinder (1 to 2 L) is required for measuring HPLC-grade water and acid when preparing the DNPH solution.

5.4.1.9 Top-Loading Balance: a one-place top loading balance is needed for weighing out the DNPH crystals used to prepare the aqueous acidic DNPH solution.

5.4.1.10 Spatulas: spatulas are needed for weighing out DNPH when preparing the aqueous DNPH solution.

5.4.1.11 HPLC-Grade Water: water (HPLC-grade) is required to mix the aqueous DNPH solution.

5.4.1.12 Hydrochloric Acid: reagent grade hydrochloric acid (approximately 12N) is required for acidifying the aqueous DNPH solution.

5.4.1.13 2,4-Dinitrophenylhydrazine: a supply of moist solid 2,4-dinitrophenylhydrazine (DNPH) is required for preparation of aqueous acidic DNPH solution. The quantity of water may vary from 10 to 30%. Reagent grade or equivalent is required.

5.4.1.14 Methylene Chloride: methylene chloride (suitable for residue and pesticide analysis, GC/MS, HPLC, GC, Spectrophotometry or equivalent) is required for cleaning the aqueous acidic DNPH solution, rinsing glassware, and recovery of sample trains.

5.4.1.15 Cyclohexane: cyclohexane (HPLC grade) is required for cleaning the aqueous acidic DNPH solution.

NOTE: Do not use spectroanalyzed grades of cyclohexane if this sampling methodology is extended to aldehydes and ketones with four or more carbon atoms.

5.4.1.16 Methanol: methanol (HPLC grade or equivalent) is required for rinsing glassware.

5.4.1.17 Acetonitrile: acetonitrile (HPLC grade or equivalent) is required for rinsing glassware.

5.4.1.18 Formaldehyde: Analytical grade or equivalent formaldehyde is required for preparation of standards. If other aldehydes or ketones are used, analytical grade or equivalent is required.

5.4.2 Preparation of Aqueous Acidic DNPH Derivatizing Reagent: Each batch of DNPH reagent should be prepared and purified within five days of sampling, according to the procedure described below.

5.4.2.1 Place an 8-L container under a fume hood on a magnetic stirrer. Add a large stir bar and fill the container half full of HPLC-grade water. Save the empty bottle from HPLC-grade water. Start the stirring bar and adjust the stir rate to be as fast as possible. Using a graduated cylinder, measure 1.4 mL of concentrated hydrochloric acid. Slowly pour the acid into the stirring water. Fumes may be generated and the water may become warm. Weigh the DNPH crystals on a one-place balance (see Table 1 for approximate amounts) and add to the stirring acid solution. Fill the 8 L container to the 8 L mark with HPLC water and stir overnight. If all of the DNPH crystals have dissolved overnight, add additional DNPH and stir for two more hours. Continue the process of adding DNPH with additional stirring until a saturated solution has been formed. Filter the DNPH solution using vacuum filtration. Gravity filtration may be used, but a

much longer time is required. Store the filtered solution in an amber bottle at room temperature.

TABLE 1. APPROXIMATE AMOUNT OF CRYSTALLINE DNPH USED
TO PREPARE A SATURATED SOLUTION

Amount of Moisture in DNPH	Weight Required per 8 L of Solution
10 weight percent	31 g
15 weight percent	33 g
30 weight percent	40 g

Within five days of proposed use, place about 1.6 L of the DNPH reagent in a 2 L separatory funnel. Add approximately 200 mL of methylene chloride and stopper the funnel. Wrap the stopper of the funnel with paper towels to absorb any leakage. Invert and vent the funnel. Then shake vigorously for 3 minutes. Initially, the funnel should be vented frequently (every 10 - 15 sec). After the layers have separated, discard the lower (organic) layer.

Extract the DNPH a second time with methylene chloride and finally with cyclohexane. When the cyclohexane layer has separated from the DNPH reagent, the cyclohexane layer will be the top layer in the separatory funnel. Drain the lower layer (the cleaned extracted DNPH reagent solution) into an amber bottle that has been rinsed with acetonitrile and allowed to dry.

5.4.3 Quality Control: Take two aliquots of the extracted DNPH reagent. The size of the aliquots is dependent upon the exact sampling procedure used, but 100 mL is reasonably representative. To ensure that the background in the reagent is acceptable for field use, analyze one aliquot of the reagent according to the procedure of EPA Draft Method 8315. Save the other aliquot of aqueous acidic DNPH for use as a method blank when the analysis is performed.

5.4.4 Shipment to the Field: Tightly cap the bottle containing extracted DNPH reagent using a Teflon®-lined cap. Seal the bottle with Teflon® tape. After the bottle is labeled, the bottle may be placed in a friction-top can (paint can or equivalent) containing a 1 -2 inch layer of granulated charcoal and stored at ambient temperature until use.

If the DNPH reagent has passed the Quality Control criteria, the reagent may be packaged to meet necessary shipping requirements and sent to the sampling area. If the Quality Control criteria are not met, the reagent solution may be re-extracted or the solution may be re-prepared and the extraction sequence repeated.

If the DNPH reagent is not used in the field within five days of extraction, an aliquot may be taken and analyzed as described Draft Method 8315. If the reagent meets the Quality Control requirements, the reagent may be used. If the reagent does not meet Quality Control requirements, the reagent must be discarded and new reagent must be prepared and tested.

5.4.5 Calculation of Acceptable Levels of Impurities in DNPH Reagent: The acceptable impurity level (AIL, µg/mL) is calculated from the expected analyte level in the sampled gas (EAL, ppbv), the volume of air that will be sampled at standard conditions (SVOL, L), the formula weight of the analyte (FW, g/mol), and the volume of DNPH reagent that will be used in the impingers (RVOL, mL):

$$AIL = 0.1 \times [EAL \times SVOL \times FW / 22.4 \times (FW + 180) / FW] / (RVOL \times 1000).$$

where 0.1 is the acceptable contaminant level, 22.4 is a factor relating ppbv to g/L, 180 is a factor relating the underivatized analyte to the derivatized analyte, and 1000 is a unit conversion factor.

5.4.6 Disposal of Excess DNPH Reagent: Excess DNPH reagent may be returned to the laboratory and recycled or treated as aqueous waste for disposal purposes. 2,4-Dinitrophenylhydrazine is a flammable solid when dry so water should not be evaporated from the solution of the reagent.

5.5 Field Spike Standard Preparation: To prepare a formaldehyde field spiking standard at 4.01 mg/mL, use a 500µL syringe to transfer 0.5 mL of 37% by weight of formaldehyde (401 mg/mL) to a 50 mL volumetric flask containing approximately 40 mL of methanol. Dilute to 50 mL with methanol.

6.0 SAMPLE COLLECTION, PRESERVATION, AND HANDLING

6.1 Because of the complexity of this method, field personnel should be trained in and experienced with the test procedures in order to obtain reliable results.

6.2 Laboratory Preparation:

6.2.1 All the components shall be maintained and calibrated according to the procedure described in APTD-0576, unless otherwise specified.

6.2.2 Weigh several 200- to 300-g portions of silica gel in airtight containers to the nearest 0.5 g. Record on each container the total weight of the silica gel plus containers. As an alternative to preweighing the silica gel, it may instead be weighed directly in the impinger or sampling holder just prior to train assembly.

6.3 Preliminary Field Determinations:

6.3.1 Select the sampling site and the minimum number of sampling points according to EPA Method 1 or other relevant criteria. Determine the stack pressure, temperature, and range of velocity heads using EPA Method 2. A leak-check of the pitot lines according to EPA Method 2, Section 3.1, must be performed. Determine the stack gas moisture content using EPA Approximation Method 4 or its alternatives to establish estimates of isokinetic sampling-rate settings. Determine the stack gas dry molecular weight, as described in EPA Method 2, Section 3.6. If integrated EPA Method 3 sampling is used for molecular weight determination, the integrated bag sample shall be taken simultaneously with, and for the same total length of time as, the sample run.

6.3.2 Select a nozzle size based on the range of velocity heads so that it is not necessary to change the nozzle size in order to maintain isokinetic sampling rates below 28 L/min (1.0 cfm). During the run, do not change the nozzle.

Ensure that the proper differential pressure gauge is chosen for the range of velocity heads encountered (see Section 2.2 of EPA Method 2).

6.3.3 Select a suitable probe liner and probe length so that all traverse points can be sampled. For large stacks, to reduce the length of the probe, consider sampling from opposite sides of the stack.

6.3.4 A minimum of 45 ft³ of sample volume is required for the determination of the Destruction and Removal Efficiency (DRE) of formaldehyde from incineration systems (45ft³ is equivalent to one hour of sampling at 0.75 dscf). Additional sample volume shall be collected as necessitated by the capacity of the DNPH reagent and analytical detection limit constraints. To determine the minimum sample volume required, refer to sample calculations in Section 10.

6.3.5 Determine the total length of sampling time needed to obtain the identified minimum volume by comparing the anticipated average sampling rate with the volume requirement. Allocate the same time to all traverse points defined by EPA Method 1. To avoid timekeeping errors, the length of time sampled at each traverse point should be an integer or an integer plus 0.5 min.

6.3.6 In some circumstances (e.g., batch cycles) it may be necessary to sample for shorter times at the traverse points and to obtain smaller gas-volume samples. In these cases, careful documentation must be maintained in order to allow accurate calculation of concentrations.

6.4 Preparation of Collection Train:

6.4.1 During preparation and assembly of the sampling train, keep all openings where contamination can occur covered with Teflon® film or aluminum foil until just prior to assembly or until sampling is about to begin.

6.4.2 Place 100 mL of cleaned DNPH solution in each of the first two impingers, and leave the third impinger empty. If additional capacity is required for high expected concentrations of formaldehyde in the stack gas, 200 mL of DNPH per impinger may be used or additional impingers may be used for sampling. Transfer approximately 200 to 300 g of pre-weighed silica gel from its container to the fourth impinger. Care should be taken to ensure that the silica gel is not entrained and carried out from the impinger during sampling. Place the silica gel container in a clean place for later use in the sample recovery. Alternatively, the weight of the silica gel plus impinger may be determined to the nearest 0.5 g and recorded.

6.4.3 With a glass or quartz liner, install the selected nozzle using a Viton-A O-ring when stack temperatures are <260°C (500°F) and a woven glass-fiber gasket when temperatures are higher. See APTD-0576 (Rom, 1972) for details. Other connecting systems utilizing either 316 stainless steel or Teflon® ferrules may be used. Mark the probe with heat-resistant tape or by some other method to denote the proper distance into the stack or duct for each sampling point.

6.4.4 Assemble the train as shown in Figure 1. During assembly, do not use any silicone grease on ground-glass joints upstream of the impingers. Use Teflon® tape, if required. A very light coating of silicone grease may be used on ground-glass joints downstream of the impingers, but the silicone grease should be limited to the outer portion (see APTD-0576) of the ground-glass joints to

necessary, a leak check shall be conducted immediately after the interruption of sampling and before the change is made. The leak check shall be done according to the procedure described in Section 6.5.1, except that it shall be done at a vacuum greater than or equal to the maximum value recorded up to that point in the test. If the leakage rate is found to be no greater than 0.00057 m³/min (0.02 cfm) or 4% of the average sampling rate (whichever is less), the results are acceptable. If a higher leakage rate is obtained, the tester must void the sampling run.

NOTE: Any correction of the sample volume by calculation reduces the integrity of the pollutant concentration data generated and must be avoided.

6.5.2.2 Immediately after a component change and before sampling is re-initiated, a leak check similar to a pre-test leak check must also be conducted.

6.5.3 Post-test Leak Check:

6.5.3.1 A leak check is mandatory at the conclusion of each sampling run. The leak check shall be done with the same procedures as the pre-test leak check, except that the post-test leak check shall be conducted at a vacuum greater than or equal to the maximum value reached during the sampling run. If the leakage rate is found to be no greater than 0.00057 m³/min (0.02 cfm) or 4% of the average sampling rate (whichever is less), the results are acceptable. If, however, a higher leakage rate is obtained, the tester shall record the leakage rate and void the sampling run.

6.6 Sampling Train Operation:

6.6.1 During the sampling run, maintain an isokinetic sampling rate to within 10% of true isokinetic, below 28 L/min (1.0 cfm). Maintain a temperature around the probe of 120° ± 14°C (248° ± 25°F).

6.6.2 For each run, record the data on a data sheet such as the one shown in Figure 2. Be sure to record the initial dry-gas meter reading. Record the dry-gas meter readings at the beginning and end of each sampling time increment, when changes in flow rates are made, before and after each leak check, and when sampling is halted. Take other readings required by Figure 2 at least once at each sample point during each time increment and additional readings when significant adjustments (20% variation in velocity head readings) necessitate additional adjustments in flow rate. Level and zero the manometer. Because the manometer level and zero may drift due to vibrations and temperature changes, make periodic checks during the traverse.

6.6.3 Clean the stack access ports prior to the test run to eliminate the chance of sampling deposited material. To begin sampling, remove the nozzle cap, verify that the filter and probe heating systems are at the specified temperature, and verify that the pitot tube and probe are properly positioned. Position the nozzle at the first traverse point, with the tip pointing directly into the gas stream. Immediately start the pump and adjust the flow to isokinetic conditions. Nomographs, which aid in the rapid adjustment of the isokinetic sampling rate without excessive computations, are available. These nomographs are designed for use when the Type S pitot tube coefficient is 0.84 ± 0.02 and the stack gas equivalent density (dry molecular weight) is equal to 29 ± 4. APTD-0576 details the procedure for using the nomographs. If the stack gas molecular weight and

minimize silicone grease contamination. If necessary, Teflon® tape may be used to seal leaks. Connect all temperature sensors to an appropriate potentiometer/display unit. Check all temperature sensors at ambient temperature.

6.4.5 Place crushed ice all around the impingers. . .

6.4.6 Turn on and set the probe heating system at the desired operating temperature. Allow time for the temperature to stabilize. . . .

6.5 Leak-Check Procedures:

6.5.1 Pre-test Leak Check:

6.5.1.1 After the sampling train has been assembled, turn on and set the probe heating system at the desired operating temperature. Allow time for the temperature to stabilize. If a Viton-A O-ring or other leak-free connection is used in assembling the probe nozzle to the probe liner, leak-check the train at the sampling site by plugging the nozzle and pulling a 381-mm Hg (15 in Hg) vacuum.

NOTE: A lower vacuum may be used, provided that the lower vacuum is not exceeded during the test.

6.5.1.2 If an asbestos string is used, do not connect the probe to the train during the leak check. Instead, leak-check the train by first attaching a carbon-filled leak check impinger to the inlet and then plugging the inlet and pulling a 381-mm Hg (15 in Hg) vacuum. (A lower vacuum may be used if this lower vacuum is not exceeded during the test.) Then connect the probe to the train and leak-check at about 25 mm Hg (1 in Hg) vacuum. Alternatively, leak-check the probe with the rest of the sampling train in one step at 381 mm Hg (15 in Hg) vacuum. Leakage rates in excess of 4% of the average sampling rate or $>0.00057 \text{ m}^3/\text{min}$ (0.02 cfm), whichever is less, are acceptable.

6.5.1.3 The following leak check instructions for the sampling train described in APTD-0576 and APTD-0581 may be helpful. Start the pump with the fine-adjust valve fully open and coarse-adjust valve completely closed. Partially open the coarse-adjust valve and slowly close the fine-adjust valve until the desired vacuum is reached. Do not reverse direction of the fine-adjust valve, as liquid will back up into the train. If the desired vacuum is exceeded, either perform the leak check at this higher vacuum or end the leak check, as shown below, and start over.

6.5.1.4 When the leak check is completed, first slowly remove the plug from the inlet to the probe. When the vacuum drops to 127 mm (5 in) Hg or less, immediately close the coarse-adjust valve. Switch off the pumping system and reopen the fine-adjust valve. Do not reopen the fine-adjust valve until the coarse-adjust valve has been closed to prevent the liquid in the impingers from being forced backward into the sampling line and silica gel from being entrained backward into the third impinger.

6.5.2 Leak Checks During Sampling Runs:

6.5.2.1 If, during the sampling run, a component change (i.e., impinger) becomes

the pitot tube coefficient are outside the above ranges, do not use the nomographs unless appropriate steps are taken to compensate for the deviations.

6.6.4 When the stack is under significant negative pressure (equivalent to the height of the impinger stem), take care to close the coarse-adjust valve before inserting the probe into the stack in order to prevent liquid from backing up through the train. If necessary, the pump may be turned on with the coarse-adjust valve closed.

6.6.5 When the probe is in position, block off the openings around the probe and stack access port to prevent unrepresentative dilution of the gas stream.

6.6.6 Traverse the stack cross section, as required by EPA Method 1, being careful not to bump the probe nozzle into the stack walls when sampling near the walls or when removing or inserting the probe through the access port, in order to minimize the chance of extracting deposited material.

6.6.7 During the test run, make periodic adjustments to keep the temperature around the probe at the proper levels. Add more ice and, if necessary, salt, to maintain a temperature of $<20^{\circ}\text{C}$ (68°F) at the silica gel outlet. Also, periodically check the level and zero of the manometer.

6.6.8 A single train shall be used for the entire sampling run, except in cases where simultaneous sampling is required in two or more separate ducts or at two or more different locations within the same duct, or in cases where equipment failure necessitates a change of trains. An additional train or additional trains may also be used for sampling when the capacity of a single train is exceeded.

6.6.9 When two or more trains are used, separate analyses of components from each train shall be performed. If multiple trains have been used because the capacity of a single train would be exceeded, first impingers from each train may be combined, and second impingers from each train may be combined.

6.6.10 At the end of the sampling run, turn off the coarse-adjust valve, remove the probe and nozzle from the stack, turn off the pump, record the final dry gas meter reading, and conduct a post-test leak check. Also, leak check the pitot lines as described in EPA Method 2. The lines must pass this leak check in order to validate the velocity-head data.

6.6.11 Calculate percent isokineticity (see Method 2) to determine whether the run was valid or another test should be made.

7.0 SAMPLE RECOVERY

7.1 Preparation:

7.1.1 Proper cleanup procedure begins as soon as the probe is removed from the stack at the end of the sampling period. Allow the probe to cool. When the probe can be handled safely, wipe off all external particulate matter near the tip of the probe nozzle and place a cap over the tip to prevent losing or gaining particulate matter. Do not cap the probe tip tightly while the sampling train is cooling because a vacuum will be created, drawing liquid from the impingers back through the sampling train.

7.1.2 Before moving the sampling train to the cleanup site, remove the probe from the sampling train and cap the open outlet, being careful not to lose any condensate that might be present. Remove the umbilical cord from the last impinger and cap the impinger. If a flexible line is used, let any condensed water or liquid drain into the impingers. Cap off any open impinger inlets and outlets. Ground glass stoppers, Teflon® caps, or caps of other inert materials may be used to seal all openings.

7.1.3 Transfer the probe and impinger assembly to an area that is clean and protected from wind so that the chances of contaminating or losing the sample are minimized.

7.1.4 Inspect the train before and during disassembly, and note any abnormal conditions.

7.1.5 Save a portion of all washing solutions (methylene chloride, water) used for cleanup as a blank. Transfer 200 mL of each solution directly from the wash bottle being used and place each in a separate, pre-labeled sample container.

7.2 Sample Containers:

7.2.1 Container 1: Probe and Impinger Catches. Using a graduated cylinder, measure to the nearest mL, and record the volume of the solution in the first three impingers. Alternatively, the solution may be weighed to the nearest 0.5 g. Include any condensate in the probe in this determination. Transfer the impinger solution from the graduated cylinder into the amber flint glass bottle. Taking care that dust on the outside of the probe or other exterior surfaces does not get into the sample, clean all surfaces to which the sample is exposed (including the probe nozzle, probe fitting, probe liner, first impinger, and impinger connector) with methylene chloride. Use less than 500 mL for the entire wash (250 mL would be better, if possible). Add the washings to the sample container.

7.2.1.1 Carefully remove the probe nozzle and rinse the inside surface with methylene chloride from a wash bottle. Brush with a Teflon® bristle brush, and rinse until the rinse shows no visible particles or yellow color, after which make a final rinse of the inside surface. Brush and rinse the inside parts of the Swagelok® fitting with methylene chloride in a similar way.

7.2.1.2 Rinse the probe liner with methylene chloride. While squirting the methylene chloride into the upper end of the probe, tilt and rotate the probe so that all inside surfaces will be wetted with methylene chloride. Let the methylene chloride drain from the lower end into the sample container. The tester may use a funnel (glass or polyethylene) to aid in transferring the liquid washes to the container. Follow the rinse with a Teflon® brush. Hold the probe in an inclined position, and squirt methylene chloride into the upper end as the probe brush is being pushed with a twisting action through the probe. Hold the sample container underneath the lower end of the probe, and catch any methylene chloride, water, and particulate matter that is brushed from the probe. Run the brush through the probe three times or more. With stainless steel or other metal probes, run the brush through in the above prescribed manner at least six times since there may be small crevices in which particulate matter can be entrapped. Rinse the brush with methylene chloride or water, and quantitatively collect these washings in the sample container. After the brushings, make a final rinse

of the probe as described above.

NOTE: Two people should clean the probe in order to minimize sample losses. Between sampling runs, brushes must be kept clean and free from contamination.

7.2.1.3 Rinse the inside surface of each of the first three impingers (and connecting tubing) three separate times. Use a small portion of methylene chloride for each rinse, and brush each surface to which sample is exposed with a Teflon® bristle brush to ensure recovery of fine particulate matter. Water will be required for the recovery of the impingers in addition to the specified quantity of methylene chloride. There will be at least two phases in the impingers. This two-phase mixture does not pour well, and a significant amount of the impinger catch will be left on the walls. The use of water as a rinse makes the recovery quantitative. Make a final rinse of each surface and of the brush, using both methylene chloride and water.

7.2.1.4 After all methylene chloride and water washings and particulate matter have been collected in the sample container, tighten the lid so that solvent, water, and DNPH reagent will not leak out when the container is shipped to the laboratory. Mark the height of the fluid level to determine whether leakage occurs during transport. Seal the container with Teflon® tape. Label the container clearly to identify its contents.

7.2.1.5 If the first two impingers are to be analyzed separately to check for breakthrough, separate the contents and rinses of the two impingers into individual containers. Care must be taken to avoid physical carryover from the first impinger to the second. The formaldehyde hydrazone is a solid which floats and froths on top of the impinger solution. Any physical carryover of collected moisture into the second impinger will invalidate a breakthrough assessment.

7.2.2 Container 2: Sample Blank. Prepare a blank by using an amber flint glass container and adding a volume of DNPH reagent and methylene chloride equal to the total volume in Container 1. Process the blank in the same manner as Container 1.

7.2.3 Container 3: Silica Gel. Note the color of the indicating silica gel to determine whether it has been completely spent and make a notation of its condition. The impinger containing the silica gel may be used as a sample transport container with both ends sealed with tightly fitting caps or plugs. Ground-glass stoppers or Teflon® caps may be used. The silica gel impinger should then be labeled, covered with aluminum foil, and packaged on ice for transport to the laboratory. If the silica gel is removed from the impinger, the tester may use a funnel to pour the silica gel and a rubber policeman to remove the silica gel from the impinger. It is not necessary to remove the small amount of dust particles that may adhere to the impinger wall and are difficult to remove. Since the gain in weight is to be used for moisture calculations, do not use water or other liquids to transfer the silica gel. If a balance is available in the field, the spent silica gel (or silica gel plus impinger) may be weighed to the nearest 0.5 g.

7.2.4 Sample containers should be placed in a cooler, cooled by although not in contact with ice. Sample containers must be placed vertically and, since they are glass, protected from breakage during shipment. Samples should be cooled during shipment so they will be received cold at the laboratory.

8.0 CALIBRATION

8.1 Probe Nozzle: Probe nozzles shall be calibrated before their initial use in the field. Using a micrometer, measure the inside diameter of the nozzle to the nearest 0.025 mm (0.001 in). Make measurements at three separate places across the diameter and obtain the average of the measurements. The difference between the high and low numbers shall not exceed 0.1 mm (0.004 in). When the nozzles become nicked or corroded, they shall be replaced and calibrated before use. Each nozzle must be permanently and uniquely identified.

8.2 Pitot tube: The Type S pitot tube assembly shall be calibrated according to the procedure outlined in Section 4 of EPA Method 2, or assigned a nominal coefficient of 0.84 if it is not visibly nicked or corroded and if it meets design and intercomponent spacing specifications.

8.3 Metering system:

8.3.1 Before its initial use in the field, the metering system shall be calibrated according to the procedure outlined in APTD-0576. Instead of physically adjusting the dry-gas meter dial readings to correspond to the wet-test meter readings, calibration factors may be used to correct the gas meter dial readings mathematically to the proper values. Before calibrating the metering system, it is suggested that a leak check be conducted. For metering systems having diaphragm pumps, the normal leak check procedure will not detect leakages within the pump. For these cases, the following leak check procedure will apply: make a ten-minute calibration run at $0.00057 \text{ m}^3/\text{min}$ (0.02 cfm). At the end of the run, take the difference of the measured wet-test and dry-gas meter volumes and divide the difference by 10 to get the leak rate. The leak rate should not exceed $0.00057 \text{ m}^3/\text{min}$ (0.02 cfm).

8.3.2 After each field use, check the calibration of the metering system by performing three calibration runs at a single intermediate orifice setting (based on the previous field test). Set the vacuum at the maximum value reached during the test series. To adjust the vacuum, insert a valve between the wet-test meter and the inlet of the metering system. Calculate the average value of the calibration factor. If the calibration has changed by more than 5%, recalibrate the meter over the full range of orifice settings, as outlined in APTD-0576.

8.3.3 Leak check of metering system: The portion of the sampling train from the pump to the orifice meter (see Figure 1) should be leak-checked prior to initial use and after each shipment. Leakage after the pump will result in less volume being recorded than is actually sampled. Use the following procedure: Close the main valve on the meter box. Insert a one-hole rubber stopper with rubber tubing attached into the orifice exhaust pipe. Disconnect and vent the low side of the orifice manometer. Close off the low side orifice tap. Pressurize the system to 13 - 18 cm (5 - 7 in) water column by blowing into the rubber tubing. Pinch off the tubing and observe the manometer for 1 min. A loss of pressure on the manometer indicates a leak in the meter box. Leaks must be corrected.

NOTE: If the dry-gas-meter coefficient values obtained before and after a test series differ by >5%, either the test series must be voided or calculations for test series must be performed using whichever meter coefficient value (i.e., before or after) gives the lower value of total sample volume.

8.4 Probe heater: The probe heating system must be calibrated before its initial use in the field according to the procedure outlined in APTD-0576. Probes constructed according to APTD-0581 need not be calibrated if the calibration curves in APTD-0576 are used.

8.5 Temperature gauges: Each thermocouple must be permanently and uniquely marked on the casting. All mercury-in-glass reference thermometers must conform to ASTM E-1 63C or 63F specifications. Thermocouples should be calibrated in the laboratory with and without the use of extension leads. If extension leads are used in the field, the thermocouple readings at ambient air temperatures, with and without the extension lead, must be noted and recorded. Correction is necessary if the use of an extension lead produces a change $>1.5\%$.

8.5.1 Impinger and dry-gas meter thermocouples: For the thermocouples used to measure the temperature of the gas leaving the impinger train, three-point calibration at ice water, room air, and boiling water temperatures is necessary. Accept the thermocouples only if the readings at all three temperatures agree to $\pm 2^{\circ}\text{C}$ (3.6°F) with those of the absolute value of the reference thermometer.

8.5.2 Probe and stack thermocouple: For the thermocouples used to indicate the probe and stack temperatures, a three-point calibration at ice water, boiling water, and hot oil bath temperatures must be performed. Use of a point at room air temperature is recommended. The thermometer and thermocouple must agree to within 1.5% at each of the calibration points. A calibration curve (equation) may be constructed (calculated) and the data extrapolated to cover the entire temperature range suggested by the manufacturer.

8.6 Barometer: Adjust the barometer initially and before each test series to agree to within ± 2.5 mm Hg (0.1 in Hg) of the mercury barometer or the corrected barometric pressure value reported by a nearby National Weather Service Station (same altitude above sea level).

8.7 Triple-beam balance: Calibrate the triple-beam balance before each test series, using Class S standard weights. The weights must be within $\pm 0.5\%$ of the standards, or the balance must be adjusted to meet these limits.

9.0 CALCULATIONS

Carry out calculations, retaining at least one extra decimal figure beyond that of the acquired data. Round off figures after final calculation.

9.1 Calculation of Total Formaldehyde:

To determine the total formaldehyde in mg, use the following equation:

$$\text{Total mg formaldehyde} = C_d \times V \times DF \times \\ \left(\frac{[\text{g/mole aldehyde}]}{[\text{g/mole DNPH derivative}]} \right) \times \\ 10^{-3} \text{ mg/\mu g}$$

where:

C_d = measured concentration of DNPH-formaldehyde derivative, $\mu\text{g/mL}$.

V = organic extract volume, mL

DF = dilution factor

9.2 Formaldehyde concentration in stack gas:

Determine the formaldehyde concentration in the stack gas using the following equation:

$$C_g = K [\text{total formaldehyde, mg}] / V_{m(\text{std})}$$

where:

$K = 35.31 \text{ ft}^3/\text{m}^3$ if $V_{m(\text{std})}$ is expressed in English units

$= 1.00 \text{ m}^3/\text{m}^3$ if $V_{m(\text{std})}$ is expressed in metric units

$V_{m(\text{std})}$ = volume of gas sample as measured by dry gas meter, corrected to standard conditions, dscm (dscf)

9.3 Average Dry Gas Meter Temperature and Average Orifice Pressure Drop are obtained from the data sheet.

9.4 Dry Gas Volume: Calculate $V_{m(\text{std})}$ and adjust for leakage, if necessary, using the equation in Section 6.3 of EPA Method 5.

9.5 Volume of Water Vapor and Moisture Content: Calculate the volume of water vapor and moisture content from equations 5-2 and 5-3 of EPA Method 5.

10.0 DETERMINATION OF VOLUME TO BE SAMPLED

To determine the minimum sample volume to be collected, use the following sequence of equations.

10.1 From prior analysis of the waste feed, the concentration of formaldehyde (FORM) introduced into the combustion system can be calculated. The degree of destruction and removal efficiency that is required is used to determine the maximum amount of FORM allowed to be present in the effluent. This amount may be expressed as:

Max FORM₁ Mass -

$$[(WF) (FORM_1 \text{ conc}) (100 - XDRE)] / 100$$

where:

WF - mass flow rate of waste feed per h, g/h (lb/h)

FORM₁ - concentration of FORM (wt %) introduced into the combustion process

DRE - percent Destruction and Removal Efficiency required

Max FORM - mass flow rate (g/h [lb/h]) of FORM emitted from the combustion source

10.2 The average discharge concentration of the FORM in the effluent gas is determined by comparing the Max FORM with the volumetric flow rate being exhausted from the source. Volumetric flow rate data are available as a result of preliminary EPA Method 1 - 4 determinations:

$$\text{Max FORM}_1 \text{ conc} = [\text{Max FORM}_1 \text{ Mass}] / DV_{\text{eff(Std)}}$$

where:

DV_{eff(Std)} - volumetric flow rate of exhaust gas, dscm (dscf)

FORM₁ conc - anticipated concentration of the FORM in the exhaust gas stream, g/dscm (lb/dscf)

10.3 In making this calculation, it is recommended that a safety margin of at least ten be included.

$$[LDL_{\text{FORM}} \times 10] / [FORM_1 \text{ conc}] = V_{\text{tbc}}$$

where:

LDL_{FORM} - detectable amount of FORM in entire sampling train

V_{tbc} - minimum dry standard volume to be collected at dry-gas meter

10.4 The following analytical detection limits and DNPH Reagent Capacity (based on a total volume of 200 mL in two impingers) must also be considered in determining a volume to be sampled.

Table 2. Instrument Detection Limits and Reagent Capacity for Formaldehyde Analysis¹

Analyte	Detection Limit, ppbv ²	Reagent Capacity, ppmv
formaldehyde	1.8	66
acetaldehyde	1.7	70
acrolein	1.5	75
acetone/propionaldehyde	1.5	75
butyraldehyde	1.5	79
methyl ethyl ketone	1.5	79
valeraldehyde	1.5	84
isovaleraldehyde	1.4	84
hexaldehyde	1.3	88
benzaldehyde	1.4	84
o-/m-/p-tolualdehyde	1.3	89
dimethylbenzaldehyde	1.2	93

¹ Oxygenated compounds in addition to formaldehyde are included for comparison with formaldehyde; extension of the methodology to other compounds is possible.

² Detection limits are determined in solvent. These values therefore represent the optimum capability of the methodology.

11.0 QUALITY CONTROL

11.1 Sampling: See EPA Manual 600/4-77-027b for Method 5 quality control.

11.2 Analysis: The quality assurance program required for this method includes the analysis of field and method blanks, procedure validations, and analysis of field spikes. The assessment of combustion data and positive identification and quantitation of formaldehyde are dependent on the integrity of the samples received and the precision and accuracy of the analytical methodology. Quality Assurance procedures for this method are designed to monitor the performance of the analytical methodology and to provide the required information to take corrective action if problems are observed in laboratory operations or in field sampling activities.

11.2.1 Field Blanks: Field blanks must be submitted with the samples collected at each sampling site. The field blanks include the sample bottles containing aliquots of sample recovery solvents, methylene chloride and water, and unused DNPH reagent. At a minimum, one complete sampling train will be assembled in the field staging area, taken to the sampling area, and leak-checked at the beginning and end of the testing (or for the same total number of times as the actual sampling train). The probe of the blank train must be heated during the sample test. The train will be recovered as if it were an actual test sample. No gaseous sample will be passed through the Blank sampling train.

11.2.2 Method Blanks: A method blank must be prepared for each set of analytical operations, to evaluate contamination and artifacts that can be derived from glassware, reagents, and sample handling in the laboratory.

11.2.3 Field Spike: A field spike is performed by introducing 200 μ L of the Field Spike Standard into an impinger containing 200 mL of DNPH solution. Standard impinger recovery procedures are followed and the field spike sample is returned to the laboratory for analysis. The field spike is used as a check on field handling and recovery procedures. An aliquot of the field spike standard is retained in the laboratory for derivatization and comparative analysis.

12.0 METHOD PERFORMANCE

12.1 Method performance evaluation: The following expected method performance parameters for precision, accuracy, and detection limits are provided in Table 3.


Table 3. Expected Method Performance for Formaldehyde

Parameter	Precision	¹ Accuracy ²	Detection Limit ³
Matrix: Dual trains	$\pm 15\%$ RPD	$\pm 20\%$	1.5×10^{-7} lb/ft ³ (1.8 ppbv)

¹ Relative percent difference limit for dual trains.

² Limit for field spike recoveries.

³ The lower reporting limit having less than 1% probability of false positive detection.



Formaldehyde Sampling Train

Ambient Temperature _____
 Barometric Pressure _____
 Assumed Moisture % _____
 Probe Length, m(ft) _____
 Nozzle Identification No. _____
 Average Calibrated Nozzle Diameter, cm (in) _____
 Probe Heating Setting _____
 Leak Rate, m³/min. (cfm) _____
 Probe Liner Material _____
 Static Pressure, mm Hg (in. Hg) _____
 Filter No. _____

Schematics of Stack Cross Section

Pilot Tube Coefficient C_p [illegible]

Figure 2. Field Data Sheet

Interpoll Laboratories
4500 Ball Road N.E.
Circle Pines, Minnesota 55014

Telephone (612)786-6020
Facsimile (612)786-7854

COLLECTION OF SEMIVOLATILE COMPOUNDS

EPA METHOD 0010

(Interpoll Method II-8788 - Version 1.0)

EPA Method SW846 USEPA Office of Solid Waste and Emergency Response 3rd
Ed., November 1986: Test Methods for Evaluating Solid Waste Volume 2:
Field Manual Physical/Chemical Methods Method 0010.

MODIFIED METHOD 5 SAMPLING TRAIN

1.0 SCOPE AND APPLICATION

1.1 This method is applicable to the determination of Destruction and Removal Efficiency (DRE) of semivolatile Principal Organic Hazardous Compounds (POHCs) from incineration systems (PHS, 1967). This method also may be used to determine particulate emission rates from stationary sources as per EPA Method 5 (see References at end of this method).

2.0 SUMMARY OF METHOD

2.1 Gaseous and particulate pollutants are withdrawn from an emission source at an isokinetic sampling rate and are collected in a multicomponent sampling train. Principal components of the train include a high-efficiency glass- or quartz-fiber filter and a packed bed of porous polymeric adsorbent resin. The filter is used to collect organic-laden particulate materials and the porous polymeric resin to adsorb semivolatile organic species. Semivolatile species are defined as compounds with boiling points $>100^{\circ}\text{C}$.

2.2 Comprehensive chemical analyses of the collected sample are conducted to determine the concentration and identity of the organic materials.

3.0 INTERFERENCES

3.1 Oxides of nitrogen (NO_x) are possible interferents in the determination of certain water-soluble compounds such as dioxane, phenol, and urethane; reaction of these compounds with NO_x in the presence of moisture will reduce their concentration. Other possibilities that could result in positive or negative bias are (1) stability of the compounds in methylene chloride, (2) the formation of water-soluble organic salts on the resin in the presence of moisture, and (3) the solvent extraction efficiency of water-soluble compounds from aqueous media. Use of two or more ions per compound for qualitative and quantitative analysis can overcome interference at one mass. These concerns should be addressed on a compound-by-compound basis before using this method.

4.0 APPARATUS AND MATERIALS

4.1 Sampling train:

4.1.1 A schematic of the sampling train used in this method is shown in Figure 1. This sampling train configuration is adapted from EPA Method 5 procedures, and, as such, the majority of the required equipment




Figure 1. Modified Method 5 Sampling Train.

0010 - 2

Revision 0
Date September 1986

is identical to that used in EPA Method 5 determinations. The new components required are a condenser coil and a sorbent module, which are used to collect semivolatile organic materials that pass through the glass- or quartz-fiber filter in the gas phase.

4.1.2 Construction details for the basic train components are given in APTD-0581 (see Martin, 1971, in Section 13.0, References); commercial models of this equipment are also available. Specifications for the sorbent module are provided in the following subsections. Additionally, the following subsections list changes to APTD-0581 and identify allowable train configuration modifications.

4.1.3 Basic operating and maintenance procedures for the sampling train are described in APTD-0576 (see Rom, 1972, in Section 13.0, References). As correct usage is important in obtaining valid results, all users should refer to APTD-0576 and adopt the operating and maintenance procedures outlined therein unless otherwise specified. The sampling train consists of the components detailed below.

4.1.3.1 Probe nozzle: Stainless steel (316) or glass with sharp, tapered (30° angle) leading edge. The taper shall be on the outside to preserve a constant I.D. The nozzle shall be buttonhook or elbow design and constructed from seamless tubing (if made of stainless steel). Other construction materials may be considered for particular applications. A range of nozzle sizes suitable for isokinetic sampling should be available in increments of 0.16 cm (1/16 in.), e.g., 0.32-1.27 cm (1/8-1/2 in.), or larger if higher volume sampling trains are used. Each nozzle shall be calibrated according to the procedures outlined in Paragraph 9.1.

4.1.3.2 Probe liner: Borosilicate or quartz-glass tubing with a heating system capable of maintaining a gas temperature of $120 \pm 14^{\circ}\text{C}$ ($248 \pm 25^{\circ}\text{F}$) at the exit end during sampling. (The tester may opt to operate the equipment at a temperature lower than that specified.) Because the actual temperature at the outlet of the probe is not usually monitored during sampling, probes constructed according to APTD-0581 and utilizing the calibration curves of APTD-0576 (or calibrated according to the procedure outlined in APTD-0576) are considered acceptable. Either borosilicate or quartz-glass probe liners may be used for stack temperatures up to about 480°C (900°F). Quartz liners shall be used for temperatures between 480 and 900°C (900 and 1650°F). (The softening temperature for borosilicate is 820°C (1508°F), and for quartz 1500°C (2732°F).) Water-cooling of the stainless steel sheath will be necessary at temperatures approaching and exceeding 500°C .

4.1.3.3 Pitot tube: Type S, as described in Section 2.1 of EPA Method 2, or other appropriate devices (Vollaro, 1976). The pitot tube shall be attached to the probe to allow constant monitoring of the stack-gas velocity. The impact (high-pressure) opening plane of the pitot tube shall be even with or above the nozzle entry plane (see EPA Method 2, Figure 2-6b) during sampling. The Type S pitot tube assembly shall have a known coefficient, determined as outlined in Section 4 of EPA Method 2.

0010 - 3

Revision 0
Date September 1986

4.1.3.4 Differential pressure gauge: Inclined manometer or equivalent device as described in Section 2.2 of EPA Method 2. One manometer shall be used for velocity-head (ΔP) readings and the other for orifice differential pressure (ΔH) readings.

4.1.3.5 Filter holder: Borosilicate glass, with a glass frit filter support and a sealing gasket. The sealing gasket should be made of materials that will not introduce organic material into the gas stream at the temperature at which the filter holder will be maintained. The gasket shall be constructed of Teflon or materials of equal or better characteristics. The holder design shall provide a positive seal against leakage at any point along the filter circumference. The holder shall be attached immediately to the outlet of the cyclone or cyclone bypass.

4.1.3.6 Filter heating system: Any heating system capable of maintaining a temperature of $120 \pm 14^{\circ}\text{C}$ ($248 \pm 25^{\circ}\text{F}$) around the filter holder during sampling. Other temperatures may be appropriate for particular applications. Alternatively, the tester may opt to operate the equipment at temperatures other than that specified. A temperature gauge capable of measuring temperature to within 3°C (5.4°F) shall be installed so that the temperature around the filter holder can be regulated and monitored during sampling. Heating systems other than the one shown in APTD-0581 may be used.

4.1.3.7 Organic sampling module: This unit consists of three sections, including a gas-conditioning section, a sorbent trap, and a condensate knockout trap. The gas-conditioning system shall be capable of conditioning the gas leaving the back half of the filter holder to a temperature not exceeding 20°C (68°F). The sorbent trap shall be sized to contain approximately 20 g of porous polymeric resin (Rohm and Haas XAD-2 or equivalent) and shall be jacketed to maintain the internal gas temperature at $17 \pm 3^{\circ}\text{C}$ ($62.5 \pm 5.4^{\circ}\text{F}$). The most commonly used coolant is ice water from the impinger ice-water bath, constantly circulated through the outer jacket, using rubber or plastic tubing and a peristaltic pump. The sorbent trap should be outfitted with a glass well or depression, appropriately sized to accommodate a small thermocouple in the trap for monitoring the gas entry temperature. The condensate knockout trap shall be of sufficient size to collect the condensate following gas conditioning. The organic module components shall be oriented to direct the flow of condensate formed vertically downward from the conditioning section, through the adsorbent media, and into the condensate knockout trap. The knockout trap is usually similar in appearance to an empty impinger directly underneath the sorbent module; it may be oversized but should have a shortened center stem (at a minimum, one-half the length of the normal impinger stems) to collect a large volume of condensate without bubbling and overflowing into the impinger train. All surfaces of the organic module wetted by the gas sample shall be fabricated of borosilicate glass, Teflon, or other inert materials. Commercial versions of the

complete organic module are not currently available, but may be assembled from commercially available laboratory glassware and a custom-fabricated sorbent trap. Details of two acceptable designs are shown in Figures 2 and 3 (the thermocouple well is shown in Figure 2).

4.1.3.8 Impinger train: To determine the stack-gas moisture content, four 500-mL impingers, connected in series with leak-free ground-glass joints, follow the knockout trap. The first, third, and fourth impingers shall be of the Greenburg-Smith design, modified by replacing the tip with a 1.3-cm (1/2-in.) I.D. glass tube extending about 1.3 cm (1/2 in.) from the bottom of the outer cylinder. The second impinger shall be of the Greenburg-Smith design with the standard tip. The first and second impingers shall contain known quantities of water or appropriate trapping solution. The third shall be empty or charged with a caustic solution, should the stack gas contain hydrochloric acid (HCl). The fourth shall contain a known weight of silica gel or equivalent desiccant.

4.1.3.9 Metering system: The necessary components are a vacuum gauge, leak-free pump, thermometers capable of measuring temperature to within 3°C (5.4°F), dry-gas meter capable of measuring volume to within 1%, and related equipment, as shown in Figure 1. At a minimum, the pump should be capable of 4 cfm free flow, and the dry-gas meter should have a recording capacity of 0-999.9 cu ft with a resolution of 0.005 cu ft. Other metering systems capable of maintaining sampling rates within 10% of isokineticity and of determining sample volumes to within 2% may be used. The metering system must be used in conjunction with a pitot tube to enable checks of isokinetic sampling rates. Sampling trains using metering systems designed for flow rates higher than those described in APTD-0581 and APTD-0576 may be used, provided that the specifications of this method are met.

4.1.3.10 Barometer: Mercury, aneroid, or other barometer capable of measuring atmospheric pressure to within 2.5 mm Hg (0.1 in. Hg). In many cases the barometric reading may be obtained from a nearby National Weather Service station, in which case the station value (which is the absolute barometric pressure) is requested and an adjustment for elevation differences between the weather station and sampling point is applied at a rate of minus 2.5 mm Hg (0.1 in. Hg) per 30-m (100 ft) elevation increase (vice versa for elevation decrease).

4.1.3.11 Gas density determination equipment: Temperature sensor and pressure gauge (as described in Sections 2.3 and 2.4 of EPA Method 2), and gas analyzer, if necessary (as described in EPA Method 3). The temperature sensor ideally should be permanently attached to the pitot tube or sampling probe in a fixed configuration such that the tip of the sensor extends beyond the leading edge of the probe sheath and does not touch any metal.




Figure 2. Adsorbent Sampling System.

0010 - 6

Revision 0
Date September 1986




Figure 3. Adsorbent Sampling System.

0010 - 7

Revision 0
Date September 1986

Alternatively, the sensor may be attached just prior to use in the field. Note, however, that if the temperature sensor is attached in the field, the sensor must be placed in an interference-free arrangement with respect to the Type S pitot tube openings (see EPA Method 2, Figure 2-7). As a second alternative, if a difference of no more than 1% in the average velocity measurement is to be introduced, the temperature gauge need not be attached to the probe or pitot tube.

4.1.3.12 Calibration/field-preparation record: A permanently bound laboratory notebook, in which duplicate copies of data may be made as they are being recorded, is required for documenting and recording calibrations and preparation procedures (i.e., filter and silica gel tare weights, clean XAD-2, quality assurance/quality control check results, dry-gas meter, and thermocouple calibrations, etc.). The duplicate copies should be detachable and should be stored separately in the test program archives.

4.2 Sample Recovery:

4.2.1 Probe liner: Probe nozzle and organic module conditioning section brushes; nylon bristle brushes with stainless steel wire handles are required. The probe brush shall have extensions of stainless steel, Teflon, or inert material at least as long as the probe. The brushes shall be properly sized and shaped to brush out the probe liner, the probe nozzle, and the organic module conditioning section.

4.2.2 Wash bottles: Three. Teflon or glass wash bottles are recommended; polyethylene wash bottles should not be used because organic contaminants may be extracted by exposure to organic solvents used for sample recovery.

4.2.3 Glass sample storage containers: Chemically resistant, borosilicate amber and clear glass bottles, 500-mL or 1,000-mL. Bottles should be tinted to prevent action of light on sample. Screw-cap liners shall be either Teflon or constructed so as to be leak-free and resistant to chemical attack by organic recovery solvents. Narrow-mouth glass bottles have been found to exhibit less tendency toward leakage.

4.2.4 Petri dishes: Glass, sealed around the circumference with wide (1-in.) Teflon tape, for storage and transport of filter samples.

4.2.5 Graduated cylinder and/or balances: To measure condensed water to the nearest 1 mL or 1 g. Graduated cylinders shall have subdivisions not >2 mL. Laboratory triple-beam balances capable of weighing to ± 0.5 g or better are required.

4.2.6 Plastic storage containers: Screw-cap polypropylene or polyethylene containers to store silica gel.

4.2.7 Funnel and rubber policeman: To aid in transfer of silica gel to container (not necessary if silica gel is weighed in field).

4.2.8 Funnels: Glass, to aid in sample recovery.

4.3 Filters: Glass- or quartz-fiber filters, without organic binder, exhibiting at least 99.95% efficiency ($<0.05\%$ penetration) on 0.3- μ m dioctyl phthalate smoke particles. The filter efficiency test shall be conducted in accordance with ASTM standard method D2986-71. Test data from the supplier's quality control program are sufficient for this purpose. In sources containing SO_2 or SO_3 , the filter material must be of a type that is unreactive to SO_2 or SO_3 . Reeve Angel 934 AH or Schleicher and Schuell #3 filters work well under these conditions.

4.4 Crushed ice: Quantities ranging from 10-50 lb may be necessary during a sampling run, depending on ambient air temperature.

4.5 Stopcock grease: Solvent-insoluble, heat-stable silicone grease. Use of silicone grease upstream of the module is not permitted, and amounts used on components located downstream of the organic module shall be minimized. Silicone grease usage is not necessary if screw-on connectors and Teflon sleeves or ground-glass joints are used.

4.6 Glass wool: Used to plug the unfritted end of the sorbent module. The glass-wool fiber should be solvent-extracted with methylene chloride in a Soxhlet extractor for 12 hr and air-dried prior to use.

5.0 REAGENTS

5.1 Adsorbent resin: Porous polymeric resin (XAD-2 or equivalent) is recommended. These resins shall be cleaned prior to their use for sample collection. Appendix A of this method should be consulted to determine appropriate precleaning procedure. For best results, resin used should not exhibit a blank of higher than 4 mg/kg of total chromatographable organics (TCO) (see Appendix B) prior to use. Once cleaned, resin should be stored in an airtight, wide-mouth amber glass container with a Teflon-lined cap or placed in one of the glass sorbent modules tightly sealed with Teflon film and elastic bands. The resin should be used within 4 wk of the preparation.

5.2 Silica gel: Indicating type, 6-16 mesh. If previously used, dry at 175°C (350°F) for 2 hr before using. New silica gel may be used as received. Alternatively, other types of desiccants (equivalent or better) may be used, subject to the approval of the Administrator.

5.3 Impinger solutions: Distilled organic-free water (Type II) shall be used, unless sampling is intended to quantify a particular inorganic gaseous species. If sampling is intended to quantify the concentration of additional species, the impinger solution of choice shall be subject to Administrator approval. This water should be prescreened for any compounds of interest. One hundred mL will be added to the specified impinger; the third impinger in the train may be charged with a basic solution (1 N sodium hydroxide or sodium acetate) to protect the sampling pump from acidic gases. Sodium acetate should be used when large sample volumes are anticipated because sodium hydroxide will react with carbon dioxide in aqueous media to form sodium carbonate, which may possibly plug the impinger.

0010 - 9

Revision 0
Date September 1986

5.4 Sample recovery reagents:

5.4.1 Methylene chloride: Distilled-in-glass grade is required for sample recovery and cleanup (see Note to 5.4.2 below).

5.4.2 Methyl alcohol: Distilled-in-glass grade is required for sample recovery and cleanup.

NOTE: Organic solvents from metal containers may have a high residue blank and should not be used. Sometimes suppliers transfer solvents from metal to glass bottles; thus blanks shall be run prior to field use and only solvents with low blank value ($<0.001\%$) shall be used.

5.4.3 Water: Water (Type II) shall be used for rinsing the organic module and condenser component.

6.0 SAMPLE COLLECTION, PRESERVATION, AND HANDLING

6.1 Because of complexity of this method, field personnel should be trained in and experienced with the test procedures in order to obtain reliable results.

6.2 Laboratory preparation:

6.2.1 All the components shall be maintained and calibrated according to the procedure described in APTD-0576, unless otherwise specified.

6.2.2 Weigh several 200- to 300-g portions of silica gel in airtight containers to the nearest 0.5 g. Record on each container the total weight of the silica gel plus containers. As an alternative to preweighing the silica gel, it may instead be weighed directly in the impinger or sampling holder just prior to train assembly.

6.2.3 Check filters visually against light for irregularities and flaws or pinhole leaks. Label the shipping containers (glass Petri dishes) and keep the filters in these containers at all times except during sampling and weighing.

6.2.4 Desiccate the filters at $20 \pm 5.6^{\circ}\text{C}$ ($68 \pm 10^{\circ}\text{F}$) and ambient pressure for at least 24 hr, and weigh at intervals of at least 6 hr to a constant weight (i.e., $<0.5\text{-mg}$ change from previous weighing), recording results to the nearest 0.1 mg. During each weighing the filter must not be exposed for more than a 2-min period to the laboratory atmosphere and relative humidity above 50%. Alternatively (unless otherwise specified by the Administrator), the filters may be oven-dried at 105°C (220°F) for 2-3 hr, desiccated for 2 hr, and weighed.

0010 - 10

Revision 0
Date September 1986

6.3 Preliminary field determinations:

6.3.1 Select the sampling site and the minimum number of sampling points according to EPA Method 1 or as specified by the Administrator. Determine the stack pressure, temperature, and range of velocity heads using EPA Method 2. It is recommended that a leak-check of the pitot lines (see EPA Method 2, Section 3.1) be performed. Determine the stack-gas moisture content using EPA Approximation Method 4 or its alternatives to establish estimates of isokinetic sampling-rate settings. Determine the stack-gas dry molecular weight, as described in EPA Method 2, Section 3.6. If integrated EPA Method 3 sampling is used for molecular weight determination, the integrated bag sample shall be taken simultaneously with, and for the same total length of time as, the sample run.

6.3.2 Select a nozzle size based on the range of velocity heads so that it is not necessary to change the nozzle size in order to maintain isokinetic sampling rates. During the run, do not change the nozzle. Ensure that the proper differential pressure gauge is chosen for the range of velocity heads encountered (see Section 2.2 of EPA Method 2).

6.3.3 Select a suitable probe liner and probe length so that all traverse points can be sampled. For large stacks, to reduce the length of the probe, consider sampling from opposite sides of the stack.

6.3.4 A minimum of 3 dscm (105.9 dscf) of sample volume is required for the determination of the Destruction and Removal Efficiency (DRE) of POHCs from incineration systems. Additional sample volume shall be collected as necessitated by analytical detection limit constraints. To determine the minimum sample volume required, refer to sample calculations in Section 10.0.

6.3.5 Determine the total length of sampling time needed to obtain the identified minimum volume by comparing the anticipated average sampling rate with the volume requirement. Allocate the same time to all traverse points defined by EPA Method 1. To avoid timekeeping errors, the length of time sampled at each traverse point should be an integer or an integer plus one-half min.

6.3.6 In some circumstances (e.g., batch cycles) it may be necessary to sample for shorter times at the traverse points and to obtain smaller gas-sample volumes. In these cases, the Administrator's approval must first be obtained.

6.4 Preparation of collection train:

6.4.1 During preparation and assembly of the sampling train, keep all openings where contamination can occur covered with Teflon film or aluminum foil until just prior to assembly or until sampling is about to begin.

6.4.2 Fill the sorbent trap section of the organic module with approximately 20 g of clean adsorbent resin. While filling, ensure that the trap packs uniformly, to eliminate the possibility of channeling. When freshly cleaned, many adsorbent resins carry a static charge, which will cause clinging to trap walls. This may be minimized by filling the trap in the presence of an antistatic device. Commercial antistatic devices include Model-204 and Model-210 manufactured by the 3M Company, St. Paul, Minnesota.

6.4.3 If an impinger train is used to collect moisture, place 100 mL of water in each of the first two impingers, leave the third impinger empty (or charge with caustic solution, as necessary), and transfer approximately 200-300 g of preweighed silica gel from its container to the fourth impinger. More silica gel may be used, but care should be taken to ensure that it is not entrained and carried out from the impinger during sampling. Place the container in a clean place for later use in the sample recovery. Alternatively, the weight of the silica gel plus impinger may be determined to the nearest 0.5 g and recorded.

6.4.4 Using a tweezer or clean disposable surgical gloves, place a labeled (identified) and weighed filter in the filter holder. Be sure that the filter is properly centered and the gasket properly placed to prevent the sample gas stream from circumventing the filter. Check the filter for tears after assembly is completed.

6.4.5 When glass liners are used, install the selected nozzle using a Viton-A O-ring when stack temperatures are $<260^{\circ}\text{C}$ (500°F) and a woven glass-fiber gasket when temperatures are higher. See APTD-0576 (Rev, 1972) for details. Other connecting systems utilizing either 316 stainless steel or Teflon ferrules may be used. When metal liners are used, install the nozzle as above, or by a leak-free direct mechanical connection. Mark the probe with heat-resistant tape or by some other method to denote the proper distance into the stack or duct for each sampling point.

6.4.6 Set up the train as in Figure 1. During assembly, do not use any silicone grease on ground-glass joints that are located upstream of the organic module. A very light coating of silicone grease may be used on all ground-glass joints that are located downstream of the organic module, but it should be limited to the outer portion (see APTD-0576) of the ground-glass joints to minimize silicone-grease contamination. Subject to the approval of the Administrator, a glass cyclone may be used between the probe and the filter holder when the total particulate catch is expected to exceed 100 mg or when water droplets are present in the stack. The organic module condenser must be maintained at a temperature of $17 \pm 3^{\circ}\text{C}$. Connect all temperature sensors to an appropriate potentiometer/display unit. Check all temperature sensors at ambient temperature.

6.4.7 Place crushed ice around the impingers and the organic module condensate knockout.

6.4.8 Turn on the sorbent module and condenser coil coolant recirculating pump and begin monitoring the sorbent module gas entry temperature. Ensure proper sorbent module gas entry temperature before proceeding and again before any sampling is initiated. It is extremely important that the XAD-2 resin temperature never exceed 50°C (122°F), because thermal decomposition will occur. During testing, the XAD-2 temperature must not exceed 20°C (68°F) for efficient capture of the semivolatile species of interest.

6.4.9 Turn on and set the filter and probe heating systems at the desired operating temperatures. Allow time for the temperatures to stabilize.

6.5 Leak-check procedures

6.5.1 Pre-test leak-check:

6.5.1.1 Because the number of additional intercomponent connections in the Semi-VOST train (over the M5 Train) increases the possibility of leakage, a pre-test leak-check is required.

6.5.1.2 After the sampling train has been assembled, turn on and set the filter and probe heating systems at the desired operating temperatures. Allow time for the temperatures to stabilize. If a Viton A O-ring or other leak-free connection is used in assembling the probe nozzle to the probe liner, leak-check the train at the sampling site by plugging the nozzle and pulling a 381-mm Hg (15-in. Hg) vacuum.

(NOTE: A lower vacuum may be used, provided that it is not exceeded during the test.)

6.5.1.3 If an asbestos string is used, do not connect the probe to the train during the leak-check. Instead, leak-check the train by first attaching a carbon-filled leak-check impinger (shown in Figure 4) to the inlet of the filter holder (cyclone, if applicable) and then plugging the inlet and pulling a 381-mm Hg (15-in. Hg) vacuum. (Again, a lower vacuum may be used, provided that it is not exceeded during the test.) Then, connect the probe to the train and leak-check at about 25-mm Hg (1-in. Hg) vacuum; alternatively, leak-check the probe with the rest of the sampling train in one step at 381-mm Hg (15-in. Hg) vacuum. Leakage rates in excess of 4% of the average sampling rate or $>0.00057 \text{ m}^3/\text{min}$ (0.02 cfm), whichever is less, are unacceptable.

6.5.1.4 The following leak-check instructions for the sampling train described in APTD-0576 and APTD-0581 may be helpful. Start the pump with fine-adjust valve fully open and coarse-adjust valve completely closed. Partially open the coarse-adjust valve and slowly close the fine-adjust valve until the desired vacuum is reached. Do not reverse direction of the fine-adjust valve; this will cause water to back up into the organic module. If the desired vacuum is exceeded, either leak-check at this higher vacuum or end the leak-check, as shown below, and start over.

0010 - 13

Revision 0
Date September 1986

CROSS SECTIONAL VIEW
Leak Testing Apparatus




Figure 4. Leak-check impinger.

0010 - 14

Revision 0
Date September 1986

6.5.1.5 When the leak-check is completed, first slowly remove the plug from the inlet to the probe, filter holder, or cyclone (if applicable). When the vacuum drops to 127 mm (5 in.) Hg or less, immediately close the coarse-adjust valve. Switch off the pumping system and reopen the fine-adjust valve. Do not reopen the fine-adjust valve until the coarse-adjust valve has been closed. This prevents the water in the impingers from being forced backward into the organic module and silica gel from being entrained backward into the third impinger.

6.5.2 Leak-checks during sampling run:

6.5.2.1 If, during the sampling run, a component (e.g., filter assembly, impinger, or sorbent trap) change becomes necessary, a leak-check shall be conducted immediately after the interruption of sampling and before the change is made. The leak-check shall be done according to the procedure outlined in Paragraph 6.5.1, except that it shall be done at a vacuum greater than or equal to the maximum value recorded up to that point in the test. If the leakage rate is found to be no greater than $0.00057 \text{ m}^3/\text{min}$ (0.02 cfm) or 4% of the average sampling rate (whichever is less), the results are acceptable, and no correction will need to be applied to the total volume of dry gas metered. If a higher leakage rate is obtained, the tester shall void the sampling run. (It should be noted that any "correction" of the sample volume by calculation by calculation reduces the integrity of the pollutant concentrations data generated and must be avoided.)

6.5.2.2 Immediately after a component change, and before sampling is reinitiated, a leak-check similar to a pre-test leak-check must also be conducted.

6.5.3 Post-test leak-check:

6.5.3.1 A leak-check is mandatory at the conclusion of each sampling run. The leak-check shall be done with the same procedures as those with the pre-test leak-check, except that it shall be conducted at a vacuum greater than or equal to the maximum value reached during the sampling run. If the leakage rate is found to be no greater than $0.00057 \text{ m}^3/\text{min}$ (0.02 cfm) or 4% of the average sampling rate (whichever is less), the results are acceptable, and no correction need be applied to the total volume of dry gas metered. If, however, a higher leakage rate is obtained, the tester shall either record the leakage rate, correct the sample volume (as shown in the calculation section of this method), and consider the data obtained of questionable reliability, or void the sampling run.

6.6 Sampling-train operation:

6.6.1 During the sampling run, maintain an isokinetic sampling rate to within 10% of true isokinetic, unless otherwise specified by the Administrator. Maintain a temperature around the filter of $120 \pm 14^\circ\text{C}$ ($248 \pm 25^\circ\text{F}$) and a gas temperature entering the sorbent trap at a maximum of 20°C (68°F).

6.6.2 For each run, record the data required on a data sheet such as the one shown in Figure 5. Be sure to record the initial dry-gas meter reading. Record the dry-gas meter readings at the beginning and end of each sampling time increment, when changes in flow rates are made before and after each leak-check, and when sampling is halted. Take other readings required by Figure 5 at least once at each sample point during each time increment and additional readings when significant changes (20% variation in velocity-head readings) necessitate additional adjustments in flow rate. Level and zero the manometer. Because the manometer level and zero may drift due to vibrations and temperature changes, make periodic checks during the traverse.

6.6.3 Clean the stack access ports prior to the test run to eliminate the chance of sampling deposited material. To begin sampling, remove the nozzle cap, verify that the filter and probe heating systems are at the specified temperature, and verify that the pitot tube and probe are properly positioned. Position the nozzle at the first traverse point, with the tip pointing directly into the gas stream. Immediately start the pump and adjust the flow to isokinetic conditions. Nomographs, which aid in the rapid adjustment of the isokinetic sampling rate without excessive computations, are available. These nomographs are designed for use when the Type S pitot-tube coefficient is 0.84 ± 0.02 and the stack-gas equivalent density (dry molecular weight) is equal to 29 ± 4 . APTD-0576 details the procedure for using the nomographs. If the stack-gas molecular weight and the pitot-tube coefficient are outside the above ranges, do not use the nomographs unless appropriate steps (Shigehara, 1974) are taken to compensate for the deviations.

6.6.4 When the stack is under significant negative pressure (equivalent to the height of the impinger stem), take care to close the coarse-adjust valve before inserting the probe into the stack, to prevent water from backing into the organic module. If necessary, the pump may be turned on with the coarse-adjust valve closed.

6.6.5 When the probe is in position, block off the openings around the probe and stack access port to prevent unrepresentative dilution of the gas stream.

6.6.6 Traverse the stack cross section, as required by EPA Method 1 or as specified by the Administrator, being careful not to bump the probe nozzle into the stack walls when sampling near the walls or when removing or inserting the probe through the access port, in order to minimize the chance of extracting deposited material.

6.6.7 During the test run, make periodic adjustments to keep the temperature around the filter holder and the organic module at the proper levels; add more ice and, if necessary, salt to maintain a temperature of $<20^{\circ}\text{C}$ (68°F) at the condenser/silica gel outlet. Also, periodically check the level and zero of the manometer.

6.6.8 If the pressure drop across the filter or sorbent trap becomes too high, making isokinetic sampling difficult to maintain, the filter/sorbent trap may be replaced in the midst of a sample run. Using another complete filter holder/sorbent trap assembly is recommended, rather than attempting to change the filter and resin themselves. After a new filter/sorbent trap assembly is installed, conduct a leak-check. The total particulate weight shall include the summation of all filter assembly catches.

6.6.9 A single train shall be used for the entire sample run, except in cases where simultaneous sampling is required in two or more separate ducts or at two or more different locations within the same duct, or in cases where equipment failure necessitates a change of trains. In all other situations, the use of two or more trains will be subject to the approval of the Administrator.

6.6.10 Note that when two or more trains are used, separate analysis of the front-half (if applicable) organic-module and impinger (if applicable) catches from each train shall be performed, unless identical nozzle sizes were used on all trains. In that case, the front-half catches from the individual trains may be combined (as may the impinger catches), and one analysis of front-half catch and one analysis of impinger catch may be performed.

6.6.11 At the end of the sample run, turn off the coarse-adjust valve, remove the probe and nozzle from the stack, turn off the pump, record the final dry-gas meter reading, and conduct a post-test leak-check. Also, leak-check the pitot lines as described in EPA Method 2. The lines must pass this leak-check in order to validate the velocity-head data.

6.6.12 Calculate percent isokineticity (see Section 10.8) to determine whether the run was valid or another test run should be made.

7.0 SAMPLE RECOVERY

7.1 Preparation:

7.1.1 Proper cleanup procedure begins as soon as the probe is removed from the stack at the end of the sampling period. Allow the probe to cool. When the probe can be safely handled, wipe off all external particulate matter near the tip of the probe nozzle and place a cap over the tip to prevent losing or gaining particulate matter. Do not cap the probe tip tightly while the sampling train is cooling down because this will create a vacuum in the filter holder, drawing water from the impingers into the sorbent module.

7.1.2 Before moving the sample train to the cleanup site, remove the probe from the sample train and cap the open outlet, being careful not to lose any condensate that might be present. Cap the filter inlet.

0010 - 18

Revision 0
Date September 1986

Remove the umbilical cord from the last impinger and cap the impinger. If a flexible line is used between the organic module and the filter holder, disconnect the line at the filter holder and let any condensed water or liquid drain into the organic module.

7.1.3 Cap the filter-holder outlet and the inlet to the organic module. Separate the sorbent trap section of the organic module from the condensate knockout trap and the gas-conditioning section. Cap all organic module openings. Disconnect the organic-module knockout trap from the impinger train inlet and cap both of these openings. Ground-glass stoppers, Teflon caps, or caps of other inert materials may be used to seal all openings.

7.1.4 Transfer the probe, the filter, the organic-module components, and the impinger/condenser assembly to the cleanup area. This area should be clean and protected from the weather to minimize sample contamination or loss.

7.1.5 Save a portion of all washing solutions (methanol/methylene chloride, Type II water) used for cleanup as a blank. Transfer 200 mL of each solution directly from the wash bottle being used and place each in a separate, prelabeled glass sample container.

7.1.6 Inspect the train prior to and during disassembly and note any abnormal conditions.

7.2 Sample containers:

7.2.1 Container no. 1: Carefully remove the filter from the filter holder and place it in its identified Petri dish container. Use a pair or pairs of tweezers to handle the filter. If it is necessary to fold the filter, ensure that the particulate cake is inside the fold. Carefully transfer to the Petri dish any particulate matter or filter fibers that adhere to the filter-holder gasket, using a dry nylon bristle brush or sharp-edged blade, or both. Label the container and seal with 1-in.-wide Teflon tape around the circumference of the lid.

7.2.2 Container no. 2: Taking care that dust on the outside of the probe or other exterior surfaces does not get into the sample, quantitatively recover particulate matter or any condensate from the probe nozzle, probe fitting, probe liner, and front half of the filter holder by washing these components first with methanol/methylene chloride (1:1 v/v) into a glass container. Distilled water may also be used. Retain a water and solvent blank and analyze in the same manner as with the samples. Perform rinses as follows:

7.2.2.1 Carefully remove the probe nozzle and clean the inside surface by rinsing with the solvent mixture (1:1 v/v methanol/methylene chloride) from a wash bottle and brushing with a nylon bristle brush. Brush until the rinse shows no visible particles; then make a final rinse of the inside surface with the solvent mix. Brush and rinse the inside parts of the Swagelok fitting with the solvent mix in a similar way until no visible particles remain.

7.2.2.2 Have two people rinse the probe liner with the solvent mix by tilting and rotating the probe while squirting solvent into its upper end so that all inside surfaces will be wetted with solvent. Let the solvent drain from the lower end into the sample container. A glass funnel may be used to aid in transferring liquid washes to the container.

7.2.2.3 Follow the solvent rinse with a probe brush. Hold the probe in an inclined position and squirt solvent into the upper end while pushing the probe brush through the probe with a twisting action; place a sample container underneath the lower end of the probe and catch any solvent and particulate matter that is brushed from the probe. Run the brush through the probe three times or more until no visible particulate matter is carried out with the solvent or until none remains in the probe liner on visual inspection. With stainless steel or other metal probes, run the brush through in the above-prescribed manner at least six times (metal probes have small crevices in which particulate matter can be entrapped). Rinse the brush with solvent and quantitatively collect these washings in the sample container. After the brushing, make a final solvent rinse of the probe as described above.

7.2.2.4 It is recommended that two people work together to clean the probe to minimize sample losses. Between sampling runs, keep brushes clean and protected from contamination.

7.2.2.5 Clean the inside of the front half of the filter holder and cyclone/cyclone flask, if used, by rubbing the surfaces with a nylon bristle brush and rinsing with methanol/methylene chloride (1:1 v/v) mixture. Rinse each surface three times or more if needed to remove visible particulate. Make a final rinse of the brush and filter holder. Carefully rinse out the glass cyclone and cyclone flask (if applicable). Brush and rinse any particulate material adhering to the inner surfaces of these components into the front-half rinse sample. After all solvent washings and particulate matter have been collected in the sample container, tighten the lid on the sample container so that solvent will not leak out when it is shipped to the laboratory. Mark the height of the fluid level to determine whether leakage occurs during transport. Label the container to identify its contents.

7.2.3 Container no. 3: The sorbent trap section of the organic module may be used as a sample transport container, or the spent resin may be transferred to a separate glass bottle for shipment. If the sorbent trap itself is used as the transport container, both ends should be sealed with tightly fitting caps or plugs. Ground-glass stoppers or Teflon caps may be used. The sorbent trap should then be labeled, covered with aluminum foil, and packaged on ice for transport to the laboratory. If a separate bottle is used, the spent resin should be quantitatively transferred from the trap into the clean bottle. Resin that adheres to the walls of the trap should be recovered using a rubber policeman or spatula and added to this bottle.

0010 - 20

Revision 0
Date September 1986

7.2.4 Container no. 4: Measure the volume of condensate collected in the condensate knockout section of the organic module to within +1 mL by using a graduated cylinder or by weighing to within +0.5 g using a triple-beam balance. Record the volume or weight of liquid present and note any discoloration or film in the liquid catch. Transfer this liquid to a prelabeled glass sample container. Inspect the back half of the filter housing and the gas-conditioning section of the organic module. If condensate is observed, transfer it to a graduated or weighing bottle and measure the volume, as described above. Add this material to the condensate knockout-trap catch.

7.2.5 Container no. 5: All sampling train components located between the high-efficiency glass- or quartz-fiber filter and the first wet impinger or the final condenser system (including the heated Teflon line connecting the filter outlet to the condenser) should be thoroughly rinsed with methanol/methylene chloride (1:1 v/v) and the rinsings combined. This rinse shall be separated from the condensate. If the spent resin is transferred from the sorbent trap to a separate sample container for transport, the sorbent trap shall be thoroughly rinsed until all sample-wetted surfaces appear clean. Visible films should be removed by brushing. Whenever train components are brushed, the brush should be subsequently rinsed with solvent mixture and the rinsings added to this container.

7.2.6 Container no. 6: Note the color of the indicating silica gel to determine if it has been completely spent and make a notation of its condition. Transfer the silica gel from the fourth impinger to its original container and seal. A funnel may make it easier to pour the silica gel without spilling. A rubber policeman may be used as an aid in removing the silica gel from the impinger. It is not necessary to remove the small amount of dust particles that may adhere strongly to the impinger wall. Because the gain in weight is to be used for moisture calculations, do not use any water or other liquids to transfer the silica gel. If a balance is available in the field, weigh the container and its contents to 0.5 g or better.

7.3 Impinger water:

7.3.1 Make a notation of any color or film in the liquid catch. Measure the liquid in the first three impingers to within +1 mL by using a graduated cylinder or by weighing it to within +0.5 g by using a balance (if one is available). Record the volume or weight of liquid present. This information is required to calculate the moisture content of the effluent gas.

7.3.2 Discard the liquid after measuring and recording the volume or weight, unless analysis of the impinger catch is required (see Paragraph 4.1.3.7). Amber glass containers should be used for storage of impinger catch, if required.

7.3.3 If a different type of condenser is used, measure the amount of moisture condensed either volumetrically or gravimetrically.

7.4 Sample preparation for shipment: Prior to shipment, recheck all sample containers to ensure that the caps are well secured. Seal the lids of all containers around the circumference with Teflon tape. Ship all liquid samples upright on ice and all particulate filters with the particulate catch facing upward. The particulate filters should be shipped unrefrigerated.

8.0 ANALYSIS

8.1 Sample preparation:

8.1.1 General: The preparation steps for all samples will result in a finite volume of concentrated solvent. The final sample volume (usually in the 1- to 10-mL range) is then subjected to analysis by GC/MS. All samples should be inspected and the appearance documented. All samples are to be spiked with surrogate standards as received from the field prior to any sample manipulations. The spike should be at a level equivalent to 10 times the MDL when the solvent is reduced in volume to the desired level (i.e., 10 mL). The spiking compounds should be the stable isotopically labeled analog of the compounds of interest or a compound that would exhibit properties similar to the compounds of interest, be easily chromatographed, and not interfere with the analysis of the compounds of interest. Suggested surrogate spiking compounds are: deuterated naphthalene, chrysene, phenol, nitrobenzene, chlorobenzene, toluene, and carbon-13-labeled pentachlorophenol.

8.1.2 Condensate: The "condensate" is the moisture collected in the first impinger following the XAD-2 module. Spike the condensate with the surrogate standards. The volume is measured and recorded and then transferred to a separatory funnel. The pH is to be adjusted to pH 2 with 6 N sulfuric acid, if necessary. The sample container and graduated cylinder are sequentially rinsed with three successive 10-mL aliquots of the extraction solvent and added to the separatory funnel. The ratio of solvent to aqueous sample should be maintained at 1:3. Extract the sample by vigorously shaking the separatory funnel for 5 min. After complete separation of the phases, remove the solvent and transfer to a Kuderna-Danish concentrator (K-D), filtering through a bed of precleaned, dry sodium sulfate. Repeat the extraction step two additional times. Adjust the pH to 11 with 6 N sodium hydroxide and reextract combining the acid and base extracts. Rinse the sodium sulfate into the K-D with fresh solvent and discard the desiccant. Add Teflon boiling chips and concentrate to 10 mL by reducing the volume to slightly less than 10 mL and then bringing to volume with fresh solvent. In order to achieve the necessary detection limit, the sample volume can be further reduced to 1 mL by using a micro column K-D or nitrogen blow-down. Should the sample start to exhibit precipitation, the concentration step should be stopped and the sample redissolved with fresh solvent taking the volume to some finite amount. After adding a standard (for the purpose of quantitation by GC/MS), the sample is ready for analysis, as discussed in Paragraph 8.2.

8.1.3 Impinger: Spike the sample with the surrogate standards; measure and record the volume and transfer to a separatory funnel. Proceed as described in Paragraph 8.1.2.

8.1.4 XAD-2: Spike the resin directly with the surrogate standards. Transfer the resin to the all-glass thimbles by the following procedure (care should be taken so as not to contaminate the thimble by touching it with anything other than tweezers or other solvent-rinsed mechanical holding devices). Suspend the XAD-2 module directly over the thimble. The glass frit of the module (see Figure 2) should be in the up position. The thimble is contained in a clean beaker, which will serve to catch the solvent rinses. Using a Teflon squeeze bottle, flush the XAD-2 into the thimble. Thoroughly rinse the glass module with solvent into the beaker containing the thimble. Add the XAD-2 glass-wool plug to the thimble. Cover the XAD-2 in the thimble with a precleaned glass-wool plug sufficient to prevent the resin from floating into the solvent reservoir of the extractor. If the resin is wet, effective extraction can be accomplished by loosely packing the resin in the thimble. If a question arises concerning the completeness of the extraction, a second extraction, without a spike, is advised. The thimble is placed in the extractor and the rinse solvent contained in the beaker is added to the solvent reservoir. Additional solvent is added to make the reservoir approximately two-thirds full. Add Teflon boiling chips and assemble the apparatus. Adjust the heat source to cause the extractor to cycle 5-6 times per hr. Extract the resin for 16 hr. Transfer the solvent and three 10-mL rinses of the reservoir to a K-D and concentrate as described in Paragraph 8.1.2.

8.1.5 Particulate filter (and cyclone catch): If particulate loading is to be determined, weigh the filter (and cyclone catch, if applicable). The particulate filter (and cyclone catch, if applicable) is transferred to the glass thimble and extracted simultaneously with the XAD-2 resin.

8.1.6 Train solvent rinses: All train rinses (i.e., probe, impinger, filter housing) using the extraction solvent and methanol are returned to the laboratory as a single sample. If the rinses are contained in more than one container, the intended spike is divided equally among the containers proportioned from a single syringe volume. Transfer the rinse to a separatory funnel and add a sufficient amount of organic-free water so that the methylene chloride becomes immiscible and its volume no longer increases with the addition of more water. The extraction and concentration steps are then performed as described in Paragraph 8.1.2.

8.2 Sample analysis:

8.2.1 The primary analytical tool for the measurement of emissions from hazardous waste incinerators is GC/MS using fused-silica capillary GC columns, as described in Method 8270 in Chapter Four of this manual. Because of the nature of GC/MS instrumentation and the cost associated

with sample analysis, prescreening of the sample extracts by gas chromatography/flame ionization detection (GC/FID) or with electron capture (GC/ECD) is encouraged. Information regarding the complexity and concentration level of a sample prior to GC/MS analysis can be of enormous help. This information can be obtained by using either capillary columns or less expensive packed columns. However, the FID screen should be performed with a column similar to that used with the GC/MS. Keep in mind that GC/FID has a slightly lower detection limit than GC/MS and, therefore, that the concentration of the sample can be adjusted either up or down prior to analysis by GC/MS.

8.2.2 The mass spectrometer will be operated in a full scan (40-450) mode for most of the analyses. The range for which data are acquired in a GC/MS run will be sufficiently broad to encompass the major ions, as listed in Chapter Four, Method 8270, for each of the designated POHCs in an incinerator effluent analysis.

8.2.3 For most purposes, electron ionization (EI) spectra will be collected because a majority of the POHCs give reasonable EI spectra. Also, EI spectra are compatible with the NBS Library of Mass Spectra and other mass spectral references, which aid in the identification process for other components in the incinerator process streams.

8.2.4 To clarify some identifications, chemical ionization (CI) spectra using either positive ions or negative ions will be used to elucidate molecular-weight information and simplify the fragmentation patterns of some compounds. In no case, however, should CI spectra alone be used for compound identification. Refer to Chapter Four, Method 8270, for complete descriptions of GC conditions, MS conditions, and quantitative and quantitative identification.

9.0 CALIBRATION

9.1 Probe nozzle: Probe nozzles shall be calibrated before their initial use in the field. Using a micrometer, measure the inside diameter of the nozzle to the nearest 0.025 mm (0.001 in.). Make measurements at three separate places across the diameter and obtain the average of the measurements. The difference between the high and low numbers shall not exceed 0.1 mm (0.004 in.). When nozzles become nicked, dented, or corroded, they shall be reshaped, sharpened, and recalibrated before use. Each nozzle shall be permanently and uniquely identified.

9.2 Pitot tube: The Type S pitot tube assembly shall be calibrated according to the procedure outlined in Section 4 of EPA Method 2, or assigned a nominal coefficient of 0.84 if it is not visibly nicked, dented, or corroded and if it meets design and intercomponent spacing specifications.

9.3 Metering system:

9.3.1 Before its initial use in the field, the metering system shall be calibrated according to the procedure outlined in APTD-0576. Instead of physically adjusting the dry-gas meter dial readings to correspond to the wet-test meter readings, calibration factors may be used to correct the gas meter dial readings mathematically to the proper values. Before calibrating the metering system, it is suggested that a leak-check be conducted. For metering systems having diaphragm pumps, the normal leak-check procedure will not detect leakages within the pump. For these cases the following leak-check procedure is suggested: Make a 10-min calibration run at $0.00057 \text{ m}^3/\text{min}$ (0.02 cfm); at the end of the run, take the difference of the measured wet-test and dry-gas meter volumes and divide the difference by 10 to get the leak rate. The leak rate should not exceed $0.00057 \text{ m}^3/\text{min}$ (0.02 cfm).

9.3.2 After each field use, the calibration of the metering system shall be checked by performing three calibration runs at a single intermediate orifice setting (based on the previous field test). The vacuum shall be set at the maximum value reached during the test series. To adjust the vacuum, insert a valve between the wet-test meter and the inlet of the metering system. Calculate the average value of the calibration factor. If the calibration has changed by more than 5%, recalibrate the meter over the full range of orifice settings, as outlined in APTD-0576.

9.3.3 Leak-check of metering system: That portion of the sampling train from the pump to the orifice meter (see Figure 1) should be leak-checked prior to initial use and after each shipment. Leakage after the pump will result in less volume being recorded than is actually sampled. The following procedure is suggested (see Figure 6): Close the main valve on the meter box. Insert a one-hole rubber stopper with rubber tubing attached into the orifice exhaust pipe. Disconnect and vent the low side of the orifice manometer. Close off the low side orifice tap. Pressurize the system to 13-18 cm (5-7 in.) water column by blowing into the rubber tubing. Pinch off the tubing and observe the manometer for 1 min. A loss of pressure on the manometer indicates a leak in the meter box. Leaks, if present, must be corrected.

NOTE: If the dry-gas-meter coefficient values obtained before and after a test series differ by >5%, either the test series shall be voided or calculations for test series shall be performed using whichever meter coefficient value (i.e., before or after) gives the lower value of total sample volume.

9.4 Probe heater: The probe-heating system shall be calibrated before its initial use in the field according to the procedure outlined in APTD-0576. Probes constructed according to APTD-0581 need not be calibrated if the calibration curves in APTD-0576 are used.




Figure 6. Leak check of meter box.

9.5 Temperature gauges: Each thermocouple must be permanently and uniquely marked on the casting; all mercury-in-glass reference thermometers must conform to ASTM E-1 63C or 63F specifications. Thermocouples should be calibrated in the laboratory with and without the use of extension leads. If extension leads are used in the field, the thermocouple readings at ambient air temperatures, with and without the extension lead, must be noted and recorded. Correction is necessary if the use of an extension lead produces a change $>1.5\%$.

9.5.1 Impinger, organic module, and dry-gas meter thermocouples: For the thermocouples used to measure the temperature of the gas leaving the impinger train and the XAD-2 resin bed, three-point calibration at ice-water, room-air, and boiling-water temperatures is necessary. Accept the thermocouples only if the readings at all three temperatures agree to $\pm 2^{\circ}\text{C}$ (3.6°F) with those of the absolute value of the reference thermometer.

9.5.2 Probe and stack thermocouple: For the thermocouples used to indicate the probe and stack temperatures, a three-point calibration at ice-water, boiling-water, and hot-oil-bath temperatures must be performed; it is recommended that room-air temperature be added, and that the thermometer and the thermocouple agree to within 1.5% at each of the calibration points. A calibration curve (equation) may be constructed (calculated) and the data extrapolated to cover the entire temperature range suggested by the manufacturer.

9.6 Barometer: Adjust the barometer initially and before each test series to agree to within ± 25 mm Hg (0.1 in. Hg) of the mercury barometer or the corrected barometric pressure value reported by a nearby National Weather Service Station (same altitude above sea level).

9.7 Triple-beam balance: Calibrate the triple-beam balance before each test series, using Class-S standard weights; the weights must be within $\pm 0.5\%$ of the standards, or the balance must be adjusted to meet these limits.

10.0 CALCULATIONS

10.1 Carry out calculations. Round off figures after the final calculation to the correct number of significant figures.

10.2 Nomenclature:

A_n = Cross-sectional area of nozzle, m^2 (ft^2).

B_{ws} = Water vapor in the gas stream, proportion by volume.

C_d = Type S pitot tube coefficient (nominally 0.84 ± 0.02), dimensionless.

I = Percent of isokinetic sampling.

- L_a = Maximum acceptable leakage rate for a leak-check, either pre-test or following a component change; equal to $0.00057 \text{ m}^3/\text{min}$ (0.02 cfm) or 4% of the average sampling rate, whichever is less.
- L_i = Individual leakage rate observed during the leak-check conducted prior to the " i^{th} " component change ($i = 1, 2, 3 \dots n$) m^3/min (cfm).
- L_p = Leakage rate observed during the post-test leak-check, m^3/min (cfm).
- M_d = Stack-gas dry molecular weight, g/g-mole (lb/lb-mole).
- M_w = Molecular weight of water, 18.0 g/g-mole (18.0 lb/lb-mole).
- P_{bar} = Barometric pressure at the sampling site, mm Hg (in. Hg).
- P_s = Absolute stack-gas pressure, mm Hg (in. Hg).
- P_{std} = Standard absolute pressure, 760 mm Hg (29.92 in. Hg).
- R = Ideal gas constant, $0.06236 \text{ mm Hg-m}^3/\text{K-g-mole}$ ($21.85 \text{ in. Hg-ft}^3/^{\circ}\text{R-lb-mole}$).
- T_m = Absolute average dry-gas meter temperature (see Figure 6), K ($^{\circ}\text{R}$).
- T_s = Absolute average stack-gas temperature (see Figure 6), K ($^{\circ}\text{R}$).
- T_{std} = Standard absolute temperature, 293K (528°R).
- V_{lc} = Total volume of liquid collected in the organic module condensate knockout trap, the impingers, and silica gel, mL .
- V_m = Volume of gas sample as measured by dry-gas meter, dscm (dscf).
- $V_m(\text{std})$ = Volume of gas sample measured by the dry-gas meter, corrected to standard conditions, dscm (dscf).
- $V_w(\text{std})$ = Volume of water vapor in the gas sample, corrected to standard conditions, scm (scf).
- V_s = Stack-gas velocity, calculated by Method 2, Equation 2-9, using data obtained from Method 5, m/sec (ft/sec).
- W_a = Weight of residue in acetone wash, mg .
- γ = Dry-gas-meter calibration factor, dimensionless.
- ΔH = Average pressure differential across the orifice meter (see Figure 2), $\text{mm H}_2\text{O}$ ($\text{in. H}_2\text{O}$).

ρ_w = Density of water, 0.9982 g/mL (0.002201 lb/mL).

θ = Total sampling time, min.

θ_1 = Sampling time interval from the beginning of a run until the first component change, min.

θ_i = Sampling time interval between two successive component changes, beginning with the interval between the first and second changes, min.

θ_p = Sampling time interval from the final (n^{th}) component change until the end of the sampling run, min.

13.6 = Specific gravity of mercury.

60 = sec/min.

100 = Conversion to percent.

10.3 Average dry-gas-meter temperature and average orifice pressure drop: See data sheet (Figure 5, above).

10.4 Dry-gas volume: Correct the sample measured by the dry-gas meter to standard conditions (20°C, 760 mm Hg [68°F, 29.92 in. Hg]) by using Equation 1:

$$V_{m(\text{std})} = V_m \gamma \frac{T_{\text{std}}}{T_m} \frac{P_{\text{bar}} + \Delta H/13.6}{P_{\text{std}}} = K_1 V_m \gamma \frac{P_{\text{bar}} + \Delta H/13.6}{T_m} \quad (1)$$

where:

K_1 = 0.3858 K/mm Hg for metric units, or
 K_1 = 17.64°R/in. Hg for English units.

It should be noted that Equation 1 can be used as written, unless the leakage rate observed during any of the mandatory leak-checks (i.e., the post-test leak-check or leak-checks conducted prior to component changes) exceeds L_a . If L_p or L_i exceeds L_a , Equation 1 must be modified as follows:

- a. Case I (no component changes made during sampling run): Replace V_m in Equation 1 with the expression:

$$V_m - (L_p - L_a)$$

- b. Case II (one or more component changes made during the sampling run): Replace V_m in Equation 1 by the expression:

$$V_m = (L_1 - L_a)\theta_1 - \sum_{i=2}^n (L_i - L_a)\theta_i - (L_p - L_a)\theta_p$$

and substitute only for those leakage rates (L_1 or L_p) that exceed L_a .

10.5 Volume of water vapor:

$$V_{w(std)} = V_{1c} \frac{P_w}{M_w} \frac{RT_{std}}{P_{std}} = K_2 V_{1c} \quad (2)$$

where:

$K_2 = 0.001333 \text{ m}^3/\text{mL}$ for metric units, or
 $K_2 = 0.04707 \text{ ft}^3/\text{mL}$ for English units.

10.6 Moisture content:

$$B_{ws} = \frac{V_{w(std)}}{V_{m(std)} + V_{w(std)}} \quad (3)$$

NOTE: In saturated or water-droplet-laden gas streams, two calculations of the moisture content of the stack gas shall be made, one from the impinger analysis (Equation 3) and a second from the assumption of saturated conditions. The lower of the two values of B_w shall be considered correct. The procedure for determining the moisture content based upon assumption of saturated conditions is given in the Note to Section 1.2 of Method 4. For the purposes of this method, the average stack-gas temperature from Figure 6 may be used to make this determination, provided that the accuracy of the in-stack temperature sensor is $\pm 1^\circ\text{C}$ (2°F).

10.7 Conversion factors:

From	To	Multiply by
scf	m^3	0.02832
g/ft ³	gr/ft ³	15.43
g/ft ³	lb/ft ³	2.205×10^{-3}
g/ft ³	g/m ³	35.31

0010 - 30

Revision 0
 Date September 1986

10.8 Isokinetic variation:

10.8.1 Calculation from raw data:

$$I = \frac{100 T_s [K_3 F_{lc} + (V_m/T_m) (P_{bar} + \Delta H/13.6)]}{608 V_s P_s A_n} \quad (4)$$

where:

$K_3 = 0.003454 \text{ mm Hg-m}^3/\text{mL-K}$ for metric units, or
 $K_3 = 0.002669 \text{ in. Hg-ft}^3/\text{mL-}^\circ\text{R}$ for English units.

10.8.2 Calculation for intermediate values:

$$I = \frac{T_s V_m(\text{std}) P_{\text{std}}^{100}}{T_{\text{std}} V_s B A_n P_s^{60(1-B_{ws})}} \quad (5)$$

$$= K_4 \frac{T_s V_m(\text{std})}{P_s V_s A_n B (1-B_{ws})}$$

where:

$K_4 = 4.320$ for metric units, or
 $K_4 = 0.09450$ for English units.

10.8.3 Acceptable results: If $90\% \leq I \leq 110\%$, the results are acceptable. If the results are low in comparison with the standard and I is beyond the acceptable range, or if I is less than 90%, the Administrator may opt to accept the results.

10.9 To determine the minimum sample volume that shall be collected, the following sequence of calculations shall be used.

10.9.1 From prior analysis of the waste feed, the concentration of POHCs introduced into the combustion system can be calculated. The degree of destruction and removal efficiency that is required is used to determine the maximum amount of POHC allowed to be present in the effluent. This may be expressed as:

$$\frac{(WF) (POHC_i \text{ conc})}{100} \frac{(100-\%DRE)}{100} = \text{Max POHC}_i \text{ Mass} \quad (6)$$

where:

WF = mass flow rate of waste feed per hr, g/hr (lb/hr).

POHC_i = concentration of Principal Organic Hazardous Compound (wt %) introduced into the combustion process.

0010 - 31

Revision 0
 Date September 1986

DRE = percent Destruction and Removal Efficiency required.

Max POHC = mass flow rate (g/hr [lb/hr]) of POHC emitted from the combustion source.

10.9.2 The average discharge concentration of the POHC in the effluent gas is determined by comparing the Max POHC with the volumetric flow rate being exhausted from the source. Volumetric flow rate data are available as a result of preliminary Method 1-4 determinations:

$$\frac{\text{Max POHC}_i \text{ Mass}}{DV_{\text{eff}}(\text{std})} = \text{Max POHC}_i \text{ conc} \quad (7)$$

where:

$DV_{\text{eff}}(\text{std})$ = volumetric flow rate of exhaust gas, dscm (dscf).

$\text{POHC}_i \text{ conc}$ = anticipated concentration of the POHC in the exhaust gas stream, g/dscm (lb/dscf).

10.9.3 In making this calculation, it is recommended that a safety margin of at least ten be included:

$$\frac{LDL_{\text{POHC}} \times 10}{\text{POHC}_i \text{ conc}} = V_{\text{TBC}} \quad (8)$$

where:

LDL_{POHC} = detectable amount of POHC in entire sampling train.

NOTE: The whole extract from an XAD-2 cartridge is seldom if ever, injected at once. Therefore, if aliquoting factors are involved, the LDL_{POHC} is not the same as the analytical (or column) detection limit.

V_{TBC} = minimum dry standard volume to be collected at dry-gas meter.

10.10 Concentration of any given POHC in the gaseous emissions of a combustion process:

1) Multiply the concentration of the POHC as determined in Method 8270 by the final concentration volume, typically 10 mL.

$$C_{\text{POHC}} (\text{ug/mL}) \times \text{sample volume (mL)} = \text{amount (ug) of POHC in sample} \quad (9)$$

where:

CPOHC = concentration of POHC as analyzed by Method 8270.

2) Sum the amount of POHC found in all samples associated with a single train.

Total (ug) = XAD-2 (ug) + condensate (ug) + rinses (ug) + impinger (ug) (10)

3) Divide the total ug found by the volume of stack gas sampled (m^3).

(Total ug)/(train sample volume) = concentration of POHC (ug/m^3) (11)

11.0 QUALITY CONTROL

11.1 Sampling: See EPA Manual 600/4-77-027b for Method 5 quality control.

11.2 Analysis: The quality assurance program required for this study includes the analysis of field and method blanks, procedure validations, incorporation of stable labeled surrogate compounds, quantitation versus stable labeled internal standards, capillary column performance checks, and external performance tests. The surrogate spiking compounds selected for a particular analysis are used as primary indicators of the quality of the analytical data for a wide range of compounds and a variety of sample matrices. The assessment of combustion data, positive identification, and quantitation of the selected compounds are dependent on the integrity of the samples received and the precision and accuracy of the analytical methods employed. The quality assurance procedures for this method are designed to monitor the performance of the analytical method and to provide the required information to take corrective action if problems are observed in laboratory operations or in field sampling activities.

11.2.1 Field Blanks: Field blanks must be submitted with the samples collected at each sampling site. The field blanks include the sample bottles containing aliquots of sample recovery solvents, unused filters, and resin cartridges. At a minimum, one complete sampling train will be assembled in the field staging area, taken to the sampling area, and leak-checked at the beginning and end of the testing (or for the same total number of times as the actual test train). The filter housing and probe of the blank train will be heated during the sample test. The train will be recovered as if it were an actual test sample. No gaseous sample will be passed through the sampling train.

11.2.2 Method blanks: A method blank must be prepared for each set of analytical operations, to evaluate contamination and artifacts that can be derived from glassware, reagents, and sample handling in the laboratory.

11.2.3 Refer to Method 8270 for additional quality control considerations.

0010 - 33

Revision 0
Date September 1986

12.0 METHOD PERFORMANCE

12.1 Method performance evaluation: Evaluation of analytical procedures for a selected series of compounds must include the sample-preparation procedures and each associated analytical determination. The analytical procedures should be challenged by the test compounds spiked at appropriate levels and carried through the procedures.

12.2 Method detection limit: The overall method detection limits (lower and upper) must be determined on a compound-by-compound basis because different compounds may exhibit different collection, retention, and extraction efficiencies as well as instrumental minimum detection limit (MDL). The method detection limit must be quoted relative to a given sample volume. The upper limits for the method must be determined relative to compound retention volumes (breakthrough).

12.3 Method precision and bias: The overall method precision and bias must be determined on a compound-by-compound basis at a given concentration level. The method precision value would include a combined variability due to sampling, sample preparation, and instrumental analysis. The method bias would be dependent upon the collection, retention, and extraction efficiency of the train components. From evaluation studies to date using a dynamic spiking system, method biases of -13% and -16% have been determined for toluene and 1,1,2,2-tetrachloroethane, respectively. A precision of 19.9% was calculated from a field test data set representing seven degrees of freedom which resulted from a series of paired, unspiked Semivolatile Organic Sampling trains (Semi-VOST) sampling emissions from a hazardous waste incinerator.

13.0 REFERENCES

1. Addendum to Specifications for Incinerator Testing at Federal Facilities, PHS, NCAPC, December 6, 1967.
2. Bursey, J., Homolya, J., McAllister, R., and McGangley, J., Laboratory and Field Evaluation of the Semi-VOST Method, Vols. 1 and 2, U.S. Environmental Protection Agency, EPA/600/4-851/075A, 075B (1985).
3. Martin, R.M., Construction Details of Isokinetic Source-Sampling Equipment, Research Triangle Park, NC, U.S. Environmental Protection Agency, April 1971, PB-203 060/BE, APTD-0581, 35 pp.
4. Rom, J.J., Maintenance, Calibration, and Operation of Isokinetic Source-Sampling Equipment, Research Triangle Park, NC, U.S. Environmental Protection Agency, March 1972, PB-209 022/BE, APTD-0576, 39 pp.
5. Schlickerrieder, L.M., Adams, J.W., and Thrun, K.E., Modified Method 5 Train and Source Assessment Sampling System: Operator's Manual, U.S. Environmental Protection Agency, EPA/600/8-85/003, (1985).

6. Shigehara, R.T., Adjustments in the EPA Nomography for Different Pitot Tube Coefficients and Dry Molecular Weights, Stack Sampling News, 2:4-11 (October 1974).

7. U.S. Environmental Protection Agency, CFR 40 Part 60, Appendix A, Methods 1-5.

8. Vollaro, R.F., A Survey of Commercially Available Instrumentation for the Measurement of Low-Range Gas Velocities, Research Triangle Park, NC, U.S. Environmental Protection Agency, Emissions Measurement Branch, November 1976 (unpublished paper).

0010 - 35

Revision 0
Date September 1986

PREPARATION OF XAD-2 SORBENT RESIN

1.0 SCOPE AND APPLICATION

1.1 XAD-2 resin as supplied by the manufacturer is impregnated with a bicarbonate solution to inhibit microbial growth during storage. Both the salt solution and any residual extractable monomer and polymer species must be removed before use. The resin is prepared by a series of water and organic extractions, followed by careful drying.

2.0 EXTRACTION

2.1 Method 1: The procedure may be carried out in a giant Soxhlet extractor. An all-glass thimble containing an extra-coarse frit is used for extraction of XAD-2. The frit is recessed 10-15 mm above a crenellated ring at the bottom of the thimble to facilitate drainage. The resin must be carefully retained in the extractor cup with a glass-wool plug and stainless steel screen because it floats on methylene chloride. This process involves sequential extraction in the following order.

<u>Solvent</u>	<u>Procedure</u>
Water	Initial rinse: Place resin in a beaker, rinse once with Type II water, and discard. Fill with water a second time, let stand overnight, and discard.
Water	Extract with H ₂ O for 8 hr.
Methyl alcohol	Extract for 22 hr.
Methylene chloride	Extract for 22 hr.
Methylene chloride (fresh)	Extract for 22 hr.

2.2 Method 2:

2.2.1 As an alternative to Soxhlet extraction, a continuous extractor has been fabricated for the extraction sequence. This extractor has been found to be acceptable. The particular canister used for the apparatus shown in Figure A-1 contains about 500 g of finished XAD-2. Any size may be constructed; the choice is dependent on the needs of the sampling programs. The XAD-2 is held under light spring tension between a pair of coarse and fine screens. Spacers under the bottom screen allow for even distribution of clean solvent. The three-necked flask should be of sufficient size (3-liter in this case) to hold solvent




Figure A-1. XAD-2 cleanup extraction apparatus.

equal to twice the dead volume of the XAD-2 canister. Solvent is refluxed through the Snyder column, and the distillate is continuously cycled up through the XAD-2 for extraction and returned to the flask. The flow is maintained upward through the XAD-2 to allow maximum solvent contact and prevent channeling. A valve at the bottom of the canister allows removal of solvent from the canister between changes.

2.2.2 Experience has shown that it is very difficult to cycle sufficient water in this mode. Therefore the aqueous rinse is accomplished by simply flushing the canister with about 20 liters of distilled water. A small pump may be useful for pumping the water through the canister. The water extraction should be carried out at the rate of about 20-40 mL/min.

2.2.3 After draining the water, subsequent methyl alcohol and methylene chloride extractions are carried out using the refluxing apparatus. An overnight or 10- to 20-hr period is normally sufficient for each extraction.

2.2.4 All materials of construction are glass, Teflon, or stainless steel. Pumps, if used, should not contain extractable materials. Pumps are not used with methanol and methylene chloride.

3.0 DRYING

3.1 After evaluation of several methods of removing residual solvent, a fluidized-bed technique has proved to be the fastest and most reliable drying method.

3.2 A simple column with suitable retainers, as shown in Figure A-2, will serve as a satisfactory column. A 10.2-cm (4-in.) Pyrex pipe 0.6 m (2 ft) long will hold all of the XAD-2 from the extractor shown in Figure A-1 or the Soxhlet extractor, with sufficient space for fluidizing the bed while generating a minimum resin load at the exit of the column.

3.3 Method 1: The gas used to remove the solvent is the key to preserving the cleanliness of the XAD-2. Liquid nitrogen from a standard commercial liquid nitrogen cylinder has routinely proved to be a reliable source of large volumes of gas free from organic contaminants. The liquid nitrogen cylinder is connected to the column by a length of precleaned 0.95-cm (3/8-in.) copper tubing, coiled to pass through a heat source. As nitrogen is bled from the cylinder, it is vaporized in the heat source and passes through the column. A convenient heat source is a water bath heated from a steam line. The final nitrogen temperature should only be warm to the touch and not over 40°C. Experience has shown that about 500 g of XAD-2 may be dried overnight by consuming a full 160-liter cylinder of liquid nitrogen.

3.4 Method 2: As a second choice, high-purity tank nitrogen may be used to dry the XAD-2. The high-purity nitrogen must first be passed through a bed

0010 - A - 3

Revision 0
Date September 1986




Figure A-2. XAD-2 fluidized-bed drying apparatus.

0010 - A - 4

Revision 0
Date September 1986

of activated charcoal approximately 150 mL in volume. With either type of drying method, the rate of flow should gently agitate the bed. Excessive fluidization may cause the particles to break up.

4.0 QUALITY CONTROL PROCEDURES

4.1 For both Methods 1 and 2, the quality control results must be reported for the batch. The batch must be reextracted if the residual extractable organics are >20 ug/mL by TCO analysis or the gravimetric residue is >0.5 mg/20 g XAD-2 extracted. (See also section 5.1, Method 0010.)

4.2 Four control procedures are used with the final XAD-2 to check for (1) residual methylene chloride, (2) extractable organics (TCO), (3) specific compounds of interest as determined by GC/MS, as described in Section 4.5 below, and (4) residue (GRAV).

4.3 Procedure for residual methylene chloride:

4.3.1 Description: A 1 ± 0.1 -g sample of dried resin is weighed into a small vial, 3 mL of toluene are added, and the vial is capped and well shaken. Five μ L of toluene (now containing extracted methylene chloride) are injected into a gas chromatograph, and the resulting integrated area is compared with a reference standard. The reference solution consists of 2.5 μ L of methylene chloride in 100 mL of toluene, simulating 100 ug of residual methylene chloride on the resin. The acceptable maximum content is 1,000 ug/g resin.

4.3.2 Experimental: The gas chromatograph conditions are as follows:

6-ft x 1/8-in. stainless steel column containing 10% OV-101 on 100/120 Supelcoport;

Helium carrier at 30 mL/min;

FID operated on 4×10^{-11} A/mV;

Injection port temperature: 250°C;

Detector temperature: 305°C;

Program: 30°C(4 min) 40°C/min 250°C (hold); and

Program terminated at 1,000 sec.

4.4 Procedure for residual extractable organics:

4.4.1 Description: A 20 ± 0.1 -g sample of cleaned, dried resin is weighed into a precleaned alundum or cellulose thimble which is plugged with cleaned glass wool. (Note that 20 g of resin will fill a thimble, and the

TOTAL CHROMATOGRAPHABLE ORGANIC MATERIAL ANALYSIS

1.0 SCOPE AND APPLICATION

1.1 In this procedure, gas chromatography is used to determine the quantity of lower boiling hydrocarbons (boiling points between 90° and 300°C) in the concentrates of all organic solvent rinses, XAD-2 resin and LC fractions - when Method 1 is used (see References, Method 0010) - encountered in Level 1 environmental sample analyses. Data obtained using this procedure serve a twofold purpose. First, the total quantity of the lower boiling hydrocarbons in the sample is determined. Then whenever the hydrocarbon concentrations in the original concentrates exceed 75 ug/m³, the chromatography results are reexamined to determine the amounts of individual species.

The extent of compound identification is limited to representing all materials as normal alkanes based upon comparison of boiling points. Thus the method is not qualitative. In a similar manner, the analysis is semiquantitative; calibrations are prepared using only one hydrocarbon. They are replicated but samples routinely are not.

1.2 Application: This procedure applies solely to the Level 1 C7-C16 gas chromatographic analysis of concentrates of organic extracts, neat liquids, and of LC fractions. Throughout the procedure, it is assumed the analyst has been given a properly prepared sample.

1.3 Sensitivity: The sensitivity of this procedure, defined as the slope of a plot of response versus concentration, is dependent on the instrument and must be verified regularly. TRW experience indicates the nominal range is of the order of 77 uV·V·sec·uL/ng of n-heptane and 79 uV·sec·uL/ng of n-hexadecane. The instrument is capable of perhaps one hundredfold greater sensitivity. The level specified here is sufficient for Level 1 analysis.

1.4 Detection limit: The detection limit of this procedure as written is 1.3 ng/uL for a 1 uL injection of n-decane. This limit is arbitrarily based on defining the minimum detectable response as 100 uV·sec. This is an easier operational definition than defining the minimum detection limit to be that amount of material which yields a signal twice the noise level.

1.5 Range: The range of the procedure will be concentrations of 1.3 ng/uL and greater.

1.6 Limitations

1.6.1 Reporting limitations: It should be noted that a typical environmental sample will contain compounds which: (a) will not elute in the specified boiling ranges and thus will not be reported, and/or (b)

resin will float out unless well plugged.) The thimble containing the resin is extracted for 24 hr with 200-mL of pesticide-grade methylene chloride (Burdick and Jackson pesticide-grade or equivalent purity). The 200-mL extract is reduced in volume to 10-mL using a Kuderna-Danish concentrator and/or a nitrogen evaporation stream. Five μ L of that solution are analyzed by gas chromatography using the TCO analysis procedure. The concentrated solution should not contain >20 μ g/mL of TCO extracted from the XAD-2. This is equivalent to 10 μ g/g of TCO in the XAD-2 and would correspond to 1.3 mg of TCO in the extract of the 130-g XAD-2 module. Care should be taken to correct the TCO data for a solvent blank prepared (200 mL reduced to 10 mL) in a similar manner.

4.4.2 Experimental: Use the TCO analysis conditions described in the revised Level 1 manual (EPA 600/7-78-201).

4.5 GC/MS Screen: The extract, as prepared in paragraph 4.4.1, is subjected to GC/MS analysis for each of the individual compounds of interest. The GC/MS procedure is described in Chapter Four, Method 8270. The extract is screened at the MDL of each compound. The presence of any compound at a concentration >25 μ g/mL in the concentrated extract will require the XAD-2 to be recleaned by repeating the methylene chloride step.

4.6 Methodology for residual gravimetric determination: After the TCO value and GC/MS data are obtained for the resin batch by the above procedures, dry the remainder of the extract in a tared vessel. There must be <0.5 mg residue registered or the batch of resin will have to be extracted with fresh methylene chloride again until it meets this criterion. This level corresponds to 25 μ g/g in the XAD-2, or about 3.25 mg in a resin charge of 130 g.

0010 - A - 6

Revision 0
Date September 1986

will not elute from the column at all and thus will not be reported. Consequently, the organic content of the sample as reported is a lower bound and should be regarded as such.

1.6.2 Calibration limitations: Quantitation is based on calibration with n-decane. Data should therefore be reported as, e.g., mg C₈/m³ as n-decane. Since response varies linearly with carbon number (over a wide range the assumption may involve a 20% error), it is clear that heptane (C₇) detected in a sample and quantitated as decane will be overestimated. Likewise, hexadecane (C₁₆) quantitated as decane will be underestimated. From previous data, it is estimated the error involved is on the order of 6-7%.

1.6.3 Detection limitations: The sensitivity of the flame ionization detector varies from compound to compound. However, n-alkanes have a greater response than other classes. Consequently, using an n-alkane as a calibrant and assuming equal responses of all other compounds tends to give low reported values.

2.0 SUMMARY OF METHOD

2.1 A mL aliquot of all 10-mL concentrates is disbursed for GC-TCO analysis. With boiling point-retention time and response-amount calibration curves, the data (peak retention times and peak areas) are interpreted by first summing peak areas in the ranges obtained from the boiling point-retention time calibration. Then, with the response-amount calibration curve, the area sums are converted to amounts of material in the reported boiling point ranges.

2.2 After the instrument is set up, the boiling point-retention time calibration is effected by injecting a mixture of n-C₇ through n-C₁₆ hydrocarbons and operating the standard temperature program. Response-quantity calibrations are accomplished by injecting n-decane in n-pentane standards and performing the standard temperature program.

2.3 Definitions

2.3.1 GC: Gas chromatography or gas chromatograph.

2.3.2 C₇-C₁₆ n-alkanes: Heptane through hexadecane.

2.3.3 GCA temperature program: 4 min isothermal at 60°C, 10°C/min from 60° to 220°C.

2.3.4 TRW temperature program: 5 min isothermal at room temperature, then program from 30°C to 250°C at 15°C/min.

3.0 INTERFERENCES

Not applicable.

0010 - B - 2

Revision 0
Date September 1986

4.0 APPARATUS AND MATERIALS

4.1 Gas chromatograph: This procedure is intended for use on a Varian 1860 gas chromatograph, equipped with dual flame ionization detectors and a linear temperature programmer. Any equivalent instrument can be used provided that electrometer settings, etc., be changed appropriately.

4.2 Gases:

4.2.1 Helium: Minimum quality is reactor grade. A 4A or 13X molecular sieve drying tube is required. A filter must be placed between the trap and the instrument. The trap should be recharged after every third tank of helium.

4.2.2 Air: Zero grade is satisfactory.

4.2.3 Hydrogen: Zero grade.

4.3 Syringe: Syringes are Hamilton 701N, 10 uL, or equivalent.

4.4 Septa: Septa will be of such quality as to produce very low bleed during the temperature program. An appropriate septum is Supelco Microsep 138, which is Teflon-backed. If septum bleed cannot be reduced to a negligible level, it will be necessary to install septum swingers on the instrument.

4.5 Recorder: The recorder of this procedure must be capable of not less than 1 mV full-scale display, a 1-sec time constant and 0.5 in. per min chart rate.

4.6 Integrator: An integrator is required. Peak area measurement by hand is satisfactory but too time-consuming. If manual integration is required, the method of "height times width at half height" is used.

4.7 Columns:

4.7.1 Preferred column: 6 ft x 1/8 in. O.D. stainless steel column of 10% OV-101 on 100/120 mesh Supelcoport.

4.7.2 Alternate column: 6 ft x 1/8 in. O.D. stainless steel column of 10% OV-1 (or other silicon phase) on 100/120 mesh Supelcoport.

4.8 Syringe cleaner: Hamilton syringe cleaner or equivalent connected to a suitable vacuum source.

5.0 REAGENTS

5.1 Pentane: "Distilled-in-Glass" (reg. trademark) or "Nanograde" (reg. trademark) for standards and for syringe cleaning.

0010 - B - 3

Revision 0
Date September 1986

5.2 Methylene chloride: "Distilled-in-Glass" (reg. trademark) or "Nanograde" (reg. trademark) for syringe cleaning.

6.0 SAMPLING HANDLING AND PRESERVATION

6.1 The extracts are concentrated in a Kuderna-Danish evaporator to a volume less than 10 mL. The concentrate is then quantitatively transferred to a 10-mL volumetric flask and diluted to volume. A 1-mL aliquot is taken for both this analysis and possible subsequent GC/MS analysis and set aside in the sample bank. For each GC-TCO analysis, obtain the sample sufficiently in advance to allow it to warm to room temperature. For example, after one analysis is started, return that sample to the sample bank and take the next sample.

7.0 PROCEDURES

7.1 Setup and checkout: Each day, the operator will verify the following:

7.1.1 That supplies of carrier gas, air and hydrogen are sufficient, i.e., that each tank contains > 100 psig.

7.1.2 That, after replacement of any gas cylinder, all connections leading to the chromatograph have been leak-checked.

7.1.3 That the carrier gas flow rate is 30 ± 2 mL/min, the hydrogen flow rate is 30 ± 2 mL/min, and the air flow rate is 300 ± 20 mL/min.

7.1.4 That the electrometer is functioning properly.

7.1.5 That the recorder and integrator are functioning properly.

7.1.6 That the septa have been leak-checked (leak-checking is effected by placing the soap bubble flow meter inlet tube over the injection port adaptors), and that no septum will be used for more than 20 injections.

7.1.7 That the list of samples to be run is ready.

7.2 Retention time calibration:

7.2.1 To obtain the temperature ranges for reporting the results of the analyses, the chromatograph is given a normal boiling point-retention time calibration. The n-alkanes, their boiling points, and data reporting ranges are given in the table below:

	<u>NBP, °C</u>	<u>Reporting Range, °C</u>	<u>Report As</u>
n-heptane	98	90-110	C7
n-octane	126	110-140	C8
n-nonane	151	140-160	C9
n-decane	174	160-180	C10
n-undecane	194	180-200	C11
n-dodecane	214	200-220	C12
n-tridecane	234	220-240	C13
n-tetradecane	252	240-260	C14
n-pentadecane	270	260-280	C15
n-hexadecane	288	280-300	C16

7.2.2 Preparation of standards: Preparing a mixture of the C7-C16 alkanes is required. There are two approaches: (1) use of a standards kit (e.g., Polyscience Kit) containing bottles of mixtures of selected n-alkanes which may be combined to produce a C7-C16 standard; or (2) use of bottles of the individual C7-C16 alkanes from which accurately known volumes may be taken and combined to give a C7-C16 mixture.

7.2.3 Procedure for retention time calibration: This calibration is performed at the start of an analytical program; the mixture is chromatographed at the start of each day. To attain the required retention time precision, both the carrier gas flow rate and the temperature program specifications must be observed. Details of the procedure depend on the instrument being used. The general procedure is as follows:

7.2.3.1 Set the programmer upper limit at 250°C. If this setting does not produce a column temperature of 250°C, find the correct setting.

7.2.3.2 Set the programmer lower limit at 30°C.

7.2.3.3 Verify that the instrument and samples are at room temperature.

7.2.3.4 Inject 1 uL of the n-alkane mixture.

7.2.3.5 Start the integrator and recorder.

7.2.3.6 Allow the instrument to run isothermally at room temperature for five min.

7.2.3.7 Shut the oven door.

7.2.3.8 Change the mode to Automatic and start the temperature program.

7.2.3.9 Repeat Steps 1-9 a sufficient number of times so that the relative standard deviation of the retention times for each peak is <5%.

0010 - B - 5

Revision 0
Date September 1986

7.3 Response calibration:

7.3.1 For the purposes of a Level 1 analysis, response-quantity calibration with n-decane is adequate. A 10- μ L volume of n-decane is injected into a tared 10 mL volumetric flask. The weight injected is obtained and the flask is diluted to the mark with n-pentane. This standard contains about 730 ng n-decane per μ L n-pentane. The exact concentration depends on temperature, so that a weight is required. Two serial tenfold dilutions are made from this standard, giving standards at about 730, 73, and 7.3 ng n-decane per μ L n-pentane, respectively.

7.3.2 Procedure for response calibration: This calibration is performed at the start of an analytical program and monthly thereafter. The most concentrated standard is injected once each day. Any change in calibration necessitates a full calibration with new standards. Standards are stored in the refrigerator locker and are made up monthly.

7.3.2.1 Verify that the instrument is set up properly.

7.3.2.2 Set electrometer at 1×10^{-10} A/mV.

7.3.2.3 Inject 1 μ L of the highest concentration standard.

7.3.2.4 Run standard temperature program as specified above.

7.3.2.5 Clean syringe.

7.3.2.6 Make repeated injections of all three standards until the relative standard deviations of the areas of each standard are $\leq 5\%$.

7.4 Sample analysis procedure:

7.4.1 The following apparatus is required:

7.4.1.1 Gas chromatograph set up and working.

7.4.1.2 Recorder, integrator working.

7.4.1.3 Syringe and syringe cleaning apparatus.

7.4.1.4 Parameters: Electrometer setting is 1×10^{-10} A/mV; recorder is set at 0.5 in./min and 1 mV full-scale.

7.4.2 Steps in the procedure are:

7.4.2.1 Label chromatogram with the data, sample number, etc.

7.4.2.2 Inject sample.

7.4.2.3 Start integrator and recorder.

7.4.2.4 After isothermal operation for 5 min, begin temperature program.

7.4.2.5 Clean syringe.

7.4.2.6 Return sample; obtain new sample.

7.4.2.7 When analysis is finished, allow instrument to cool. Turn chromatogram and integrator output and data sheet over to data analyst.

7.5 Syringe cleaning procedure:

7.5.1 Remove plunger from syringe.

7.5.2 Insert syringe into cleaner; turn on aspirator.

7.5.3 Fill pipet with pentane; run pentane through syringe.

7.5.4 Repeat with methylene chloride from a separate pipet.

7.5.5 Flush plunger with pentane followed by methylene chloride.

7.5.6 Repeat with methylene chloride.

7.6 Sample analysis decision criterion: The data from the TCO analyses of organic extract and rinse concentrates are first used to calculate the total concentration of C7-C16 hydrocarbon-equivalents (Paragraph 7.7.3) in the sample with respect to the volume of air actually sampled, i.e., ug/m^3 . On this basis, a decision is made both on whether to calculate the quantity of each n-alkane equivalent present and on which analytical procedural pathway will be followed. If the total organic content is great enough to warrant continuing the analysis -- $>500 \text{ ug}/\text{m}^3$ -- a TCO of less than $75 \text{ ug}/\text{m}^3$ will require only LC fractionation and gravimetric determinations and IR spectra to be obtained on each fraction. If the TCO is greater than $75 \text{ ug}/\text{m}^3$, then the first seven LC fractions of each sample will be reanalyzed using this same gas chromatographic technique.

7.7 Calculations:

7.7.1 Boiling Point - Retention Time Calibration: The required data for this calibration are on the chromatogram and on the data sheet. The data reduction is performed as follows:

7.7.1.1 Average the retention times and calculate relative standard deviations for each n-hydrocarbon.

0010 - B - 7

Revision 0
Date September 1986

7.7.1.2 Plot average retention times as abscissae versus normal boiling points as ordinates.

7.7.1.3 Draw in calibration curve.

7.7.1.4 Locate and record retention times corresponding to boiling ranges 90-100, 110-140, 140-160, 160-180, 180-200, 200-220, 220-240, 240-260, 260-280, 280-300°C.

7.7.2 Response-amount calibration: The required data for this calibration are on the chromatogram and on the data sheet. The data reduction is performed as follows:

7.7.2.1 Average the area responses of each standard and calculate relative standard deviations.

7.7.2.2 Plot response (uV·sec) as ordinate versus ng/uL as abscissa.

7.7.2.3 Draw in the curve. Perform least squares regression and obtain slope (uV·sec·uL/ng).

7.7.3 Total C7-C16 hydrocarbons analysis: The required data for this calculation are on the chromatogram and on the data sheet. The data reduction is performed as follows:

7.7.3.1 Sum the areas of all peaks within the retention time range of interest.

7.7.3.2 Convert this area (uV·sec) to ng/uL by dividing by the weight response for n-decane (uV·sec·uL/ng).

7.7.3.3 Multiply this weight by the total concentrate volume (10 mL) to get the weight of the C7-C16 hydrocarbons in the sample.

7.7.3.4 Using the volume of gas sampled or the total weight of sample acquired, convert the result of Step 7.7.3.3 above to ug/m³.

7.7.3.5 If the value of total C7-C16 hydrocarbons from Step 7.7.3.4 above exceeds 75 ug/m³, calculate individual hydrocarbon concentrations in accordance with the instructions in Paragraph 7.7.5.5 below.

7.7.4 Individual C7-C16 n-Alkane Equivalent Analysis: The required data from the analyses are on the chromatogram and on the data sheet. The data reduction is performed as follows:

7.7.4.1 Sum the areas of peaks in the proper retention time ranges.

0010 - B - 8

Revision 0
Date September 1986

7.7.4.2 Convert areas ($\mu\text{V}\cdot\text{sec}$) to $\text{ng}/\mu\text{L}$ by dividing by the proper weight response ($\mu\text{V}\cdot\text{sec}\cdot\mu\text{L}/\text{ng}$).

7.7.4.3 Multiply each weight by total concentrate volume (10 mL) to get weight of species in each range of the sample.

7.7.4.4 Using the volume of gas sampled on the total weight of sample acquired, convert the result of Step 7.7.4.3 above to $\mu\text{g}/\text{m}^3$.

8.0 QUALITY CONTROL

8.1 Appropriate QC is found in the pertinent procedures throughout the method.

9.0 METHOD PERFORMANCE

9.1 Even relatively comprehensive error propagation analysis is beyond the scope of this procedure. With reasonable care, peak area reproducibility of a standard should be of the order of 1% RSD. The relative standard deviation of the sum of all peaks in a fairly complex waste might be of the order of 5-10%. Accuracy is more difficult to assess. With good analytical technique, accuracy and precision should be of the order of 10-20%.

10.0 REFERENCES

1. Emissions Assessment of Conventional Stationary Combustion Systems: Methods and Procedure Manual for Sampling and Analysis, Interagency Energy/Environmental R&D Program, Industrial Environmental Research Laboratory, Research Triangle Park, NC 27711, EPA-600/7-79-029a, January 1979.

APPENDIX K

CALCULATION EQUATIONS

METHOD 2
CALCULATION EQUATIONS

$$\bar{V}_s = 85.49 C_p (\sqrt{\Delta p})_{avg} \sqrt{\frac{T_{s(avg)}}{P_s M_s}}$$

$$Q_{s,d} = 60 (1 - B_{ws}) \bar{V}_s A \left(\frac{528}{T_{s(avg)}} \right) \left(\frac{P_s}{29.92} \right)$$

$$Q_d = 60 \bar{V}_s A$$

$$\dot{m}_s = \frac{4.995 Q_{s,d} G_d}{1 - B_{ws}}$$

$$RH^* = 100 (\nu p_{twb} - 0.0003641 P_s (T_{db} - T_{wb})) / \nu p_{adb}$$

$$B_{ws}^* = RH(\nu p_{adb}) / P_s$$

$$\rho = \frac{4.585 \times 10^{-2} P_s M_s}{T_s (avg)}$$

*Alternate equations for calculating moisture content from wet bulb and dry bulb data.

032294-G:\STACK\WPMETHODSS-EQ.15

SYMBOLS

A	=	Cross Sectional area of stack, SQ. FT.
A_n	=	Cross sectional area of nozzle, SQ. FT.
B_{ws}	=	Water vapor in gas stream, proportion by volume
C_p	=	Pitot tube coefficient, dimensionless
C_a	=	Concentration of particulate matter in stack gas, wet basis, GR/ACF
C_s	=	Concentration of particulate matter in stack gas, dry basis, corrected to standard conditions, GR/DSCF
EA	=	Excess air, percent by volume
γ	=	Dry test meter correction factor, dimensionless
G_d	=	Specific gravity (relative to air), dimensionless
I	=	Isokinetic variation, percent by volume
M_d	=	Molecular weight of stack gas, dry basis, g/g - mole.
m_s	=	Mass flow of wet flue gas, LB/HR
m_p	=	Particulate mass flow, LB/HR
M_s	=	Molecular weight of stack gas, wet basis, g/g mole.
M_p	=	Total amount of particulate matter collected, g
P_{bar}	=	Atmospheric pressure, IN. HG. (uncompensated)
P_s	=	Stack static gas pressure, IN. WC.
P_s	=	Absolute pressure of stack gas, IN. HG.
P_{std}	=	Standard absolute pressure, 29.92 IN. HG.
A_a	=	Actual volumetric stack gas flow rate, ACFM
$Q_{s, d}$	=	Dry volumetric stack gas flow rate corrected to standard conditions, DSCFM
RH	=	Relative humidity, %

032294-G:STACKWPMETHODS-EQ.15

T_{db}	=	Dry bulb temperature of stack gas, °F
T_{wb}	=	Wet bulb temperature of stack gas, °F
$T_{m(avg)}$	=	Absolute average dry gas meter temperature, °R
$T_{s(avg)}$	=	Absolute average stack temperature, °R
T_{std}	=	Standard absolute temperature, 528 °R (68 °F)
θ	=	Total sampling time, min.
V_{lc}	=	Total volume of liquid collected in impingers and silica gel, ml
V_m	=	Volume of gas sample as measured by dry gas meter, CF
$V_{m(std)}$	=	Volume of gas sample measured by the dry gas meter corrected to standard conditions, DSCF
$V_{w(std)}$	=	Volume of water vapor in the gas sample corrected to standard conditions, SCF
$\bar{V}_s$	=	Average actual stack gas velocity, FT/SEC
vp_{tdb}	=	Vapor pressure at T_{db} , IN. HG.
vp_{twb}	=	Vapor pressure at T_{wb} , IN. HG.
$\overline{\Delta H}$	=	Average pressure differential across the orifice meter, IN. WC.
ΔP	=	Velocity pressure of stack gas, IN. WC.
γ	=	Dry test meter correction coefficient, dimensionless
ρ	=	Actual gas density, LB/ACF

METHOD 3
CALCULATION EQUATIONS

$$\%EA = \frac{100(\%O_2 - 0.5\% CO)}{0.264\% N_2 - \%O_2 + 0.5\% CO}$$

$$M_d = 0.44(\%CO_2) + 0.32 (\%O_2) + 0.28 (\%N_2 + \%CO)$$

$$M_s = M_d (I - B_{ws}) + 0.18 B_{ws}$$

$$B_{ws} = \frac{V_{w(std)}}{V_{w(std)} + V_{m(std)}}$$

METHOD 5
CALCULATION EQUATIONS

$$V_{m(std)} = 17.65 V_m \gamma \left(\frac{P_{bar} + \overline{\Delta H}/13.6}{T_{m(avg)}} \right)$$

$$V_{w(std)} = 0.0472 V_{Is}$$

$$B_{ws} = \frac{V_{w(std)}}{V_{w(std)} + V_{m(std)}}$$

$$I = 0.0944 \left(\frac{T_{s(avg)} V_{m(std)}}{P_s V_s A_n \theta (I - B_{ws})} \right)$$

$$C_s = \frac{15.43 M_p}{V_{m(std)}}$$

$$C_d = \frac{272.3 M_p P_s}{T_{s(avg)} (V_{w(std)} + V_{m(std)})}$$

$$(\dot{m}_p)_1 = 8.5714 \times 10^{-3} C_s Q_{s,d}$$

032294-G:STACKWPMETHODSS-EQ.15

$$(\dot{m}_p)_2 = \frac{1.3228 \times 10^{-1} M_p A}{\theta A_n}$$

$$\dot{m}_p = \frac{(\dot{m}_p)_1 + (\dot{m}_p)_2}{2}$$

CALCULATION EQUATIONS

METHOD 7

$$V_{m(std)} = 17.64 (V_f - 25) \left[\frac{P_f}{T_f} - \frac{P_i}{T_i} \right]$$

$$C_s = 6.243 \times 10^{-5} \frac{M}{V_{m(std)}}$$

$$E = \frac{2090 C_s F}{20.9 - \bar{B}_{O_2}}$$

$$C_s (GR/DSCF) = 7000 C_s$$

$$C_s (MG/DSCM) = 1.60186 \times 10^7 C_s$$

$$C_s (ppm-dry) = 8.37552 \times 10^6 C_s$$

$$C_s (ppm-3\% O_2) = 8.37552 \times 10^6 C_s \left\{ 1 + \left[\frac{\bar{B}_{O_2} - 3}{20.9 - \bar{B}_{O_2}} \right] \right\}$$

$$C_s (ppm-wet) = 8.37552 \times 10^6 C_s \left(1 - \frac{MC}{100} \right)$$

G:\STACK\WP\METHODS\EQ.M7

SYMBOLS

$\bar{B}_{O_2}$	=	Average oxygen content in flue gas, % v/v
C_s	=	Concentration of nitrogen oxides in flue gas, dry basis, corrected to standard conditions, LB/DSCF
C_s (GR/DSCF)	=	Concentration of nitrogen oxides in flue gas, dry basis, corrected to standard conditions, GR/DSCF
C_s (MG/DSCM)	=	Concentration of nitrogen oxides in flue gas, dry basis, corrected to standard conditions, MG/DSCM
E	=	Emission factor, LB/10 ⁶ BTU
F	=	F-Factor for given fuel type, DSCF/10 ⁴ BTU
M	=	Mass of nitrogen oxides as nitrogen dioxide in gas sample, ug
MC	=	Moisture content of flue gas, %
P_f	=	Final absolute pressure in flask, IN. HG
P_i	=	Initial absolute pressure in flask, IN. HG
C_s (ppm-dry)	=	Concentration of nitrogen oxides in flue gas, dry basis, (v/v), ppm
C_s (ppm-3% O ₂)	=	Concentration of nitrogen oxides in flue gas, dry basis, corrected to 3% O ₂ , (v/v) ppm
C_s (ppm-wet)	=	Concentration of nitrogen oxides in flue gas, wet basis, (v/v), ppm
T_f	=	Final absolute temperature in flask, °R
T_i	=	Initial absolute temperature in flask, °R
V_f	=	Volume of flask and valve, cc
$V_{m(std)}$	=	Sample volume at standard conditions, dry basis, cc

G:\STACK\WP\METHODS\EQ.M7

CALCULATION EQUATIONS

METHOD 10

$$CO\text{-}PPM\text{-}DRY = CO_{CO_2} - free, dry, avg (1 - CO_{2,d}/100)$$

$$CO\text{-}PPM\text{-}WET = CO\text{-}PPM\text{-}DRY (1 - MC/100)$$

$$GR/DSCF = 5.0885 \times 10^{-4} (CO\text{-}PPM\text{-}DRY)$$

$$mg/dscm = 1.165 (CO\text{-}PPM\text{-}DRY)$$

$$\dot{m} = 8.5714 \times 10^{-3} (GR/DSCF) (Q_{s,d})$$

$$E = \frac{2.9857 \times 10^{-3} F_d (GR/DSCF)}{20.9 - O_{2,d}}$$

where:

$CO_{CO_2} - free, dry, avg$

= average of two determinations of carbon monoxide on a dry, CO_2 - free integrated flue gas sample reported in ppm by volume

$CO_{2,d}$ = carbon dioxide concentration of flue gas on a dry percent by volume basis

$O_{2,d}$ = oxygen concentration of flue gas on a dry percent by volume basis

G:\STACK\WP\METHODS\EQ.M10

MC	=	moisture content of flue gas on a percent by volume basis
CO·PPM·DRY	=	carbon monoxide concentration in ppm by volume on a dry basis
CO·PPM·WET	=	carbon monoxide concentration in ppm by volume on a wet or actual basis
GR/DSCF	=	concentration of carbon monoxide in flue gas on a grains per dry standard cubic foot basis (68 °F, 29.92 IN. HG.)
mg/dscm	=	concentration of carbon monoxide in flue gas on a milligrams per dry standard cubic meter basis (60 °F, 29.92 IN. HG.)
m	=	emissions or mass rate of carbon monoxide on a LB/HR basis
$Q_{s,d}$	=	volumetric flow rate of flue gas in dry standard cubic feet per minute
E	=	emission factor of carbon monoxide in pounds of carbon monoxide emitted per million BTU heat input (LB/MMBTU)
F_d	=	F-Factor of respective fuel in dry standard cubic feet of exhaust gas at 0% oxygen per million BTU of heat input (DSCF/MMBTU)

METHOD 25A

Total Gaseous Organics Calculation Equation

$$\text{GR C/SCF} = 2.180 \times 10^{-4} (\text{ppm, w})$$

$$\text{GR C/DSCF} = 2.180 \times 10^{-4} (\text{ppm, w}) / (1 - \text{MC}/100)$$

$$\text{LB C/HR} = 8.5714 \times 10^{-3} (\text{GR/DSCF}) (\text{DSCFM})$$

where:

GR C/SCF = grains of total gaseous organics as carbon per actual (wet) standard cubic foot

GR C/DSCF = grains of total gaseous organics as carbon per dry standard cubic foot

LB C/HR = pounds of total gaseous organics as carbon emitted per hour


Note 1: The Ratfisch Model RS 55 Heated FID Analyzer as normally operated with a heated filter, sample line and heated detector oven gives ppm, w.

Note 2: ppm, C = ppm as carbon = 3(ppm propane)

031894-GASTACKIWPMETHODSS-EQ.07

Concentration Calculation Equations for Benzene

1. Structure:



2. Molecular weight:

78.11 g/g-mole

3. Mass/volume Concentration:

$$C_{ug/Nm^3} = \frac{35.314 \text{ m}}{V_{std}}$$

where m = Total mass of Benzene
in sample in micrograms (ug), and

V_{std} = Total volume of exhaust gas or air
sampled in dry standard cubic feet
(DSCF).

4. Volume/volume Concentration:

$$\frac{C_{C_6H_6}}{C_{ppmv}} = \left(\frac{mg}{Nm^3} \right) \times \left(\frac{24,054 \text{ mL}}{78.11 \text{ mg}} \right) = ppmv$$

$$\frac{C_{C_6H_6}}{C_{ppmv}} = 0.3080 \left(\frac{C_{C_6H_6}}{C_{mg/Nm^3}} \right)$$

$$C_{ppmv} = 3.08 \times 10^{-5} \cdot C_{ug/Nm^3}$$

5. Notes:

see Excel spreadsheet

6: \STACK\EXCEL\TEMPLATE\BENZENE.TEM

Derived by: D. DESPENDate: 9-10-90

CALCULATION EQUATIONS

Chromotropic Acid Method for Formaldehyde

$$m_t = \frac{m_a V_{soln}}{V_{aliquot}}$$

where:

m_t	=	mass of formaldehyde in total sample in ug
m_a	=	mass of formaldehyde in aliquot in ug
V_{soln}	=	volume of total sample in cc (500 cc normally)
$V_{aliquot}$	=	volume of aliquot taken for analysis in cc
PPM·DRY	=	$\frac{0.0283 m_t}{V_{std}}$
PPM·WET	=	PPM·DRY (1-MC/100)
GR/DSCF	=	5.45×10^{-4} (PPM·DRY)
mg/dscm	=	1.249 (PPM·DRY)
$\dot{m}$	=	8.5714×10^{-3} (GR/DSCF) (Q_g)

where:

PPM·DRY	=	concentration of formaldehyde in parts per million by volume on a dry basis
PPM·WET	=	concentration of formaldehyde in parts per million by volume on an actual or wet basis
MC	=	moisture content of gas on a percent by volume basis
GR/DSCF	=	concentration of formaldehyde in gas on a grains per dry standard cubic foot basis (68 °F, 29.92 IN. HG.)
$\dot{m}$	=	emission or mass rate of formaldehyde in pounds per hour (LB/HR)
V_{std}	=	dry gas volume as measured by the dry gas meter, corrected to standard conditions (at 68 °F and 1 atmosphere) DSCF

031894-GASTACK\WPMETHODSS-EQ.03

CALCULATION EQUATIONS

Gas Chromatographic Method for Phenol in Air

$$\text{PPM-DRY} = \frac{9.03 \times 10^{-3} m}{V_{\text{std}}}$$

$$\text{PP-WET} = \text{PPM-DRY} (1-\text{MC}/100)$$

$$\text{GR/DSCF} = 1.709 \times 10^{-3} (\text{PPM-DRY})$$

$$\text{mg/dscm} = 3.913 (\text{PPM-DRY})$$

$$m = 8.5714 \times 10^{-3} (\text{GR/DSCF}) (Q_{s,d})$$

where:

PPM-DRY = concentration of phenol in gas in parts per million by volume on a dry basis

PPM-WET = concentration of phenol in gas in parts per million by volume on an actual or wet basis

MC = moisture content of gas on a percent by volume basis

GR/DSCF = concentration of phenol in gas on a grains per dry standard cubic foot basis (68 °F, 29.92 IN. HG.)

m = emission or mass rate of phenol in pounds per hour (LB/HR)

$Q_{s,d}$ = volumetric flow rate of stack gas in dry standard cubic feet per minute (DSCFM)

CALCULATION OF PAH EMISSION RATES

in g/sec and 10^{-6} g/sec

$\dot{m}$ (g/sec)

$$= 4.716 \times 10^{-10} C_s (\text{ug/m}^3) Q_{s,d} (\text{DSCFM})$$

$\dot{m}$ (10^{-3} g/sec)

$$= 4.716 \times 10^{-7} C_s (\text{ug/m}^3) Q_{s,d} (\text{DSCFM})$$

$\dot{m}$ (10^{-6} g/sec)

$$= 4.716 \times 10^{-4} C_s (\text{ug/m}^3) Q_{s,d} (\text{DSCFM})$$

where:

$$Q_s = \text{ug/dsm}^3$$

$$Q_{s,d} = \text{DSCF/MIN}$$

Concentration Calculation Equations for

MDI

1. Structure:

2. Molecular weight:

250.26 g/g-mole

3. Mass/volume Concentration:

$$C_{ug/Nm^3} = \frac{35.314 \text{ m}}{V_{std}}$$

where m = Total mass of MDI
in sample in micrograms (ug), and

Vstd = Total volume of exhaust gas or air
sampled in dry standard cubic feet
(DSCF).

4. Volume/volume Concentration:

$$C_{ppmv} = \left(\frac{24.054 \text{ ul}}{250.26 \text{ ug}} \right) \left(\frac{1/Nm^3}{1000 L} \right) \left(\frac{35.314 \text{ m}}{V_{std}} \right)$$

$$C_{ppmv} = (9.612 \times 10^{-5}) C_{ug/Nm^3}$$

5. Notes: * see Excel spreadsheet:

G:\STACK\EXCEL\TEMPLATE\MDI.Tem

Derived by:

Shari P.

Date:

4-27-95

		LOUISIANA PACIFIC		Report No. 6-7318	
		HAYWARD, WI			
		Oxides of Nitrogen Calculations			
DRYER RTO STACK		LB/HR Calculations			
TEST 6	NOX ppm	Flow	LB/DSCF	LB/HR	
RUN					
1	20.7	71990	2.47E-06	10.67538	
2	18.1	70905	2.16E-06	9.193826	
3	20.2	71495	2.41E-06	10.34589	
AVG	19.7			10.1	
LINE 1 CORE DRYER DUCT		LB/HR Calculations			
TEST 7	NOX ppm	Flow	LB/DSCF	LB/HR	
RUN					
1	35.3	22252	4.21E-06	5.6271	
2	37.9	23520	4.53E-06	6.38583	
3	35.7	22216	4.26E-06	5.681656	
AVG	36.3			5.9	
LINE 1 SURFACE DRYER DUCT		LB/HR Calculations			
TEST 8	NOX ppm	Flow	LB/DSCF	LB/HR	
RUN					
1	20.6	21479	2.46E-06	3.169729	
2	68.3	22195	8.15E-06	10.85967	
3	74	21107	8.84E-06	11.1892	
AVG	54.3			8.4	
PRESS VENT RTO STACK		LB/HR Calculations			
TEST 10	NOX ppm	Flow	LB/DSCF	LB/HR	
RUN					
1	24.4	74155	2.91E-06	12.96197	
2	24.1	75440	2.88E-06	13.02446	
3	23.6	74754	2.82E-06	12.63826	
AVG	24.0			12.9	
LINE 1 PRESS RTO INLET		LB/HR Calculations			
TEST 13	NOX ppm	Flow	LB/DSCF	LB/HR	
RUN					
1	11.4	74064	1.36E-06	6.048572	
2	4.9	74787	5.85E-07	2.625204	
3	3.3	74063	3.94E-07	1.750879	
AVG	6.5			3.5	
LINE 1 THERMAL OIL HEATER STACK		LB/HR Calculations			
TEST 18	NOX ppm	Flow	LB/DSCF	LB/HR	
RUN					
1	89.9	12735	1.07E-05	8.201617	
2	97.5	11660	1.16E-05	8.144117	
3	89.3	11910	1.07E-05	7.619107	
AVG	92.2			8.0	

Report No. 6-7318

LOUISIANA PACIFIC CORPORATION
Hayward, Wisconsin

BENZENE

TEST 5		Dryer RTO Stack									
	RUN	Vstd (DSCF)	MASS (ug)	CONC (ug/Nm3)	CONC (ppmv)	CONC (GR/DSCF)	FLOW (DSCFM)	E-RATE (LB/HR)			
	1	2.2	15	241	0.074159	0.00010522	71993	0.064929			
	2	2.21	17	272	0.083667	0.00011871	70905	0.072146			
	3	2.15	17	279	0.086002	0.00012202	71496	0.074778			
	AVG				0.081276			0.07062			

TEST 15		Line 1 Thermal Oil Heater Stack									
	RUN	Vstd (DSCF)	MASS (ug)	CONC (ug/Nm3)	CONC (ppmv)	CONC (GR/DSCF)	FLOW (DSCFM)	E-RATE (LB/HR)			
	1	1.834	<	<	<	<	1.767E-05	12735	<	0.001929	
	2	2.11	<	<	<	<	1.5359E-05	11663	<	0.001535	
	3	1.92	<	<	<	<	1.6879E-05	11906	<	0.001723	
					<	<	0.011725		<	0.00173	

Report No. 6-7318									
LOUISIANA PACIFIC CORPORATION									
Hayward, Wisconsin									
Total Hydrocarbons Calculations									
DRYER RTO STACK		CONC		GASFLOW		MASSRATE		AVERAGE	
TEST #	RUN	MC%	(ppmC,w)	(DSCFM)	(LB/HR)	(ppmC,w)	(LB/HR)	(ppmC,w)	(LB/HR)
6	1	22.29	8.7	71993	1.51				
	2	23.6	12.3	70905	2.13				
	3	23.48	14.0	71496	2.44				
						11.666667			2.027773
LINE 1 CORE DRYER DUCT									
TEST #	RUN	MC%	CONC	GASFLOW	MASSRATE	AVERAGE			
7	1	27.75	312	22252	17.96				
	2	21.64	399	23520	22.38				
	3	28.00	375	22216	21.62				
						362			20.65145
LINE 1 SURFACE DRYER DUCT									
TEST #	RUN	MC%	CONC	GASFLOW	MASSRATE	AVERAGE			
8	1	30.84	740	21479	42.94				
	2	30.87	541	22195	32.46				
	3	31.01	560	21107	32.01				
						613.66667			35.80445

K-20

Page 2

	LOUISIANA PACIFIC CORPORATION					Report No. 6-7318			
	Hayward, Wisconsin								
TEST 6	DRYER RTO STACK								
	Gas Concentration Correction Calculations								
	NOx Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	21.3	2	0	1.0	142	139	142	140.50	20.7
2	17.3	1	2	-0.5	142	140	139	139.50	18.1
3	19.3	-1	1	-1.0	142	144	140	142.00	20.2
Avg									19.6
	CO Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	183.3	6	0	3.0	289	298	290	294.00	179
2	232.8	2	6	-2.0	289	302	298	300.00	225
3	205.7	4	2	1.0	289	290	296	293.00	203
avg									202
	CO2 Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	4.2	0.2	0	0.1	10.9	10.8	10.9	10.85	4.2
2	3.4	0.1	0.2	-0.1	10.9	10.7	10.8	10.75	3.5
3	4.2	0.2	0.1	0.1	10.9	11.2	10.7	10.95	4.2
Avg									3.9
	O2 Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	16.3	-0.2	0	-0.1	13	13.2	13	13.10	16.2
2	16.9	0	0	0.0	13	12.9	13.1	13.00	16.9
3	16.2	-0.1	0	-0.1	13	13	12.9	12.95	16.3
Avg									16.4

TEST 7	LINE 1 CORE DRYER DUCT								
	Gas Concentration Correction Calculations								
	NOx Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	36.0	2.54	2.14	0.2	240	247.03	239.87	243.45	35.3
2	37.9	1.22	2.54	-0.7	240	245.97	240.48	243.23	37.9
3	35.4	0	1.22	-0.6	240	241.7	241.7	241.70	35.7
Avg									36.3
	CO Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	667.4	1.22	1.02	0.1	299	297.85	299.07	298.46	668.7
2	907.5	0	1.22	-0.6	299	297.85	297.85	297.85	909.8
3	774.6	0	0	0.0	299	297.85	297.85	297.85	777.6
Avg									785.
	CO2 Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	4.5	0.02	0	0.01	10.5	10.45	10.5	10.48	4.5
2	4.6	0	0.02	-0.01	10.5	10.45	10.45	10.45	4.6
3	4.7	0	0	0.00	10.5	10.45	10.45	10.45	4.7
Avg									4.6
	O2 Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	16.4	0.08	0.02	0.03	13.1	13.11	13.11	13.11	16.4
2	16.3	0	0.08	-0.04	13.1	13.17	13.11	13.14	16.2
3	16.2	0	0	0.00	13.1	13.39	13.17	13.28	16.0
Avg									16.2

TEST 3 LINE 1 SURFACE DRYER DUCT									
Gas Concentration Correction Calculations									
NOX Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	20.6	0	0	0.0	72.1	72	72.1	72.05	20.6
2	68	0.5	0	0.3	72.1	71.5	72.1	71.80	68.3
3	73.5	1	0	0.5	72.1	71.2	72.1	71.65	74.0
Avg									54.3
CO Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	910	0	0	0.0	600	595	600	597.50	913.8
2	897	0.2	0	0.1	600	590	600	595.00	904.6
3	892	1	0	0.5	600	597	600	598.50	894.5
Avg									904.3

TEST 10	PRESS VENT RTO STACK								
	Gas Concentration Correction Calculations								
	NOx Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	25.7	3	2	0.5	142	150	144	147.00	24.4
2	25.0	2	3	-0.5	142	150	150	150.00	24.1
3	25.2	2	2	0.0	142	153	150	151.50	23.6
Avg									24.0
	CO Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	17.4	4	1	1.5	289	301	294	297.50	15.5
2	27.5	9	4	2.5	289	300	298	299.00	24.4
3	29.6	3	9	-3.0	289	299	300	299.50	31.1
Avg									23.7
	CO2 Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	0.6	-0.1	0	-0.05	10.9	10.7	10.9	10.80	0.7
2	0.6	0	0	0.00	10.9	10.8	10.9	10.85	0.6
3	0.6	-0.1	0	-0.05	10.9	10.8	10.8	10.80	0.7
Avg									0.6
	O2 Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	20.2	0.2	0	0.10	13.0	12.9	13.0	12.95	20.3
2	20.0	-0.1	0	-0.05	13.0	13.0	12.9	12.95	20.1
3	20.0	0	0	0.00	13.0	13.1	13.0	13.05	19.9
Avg									20.1

TEST 13 LINE 1 PRESS RTO INLET									
Gas Concentration Correction Calculations									
NOx Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	12.6	2.69	0	1.3	72.1	72.14	72.33	72.24	11.4
2	4.8	0	0.37	-0.2	72.1	74	72.14	73.07	4.9
3	3.3	0	0	0.0	72.1	71	72.75	71.88	3.3
Avg									6.6
CO Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	10.1	0	0	0.0	299	296.63	298	297.32	10.2
2	7.5	0	0	0.0	299	292	296.63	294.32	7.6
3	3	0	0	0.0	299	298	292	295.00	3.0
Avg									6.9
CO2 Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	0.1	0.02	0	0.01	10.5	10.45	10.5	10.48	0.1
2	0.1	0	0	0.00	10.5	10.4	10.5	10.43	0.1
3	0.1	0	0	0.00	10.5	10.3	10.4	10.35	0.1
Avg									0.1
O2 Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	21.0	0.03	0.00	0.02	13.1	13	13.12	13.06	21.1
2	21.3	0.00	0.03	-0.02	13.1	13.1	13.18	13.14	21.2
3	21.2	0.00	0.00	0.00	13.1	13.03	13.1	13.07	21.3
Avg									21.2

TEST 18 LINE 1 THERMAL OIL HEATER STACK									
Gas Concentration Correction Calculations									
NOx Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	90.3	2.44	0	1.2	145	144.65	145	144.83	89.9
2	97.7	1	0.31	0.3	145	145.57	144.65	145.11	97.5
3	89.7	1.22	1	0.1	145	145.57	145.57	145.57	89.3
Avg									92.3
CO Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	177	1.22	0	0.6	299	299.07	298.00	298.54	177.0
2	247.6	2	0	1.0	299	298.00	299.07	298.54	247.8
3	114	2	2	0.0	299	299.07	298.00	298.54	114.7
Avg									179.1
CO2 Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	6.5	0	0	0.00	10.5	10.45	10.5	10.48	6.5
2	8.4	0	0	0.00	10.5	10.4	10.5	10.43	8.5
3	7.7	0	0	0.00	10.5	10.4	10.4	10.40	7.8
Avg									7.6
O2 Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	14.2	0.10	0.00	0.05	13.1	13.2	13.1	13.15	14.2
2	11.8	0.10	0.10	0.00	13.1	13.1	13.1	13.10	11.8
3	13.0	0.10	0.10	0.00	13.1	13.1	13.1	13.10	13.0
Avg									13.0

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Average Gas Concentration
(Eq. 6C - 1)

$$C_{gas} = (\bar{C} - C_o) \frac{C_{MA}}{(C_M - C_o)}$$

$$C_o = \frac{C_{oi} + C_{of}}{2}$$

where: C_{oi} : Initial zero response
 C_{of} : Final zero response

$$C_M = \frac{C_{si} + C_{sf}}{2}$$

where: C_{si} : Initial span response
 C_{sf} : Final span response

C_{MA} = Span tank concentration

$\bar{C}$ = Data logger average

K-28

Page 1

APPENDIX L

OPERATIONAL DATA

<u>CONTENTS</u>	<u>PAGE</u>
TEST SCHEDULES	2
LINE I DRYER DATA SUMMARY	3
LINE I PRESS & THERMAL OIL DATA SUMMARY	4
LINE I DRYER TESTING FEBRUARY 20, 1996 PM, METH., BENZ., NOX, CO, CO2, THC, M2, PHENOL	
PRODUCTION/SUMMARY	5-6
PRESS CHARTS	7-8
PRESS REPORT	9
DRYER READINGS	10-11
DRYER CHARTS	12-13
DRYER RTO READINGS	14
DRYER RTO CHART	15
BOARD WEIGHTS/THICKNESSES	16-17
LINE I DRYER TESTING FEBRUARY 21, 1996 FORMALDEHYDE	
PRODUCTION/SUMMARY	18
PRESS REPORT	19-20
PRESS CHARTS	21-22
DRYER READINGS	23-24
DRYER CHARTS	25-28
EFB READINGS	29-30
DRYER RTO READINGS	31-32
DRYER RTO CHART	33
BOARD WEIGHTS/THICKNESSES	34-35
LINE I DRYER TESTING FEBRUARY 21-22, 1996 POM	
PRODUCTION/SUMMARY	36
PRESS REPORT	37
PRESS CHARTS	38-39
DRYER READINGS	40-41
DRYER CHARTS	42-43
EFB READINGS	44
DRYER RTO READINGS	45
DRYER RTO CHART	46
BOARD WEIGHTS/THICKNESSES	47-48

* Tested using 10% pine EMS 4-10-96

**LINE I PRESS VENT/INLET TESTING FEBRUARY 21, 1996
PM,METH.,BENZ.,NOX,CO,CO2,THC,M2**

PRODUCTION/SUMMARY	49
MICRO-MOTIONS RESIN USAGE	50-52
PRESS REPORT	53-54
PRESS CHARTS	55-56
DRYER RTO READINGS	57-58
DRYER RTO CHART	59

**LINE I PRESS VENT/RTO STACK TESTING FEBRUARY 21, 1996
MDI,FORMALDEHYDE**

PRODUCTION/SUMMARY	60-61
MICRO-MOTIONS RESIN USAGE	62-70
PRESS REPORT	71
PRESS CHARTS	72-73
DRYER RTO READINGS	74
DRYER RTO CHART	75

**LINE I THERMAL OIL HEATING TESTING FEBRUARY 20-21, 1996
POM**

PRODUCTION/SUMMARY	76
PRESS REPORT	77
PRESS CHARTS	78-79
DRYER RTO READINGS	80
DRYER RTO CHART	81

**LINE I THERMAL OIL HEATING TESTING FEBRUARY 21, 1996
PHENOL,PM**

PRODUCTION/SUMMARY	82-83
PRESS REPORT	84-85
PRESS CHARTS	86-87
DRYER RTO READINGS	88-89
DRYER RTO CHART	90

**LINE I THERMAL OIL HEATING TESTING FEBRUARY 21, 1996
NO,CO,CO2,FORMALDEHYDE,BENZENE**

PRODUCTION/SUMMARY	91
PRESS REPORT	92
PRESS CHARTS	93-94
DRYER RTO READINGS	95
DRYER RTO CHART	96

KONUS DATA 2/20/96	97-102
KONUS EFB REPORT 2/20/96	103-104
KONUS DATA 2/21/96	105-106
KONUS EFB REPORT 2/21/96	107-108
KONUS EFB REPORT 2/22/96	109

LINE 1 PRESS TESTING FEBRUARY 21, 1996 - PM,METH,BENZ,NOx...

20.69 =Plant Production rate in Tons per hour
420.67 =MDI resin usage in pounds per hour
1.02% =MDI resin usage as % of finished product
886.67 =Liquid phenolic resin usage in pounds per hour (100% solids)
2.14% =Liquid phenolic resin usage as % of finished product (100% solids)
301.33 =Wax usage in pounds per hour
0.73% =Wax usage as % of finished product

LINE 1 PRESS TESTING FEBRUARY 22, 1996 - MDI

20.53 =Plant Production rate in Tons per hour
421.00 =MDI resin usage in pounds per hour
1.03% =MDI resin usage as % of finished product
908.25 =Liquid phenolic resin usage in pounds per hour (100% solids)
2.21% =Liquid phenolic resin usage as % of finished product (100% solids)
293.00 =Wax usage in pounds per hour
0.71% =Wax usage as % of finished product

LINE 1 PRESS TESTING FEBRUARY 22, 1996 - FORMALDEHYDE

19.43 =Plant Production rate in Tons per hour
419.25 =MDI resin usage in pounds per hour
1.08% =MDI resin usage as % of finished product
904.00 =Liquid phenolic resin usage in pounds per hour (100% solids)
2.33% =Liquid phenolic resin usage as % of finished product (100% solids)
280.50 =Wax usage in pounds per hour
0.72% =Wax usage as % of finished product

LINE 1 THERMAL OIL HEATER FEBRUARY 21, - PM

20.15 =Production rate in Tons per hour
0.46 =K1 estimated Tons per hour of fuel burned based on fuel measurement
8.25 =K1 estimated mmBTU per hour input based on fuel measurement
0.61 =K2 estimated Tons per hour of fuel burned based on fuel measurement
11.01 =K2 estimated mmBTU per hour input based on fuel measurement
1.07 =Total tons of dry bark per hour input
19.27 =Total mmBTU per hour input

LINE 1 THERMAL OIL HEATER - FEBRUARY 20/21, - POM

20.35 =Production rate in Tons per hour
0.48 =K1 estimated Tons per hour of fuel burned based on fuel measurement
8.63 =K1 estimated mmBTU per hour input based on fuel measurement
0.68 =K2 estimated Tons per hour of fuel burned based on fuel measurement
12.22 =K2 estimated mmBTU per hour input based on fuel measurement
1.16 =Total tons of dry bark per hour input
20.85 =Total mmBTU per hour input

LINE 1 THERMAL OIL HEATER - FEBRUARY 21, - PHENOL

20.73 =Production rate in Tons per hour
0.46 =K1 estimated Tons per hour of fuel burned based on fuel measurement
8.25 =K1 estimated mmBTU per hour input based on fuel measurement
0.69 =K2 estimated Tons per hour of fuel burned based on fuel measurement
12.50 =K2 estimated mmBTU per hour input based on fuel measurement
1.15 =Total tons of dry bark per hour input
20.74 =Total mmBTU per hour input

LINE 1 THERMAL OIL HEATER - FEBRUARY 22, - METH,BENZ,NOx...

20.32 =Production rate in Tons per hour
0.45 =K1 estimated Tons per hour of fuel burned based on fuel measurement
8.06 =K1 estimated mmBTU per hour input based on fuel measurement
0.64 =K2 estimated Tons per hour of fuel burned based on fuel measurement
11.52 =K2 estimated mmBTU per hour input based on fuel measurement
1.09 =Total tons of dry bark per hour input
19.58 =Total mmBTU per hour input

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices
per unit over the testing period.

1/2"

per/peice 55.54

per/ 8' x 16' 222.17

PLANT PRODUCTION RATE

4.75 =hours during testing

70 =pressloads

840 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

186,621 =lbs of finished product (boards produced x weight of finished board)

39,289 =lbs of finished product per hour (lbs of finshed product / hours)

19.64 =tons of finished product per hour (lbs of finshed product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY DRY FUEL INPUTSURFACE

10 =SURFACE fuel calibration in pounds per count

2,191 =SURFACE counts during testing hours

21,910 =SURFACE lbs of fuel burned during testing

4.75 =hours during testing

4,613 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.31 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

39.7 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,630 =average inlet temperature

52.55 =average incoming moisture percent

5.47 =average dry moisture percent

CORE

10 =CORE fuel calibration in pounds per count

2,032 =CORE counts during testing hours

20,320 =CORE lbs of fuel burned during testing

4.75 =hours during testing

4,278 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.14 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

36.8 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,597 =average inlet temperature

52.55 =average incoming moisture percent

6.20 =average dry moisture percent

DRYER THROUGHPUT RATE

8,891 =Total pounds of fuel burned per hour in Core and Surface Dryer

39,289 =lbs of finished product per hour (lbs of finshed product / hours)

48,179 =Pounds of material produced by the dryer per hour (dry basis, assumming fuel balances)

2,642 = weight of trim per hour at 6.3% of finished product

6,249 =weight of screened fines per hour (total fuel - trim)

12.97% =resulting loss to fines as percentage of dryer throughput

HAYWARD TESTING FEBRUARY 20th - 22nd
Test schedule

Line 1 Dryer Outlet / RTO Outlet / E-Tube Outlet

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
2-20	PM/METH/BENZ/ NOX/CO/CO2/THC	0950-1057	1140-1248	1320-1430
2-20	PHENOL	1520-1620	1635-1735	1750-1850

Line 1 Dryer RTO Stack

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
2-21	FORMALDEHYDE	0830-0938	1020-1127	1205-1310
2-21	POM	1730-2037		
2-22	POM		0800-1102	1300-1556

Line 1 Press Vent RTO Stack

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
2-21	PM/METH/BENZ/ NOX/CO/CO2/THC	1215-1316	1400-1501	1535-1636

Line 1 Press Vent RTO Stack

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
2-22	MDI	0800-0913	0940-1052	1117-1229
2-22	FORMALDEHYDE	1335-1436	1450-1551	1608-1708

Line 1 Thermal Oil Stack

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
2-20	POM	1550-1905		
2-21	POM		0835-1130	1329-1618

Line 1 Thermal Oil Stack

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
2-21	PHENOL	0934-1038	1056-1158	1341-1441
2-21	PM	1535-1651	1725-1829	1900-2004

Line 1 Thermal Oil Stack

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
2-22	BENZ/FORM/NOX CO/O2/CO2	0900-1005	1053-1157	1303-1403

**APPROXIMATE TEST TIMES ONLY - SEE INTERPOLL SHEETS
 FOR EXACT TIMES.**

HAYWARD LINE 1 DRYER TESTING FEBRUARY 20 - 22, 1996
Line 1 process data summary

LINE 1 DRYER TESTING FEBRUARY 20, 1996 PM/METH/BENZ...

19.64 = Press Production rate in Tons per hour
48,179 = Production rate of both dryers in pounds per hour
2.31 = Surface fuel burned in tons per hour
2.14 = Core fuel burned in tons per hour
4.45 = Total fuel (both dryers) burned in tons per hour
52.6% = average incoming moisture percent (both dryers)
5.8% = average dry moisture percent (both dryers)
1,613 = average inlet temperature (both dryers)

LINE 1 DRYER TESTING FEBRUARY 21, 1996 PHENOL

19.55 = Press Production rate in Tons per hour
47,750 = Production rate of both dryers in pounds per hour
2.28 = Surface fuel burned in tons per hour
2.05 = Core fuel burned in tons per hour
4.32 = Total fuel (both dryers) burned in tons per hour
52.6% = average incoming moisture percent (both dryers)
5.1% = average dry moisture percent (both dryers)
1,636 = average inlet temperature (both dryers)

LINE 1 DRYER TESTING FEBRUARY 21, 1996 FORMALDEHYDE

20.70 = Press Production rate in Tons per hour
50,157 = Production rate of both dryers in pounds per hour
2.24 = Surface fuel burned in tons per hour
2.14 = Core fuel burned in tons per hour
4.38 = Total fuel (both dryers) burned in tons per hour
51.7% = average incoming moisture percent (both dryers)
5.5% = average dry moisture percent (both dryers)
1,635 = average inlet temperature (both dryers)

LINE 1 DRYER TESTING FEBRUARY 21&22, 1996 POM

19.27 = Press Production rate in Tons per hour
46,933 = Production rate of both dryers in pounds per hour
2.21 = Surface fuel burned in tons per hour
1.98 = Core fuel burned in tons per hour
4.19 = Total fuel (both dryers) burned in tons per hour
52.7% = average incoming moisture percent (both dryers)
5.5% = average dry moisture percent (both dryers)
1,635 = average inlet temperature (both dryers)

HAYWARD LINE I FEBRUARY 20 th 1996

PHENOL

DATA TIME START= 15:15 END= 19:00 HOURS= 3.75

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices per unit over the testing period.

1/2"

per/peice 55.54

per/ 8' x 16' 222.17

PLANT PRODUCTION RATE

3.75 =hours during testing

55 =pressloads

660 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

146,631 =lbs of finished product (boards produced x weight of finished board)

39,102 =lbs of finished product per hour (lbs of finished product / hours)

19.55 =tons of finished product per hour (lbs of finished product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY DRY FUEL INPUT

SURFACE

10 =SURFACE fuel calibration in pounds per count

1,709 =SURFACE counts during testing hours

17,090 =SURFACE lbs of fuel burned during testing

3.75 =hours during testing

4,557 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.28 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

39.2 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,653 =average inlet temperature

52.55 =average incoming moisture percent

5.05 =average dry moisture percent

CORE

10 =CORE fuel calibration in pounds per count

1,534 =CORE counts during testing hours

15,340 =CORE lbs of fuel burned during testing

3.75 =hours during testing

4,091 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.05 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

35.2 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,619 =average inlet temperature

52.55 =average incoming moisture percent

5.16 =average dry moisture percent

DRYER THROUGHPUT RATE

8,648 =Total pounds of fuel burned per hour in Core and Surface Dryer

39,102 =lbs of finished product per hour (lbs of finished product / hours)


47,750 =Pounds of material produced by the dryer per hour (dry basis, assumming fuel balances)

2,629 = weight of trim per hour at 6.3% of finished product


6,019 =weight of screened fines per hour (total fuel - trim)

12.61% =resulting loss to fines as percentage of dryer throughput

PRESS CHART
2/20/96
0700-1500



PRESS CHART
15:00-19:00



PRESS REPORT - LINE 1 2

Nievers

SHIFT:

DATE: 2-20-96

CREW:

C

THICKNESS

 $2\frac{3}{32}''$

PRESS LDS:

$3\frac{23}{32}H, 181\frac{1}{2}$

OVERALL

TIMER:

270

DECOMPRESSION

TIME:

-30

PRESS

TEMP:

25°C

TOTAL

REJECTS:

LOG COUNT:

1517

LINE SPEED	THKNS.	FROM	TO
35	$2\frac{3}{32}$ H	7:00	712
52	$\frac{1}{2}$	712	829
55	"	829	223
45	"	223	300
55	"	3:00	300

F.C.O.S. HYD. RADIATOR:

730

TIME

PRESS BLOWN DOWN:

700

SPINNER HEADS FLUSHED:

TIME

SURFACE BLENDER HOSED:

TIME

FORMER HYD RADIATOR:

TIME

[illegible]

DOWNTIME CODE:

M - MECHANICAL

E - ELECTRICAL


O - OPERATOR

date 2/20/96
by _____


page 2 of 2

[illegible]

SURFACE DRYER
2/20/96



LINE I
CORE DRYER
2/20/96
7 AM - 7 PM




LI Orver R40 2-20-96

RECORD EVERY 15 MIN.						HAYWARD AIR TESTING WORKSHEET						
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage
9:00	315	356	469	435	335	1.7	43.6	50.0	1515	254	26.1	0
9:15	319	351	468	442	329	1.5	25.0	25.8	1526	245	26.7	2
9:30	318	350	469	443	328	1.5	26.0	26.6	1531	247	26.8	4
9:45	317	348	473	441	329	1.1	50.8	28.8	1521	250	27.3	7
10:00	316	350	472	444	325	1.3	29.8	32.6	1514	241	26.7	9
10:15	315	351	473	446	324	1.2	27.8	31.7	1514	240	26.7	11
10:30	314	351	473	447	323	1.0	27.0	29.4	1514	239	26.2	14
10:45	314	350	476	444	325	1.2	24.0	31.8	1516	241	26.6	16
11:00	312	352	474	448	321	.6	36.1	32.3	1512	240	26.3	18
11:15	312	353	474	449	321	1.2	35.0	28.8	1513	242	26.6	20
11:30	312	354	476	449	320	.9	36.0	25.8	1513	241	26.3	23
11:45	311	355	475	451	320	1.3	34.3	27.7	1512	242	26.6	25
12:00	311	357	475	451	319	1.3	35.7	31.0	1513	246	26.7	27
12:15	310	356	475	451	320	1.5	36.1	22.7	1512	243	26.5	29
12:30	309	356	472	449	317	1.2	36.8	30.7	1512	240	26.8	32
12:45	308	357	473	448	317	1.1	25.1	29.6	1519	246	26.7	34
1:00	309	357	474	449	317	1.1	62.6	29.8	1512	245	26.8	37
1:15												
1:30	309	359	475	449	318	.9	36.8	34.9	1511	256	26.2	41
1:45	310	360	475	451	317	.9	37.2	26.8	1509	252	26.2	43
2:00	309	360	476	450	317	1.0	36.7	20.6	1508	253	26.3	46
2:15	310	358	477	449	318	1.2	35.0	28.2	1514	246	26.8	48
2:30	310	360	476	449	318	.9	36.3	33.6	1509	257	26.2	50
2:45	310	361	477	449	319	1.2	34.4	24.9	1513	252	26.1	52
3:00	310	362	476	449	319	1.0	34.2	24.0	1509	251	26.2	55
3:15	311	361	476	449	319	1.1	33.9	28.3	1509	246	26.6	57
3:30	311	361	475	449	319	1.1	35.8	27.7	1509	252	26.3	59
3:45	312	357	476	447	317	1.2	34.0	22.6	1511	242	26.5	62
4:00	313	355	478	445	320	.7	35.0	28.0	1509	240	26.2	64
4:15	314	356	476	447	321	.8	38.5	31.3	1510	241	26.1	66
4:30	314	355	474	446	320	.9	35.3	30.7	1509	240	26.5	68
4:45	315	354	474	446	322	1.0	36.8	30.1	1512	240	26.2	71
5:00	316	353	476	444	324	1.5	37.7	27.3	1510	242	26.5	73
5:15	317	353	477	442	326	1.2	56.3	31.8	1506	250	27.2	75
5:30	317	352	475	442	326	1.2	43.7	25.4	1509	244	26.8	77
5:45	318	352	476	440	328	.8	50.3	32.1	1510	250	27.2	80
6:00	317	351	476	439	328	.6	46.8	33.0	1511	250	27.2	82
6:15	317	352	476	439	329	.8	51.2	34.6	1511	250	27.4	84
6:30	317	352	476	438	330	.5	50.6	30.0	1511	251	27.4	86
6:45	317	353	476	438	331	.7	53.7	31.9	1509	250	27.5	89
7:00	317	352	475	437	331	.6	50.9	34.7	1511	250	27.4	91

KCF

Line I Dryer RTO
2/20/96



DATE: 22A-96-1
 SHIFT/CREW: 1st 2nd C
 OPERATOR: ATKINSON

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
1	#3693	36 5/8 705	31	#4475	40 3/4 10
2		36 5/8 711	32	#4470	41 1/2 10
3		36 5/8 716	33	#4384	41 3/4 11
4	#3741	36 5/8 721	34	#4617	41 1/2 11
5		36 5/8 728	35	#4499	40 3/4 11
6	#4346	39 3/4 736	36	#4515	41 1/2 11
7	#4320	40 3/4 744	37	#4451	40 3/4 11
8	#4436	40 3/4 750	38	#4545	41 1/2 11
9	#4423	40 3/4 757	39	#4498	40 3/4 11
10	#4489	41 3/4 804	40	#4493	41 1/2 11
11	#4410	40 5/8 810	41	#4503	41 1/2 11
12	#4421	40 5/8 816	42	#4516	40 3/4 11
13	#4400	40 5/8 824	43	#4540	40 3/4 11
14	#4425	40 5/8 830	44	#4571	41 1/2 11
15	#4406	40 5/8 837	45	#4459	40 5/8 11
16	#4442	40 5/8 843	46	#4600	41 1/2 11
17	#4342	40 5/8 850	47	#4518	40 5/8 11
18	#4287	40 5/8 856	48	#4488	40 5/8 11
19	#4415	40 3/4 902	49	#4510	40 3/4 11
20	#4377	40 5/8 908	50	#4345	40 3/4 11
21	#4396	40 1/2 914	51	#4389	39 3/4 11
22	#4392	40 4/8 922	52	#4419	40 1/2 11
23	#4387	40 5/8 928	53	#4365	40 1/2 11
24	#4349	40 5/8 935	54	#4530	39 3/4 11
25	#4373	40 5/8 941	55	#4327	39 1/2 11
26	#4442	40 5/8 947	56	#4356	39 3/4 11
27	#4443	40 5/8 953	57	#4344	40 5/8 11
28	#4453	40 5/8 957	58	#4397	39 3/4 11
29	#4387	40 5/8 1005	59	#4479	40 5/8 11
30	#4438	41 1/8 1010	60	#4447	40 5/8 11
31	#4351	40 5/8 1017	61	#4431	40 5/8 11
32	#4381	40 5/8 1024	62	#4471	40 3/4 11
33	#4371	40 3/4 1031	63	#4478	40 5/8 11
34	#4100	40 3/4 1037	64	#4460	40 3/4 11
35	#4475	40 5/8 1044	65	#4719	40 3/4 11

DATE: 2/20/96
 SHIFT/CREW: _____
 OPERATOR: _____

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
5 16	#4598	40 307	2 101	4492	40 3649
67	#4614	41 315	102	4480	40 365
68	#4391	40 321			
69	#4433	40 327			
70	#4469	40 333			
71	#4491	40 340			
72	#4504	40 346			
73	#4527	40 353			
74	#4477	40 359			
75	#4473	40 405			
76	#4492	40 411			
77	#4472	40 419			
78	#4479	40 424			
79	#4448	40 431			
80	#4409	40 437			
81	#4334	40 444			
82	#11316	40 449			
83	#4341	40 457			
84	#4268	40 502			
85	#11360	40 508			
86	#4258	40 515			
87	#4348	40 520			
88	#4367	40 527			
89	#4376	40 533			
90	#4359	40 540			
91	#4378	40 546			
92	#4366	40 554			
93	#4423	40 559			
94	#4463	40 605			
95	#4500	40 612			
96	#4517	40 616			
97	#4502	40 623			
98	#4495	40 630			
99	#4491	40 637			
100	#4488	40 643			

HAYWARD LINE I FEBRUARY 21 st 1996

FORMALDEHYDE

DATA TIME START= 08:30 END= 13:15 HOURS= 4.75

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices per unit over the testing period.

1/2"

per/peice 54.63

per/ 8' x 16' 218.51

PLANT PRODUCTION RATE

4.75 =hours during testing

75 =pressloads

900 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

196,657 =lbs of finished product (boards produced x weight of finished board)

41,402 =lbs of finished product per hour (lbs of finshed product / hours)

20.70 =tons of finished product per hour (lbs of finshed product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY DRY FUEL INPUT

SURFACE

10 =SURFACE fuel calibration in pounds per count

2,128 =SURFACE counts during testing hours

21,280 =SURFACE lbs of fuel burned during testing

4.75 =hours during testing

4,480 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.24 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

38.5 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,646 =average inlet temperature

51.68 =average incoming moisture percent

5.03 =average dry moisture percent

CORE

10 =CORE fuel calibration in pounds per count

2,031 =CORE counts during testing hours

20,310 =CORE lbs of fuel burned during testing

4.75 =hours during testing

4,276 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.14 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

36.8 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,623 =average inlet temperature

51.68 =average incoming moisture percent

5.96 =average dry moisture percent

DRYER THROUGHPUT RATE

8,756 =Total pounds of fuel burned per hour in Core and Surface Dryer

41,402 =lbs of finished product per hour (lbs of finshed product / hours)

50,157 =Pounds of material produced by the dryer per hour (dry basis, assumming fuel balances)

2,784 = weight of trim per hour at 6.3% of finished product

5,972 =weight of screened fines per hour (total fuel - trim)

11.91% =resulting loss to fines as percentage of dryer throughput

PRESS REPORT - LINE 1 2

SHIFT:

DATE: 7-21-96

CREW:

THICKNESS

PRESS LDS:

DECOMPRESSION

TIME:

TOTAL

REJECTS:

LOG COUNT:

F.C.O.S. HYD. RADIATOR:

PRESS BLOWN DOWN:

SPINNER HEADS FLUSHED:

SURFACE BLENDER HOSED:

FORMER HYD RADIATOR:

LINE SPEED	THKNS.	FROM	TO
55	1/2	7:00	
46	17/32 SE	855	
52	15/32	100	
48	25/32	500	
45	15/32	640	

[illegible]


DOWNTIME CODE:

M - MECHANICAL


E - ELECTRICAL

O - OPERATOR

2/21/96
0700-1500



LINE 1
PRESS CHART
2/21/94
1500-2030




2/21/96


page / of 2

TIME	FACE				CORE								WET BIN		DRY BIN		EVERY HOUR FLAKE MOISTURE	
	OUT. SET POINT	FEED RATE	INLET TEMP	OUTLET TEMP	FUEL COUNT	WET BIN LEVEL	OUT. SET POINT	FEED RATE	INLET TEMP	OUTLET TEMP	FUEL COUNT	WET BIN LEVEL	FACE	LEVEL	CORE	FACE	CORE	
8:30	258	55	1647	2432	683	60%	271	59	1578	271	653	50%	90%	75%	510	4.8	4.6	
8:45	258	54	1668	2440	794	60%	271	59	1669	2466	752	50%	90%	75%		5.0	4.8	
9:00	258	55	1661	2441	909	70%	269	61	1603	2465	877	60%	90%	70%		5.2	5.0	
9:15	258	57	1673	2443	1019	70%	261	61	1598	2455	966	60%	80%	70%		4.8	5.6	
9:30	258	56	1656	2399	1137	75%	267	60	1613	250	1077	70%	75%	60%		5.6	6.6	
9:45	258	56	1640	2316	1245	75%	267	59	1595	255	1181	75%	75%	60%	512	5.2	6.6	
10:00	258	56	1678	2347	1371	75%	267	60	1616	259	1301	75%	75%	60%		4.8	5.6	
10:15	258	56	1665	2333	1480	75%	267	58	1602	248	1404	75%	75%	60%		5.2	6.8	
10:30	258	52	1678	234	1590	80%	267	56	1609	253	1511	90%	75%	70%	508	5.6	6.2	
10:45	258	55	1650	250	1701	90%	267	59	1627	2466	1627	90%	75%	70%		4.6	4.8	
11:00	258	55	1629	237	1816	100%	263	58	1625	247	1734	100%	70%	70%		4.8	6.6	
11:15	258	54	1637	248	1919	100%	263	56	1606	252	1831	100%	70%	60%		4.8	6.2	
11:30	258	55	1666	239	2038	100%	263	57	1633	262	1943	100%	70%	70%	514	4.4	4.6	
11:45	258	55	1674	239	2138	100%	263	57	1658	257	2021	100%	70%	70%		5.6	5.3	
12:00	258	55	1641	235	2250	100%	263	56	1623	244	2146	100%	60%	60%		5.2	6.8	
12:15	258	53	1623	244	2362	100%	263	58	1622	261	2253	100%	60%	60%		4.8	5.4	
12:30	258	54	1623	235	2474	100%	263	57	1619	245	2360	100%	60%	60%	540	5.6	6.8	
11:45	258	56	1674	251	2587	100%	263	58	1639	258	2471	100%	60%	60%		4.8	6.2	
1:00	258	55	1629	232	2702	100%	263	62	1665	253	2578	100%	50%	50%		5.2	6.4	
1:15	258	53	1650	246	2816	100%	263	58	1671	252	2684	100%	60%	40%		4.6	7.2	
1:30	258	55	1674	240	2939	90%	263	58	1604	255	2797	90%	50%	40%	520	4.8	6.0	
1:45	258	53	1636	233	3048	40%	263	53	1613	264	2902	70%	50%	50%		5.2	5.6	
2:00	258	55	1472	246	3154	60%	263	61	1610	262	2997	70%	50%	50%		4.8	5.0	
2:15	258	57	1614	236	3262	50%	263	62	1671	260	3094	60%	50%	50%		5.6	6.0	
2:30	258	53	1653	251	3384	50%	265	60	1663	251	3212	60%	50%	50%	516	5.4	6.6	
2:45	251	54	1400	250	3484	50%	265	58	1650	259	3316	60%	60%	50%		5.0	6.0	
3:00	251	56	1617	248	3606	50%	265	60	1584	265	3427	60%	50%	50%	418	4.8	5.2	
3:15	251	58	1680	246	3720	60%	265	61	1649	265	3524	60%	40%	40%		4.8	5.2	
3:30	251	57	1665	241	3822	60%	265	62	1624	262	3437	60%	40%	40%	520	4.8	5.6	
3:45	251	54	1641	246	3947	70%	265	62	1633	263	3745	60%	40%	40%		5.2	5.6	
4:00	251	56	1665	244	4063	75%	266	62	1646	260	3854	70%	40%	40%		5.0	6.2	
4:15	251	55	1606	257	4171	70%	266	60	1660	264	3960	70%	40%	40%		4.6	6.0	
4:30	250	58	1566	241	4280	70%	267	62	1588	264	4062	70%	40%	40%	318	4.0	5.0	
4:45	250	58	1629	253	4388	75%	267	62	1661	267	4164	70%	50%	40%		4.0	5.2	
5:00	250	57	1626	237	4510	75%	267	63	1684	261	4271	75%	50%	40%		4.8	6.8	
5:15	250	52	1619	219	4605	75%	267	58	1688	250	4363	75%	60%	50%		6.0	6.4	


LINE I
CORE DRYER
2/24/96
7 AM - 7 PM




LINE II
SURFACE DRYER
2/21/96
7 AM - 7 PM



LINE I
CORE DRYER
2/21/46
7pm - 7am



7pm - 7am



Konus EFB Readings
Plant

Hayward LP.

date
by

2/21/96
Jason N.

readings every 10 minutes

Time	K1 and K2				K3 and K4				Baghouse Press.	EFB Press.	Ion Current	Ion Volt	Bed Current	Bed Volt
	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.	Bed Volt	Bed Current						
4:30	13.5	0.2	20	1.2	1.8	4								
4:45	13.5	0.4	28	3.6	1	4								
5:00	13.5	0.2	30	4	1.4	4								
5:15	13.0	0.1	30	4	1.6	4								
5:30	13.0	0.2	29	4	1.9	4								
5:45	13.0	0.2	29	4	1.9	4								
6:00	13.0	0.2	30	4	2.2	4								
6:15	13.0	0.2	29	4	2.9	4								
6:30	13.0	0.2	30	4	3.4	4								
6:45	12.5	0.3	31	4	3.3	4								
7:00	13.0	0.3	30	4	2.9	4								
7:15	13.0	0.3	29	4	3	4								
7:30	13.0	0.3	29	4	2.8	4								
7:45	13.0	0.3	30	4	1.8	4								
8:00	12.0	0.3	30	4	1.4	4								
8:15	12.5	0.3	28	4	1.6	4								
8:30	12.5	0.3	30	4	1.6	4								
8:45	12.5	0.3	29	4	1.7	4								
9:00	12.5	0.3	29	4	1.5	4								
9:15	12.5	0.3	30	4	1.8	4								
9:30	12.5	0.3	29	4	1.4	4								
9:45	12.5	0.3	30	4	1.4	4.5								
10:00	12.5	0.3	29	4	1.4	4.5								
10:15	12.5	0.3	30	4	1.2	4								
10:30	12.5	0.3	29	4	1.4	4.2								
10:45	12.5	0.3	29	4	1.3	5								

Konus EFB Readings
Plant

Wayward LP

date 2/21/96
by Jason N.

readings every 10 minutes

Time	K1 and K2						K3 and K4					
	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.
4:00	12.5	0.6	28.5	.4	1.	.4						
4:15	12.5	0.3	30.0	.4	1.	.4						
4:30	12.0	0.3	29.0	.4	.9	.4						
4:45	12.0	0.3	29.0	.4	.4	.4						
5:00	12.5	0.3	29.0	.4	.6	.4						
5:15	12.5	0.3	29.0	.4	.6	.4						
5:30	12.0	0.3	31.0	.4	.6	.4						
5:45	12.5	0.3	30	.4	.6	.4						
6:00	12.5	0.3	29	.4	.4	.4						
6:15	12.5	0.3	29	.4	.6	.4						
6:30	12.5	0.3	29	.4	.4	.4						
6:45	12.5	0.3	29	.4	.4	.4						
7:00	12.5	0.3	29	.4	.2	.4						
7:15	12.5	0.3	29	.4	0	.4						
7:30	12.5	0.3	28	.4	0	.4						
7:45	12.5	0.3	28.5	.4	0	.4						
8:00	12.5	0.3	29	3.8	0	.4						


LI Dryer Rto

2-21-98

RECORD EVERY 15 MIN.

HAYWARD AIR TESTING WORKSHEET

Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage
8:30	317	352	465	439	320	.7	33.8	27.4	1513	238	26.8	0
8:45	316	357	462	442	321	1.3	34.0	22.8	1508	252	26.4	2
9:00	314	360	464	439	324	.4	43.0	42.1	1502	256	26.4	4
9:15	314	360	467	437	326	1.4	40.6	50.5	1511	252	26.6	6
9:30	314	360	467	438	326	1.4	40.7	51.5	1511	249	26.7	8
9:45	314	361	467	439	326	1.7	40.6	45.2	1512	248	26.7	11
10:00	314	360	469	437	327	1.9	58.5	39.7	1515	249	26.7	13
10:15	315	359	471	436	327	1.7	39.7	32.8	1517	243	26.2	15
10:30	315	360	472	438	326	1.8	28.5	44.3	1522	243	26.4	18
10:45	316	356	474	436	327	1.0	35.5	27.4	1522	244	27.0	20
11:00	317	353	476	437	327	.5	33.4	32.1	1525	249	27.4	22
11:15	317	353	477	438	326	.5	31.1	24.7	1534	249	27.4	24
11:30	316	357	477	438	327	.7	34.8	31.5	1527	247	27.0	26
11:45	316	358	477	438	328	1.3	43.2	28.5	1515	246	26.9	29
12:00	318	355	478	438	327	.5	40.9	26.7	1520	250	27.1	31
12:15	317	357	478	438	328	.6	35.8	44.7	1524	248	27.3	33
12:30	318	356	479	439	328	.5	40.2	31.5	1523	251	27.3	35
12:45	315	360	475	437	328	1.7	30.3	38.3	1525	242	26.5	38
1:00	315	362	475	439	328	1.8	50.5	74.2	1515	245	26.4	40
1:15	318	358	479	436	330	.8	49.5	34.4	1517	247	27.1	42
1:30	316	363	474	441	329	1.8	42.9	33.3	1532	252	26.6	44
1:45	317	363	475	439	331	1.8	45.3	29.7	1519	245	26.4	46
2:00	317	361	476	437	331	1.6	47.5	35.3	1517	244	26.6	49
2:15	317	365	471	443	328	.4	44.0	38.3	1516	259	26.5	51
2:30	317	363	476	438	333	1.8	43.6	40.1	1516	247	26.5	53
2:45	317	364	472	441	331	1.3	58.0	47.5	1514	253	27.1	56
3:00	317	362	473	438	333	1.7	50.2	49.3	1515	245	26.5	58
3:15	317	364	472	439	333	1.8	46.0	45.0	1518	248	26.5	60
3:30	317	365	469	444	331	.5	46.3	42.1	1523	259	26.3	62
3:45	318	365	468	445	331	1.0	38.2	28.3	1525	260	26.4	64
4:00	318	365	468	445	332	.3	37.5	32.0	1520	258	26.2	66
4:15	320	361	467	448	329	1.0	37.2	31.9	1522	247	26.7	68
4:30	319	359	475	438	337	1.9	42.2	43.9	1519	252	26.8	70
4:45	319	363	467	447	330	1.1	50.8	22.4	1523	248	26.6	73
5:00	320	360	468	448	330	1.4	37.7	20.1	1521	245	26.6	75
5:15	321	360	468	449	331	1.3	35.4	30.2	1519	245	26.4	77
5:30	319	365	468	447	334	.9	41.9	35.4	1520	259	26.2	79
5:45	319	363	472	440	338	1.7	54.3	28.9	1521	245	26.2	81
6:00	318	361	465	446	332	.9	32.3	27.4	1516	248	26.7	84
6:15	318	356	466	443	330	.9	27.8	29.6	1522	240	26.4	86



Line I Dyer R10
2/21/96

DATE: 2 21 56
 SHIFT/CREW: 1st T crew
 OPERATOR: M. J. H.

UNIT/ 1/2"	THICKNESS	WEIGHT	HEIGHT	UNIT/	THICKNESS	WEIGHT	HEIGHT
1	7.40	4414	39 3/4	36	11.21	4476	41
2	7.47	4435	39 3/4	37	11.27	4490	40 3/4
3	7.53	4423	39 3/4	38	11.34	4481	41
4	8.01	4463	40	39	11.40	4471	41
5	8.06	4400	40 1/2	40	11.46	4438	40 3/4
6	8.12	4358	40 3/4	41	11.53	4425	40 3/4
7	8.18	4409	40 1/2	42	11.59	4430	41
8	8.26	4476	40 1/2	43	12.06	4409	40 3/4
9	8.33	4358	40 3/4	44	12.12	4387	40 3/4
10	8.39	4350	40 1/2	45	12.18	4378	40 3/4
11	8.44	4305 CP	40 3/4	46	12.24	4371	40 3/4
12	8.51	4291	41	47	12.31	4350	40 3/4
13	8.57	4276	40 3/4	48	12.36	4315	40 3/4
14	8.03	4327	41	49	12.43	4355	40 3/4
15	8.11	4378	40 3/4	50	12.50	4376	40 1/2
16	8.16	4356	41	51	12.56	4377	41
17	8.22	4376	40 3/4	52	13.02	4345	40 3/4
18	8.28	4379	40 3/4	53	13.08	4381	40 3/4
19	8.35	4317	40 3/4	54	13.15	4349	40 3/4
20	8.42		40 1/2	55	13.20	4321	40 1/2
21	8.51	4320	40 1/2	56	13.27	4339	40 1/2
22	8.54	4305	40 1/2	57	13.35	4328	40 1/2
23	8.59	4345	40 1/2	58	13.42	4499	40 1/2
24	10.06	4321	40 1/2	59	13.50	4537 CP	40 1/2
25	10.12	4277	40 3/4	60	13.57	4510	40 3/4
26	10.18	4250	40 1/2	61	13.63	4470	41
27	10.25	4205 CP	40 1/2	62	13.69	4362	40 3/4
28	10.31	4255	40 1/2	63	13.76	4350	41
29	10.37	4252 CP	40 1/2	64	13.82	4369	40 3/4
30	10.44	4314	41	65	13.88	4371	40 3/4
31	10.50	4349	40 3/4	66	13.95	4389	40 3/4
32	10.55	4389	41	67	14.02	4399	40 1/2
33	11.02	4393	41	68	14.08	4343	40 1/2
34	11.08	4440	40 3/4	69	14.14	4345	40 3/4
35	11.17	4460	41	70	14.20 CP	4317	40 1/2

DATE: _____
 SHIFT/CREW: _____
 OPERATOR: _____

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
71 :05	4263	40 1/4	106 :57	4483	41
72 :12	4247	40 1/6			
73 :18	4229 CP	40 1/4	B 1 :04	4460	41
74 :25	4291	40 1/6	2 :09	4457	40 3/4
75 :31	4301	40 1/2	3 :17	4443	40 3/4
76 :37	4273	40 1/6	4 :23	4435	40 3/4
77 :44	4321	40 1/6	5 :29	4430	40 3/4
78 :50	4301	40 1/2	6 :36	4414	40 3/4
79 :56	4362	40 1/2	7 :42	4409	40 3/4
80 4:02	4389	40 3/4	8 :48	4388	40 3/4
81 :09	4385	40 1/2	9 :54	4365	40 3/4
82 :14	4422	40 3/4	10 :00	4364	40 3/4
83 :21	4455	41	11 :07	4393	41
84 :28	4461	40 3/4	12 :20	4401	40 3/4
85 :33	4446	40 3/4	13 :20	4396	40 3/4
86 :39	4437	40 3/4	14 :27	4377	40
87 :45	4432	40 3/4	15 :33	4373	40
88 :53	4393	40 1/2	16 :		
89 5:07	4496	40 1/2	17 :		
90 :09	4503	40 1/4			
91 :16	4436	40 1/4			
92 :25	4404	40 1/4			
93 :32	4407	40 1/4			
94 :40	4379	40			
95 :48	4342	40			
96 :55	4310	40 1/4			
97 6:01	4255 CP	40 1/2			
98 :07	4167	40			
99 :14	4222	40 1/2			
100 :21	4321	40 1/2			
101 :27	4340	40 1/2			
102 :33	4376	41			
103 :39	4401	40 3/4			
104 :45	4467	41			
105 :50	4487	41			

HAYWARD LINE I FEBRUARY 21st & 22nd 1996

POM

DATA TIME	START=	17:30	END=	20:45	HOURS=	3.25
DATA TIME	START=	08:00	END=	16:00	HOURS=	8.00
					TOTAL=	11.25

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices per unit over the testing period.

1/2"

per/peice 54.42

per/ 8' x 16' 217.68

PLANT PRODUCTION RATE

11.25 =hours during testing

166 =pressloads

1992 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

433,619 =lbs of finished product (boards produced x weight of finished board)

38,544 =lbs of finished product per hour (lbs of finshed product / hours)

19.27 =tons of finished product per hour (lbs of finshed product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY DRY FUEL INPUT

SURFACE

10 =SURFACE fuel calibration in pounds per count

4,973 =SURFACE counts during testing hours

49,730 =SURFACE lbs of fuel burned during testing

11.25 =hours during testing

4,420 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.21 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

38.0 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,644 =average inlet temperature

52.74 =average incoming moisture percent

5.14 =average dry moisture percent

CORE

10 =CORE fuel calibration in pounds per count

4,465 =CORE counts during testing hours

44,650 =CORE lbs of fuel burned during testing

11.25 =hours during testing

3,969 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

1.98 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

34.1 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,627 =average inlet temperature

52.74 =average incoming moisture percent

5.81 =average dry moisture percent

DRYER THROUGHPUT RATE

8,389 =Total pounds of fuel burned per hour in Core and Surface Dryer

38,544 =lbs of finished product per hour (lbs of finshed product / hours)

46,933 =Pounds of material produced by the dryer per hour (dry basis, assumming fuel balances)

2,592 = weight of trim per hour at 6.3% of finished product

5,798 =weight of screened fines per hour (total fuel - trim)

12.35% =resulting loss to fines as percentage of dryer throughput

PRESS REPORT - LINE 71 2

DATE:

2-22-96

SHIFT:

Ann

CREW:

1

THICKNESS

PRESS LDS:

OVERALL

DECOMPRESSION

TIMER:

TIME:

PRESS

TOTAL

TEMP:

REJECTS:

LOG COUNT:

F.C.O.S. HYD. RADIATOR:

TIME

PRESS BLOWN DOWN:

SPINNER HEADS FLUSHED:

TIME

SURFACE BLENDER HOSED:

TIME

FORMER HYD RADIATOR:

TIME


DOWNTIME CODE:

M - MECHANICAL


E - ELECTRICAL

O - OPERATOR

LINE 1
PRESS CHART
2/22/96
0700-1500



LINE 1
PRESS CHART
2/22/96
1500-1900



fuel calibration 'ib/coun face

core

date by

by


page

2 of


2

[illegible]

LINE I
SURFACE DRYER
2/22/96
7am-7pm



LINE I
CORE DRYER
2/22/96
7AM - 7PM



Hayward C.P.

date by


2/22/96
Put in

[illegible]

LI Dryer R70 2-22-96

RECORD EVERY 15 MIN.						HAYWARD AIR TESTING WORKSHEET						
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage
8:00 AM	316	350	470	431	335	0.5	41.6	23.6	1521	249	27.8	0
8:15	317	351	463	439	329	0.8	33.0	18.3	1518	240	26.4	2
8:30	314	360	463	437	333	1.4	28.6	25.2	1520	250	26.5	4
8:45	318	350	468	436	332	0.7	28.8	20.9	1528	244	26.8	6
9:00	315	357	468	434	335	1.3	39.6	24.0	1529	244	26.8	8
9:15	314	361	464	440	332	0.8	40.2	38.6	1515	254	26.9	10
9:30	316	361	463	442	332	0.3	46.1	49.5	1516	256	26.7	13
9:45	317	356	463	445	328	1.2	35.5	17.4	1517	249	26.6	15
10:00	318	350	471	436	333	0.4	42.6	33.0	1518	247	27.2	18
10:15	318	354	465	444	328	0.6	30.3	15.1	1529	240	26.6	20
10:30	317	356	464	446	327	1.3	28.2	46.6	1519	248	26.8	22
10:45	317	354	472	435	334	0.4	36.0	22.9	1524	250	27.5	24
11:00	318	356	466	446	327	1.1	24.7	27.2	1521	243	26.7	26
11:15	315	363	469	441	332	1.6	49.8	31.9	1520	249	26.4	28
11:30	317	360	475	437	334	0.9	33.0	28.6	1531	248	27.2	31
11:45	316	364	470	444	331	1.2	38.2	32.9	1522	255	26.7	33
12:00	320	357	472	445	328	1.3	27.9	28.2	1525	243	26.4	34
12:15	320	357	478	439	332	0.8	35.8	30.9	1527	252	27.1	37
12:30	317	366	470	447	327	1.0	29.5	40.6	1528	259	26.5	39
12:45	318	360	480	438	332	0.4	49.8	26.7	1522	253	27.6	40
1:00	316	362	477	437	329	1.2	35.0	31.1	1529	244	27.0	43
1:15	315	367	474	442	327	1.2	38.5	41.7	1519	252	26.8	45
1:30	319	360	476	446	322	0.9	27.6	20.7	1534	244	27.0	47
1:45	319	359	482	440	326	0.9	27.4	10.5	1538	247	27.0	50
2:00	316	370	476	444	325	0.2	30.6	37.2	1525	259	26.6	52
2:15	320	361	479	413	324	1.2	34.6	18.9	1523	244	26.5	54
2:30	316	371	479	442	328	1.4	47.1	46.3	1519	250	26.6	56
2:45	317	369	489	440	329	1.8	52.8	36.2	1517	245	26.6	58
3:00	320	361	481	443	325	1.4	26.8	18.1	1514	248	27.1	61
3:15	318	370	477	446	324	0.9	36.3	27.7	1519	260	26.6	63
3:30	320	362	482	442	323	1.2	25.0	17.4	1526	244	26.6	65
3:45	320	361	485	439	325	0.7	30.1	17.6	1523	249	27.1	67
4:00	320	361	486	439	325	0.2	33.9	18.4	1522	249	27.2	69
4:15	319	366	480	445	321	1.1	28.2	29.9	1519	247	26.9	72
4:30	317	368	486	435	329	1.2	45.3	41.1	1518	246	26.9	73
4:45	316	371	481	440	326	1.7	40.5	30.8	1521	259	26.8	76
5:00	318	364	487	435	327	0.4	38.0	30.2	1527	252	27.6	78
5:10	320	361	480	437	325	0.3	37.9	20.1	1527	248	27.1	79

Pm



Line I Dyer RTO
2/22/96
46

DATE: 2 22 96
SHIFT/CREW: 1st Draw
OPERATOR: MESSER

UNIT/ 1/2	THICKNESS	WEIGHT	HEIGHT	UNIT/	THICKNESS	WEIGHT	HEIGHT
1	7:22	4261	39 1/4	36	11:12	4399	40 3/4
2	:36	4376 CP	39	37	12	4411	41
3	:45	4399	39 1/2	38	:24	4391	40 3/4
4	:51	4395	39 1/2	39	:31	4393	41
5	:58	4395	40	40	:37	4359	40 3/4
6	8:04	4383	40 3/4	41	:43	4340	40 1/2
7	:10	4306	40 1/2	42	:50	4342	40 1/2
8	:16	4273	40 3/4	43	:56	4301	40 3/4
9	:23	4261	40 1/2	44	12:02	4269	40 3/4
10	:29	4206 CP	40 1/2	45	:08	4263	40 3/4
11	:36	4187	40 1/2	46	:14	4236	40 1/2
12	:42	4228	40 1/2	47	:20	4216	40 3/4
13	:48	4179 CP	40 1/2	48	:28	4179 CP	40 1/2
14	:54	4236	40 3/4	49	:34	4202	40 1/2
15	9:00	4199	40 3/4	50	1:03	4188	40 3/4
16	:07	4179 CP	40 3/4	51	:10	4239	40 3/4
17	:13	4279	40 3/4	52	:15	4409	40 3/4
18	:20	4249	40 1/2	53	:21	4403	40
19	:25	4258	40 3/4	54	:29	4462	41 1/4
20	:31	4229	40 1/2	55	:35	4482	41
21	:38	4263	40 3/4	56	:41	4412	41 1/4
22	:44	4239	40 1/2	57	:48	4439 CP	41 1/4
23	:51	4246	40 3/4	58	:54	4463	41
24	:58	4248	40 3/4	59	:58	4434	40 3/4
25	10:03	4333	40 3/4	60	1:05	4450	40 1/2
26	10:09	4349	41	61	:13	4439	40 1/2
27	:16	4332	41	62	:18	4462	40 1/2
28	:22	4432	41	63	:25	4436	40 1/2
29	:27	4373	40 3/4	64	:31	4376	40 3/4
30	:34	4411	41	65	:37	4408	40
31	:40	4391	41	66	:44	4427	40
32	:46		41	67	:50	4423	40
33	:53		41	68	:56	4419	40 1/4
34	:59		41	69	3:03	4376	40
35	11:05		41	70	:09	4386	40

OPERATOR:

[illegible]

HAYWARD LINE I FEBRUARY 21st 1996

PRESS RTO (VENT/INLET)PM/METH/BENZ/NOx/CO/CO2/THC/M2/NOx

DATA TIM START= 12:15 END= 16:45 HOURS= 4.50

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices
per unit over the testing period.

1/2"

per/peice 54.63

per/ 8' x 16' 218.51

PLANT PRODUCTION RATE

4.50 =hours during testing

71 =pressloads

852 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

186,169 =lbs of finished product (boards produced x weight of finished board)

41,371 =lbs of finished product per hour (lbs of finshed product / hours)

20.69 =tons of finished product per hour (lbs of finshed product per hour / 2000 lb)

RESIN USAGE TAKEN FROM MICRO - MOTIONS

TIME	MDI	PHENOL	WAX
12:15-1:15	421	887	303
2:00-3:00	420	885	301
3:25-4:25	421	888	300

AVERAGE 420.67 886.67 301.33

41,371 =average lbs. per hour finished product produced during testing

420.67 =average lbs. per hour of MDI resin used during testing

1.02% = MDI resin used as % of finished product

886.67 =average lbs. per hour of phenolic resin (100% solids) used during testing

2.14% =Phenolic resin used as % of finished product

301.33 =average lbs. per hour of wax (100% solids) used during testing

0.73% =wax used as % of finished product

Micro-Motions		100% Solids
Solids	Pounds	
100% MDI Core -	421	421
57% PF Surf. -	1557	887
58% Wax Core -	197	303
58% Wax Surf. -	325	

Tanks		100% Solids
Solids	Before After Pounds	
100% Core MDI -	226.875 226.25	375 375
2 ÷ 61% Surf PF -	37 37	—
2 ÷ 57% Day Tank PF -	485 1044	1860 530
2 ÷ 57% Mix Tank PF -	761 18	
2 ÷ 58% Wax -	124 121½	955 277

Factors per inch	
MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon	
Day Tank -	10.11
Mix Tank -	10.11

Micro-Motions

Solids

Pounds

100%
Solids

100% MDI Core - 420

420

57% PF Surf. - 1552

885

58% Wax Core - 202

301

58% Wax Surf. - 317

Tanks

Solids

Before

After

Pounds

100%
Solids

100% Core MDI -

225.75

224.875

525 ~~334~~

525

2 ÷ 61% Surf PF -

37

37

2 ÷ 57% Day Tank PF -

834

559 ~~567~~

2780

792

2 ÷ 57% Mix Tank PF -

8

8

2 ÷ 58% Wax -

119.5

117.0

955

277

Factors per inch

MDI Tank - 600.466

PF Tank - 727.583

Wax Tank - 381.86

Factors per gallon

Day Tank - 10.11

Mix Tank - 10.11

Micro-Motions		100% Solids
Solids	Pounds	
100% MDI Core -	421	421
57% PF Surf. -	1558	888
58% Wax Core -	206	300
58% Wax Surf. -	311	

Tanks		100% Solids
Solids	Before After Pounds	Solids
100% Core MDI -	224.75 224	450 450
2 ÷ 61% Surf PF -	26.5 26.5	
2 ÷ 57% Day Tank PF -	442 991	2639 752
2 ÷ 57% Mix Tank PF -	820 10	
2 ÷ 58% Wax -	115.5 113	955 277

Factors per inch	
MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon	
Day Tank -	10.11
Mix Tank -	10.11

PRESS REPORT - LINE 1) 2

SHIFT:

DATE:

CREW:

THICKNESS

PRESS LDS:

OVERALL
TIMER:

DECOMPRESSION
TIME:

PRESS
TEMP:

TOTAL
REJECTS:

LOG COUNT:

F.C.O.S. HYD. RADIATOR:

TIME

PRESS BLOWN DOWN:

SPINNER HEADS FLUSHED:

TIME

SURFACE BLENDER HOSED:

TIME

FORMER HYD RADIATOR:

TIME

DOWNTIME CODE:

M - MECHANICAL

E - ELECTRICAL

O - OPERATOR

PRESS REPORT - LINE 7 2

DATE: 7-21-96

CREW: *[Signature]*

OPERATOR

SHIFT:

PRESS LDS: 30 1/2 55 1 3/32 SE 87 15/32

THICKNESS

OVERALL.

TIMER:

PRESS

TEMP:

DECOMPRESSION

TIME:

TOTAL

REJECTS:

LOG COUNT:

F.C.O.S. HYD. RADIATOR:

TIME

PRESS BLOWN DOWN:

SPINNER HEADS FLUSHED:

TIME

SURFACE BLENDER HOSED:

TIME

FORMER HYD RADIATOR:

TIME

LINE SPEED	THKNS.	FROM	TO
55	1/2	7:00	
46	17/32 SE	855	
52	15/32	100	
48	25/32	500	
45	15/32	640	

[illegible]


DOWNTIME CODE:

M - MECHANICAL


E - ELECTRICAL

O - OPERATOR

LINE 1 PRESS
CHART
2/21/96
0700-1500



Line I
 PRESS CHART
 2/21/94
 1500 - 2030




LI Dryer RTO 2-21-96

RECORD EVERY 15 MIN.						HAYWARD AIR TESTING WORKSHEET						
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage
8:30	317	352	465	439	320	.7	33.8	27.4	1513	238	26.8	0
8:45	316	357	462	442	321	1.3	34.0	22.8	1508	252	26.4	2
9:00	314	360	464	439	324	.4	43.0	42.1	1502	256	26.4	4
9:15	314	360	467	437	326	1.4	40.6	50.5	1511	252	26.6	6
9:30	314	360	467	438	326	1.4	40.7	51.5	1511	249	26.7	8
9:45	314	361	467	439	326	1.7	40.6	45.2	1512	248	26.7	11
10:00	314	360	469	437	327	1.9	58.5	39.7	1515	249	26.7	13
10:15	315	359	471	436	327	1.7	39.7	32.8	1517	243	26.2	15
10:30	315	360	472	438	326	1.8	28.5	44.3	1522	243	26.4	18
10:45	316	356	474	436	327	1.0	35.5	27.4	1522	244	27.0	20
11:00	317	353	476	437	327	.5	33.4	32.1	1525	249	27.4	22
11:15	317	353	477	438	326	.5	31.1	24.7	1534	249	27.4	24
11:30	316	357	477	438	327	.7	34.8	31.5	1527	247	27.0	26
11:45	316	358	477	438	328	1.3	43.2	28.5	1518	246	26.9	29
12:00	318	355	478	438	327	.5	40.9	26.7	1520	250	27.1	31
12:15	317	357	478	438	328	.6	35.8	44.7	1524	248	27.3	33
12:30	318	356	479	439	328	.5	40.2	31.5	1523	251	27.3	35
12:45	315	360	475	437	328	1.7	30.3	38.3	1525	242	26.5	38
1:00	315	362	475	439	328	1.8	50.5	74.2	1515	248	26.4	40
1:15	318	358	479	436	330	.8	49.5	34.4	1517	247	27.1	42
1:30	316	363	474	441	329	1.8	42.9	33.3	1532	252	26.6	44
1:45	317	363	475	439	331	1.8	45.3	29.7	1519	245	26.4	46
2:00	317	361	476	437	331	1.6	47.5	35.3	1517	244	26.6	49
2:15	317	365	471	443	328	.4	44.0	38.3	1516	259	26.5	51
2:30	317	363	476	438	333	1.8	43.6	40.1	1516	247	26.5	53
2:45	317	364	472	441	331	1.3	58.0	47.5	1514	253	27.1	56
3:00	317	362	473	438	333	1.7	50.2	48.3	1515	245	26.5	58
3:15	317	364	472	439	333	1.8	46.0	45.0	1518	248	26.5	60
3:30	317	365	469	444	331	.5	46.3	42.1	1523	259	26.3	62
3:45	318	365	468	445	331	1.0	38.2	28.3	1525	260	26.4	64
4:00	318	365	468	445	332	.3	37.5	32.0	1520	258	26.2	66
4:15	320	361	467	448	329	1.0	37.2	31.9	1522	247	26.7	68
4:30	319	359	475	438	337	1.9	42.2	43.9	1519	252	26.8	70
4:45	319	363	467	447	330	1.1	50.8	22.4	1523	248	26.6	73
5:00	320	360	468	448	330	1.4	37.7	20.1	1521	245	26.6	75
5:15	321	360	468	449	331	1.3	35.4	30.2	1519	245	26.4	77
5:30	319	365	468	447	334	.9	41.9	35.4	1520	259	26.2	79
5:45	319	363	472	440	338	1.7	54.3	28.9	1521	245	26.2	81
6:00	318	361	465	446	332	.9	32.3	27.4	1516	248	26.7	84
6:15	318	356	466	443	330	.9	27.8	29.6	1522	240	26.4	86

KC.

2/21/96



HAYWARD LINE I FEBRUARY 22nd 1996

PRESS VENT RTO STACK - MDI

DATA TIM START= 08:00 END= 12:30 HOURS= 4.50

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices
per unit over the testing period.

1/2"

per/peice 54.21

per/ 8' x 16' 216.85

PLANT PRODUCTION RATE

4.50 =hours during testing

71 =pressloads

852 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

184,758 =lbs of finished product (boards produced x weight of finished board)

41,057 =lbs of finished product per hour (lbs of finshed product / hours)

20.53 =tons of finished product per hour (lbs of finshed product per hour / 2000 lb)

RESIN USAGE TAKEN FROM MICRO - MOTIONS

TIME	MDI	PHENOL	WAX	
8:00-9:00	420	910	292	
9:00-10:00	421	907	296	
10:00-11:00	421	908	290	
11:00-12:00	422	908	294	
12:00-12:30	256	544	177	** HALF HOUR TOTALS
AVERAGE	421.00	908.25	293.00	

41,057 =average lbs. per hour finished product produced during testing

421.00 =average lbs. per hour of MDI resin used during testing

1.03% = MDI resin used as % of finished product

908.25 =average lbs. per hour of phenolic resin (100% solids) used during testing

2.21% =Phenolic resin used as % of finished product

293.00 =average lbs. per hour of wax (100% solids) used during testing

0.71% =wax used as % of finished product

HAYWARD LINE I FEBRUARY 22nd 1996
PRESS VENT RTO STACK - FORMALDEHYDE
DATA TIM START= 13:30 END= 17:15 HOURS= 3.75

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices
per unit over the testing period.

1/2"

per/peice 54.21

per/ 8' x 16' 216.85

PLANT PRODUCTION RATE

3.75 =hours during testing

56 =pressloads

672 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

145,725 =lbs of finished product (boards produced x weight of finished board)

38,860 =lbs of finished product per hour (lbs of finshed product / hours)

19.43 =tons of finished product per hour (lbs of finshed product per hour / 2000 lb)

RESIN USAGE TAKEN FROM MICRO - MOTIONS

TIME	MDI	PHENOL	WAX
1:00-2:00	416	899	278
2:00-3:00	421	906	281
3:00-4:00	421	906	282
4:00-5:00	419	905	281
AVERAGE	419.25	904.00	280.50

38,860 =average lbs. per hour finished product produced during testing

419.25 =average lbs. per hour of MDI resin used during testing

1.08% = MDI resin used as % of finished product

904.00 =average lbs. per hour of phenolic resin (100% solids) used during testing

2.33% =Phenolic resin used as % of finished product

280.50 =average lbs. per hour of wax (100% solids) used during testing

0.72% =wax used as % of finished product

2-22-96

Micro-Motions
Solids Pounds

100% MDI Core -	420
57% PF Surf. -	1597
58% Wax Core -	192
58% Wax Surf. -	312

100%
Solids
420
910
292

Tanks

Solids	Before	After	Pounds	100% Solids
100% Core MDI -	213.5	212.375	676	676
2 ÷ 61% Surf PF -	196	196		
2 ÷ 57% Day Tank PF -	854	570	2932	836
2 ÷ 57% Mix Tank PF -	8	2		
2 ÷ 58% Wax -	78"	75.5	955	27

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

2-22-96

Solids	Micro-Motions	Pounds	100% Solids
100% MDI Core -	421		421
57% PF Surf. -	1591		907
58% Wax Core -	193		296
58% Wax Surf. -	317		

Tanks

Solids	Before	After	Pounds	100% Solids
100% Core MDI -	212.375	211.625	450	45
2 ÷ 61% Surf PF -	196	184.75	-8185	
2 ÷ 57% Day Tank PF -	570	856	2675	76
2 ÷ 57% Mix Tank PF -	2	257	+5510	
2 ÷ 58% Wax -	75.5	72.75	1050	305

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

Press Test

10:00 AM - 11:00 AM

2-22-96

Solids

Micro-Motions

Pounds

100% MDI Core - 421
57% PF Surf. - 1593
58% Wax Core - 192
58% Wax Surf. - 308

100%
Solids

421

908

290

Tanks

Solids

Before

After

Pounds

100%

Solids

100% Core MDI -

211.625

211.25

225

225

2 ÷ 61% Surf PF -

184.75

184.75

2 ÷ 57% Day Tank PF -

856

828

2831

807

2 ÷ 57% Mix Tank PF -

257

5

2 ÷ 58% Wax -

72.75

70

1050

305

Factors per inch

MDI Tank - 600.466

PF Tank - 727.583

Wax Tank - 381.86

Factors per gallon

Day Tank - 10.11

Mix Tank - 10.11

2-22-96

Micro-Motions

100%

Solids

Pounds

Solids

100% MDI Core - 422

422

57% PF Surf. - 1593

908

58% Wax Core - 194

294

58% Wax Surf. - 313

Tanks

Solids

Before

After

Pounds

100% Solids

100% Core MDI -

211.25

210.625

375

37

2 ÷ 61% Surf PF -

184.75

184.75

2 ÷ 57% Day Tank PF -

828

548

2831

806

2 ÷ 57% Mix Tank PF -

5

5

2 ÷ 58% Wax -

70

66.5

1337

388

Factors per inch

MDI Tank - 600.466

PF Tank - 727.583

Wax Tank - 381.86

Factors per gallon

Day Tank - 10.11

Mix Tank - 10.11

Press Test #

12:00 PM - 1:00 PM

2-22-96

Down 24 Minutes

Solids	Micro-Motions	Pounds	100% Solids
100% MDI Core -		256	256
57% PF Surf. -		954	544
58% Wax Core -		118	-177
58% Wax Surf. -		188	

Tanks

Solids	Before	After	Pounds	100% Solids
100% Core MDI -	210.625	210.25	225	225
2 ÷ 61% Surf PF -	184.75	173.5	-8185	
2 ÷ 57% Day Tank PF -	548	682	2776	791
2 ÷ 57% Mix Tank PF -	5	406	+5409	
2 ÷ 58% Wax -	66.5	64.5	764	221

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

2-22-96

Micro-Motions

Solids

Pounds

100%
Solids

100%	MDI Core	-	416	416
57%	PF Surf.	-	1578	899
58%	Wax Core	-	182	278-
58%	Wax Surf.	-	298	

Tanks

Solids

Before

After

Pounds

100%
Solid

100%	Core MDI	-	210.25	209.625	375	375
2 ÷ 61%	Surf PF	-	173.5	173.5		
7 ÷ 57%	Day Tank PF	-	682	892	1890	538
2 ÷ 57%	Mix Tank PF	-	406	9		
2 ÷ 58%	Wax	-	64.5	63	573	166

Factors per inch

MDI Tank - 600.466

PF Tank - 727.583

Wax Tank - 381.86

Factors per gallon

Day Tank - 10.11

Mix Tank - 10.11

2-22-96

		Micro-Motions	
Solids		Pounds	100% Solids
100%	MDI Core -	421	421
57%	PF Surf. -	1590	906
58%	Wax Core -	186	281
58%	Wax Surf. -	299	

Tanks

		Before	After	Pounds	100% Solids
100%	Core MDI -	209.625	208.938	413	413
2 ÷	61% Surf PF -	173.5	173.5		
2 ÷	57% Day Tank PF -	892	625	2720	775
2 ÷	57% Mix Tank PF -	9	7		
2 ÷	58% Wax -	63	60.5	955	277

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

2-22-96

	Micro-Motions		100%
Solids	Pounds		Solids
100% MDI Core -	421		421
57% PF Surf. -	1590		906
58% Wax Core -	187		
58% Wax Surf. -	300		282

Tanks

Solids		Tanks		Pounds	100% Solids
		Before	After		
100% Core MDI -		208.938	208.438	300	300
2 ÷ 61% Surf PF -		173.5	162.188	-8230	
2 ÷ 57% Day Tank PF -		625	478	3721	1060
2 ÷ 57% Mix Tank PF -		7	700	+4509	
2 ÷ 58% Wax -		60.5	58	955	276

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

Press Test #

4:00pm - 5:00pm

2-22-96

Solids	Micro-Motions	100% Solids
	Pounds	
100% MDI Core -	419	419
57% PF Surf. -	1588	905
58% Wax Core -	184	281
58% Wax Surf. -	300	

Tanks

Solids	Before	After	Pounds	100% Solids
100% Core MDI -	208.438	207.938	300	300
2 ÷ 61% Surf PF -	162.188	162.188		
2 ÷ 57% Day Tank PF -	478	898	2669	761
2 ÷ 57% Mix Tank PF -	700	16		
2 ÷ 58% Wax -	58	55.5	955	277

Factors per inch


MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon


Day Tank -	10.11
Mix Tank -	10.11

7/

PRESS CHART
2/22/96
0700-1500




LINE 1
PRESS CHART
2/22/96
1500-1900



RECORD EVERY 15 MIN.												
HAYWARD AIR TESTING WORKSHEET												
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage
8:00	316	350	470	431	335	0.5	41.6	23.6	1521	247	27.8	0
8:15	317	351	463	439	329	0.8	33.0	18.3	1518	240	26.4	2
8:30	314	360	463	437	333	1.4	28.6	25.2	1520	250	26.5	4
8:45	318	350	468	436	332	0.7	28.8	20.9	1528	244	26.8	6
9:00	315	357	468	434	335	1.3	39.6	24.0	1527	244	26.8	8
9:15	314	361	464	440	332	0.8	40.2	38.6	1515	250	26.9	10
9:30	316	361	463	442	332	0.3	46.1	49.5	1516	256	26.7	13
9:45	317	356	463	445	328	1.2	35.5	17.4	1517	249	26.6	15
10:00	318	350	471	436	333	0.4	42.6	33.0	1518	247	27.2	18
10:15	318	354	465	444	328	0.6	30.3	15.1	1529	240	26.6	20
10:30	317	356	464	446	327	1.3	28.2	46.6	1519	248	26.8	22
10:45	317	354	472	435	334	0.4	36.0	22.9	1524	250	27.5	24
11:00	318	356	466	446	327	1.1	24.7	27.2	1521	243	26.7	26
11:15	315	363	469	441	337	1.6	49.8	31.9	1520	249	26.4	28
11:30	317	360	475	437	334	0.9	33.0	28.6	1531	249	27.2	31
11:45	316	364	470	444	331	1.2	38.2	32.9	1522	255	26.7	33
12:00	320	357	472	445	328	1.3	27.9	28.2	1525	243	26.4	34
12:15	320	357	478	439	332	0.8	35.8	30.9	1527	252	27.1	37
12:30	317	366	470	447	327	1.0	29.5	40.6	1528	259	26.5	39
12:45	318	360	480	438	332	0.4	49.8	26.7	1522	253	27.6	40
1:00	316	362	477	437	329	1.7	35.0	31.1	1529	244	27.0	43
1:15	315	367	474	442	327	1.2	38.5	71.7	1519	252	26.8	45
1:30	319	360	476	446	322	0.9	27.6	20.7	1534	244	27.0	47
1:45	319	359	482	440	326	0.9	27.4	10.5	1538	247	27.0	50
2:00	316	370	476	444	325	0.2	30.6	37.2	1525	259	26.6	52
2:15	320	361	479	443	324	1.2	34.6	18.9	1523	244	26.5	54
2:30	316	371	479	442	328	1.4	47.1	46.3	1519	250	26.6	56
2:45	317	369	489	440	329	1.8	52.8	36.2	1517	245	26.6	58
3:00	320	361	481	443	325	1.4	26.8	18.1	1514	248	27.1	61
3:15	318	370	477	446	324	0.9	36.3	27.7	1519	260	26.1	63
3:30	320	362	492	447	323	1.2	35.0	17.4	1526	244	26.6	65
3:45	320	361	485	439	325	0.7	20.1	17.6	1523	249	27.1	67
4:00	320	361	486	439	325	0.2	33.9	18.4	1522	249	27.2	69
4:15	319	366	480	445	321	1.1	28.2	29.9	1519	247	26.9	72
4:30	317	368	486	435	329	1.2	45.3	41.1	1518	246	26.9	73
4:45	316	371	481	440	326	1.7	40.5	30.8	1521	250	26.8	76
5:00	318	364	487	435	327	0.4	38.0	30.2	1527	252	27.6	78
5:10	320	361	486	437	325	0.3	33.9	20.1	1527	248	27.1	79

Line I Dyer RTO
2/22/96



AYWARD LINE I FEBRUARY 20,21 1996

HERMAL OIL STACK - POM

ATA TIME	START=	15:45	END=	19:15	HOURS=	3.50
ATA TIME	START=	08:30	END=	16:30	HOURS=	8.00
					TOTAL=	11.5

OAF 'EIGHTS - LBS

verage weights determined by taking bundle weights divided by peices
er unit over the testing period.

1/2"
er/peice 55.08
er/ 8' x 16' 220.32

'LANT PRODUCTION RATE

11.50 =hours during testing
177 =pressloads
2124 =no. of 8'x16' boards produced (pressloads x 8 boards per load)
467,960 =lbs of finished product (boards produced x weight of finished board)
40,692 =lbs of finished product per hour (lbs of finshed product / hours)
20.35 =tons of finished product per hour (lbs of finshed product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY BARK INPUT

K1

13.89 =K1 fuel calibration in pounds per count
1,313 =K1 counts during testing hours
18,238 =K1 lbs of wet fuel burned during testing
11.50 =hours during testing
39.52% =average moisture content of fuel
11,030 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))
959.10 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
0.48 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
9,000 =estimated BTU content per pound of dry fuel,
8.63 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

K2

.49 =K2 fuel calibration in pounds per count
1,859 =K2 counts during testing hours
25,822 =K2 lbs of wet fuel burned during testing
11.50 =hours during testing
39.52% =average moisture content of fuel
15,616 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))
1,357.94 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
0.68 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
9,000 =estimated BTU content per pound of dry fuel,
12.22 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

FUEL BURNING RATE ESTIMATED TEMPERATURE DIFFERENTIAL

K1

447.3 =average incoming oil temperature on degrees f.
473.5 =average outgoing oil temperature on degrees f.
60 =temperature differential at 100% capacity in degrees f
26.2 =actual temperature differential
19.4 =maximum mmbtu input at 100% capacity
8.47 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input
9,000 =estimated BTU content per pound of dry fuel,
0.47 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

K2

420.1 =average incoming oil temperature on degrees f.
472.1 =average outgoing oil temperature on degrees f.
60 =temperature differential at 100% capacity in degrees f
.19 =actual temperature differential
19.4 =maximum mmbtu input at 100% capacity
16.7907 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input
9,000 =estimated BTU content per pound of dry fuel,
0.93 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

PRESS REPORT - LINE 6 2

OPERATOR *Heister*

SHIFT:

DATE: 2-20-96

CREW: C

THICKNESS

PRESS LDS:

OVERALL
TIMER:

DECOMPRESSION
TIME:

PRESS
TEMP:

TOTAL
REJECTS:

LOG COUNT:

LINE SPEED	THKNS.	FROM	TO
3S	$2\frac{3}{4}$ H	7:00	712
52	$\frac{1}{2}$	712	829
SS	"	829	223
4S	"	223	300
SS	"	3:00	300

F.C.O.S. HYD. RADIATOR:

PRESS BLOWN DOWN:

SPINNER HEADS FLUSHED:

SURFACE BLENDER HOSED:

FORMER HYD RADIATOR:

[illegible]


DOWNTIME CODE:

M - MECHANICAL


E - ELECTRICAL

O - OPERATOR

LINE 1
PRESS CHART
2/20/96
0700-1500



LINE 1
PRESS CHAT
15:00-19:



LI Driver Rto 2-20-96


RECORD EVERY 15 MIN.

HAYWARD AIR TESTING WORKSHEET

Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Droo	Usage
9:00	315	356	469	435	335	1.7	43.6	50.0	1515	254	26.1	0
9:15	319	351	468	442	329	1.5	25.0	25.8	1526	245	26.7	2
9:30	319	350	469	443	328	1.5	26.0	26.6	1531	247	26.8	4
9:45	317	349	473	441	329	1.1	50.8	28.8	1521	250	27.3	7
10:00	316	350	472	444	325	1.3	29.8	32.6	1514	241	26.7	9
10:15	315	351	473	446	324	1.2	27.8	31.7	1514	240	26.7	11
10:30	314	351	473	447	323	1.0	27.0	29.4	1514	239	26.2	14
10:45	314	350	476	444	325	1.2	24.0	31.8	1516	241	26.6	16
11:00	315	352	474	448	321	.6	36.1	32.3	1512	240	26.3	18
11:15	312	353	474	449	321	1.2	35.0	28.8	1513	242	26.6	20
11:30	312	354	476	449	320	.9	36.0	25.8	1513	241	26.3	23
11:45	311	355	475	451	320	1.3	34.3	27.7	1512	242	26.6	25
12:00	311	357	475	451	319	1.3	35.7	31.0	1513	246	26.7	27
12:15	310	356	475	451	320	1.5	36.1	22.7	1512	243	26.5	29
12:30	309	356	472	449	317	1.2	36.8	30.7	1512	240	26.8	32
12:45	308	357	473	448	317	1.1	25.1	29.6	1519	246	26.7	34
1:00	309	357	474	449	317	1.1	62.6	29.8	1512	245	26.8	37
1:15												
1:30	309	359	475	449	318	.9	36.8	34.9	1511	256	26.2	41
1:45	310	360	475	451	317	.9	37.2	26.8	1509	252	26.2	43
2:00	309	360	476	450	317	1.0	36.7	20.6	1508	253	26.3	46
2:15	310	358	477	449	318	1.2	35.0	28.2	1514	246	26.8	48
2:30	310	360	476	449	318	.9	36.3	33.6	1509	257	26.2	50
2:45	310	361	477	449	319	1.2	34.4	24.9	1513	252	26.1	52
3:00	310	362	476	449	319	1.0	34.2	24.0	1509	251	26.2	55
3:15	311	361	476	449	319	1.1	33.9	28.3	1509	246	26.6	57
3:30	311	361	475	449	319	1.1	35.8	27.7	1509	252	26.3	59
3:45	312	357	476	447	319	1.2	34.0	22.6	1511	242	26.5	62
4:00	313	355	478	445	320	.7	35.0	28.0	1509	240	26.2	64
4:15	314	356	476	447	321	.8	38.5	31.3	1510	241	26.1	66
4:30	314	355	474	446	320	.9	35.3	30.7	1509	240	26.5	68
4:45	315	354	474	446	322	1.0	36.8	36.1	1512	240	26.2	71
5:00	316	353	476	444	324	1.5	37.7	27.3	1510	242	26.5	73
5:15	317	353	477	442	326	1.2	56.3	31.8	1506	250	27.2	75
5:30	317	352	475	442	326	1.2	43.7	25.9	1509	244	26.8	77
5:45	318	352	476	440	328	.8	50.2	32.1	1510	250	27.2	80
6:00	317	351	476	439	328	.6	46.8	33.0	1511	250	27.2	82
6:15	317	352	476	439	329	.8	51.2	34.6	1511	250	27.4	84
6:30	317	352	476	438	330	.5	50.6	30.0	1511	251	27.4	86
6:45	317	353	476	438	331	.7	53.7	31.9	1509	250	27.5	89
7:00	317	352	475	437	331	.6	50.9	34.7	1511	250	27.4	91

KCF

Line I Dry RTO
2/20/96



DAYWARD LINE I FEBRUARY 21, 1996

THERMAL OIL STACK - PHENOL

DATA TIME START= 09:30 END= 14:45 HOURS= 5.25

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices
per unit over the testing period.

1/2"

per/peice 54.63

per/ 8' x 16' 218.51

PLANT PRODUCTION RATE

5.25 =hours during testing

83 =pressloads

996 =no. of 8'x16' boards produced (pressloads x 8 boards per load)

217,634 =lbs of finished product (boards produced x weight of finished board)

41,454 =lbs of finished product per hour (lbs of finished product / hours)

20.73 =tons of finished product per hour (lbs of finished product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY BARK INPUT

K1

13.89 =K1 fuel calibration in pounds per count

561 =K1 counts during testing hours

7,792 =K1 lbs of wet fuel burned during testing

5.25 =hours during testing

38.26% =average moisture content of fuel

4,811 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))

916.37 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

0.46 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

9,000 =estimated BTU content per pound of dry fuel,

8.25 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

K2

39 =K2 fuel calibration in pounds per count

650 =K2 counts during testing hours

11,807 =K2 lbs of wet fuel burned during testing

5.25 =hours during testing

38.26% =average moisture content of fuel

7,289 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))

1,388.44 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

0.69 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

9,000 =estimated BTU content per pound of dry fuel,

12.50 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

FUEL BURNING RATE ESTIMATED TEMPERATURE DIFFERENTIAL

K1

446.64 =average incoming oil temperature on degrees f.

471.31 =average outgoing oil temperature on degrees f.

60 =temperature differential at 100% capacity in degrees f

24.7 =actual temperature differential

19.4 =maximum mmbtu input at 100% capacity

7.98 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input

9,000 =estimated BTU content per pound of dry fuel,

0.44 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

K2

419.85 =average incoming oil temperature on degrees f.

470.88 =average outgoing oil temperature on degrees f.

60 =temperature differential at 100% capacity in degrees f

1.0 =actual temperature differential

19.4 =maximum mmbtu input at 100% capacity

16.50141 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input

9,000 =estimated BTU content per pound of dry fuel,

0.92 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

HAYWARD LINE I FEBRUARY 21, 1996

THERMAL OIL STACK - PM

DATA TIME START= 15:30 END= 20:15 HOURS= 4.75

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices per unit over the testing period.

1/2"
per/peice 54.63
per/ 8' x 16' 218.52

PLANT PRODUCTION RATE

4.75 =hours during testing
73 =pressloads
876 =no. of 8'x16' boards produced (pressloads x 8 boards per load)
191,424 =lbs of finished product (boards produced x weight of finished board)
40,300 =lbs of finished product per hour (lbs of finished product / hours)
20.15 =tons of finished product per hour (lbs of finished product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY BARK INPUT

K1

13.89 =K1 fuel calibration in pounds per count
518 =K1 counts during testing hours
7,195 =K1 lbs of wet fuel burned during testing
4.75 =hours during testing
39.45% =average moisture content of fuel
4,357 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))
917.18 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
0.46 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
9,000 =estimated BTU content per pound of dry fuel,
8.25 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

K2

13.89 =K2 fuel calibration in pounds per count
691 =K2 counts during testing hours
9,598 =K2 lbs of wet fuel burned during testing
4.75 =hours during testing
39.45% =average moisture content of fuel
5,812 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))
1,223.49 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
0.61 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
9,000 =estimated BTU content per pound of dry fuel,
11.01 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

FUEL BURNING RATE ESTIMATED TEMPERATURE DIFFERENTIAL

K1

451.00 =average incoming oil temperature on degrees f.
474.80 =average outgoing oil temperature on degrees f.
60 =temperature differential at 100% capacity in degrees f
23.8 =actual temperature differential
19.4 =maximum mmbtu input at 100% capacity
7.70 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input
9,000 =estimated BTU content per pound of dry fuel,
0.43 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

K2

423.80 =average incoming oil temperature on degrees f.
469.50 =average outgoing oil temperature on degrees f.
60 =temperature differential at 100% capacity in degrees f
45.7 =actual temperature differential
19.4 =maximum mmbtu input at 100% capacity
14.77633 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input
9,000 =estimated BTU content per pound of dry fuel,
0.82 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

PRESS REPORT - LINE

PRESS REPORT - LINE 1) 2

OPERATOR

SHIFT:

DATE:

2/21/96

CREW:

THICKNESS

OVERALL
TIMER:

PRESS
TEMP:

PRESS LDS:

DECOMPRESSION
TIME:

TOTAL
REJECTS:

LOG COUNT:

LINE SPEED	THKNS.	FROM	TO
53	7/16	7:00	
53	1/2	7:20	
55	11	8:20	
45	11	1:20	
55	11	1:45	
45	11	4:30	
55	11	5:50	

F.C.O.S. HYD. RADIATOR:

TIME

PRESS BLOWN DOWN:

SPINNER HEADS FLUSHED:

TIME

SURFACE BLENDER HOSED:

TIME

FORMER HYD RADIATOR:

TIME

[illegible]

DOWNTIME CODE:

M - MECHANICAL

E - ELECTRICAL

O - OPERATOR

PRESS REPORT - LINE 1 2
PERATOR VISER

SHIFT:

CREW:

THICKNESS

PRESS LDS:

DECOMPRESSION
TIME:

TOTAL
REJECTS:

LOG COUNT:

F.C.O.S. HYD. RADIATOR:

PRESS BLOWN DOWN:

SPINNER HEADS FLUSHED:

SURFACE BLENDER HOSED:

FORMER HYD RADIATOR:

LINE SPEED	THKNS.	FROM	TO
55	1/2	750	
46	17/32 SE	855	
52	15/32	100	
48	25/32	500	
45	15/32	640	

[illegible]


DOWNTIME CODE:

M - MECHANICAL


E - ELECTRICAL

O - OPERATOR

LINE 1 PRESS
CHART
2/21/96
0700-1500



LINE I
PRESS CHART
2/21/94
1500-2030




LI Dryer RTO 2-21-96

HAYWARD AIR TESTING WORKSHEET													
RECORD EVERY 15 MIN.													
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas	
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage	
8:30	317	352	465	439	320	.7	33.8	27.4	1513	238	26.8	0	
8:45	316	357	462	442	321	1.3	34.0	22.8	1508	252	26.4	2	
9:00	314	360	464	439	324	.4	43.0	42.1	1502	256	26.4	4	
9:15	314	360	467	437	326	1.4	40.6	50.5	1511	252	26.6	6	
9:30	314	360	467	438	326	1.4	40.7	51.5	1511	249	26.7	8	
9:45	314	361	467	439	326	1.7	40.6	45.2	1512	248	26.7	11	
10:00	314	360	469	437	327	1.9	58.5	39.7	1515	249	26.7	13	
10:15	315	359	471	436	327	1.7	39.7	32.8	1517	243	26.2	15	
10:30	315	360	472	438	326	1.8	28.5	44.3	1522	243	26.4	18	
10:45	316	356	474	436	327	1.0	35.5	27.4	1520	244	27.0	20	
11:00	317	353	476	437	327	.5	33.4	32.1	1525	249	27.4	22	
11:15	317	353	477	438	326	.5	31.1	24.7	1534	249	27.4	24	
11:30	316	357	477	438	327	.7	34.8	31.5	1527	247	27.0	26	
11:45	316	358	477	438	328	1.3	43.2	28.5	1515	246	26.9	29	
12:00	318	355	478	438	327	.5	40.9	26.7	1520	250	27.1	31	
12:15	317	357	478	438	328	.6	35.8	44.7	1524	248	27.3	33	
12:30	318	356	479	439	328	.5	40.2	31.5	1523	251	27.3	35	
12:45	315	360	475	437	328	1.7	30.3	38.3	1525	242	26.5	38	
1:00	315	362	475	439	328	1.8	50.5	74.2	1515	248	26.4	40	
1:15	318	358	479	436	330	.8	49.5	34.4	1517	247	27.1	42	
1:30	316	363	474	441	329	1.8	42.9	33.3	1532	252	26.6	44	
1:45	317	363	475	439	331	1.8	45.3	29.7	1519	245	26.4	46	
2:00	317	361	476	437	331	1.6	47.5	35.3	1517	244	26.6	49	
2:15	317	365	471	443	328	.4	44.0	38.3	1516	259	26.5	51	
2:30	317	363	476	438	333	1.8	43.6	40.1	1516	247	26.5	53	
2:45	317	364	472	441	331	1.3	58.0	47.5	1514	253	27.1	56	
3:00	317	362	473	438	333	1.7	50.2	48.3	1515	245	26.5	58	
3:15	317	364	472	439	333	1.8	46.0	45.0	1518	248	26.5	60	
3:30	317	365	469	444	331	.5	46.3	42.1	1523	259	26.3	62	
3:45	318	365	468	445	331	1.0	38.2	28.3	1525	260	26.4	64	
4:00	318	365	468	445	332	.3	37.5	32.0	1520	258	26.2	66	
4:15	320	361	467	448	329	1.0	33.2	31.9	1522	247	26.7	68	
4:30	319	359	475	438	337	1.9	42.2	43.9	1519	252	26.8	70	
4:45	319	363	467	447	330	1.1	50.8	22.4	1523	248	26.6	73	
5:00	320	360	468	448	330	1.4	37.7	20.1	1521	245	26.6	75	
5:15	321	360	468	449	331	1.3	35.4	30.2	1519	245	26.4	77	
5:30	319	365	468	447	334	.9	41.9	35.4	1520	259	26.2	79	
5:45	319	363	472	440	338	1.7	54.3	28.9	1521	245	26.2	81	
6:00	318	361	465	446	332	.9	32.3	27.4	1516	248	26.7	84	
6:15	318	356	466	443	330	.9	27.8	29.6	1522	240	26.4	86	

KCF

[illegible]

2/21/96



HAYWARD LINE I FEBRUARY 22, 1996
THERMAL OIL STACK NOX,CO,CO2,02,FORMALDEHYDE,BENZENE
DATA TIME START= 09:00 END= 14:15 HOURS= 5.25

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices
per unit over the testing period.

1/2"
per/peice 54.21
per/ 8' x 16' 216.85

PLANT PRODUCTION RATE.

5.25 =hours during testing
82 =pressloads
984 =no. of 8'x16' boards produced (pressloads x 8 boards per load)
213,382 =lbs of finished product (boards produced x weight of finished board)
40,644 =lbs of finished product per hour (lbs of finished product / hours)
20.32 =tons of finished product per hour (lbs of finished product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY BARK INPUT

K1

13.89 =K1 fuel calibration in pounds per count
565 =K1 counts during testing hours
7,848 =K1 lbs of wet fuel burned during testing
5.25 =hours during testing
40.10% =average moisture content of fuel
4,701 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))
895.40 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
0.45 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
9,000 =estimated BTU content per pound of dry fuel,
8.06 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

K2

13.89 =K2 fuel calibration in pounds per count
808 =K2 counts during testing hours
11,223 =K2 lbs of wet fuel burned during testing
5.25 =hours during testing
40.10% =average moisture content of fuel
6,723 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))
1,280.50 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
0.64 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
9,000 =estimated BTU content per pound of dry fuel,
11.52 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

FUEL BURNING RATE ESTIMATED TEMPERATURE DIFFERENTIAL

K1

445.79 =average incoming oil temperature on degrees f.
473.21 =average outgoing oil temperature on degrees f.
60 =temperature differential at 100% capacity in degrees f
27.4 =actual temperature differential
19.4 =maximum mmbtu input at 100% capacity
8.87 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input
9,000 =estimated BTU content per pound of dry fuel,
0.49 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

K2

420.06 =average incoming oil temperature on degrees f.
473.53 =average outgoing oil temperature on degrees f.
60 =temperature differential at 100% capacity in degrees f
53.5 =actual temperature differential
19.4 =maximum mmbtu input at 100% capacity
17.29 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input
9,000 =estimated BTU content per pound of dry fuel,
0.96 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

PRESS REPORT - LINE 1 2

SHIFT:

DATE: 2-22-96

CREW:

THICKNESS

PRESS LDS:

OVERALL
TIMER:

DECOMPRESSION
TIME:

PRESS
TEMP:

TOTAL
REJECTS:

LOG COUNT:

LINE SPEED	THKNS.	FROM	TO
45	12/32	700	
45	17	715	
55	11	745	
52	11	5:55	

F.C.O.S. HYD. RADIATOR:

PRESS BLOWN DOWN:

SPINNER HEADS FLUSHED:

SURFACE BLENDER HOSED:

FORMER HYD RADIATOR:

[illegible]


DOWNTIME CODE:

M - MECHANICAL


E - ELECTRICAL

O - OPERATOR

PRESS CHART
 2/22/96
 0700-1500




PRESS CHART
 2/22/96
 1500-1900



RECORD EVERY 15 MIN.					HAYWARD AIR TESTING WORKSHEET							
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas
	#1	#2	#3	#4	#5	Press.	#1	#2	Temp.	Temp.	Droo	Usage
8:00 AM	316	350	470	431	335	0.5	41.6	23.6	1521	249	27.8	0
8:15	317	351	463	439	329	0.8	33.0	18.3	1518	240	26.4	2
8:30	314	360	463	437	333	1.4	28.1	25.2	1520	250	26.5	4
8:45	318	350	468	436	332	0.7	28.8	20.9	1528	244	26.8	6
9:00	315	357	468	434	335	1.3	39.6	24.0	1529	240	26.8	8
9:15	314	361	464	440	332	0.8	40.2	38.6	1515	250	26.9	10
9:30	316	361	463	442	332	0.3	46.1	49.5	1516	256	26.7	13
9:45	317	356	463	445	328	1.2	35.5	17.4	1517	249	26.6	15
10:00	318	350	471	436	333	0.4	42.6	33.0	1518	247	27.2	18
10:15	318	350	465	444	328	0.6	30.3	15.1	1529	240	26.6	20
10:30	317	356	464	446	327	1.3	28.2	46.6	1519	248	26.8	22
10:45	317	351	472	435	334	0.4	36.0	22.9	1524	250	27.5	24
11:00	318	356	466	446	327	1.1	24.7	27.2	1521	243	26.7	26
11:15	315	363	469	441	332	1.6	49.8	37.9	1520	249	26.4	28
11:30	317	360	475	437	334	0.9	33.0	28.6	1531	249	27.2	31
11:45	316	364	470	444	331	1.2	38.2	32.9	1522	255	26.7	33
12:00	320	357	472	445	328	1.3	27.9	28.2	1525	243	26.4	34
12:15	320	357	478	439	332	0.8	35.8	30.9	1527	252	27.1	37
12:30	317	366	470	447	327	1.0	29.5	40.6	1528	259	26.5	39
12:45	318	360	480	438	332	0.4	49.8	26.7	1522	253	27.6	40
1:00	316	361	477	437	329	1.2	35.0	31.1	1529	244	27.0	43
1:15	315	367	474	442	327	1.2	38.5	41.7	1519	252	26.8	45
1:30	319	360	476	446	322	0.9	27.6	20.7	1534	244	27.0	47
1:45	319	359	482	440	326	0.9	27.4	10.5	1538	247	27.0	50
2:00	316	370	476	444	325	0.2	30.6	37.2	1525	259	26.6	52
2:15	320	361	479	443	324	1.2	34.6	18.9	1523	244	26.5	54
2:30	316	371	479	442	328	1.4	47.1	46.3	1519	250	26.6	56
2:45	317	369	489	440	329	1.8	52.8	36.2	1517	245	26.6	58
3:00	320	361	481	443	325	1.4	26.8	18.1	1524	248	27.1	61
3:15	318	370	477	446	324	0.9	36.3	27.7	1519	260	26.1	63
3:30	320	362	492	447	323	1.2	25.0	17.4	1526	244	26.6	65
3:45	320	361	485	439	325	0.7	30.1	17.6	1523	248	27.1	67
4:00	320	361	486	439	325	0.2	33.9	18.4	1522	249	27.2	69
4:15	319	366	480	445	321	1.1	28.2	29.9	1519	247	26.9	72
4:30	317	368	486	435	329	1.2	45.3	41.1	1519	246	26.9	73
4:45	316	371	481	440	326	1.7	40.5	30.8	1521	250	26.8	76
5:00	318	364	487	435	327	0.4	38.0	30.2	1527	252	27.6	78
5:10	320	361	486	437	325	0.3	37.9	20.1	1527	248	27.1	79

Pm

Line I Dyer RTD
2/22/96



KONUS DATA READINGS EVERY 10 MINUTES PLANT Hayward L.P.

BY Pat M.

DATE 2/20/96 PAGE 1 OF 2

TIME	K1				K2				K3				K4				FUEL COUNT			ONCE/HR BARK MOISTURE	
	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W.G.	I.D. FAN W.G.	OIL IN TEMP	OIL OUT TEMP	OIL OUT TEMP	I.D. FAN W.G.	OIL IN TEMP	OIL OUT TEMP	OIL OUT TEMP	I.D. FAN W.G.	OIL IN TEMP	OIL OUT TEMP	OIL OUT TEMP	I.D. FAN W.G.	K1	K2	K3	K4	
9:00	240°	255°	0.9	1.0	228°	254°	254°	+1.0									363	359		900 AM	39.8
9:15	241°	260°	0.9	1.0	230°	265°	265°	+1.0									388	415		10:00 AM	40.6
9:30	244°	256°	0.8	0.8	230°	266°	266°	0.8									393	455		11:00 AM	40.2
9:45	238°	250°	0.9	0.9	224°	253°	253°	+1.6									436	493		12:00 PM	39.3
10:00	235°	250°	0.8	0.8	221°	256°	256°	+1.4									479	542		1:00 PM	39.2
10:15	240°	250°	0.9	0.9	225°	252°	252°	+1.6									518	569		2:00 PM	39.8
10:30	233°	244°	0.9	0.9	221°	256°	256°	+1.4									566	628		3:00 PM	39.5
10:45	230°	241°	0.9	0.9	215°	244°	244°	+1.4									612	693		4:00 PM	40.4
11:00	230°	245°	1.2	1.2	218°	251°	251°	+1.4									663	748		5:00 PM	41.6
11:15	236°	257°	1.2	1.2	222°	248°	248°	+1.1									694	796		6:00 PM	41.1
11:30	237°	251°	1.2	1.2	225°	263°	263°	+1.1									738	842			
11:45	235°	246°	1.4	1.4	222°	259°	259°	+1.6									784	887			
12:00	237°	253°	1.1	1.1	224°	253°	253°	+1.6									809	929			
12:15	243°	255°	1.2	1.2	230°	265°	265°	0.8									848	952			
12:30	240°	256°	1.1	1.1	228°	254°	254°	+1.1									896	987			
12:45	237°	251°	1.1	1.1	223°	251°	251°	0.8									936	1028			
1:00	234°	250°	1.2	1.2	220°	247°	247°	0.8									996	1078			
1:20	243°	262°	1.2	1.2	229°	256°	256°	+1.0									1012	1170			
1:45	245°	260°	1.2	1.2	222°	257°	257°	+1.0									1013	1206			
2:00	243°	255°	1.2	1.2	224°	253°	253°	0.8									1058	1230			
2:15	240°	249°	1.2	1.2	226°	256°	256°	0.6									1098	1261			
2:30	239°	247°	0.7	0.7	227°	251°	251°	0.4									1133	1302			
2:45	241°	250°	0.5	0.5	228°	254°	254°	0.4									1188	1314			
3:00	244°	254°	0.5	0.5	230°	255°	255°	1.2									1230	1360			
3:15	236°	245°	0.6	0.6	221°	247°	247°	1.0									1275	1402			
3:30	232°	239°	0.6	0.6	218°	246°	246°	1.2									1316	1451			
3:45	230°	240°	0.5	0.5	217°	244°	244°	1.0									1367	1501			
4:00	226°	246°	0.4	0.4	209°	250°	250°	0.9									1411	1560			
4:15	225°	249°	0.6	0.6	209°	242°	242°	1.0									1444	1606			
4:30	227°	250°	0.5	0.5	208°	244°	244°	0.8													

BY Paul M.

KONUS DATA READINGS EVERY 10 MINUTES

PLANT Hayward L.P.

TIME	K1				K2				K3				K4				FUEL COUNT				ONCE/HR	
	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W.G.	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W.G.	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W.G.	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W.G.	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W.G.	K1	K2	K3	K4	BARK	MOISTURE	
4:45	230°	250°	0.5	214°	250°	0.8										1478	1719					
5:00	233°	255°	0.5	216°	257°	0.4										1506	1721					
5:15	225°	245°	0.5	207°	235°	0.2										1537	1823					
5:30	234°	245°	0.6	215°	251°	0.4										1567	1876					
5:45	234°	252°	0.5	214°	248°	0.6										1597	1909					
6:00	233°	246°	0.6	218°	243°	0.6										1627	1942					
6:15	234°	249°	0.5	219°	242°	1.0										1656	1975					
6:30	233°	250°	0.6	222°	251°	0.8										1687	2014					
6:45	235°	257°	0.6	216°	248°	0.4										1718	2057					
7:00	237°	257°	0.5	224°	250°	0.6										1747	2086					
															</							

KONUS DATA READINGS EVERY 10 MINUTES

PLANT Hwy 4 road L.P.

BY Pat m.

DATE 2/21/96 PAGE 1 OF 2

TIME	K1				K2				K3				K4				FUEL COUNT		ONCE/HR BARK MOISTURE	
	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/G		OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/G		OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/G		OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/G		K1	K2	K3	K4
8:30	230	235	-0.5		214	232	-1.2										193	287		37.7%
8:45	232	237	-0.5		216	234	-1.0										219	323		38.4%
9:00	230	245	-0.5		219	246	-1.0										254	386		38.1%
9:15	230	245	-0.5		214	252	-0.2										279	415		36.4%
9:30	230	249	-0.5		217	242	-0.8										311	454		39.5%
9:45	230	245	-0.4		211	243	-0.8										339	488		38.9%
10:00	235	249	-0.6		219	250	-0.2										372	530		39.3%
10:15	230	242	-0.4		217	238	-1.0										377	561		40.2%
10:30	228	245	-0.6		214	237	-1.1										425	603		38.7%
10:45	228	242	-0.6		216	244	-0.6										451	648		
11:00	230	250	-0.6		216	247	-0.6										485	706		
11:15	230	245	-0.6		211	237	-0.6										512	744		
11:30	233	247	-0.4		218	245	-0.5										541	782		
11:45	230	250	-0.4		210	244	-0.2										570	820		
12:00	232	244	-0.6		219	246	-0.8										597	851		
12:15	235	246	-0.4		220	240	-0.8										622	887		
12:30	226	240	-0.6		212	231	-1.6										643	927		
12:45	228	240	-0.5		214	239	-0.8										672	965		
1:00	234	250	-0.5		221	250	-0.2										699	1011		
1:15	244	247	-0.6		219	240	-1.6										695	1044		
1:30	230	235	-0.4		216	249	-0.4										728	1091		
1:45	227	236	-0.6		213	231	-1.2										755	1130		
2:00	226	226	-0.6		213	238	-0.4										784	1174		
2:15	235	247	-0.5		219	251	-0.6										813	1210		
2:30	228	241	-0.5		215	245	-0.6										842	1259		
2:45	234	246	-0.5		219	238	-0.6										872	1304		
3:00	231	240	-0.6		216	243	-0.6										901	1347		
3:15	230	251	-0.5		217	247	-0.4										932	1392		
3:30	235	248	-0.6		221	257	-0.3										962	1433		
3:45	232	239	-0.5		216	241	-1.0										991	1466		

KONUS DATA READINGS EVERY 10 MINUTES

Plant Hayward LP

By Dat M

DATE 2/22/96 PAGE 1 OF

TIME	K1			K2			K3			K4			FUEL				ONCE/HR BARK MOISTURE
	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/G	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/G	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/G	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/G	K1 COUNT	K2 COUNT	K3 COUNT	K4 COUNT	
9:00	235	250	-0.5	221	255	-0.6							228	362			41.7%
9:15	226	240	-0.5	213	240	-1.0							261	409			38.8%
9:30	230	246	-0.4	217	238	-1.0							287	446			39.4%
9:45	236	247	-0.5	221	240	-0.8							317	486			38.5%
10:00	235	254	-0.5	217	250	-1.0							344	525			39.9%
10:15	223	241	-0.4	204	239	-0.6							380	570			
10:30	227	245	-0.5	217	248	-0.8							411	609			
10:45	234	250	-0.5	222	254	-0.6							436	647			
11:00	229	240	-0.5	215	250	-0.2							465	686			
11:15	228	244	-0.5	214	246	-0.2							495	726			
11:30	231	246	-0.4	217	243	-0.6							526	770			
11:45	228	245	-0.5	214	241	-0.6							554	809			
12:00	224	245	-0.4	214	251	-1.4							583	847			
12:15	226	244	-0.4	212	241	-0.6							609	885			
12:30	224	240	-0.5	207	233	-1.0							641	930			
12:45	238	249	-0.4	224	239	-1.2							671	971			
1:00	242	255	-0.5	225	253	-0.8							701	1006			
1:15	227	258	-0.5	214	244	-0.6							737	1046			
1:30	228	241	-0.5	212	239	-0.6							762	1098			
1:45	226	244	-0.5	214	244	-0.4							793	1128			
2:00	226	241	-0.4	211	238	-0								1170			

KONUS DATA READINGS EVERY 10 MINUTES

PLANT Hayward L.P.

BY Pat m.

DATE 2/21/96 PAGE 2 OF 2

TIME	K1			K2			K3			K4			FUEL				ONCE/HR BARK MOISTURE
	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/C	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/C	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/C	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/C	K1	K2	K3	K4	
4:00	231	244	-0.5	216	241	-0.8							1019	1495			
4:15	230	245	-0.6	216	242	-0.8							1049	1529			
4:30	227	240	-0.6	213	234	-1.4							1079	1561			
4:45	234	245	-0.6	219	240	-0.8							1107	1590			
5:00	234	249	-0.5	219	239	-0.7							1137	1639			
5:15	239	250	-0.5	224	248	-0.8							1165	1691			
5:30	236	247	-0.5	222	258	0							1192	1739			
5:45	235	254	-0.4	222	247	-0.8							1219	1763			
6:00	233	254	-0.4	216	229	-1.2							1247	1786			
6:15	232	254	-0.5	214	252	-0.6							1276	1830			
6:30	235	255	-0.5	219	244	-0.8							1305	1875			
6:45	235	249	-0.5	222	257	-0.1							1332	1895			
7:00	234	240	-0.6	214	235	-1.0							0	0			
7:15	233	240	-0.6	214	241	-0.8							35	49			
7:30	230	240	-0.6	216	249	-0.6							63	90			
7:45	230	240	-0.6	215	236	-0.6							98	136			
8:00	230	244	-0.5	215	242	-0.6							148	229			

Konus EFB Readings

Plant

readings every 10 minutes

Hayward 6P

date
by

2/22/96
Put in

Time	K1 and K2						K3 and K4					
	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.
9:00	12.5	0.4	30	4	2.2	4						
9:15	13.0	0.4	28.5	4	2.0	4						
9:30	13.0	0.4	28.5	4	2.0	4						
9:45	13.0	0.4	28.5	4	2.2	4						
10:00	13.0	0.4	30	4	2.2	4						
10:15	13.0	0.4	30	4	2.2	4						
10:30	13.0	0.4	30	4	2.2	4						
10:45	12.5	0.4	28.5	4	2.2	4						
11:00	13.0	0.4	30	4	2.2	4						
11:15	13.0	0.4	30	4	2.4	4.5						
11:30	12.0	0.4	30	4	2.4	4						
11:45	13.0	0.4	30	4	2.4	4						
12:00	12.0	0.4	30	4	1.2	4						
12:15	13.0	0.4	30	4	1.2	4						
12:30	13.0	0.4	30	4	1.0	4						
12:45	13.0	0.4	28.5	4	0.8	4						
1:00	13.0	0.4	28	4	1.0	4						
1:15	13.0	0.4	30	4	1.0	4.5						
1:30	12.0	0.4	30	4	1.0	4.5						
1:45	13.0	0.4	30	4	0.8	4						
2:00	13.0	0.4	30	4	1.0	5						

SHIFT: 1 OR II
 LINES 1 & 2

K-1 - K-2

 Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

7	8	9	10	11	12	1	2	3	4	5
7.5	7.5	7.5			10	10	11	11	1	5
20	20	20			20	20	21	22	27	20
22	22	22			25	25	25	26	28	28
1.8	1.8	1.8			2.0	2.0	2.2	2.4	2.2	3.0
2.4	2.4	2.4			2.0	2.0	2.0	2.1	2.2	2.0
467	455	458			453	459	455	447	467	477
395	391	391			363	372	375	373	370	381
OK	OK	OK			OK	OK	OK	OK	OK	OK
OK	OK	OK	6	8	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

K-3 - K-4

 Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
5.5	6	6	6	6	6	5	6	7	6	6	6
21	20	20	21	24	24	23	24	24	30	26	28
22	22	22	22	22	22	21	22	22	22	22	23
2.2	2.2	2.2	2.2	2.2	2.2	2.4	2.0	2.6	2.4	2.0	2.0
1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04
475	472	474	484	457	455	457	431	417	478	485	5
427	422	421	419	423	426	430	430	422	423	431	424
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	

Rock Usage/Shift: _____

 Baghouse
 Pressure
 Drop: (in.)

	7	8	9	10	11	12	1	2	3	4	5	6
L-I	4.0	4.0	4.0			4.0	4.0	4.0	4.0	4.0	4.0	4.2
L-II	3.8	3.7	3.8	4.0	3.9	4.0	4.0	4.0	3.8	4.0	4.4	3.8

Comments/Problems: _____

Changed A Insulator in Line I

*Condition Codes

- 1) Start up/shutdown
- 2) Konus down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Konus on oil
- 8) Maintenance

VOLUME PER SHIFT

LINE I	2
LINE II	2

SHIFT: I OR II
LINES 1 & 2

L-1-K-2

Bed Voltage (KV)
Bed Amperage (MA)
Ionizer Voltage (KV)
Ionizer Amperage (MA)
EFB Pressure Drop (In.)
Inlet Temperature
Outlet Temperature
Rock Flow
Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
10	5	7	7	10	10	12	13	7	15	15	15
2.5	1.0	1.0	1.0	1.0	1.0	1.04	1.03	2.4	0	0	0
30	22	22	22	22	22	22	22	22	18	20	20
3.8	1.8	1.8	1.8	1.8	1.8	1.6	1.6	3.0	2.0	2.0	2.0
2.0	1.05	1.05	1.05	0	0	0	0	0	0	0	0
4151	4149	447	457	457	460	444	4415	440	456	459	469
383	379	378	382	383	385	360	359	360	360	368	394
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

K-3-K-4

Bed Voltage (KV)
Bed Amperage (MA)
Ionizer Voltage (KV)
Ionizer Amperage (MA)
EFB Pressure Drop (In.)
Inlet Temperature
Outlet Temperature
Rock Flow
Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
8	5	5	5	5	5	5	5	5	5	5	5
3.0	2.4	2.4	2.4	2.4	2.4	2.4	2.6	2.0	2.0	2.0	2.0
20	20	20	20	20	20	20	20	20	20	20	20
2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
104	104	104	104	104	104	104	104	104	104	104	104
509	512	513	519	525	527	547	548	540	532	534	576
419	424	425	424	422	425	417	419	416	415	414	410
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

Baghouse
Pressure
Drop: (in.)

	7	8	9	10	11	12	1	2	3	4	5	6
L-I	3.5	4.0	4.0	4.0	4.0	4.0	3.5	3.0	4.0	4.0	4.0	3.0
L-II	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0

Comments/Problems: _____

*Condition Codes

- 1) Start up/shutdown
- 2) Konus down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Konus on oil
- 8) Maintenance

VOLUME PER SHIFT

LINE I	1 1/2
LINE II	1 1/2

Konus EFB Readings
Plant

Hayward LP.

date
by

2/21/96
Jason N.

readings every 10 minutes

time	K1 and K2						K3 and K4					
	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.
8:30	13.5	0.2	20	1.2	.8	.4						
8:45	13.5	0.4	28	3.6	1	.4						
9:00	13.5	0.2	30	4	1.4	.4						
9:15	13.0	0.1	30	4	1.6	.4						
9:30	13.0	0.2	29	4	1.9	.4						
9:45	13.0	0.2	29	4	1.9	.4						
10:00	13.0	0.2	30	4	2.2	.4						
10:15	13.0	0.2	29	4	2.9	.4						
10:30	13.0	0.2	30	4	3.4	.4						
10:45	12.5	0.3	31	4	3.3	.4						
11:00	13.0	0.3	30	4	2.9	.4						
11:15	13.0	0.3	29	4	3	.4						
11:30	13.0	0.3	29	4	2.8	.4						
11:45	13.5	0.3	30	4	2.8	.4						
12:00	13.0	0.3	30	4	3.4	.4						
12:15	13.0	0.3	29	4	3.2	.4						
12:30	12.5	0.3	28	4	2.8	.4						
12:45	13.0	0.3	30	4	1.8	.4						
1:00	12.0	0.3	30	4	1.4	.4						
1:15	12.5	0.3	28	4	1.6	.4						
1:30	12.5	0.3	30	4	1.6	.4						
1:45	12.5	0.3	29	4	1.7	.4						
2:00	12.5	0.3	29	4	1.5	.4						
2:15	12.5	0.3	30	4	1.8	.4						
2:30	12.5	0.3	29	4	1.4	.4						
2:45	12.5	0.3	30	4	1.4	4.5						
3:00	12.5	0.3	29	4	1.4	4.5						
3:15	12.5	0.3	30	4	1.2	4						
3:30	12.5	0.3	29	4	1.4	4.2						
3:45	12.5	0.3	29	4	1.3	5						

readings every 10 minutes'

date 2/21/96
by Jason n

time	K1 and K2					K3 and K4						
	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.
4:00	12.5	0.6	28.5	.4	1.	4						
4:15	12.5	0.3	30.0	.4	1	4						
4:30	12.0	0.3	29.0	.4	.9	4						
4:45	12.0	0.3	29.0	.4	.4	4						
5:00	12.5	0.3	29.0	.4	.6	4						
5:15	12.5	0.3	29.0	.4	.6	4						
5:30	12.0	0.3	31.0	.4	.6	4						
5:45	12.5	0.3	30	.4	.6	4						
6:00	12.5	0.3	29	.4	.4	4						
6:15	12.5	0.3	29	.4	.6	4						
6:30	12.5	0.3	29	.4	.4	4						
6:45	12.5	0.3	29	.4	.4	4						
7:00	12.5	0.3	28	.4	.2	4						
7:15	12.5	0.3	28	.4	0	4						
7:30	12.5	0.3	28	.4	0	4						
7:45	12.5	0.3	28.5	.4	0	4						
8:00	12.5	0.3	29	3.8	0	4						

SHIFT: ① OR II
LINES 1 & 2

K-1 - K-2

	7	8	9	10	11	12	1	2	3	4	5	6
Bed Voltage (KV)	15.0	14.0	13.5	13.5	12.5	12.5	12.5	12.5	12.5	12.5	12.5	12.0
Bed Amperage (MA)	.2	.2	.4	.4	.6	.6	.6	.6	.6	.4	.6	.6
Ionizer Voltage (KV)	26	26	26	30	30	30	30	30	30	29	29	29
Ionizer Amperage (MA)	2.6	2.4	2.6	3.0	4.2	4.2	4.0	4.0	4.0	3.8	4.0	4.0
EFB Pressure Drop (In.)	0	.4	1.4	2.6	3.2	3.4	1.2	1.2	1.4	1.2	.6	.6
Inlet Temperature	459	475	444	480	480	487	472	481	492	491	478	497
Outlet Temperature	377	390	366	398	405	413	398	412	413	411	403	417
Rock Flow	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
Condition Code*	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok

Rock Usage/Shift: _____

K-3 - K-4

	7	8	9	10	11	12	1	2	3	4	5	6
Bed Voltage (KV)	5.0	5.0	5.0	5.0	4.0	5.0	5.0	5.0	5.0	6.0	5.0	5.0
Bed Amperage (MA)	2.4	2.6	2.4	2.2	1.8	2.2	2.4	2.6	2.6	2.2	2.0	2.0
Ionizer Voltage (KV)	21	22	22	22	22	22	22	22	22	21	20	20
Ionizer Amperage (MA)	2.0	2.0	2.0	2.0	2.0	2.0	2.2	2.0	2.0	2.2	2.0	2.4
EFB Pressure Drop (In.)	.4	.4	.4	.4	.4	.4	.4	.4	.4	.4	.4	.4
Inlet Temperature	492	502	499	527	477	477	468	461	451	434	461	497
Outlet Temperature	422	423	419	404	414	419	427	330	432	431	427	427
Rock Flow	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
Condition Code*	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok

Rock Usage/Shift: _____

Baghouse
Pressure
Drop: (in.)

	7	8	9	10	11	12	1	2	3	4	5	6
L-I	4.5	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.5	4.8	4.0	4.0
L-II	4.2	4.8	4.6	4.8	4.0	4.2	3.8	4.0	4.2	4.4	3.8	4.0

Comments/Problems: _____

*Condition Codes

- 1) Start up/shutdown
- 2) Konus down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Konus on oil
- 8) Maintenance

VOLUME PER SHIFT

LINE I	2
LINE II	2

1033FBFORMSKNSRPT

SHIFT: I OR II
LINES 1 & 2

-1 - K-2

Bed Voltage (KV)
Bed Amperage (MA)
Ionizer Voltage (KV)
Ionizer Amperage (MA)
EFB Pressure Drop (In.)
Inlet Temperature
Outlet Temperature
Rock Flow
Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
12	12.5	12	12	12	12	12	12	12	12	12	12
0.8	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.4	0.4	0.4
28	28	29	29	29	29	29	29	29	29	29	29
4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	3.8	3.8	3.8	4.0
0.2	0	0	0	0	0	0	0	0	0.2	0.4	0.4
479	485	502	506	504	509	513	508	502	497	491	491
401	406	417	418	420	421	414	407	403	405	407	410
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

K-3 - K-4

Bed Voltage (KV)
Bed Amperage (MA)
Ionizer Voltage (KV)
Ionizer Amperage (MA)
EFB Pressure Drop (In.)
Inlet Temperature
Outlet Temperature
Rock Flow
Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
5	5	5	5	5	5	5	5	5	5	5	5
2.2	2.2	2.2	2.2	2.4	2.4	2.2	2.2	2.2	2.2	2.2	2.0
20	20	20	20	20	20	20	20	20	20	20	20
2.0	2.2	2.2	2.2	2.2	2.2	2.2	2.2	2.2	2.2	2.2	2.4
0.3	0.2	0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.4
500	504	500	508	517	528	523	527	530	526	520	504
433	426	426	428	425	424	426	422	421	423	425	421
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

Baghouse
Pressure
Drop: (in.)

	7	8	9	10	11	12	1	2	3	4	5	6
L-I	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.5	4.0
L-II	4.0	4.0	4.0	4.0	4.2	4.4	4.4	4.4	4.4	4.6	4.6	4.2

Comments/Problems: _____

*Condition Codes

- 1) Start up/shutdown
- 2) Konus down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Konus on oil
- 8) Maintenance

VOLUME PER SHIFT

LINE I	2
LINE II	3

FORMS/KNSRPT

SHIFT: ① OR II
 LINES 1 & 2

K-1 - K-2

 Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
12.5	12.5	13.0	13.0	13.0	13.0	13.0	13.0	12.5	12.5	13.0	13.0
.4	.4	.4	.2	.4	.4	.4	.4	.4	.4	.4	.4
29	30	29	28	30	30	30	30	30	30	30	30
3.8	4.	4.0	4.0	4.0	4.0	4.0	3.8	4.0	3.8	4.0	4.0
2.6	2.2	2.0	2.4	2.2	.8	1.0	1.2	.8	.8	1.0	1.0
492	488	487	492	495	513	514	514	509	505	507	502
407	404	403	405	406	418	417	415	414	411	412	413
ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok

Rock Usage/Shift: _____

K-3 - K-4

 Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
5.0	6.0	5.5	5.5	5.5	6.0	5.5	5.5	4.5	5.0	5.0	5.0
2.4	1.8	1.8	1.8	1.8	2.0	2.0	2.0	2.6	2.8	2.6	2.6
20	20	20	20	20	20	20	20	20	20	20	20
2.4	2.4	2.6	2.4	2.6	2.4	2.4	2.6	2.4	1.4	2.0	2.0
.4	.4	.4	.4	.4	.4	.4	.4	.4	.4	.4	.4
510	476	487	504	495	486	487	487	530	548	533	511
421	413	394	396	397	391	391	391	400	412	416	417
ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok

Rock Usage/Shift: _____

 Baghouse
 Pressure
 Drop: (in.)

L-I

L-II

7	8	9	10	11	12	1	2	3	4	5	6
4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.5	4.0	4.0
5.0	4.5	4.2	4.2	4.0	4.2	4.6	4.8	4.4	4.0	4.0	4.0

Comments/Problems: _____

*Condition Codes

- 1) Start up/shutdown
- 2) Dryers down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Dryer in oil
- 8) Pre-heater failure

VOLUME PER SHIFT

LINE I	2
LINE II	2

KNSRPT

APPENDIX M
SAMPLING TRAIN CALIBRATION DATA

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job L.P. / Hayward Date 2-20-96
Operator EJ Module No. 10

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 28.48 in.Hg $\theta =$ 1.0004 $\Delta H@$ 1.95 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(697.20)		
2.5	699.08	47	33
3.0	700.90	48	31
7.5	702.78	49	30
10	704.57	51	31
	$V_m = 7.37$	$Avg(t_m) =$	40 °F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(t_m + 460)}{P_b} \right]^{0.5}$$

$$Y_m = \frac{1.786}{(1.0004)(7.37)} \left[\frac{(40) + 460}{(28.48)} \right]^{0.5} 4.19$$

$$Y_m = \underline{1.01}$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job L.P. Hayward Date 2-21-96
Operator EJ Module No. 10

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 29.24 in.Hg $\theta =$ 1.0004 $\Delta H@$ 1.95 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(980.50)		
2.5	982.34	15	10
5.0	984.15	16	11
7.5	985.96	38	12
10	987.80	38	12
	$V_m = 7.30$	$Avg(t_m) = 18.25$	°F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(t_m + 460)}{P_b} \right]^{0.5}$$

$$Y_m = \frac{1.786}{(7.30)(1.0004)} \left[\frac{(18.25 + 460)}{(29.24)} \right]^{0.5} \frac{4.04}{.347}$$

$$Y_m = \underline{.988}$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job L.P. Hayward Date 2-22-96
Operator ES Module No. 10

Instructions:
Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 29.01 in.Hg $\theta =$ 1.0004 $\Delta H@$ 1.95 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(273.20)		
2.5	275.07	23	14
5.0	276.89	26	14
7.5	278.74	28	14
10	280.57	32	15
	$V_m = 7.37$	$Avg(t_m) = 20.75$	°F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(t_m + 460)}{P_b} \right]^{0.5}$$

$$Y_m = \frac{1.786}{(1.0004)(7.37)} \left[\frac{(20.75 + 460)}{(29.01)} \right]^{0.5} = 4.07$$

$$Y_m = \underline{.985}$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job LP-Hayward, WI Date 2/19/96
Operator SK Module No. 17

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 28.18 in.Hg $\theta =$.9985 $\Delta H@$ 1.74 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(213.400)		
2.5	215.294	50	47
5.0	217.190	55	49
7.5	219.110	58	50
10	226.033	61	51
	$V_m = 7.633$	Avg(t_m) = 52.6	°F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(t_m + 460)}{P_b} \right]^{0.5}$$

$$Y_m = \frac{1.786}{(.9985)(7.633)} \left[\frac{(52.6) + 460}{(28.18)} \right]^{0.5}$$

$$Y_m = \underline{.9994}$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

INTERPOLL LABORATORIES, INC.
(612) 786-6020

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job L.P. / Hayward, WI Date 2-20-96
Operator M. Kachler Module No. 13

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 28.75 in.Hg $\theta =$ 1.0051 $\Delta H@$ 1.91 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(257.50)		
2.5	259.36	46	43
5.0	261.23	47	43
7.5	263.09	49	43
10	264.95	52	43
	$V_m = 7.45$	$Avg(t_m) = 45.75$	°F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(t_m + 460)}{P_b} \right]^{0.5}$$

$$Y_m = \frac{1.786}{(1.0051)(7.45)} \left[\frac{(45.75) + 460}{(28.75)} \right]^{0.5}$$

$$Y_m = \underline{1.000}$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job L.P. / Hayward, WI Date 2-22-96
Operator M. Koehler Module No. 18

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 28.91 in.Hg $\theta =$ 1.0051 $\Delta H@$ 1.91 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(426.30)		
2.5	424.22	62	61
5.0	426.10	61	63
7.5	428.05	65	62
10	429.95	66	62
	$V_m = 7.65$	$Avg(t_m) = 62.75$	°F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(t_m + 460)}{P_b} \right]^{0.5}$$

$$Y_m = \frac{1.786}{(1.0051)(7.65)} \left[\frac{(62.75) + 460}{(28.91)} \right]^{0.5}$$

$$Y_m = \underline{0.998}$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: February 28, 1996

Meter Box No.: 5 (Rockwell Dry Test Meter Serial No. 949230)

Date of Last Calibration: July 4, 1995

Calibration Technician: S. Fjelsta

Test Meter No.: American Meter AL-20

Date of Use	Report No.	Initial Meter Reading	Final Meter Reading	Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
January 11, 1996	6-7164	357.10	574.29	217.19	217.19
February 16, 1996	6-7287	583.30	708.99	125.69	342.88
February 21, 1996	6-7318	709.40	1016.57	307.17	650.05

* Total volume through meter since last calibration.

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: February 28, 1996

Meter Box No. : 6 (Rockwell Dry Test Meter Serial No. 964548)

Date of Last Calibration: January 11, 1996

Calibration Technician: S. Fjelsta

Wet Test Meter No.: American Meter AL-20

Date of Use	Report No.	Initial Meter Reading	Final Meter Reading	Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
February 22, 1996	6-7318	437.32	595.20	157.88	157.88

* Total volume through meter since last calibration.

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: February 28, 1996

Meter Box No. : 10 (Rockwell Dry Test Meter Serial No. 1334112)

Date of Last Calibration: December 5, 1995

Calibration Technician: D. Van Hoever

Wet Test Meter No.: American Meter AL-20

Date of Use	Report No.	Initial Meter		Final Meter		Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
		Reading		Reading			
December 14, 1995	5-6998	26.35		152.02		125.67	125.67
December 20, 1995	5-7027	170.70		308.60		137.90	263.57
January 09, 1996	6-7145	319.40		461.20		141.80	405.37
January 11, 1996	6-7164	473.50		692.71		219.21	624.58
February 20, 1996	6-7318	704.80		1517.09		812.29	1436.87

* Total volume through meter since last calibration.

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: February 28, 1996

Meter Box No. : 17 (Rockwell Dry Test Meter Serial No. 1334113)

Date of Last Calibration: January 18, 1996

Calibration Technician: S. Kelker

Wet Test Meter No.: American Meter AL-20

Date of Use	Report No.	Initial Meter		Final Meter		Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
		Reading		Reading			
February 13, 1996	6-7285	114.25		210.80		96.55	96.55
February 20, 1996	6-7318	222.00		436.66		214.66	311.21

* Total volume through meter since last calibration.

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: February 28, 1996

Meter Box No. : 18 (Rockwell Dry Test Meter Serial No. 1334117)

Date of Last Calibration: January 22, 1996
Calibration Technician: S. Kelker
Wet Test Meter No.: American Meter AL-20

Date of Use	Report No.	Initial Meter		Final Meter		Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
		Reading		Reading			
February 21, 1996	6-7318	266.50		695.66		429.16	429.16

* Total volume through meter since last calibration.

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: February 28, 1996

Meter Box Number: 1-S (Rockwell Dry Test Meter Serial No. 64710)

Date of Last Calibration: January 11, 1996

Calibration Technician: S. Fjelsta

Wet Test Meter Number: American Meter AL-17 (0.05 CF/REV)

Date of Use	Report No.	Initial Meter Reading	Final Meter Reading	Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
February 22, 1996	6-7318	861.736	868.220	6.484	6.484

* Total volume through meter since last calibration.

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: February 28, 1996

Meter Box No. : 6-S (Rockwell Dry Test Meter Serial No. 649078)

Date of Last Calibration: January 11, 1996

Calibration Technician: S. Fjelsta

Wet Test Meter No.: American Meter AL-17 (0.05 CF/REV)

Date of Use	Report No.	Initial Meter Reading	Final Meter Reading	Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
February 13, 1996	6-7285	463.200	465.830	2.630	2.630
February 20, 1996	6-7318	466.403	473.379	6.976	9.606

* Total volume through meter since last calibration.

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: February 28, 1996

Meter Box No. : CEM Trailer (Rockwell Dry Test Meter Serial No. 964554)

Date of Last Calibration: February 8, 1996

Calibration Technician: S. Kelker

Wet Test Meter No.: American Meter AL-17

Date of Use	Report No.	Initial Meter		Final Meter		Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
		Reading		Reading			
February 21, 1996	6-7318	939.410		946.262		6.852	6.852

* Total volume through meter since last calibration.

Meter Calibration Sheet EPA/Method 5.1

[illegible]

Positive leak check performed by SF
Meter was in tolerance [Signature]
Approved by [Signature]
*Based on AL-20 wet test meter calibration in N6v, 1991 against Bell Prover (NBS Traceable) - Carl Poe Co.
Meter was not in tolerance
Meter was not in tolerance
Date 11/9/96
☐: readjusted linkage
☐: changed dry test meter
031794-G\STACKW\PF\FORM55-0102RR

Meter Calibration Sheet EPA/Method-5

35

[illegible]☐: changed dry test meter

031794-G:\STACK\WP\FORMS\5-0102RR

Meter Calibration Sheet EPA/Method.5.4

Siobhán

Dec 5 1995 IN:HG
28.81

AL-20

Control Module No.

Serial No. DTM

Technician

[illegible]

Positive leak check performed by
Meter was in tolerance
Approved by

Meter was not in tolerance

Meter was not in tolerance.

Date _____

- ☐: readjusted linkage
- ☐: changed dry test meter

erance
12/14/95

*Based on At-20 wet test meter calibration in Nov. 1991 against Bell Prover (NBS Traceable) - Carl Poe Co.

031794-G:\STACK\WP\FORMS\5-0102RR

INTERPOL LABORATORIES, INC.
(612) 786-6020

Meter Calibration Sheet EPA/Method 5

11/18/96

Date _____

Bar. Press.

Wet Test Meter No.

Control Module No.

Serial No. DTM

Technician

IN.HG

AL-20

[illegible]

Positive leak check performed by

Meter was in tolerance

Approved by _____

Positive leak check performed by
Meter was in tolerance
Approved by  K. Smith
Based on AI-20 wet test meter calibration in Nov 1991 against Bell Prover (

Meter was not in tolerance

Meler was not in tolerance

Date: _____

☐: readjusted linkage
☐: changed dry test meter

*Based on Al-20 wet test meter calibration in Nov. 1991 against Bell Prover (NBS Traceable) - Carl Poe Co.

071794 C:\STACK\W\W\FORMS\5-0102RR

INTERPOL LABORATORIES, INC.
(612) 786-6020

Meter Calibration Sheet EPA/Method 5

Date 1/22/96 Control Module No. 18
Bar. Press. 29.19 Serial No. DTM 1334117
Technician SK AI-20

[illegible]

positive leak check performed by SK
Meter was in tolerance ☒
Approved by 
Based on At-20 wet test meter calibration in Nov. 1991 against Bell Prover (NBS Tracable) - Carl Poe Co. 2/2/96
Meter was not in tolerance _____
Meter was not in tolerance _____
Date _____
☐: readjusted linkage
☐: changed dry test meter

031294 GASTACKWV\FORM55-0102RR

(612) 786-6020

Minimodule Calibration Sheet/Flow Rate Range 0-0.13 CFM/(0-4 LPM)

Dale

Date _____
Bar. Press. _____

Wet Test Meler No.

IN.HG

Meter Box No.
Serial No. DTM

Technician

KT
964554
Steve Kelker

Rota-meter Reading (cc/Min)	ΔP_a (IN. WC)	Gas Volume Wet Test Meter (ft^3)	** Cal Index ϕ (%)	Diff. Wet Test Meter ΔP_w (IN. WC)	Gas Volume Dry Test Meter (ft^3)		Gas Temperature		Time θ (Min/Sec)	Meter Coeff.	Rota-meter Coeff.
					V_{dl}	V_{dl}	Wet Test t_w ($^{\circ}\text{F}$)	Dry Test t_d ($^{\circ}\text{F}$)			
1000	.001	.5	99.55	0.04	929.700	930.198	69.4	68	—	1.0003	Z
1000	.001	.5	99.55	0.04	930.198	930.698	69.4	68	—	0.9963	
1000	.001	.5	99.55	0.04	930.698	931.198	69.4	68	—	0.9963	
Total Avg.											0.9976

Meter was in tolerance

Meler was not in tolerance

Meter was not in tolerance

Approved by 

☒

□: readjusted linkage

☒: changed dry test meters

Date 2/2/20

Gas Meter Bimetallic Therm.

$\square \geq \pm 5^{\circ}\text{F}$ (Out of control)

 $\Delta \leq \pm 5^{\circ}\text{F (In control)}$

*
erification

□ Re

Z
□


st mercury in

*Based on Al-17 wet test meter calibration in Aug. 1989 against Bell Prover (NBS Traceable) - Carl Poe Co.

DIFFERENTIAL INCHES H₂O

PULSATION RANGE

ET TEST METER



Calibrated with a 10 Ft. American Bell Prover, Serial No. 3157. Traceable to the Bureau of Standards. Reference No. 5249060, PI-TAPE.

AL-20 American Met Test Meter
Serial No. P-2112

Stainless Steel w/Removable Back
Calibrated w/Saturated Air
Water Temp. 74° F.


Air Temp. 74° F.

Inlet Pressure 2" H₂O Constant

Calibration Rate: 60 CFH Per/Hr.

Capacity Rate: 120 CFH Per/Hr.

Restricted Outlet for Rate Deviation




CORRECT VOLUME INDEX READING X PROOF = 100

FLOW RATE - CUBIC FEET OF AIR PER HOUR

DAVID DANIS

DIFFERENTIAL PRESSURE PROOF CALIBRATION CURVE



FLOW RATE - CUP'S FEET OF AIR PER HOUR

DAVID BANKS
AUGUST, 1988

Interpoll Laboratories, Inc.

(612) 786-6020

Nozzle Calibration

Data Sheet

Date of Calibration: 02-20-96

Nozzle Number 3-4

Technician: Ed Juers

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	.247
2	.246
3	.249
Average:	.247

Interpoll Laboratories, Inc.
(612) 786-6020

Nozzle Calibration
Data Sheet

Date of Calibration: 02-20-96

Nozzle Number 7-8

Technician: Duane Van Hoever

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	.453
2	.452
3	.455
Average:	.453

Interpoll Laboratories, Inc.
(612) 786-6020

Nozzle Calibration
Data Sheet

Date of Calibration: 02-20-96

Nozzle Number 8-8

Technician: Duane Van Hoever

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	.434
2	.434
3	.435
Average:	.434

Interpoll Laboratories, Inc.
(612) 786-6020

Nozzle Calibration
Data Sheet

Date of Calibration: 02-21-96

Nozzle Number 2-4

Technician: Mark Kaehler

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	.249
2	.251
3	.251
Average:	.250

Interpoll Laboratories, Inc.
(612) 786-6020

Nozzle Calibration
Data Sheet

Date of Calibration: 02-21-96

Nozzle Number GLASS

Technician: Ed Juers

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	.275
2	.276
3	.275
Average:	.275

Interpoll Laboratories, Inc.

(612) 786-6020

Nozzle Calibration

Data Sheet

Date of Calibration: 02-22-96

Nozzle Number GLASS

Technician: Duane Van Hoever

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	.434
2	.434
3	.434
Average:	.434

Interpoll Laboratories, Inc.
(612) 786-6020

Nozzle Calibration
Data Sheet

Date of Calibration: 02-22-96

Nozzle Number

GLASS-3

Technician: Mark Kaehler

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	.187
2	.187
3	.187
Average:	.187

Temperature Measurement Device Calibration Sheet

Unit Under Test:

Vendor

Model

Range

Date of Calibration

Method of Calibration:

Omega

HH 81

0-2000

12-26-95

°F

Serial Number

Thermocouple Type

Technician

PDT No.

23 J x 1495

K

Mark Bachler

31

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☐ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0		-3	3	.65
100		97	3	.54
200		200	0	0
300		298	2	.26
400		397	3	.35
500		497	3	.31
600		599	1	.09
700		698	2	.17
800		800	0	0
900		899	1	.07
1000		999	1	.07
1100		1099	1	.06
1200		1199	1	.06
1300		1298	2	.11
1400		1400	0	0
1500		1498	2	.10
1600		1600	0	0
1700		1699	1	.05
1800		1800	0	0
1900		1897	3	.13
2000		1998	2	.08
2100		2095	5	.20
		Averages:	1.64	.15

OF = off scale response by unit under test (°F)

☒ Unit in tolerance

% dev = $100 \Delta t / (460 + t)$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACKWP\FORMSS-433

Temperature Measurement Device Calibration Sheet

Unit Under Test:

Model

Range

Date of Calibration

Method of Calibration:

Omega

HH 81

0 - 2100

2/6/96

°F

Serial Number

Thermocouple Type

Technician

PDT No.

731X1493

K

SK

32

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☒ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0	0	-3	3	.652
100	100	97	3	.536
200	200	199	1	.152
300	300	298	2	.263
400	400	397	3	.349
500	500	497	3	.313
600	600	599	1	.094
700	700	698	2	.172
800	800	800	0	0
900	900	899	1	.074
1000	1000	999	1	.068
1100	1100	1098	2	.128
1200	1200	1199	1	.060
1300	1300	1298	2	.114
1400	1400	1401	1	.054
1500	1500	1498	2	.102
1600	1600	1602	2	.097
1700	1700	1699	1	.046
1800	1800	1801	1	.044
1900	1900	1899	1	.042
2000	2000	2000	0	0
2100	2100	2097	3	.039
		Averages:	1.6	.154

OF = off scale response by unit under test (°F)

☒ Unit in tolerance

% dev = $100 \Delta t / (460 + t)$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACK\WP\FORMS\5-433

INTERPOL LABORATORIES, INC.

(612) 786-6020

Temperature Measurement Device Calibration Sheet

Unit Under Test:

Vendor

Model

Range

Date of Calibration

Method of Calibration:

OMEGA

H481

0 - 2000

1-10-96

°F

Serial Number

Thermocouple Type

Technician

PDT No.

74TX0343

K

ETI/MLD

34

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☒ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0	0	-3	3	.165
100	100	97	3	.53
200	200	199	1	.15
300	300	298	2	.26
400	400	397	3	.39
500	500	498	2	.20
600	600	600	0	0
700	700	699	1	.08
800	800	802	2	.16
900	900	900	0	0
1000	1000	1001	1	.07
1100	1100	1099	1	.06
1200	1200	1201	1	.06
1300	1300	1300	0	0
1400	1400	1403	3	.16
1500	1500	1501	1	.05
1600	1600	1604	4	.19
1700	1700	1701	1	.05
1800	1800	1804	4	.17
1900	1900	1901	1	.04
2000	2000	2003	3	.12
2100	2100	2100	0	0
		Averages:	1.68	.154

OF = off scale response by unit under test (°F)

% dev = $100 \Delta t / (460 + t)$

☒ Unit in tolerance

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-GASTACKWPFORMSS-433

Temperature Measurement Device Calibration Sheet

Unit Under Test:

Vendor

Model

Range

Date of Calibration

Method of Calibration:

OMEGA
H H 81
-160°C to 1372°C
2-6-96

Serial Number

Thermocouple Type

Technician

PDT No.

741X1327
K
EJ
42

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☒ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0	0	-3	3	.65
100	100	97	3	.53
200	200	199	1	.15
300	300	297	3	.39
400	400	397	3	.35
500	500	497	3	.31
600	600	599	1	.09
700	700	698	2	.17
800	800	800	0	0
900	900	899	1	.07
1000	1000	1000	0	0
1100	1100	1098	2	.13
1200	1200	1200	0	0
1300	1300	1298	2	.11
1400	1400	1401	1	.05
1500	1500	1499	1	.05
1600	1600	1602	2	.09
1700	1700	1701	1	.05
1800	1800	1802	2	.09
1900	1900	1901	1	.04
2000	2000	2000	0	0
2100	2100	2099	1	.04
		Averages:	1.5	.153

Off = off scale response by unit under test (°F)

☒ Unit in tolerance

% dev = $100 \Delta t / (460 + t)$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACK\WPA\FORMS\SS-433

Temperature Measurement Device Calibration Sheet

Unit Under Test:

Vendor

Model

Range

Date of Calibration

Method of Calibration:

Omega

HH 81

0-2000

2-16-96

Serial Number

Thermocouple Type

Technician

PDT No.

745X1539

K

LH

43

☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.

☒ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0	0	-3	3	.650
100	100	98	2	.357
200	200	200	0	0
300	300	299	1	-.132
400	400	398	2	-.233
500	500	499	1	-.104
600	600	600	0	0
700	700	699	1	-.086
800	800	801	1	.079
900	900	899	1	-.074
1000	1000	1000	0	0
1100	1100	1098	2	-.128
1200	1200	1200	0	0
1300	1300	1298	2	-.113
1400	1400	1401	1	.054
1500	1500	1499	1	-.051
1600	1600	1602	2	.097
1700	1700	1700	0	0
1800	1800	1802	2	.088
1900	1900	1900	0	0
2000	2000	2000	0	0
2100	2100	2097	3	-.117
		Averages:	1.137	-.107

OF = off scale response by unit under test (°F)

% dev = $100 \Delta t / (460 + t)$

☒ Unit in tolerance

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACKWPFORM5S-433

Temperature Measurement Device Calibration Sheet

Unit Under Test:

ndor

Model

Range

Date of Calibration

Method of Calibration:

Omega

HH B1

0-2000

12-26-95

°F

Serial Number

Thermocouple Type

Technician

PDT No.

743X1560

K

Mark Boehler

45

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☐ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0		-2	2	.43
100		98	2	.36
200		200	0	0
300		298	2	.26
400		398	2	.23
500		499	1	.10
600		600	0	0
700		699	1	.09
800		801	1	.08
900		900	0	0
1000		1001	1	.07
1100		1099	1	.06
1200		1201	1	.06
1300		1299	1	.06
1400		1402	2	.11
1500		1499	1	.05
1600		1602	2	.10
1700		1701	1	.05
1800		1802	2	.09
1900		1901	1	.04
2000		2001	1	.04
2100		2099	1	.04
		Averages:	1.18	.11

OF = off scale response by unit under test (°F)

☒ Unit in tolerance

% dev = $100 \Delta t / (460 + t)$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACKWPFORMSS-433

Temperature Measurement Device Calibration Sheet

Unit Under Test:

Vendor

Model

Range

Date of Calibration

Method of Calibration:

OMEGA
HH81
-160 to +1,372 °C
2-6-96

Serial Number

Thermocouple Type

Technician

PDT No.

755X1176
K
ES
47

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☒ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0	0	-3	3	.65
100	100	98	2	.36
200	200	200	0	0
300	300	298	2	.26
400	400	398	2	.24
500	500	499	1	.10
600	600	600	0	0
700	700	699	1	.09
800	800	801	1	.09
900	900	901	1	.07
1000	1000	1001	1	.07
1100	1100	1099	1	.06
1200	1200	1201	1	.06
1300	1300	1299	1	.06
1400	1400	1402	2	.11
1500	1500	1500	0	0
1600	1600	1602	2	.09
1700	1700	1701	1	.05
1800	1800	1803	3	.13
1900	1900	1901	1	.04
2000	2000	2001	1	.04
2100	2100	2099	1	.04
Averages:			1.27	.12

OF = off scale response by unit under test (°F)

☒ Unit in tolerance

% dev = $100 \Delta t / (460 + t)$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACK\WP\FORMS\5-433

S-Type Pitot Tube Inspection Sheet

Pitot Tube No. 22-8

Pitot tube dimensions:

1. External tubing diameter (D) .316 IN.
2. Base to Side A opening plane (P_A) .460 IN.
3. Base to Side B opening plane (P_B) .460 IN.

Alignment:

4. α_1 < 10° 0
5. α_2 < 10° 0
6. B_1 < 5° 0
7. B_2 < 5° 0
8. Z < .125" .0
9. W < .0625" .0

Distance from Pitot to Probe Components:

10. Pitot to 0.500 IN. nozzle .760 IN.
11. Pitot to probe sheath 3.0 IN.
12. Pitot to thermocouple (parallel to probe) 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) .760 IN.

- ☒ Meets all EPA design criteria thus $C_p = 0.84$
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
 $C_p =$ _____

Date of Inspection:

11-8-84

Inspected by:

[Signature]

S-Type Pitot Tube Inspection Sheet

Pitot Tube No. 23-6

Pitot tube dimensions:

1. External tubing diameter (D) .316 IN.
2. Base to Side A opening plane (P_A) .460 IN.
3. Base to Side B opening plane (P_B) .460 IN.

Alignment:

4. α_1 < 10° 0
5. α_2 < 10° 0

6. B₁ < 5° 0
7. B₂ < 5° 0

8. Z < .125" .02
9. W < .0625" .025

Distance from Pitot to Probe Components:

10. Pitot to 0.500 IN. nozzle .750 IN.
11. Pitot to probe sheath 3.0 IN.
12. Pitot to thermocouple (parallel to probe) 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) .760 IN.

- ☒ Meets all EPA design criteria thus C_p = 0.84
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
C_p = _____

Date of Inspection:

4-8-94

Inspected by:

[Signature]

S-Type Pitot Tube Inspection Sheet

Pitot Tube No. 27-6

Pitot tube dimensions:

1. External tubing diameter (D) .316 IN.
2. Base to Side A opening plane (P_A) .460 IN.
3. Base to Side B opening plane (P_B) .460 IN.

Alignment:

4. α_1 < 10° 0
5. α_2 < 10° 0
6. B₁ < 5° 0
7. B₂ < 5° 0
8. Z < .125" .01
9. W < .0625" .02

Distance from Pitot to Probe Components:

10. Pitot to 0.500 IN. nozzle .750 IN.
11. Pitot to probe sheath 3.0 IN.
12. Pitot to thermocouple (parallel to probe) 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) .760 IN.

- ☒ Meets all EPA design criteria thus C_p = 0.84
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
C_p = _____

Date of Inspection:

4-7-94

Inspected by:

[Signature]

S-Type Pitot Tube Inspection Sheet

Pitot Tube No. 29-8

Pitot tube dimensions:

1. External tubing diameter (D_t) .316 IN.
2. Base to Side A opening plane (P_A) .460 IN.
3. Base to Side B opening plane (P_B) .460 IN.

Alignment:

4. α_1 $< 10^\circ$ 0
5. α_2 $< 10^\circ$ 0

6. β_1 $< 5^\circ$ 0
7. β_2 $< 5^\circ$ 0

8. Z $< .125"$.01
9. W $< .0625"$ 0.2

Distance from Pitot to Probe Components:

10. Pitot to 0.500 IN. nozzle .750 IN.
11. Pitot to probe sheath 3.0 IN.
12. Pitot to thermocouple (parallel to probe) 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) .760 IN.

- ☐ Meets all EPA design criteria thus $C_p = 0.84$
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
 $C_p =$ _____

Date of Inspection:

4-7-94

Inspected by:

[Signature]

S-Type Pitot Tube Inspection Sheet

Pitot Tube No. MM-6

Pitot tube dimensions:

1. External tubing diameter (D) 1.316 IN.
2. Base to Side A opening plane (P_A) 460 IN.
3. Base to Side B opening plane (P_B) 460 IN.

Alignment:

4. α_1 < 10° 0
5. α_2 < 10° 0
6. B_1 < 5° 0
7. B_2 < 5° 0
8. Z < .125" .03
9. W < .0625" .025

Distance from Pitot to Probe Components:

10. Pitot to 0.500 IN. nozzle 750 IN.
11. Pitot to probe sheath 3.0 IN.
12. Pitot to thermocouple (parallel to probe) 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) 760 IN.

- ☒ Meets all EPA design criteria thus $C_p = 0.84$
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
 $C_p =$ _____

Date of Inspection:

4-8-84

Inspected by:

[Signature]

S-Type Pitot Tube Inspection Sheet

Pitot Tube No. MM5-8

Pitot tube dimensions:

1. External tubing diameter (D) .316 IN.
2. Base to Side A opening plane (P_A) .460 IN.
3. Base to Side B opening plane (P_B) .460 IN.

Alignment:

4. α_1 < 10° 0
5. α_2 < 10° 0

6. B_1 < 5° 2
7. B_2 < 5° 2

8. Z < .125" .02
9. W < .0625" .02

Distance from Pitot to Probe Components:


10. Pitot to 0.500 IN. nozzle .750 IN.
11. Pitot to probe sheath 3.0 IN.
12. Pitot to thermocouple (parallel to probe) 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) .760 IN.

- ☒ Meets all EPA design criteria thus $C_p = 0.84$
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
 $C_p =$ _____

Date of Inspection:

4-7-93

Inspected by:



INTERPOLL LABORATORIES, INC.
(612) 786-6020

Stack Sampling Department - QA
Aneroid Barometer Calibration Sheet

Date 2-9-96
Technician E. J. J. S.
Mercury Column Barometer No. 1
Aneroid Barometer No. 10724004

Actual Mercury Barometer Read	Ambient Temp.	Temperature Correction Factor	Adjusted Mercury Barometer Read	Initial Aneroid Barometer Read	Difference ($P_{ba} - P_{bm}$)
28.99	82	.136	28.85	28.85	0

Has this barometer shown any consistent problems with calibration? Yes/No. If yes, explain. NO

Has problem been alleviated? Yes/No. How? _____

Note: Aneroid barometers will be calibrated periodically against a mercury column barometer. The aneroid barometer to be calibrated should be placed in close proximity to the mercury barometer and left to equilibrate for 20 - 30 minutes before calibrating. Aneroid barometer will be calibrated to the adjusted mercury barometer readings.

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Stack Sampling Department - QA
Aneroid Barometer Calibration Sheet

Date 12-26-95
Technician Mark Isachler
Mercury Column Barometer No. Lab 1
Aneroid Barometer No. 21029004

Actual Mercury Barometer Read	Ambient Temp.	Temperature Correction Factor	Adjusted Mercury Barometer Read	Initial Aneroid Barometer Read	Difference ($P_{ba} - P_{bm}$)
29.080	80	.131	28.949	28.95	.001

Has this barometer shown any consistent problems with calibration? Yes/No. If yes, explain. _____

Has problem been alleviated? Yes/No. How? _____

Note: Aneroid barometers will be calibrated periodically against a mercury column barometer. The aneroid barometer to be calibrated should be placed in close proximity to the mercury barometer and left to equilibrate for 20 - 30 minutes before calibrating. Aneroid barometer will be calibrated to the adjusted mercury barometer readings.

INTERPOLL LABORATORIES
(612)786-6020
Stack Sampling Department - QA
Aneroid Barometer Calibration Sheet

Date 1-10-96
Technician E. Trumble
Mercury Column Barometer No. ULTIMETER MODEL 12
Aneroid Barometer No. SN - D1002005

Actual Mercury Barometer Read	Ambient Temp.	Temperature Correction Factor	Adjusted Mercury Barometer Read	Initial Aneroid Barometer Read	Difference (P _{ba} -P _{bm})
29.164	72	.116	29.05	29.05	-0-

Has this barometer shown any consistent problems with calibration? Yes/No. If yes, explain. No

Has problem been alleviated? Yes/No. How? _____

***Note**

Aneroid barometers will be calibrated periodically against a mercury column barometer. The aneroid barometer to be calibrated should be placed in close proximity to the mercury barometer and left to equilibrate for 20-30 minutes before calibrating. Aneroid barometer will be calibrated to the adjusted mercury barometer readings.

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Stack Sampling Department - QA
Aneroid Barometer Calibration Sheet

Date

12/8/95

Technician

D. VAN HOEVER

Mercury Column Barometer No.

LAB

Aneroid Barometer No.

DUN'S

Actual Mercury Barometer Read	Ambient Temp.	Temperature Correction Factor	Adjusted Mercury Barometer Read	Initial Aneroid Barometer Read	Difference ($P_{ba} - P_{bm}$)
29.14	82	.142	28.998	28.94	.058

Has this barometer shown any consistent problems with calibration? Yes ☒ No ☐ If yes, explain. _____

Has problem been alleviated? Yes/No. How? _____

Note: Aneroid barometers will be calibrated periodically against a mercury column barometer. The aneroid barometer to be calibrated should be placed in close proximity to the mercury barometer and left to equilibrate for 20 - 30 minutes before calibrating. Aneroid barometer will be calibrated to the adjusted mercury barometer readings.

FILE COPY

Interpoll Laboratories, Inc.
4500 Ball Road N.E.
Circle Pines, Minnesota 55014-1819

TEL: (612) 786-6020
FAX: (612) 786-7854

**RESULTS OF THE MARCH 21, 1996
AIR EMISSION COMPLIANCE TEST OF THE
LINE 1 THERMAL OIL HEATER AT THE
LOUISIANA PACIFIC PLANT IN
HAYWARD, WISCONSIN**

Submitted to:

LOUISIANA-PACIFIC CORPORATION
Route 8, Box 8263
Hayward, Wisconsin 54843

Attention:

Keith Seelig

Approved by:



Daniel Despen
Manager
Stationary Source Testing Department

Report Number 6-7451E
April 24, 1996
SL/sll

TABLE OF CONTENTS

ABBREVIATIONS	iii
1 INTRODUCTION	1
2 SUMMARY AND DISCUSSION	3
3 AIR EMISSION RESULTS	6
3.1 Orsat and Moisture Analyses	7
3.2 Results of Particulate Determinations	9
4 RESULTS OF FUEL ANALYSIS	11

APPENDICES:

- A - Preliminary Volumetric Flow Rate Determination
- B - Location of Test Ports
- C - Field Data Sheets
- D - Interpoll Laboratories Analytical Data
- E - Operational Data
- F - Procedures
- G - Calculation Equations
- H - Sampling Train Calibration Data

ABBREVIATIONS

ACFM	actual cubic feet per minute
cc (ml)	cubic centimeter (milliliter)
DSCFM	dry standard cubic foot of dry gas per minute
DSML	dry standard milliliter
DEG-F (°F)	degrees Fahrenheit
DIA.	diameter
FP	finished product for plant
FT/SEC	feet per second
g	gram
GPM	gallons per minute
GR/ACF	grains per actual cubic foot
GR/DSCF	grains per dry standard cubic foot
g/dscm	grams per dry standard cubic meter
HP	horsepower
HRS	hours
IN.	inches
IN.HG.	inches of mercury
IN.WC.	inches of water
LB	pound
LB/DSCF	pounds per dry standard cubic foot
LB/HR	pounds per hour
LB/10 ⁶ BTU	pounds per million British Thermal Units heat input
LB/MMBTU	pounds per million British Thermal Units heat input
LTPD	long tons per day
MW	megawatt
mg/Nm ³	milligrams per dry standard cubic meter
ug/Nm ³	micrograms per dry standard cubic meter
microns (um)	micrometer
MIN.	minutes
ng	nanograms
ohm-cm	ohm-centimeter
PM	particulate matter
PPH	pounds per hour
PPM	parts per million
ppmC	parts per million carbon
ppm,d	parts per million, dry
ppm,w	parts per million, wet
ppt	parts per trillion
PSI	pounds per square inch
SQ.FT.	square feet
TPD	tons per day
ug	micrograms
v/v	percent by volume
w/w	percent by weight
<	≤ (when following a number)

Standard conditions are defined as 68°F (20°C) and 29.92 IN. of mercury pressure.

1 INTRODUCTION

On March 21, 1996 Interpoll Laboratories personnel conducted a particulate emission compliance test of the Line 1 Thermal Oil Heater at the Louisiana Pacific Plant in Hayward, Wisconsin. On-site testing was performed by Jamie Bainville and Jim Lorenz. Coordination between testing activities and plant operation was provided by Keith Selig of Louisiana Pacific Corporation. The tests were not witnessed by a member of the Wisconsin Department of Natural Resources.

Particulate determinations were performed in accordance with EPA Methods 2 - 5, CFR Title 40, Part 60, Appendix A (revised July 1, 1995). A preliminary volumetric flow rate determination was performed to select the appropriate nozzle diameter required for isokinetic sample withdrawal. An Interpoll Labs sampling train which meets or exceeds specifications in the above-cited reference was used to extract particulate samples by means of a heated glass-lined probe. Wet catch samples were collected in the back half of the Method 5 sampling train and analyzed as per Wisconsin DNR Protocol.

An integrated flue gas sample was extracted simultaneously with the particulate sampling train using a specially designed gas sampling system. Integrated flue gas samples were collected in 44-liter Tedlar bags housed in a protective aluminum container. After sampling was complete, the bags were sealed and returned to the laboratory for Orsat analysis. Prior to sampling, the Tedlar bags are leak-checked at 15 IN.HG. vacuum with an in-line rotameter. Bags with any detectable in-leakage are discarded.

Testing was conducted from two test ports oriented at 90° on the stack. These test ports are located approximately 4.8 diameters downstream and 2.3 diameters upstream of the nearest flow disturbance. A 20-point traverse was used to collect representative particulate samples. Each traverse point was sampled 3 minutes to give a total sampling time of 60 minutes per run.

The important results of the test are summarized in Section 2. Detailed results are presented in Section 3. Field data and all other supporting information are presented in the appendices.

2 SUMMARY AND DISCUSSION

The results of the air emission compliance tests are summarized in Table 1. An overview of the results is presented in the table below:

<u>Parameter</u>	<u>Measured</u>
Particulate	
(Dry + Wet Catch)	
..... (GR/DSCF)	0.0147
..... (LB/10 ⁶ BTU)	0.056
(Dry Catch Only)	
..... (GR/DSCF)	0.010
..... (LB/10 ⁶ BTU)	0.040

The wet catch portion of the first sampling run was accidentally spilled during recovery, therefore, this run was voided by the Interpoll Laboratories field engineer. An additional test run was performed immediately following the third test run. No other difficulties were encountered in the field or in the laboratory evaluation of the samples. On the basis of these facts and a complete review of the data and results, it is our opinion that the results reported herein are accurate and closely reflect the actual values which existed at the time the test was performed.

Table 1a Summary of the Results of the March 21, 1996 Particulate Emission Test of the Line 1 Thermal Oil Heater Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	03-21-96	03-21-96	03-21-96
Time runs were done (HRS)	1038/1145	1210/1312	1340/1445
Steam flow (KLB/HR)			
Volumetric flow actual (ACFM)	17922	19125	19072
standard (DSCFM)	10922	11762	11338
Gas temperature (DEG-F)	306	310	308
Moisture content (%V/V)	9.62	8.21	11.53
Gas composition (%V/V, dry)			
carbon dioxide	7.10	6.50	5.30
oxygen	12.80	13.40	14.80
nitrogen	80.10	80.10	79.90
Isokinetic variation (%)	97.0	97.5	100.2
Particulate concentration actual (GR/ACF)	.007330	.0113	.00811
standard (GR/DSCF)	.0120	.0184	.0136
part. emission rate (LB/HR)	1.13	1.86	1.33
Emission factor (LB/MMBTU)	0.041	0.067	0.061

.0147
1.54

Note: Dry + Organic/Inorganic Wet Catch

Table 1b Summary of the Results of the March 21, 1996 Particulate Emission Test of the Line 1 Thermal Oil Heater Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	03-21-96	03-21-96	03-21-96
Time runs were done (HRS)	1038/1145	1210/1312	1340/1445
Steam flow (KLB/HR)			
Volumetric flow actual (ACFM)	17922	19125	19072
standard (DSCFM)	10922	11762	11338
Gas temperature (DEG-F)	306	310	308
Moisture content (%V/V)	9.62	8.21	11.53
Gas composition (%V/V, dry)			
carbon dioxide	7.10	6.50	5.30
oxygen	12.80	13.40	14.80
nitrogen	80.10	80.10	79.90
Isokinetic variation (%)	97.0	97.5	100.2
Particulate concentration actual (GR/ACF)	.006409	.006016	.00655
standard (GR/DSCF)	.0105	.009786	.0110
Part. emission rate (LB/HR)	0.985	0.987	1.07
Emission factor (LB/MMBTU)	0.035	0.036	0.049

1014

Note: Dry Catch Only

3 RESULTS

The results of all field and laboratory evaluations are presented in this section. Gas composition (Orsat and moisture) are presented first followed by the computer printout of the particulate results. Preliminary measurements including test port locations are given in the appendices.

The results have been calculated on a personal computer using programs written in Extended BASIC specifically for source testing calculations. EPA-published equations have been used as the basis of the calculation techniques in these programs. The particulate emission rate has been calculated using the product of the concentration times flow method.

3.1 Orsat & Moisture Analyses

Test No. 18
Line 1 Thermal Oil Heater Stack

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

	Run 1	Run 2	Run 3
Date of run	03-21-96	03-21-96	03-21-96

Dry basis (orsat)

carbon dioxide.....	7.10	6.50	5.30
oxygen.....	12.80	13.40	14.80
nitrogen.....	80.10	80.10	79.90

Wet basis (orsat)

carbon dioxide.....	6.42	5.97	4.69
oxygen.....	11.57	12.30	13.09
nitrogen.....	72.39	73.53	70.69
water vapor.....	9.62	8.21	11.53
Dry molecular weight.....	29.65	29.58	29.44
Wet molecular weight.....	28.53	28.63	28.12
Specific gravity.....	0.985	0.989	0.971
Water mass flow.....(LB/HR)	3261	2950	4145

FO	1.141	1.154	1.151
----	-------	-------	-------

3.2 Results of Particulate Determinations

Test No. 18
Line 1 Thermal Oil Heater Stack

Results of Particulate Loading Determinations-----Method 5

	Run 1 03-21-96	Run 2 03-21-96	Run 3 03-21-96
Date of run	03-21-96	03-21-96	03-21-96
Time run start/end.....(HRS)	1038/1145	1210/1312	1340/1445
Static pressure.....(IN.WC)	-0.12	-0.12	0.00
Cross sectional area (SQ.FT)	14.75	14.75	14.75
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	88.0	79.0	118.0
desiccant.....(GRAMS)	11.0	11.0	12.0
total.....(GRAMS)	99.0	90.0	130.0
Total particulate material..			
.....collected(grams)	0.0342	0.0566	0.0416
Gas meter coefficient.....	1.0023	1.0023	1.0023
Barometric pressure...(IN.HG)	29.26	29.26	29.26
Avg. orif.pres.drop...(IN.WC)	1.75	2.08	2.04
Avg. gas meter temp...(DEF-F)	58.0	65.5	67.6
Volume through gas meter....			
at meter conditions...(CF)	43.72	47.96	47.72
standard conditions.(DSCF)	43.86	47.46	47.03
Total sampling time....(MIN)	60.00	60.00	60.00
Nozzle diameter.....(IN)	.432	.432	.432
Avg.stack gas temp ..(DEG-F)	306	310	308
Volumetric flow rate.....			
actual.....(ACFM)	17922	19125	19072
dry standard.....(DSCFM)	10922	11762	11338
Isokinetic variation.....(%)	97.0	97.5	100.2
Particulate concentration...			
actual.....(GR/ACF)	0.00733	0.01131	0.00811
dry standard.....(GR/DSCF)	0.01203	0.01840	0.01365
Particle mass rate...(LB/HR)	1.126	1.855	1.33
F-factor(DSCF/MMBTU)	9140	9140	9140
Emission factor...(LB/MMBTU)	0.041	0.067	0.061

4 RESULTS OF FUEL ANALYSIS

INTERPOLL LABORATORIES, INC.**Fuel Laboratory****(612) 786-6020**

Date: 3/28/96
Client: LOUISIANA-PACIFIC, HAYWARD
Laboratory Log Number: 7451-64-9999
Sample Collected: 3/21/96
Sample Received: 3/22/96
Source: LINE 1 KONUS
Sample Identification: TEST 18, WOOD

Proximate and Ultimate Analysis WT %**Proximate Analysis WT %**

Parameter	Moisture & Ash Free	Moisture Free	As Received
Moisture, Total			43.45
Ash		3.16	1.79
Volatile Matter	81.07	78.51	44.40
Fixed Carbon (calculation)	18.93	18.33	10.37
Sulfur	0.02	0.02	0.01
Heating Value, BTU/LB.	8434	8168	4619

Ultimate Analysis WT %

Parameter	Moisture & Ash Free	Moisture Free	As Received
Moisture, Total			43.45
Ash		3.16	1.79
Carbon	51.54	49.91	28.23
Hydrogen	4.99	4.84	2.74
Nitrogen	0.06	0.06	0.03
Oxygen (calculated)	43.39	42.02	23.76
Sulfur	0.02	0.02	0.01

Respectfully submitted,



David J. Schneider, Manager
Chemistry Department

APPENDIX A

PRELIMINARY VOLUMETRIC FLOW RATE DETERMINATION


Test No. 18
Line 1 Thermal Oil Heater Stack

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-21-96
Time of Determination.....(HRS)	800
Barometric pressure.....(IN.HG)	29.26
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	20
Shape of duct.....	Round
Stack diameter.....(IN)	52
Duct area.....(SQ.FT)	14.75
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.115
Avg. gas temp.....(DEG-F)	288
Moisture content.....(% V/V)	10.78
Avg. linear velocity.....(FT/SEC)	19.8
Gas density.....(LB/ACF)	.05088
Molecular weight.....(LB/LBMOLE)	29.65
Mass flow of gas.....(LB/HR)	53358
Volumetric flow rate.....	
actual.....(ACFM)	17478
dry standard.....(DSCFM)	10761

APPENDIX B

LOCATION OF TEST PORTS



HAYWARD, WI
DRAWING 10
LINE 1
THERMAL OIL HEATER
STACK
ELEVATION

APPENDIX C
FIELD DATA SHEETS

INTERPOLL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Job LP HAWARD
 Source LINE 1 THERMO OIL HEATER STACK
 Test 18 Run 3-21-96 Date 3-21-96
 Stack Dimen. 52 IN.
 Dry Bulb °F Wet bulb °F
 Manometer ☒ Reg. ☐ Exp ☐ Elec.
 Barometric Pressure 29.26 IN.HG
 Static Pressure -.115 IN.WC
 Operators S. BAINVILLE, J. Lorenz
 Pitot No. V2355 C_p .84

Cross-section View	Elevation View
-----------------------	-------------------

Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas
		Port Length: <u>6.5</u> IN.		Time Start: <u>800</u> HRS	
A 1		<u>1.35</u>	<u>7.85</u>	<u>.06</u>	
2		<u>4.26</u>	<u>10.76</u>	<u>.07</u>	
3		<u>7.59</u>	<u>14.09</u>	<u>.075</u>	
4		<u>11.75</u>	<u>18.25</u>	<u>.09</u>	
5		<u>17.79</u>	<u>24.29</u>	<u>.095</u>	
6		<u>34.22</u>	<u>40.71</u>	<u>.105</u>	
7		<u>40.24</u>	<u>46.74</u>	<u>.11</u>	
8		<u>44.41</u>	<u>50.90</u>	<u>.1</u>	
9		<u>47.74</u>	<u>54.24</u>	<u>.105</u>	
10		<u>50.64</u>	<u>57.14</u>	<u>.08</u>	
B 1				<u>.07</u>	
2				<u>.09</u>	
3				<u>.1</u>	
4				<u>.11</u>	
5				<u>.11</u>	
6				<u>.09</u>	
7				<u>.07</u>	
8				<u>.065</u>	
9				<u>.06</u>	
10				<u>.055</u>	
Temp. Meas. Device & S/N:				Time End:	HRS

R or nothing = reg. manometer; S = expanded; E = electronic

460.4
459.3

032594-G:\STACK\WP\FORMS\S-392.1

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP/HAYWARD Date 3-21-96 Test 18 Run 1
Source THE NO. 1 KOKUS STACK No. of traverse points 20
Method 5 Filter holder: 4" GLASS Filter type: GLASS FIBER

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: .00 cfm at 6 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

7989

Recovery solvent(s)

☒ Acetone _____
☐ Other(s) _____

No. of probe wash bottles:

Sample recovered by:

1
3. BATHUR

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	534	486	98
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1425	1418	7
Total			105

Integrated Gas Sampling Data:

Bag Pump No. 27B Box No. 28 Bag No. 1
Bag Material: 5-layer Aluminized Tedlar Size: 44 L
Pretest leak check: 0 cc/min at 400 IN.HG
Time start: 850 (HRS) Time end: 955 (HRS)
Sampling rate: 400 cc/min Operator: JB

S/N of O₂ Analyzer used to monitor train outlet: _____

052394-C-STACKIWP-FORMS-0046Rk

EPA Method 5 Field Data Sheet

Job LP/HAYWARD
Source LTRE. Sub 1 KONS STACK
Date 3-21-96 Test 18 Run 1

**Operators
Meter Box
Gasmeter**

JB/JL
13 A110 1.92 in.WC
1.0023

Nozzle No.
Nozzle Dia.
Bar. Press.

6-5-7

5-7
in. 432
in. fig 29.26

Pilot No.

$$\frac{C_1}{C_2} = \frac{O_1}{O_2}$$

078.10

[illegible]

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP/HAYWARD Date 3-21-96 Test 18 Run 2
 Source LINE NO. 1 KOKINS STACK No. of traverse points 20
 Method 5 Filter holder: 4" glass Filter type: glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: .00 cfm at 6 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

7927

Recovery solvent(s)

☒ acetone☐ other(s)

No. of probe wash bottles:

Sample recovered by:

1
R.R. / J.B. / J.L.

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	564	476	88
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1528	1517	11
Total			99

Integrated Gas Sampling Data:

Bag Pump No.

Bag Material:

Pretest leak check:

Time start:

Sampling rate:

27B
5-layer Aluminized Tedlar
0
1038
400

Box No.

Size:

cc/min at

(HRS) Time end:

cc/min Operator:

28 Bag No. 2
44 L
22 IN.HG
1145 (HRS)
J.B.

S/N of O₂ Analyzer used to monitor train outlet:

052394-C:STACK\WP\FORMS\SS-0046RR

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP/HAYWARD Date 3-21-96 Test 18 Run 3
 Source LTLF No. 1 KOWERS STACK No. of traverse points 20
 Method S Filter holder: 4" GLASS Filter type: GLASS FIBER

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.00 cfm at 5 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

7986

Recovery solvent(s)

☒ Acetone☐ other(s)

No. of probe wash bottles:

Sample recovered by:

1
R.R. / J.B. / J.L.

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	565	486	79
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1436	1425	11
Total			90

Integrated Gas Sampling Data:

Bag Pump No. 27B
 Bag Material: 5-layer Aluminized Tedlar
 Pretest leak check: 0
 Time start: 1210
 Sampling rate: 400

Box No. 28 Bag No. 3
 Size: 44 L
 cc/min at 22 IN.HG
 (HRS) Time end: 1315 (HRS)
 cc/min Operator: DTB

S/N of O₂ Analyzer used to monitor train outlet:

EPA Method 5 Field Data Sheet

5-7

Pilot No. 23v-5

Jobs

LP/HAYWARD

LP/HAYWARD

Operators

Operators JB. / R.O. 12.11.10

Operators JB. / R.D. / 100 in WC

Nozzle No.

1537 in.

U=

078.840

Date	Time	Test	Run	Gasmeter Coeff.	Orifice Meter (in.WC)	Velocity Head (in.WC)	Sample Vol. (cc)	Des. Vol. (cf)	VAC. (in.Hg)	Temperatures (°F)						Oxygen (% v/v)
										Stack	Probe	Oven	Insp.	Gas/In	Gas/Out	
3-21-96	12:10	18	3				(543.63)									
1	3			.065	1.35	5.56	B									
2	6			.07	1.45	7.57	4									
3	9			.08	1.67	9.73	4									
4	12			.08	1.67	1.89	4									
5	15			.100	2.08	4.30	5									
6	18			.130	2.70	7.05	6									
7	21			.128	2.66	9.97	6									
8	24			.122	2.53	2.43	6									
9	27			.105	2.18	4.90	5									
10	30			.094	1.98	7.26	5									
11	33			.097	2.05	9.65	5									
12	36			.114	2.38	2.23	5									
13	39			.120	2.51	4.88	6									
14	42			.125	2.60	7.59	6									
15	45			.115	2.39	0.18	6									
16	48			.126	2.50	2.83	6									
17	51			.106	2.20	5.32	5									
18	54			.088	1.83	7.60	4									
19	57			.060	1.26	9.48	3									
20	60			.075	1.58	1.59	3									
	(1312)															
	60				2.08		V _m = 47.96							Avg. = 65.5		

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP HAYWARDDate 3-21-96 Test 18 Run 4Source LICU KINGS STARKNo. of traverse points 20Method 5 Filter holder: GLASSFilter type: GLASS

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0 cfm at 7 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

7987☒ Acetone☐ Other(s)

No. of probe wash bottles:

Sample recovered by:

1
5. BATHUBS / KNSL

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	618	500	118
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1540	1528	12
Total			140130 SALS 2/28/96

Integrated Gas Sampling Data:

Bag Pump No.

27B

Box No.

28 Bag No. 3

Bag Material:

5-layer Aluminized Tedlar

Size:

44 L

Pretest leak check:

0

cc/min at

22

IN.HG

Time start:

1340

(HRS) Time end:

1445

(HRS)

Sampling rate:

400

cc/min Operator:

SDS/N of O₂ Analyzer used to monitor train outlet:

052394-C:\STACK\WP\FORMS\5-0046RR

(612) ; 6020

EPA Method 5 Field Data Sheet

(c) 29/11/2017

Source LF-6 no 1 K625172K

Date 3-21-96 Test 16 Run 4

5-7

Nozzle No.

Nozzle Dia. .432 in.

Bar. Press.

Pilot No.

.340

H_2O 10 %

[illegible]

APPENDIX D

INTERPOLL LABORATORIES ANALYTICAL RESULTS

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job

Team Leader

ate Submitted

Test No.

Date of Analysis

Source

Test Site

Date of Test

No. of Runs Completed

Technician

UP/HAYWARD
TS
18

Line 1 KONUS
STILL
3-21-96
5
ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
18-1	7451-61	1	0	7.1	14.9	7.1	12.8	
		2	0	7.1	19.9	7.1	12.8	
		Avg				7.1	12.8	
18-2	62	1	0	6.5	19.9	6.5	13.4	
		2	0	6.5	19.9	6.5	13.4	
		Avg				6.5	13.4	
18-3	63	1	0	5.3	20.1	5.3	14.8	
		2	0	5.3	20.1	5.3	14.8	
		Avg				5.3	14.8	
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						

Ambient Air QA Check

Orsat Analyzer System Leak Check

F₀ Within EPA M-3 Guidelines
for fuel type.Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F - Flask (250 cc all glass)

B - Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type

F₀ Range

Coal:

Anthracite/Lignite

1.016-1.130

Bituminous

1.083-1.230

Oil:

Distillate

1.260-1.413

Residual

1.210-1.370

Gas:

Natural

1.600-1.836

Propane

1.434-1.586

Butane

1.405-1.553

Wood/Wood Bark

1.000-1.130

INTERPOL LABORATORIES, INC.

(612) 786-6020

Impinger Catch Data Reporting Sheet

Protocol:

☐ Minnesota ☒ Wisconsin ☐ Iowa☐ EPA Method 202 ☐ Other

Job

LP/Hayward

Source/Site

Line No. 1 Korus / Stack

Date Submitted

3-22-96

Test No.

18

Date of Analysis

3-27-96

Technician

B.O.

		Solvent Phase		Aqueous Phase	
Test: 18	Run: 1	Dish No: 58		Dish No: 703	
Log No: 7451-57I		Dish + Sample Wt: 40.7126 g		Dish + Sample Wt: 46.8705 g	
Color & Appearance:		Dish Tare Wt: 40.7126 g		Dish Tare Wt: 46.8704 g	
		Fraction Wt: 0.0000 g		Fraction Wt: 0.0001 g	
Comments:		Smpl Vol: 200 ml, Alqt: 200 ml, Factor: 1.000		Smpl Vol: 200 ml, Alqt: 100 ml, Factor: 2.000	
		Sample Wt: 0.0000 g		Sample Wt: 0.0002 g	
Test: 18	Run: 2	Dish No: 62		Dish No: 714	
Log No: -58I		Dish + Sample Wt: 50.8913 g		Dish + Sample Wt: 48.6346 g	
Color & Appearance:		Dish Tare Wt: 50.8883 g		Dish Tare Wt: 48.6341 g	
		Fraction Wt: 0.0030 g		Fraction Wt: 0.0005 g	
Comments:		Smpl Vol: 240 ml, Alqt: 240 ml, Factor: 1.000		Smpl Vol: 240 ml, Alqt: 100 ml, Factor: 2.400	
		Sample Wt: 0.0030 g		Sample Wt: 0.0015 g	
Test: 18	Run: 3	Dish No: 65		Dish No: 718	
Log No: -59I		Dish + Sample Wt: 44.6607 g		Dish + Sample Wt: 41.3981 g	
Color & Appearance:		Dish Tare Wt: 44.6570 g		Dish Tare Wt: 41.3909 g	
		Fraction Wt: 0.0037 g		Fraction Wt: 0.0072 g	
Comments:		Smpl Vol: 320 ml, Alqt: 320 ml, Factor: 1.000		Smpl Vol: 320 ml, Alqt: 100 ml, Factor: 3.200	
		Sample Wt: 0.0037 g		Sample Wt: 0.0230 g	
Test: 18	Run: 4	Dish No: 68		Dish No: 728	
Log No: -60I		Dish + Sample Wt: 43.1614 g		Dish + Sample Wt: 42.9810 g	
Color & Appearance:		Dish Tare Wt: 43.1548 g		Dish Tare Wt: 42.9805 g	
		Fraction Wt: 0.0066 g		Fraction Wt: 0.0005 g	
Comments:		Smpl Vol: 310 ml, Alqt: 310 ml, Factor: 1.000		Smpl Vol: 310 ml, Alqt: 100 ml, Factor: 3.100	
		Sample Wt: 0.0066 g		Sample Wt: 0.0016 g	

Note: Factor = Sample Volume/Aliquot Volume

Blank Solvent Wt. 0.0000 g

		RUN 1	RUN 2	RUN 3	RUN 4
Results of Solvent Phase	g	0.0000	0.0030	0.0037	0.0066
Results of Aqueous Phase	g	0.0000	0.0013	0.0228	0.0014

INTERPOL LABORATORIES, INC.
(612) 786-6020
Solvent Rinse Data Reporting Sheet

☒ EPA Method 5 Probe Wash

☐ EPA Method 29 Probe Wash

☐ EPA Method 202 Cup & Tube Wash

Job

LP/HAYWARD

Source/Site

LINE 1 KONGS STACK

Date Submitted

4-4-96

Test No.

18

Date of Analysis

4-4-96

Technician

SCB

Transport Leakage ☐

None ☒

ml

Solvent

Test: <u>18</u>	Run: <u>0</u>	Dish No: <u>23</u>
Log No: <u>7451-56P</u>		Dish + Sample Wt: <u>46.0848</u> g
Volume of Solvent <u>120</u> ml		Dish Tare Wt: <u>46.0847</u> g
*Solvent Residue _____ ug/ml		Sample Wt: <u>.0001</u> g
Test: <u>18</u>	Run: <u>1</u>	Dish No: <u>882</u>
Vol. of Solvent <u>130</u> ml		Dish + Sample Wt: <u>38.1182</u> g
Log Number <u>-57P</u>		Dish Tare Wt: <u>38.0970</u> g
Comments		Sample Wt: <u>.0212</u> g
Test: <u>18</u>	Run: <u>2</u>	Dish No: <u>849</u>
Vol. of Solvent <u>150</u> ml		Dish + Sample Wt: <u>46.5371</u> g
Log Number <u>-58P</u>		Dish Tare Wt: <u>46.5198</u> g
Comments		Sample Wt: <u>.0073</u> g
Test: <u>18</u>	Run: <u>3</u>	Dish No: <u>93</u>
Vol. of Solvent <u>160</u> ml		Dish + Sample Wt: <u>53.9928</u> g
Log Number <u>-58P</u>		Dish Tare Wt: <u>53.9832</u> g
Comments		Sample Wt: <u>.0096</u> g

*Solvent Residue _____ ug/ml = [(Sample Wt. _____ g) (10⁶)]/Vol. of Sol. _____ ml

EPA-M5 Acetone Residue Blank Spec. ≤ 7.8 ug/ml

	<u>✓</u> RUN <u>0</u>	RUN <u>1</u>	RUN <u>2</u>	RUN <u>3</u>
Results of Solvent Rinse	<u>.0001</u>	<u>.0212</u> D-3	<u>.0072</u>	<u>.0095</u>

INTERPOLL LABORATORIES, INC.
(612) 786-6020
Solvent Rinse Data Reporting Sheet

☒ EPA Method 5 Probe Wash ☐ EPA Method 29 Probe Wash ☐ EPA Method 202 Cup & Tube Wash

Job LP/HAYWARD Source/Site LINE 1 KONUS STACK
Date Submitted _____ Test No. 18
Date of Analysis 9-9-96 Technician SLB

Transport Leakage ☐ None ☒ _____ ml Solvent _____

Test: <u>18</u>	Run: <u>7</u>	Dish No: <u>622</u>
Log No: <u>7451-607</u>		Dish + Sample Wt: <u>48.8508</u> g
Volume of Solvent <u>165</u> ml		Dish Tare Wt: <u>48.8492</u> g
*Solvent Residue _____ ug/ml		Sample Wt: <u>.0016</u> g
Test: _____	Run: _____	Dish No: _____
Vol. of Solvent _____ ml		Dish + Sample Wt: _____ g
Log Number _____		Dish Tare Wt: _____ g
Comments _____		Sample Wt: _____ g
Test: _____	Run: _____	Dish No: _____
Vol. of Solvent _____ ml		Dish + Sample Wt: _____ g
Log Number _____		Dish Tare Wt: _____ g
Comments _____		Sample Wt: _____ g
Test: _____	Run: _____	Dish No: _____
Vol. of Solvent _____ ml		Dish + Sample Wt: _____ g
Log Number _____		Dish Tare Wt: _____ g
Comments _____		Sample Wt: _____ g

*Solvent Residue _____ ug/ml = [(Sample Wt. _____ g) (10⁶)] / Vol. of Sol. _____ ml

EPA-M5 Acetone Residue Blank Spec. ≤ 7.8 ug/ml

		<u>✓</u> RUN <u>4</u>	RUN	RUN	RUN
		Results of Solvent Rinse g <u>0.0015</u>	D-4		

INTERPOLL LABORATORIES, INC.
(612) 786-6020
Filter Gravimetrics Reporting Sheet

Filter Type: ☒ EPA Method 5 ☐ EPA Method 29 ☐ EPA Method 202 ☐ Other _____

Job: LP/HAYWARD Source/Site: LINE 1 KONUS STACK
Date Submitted: _____ Test No.: 18
Date of Analysis: 4-8-6 Technician: SLB

Test: <u>1D</u>	Run: <u>0</u>	Filter No: <u>2988</u>	
Field Blank:		Filter Type: <u>4" G.F.</u>	
Log No: <u>7451-56F</u>		Filter + Sample Wt: <u>.9561</u>	g
Color: <u>WHITE</u>		Filter Tare Wt: <u>.8561</u>	g
		Sample Wt: <u>.0000</u>	g
Test: <u>1D</u>	Run: <u>1</u>	Filter No: <u>2989</u>	
Log No: <u>-57F</u>		Filter Type: <u>4" G.F.</u>	
Color: <u>LIGHT TAN</u>		Filter + Sample Wt: <u>.8694</u>	g
		Filter Tare Wt: <u>.8463</u>	g
		Sample Wt: <u>.0231</u>	g
Test: <u>18</u>	Run: <u>2</u>	Filter No: <u>2977</u>	
Log No: <u>-58F</u>		Filter Type: <u>4" G.F.</u>	
Color: <u>LIGHT TAN</u>		Filter + Sample Wt: <u>.9824</u>	g
		Filter Tare Wt: <u>.9597</u>	g
		Sample Wt: <u>.0227</u>	g
Test: <u>18</u>	Run: <u>3</u>	Filter No: <u>2986</u>	
Log No: <u>-59F</u>		Filter Type: <u>4" G.F.</u>	
Color: <u>LIGHT TAN</u>		Filter + Sample Wt: <u>.8771</u>	g
		Filter Tare Wt: <u>.8565</u>	g
		Sample Wt: <u>.0206</u>	g

✓ g/L

	RUN <u>0</u>	RUN <u>1</u>	RUN <u>2</u>	RUN <u>3</u>
Results of Filter Analysis g	.0000	.0231	.0227	.0206

	RUN	RUN	RUN	RUN
Total Mass g				

INTERPOL LABORATORIES, INC.
(612) 786-6020
Filter Gravimetrics Reporting Sheet

Filter Type: ☒ EPA Method 5 ☐ EPA Method 29 ☐ EPA Method 202 ☐ Other _____

Job: LP/HAYWARD Source/Site: Zinc No. 1 KOWUS Stack
Date Submitted: _____ Test No.: 18
Date of Analysis: 4-7-90 Technician: SLD

Test: <u>18</u>	Run: <u>4</u>	Filter No: <u>7987</u>
Field Blank:		Filter Type: <u>4" G.F.</u>
Log No: <u>7951-60F</u>		Filter + Sample Wt: <u>.8761</u> g
Color: <u>GREY</u>		Filter Tare Wt: <u>.8440</u> g
		Sample Wt: <u>.0321</u> g
Test:	Run:	Filter No:
Log No:		Filter Type:
Color:		Filter + Sample Wt: g
		Filter Tare Wt: g
		Sample Wt: g
Test:	Run:	Filter No:
Log No:		Filter Type:
Color:		Filter + Sample Wt: g
		Filter Tare Wt: g
		Sample Wt: g
Test:	Run:	Filter No:
Log No:		Filter Type:
Color:		Filter + Sample Wt: g
		Filter Tare Wt: g
		Sample Wt: g

	RUN	<u>4</u>	RUN	RUN	RUN
Results of Filter Analysis	g	<u>.0321</u>			

	RUN	RUN	RUN	RUN
Total Mass	g			

INTERPOL LABORATORIES, INC.
(612) 786-6020

Sample Chain of Custody

Job Field Engineer L.P. HAYWARD Source L-148 Ab. 1 Knox Site Date of Test 3-21-96 Test No. 18 Log No. 7451 No. of Runs 4

No. Items	Sample Type	Analysis	Sequence No.	Comments
	Probe Wash: ☒ Acetone ☐ DI Water ☐ MeCl ₂	☒ EPA M-5 ☐ EPA M-29	☐ EPA M-201A	
	Filter: ☒ 4" Glass ☐ SS Thimble	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A	☐ EPA M-17	
	Impingers: ☒ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ MN Protocol ☒ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases	☐ IA Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☐	
	Integrated Gas: ☒ Tedlar Bag	☐ EPA M-3	☐ EPA M-10	
	Oxides of Nitrogen:	☐ EPA M-7A		
	Fuel Lab: ☒ Fuel Sample ☐ Aggregate	☐ Per S-0163		
	Particle Sizing:	☐ X-Ray Sdgraph ☐	☐ Cascade Imp	
	Miscellaneous:	☐		

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
Wood: ☒ Wood Waste ☐ Dust ☐ Bark
Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
Misc: ☐ Natural Gas ☐ RDF ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>James Barnard</u>	<u>Interpol</u>	<u>3/22/96 1115</u>

APPENDIX E

OPERATIONAL DATA

HAYWARD LINE 1 THERMAL OIL (REVISED)

<u>CONTENTS</u>	<u>PAGE</u>
TEST SCHEDULES	1
LINE 2 THERMAL OIL , DRYER & PRESS DATA SUMMARY	2
LINE 1 THERMAL OIL HEATER MARCH 21, 1996 PM	
PRODUCTION/SUMMARY	3
PRESS REPORT	4
PRESS CHARTS	5
KONUS DATA SHEETS	6-8
PRESS RTO CHART	9
BOARD WEIGHTS/THICKNESSES	10

HAYWARD TESTING MARCH 21st, 1996
Test schedule

Line 1 Thermal Oil Stack

	<u>POLLUTAN</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
3-21	PM	850-955	1038-1145	1210-1312

HAYWARD LINE 1 TESTING MARCH 21, 1996

Line 1 process data summary

LINE 1 THERMAL OIL HEATER MARCH 21, 1996 - PM

18.73 =Production rate in Tons per hour

0.58 =K3 estimated Tons per hour of fuel burned based on fuel measurement

10.41 =K3 estimated mmBTU per hour input based on fuel measurement

0.88 =K4 estimated Tons per hour of fuel burned based on fuel measurement

15.77 =K4 estimated mmBTU per hour input based on fuel measurement

1.45 =Total tons of dry bark per hour input

26.18 =Total mmBTU per hour input

HAYWARD LINE 1 MARCH 21, 1996

THERMAL OIL STACK - PM

DATA TIME	START=	08:45	END=	08:55	HOURS=	0.17
	START=	09:10	END=	13:15	HOURS=	4.08
					TOTAL=	4.25

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices per unit over the testing period.

7/16"

per/peice 48.77

per/ 8' x 16' 195.07

PLANT PRODUCTION RATE

4.25 =hours during testing

68 =pressloads

816 =no. of 8'x16' boards produced (pressloads x 8 boards per load)

159,179 =lbs of finished product (boards produced x weight of finished board)

37,454 =lbs of finished product per hour (lbs of finished product / hours)

18.73 =tons of finished product per hour (lbs of finished product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY BARK INPUT

K1

13.89 =K1 fuel calibration in pounds per count

589 =K1 counts during testing hours

8,181 =K1 lbs of wet fuel burned during testing

4.25 =hours during testing

39.90% =average moisture content of fuel

4,917 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))

1,156.92 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

0.58 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

9,000 =estimated BTU content per pound of dry fuel,

10.41 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

K2

13.89 =K2 fuel calibration in pounds per count

892 =K2 counts during testing hours

12,390 =K2 lbs of wet fuel burned during testing

4.25 =hours during testing

39.90% =average moisture content of fuel

7,446 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))

1,752.07 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

0.88 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

9,000 =estimated BTU content per pound of dry fuel,

15.77 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

FUEL BURNING RATE ESTIMATED TEMPERATURE DIFFERENTIAL

K1

454.40 =average incoming oil temperature on degrees f.

481.30 =average outgoing oil temperature on degrees f.

60 =temperature differential at 100% capacity in degrees f

26.9 =actual temperature differential

19.4 =maximum mmbtu input at 100% capacity

8.70 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input

9,000 =estimated BTU content per pound of dry fuel,

0.48 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

K2

428.30 =average incoming oil temperature on degrees f.

471.40 =average outgoing oil temperature on degrees f.

60 =temperature differential at 100% capacity in degrees f

43.1 =actual temperature differential

19.4 =maximum mmbtu input at 100% capacity

13.94 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input

9,000 =estimated BTU content per pound of dry fuel,

0.77 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

PRESS REPORT - LINE (1) 2
 OPERATOR M. E. F. S. SHIFT: 7:00 DATE: 2.17.106. CREW: C
 THICKNESS 7/16 PRESS LOS: 196 7/16
 OVERALL TIMER: 157 DECOMPRESSION TIME: 14-1
 PRESS TEMP: 215 TOTAL REJECTS: —

LINE SPEED	THICKNESS	FROM	TO
55	7/16	700	923
58	7/16	923	210
59	7/16	210	700

LOG COUNT: 1435

F.C.O.S. HYD. RADIATOR: 10:00 TIME

PRESS BLOWN DOWN: 9:30

SPINNER HEADS FLUSHED: — TIME

SURFACE BLENDER HOSED: — TIME

FORMER HYD RADIATOR: — TIME

L.S.C.

DOWNTIME		DOWNTIME (MINS)			K E Y	REASONS FOR DOWNTIME
FROM	TO	M	E	O		
—	—	—	—	—	—	Repaired torn screen.
9:00	9:18	—	18	—	—	Fuse blown for Loader Boom Brake.
						Kept tripping out Loader Boom.

DOWNTIME CODE:


M - MECHANICAL

(18)

E - ELECTRICAL

O - OPERATOR

LINE I
PRESS CHART
3/21/96
0700 - 1500



KONUS DATA READINGS EVERY 10 MINUTES

PLANT Hayward LP

BY Pat m DATE 3-21-96 PAGE 1 OF 1

TIME	K1			K2			K3			K4			FUEL				ONCE/HR BANK MOISTURE
	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/G	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/G	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/G	OIL IN TEMP	OIL OUT TEMP	I.D. FAN W/G	K1	K2	K3	K4	
8:30	234	253	-0.4	219	233	-3							333	412			40.1
8:45	233	251	-0.4	219	241	-2.6							560	472			39.6
9:00	235	254	-0.3	221	247	-2.2							418	514			39.8
9:15	239	256	-0.4	219	253	-2.0							457	561			40.5
9:30	234	258	-0.4	225	250	-2.4							490	605			39.3
9:45	232	250	-0.4	219	245	-2.2							528	661			40.2
10:00	232	244	-0.4	219	244	-2.4							556	702			40.3
10:15	232	246	-0.4	219	240	-2.4							593	757			39.6
10:30	232	244	-0.4	216	238	-2.4							629	816			
10:45	233	256	-0.4	220	242	-2.2							672	973			
11:00	236	256	-0.4	223	249	-2.4							717	929			
11:15	246	257	-0.4	227	248	-2.4							770	997			
11:30	235	254	-0.4	220	239	-2.6							819	1059			
11:45	236	253	-0.4	221	244	-2.4							864	1106			
12:00	237	256	-0.4	224	251	-2.2							911	1145			
12:15	235	247	-0.4	221	246	-2.2							953	1184			
12:30	232	241	-0.4	217	237	-2.4							1004	1221			
12:45	233	241	-0.5	218	242	-2.4							1050	1278			
1:00	234	240	-0.5	218	241	-2.4							1105	1325			
1:15	231	241	-0.5	216	237	-2.6							1149	1364			
1:30	234	252	-0.4	220	243	-2.4							1201	1422			
1:45	234	254	-0.4	220	244	-2.4							1251	1475			
2:00	238	256	-0.4	225	246	-2.2							1291	1524			
2:15	235	255	-0.5	225	249	-2.2							1335	1586			
2:30	241	256	-0.4	229	251	-2.2							374	1631			
2:45	234	250	-0.5	221	250	-1.6							416	1685			
3:00	234	253	-0.4	220	248	-2.2							458	1729			

Konus EFB Readings

Plant Hayward L.P.
readings every 10 minutes

date 3-21-06 Page 1 of 1
by Pat m

time	K1 and K2						K3 and K4					
	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.
8:30	11.5	1.4	30	3.8	0.8	3.5						
8:45	9.5	1.4	28	3.8	1.6	2.5						
9:00	12.0	1.6	28	3.6	2.0	2.0						
9:15	12.0	1.4	28	3.4	2.2	2.5						
9:30	12.0	1.4	28	3.6	1.2	2.5						
9:45	12.0	1.6	28	3.6	2.4	2.0						
10:00	12.0	1.6	29	3.6	2.6	2.0						
10:15	12.0	1.6	28	3.6	2.6	2.0						
10:30	12.0	1.6	28	3.8	2.6	2.0						
10:45	11.5	1.6	28	3.8	2.0	2.5						
11:00	11.5	1.8	27	4.0	1.8	2.0						
11:15	11.5	2.0	27	4.0	1.8	2.5						
11:30	11.5	2.0	27	3.6	1.8	2.0						
11:45	10.0	2.8	27	4.0	2.0	2.5						
12:00	11.5	2.0	28	3.4	2.2	2.5						
12:15	11.5	2.0	27	3.4	2.0	2.5						
12:30	11.3	1.8	27	3.6	2.4	2.0						
12:45	11.5	1.8	27	3.6	2.6	2.0						
1:00	9.0	1.6	27	3.8	2.4	2.5						
1:15	11.5	1.6	27	3.8	2.2	2.5						
1:30	11.5	1.8	28	3.6	2.0	2.5						
1:45	9.5	2.2	29	3.8	2.0	2.5						
2:00	11.5	2.0	29	3.8	2.0	2.0						
2:15	11.6	2.0	28	3.6	2.2	2.5						
2:30	11.0	2.0	29	3.6	2.0	2.0						
2:45	11.0	2.2	26	3.8	2.0	2.5						
3:00	11.0	2.0	28	3.8	2.0	2.5						

SHIFT: (1) OR II
LINES 1 & 2

K-1 - K-2

Bed Voltage (KV)
Bed Amperage (MA)
Ionizer Voltage (KV)
Ionizer Amperage (MA)
EFB Pressure Drop (In.)
Inlet Temperature
Outlet Temperature
Rock Flow
Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
13	12.5	12	12	11.5	11.5	11.5	11.5	10	11	11	11
108	110	114	115	117	120	114	118	120	121	122	122
27	28	28	27	29	29	28	29	28	28	28	26
30	32	34	38	39	34	36	38	40	36	30	34
0	17	17	22	26	27	24	21	20	18	16	16
378	375	406	411	416	418	403	411	418	419	420	419
290	297	303	312	320	323	323	323	327	327	330	329
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

K-3 - K-4

Bed Voltage (KV)
Bed Amperage (MA)
Ionizer Voltage (KV)
Ionizer Amperage (MA)
EFB Pressure Drop (In.)
Inlet Temperature
Outlet Temperature
Rock Flow
Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
6.5	6.5	6.5	6.5	6.5	6.5	6.5	7	7	7	7	7
120	120	120	118	118	118	120	120	116	118	118	117
21	21	21	21	20	20	21	21	21	21	21	21
2.0	2.0	2.0	2.1	2.1	2.0	2.0	2.2	2.0	2.0	2.1	2.2
104	104	105	104	104	104	105	104	104	104	104	104
499	475	484	449	437	439	443	435	449	453	448	430
395	398	396	397	403	403	407	403	404	405	407	400
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

Baghouse
Pressure
Drop: (in.)

	7	8	9	10	11	12	1	2	3	4	5	6
L-I	2.4	2.3	2.5	2.4	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.1
L-II	4.8	4.8	4.8	4.7	4.7	4.7	4.4	4.4	4.6	4.4	4.4	4.6

Comments/Problems: _____

*Condition Codes

- 1) Start up/shutdown
- 2) Konus down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Konus on oil
- 8) Maintenance

VOLUME PER SHIFT

LINE I	1 1/2
LINE II	1 1/2

123456789101112131415161718192021222324252627282930313233343536373839404142434445464748495051525354555657585960616263646566676869707172737475767778798081828384858687888990919293949596979899100

DATE: 3-21-96 - 1
 SHIFT/CREW: 7th ^{DR} C
 OPERATOR: ATKINSON

3/21 1-3
 26 114718

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
716	#4206	39 3/4	76	36	39 3/4
2	called	39 3/4	37		39 1/2
3		40	38		39 5/8
4	#4208	39 5/8	39		39 1/2
5		40	40	#4376	39 5/8
6		40	41		39 1/2
7	called	40	42		39 5/8
8	#4411	40 1/4	43		39 1/2
9		39 7/8	44	#4436	39 1/2
10		39 1/2	45		39 1/2
11		39 1/2	46		39 3/4
12	#4318	39 1/2	47		39 1/4
13		39 1/2	48	#4569	39 3/4
14		39 1/2	49		39 3/4
15		39 1/2	50		39 3/4
16	#4412	39 1/2	51		39 3/4
17		39 1/2	52	#4451	39 1/2
18		39 1/2	53		39 3/4
19		39 3/4	54		39 3/8
20	#4442	39 1/2	55		39 3/4
21		39 1/2	56	4360	39 1/2
22		39 1/2	57		39 3/4
23		39 1/2	58		39 1/2
24	#4430	39 1/2	59		39 3/4
25		39 3/8	60	4331	38 3/4
26		39 1/2	61		39 1/2
27		39 1/4	62		39 1/2
28	#4446	39 1/2	63		39 1/2
29		39 1/2	64	#4379	39 1/2
30		39 1/2	65		39 3/4
31		39 3/8	66		39 1/2
32	#4453	39 3/8	67	called	40
33		39 3/4	68	4342	40
34		39 5/8	69		39 3/8
35		39 3/4	70		39 1/2

APPENDIX F

PROCEDURES

Particulate Loading and Emission Rates

The particulate emission rates were determined per EPA Methods 1 - 5, CFR Title 40, Part 60, Appendix A (revised July 1, 1992). In this procedure a preliminary velocity profile of the gases in the flue is obtained by means of a temperature and velocity traverse. On the basis of these values, sampling nozzles of appropriate diameter are selected to allow isokinetic sampling, a necessary prerequisite for obtaining a representative sample.

The sampling train consists of a heated glass-lined sampling probe equipped with a Type S pitot and a thermocouple. The probe is attached to a sampling module which houses the all-glass in line filter holder in a temperature controlled oven. The sampling module also houses the impinger case and a Drierite filled column. The sampling module is connected by means of an umbilical cord to the control module. The control module houses the dry test gas meter, the calibrated orifice, a leakless pump, two inclined manometers, and all controls required for operating the sampling train.

Particulate samples are collected as follows: The sample gas is drawn through the sampling probe isokinetically and passed through a 4-inch diameter Gelman Type A/E glass fiber filter where particulates are removed. The sample gas is then passed through an ice-cooled impinger train and a desiccant-packed column which absorbs remaining moisture. The sample gas then passes through a vacuum pump followed by a dry test gas meter. The gas meter integrates the sample gas flow throughout the course of the test. A calibrated orifice attached to the outlet of the gasmeter provides real time flow rate data.

A representative particulate sample was acquired by sampling for equal periods of time at the centroid of a number of equal area regions in the duct. The sampling rate is adjusted at each test point maintaining isokinetic sampling conditions. Nomographs are used for rapid determination of the sampling rate.

Particulate Loading and Emission Rates

After sampling is complete, the filter is removed and placed in a clean container. The nozzle and inlet side of the filter holder are quantitatively washed with acetone and the washings are stored in a second container. A brush is often used in the cleaning step to help dislodge deposits. The samples are returned to the laboratory where they are logged in and analyzed. The volume of the acetone rinse ("probe wash") is noted and then the rinse is quantitatively transferred to a tared 120 cc porcelain evaporating dish and the acetone evaporated off at 97-105 °F. This temperature is used to prevent condensation of atmospheric moisture due to the cooling effect induced by the evaporation of acetone. The acetone-free sample is then transferred to an oven and dried at 105 °C for 30 minutes, cooled in a desiccator over Drierite, and then weighed to the nearest .01 mg. The filter sample is quantitatively transferred to a 6-inch watch glass and dried in an oven at 105 °C for two hours. The filter and watch glass are then cooled in a desiccator and the filter weighed to the nearest .01 mg. All weighings are performed in a balance room where the relative humidity is hydrostatted to less than 50% relative humidity. Microscopic examination of the samples is performed if any unusual characteristics are observed. The weight of the acetone rinse is corrected for the acetone blank. The Drierite column is weighed on-site and the water collected by Drierite is added to the condensate so that the total amount of absorbed water may be ascertained.

Integrated flue gas samples for Orsat analysis were collected simultaneously with each pollutant sample. The samples were collected in 15-liter gas sampling bags at a constant flow rate throughout each particulate run. The bags were at a constant flow rate throughout each particulate run. The bags were then returned to the laboratory and analyzed by Orsat analysis. Standard commercially prepared solutions were used in the Orsat analyzer (sat. KOH for carbon dioxide and reduced methylene blue for oxygen).

Condensible Organic Compounds Analysis

(State of Wisconsin - EPA Method 5)

Method II-8672-WI

Equipment: Separatory funnel - 500 cc with Teflon stopcock

Powder funnel - 75 mm ID with a glass wool plug

Evaporating dish(es) - 200 cc or 250 cc beaker

Reagents: Methylene chloride

Sodium sulfate - (ACS) granular anhydrous (purified by heating for four hours in a shallow tray)

SAMPLING

An all-glass impinger assembly is used in the back half of the EPA Method 5 sampling train when an organic wet catch is to be collected. The impinger assembly consists of a modified impinger, a Greenburg Smith impinger followed by another modified impinger. The third impinger should have a temperature measuring device at the outlet upstream of a final impinger or desiccant column to monitor the temperature of the outlet gas stream. Prior to the start of the test, each of the first two impingers should be charged with 100 g of Class I water. The Method 5 train should be operated as provided for in EPA Method 5. Ice should be added to the impinger bath to keep the temperature of the gas at the outlet at or less than 68°F. After the post test leak check, the impinger train is removed and impinger contents poured into a tared all-glass sample bottle and closed with a Teflon-lined cap. The sample bottle is then weighed and the total condensate calculated by subtraction of the bottle tare weight and the weight of initial water added to the impingers (200 g). A label is affixed and the sample is returned to the laboratory for analysis. The sample should be stored at 4°C if the analysis is not conducted within 48 hours.

030894-G:\STACK\WPMETHODS\II-8672.WI

ANALYSIS

1. Sample bottles are removed from storage and the contents quantitatively transferred to a clean 500 cc separatory funnel equipped with a Teflon stopcock.
2. Rinse the sample container with distilled water and add to separatory funnel.
3. Then rinse the sample container with acetone and pour through sodium sulfate into a tare beaker marked A.
4. The sample is then extracted consecutively with three 50 cc aliquots of methylene chloride. The extraction is performed according to normal laboratory practice observing the customary safety precaution of releasing excess pressure after each shaking.
5. After each of the three extractions are completed, the organic solvent should be dried by passing it through a funnel containing anhydrous sodium sulfate and collecting it and two 50 cc rinses in the tared beaker marked A (the same one used to catch the acetone container rinse).
6. Evaporate to dryness in a hood at 70°F or less. Do not evaporate so quickly as to allow evaporative cooling to lower the temperature of the container below the dew point otherwise water will be condensed in the container.
7. Desiccate for two hours in a sealed desiccator and final weigh. Report all results in grams. All weighings should be made to nearest 0.1 mg (four places).
8. The remaining liquid in the separatory funnel is then transferred to a tared beaker marked B and is evaporated to dryness at $220^{\circ}\text{F} \pm 10^{\circ}\text{F}$. The analyst may take an aliquot of the sample, transferring it to a tared beaker and evaporate to dryness at $220^{\circ}\text{F} \pm 10^{\circ}\text{F}$. If an aliquot is used, the weight of the sample and aliquot will have to be taken to correct for the total sample weight.

030894-G:STACK\WPMETHODS\II-8672.WI

9. After the drying step, the sample is cooled in a desiccator and weighted to a constant weight to the nearest 0.1 mg.

Calculation (if aliquot is taken):


$$\text{grams} = \frac{(\text{grams recovered from aliquot}) \times (\text{total volume (ml) or grams of sample})}{(\text{aliquot volume (ml) or grams used})}$$

If volume is used, it must be used for both the aliquot and sample. The same goes for using weight.

10. A field blank should be analyzed in an identical manner. If a field blank is not submitted, take an aliquot of Class I water equal in volume to the samples and analyze in a similar manner.
11. The results for container A are to be marked in the organic section of Interpoll Form #LSC-03G.
12. The results for container B are to be marked in the inorganic section of Interpoll Form #LSC-03G.

PARTICULATE SAMPLING TRAIN

MPNGER TRAIN OPTIONAL. MAY BE REPLACED
BY AN EQUIVALENT CONDENSER



APPENDIX G

CALCULATION EQUATIONS

METHOD 2
CALCULATION EQUATIONS

$$\bar{V}_s = 85.49 C_p (\sqrt{\Delta p})_{avg} \sqrt{\frac{T_{s(avg)}}{P_s M_s}}$$

$$Q_{s,d} = 60 (1 - B_{ws}) \bar{V}_s A \left(\frac{528}{T_{s(avg)}} \right) \left(\frac{P_s}{29.92} \right)$$

$$Q_a = 60 \bar{V}_s A$$

$$\dot{m}_s = \frac{4.995 Q_{s,d} G_d}{1 - B_{ws}}$$

$$RH^* = 100 (vp_{twb} - 0.0003641 P_s (T_{db} - T_{wb})) / vp_{tdb}$$

$$B_{ws}^* = RH(vp_{tdb}) / P_s$$

$$\rho = \frac{4.585 \times 10^{-2} P_s M_s}{T_s (avg)}$$

*Alternate equations for calculating moisture content from wet bulb and dry bulb data.

SYMBOLS

A	=	Cross Sectional area of stack, SQ. FT.
A_n	=	Cross sectional area of nozzle, SQ. FT.
B_{ws}	=	Water vapor in gas stream, proportion by volume
C_p	=	Pitot tube coefficient, dimensionless
C_a	=	Concentration of particulate matter in stack gas, wet basis, GR/ACF
C_s	=	Concentration of particulate matter in stack gas, dry basis, corrected to standard conditions, GR/DSCF
EA	=	Excess air, percent by volume
γ	=	Dry test meter correction factor, dimensionless
G_d	=	Specific gravity (relative to air), dimensionless
I	=	Isokinetic variation, percent by volume
M_d	=	Molecular weight of stack gas, dry basis, g/g - mole.
m_g	=	Mass flow of wet flue gas, LB/HR
m_p	=	Particulate mass flow, LB/HR
M_s	=	Molecular weight of stack gas, wet basis, g/g mole.
M_p	=	Total amount of particulate matter collected, g
P_{bar}	=	Atmospheric pressure, IN. HG. (uncompensated)
P_g	=	Stack static gas pressure, IN. WC.
P_s	=	Absolute pressure of stack gas, IN. HG.
P_{std}	=	Standard absolute pressure, 29.92 IN. HG.
A_a	=	Actual volumetric stack gas flow rate, ACFM
$Q_{s, d}$	=	Dry volumetric stack gas flow rate corrected to standard conditions, DSCFM
RH	=	Relative humidity, %

032294-G:\STACK\WPMETHODS\SS-EQ.15

T_{db}	=	Dry bulb temperature of stack gas, °F
T_{wb}	=	Wet bulb temperature of stack gas, °F
$T_{m(avg)}$	=	Absolute average dry gas meter temperature, °R
$T_{s(avg)}$	=	Absolute average stack temperature, °R
T_{std}	=	Standard absolute temperature, 528 °R (68 °F)
θ	=	Total sampling time, min.
V_{lc}	=	Total volume of liquid collected in impingers and silica gel, ml
V_m	=	Volume of gas sample as measured by dry gas meter, CF
$V_{m(std)}$	=	Volume of gas sample measured by the dry gas meter corrected to standard conditions, DSCF
$V_{w(std)}$	=	Volume of water vapor in the gas sample corrected to standard conditions, SCF
$\bar{V}_s$	=	Average actual stack gas velocity, FT/SEC
vp_{tdb}	=	Vapor pressure at T_{db} , IN. HG.
vp_{twb}	=	Vapor pressure at T_{wb} , IN. HG.
$\overline{\Delta H}$	=	Average pressure differential across the orifice meter, IN. WC.
ΔP	=	Velocity pressure of stack gas, IN. WC.
γ	=	Dry test meter correction coefficient, dimensionless
ρ	=	Actual gas density, LB/ACF

METHOD 3
CALCULATION EQUATIONS

$$\%EA = \frac{100(\%O_2 - 0.5\% CO)}{0.264\% N_2 - \%O_2 + 0.5\% CO}$$

$$M_d = 0.44(\%CO_2) + 0.32 (\%O_2) + 0.28 (\%N_2 + \%CO)$$

$$M_s = M_d (I - B_{ws}) + 0.18 B_{ws}$$

$$B_{ws} = \frac{V_{w(std)}}{V_{w(std)} + V_{m(std)}}$$

METHOD 5
CALCULATION EQUATIONS

$$V_{m(std)} = 17.65 V_m \gamma \left(\frac{P_{bar} + \overline{\Delta H}/13.6}{T_{m(avg)}} \right)$$

$$V_{w(std)} = 0.0472 V_L$$

$$B_{ws} = \frac{V_{w(std)}}{V_{w(std)} + V_{m(std)}}$$

$$I = 0.0944 \left(\frac{T_{s(avg)} V_{m(std)}}{P_s V_s A_n \theta (I - B_{ws})} \right)$$

$$C_s = \frac{15.43 M_p}{V_{m(std)}}$$

$$C_a = \frac{272.3 M_p P_s}{T_{s(avg)} (V_{w(std)} + V_{m(std)})}$$

$$(\dot{m}_p)_1 = 8.5714 \times 10^{-3} C_s Q_{s,d}$$

$$(\dot{m}_p)_2 = \frac{1.3228 \times 10^{-1} M_p A}{\theta A_n}$$

$$\dot{m}_p = \frac{(\dot{m}_p)_1 + (\dot{m}_p)_2}{2}$$

APPENDIX H

SAMPLING TRAIN CALIBRATION DATA

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job LP HAYWARD Date 3-21-96
Operator S. BAEVILE S. LONCE Module No. 13

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 29.26 in.Hg $\theta =$ 1.0023 $\Delta H@$ 1.82 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(450.90)		
2.5	452.74	32	18
5.0	454.57	36	19
7.5	456.36	37	20
10	458.14	40	21
	$V_m = 7.24$	$Avg(t_m) = 27.9$	°F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(t_m + 460)}{P_s} \right]^{0.5}$$

$\frac{1.786}{(1.0023)(7.24)} \left[\frac{(27.9 + 460)}{(29.26)} \right]^{0.5}$

$Y_m = 1.005$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: March 26, 1996

Meter Box No. : 13 (Rockwell Dry Test Meter Serial No. 1334119)

Date of Last Calibration: January 5, 1996

Calibration Technician: S. Fjelsta

Wet Test Meter No.: American Meter AL-20

Date of Use	Report No.	Initial Meter Reading	Final Meter Reading	Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
March 19, 1996	6-7451	315.18	639.72	324.54	324.54

* Total volume through meter since last calibration.

INTERPOL LABORATORIES, INC.
(612) 786-6020

Meter Calibration Sheet EPA/Method 5

Date:

1-5-5-1

Date 1-5-75 IN.HC
Bar. Press. 27.60

Control Module No.

Serial No. DTM

Wet Test Meter No.

AL-20

Technician

[illegible]

Positive leak check performed by

Positive leak check performed
Meter was in tolerance

Positive leak
Meter was in
Approved by

Positive leak check performed by
Meter was in tolerance
Approved by SF
[Signature]
*Based on AL-20 wet meter calibration in Nov. 1991 against Bell Prover

Meter was not in tolerance

Meter was not in tolerance

Date _____

☐: readjusted linkage
☐: changed dry test meter

erance
1/5/96

*Based on AL-20 wet test meter calibration in Nov. 1991 against Bell Prover (NBS Traceable) - Carl Poe Co.

031794-G:\STACK\WP\FORMS\5-0102RR

S-Type Pitot Tube Inspection Sheet

Pitot Tube No 23-5

Pitot tube dimensions:

1. External tubing diameter (D_t) _____, 3.16 IN.
2. Base to Side A opening plane (P_A) _____, 4.60 IN.
3. Base to Side B opening plane (P_B) _____, 4.60 IN.

Alignment:

4. α_1 < 10° 0
5. α_2 < 10° 0

6. B_1 < 5° 0
7. B_2 < 5° 0

8. Z < .125" .02
9. W < .0625" .01

Distance from Pitot to Probe Components:

10. Pitot to 0.500 IN. nozzle _____, 7.60 IN.
11. Pitot to probe sheath _____, 3.0 IN.
12. Pitot to thermocouple (parallel to probe) _____, 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) _____, 7.60 IN.

- ☒ Meets all EPA design criteria thus $C_p = 0.84$
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
 $C_p =$ _____

Date of Inspection:

2-8-94

Inspected by:

[Signature]


Interpoll Laboratories
(612) 786-6020

Nozzle Calibration Data Sheet

Date of Calibration: 03-21-96
Technician: Jamie Bainville
Nozzle Number: 5-7

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	0.432
2	0.431
3	0.432
Average	0.432



Data obtained on an American Bell-prover, Serial No. 2260, traceable to the Bureau of Standards. Reference No. 106870, PI-TAPE.

AL-17	American Mel	Test Meter
	Serial No. p-718	
	Stainless Steel w/Removable Back	
	Calibrated with Saturated Air	
	Water Temp. 74° F.	
	Air Temp. 74° F.	
	Inlet Pressure 2" H ₂ O. Constant	
	Calibration Rate: 4 CFH Air	
	Capacity Rate: 8 CFH Air	
	Restricted Outlet for Rate Deviation.	

CORRECT VOLUME = INDEX READING x PROOF ÷ 100

8 10
FLOW RATE - CUB FEET OF AIR PER HOUR

DAVID BANKS
AUGUST, 1989

Interpoll Laboratories, Inc.
4500 Ball Road N.E.
Circle Pines, Minnesota 55014-1819

TEL: (612) 786-6020
FAX: (612) 786-7854

**RESULTS OF THE MARCH 21, 1996
AIR EMISSION COMPLIANCE TEST OF THE
LINE 1 THERMAL OIL HEATER AT THE
LOUISIANA PACIFIC PLANT IN
HAYWARD, WISCONSIN**

Submitted to:

LOUISIANA-PACIFIC CORPORATION
Route 8, Box 8263
Hayward, Wisconsin 54843

Attention:

Keith Seelig

Approved by:



Daniel Despen
Manager
Stationary Source Testing Department

Report Number 6-7451E
April 24, 1996
SL/sll

TABLE OF CONTENTS

ABBREVIATIONS	iii
1 INTRODUCTION	1
2 SUMMARY AND DISCUSSION	3
3 AIR EMISSION RESULTS	6
3.1 Orsat and Moisture Analyses	7
3.2 Results of Particulate Determinations	9
4 RESULTS OF FUEL ANALYSIS	11

APPENDICES:

- A - Preliminary Volumetric Flow Rate Determination
- B - Location of Test Ports
- C - Field Data Sheets
- D - Interpoll Laboratories Analytical Data
- E - Operational Data
- F - Procedures
- G - Calculation Equations
- H - Sampling Train Calibration Data

ABBREVIATIONS

ACFM	actual cubic feet per minute
cc (ml)	cubic centimeter (milliliter)
DSCFM	dry standard cubic foot of dry gas per minute
DSML	dry standard milliliter
DEG-F (°F)	degrees Fahrenheit
DIA.	diameter
FP	finished product for plant
FT/SEC	feet per second
g	gram
GPM	gallons per minute
GR/ACF	grains per actual cubic foot
GR/DSCF	grains per dry standard cubic foot
g/dscm	grams per dry standard cubic meter
HP	horsepower
HRS	hours
IN.	inches
IN.HG.	inches of mercury
IN.WC.	inches of water
LB	pound
LB/DSCF	pounds per dry standard cubic foot
LB/HR	pounds per hour
LB/10 ⁶ BTU	pounds per million British Thermal Units heat input
LB/MMBTU	pounds per million British Thermal Units heat input
LTPD	long tons per day
MW	megawatt
mg/Nm ³	milligrams per dry standard cubic meter
ug/Nm ³	micrograms per dry standard cubic meter
microns (um)	micrometer
MIN.	minutes
ng	nanograms
ohm-cm	ohm-centimeter
PM	particulate matter
PPH	pounds per hour
PPM	parts per million
ppmC	parts per million carbon
ppm,d	parts per million, dry
ppm,w	parts per million, wet
ppt	parts per trillion
PSI	pounds per square inch
SQ.FT.	square feet
TPD	tons per day
ug	micrograms
v/v	percent by volume
w/w	percent by weight
<	≤ (when following a number)

Standard conditions are defined as 68°F (20°C) and 29.92 IN. of mercury pressure.

1 INTRODUCTION

On March 21, 1996 Interpoll Laboratories personnel conducted a particulate emission compliance test of the Line 1 Thermal Oil Heater at the Louisiana Pacific Plant in Hayward, Wisconsin. On-site testing was performed by Jamie Bainville and Jim Lorenz. Coordination between testing activities and plant operation was provided by Keith Selig of Louisiana Pacific Corporation. The tests were not witnessed by a member of the Wisconsin Department of Natural Resources.

Particulate determinations were performed in accordance with EPA Methods 2 - 5, CFR Title 40, Part 60, Appendix A (revised July 1, 1995). A preliminary volumetric flow rate determination was performed to select the appropriate nozzle diameter required for isokinetic sample withdrawal. An Interpoll Labs sampling train which meets or exceeds specifications in the above-cited reference was used to extract particulate samples by means of a heated glass-lined probe. Wet catch samples were collected in the back half of the Method 5 sampling train and analyzed as per Wisconsin DNR Protocol.

An integrated flue gas sample was extracted simultaneously with the particulate sampling train using a specially designed gas sampling system. Integrated flue gas samples were collected in 44-liter Tedlar bags housed in a protective aluminum container. After sampling was complete, the bags were sealed and returned to the laboratory for Orsat analysis. Prior to sampling, the Tedlar bags are leak-checked at 15 IN.HG. vacuum with an in-line rotameter. Bags with any detectable in-leakage are discarded.

Testing was conducted from two test ports oriented at 90° on the stack. These test ports are located approximately 4.8 diameters downstream and 2.3 diameters upstream of the nearest flow disturbance. A 20-point traverse was used to collect representative particulate samples. Each traverse point was sampled 3 minutes to give a total sampling time of 60 minutes per run.

The important results of the test are summarized in Section 2. Detailed results are presented in Section 3. Field data and all other supporting information are presented in the appendices.

2 SUMMARY AND DISCUSSION

The results of the air emission compliance tests are summarized in Table 1. An overview of the results is presented in the table below:

<u>Parameter</u>	<u>Measured</u>
Particulate	
(Dry + Wet Catch)	
..... (GR/DSCF)	0.0147
..... (LB/10 ⁶ BTU)	0.056
(Dry Catch Only)	
..... (GR/DSCF)	0.010
..... (LB/10 ⁶ BTU)	0.040

The wet catch portion of the first sampling run was accidentally spilled during recovery, therefore, this run was voided by the Interpoll Laboratories field engineer. An additional test run was performed immediately following the third test run. No other difficulties were encountered in the field or in the laboratory evaluation of the samples. On the basis of these facts and a complete review of the data and results, it is our opinion that the results reported herein are accurate and closely reflect the actual values which existed at the time the test was performed.

Table 1a Summary of the Results of the March 21, 1996 Particulate Emission Test of the Line 1 Thermal Oil Heater Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	03-21-96	03-21-96	03-21-96
Time runs were done (HRS)	1038/1145	1210/1312	1340/1445
Steam flow (KLB/HR)			
Volumetric flow (ACFM)	17922	19125	19072
standard (DSCFM)	10922	11762	11338
Gas temperature (DEG-F)	306	310	308
Moisture content (%V/V)	9.62	8.21	11.53
Gas composition (%V/V, dry)			
carbon dioxide	7.10	6.50	5.30
oxygen	12.80	13.40	14.80
nitrogen	80.10	80.10	79.90
Isokinetic variation (%)	97.0	97.5	100.2
Particulate concentration			
actual (GR/ACF)	.007330	.0113	.00811
standard (GR/DSCF)	.0120	.0184	.0136
Part. emission rate (LB/HR)	1.13	1.86	1.33
Emission factor (LB/MMBTU)	0.041	0.067	0.061

Note: Dry + Organic/Inorganic Wet Catch

Table 1b Summary of the Results of the March 21, 1996 Particulate Emission Test of the Line 1 Thermal Oil Heater Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	03-21-96	03-21-96	03-21-96
Time runs were done (HRS)	1038/1145	1210/1312	1340/1445
Steam flow (KLB/HR)			
Volumetric flow actual (ACFM)	17922	19125	19072
standard (DSCFM)	10922	11762	11338
Gas temperature (DEG-F)	306	310	308
Moisture content (%V/V)	9.62	8.21	11.53
Gas composition (%V/V, dry)			
carbon dioxide	7.10	6.50	5.30
oxygen	12.80	13.40	14.80
nitrogen	80.10	80.10	79.90
Isokinetic variation (%)	97.0	97.5	100.2
Particulate concentration actual (GR/ACF)	.006409	.006016	.00655
standard (GR/DSCF)	.0105	.009786	.0110
Part. emission rate (LB/HR)	0.985	0.987	1.07
Emission factor (LB/MMBTU)	0.035	0.036	0.049

Note: Dry Catch Only

3 RESULTS

The results of all field and laboratory evaluations are presented in this section. Gas composition (Orsat and moisture) are presented first followed by the computer printout of the particulate results. Preliminary measurements including test port locations are given in the appendices.

The results have been calculated on a personal computer using programs written in Extended BASIC specifically for source testing calculations. EPA-published equations have been used as the basis of the calculation techniques in these programs. The particulate emission rate has been calculated using the product of the concentration times flow method.

3.1 Orsat & Moisture Analyses

Test No. 18
Line 1 Thermal Oil Heater Stack

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

	Run 1	Run 2	Run 3
Date of run	03-21-96	03-21-96	03-21-96

Dry basis (orsat)

carbon dioxide.....	7.10	6.50	5.30
oxygen.....	12.80	13.40	14.80
nitrogen.....	80.10	80.10	79.90

Wet basis (orsat)

carbon dioxide.....	6.42	5.97	4.69
oxygen.....	11.57	12.30	13.09
nitrogen.....	72.39	73.53	70.69
water vapor.....	9.62	8.21	11.53
Dry molecular weight.....	29.65	29.58	29.44
Wet molecular weight.....	28.53	28.63	28.12
Specific gravity.....	0.985	0.989	0.971
Water mass flow.....(LB/HR)	3261	2950	4145

FO	1.141	1.154	1.151
----	-------	-------	-------

3.2 Results of Particulate Determinations

Test No. 18
Line 1 Thermal Oil Heater Stack

Results of Particulate Loading Determinations-----Method 5

	Run 1 03-21-96	Run 2 03-21-96	Run 3 03-21-96
Date of run			
Time run start/end.....(HRS)	1038/1145	1210/1312	1340/1445
Static pressure.....(IN.WC)	-0.12	-0.12	0.00
Cross sectional area (SQ.FT)	14.75	14.75	14.75
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	88.0	79.0	118.0
desiccant.....(GRAMS)	11.0	11.0	12.0
total.....(GRAMS)	99.0	90.0	130.0
Total particulate material..collected(grams)	0.0342	0.0566	0.0416
Gas meter coefficient.....	1.0023	1.0023	1.0023
Barometric pressure..(IN.HG)	29.26	29.26	29.26
Avg. orif.pres.drop..(IN.WC)	1.75	2.08	2.04
Avg. gas meter temp..(DEF-F)	58.0	65.5	67.6
Volume through gas meter....			
at meter conditions...(CF)	43.72	47.96	47.72
standard conditions.(DSCF)	43.86	47.46	47.03
Total sampling time....(MIN)	60.00	60.00	60.00
Nozzle diameter.....(IN)	.432	.432	.432
Avg.stack gas temp ..(DEG-F)	306	310	308
Volumetric flow rate.....			
actual.....(ACFM)	17922	19125	19072
dry standard.....(DSCFM)	10922	11762	11338
Isokinetic variation.....(%)	97.0	97.5	100.2
Particulate concentration...			
actual.....(GR/ACF)	0.00733	0.01131	0.00811
dry standard.....(GR/DSCF)	0.01203	0.01840	0.01365
Particle mass rate...(LB/HR)	1.126	1.855	1.33
F-factor(DSCF/MMBTU)	9140	9140	9140
Emission factor...(LB/MMBTU)	0.041	0.067	0.061

4 RESULTS OF FUEL ANALYSIS

INTERPOLL LABORATORIES, INC.**Fuel Laboratory****(612) 786-6020**

Date: 3/28/96
Client: LOUISIANA-PACIFIC, HAYWARD
Laboratory Log Number: 7451-64-9999
Sample Collected: 3/21/96
Sample Received: 3/22/96
Source: LINE 1 KONUS
Sample Identification: TEST 18, WOOD

Proximate and Ultimate Analysis WT %**Proximate Analysis WT %**

Parameter	Moisture & Ash Free	Moisture Free	As Received
Moisture, Total			43.45
Ash		3.16	1.79
Volatile Matter	81.07	78.51	44.40
Fixed Carbon (calculation)	18.93	18.33	10.37
Sulfur	0.02	0.02	0.01
Heating Value, BTU/LB.	8434	8168	4619

Ultimate Analysis WT %

Parameter	Moisture & Ash Free	Moisture Free	As Received
Moisture, Total			43.45
Ash		3.16	1.79
Carbon	51.54	49.91	28.23
Hydrogen	4.99	4.84	2.74
Nitrogen	0.06	0.06	0.03
Oxygen (calculated)	43.39	42.02	23.76
Sulfur	0.02	0.02	0.01

Respectfully submitted,



David J. Schneider, Manager
Chemistry Department

APPENDIX A

PRELIMINARY VOLUMETRIC FLOW RATE DETERMINATION


Test No. 18
Line 1 Thermal Oil Heater Stack

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-21-96
Time of Determination.....(HRS)	800
Barometric pressure.....(IN.HG)	29.26
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	20
Shape of duct.....	Round
Stack diameter.....(IN)	52
Duct area.....(SQ.FT)	14.75
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.115
Avg. gas temp.....(DEG-F)	288
Moisture content.....(% V/V)	10.78
Avg. linear velocity.....(FT/SEC)	19.8
Gas density.....(LB/ACF)	.05088
Molecular weight.....(LB/LBMOLE)	29.65
Mass flow of gas.....(LB/HR)	53358
Volumetric flow rate.....	
actual.....(ACFM)	17478
dry standard.....(DSCFM)	10761

APPENDIX B

LOCATION OF TEST PORTS



HAYWARD, WI
DRAWING 10
LINE 1
THERMAL OIL HEATER
STACK
ELEVATION

APPENDIX C

FIELD DATA SHEETS

EPA Method 2 Field Data Sheet

Drawing of Test Site

Job LP HAWARD
Source LINE 1 THERMOCODE Heater STACK
Test 18 Run 3-21-96 Date 3-21-96
Stack Dimen. 52 IN.
Dry Bulb °F Wet bulb °F
Manometer ☒ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 29.26 IN.HG
Static Pressure - .115 IN.WC
Operators S. BAINVILLE, J. Lorenz
Pitot No. V23-5 C_p .84

Cross-section View	Elevation View
-----------------------	-------------------

Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas
		Port Length:	6.5 IN.	Time Start: 800	HRS
A 1		1.35	7.85	.06	
2		4.26	10.76	.07	
3		7.59	14.09	.075	
4		11.75	18.25	.09	
5		17.79	24.29	.095	
6		34.22	40.71	.105	
7		40.24	46.74	.11	
8		44.41	50.90	.1	
9		47.74	54.24	.105	
10		50.64	57.14	.08	
B 1				.07	
2				.09	
3				.1	
4				.11	
5				.11	
6				.09	
7				.07	
8				.065	
9				.06	
10				.055	
Temp. Meas. Device & S/N:				Time End:	HRS

R or nothing = reg. manometer; S = expanded; E = electronic

460.4
454.3

032594G:\STACK\WP\FORMS\S-392.1

EPA Method 5 Field Data Sheet

Job LP11842000
Source LP-6 no 1 Kowalski
Date 3-21-96 Test 115 Run 4

Nozzle No.
Nozzle Dia.
Bar. Press.

5-7
432 in.
29-26 in. lg

Pilot No.
 C_n H₂O

230-51
-840
10

[illegible]

APPENDIX D

INTERPOLL LABORATORIES ANALYTICAL RESULTS

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job
Team Leader
Date Submitted
Test No.
Date of Analysis

LP/HAYWARD
JB
18

Source
Test Site
Date of Test
No. of Runs Completed
Technician

Line 1 KONUS
STAIR
3-21-96
3
ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
18-1	7451-61	1	0	7.1	14.9	7.1	12.8	
		2	0	7.1	14.9	7.1	12.8	
		☒ B ☐ F Avg				7.1	12.8	
18-2	62	1	0	6.5	14.9	6.5	13.4	
		2	0	6.5	14.9	6.5	13.4	
		☒ B ☐ F Avg				6.5	13.4	
18-3	63	1	0	5.3	20.1	5.3	14.8	
		2	0	5.3	20.1	5.3	14.8	
		☒ B ☐ F Avg				5.3	14.8	
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						

Ambient Air QA Check
Orsat Analyzer System Leak Check
F₀ Within EPA M-3 Guidelines
for fuel type.

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F - Flask (250 cc all glass)

B - Tedlar Bag (5 layer)

INTERPOL LABORATORIES, INC.

(612) 786-6020

Impinger Catch Data Reporting Sheet

Protocol: ☐ Minnesota ☒ Wisconsin ☐ Iowa☐ EPA Method 202 ☐ OtherJob LP/HaywardSource/Site Line No. 1 Korus / StackDate Submitted 3-22-96Test No. 18Date of Analysis 3-27-96Technician B.O.

		Solvent Phase		Aqueous Phase	
Test: <u>18</u>	Run: <u>1</u>	Dish No: <u>58</u>		Dish No: <u>703</u>	
Log No: <u>7451-57I</u>		Dish + Sample Wt: <u>40.7126</u> g		Dish + Sample Wt: <u>46.8705</u> g	
Color & Appearance:		Dish Tare Wt: <u>40.7126</u> g		Dish Tare Wt: <u>46.8704</u> g	
		Fraction Wt: <u>0.0000</u> g		Fraction Wt: <u>0.0001</u> g	
Comments:		Smpl Vol: <u>200</u> ml, Alqt: <u>200</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>200</u> ml, Alqt: <u>100</u> ml, Factor: <u>2.000</u>	
		Sample Wt: <u>0.0000</u> g		Sample Wt: <u>0.0002</u> g	
Test: <u>18</u>	Run: <u>2</u>	Dish No: <u>62</u>		Dish No: <u>714</u>	
Log No: <u>-58I</u>		Dish + Sample Wt: <u>50.8913</u> g		Dish + Sample Wt: <u>48.6346</u> g	
Color & Appearance:		Dish Tare Wt: <u>50.8883</u> g		Dish Tare Wt: <u>48.6341</u> g	
		Fraction Wt: <u>0.0030</u> g		Fraction Wt: <u>0.0005</u> g	
Comments:		Smpl Vol: <u>290</u> ml, Alqt: <u>290</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>290</u> ml, Alqt: <u>100</u> ml, Factor: <u>2.900</u>	
		Sample Wt: <u>0.0030</u> g		Sample Wt: <u>0.0015</u> g	
Test: <u>18</u>	Run: <u>3</u>	Dish No: <u>65</u>		Dish No: <u>718</u>	
Log No: <u>-59I</u>		Dish + Sample Wt: <u>44.6607</u> g		Dish + Sample Wt: <u>41.3981</u> g	
Color & Appearance:		Dish Tare Wt: <u>44.6570</u> g		Dish Tare Wt: <u>41.3909</u> g	
		Fraction Wt: <u>0.0037</u> g		Fraction Wt: <u>0.0072</u> g	
Comments:		Smpl Vol: <u>320</u> ml, Alqt: <u>320</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>320</u> ml, Alqt: <u>100</u> ml, Factor: <u>3.200</u>	
		Sample Wt: <u>0.0037</u> g		Sample Wt: <u>0.0230</u> g	
Test: <u>18</u>	Run: <u>4</u>	Dish No: <u>68</u>		Dish No: <u>728</u>	
Log No: <u>-60I</u>		Dish + Sample Wt: <u>43.1614</u> g		Dish + Sample Wt: <u>42.9810</u> g	
Color & Appearance:		Dish Tare Wt: <u>43.1548</u> g		Dish Tare Wt: <u>42.9805</u> g	
		Fraction Wt: <u>0.0066</u> g		Fraction Wt: <u>0.0005</u> g	
Comments:		Smpl Vol: <u>310</u> ml, Alqt: <u>310</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>310</u> ml, Alqt: <u>100</u> ml, Factor: <u>3.100</u>	
		Sample Wt: <u>0.0066</u> g		Sample Wt: <u>0.0016</u> g	

Note: Factor = Sample Volume/Aliquot Volume

Blank Solvent Wt. 0.0000 g

		RUN 1	RUN 2	RUN 3	RUN 4
Results of Solvent Phase	g	<u>0.0000</u>	<u>0.0030</u>	<u>0.0037</u>	<u>0.0066</u>
Results of Aqueous Phase	g	<u>0.0000</u>	<u>0.0013</u>	<u>0.0228</u>	<u>0.0014</u>

INTERPOLL LABORATORIES, INC.
(612) 786-6020
Solvent Rinse Data Reporting Sheet

☒ EPA Method 5 Probe Wash ☐ EPA Method 29 Probe Wash ☐ EPA Method 202 Cup & Tube Wash

Job LP/HAYWARD Source/Site LINE 1 KONUS STACK
Date Submitted _____ Test No. 18
Date of Analysis 4-4-96 Technician SCB
Transport Leakage ☐ None ☒ _____ ml Solvent _____

Test: <u>18</u>	Run: <u>0</u>	Dish No: <u>23</u>
Log No: <u>7451-56P</u>		Dish + Sample Wt: <u>46.0848</u> g
Volume of Solvent <u>120</u> ml		Dish Tare Wt: <u>46.0847</u> g
*Solvent Residue _____ ug/ml		Sample Wt: <u>.0001</u> g
Test: <u>18</u>	Run: <u>1</u>	Dish No: <u>882</u>
Vol. of Solvent <u>130</u> ml		Dish + Sample Wt: <u>38.1182</u> g
Log Number <u>-57P</u>		Dish Tare Wt: <u>38.0970</u> g
Comments _____		Sample Wt: <u>.0212</u> g
Test: <u>18</u>	Run: <u>2</u>	Dish No: <u>849</u>
Vol. of Solvent <u>150</u> ml		Dish + Sample Wt: <u>46.5321</u> g
Log Number <u>-58P</u>		Dish Tare Wt: <u>46.5198</u> g
Comments _____		Sample Wt: <u>.0073</u> g
Test: <u>18</u>	Run: <u>3</u>	Dish No: <u>93</u>
Vol. of Solvent <u>160</u> ml		Dish + Sample Wt: <u>53.9928</u> g
Log Number <u>-58P</u>		Dish Tare Wt: <u>53.9832</u> g
Comments _____		Sample Wt: <u>.0096</u> g

*Solvent Residue _____ ug/ml = [(Sample Wt. _____ g) (10⁶)]/Vol. of Sol. _____ ml

EPA-M5 Acetone Residue Blank Spec. ≤ 7.8 ug/ml

	<u>✓</u>	RUN <u>0</u>	RUN <u>1</u>	RUN <u>2</u>	RUN <u>3</u>
Results of Solvent Rinse	g	<u>.0001</u>	<u>.0011</u> D-3	<u>.0072</u>	<u>.0095</u>

INTERPOL LABORATORIES, INC.
(612) 786-6020
Solvent Rinse Data Reporting Sheet

☒ EPA Method 5 Probe Wash ☐ EPA Method 29 Probe Wash ☐ EPA Method 202 Cup & Tube Wash

Job LP/HAYWARD Source/Site LINE 1 KONUS STALK
Date Submitted _____ Test No. 18
Date of Analysis 4-4-96 Technician SLB

Transport Leakage ☐ None ☒ _____ ml Solvent _____

Test: <u>18</u>	Run: <u>4</u>	Dish No: <u>622</u>
Log No: <u>7451-607</u>		Dish + Sample Wt: <u>48.8508</u> g
Volume of Solvent <u>165</u> ml		Dish Tare Wt: <u>48.8492</u> g
*Solvent Residue _____ ug/ml		Sample Wt: <u>.0016</u> g
Test: _____	Run: _____	Dish No: _____
Vol. of Solvent _____ ml		Dish + Sample Wt: _____ g
Log Number _____		Dish Tare Wt: _____ g
Comments _____		Sample Wt: _____ g
Test: _____	Run: _____	Dish No: _____
Vol. of Solvent _____ ml		Dish + Sample Wt: _____ g
Log Number _____		Dish Tare Wt: _____ g
Comments _____		Sample Wt: _____ g
Test: _____	Run: _____	Dish No: _____
Vol. of Solvent _____ ml		Dish + Sample Wt: _____ g
Log Number _____		Dish Tare Wt: _____ g
Comments _____		Sample Wt: _____ g

*Solvent Residue _____ ug/ml = [(Sample Wt. _____ g) (10⁶)] / Vol. of Sol. _____ ml

EPA-M5 Acetone Residue Blank Spec. ≤ 7.8 ug/ml

	✓ <u>SV</u>			
	RUN <u>4</u>	RUN	RUN	RUN
Results of Solvent Rinse	g <u>0.0015</u>	D-4		

INTERPOL LABORATORIES, INC.
(612) 786-6020
Filter Gravimetrics Reporting Sheet

Filter Type: ☒ EPA Method 5 ☐ EPA Method 29 ☐ EPA Method 202 ☐ Other _____

Job: LP/HAYWARD Source/Site: LINE 1 KONUS STACK
Date Submitted: _____ Test No.: 18
Date of Analysis: 4-8-6 Technician: SLB

Test: <u>1D</u>	Run: <u>0</u>	Filter No: <u>7988</u>
Field Blank:		Filter Type: <u>4" G.F.</u>
Log No: <u>7451-56F</u>		Filter + Sample Wt: <u>.9561</u> g
Color: <u>WHITE</u>		Filter Tare Wt: <u>.8561</u> g
		Sample Wt: <u>.0000</u> g
Test: <u>1D</u>	Run: <u>1</u>	Filter No: <u>7989</u>
Log No: <u>-57F</u>		Filter Type: <u>4" G.F.</u>
Color: <u>LIGHT TAN</u>		Filter + Sample Wt: <u>.8694</u> g
		Filter Tare Wt: <u>.8463</u> g
		Sample Wt: <u>.0231</u> g
Test: <u>18</u>	Run: <u>2</u>	Filter No: <u>7977</u>
Log No: <u>-58F</u>		Filter Type: <u>4" G.F.</u>
Color: <u>LIGHT TAN</u>		Filter + Sample Wt: <u>.9824</u> g
		Filter Tare Wt: <u>.9597</u> g
		Sample Wt: <u>.0227</u> g
Test: <u>18</u>	Run: <u>3</u>	Filter No: <u>7986</u>
Log No: <u>-59F</u>		Filter Type: <u>4" G.F.</u>
Color: <u>LIGHT TAN</u>		Filter + Sample Wt: <u>.9771</u> g
		Filter Tare Wt: <u>.8565</u> g
		Sample Wt: <u>.0206</u> g

✓ g/L

	RUN <u>0</u>	RUN <u>1</u>	RUN <u>2</u>	RUN <u>3</u>
Results of Filter Analysis g	<u>.0000</u>	<u>.0231</u>	<u>.0227</u>	<u>.0206</u>

	RUN	RUN	RUN	RUN
Total Mass g				

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job Field Engineer LP/HAYWARD Source L-11E No. 1 Kous Site Log No. 7451
J. BAZZVILLE Date of Test 3-21-96 Test No. 18 No. of Runs 4

No. Items	Sample Type	Analysis	Sequence No.	Comments
	Probe Wash: ☒ DI Water ☐ MeCl ₃	☒ EPA M-5 ☐ EPA M-29		
	Filler: ☒ 4" Glass ☐ SS Thimble	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
	Impingers: ☒ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ MN Protocol ☒ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Cases		
	Integrated Gas: ☒ Tedlar Bag	☐ EPA M-3 ☐ EPA M-10		
	Oxides of Nitrogen:	☐ EPA M-7A ☐ Per S-0163		
	Fuel Lab: ☒ Fuel Sample ☐ Aggregate			
	Particle Sizing:	☐ X-Ray Sdgraph ☐ Cascade Imp		
	Miscellaneous:	☐		

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
 Wood: ☒ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☐ Natural Gas ☐ RDF ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>James Bazzville Interpoll Labs</u>	<u>AL Interpoll</u>	<u>3/20/96 1115</u>

APPENDIX E

OPERATIONAL DATA

HAYWARD LINE 1 THERMAL OIL (REVISED)

<u>CONTENTS</u>	<u>PAGE</u>
TEST SCHEDULES	1
LINE 2 THERMAL OIL , DRYER & PRESS DATA SUMMARY	2
LINE 1 THERMAL OIL HEATER MARCH 21, 1996 PM	
PRODUCTION/SUMMARY	3
PRESS REPORT	4
PRESS CHARTS	5
KONUS DATA SHEETS	6-8
PRESS RTO CHART	9
BOARD WEIGHTS/THICKNESSES	10

HAYWARD TESTING MARCH 21st, 1996
Test schedule

Line 1 Thermal Oil Stack

	<u>POLLUTAN</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
3-21	PM	850-955	1038-1145	1210-1312

HAYWARD LINE 1 TESTING MARCH 21, 1996
Line 1 process data summary

LINE 1 THERMAL OIL HEATER MARCH 21, 1996 - PM

18.73 =Production rate in Tons per hour
0.58 =K3 estimated Tons per hour of fuel burned based on fuel measurement
10.41 =K3 estimated mmBTU per hour input based on fuel measurement
0.88 =K4 estimated Tons per hour of fuel burned based on fuel measurement
15.77 =K4 estimated mmBTU per hour input based on fuel measurement
1.45 =Total tons of dry bark per hour input
26.18 =Total mmBTU per hour input

THERMAL OIL STACK - PM

DATA TIME	START=	08:45	END=	08:55	HOURS=	0.17
	START=	09:10	END=	13:15	HOURS=	4.08
					TOTAL=	4.25

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices
per unit over the testing period.

7/16"

per/peice 48.77

per/ 8' x 16' 195.07

PLANT PRODUCTION RATE

4.25 =hours during testing

68 =pressloads

816 =no. of 8'x16' boards produced (pressloads x 8 boards per load)

159,179 =lbs of finished product (boards produced x weight of finished board)

37,454 =lbs of finished product per hour (lbs of finished product / hours)

18.73 =tons of finished product per hour (lbs of finished product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY BARK INPUT

K1

13.89 =K1 fuel calibration in pounds per count

589 =K1 counts during testing hours

8,181 =K1 lbs of wet fuel burned during testing

4.25 =hours during testing

39.90% =average moisture content of fuel

4,917 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))

1,156.92 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

0.58 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

9,000 =estimated BTU content per pound of dry fuel,

10.41 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

K2

13.89 =K2 fuel calibration in pounds per count

892 =K2 counts during testing hours

12,390 =K2 lbs of wet fuel burned during testing

4.25 =hours during testing

39.90% =average moisture content of fuel

7,446 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))

1,752.07 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

0.88 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

9,000 =estimated BTU content per pound of dry fuel,

15.77 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

FUEL BURNING RATE ESTIMATED TEMPERATURE DIFFERENTIAL

K1

454.40 =average incoming oil temperature on degrees f.

481.30 =average outgoing oil temperature on degrees f.

60 =temperature differential at 100% capacity in degrees f

26.9 =actual temperature differential

19.4 =maximum mmbtu input at 100% capacity

8.70 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input

9,000 =estimated BTU content per pound of dry fuel,

0.48 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

K2

428.30 =average incoming oil temperature on degrees f.

471.40 =average outgoing oil temperature on degrees f.

60 =temperature differential at 100% capacity in degrees f

43.1 =actual temperature differential

19.4 =maximum mmbtu input at 100% capacity

13.94 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input

9,000 =estimated BTU content per pound of dry fuel,


0.77 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

4

LINE I
PRESS CHART

3/21/96

0700 - 1500



KONUS DATA READINGS EVERY 10 MINUTES

PLANT Hayward LP

BY Pat m

DATE 3-21-96 PAGE 1 OF 1

TIME	K1			K2			K3			K4			FUEL				ONCE/HR	
	OIL IN TEMP	OIL OUT TEMP	LD. FAN W/G	OIL IN TEMP	OIL OUT TEMP	LD. FAN W/G	OIL IN TEMP	OIL OUT TEMP	LD. FAN W/G	OIL IN TEMP	OIL OUT TEMP	LD. FAN W/G	K1	K2	K3	K4	BARK	MOISTURE
8:30	234	253	-0.4	219	233	-3							333	412			40.1	
8:45	233	251	-0.4	219	241	-2.6							360	472			39.6	
9:00	235	254	-0.3	221	247	-2.2							418	514			39.8	
9:15	239	256	-0.4	219	253	-2.0							457	561			40.5	
9:30	239	258	-0.4	225	250	-2.4							490	605			39.3	
9:45	232	250	-0.4	219	245	-2.2							528	661			40.2	
10:00	232	249	-0.4	219	244	-2.4							556	702			40.3	
10:15	232	246	-0.4	219	240	-2.4							593	757			39.6	
10:30	232	244	-0.4	216	238	-2.4							629	816				
10:45	233	256	-0.4	220	242	-2.2							672	973				
11:00	236	256	-0.4	223	249	-2.4							717	929				
11:15	246	257	-0.4	227	248	-2.4							770	997				
11:30	235	254	-0.4	220	239	-2.6							819	1059				
11:45	236	253	-0.4	221	244	-2.4							864	1106				
12:00	237	256	-0.4	224	251	-2.2							911	1145				
12:15	235	247	-0.4	221	246	-2.2							953	1184				
12:30	232	241	-0.4	217	237	-2.4							1004	1221				
12:45	233	241	-0.5	218	242	-2.4							1050	1278				
1:00	234	240	-0.5	218	241	-2.4							1105	1325				
1:15	231	241	-0.5	216	237	-2.6							1149	1364				
1:30	234	252	-0.4	220	243	-2.4							1201	1422				
1:45	234	254	-0.4	220	244	-2.4							1251	1475				
2:00	238	256	-0.4	225	246	-2.2							1291	1524				
2:15	235	255	-0.5	225	249	-2.2							1335	1586				
2:30	241	256	-0.4	229	251	-2.2							374	1631				
2:45	234	250	-0.5	221	250	-1.6							416	1685				
3:00	234	253	-0.4	220	248	-2.2							458	1729				

Konus EFB Readings
Plant Hayward L.P.
readings every 10 minutes

date 3-21-96
by Pat m

Page 1 of 1

time	K1 and K2						K3 and K4					
	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.	Bed Volt	Bed Current	Ion Volt	Ion Current	EFB Press.	Baghouse Press.
8:30	11.5	1.4	3.0	3.8	0.8	3.5						
8:45	4.5	1.4	2.8	3.8	1.6	2.5						
9:00	12.0	1.6	2.8	3.6	2.0	2.0						
9:15	12.0	1.4	2.8	3.4	2.2	2.5						
9:30	12.0	1.4	2.8	3.6	2.2	2.5						
9:45	12.0	1.6	2.8	3.6	2.4	2.0						
10:00	12.0	1.6	2.9	3.6	2.6	2.0						
10:15	12.0	1.6	2.8	3.6	2.6	2.0						
10:30	12.0	1.6	2.8	3.8	2.6	2.0						
10:45	11.5	1.6	2.8	3.8	2.0	2.5						
11:00	11.5	1.8	2.7	4.0	1.8	2.0						
11:15	11.5	2.0	2.7	4.0	1.8	2.5						
11:30	11.5	2.0	2.7	3.6	1.8	2.0						
11:45	10.0	1.8	2.7	4.0	2.0	2.5						
12:00	11.5	2.0	2.8	3.4	2.2	2.5						
12:15	11.5	2.0	2.7	3.4	2.0	2.5						
12:30	11.3	1.8	2.7	3.6	2.4	2.0						
12:45	11.5	1.8	2.7	3.6	2.6	2.0						
1:00	9.0	1.6	2.7	3.8	2.4	2.5						
1:15	11.5	1.6	2.7	3.8	2.2	2.5						
1:30	11.5	1.8	2.8	3.6	2.0	2.5						
1:45	9.5	2.2	2.9	3.8	2.0	2.5						
2:00	11.5	2.0	2.9	3.8	2.0	2.0						
2:15	11.6	2.0	2.8	3.6	2.2	2.5						
2:30	11:0	2.0	2.9	3.6	2.0	2.0						
2:45	11.0	2.2	2.8	3.8	2.0	2.5						
3:00	11.0	2.0	2.8	3.8	2.0	2.5						

SHIFT: ① OR II
LINES 1 & 2

K-1 - K-2

Bed Voltage (KV)
Bed Amperage (MA)
Ionizer Voltage (KV)
Ionizer Amperage (MA)
EFB Pressure Drop (In.)
Inlet Temperature
Outlet Temperature
Rock Flow
Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
13	12.5	12	12	11.5	11.5	11.5	11.5	10	11	11	11
108	110	114	115	117	120	114	118	120	121	122	122
27	22	22	27	27	27	22	29	28	28	28	26
30	32	36	38	39	34	36	38	40	34	30	34
0	17	17	22	26	22	24	21	28	18	16	16
378	395	406	411	416	418	403	411	418	419	428	419
290	297	303	312	323	323	323	323	327	327	330	329
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

K-3 - K-4

Bed Voltage (KV)
Bed Amperage (MA)
Ionizer Voltage (KV)
Ionizer Amperage (MA)
EFB Pressure Drop (In.)
Inlet Temperature
Outlet Temperature
Rock Flow
Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
6.5	6.5	6.5	6.5	6.5	6.5	6.5	7	7	7	7	7
20	20	20	18	18	18	20	20	18	18	18	17
21	21	21	21	25	25	21	21	21	21	21	21
2.0	2.0	2.0	2.1	2.6	2.0	2.0	2.2	2.0	2.0	2.1	2.2
104	104	105	104	104	104	105	104	104	104	104	104
499	475	484	449	437	439	443	435	449	453	442	480
395	398	396	397	403	403	407	403	404	405	407	400
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

Baghouse
Pressure
Drop: (in.)

	7	8	9	10	11	12	1	2	3	4	5	6
L-I	2.4	2.3	2.5	2.4	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.1
L-II	4.8	4.8	4.8	4.7	4.7	4.7	4.4	4.4	4.6	4.4	4.4	4.6

Comments/Problems: _____


*Condition Codes

- 1) Start up/shutdown
- 2) Konus down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Konus on oil
- 8) Maintenance

VOLUME PER SHIFT

LINE I	1 1/2
LINE II	1 1/2



DATE: 3-21-96 - 1
 SHIFT/CREW: 7th 2nd C
 OPERATOR: ATKINSON

3121 1-3
 16 114718

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
7/16	#4206	39 3/4	7/16	#42133	39 3/4
2	called	39 3/4	37		39 1/2
3		40	38		39 5/8
4	#4208	39 5/8	39		39 1/2
5		40	40	#4376	39 5/8
6		40	41		39 1/2
7	called	40	42		39 5/8
8	#4411	40 1/4	43		39 1/2
9		39 7/8	44	#4436	39 1/2
10		39 1/2	45		39 1/2
11		39 1/2	46		39 3/4
12	#4318	39 1/2	47		39 3/4
13		39 1/2	48	#4569	39 3/4
14		39 1/2	49		39 3/4
15		39 1/2	50		39 3/4
16	#4412	39 1/2	51		39 3/4
17		39 1/2	52	#4451	39 1/2
18		39 1/2	53		39 1/2
19		39 3/4	54		39 1/2
20	#4442	39 1/2	55		39 3/4
21		39 1/2	56	4360	39 1/2
22		39 1/2	57		39 3/4
23		39 1/2	58		39 1/2
24	#4430	39 1/2	59		39 3/4
25		39 3/8	60	4331	39 3/4
26		39 1/2	61		39 1/2
27		39 1/4	62		39 1/2
28	#4446	39 1/2	63		39 1/2
29		39 1/2	64	#4379	39 1/2
30		39 1/2	65		39 3/4
31		39 3/8	66		39 1/2
32	#4453	39 3/8	67	called	40
33		39 3/8	68	4342	40
34		39 5/8	69		39 3/8
35		39 3/4	70		39 1/2

APPENDIX F

PROCEDURES

Particulate Loading and Emission Rates

The particulate emission rates were determined per EPA Methods 1 - 5, CFR Title 40, Part 60, Appendix A (revised July 1, 1992). In this procedure a preliminary velocity profile of the gases in the flue is obtained by means of a temperature and velocity traverse. On the basis of these values, sampling nozzles of appropriate diameter are selected to allow isokinetic sampling, a necessary prerequisite for obtaining a representative sample.

The sampling train consists of a heated glass-lined sampling probe equipped with a Type S pitot and a thermocouple. The probe is attached to a sampling module which houses the all-glass in line filter holder in a temperature controlled oven. The sampling module also houses the impinger case and a Drierite filled column. The sampling module is connected by means of an umbilical cord to the control module. The control module houses the dry test gas meter, the calibrated orifice, a leakless pump, two inclined manometers, and all controls required for operating the sampling train.

Particulate samples are collected as follows: The sample gas is drawn through the sampling probe isokinetically and passed through a 4-inch diameter Gelman Type A/E glass fiber filter where particulates are removed. The sample gas is then passed through an ice-cooled impinger train and a desiccant-packed column which absorbs remaining moisture. The sample gas then passes through a vacuum pump followed by a dry test gas meter. The gas meter integrates the sample gas flow throughout the course of the test. A calibrated orifice attached to the outlet of the gasmeter provides real time flow rate data.

A representative particulate sample was acquired by sampling for equal periods of time at the centroid of a number of equal area regions in the duct. The sampling rate is adjusted at each test point maintaining isokinetic sampling conditions. Nomographs are used for rapid determination of the sampling rate.

Particulate Loading and Emission Rates

After sampling is complete, the filter is removed and placed in a clean container. The nozzle and inlet side of the filter holder are quantitatively washed with acetone and the washings are stored in a second container. A brush is often used in the cleaning step to help dislodge deposits. The samples are returned to the laboratory where they are logged in and analyzed. The volume of the acetone rinse ("probe wash") is noted and then the rinse is quantitatively transferred to a tared 120 cc porcelain evaporating dish and the acetone evaporated off at 97-105 °F. This temperature is used to prevent condensation of atmospheric moisture due to the cooling effect induced by the evaporation of acetone. The acetone-free sample is then transferred to an oven and dried at 105 °C for 30 minutes, cooled in a desiccator over Drierite, and then weighed to the nearest .01 mg. The filter sample is quantitatively transferred to a 6-inch watch glass and dried in an oven at 105 °C for two hours. The filter and watch glass are then cooled in a desiccator and the filter weighed to the nearest .01 mg. All weighings are performed in a balance room where the relative humidity is hydrostatted to less than 50% relative humidity. Microscopic examination of the samples is performed if any unusual characteristics are observed. The weight of the acetone rinse is corrected for the acetone blank. The Drierite column is weighed on-site and the water collected by Drierite is added to the condensate so that the total amount of absorbed water may be ascertained.

Integrated flue gas samples for Orsat analysis were collected simultaneously with each pollutant sample. The samples were collected in 15-liter gas sampling bags at a constant flow rate throughout each particulate run. The bags were at a constant flow rate throughout each particulate run. The bags were then returned to the laboratory and analyzed by Orsat analysis. Standard commercially prepared solutions were used in the Orsat analyzer (sat. KOH for carbon dioxide and reduced methylene blue for oxygen).

Condensible Organic Compounds Analysis

(State of Wisconsin - EPA Method 5)

Method II-8672-WI

Equipment: Separatory funnel - 500 cc with Teflon stopcock

Powder funnel - 75 mm ID with a glass wool plug

Evaporating dish(es) - 200 cc or 250 cc beaker

Reagents: Methylene chloride

Sodium sulfate - (ACS) granular anhydrous (purified by heating for four hours in a shallow tray)

SAMPLING

An all-glass impinger assembly is used in the back half of the EPA Method 5 sampling train when an organic wet catch is to be collected. The impinger assembly consists of a modified impinger, a Greenburg Smith impinger followed by another modified impinger. The third impinger should have a temperature measuring device at the outlet upstream of a final impinger or desiccant column to monitor the temperature of the outlet gas stream. Prior to the start of the test, each of the first two impingers should be charged with 100 g of Class I water. The Method 5 train should be operated as provided for in EPA Method 5. Ice should be added to the impinger bath to keep the temperature of the gas at the outlet at or less than 68°F. After the post test leak check, the impinger train is removed and impinger contents poured into a tared all-glass sample bottle and closed with a Teflon-lined cap. The sample bottle is then weighed and the total condensate calculated by subtraction of the bottle tare weight and the weight of initial water added to the impingers (200 g). A label is affixed and the sample is returned to the laboratory for analysis. The sample should be stored at 4°C if the analysis is not conducted within 48 hours.

030894-G:\STACK\WP\METHODS\II-8672.WI

ANALYSIS

1. Sample bottles are removed from storage and the contents quantitatively transferred to a clean 500 cc separatory funnel equipped with a Teflon stopcock.
2. Rinse the sample container with distilled water and add to separatory funnel.
3. Then rinse the sample container with acetone and pour through sodium sulfate into a tare beaker marked A.
4. The sample is then extracted consecutively with three 50 cc aliquots of methylene chloride. The extraction is performed according to normal laboratory practice observing the customary safety precaution of releasing excess pressure after each shaking.
5. After each of the three extractions are completed, the organic solvent should be dried by passing it through a funnel containing anhydrous sodium sulfate and collecting it and two 50 cc rinses in the tared beaker marked A (the same one used to catch the acetone container rinse).
6. Evaporate to dryness in a hood at 70°F or less. Do not evaporate so quickly as to allow evaporative cooling to lower the temperature of the container below the dew point otherwise water will be condensed in the container.
7. Desiccate for two hours in a sealed desiccator and final weigh. Report all results in grams. All weighings should be made to nearest 0.1 mg (four places).
8. The remaining liquid in the separatory funnel is then transferred to a tared beaker marked B and is evaporated to dryness at $220^{\circ}\text{F} \pm 10^{\circ}\text{F}$. The analyst may take an aliquot of the sample, transferring it to a tared beaker and evaporate to dryness at $220^{\circ}\text{F} \pm 10^{\circ}\text{F}$. If an aliquot is used, the weight of the sample and aliquot will have to be taken to correct for the total sample weight.

030894-G:STACKWPMETHODSII-8672.WI

9. After the drying step, the sample is cooled in a desiccator and weighted to a constant weight to the nearest 0.1 mg.

Calculation (if aliquot is taken):


$$\text{grams} = \frac{(\text{grams recovered from aliquot}) \times (\text{total volume (ml) or grams of sample})}{(\text{aliquot volume (ml) or grams used})}$$

If volume is used, it must be used for both the aliquot and sample. The same goes for using weight.

10. A field blank should be analyzed in an identical manner. If a field blank is not submitted, take an aliquot of Class I water equal in volume to the samples and analyze in a similar manner.
11. The results for container A are to be marked in the organic section of Interpoll Form #LSC-03G.
12. The results for container B are to be marked in the inorganic section of Interpoll Form #LSC-03G.

PARTICULATE SAMPLING TRAIN

MPINGER TRAN OPTIONAL, MAY BE REPLACED
BY AN EQUIVALENT CONDENSER



APPENDIX G

CALCULATION EQUATIONS

METHOD 2
CALCULATION EQUATIONS

$$\bar{V}_s = 85.49 C_p (\sqrt{\Delta p})_{avg} \sqrt{\frac{T_{s(avg)}}{P_s M_s}}$$

$$Q_{s,d} = 60 (1 - B_{ws}) \bar{V}_s A \left(\frac{528}{T_{s(avg)}} \right) \left(\frac{P_s}{29.92} \right)$$

$$Q_a = 60 \bar{V}_s A$$

$$\dot{m}_s = \frac{4.995 Q_{s,d} G_d}{1 - B_{ws}}$$

$$RH^* = 100 (vp_{twb} - 0.0003641 P_s (T_{db} - T_{wb})) / vp_{adb}$$

$$B_{ws}^* = RH(vp_{adb}) / P_s$$

$$\rho = \frac{4.585 \times 10^{-2} P_s M_s}{T_s (avg)}$$

*Alternate equations for calculating moisture content from wet bulb and dry bulb data.

SYMBOLS

A	=	Cross Sectional area of stack, SQ. FT.
A_n	=	Cross sectional area of nozzle, SQ. FT.
B_{ws}	=	Water vapor in gas stream, proportion by volume
C_p	=	Pitot tube coefficient, dimensionless
C_s	=	Concentration of particulate matter in stack gas, wet basis, GR/ACF
C_d	=	Concentration of particulate matter in stack gas, dry basis, corrected to standard conditions, GR/DSCF
EA	=	Excess air, percent by volume
γ	=	Dry test meter correction factor, dimensionless
G_d	=	Specific gravity (relative to air), dimensionless
I	=	Isokinetic variation, percent by volume
M_d	=	Molecular weight of stack gas, dry basis, g/g - mole.
$\dot{m}_g$	=	Mass flow of wet flue gas, LB/HR
$\dot{m}_p$	=	Particulate mass flow, LB/HR
M_s	=	Molecular weight of stack gas, wet basis, g/g mole.
M_p	=	Total amount of particulate matter collected, g
P_{bar}	=	Atmospheric pressure, IN. HG. (uncompensated)
P_s	=	Stack static gas pressure, IN. WC.
P_s	=	Absolute pressure of stack gas, IN. HG.
P_{std}	=	Standard absolute pressure, 29.92 IN. HG.
A_s	=	Actual volumetric stack gas flow rate, ACFM
$Q_{s, d}$	=	Dry volumetric stack gas flow rate corrected to standard conditions, DSCFM
RH	=	Relative humidity, %

032294-G:STACKWPMETHODSS-EQ.15

T_{db}	=	Dry bulb temperature of stack gas, °F
T_{wb}	=	Wet bulb temperature of stack gas, °F
$T_{m(avg)}$	=	Absolute average dry gas meter temperature, °R
$T_{s(avg)}$	=	Absolute average stack temperature, °R
T_{std}	=	Standard absolute temperature, 528 °R (68 °F)
θ	=	Total sampling time, min.
V_{lc}	=	Total volume of liquid collected in impingers and silica gel, ml
V_m	=	Volume of gas sample as measured by dry gas meter, CF
$V_{m(std)}$	=	Volume of gas sample measured by the dry gas meter corrected to standard conditions, DSCF
$V_{w(std)}$	=	Volume of water vapor in the gas sample corrected to standard conditions, SCF
$\bar{V}_s$	=	Average actual stack gas velocity, FT/SEC
vp_{tdb}	=	Vapor pressure at T_{db} , IN. HG.
vp_{twb}	=	Vapor pressure at T_{wb} , IN. HG.
$\overline{\Delta H}$	=	Average pressure differential across the orifice meter, IN. WC.
ΔP	=	Velocity pressure of stack gas, IN. WC.
γ	=	Dry test meter correction coefficient, dimensionless
ρ	=	Actual gas density, LB/ACF

METHOD 3
CALCULATION EQUATIONS

$$\%EA = \frac{100(\%O_2 - 0.5\% CO)}{0.264\% N_2 - \%O_2 + 0.5\% CO}$$

$$M_d = 0.44(\%CO_2) + 0.32 (\%O_2) + 0.28 (\%N_2 + \%CO)$$

$$M_s = M_d (I - B_{ws}) + 0.18 B_{ws}$$

$$B_{ws} = \frac{V_{w(szd)}}{V_{w(szd)} + V_{m(szd)}}$$

METHOD 5
CALCULATION EQUATIONS

$$V_{m(std)} = 17.65 V_m \gamma \left(\frac{P_{bar} + \overline{\Delta H}/13.6}{T_{m(avg)}} \right)$$

$$V_{w(std)} = 0.0472 V_{ls}$$

$$B_{ws} = \frac{V_{w(std)}}{V_{w(std)} + V_{m(std)}}$$

$$I = 0.0944 \left(\frac{T_{s(avg)} V_{m(std)}}{P_s V_s A_n \theta (I - B_{ws})} \right)$$

$$C_s = \frac{15.43 M_p}{V_{m(std)}}$$

$$C_a = \frac{272.3 M_p P_s}{T_{s(avg)} (V_{w(std)} + V_{m(std)})}$$

$$(\dot{m}_p)_1 = 8.5714 \times 10^{-3} C_s Q_{s,d}$$

$$(\dot{m}_p)_2 = \frac{1.3228 \times 10^{-1} M_p A}{\theta A_n}$$

$$\dot{m}_p = \frac{(\dot{m}_p)_1 + (\dot{m}_p)_2}{2}$$

APPENDIX H

SAMPLING TRAIN CALIBRATION DATA

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job LP HAYWARD Date 3-21-96
Operator S. BAEUWILLE S. LONGUE Module No. 13

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 29.26 in.Hg $\theta =$ 1.0023 $\Delta H@$ 1.82 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(450.90)		
2.5	452.74	32	18
5.0	454.57	36	19
7.5	456.36	37	20
10	458.14	46	21
	$V_m = 7.24$	Avg(t_m) = 27.9	°F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta \frac{V_m}{7.256}} \left[\frac{(t_m + 460)}{P_b} \right]^{0.5}$$

.746 4.083

$$Y_m = \frac{1.786}{(1.0023)(7.24)} \left[\frac{(27.9) + 460}{(29.26)} \right]^{0.5}$$

$$Y_m = \underline{1.005}$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: March 26, 1996

Meter Box No. : 13 (Rockwell Dry Test Meter Serial No. 1334119)

Date of Last Calibration: January 5, 1996

Calibration Technician: S. Fjelsta

Wet Test Meter No.: American Meter AL-20

Date of Use	Report No.	Initial Meter		Final Meter	Volume/Job		Total Volume*
		Reading			(cu. ft.)		
March 19, 1996	6-7451	315.18		639.72	324.54		324.54

* Total volume through meter since last calibration.

Meter Calibration Sheet EPA/Method 5

Control Module No.	
Serial No. DTM	
Technician	

13
1334119
55

Positive leak check performed by SF
Meter was in tolerance ☒ Meter was not in tolerance
Approved by [Signature]
Date 11/9/96
Meter was in tolerance ☐ Meter was not in tolerance
Meter changed dry test meter ☐ readjusted linkage ☐
*Based on AL-20 wet test meter calibration in Nov. 1991 against Bell Prover (NBS Traceable) - Carl Poe Co.
031794-G:\STACK\W\A\FORMSS-0102RR

Interpoll Laboratories
(612) 786-6020


Nozzle Calibration Data Sheet

Date of Calibration: 03-21-96
Technician: Jamie Bainville
Nozzle Number: 5-7

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	0.432
2	0.431
3	0.432
Average	0.432

DIFFERENTIAL PRESSURE PROOF CALIBRATION CURVE



Data obtained on an American Bell Prover, Serial No. 2260, Traceable to the Bureau of Standards. Reference No. 106870, PI-TAPE.

AL-17 American Wel Test Meter
Serial No. P-718
Stainless Steel w/Removable Back
Calibrated with Saturated Air
Water Temp. 74° F.
Air Temp. 74° F.
Inlet Pressure 2" H₂O Constant
Calibration Rate: 4 CFH Air
Capacity Rate: 8 CFH Air
Restricted Outlet for Rate Deviation.

READING x PROOF = 100

FLOW RATE - CUP - PER HOUR

DAVID BANKS
AUGUST, 1989