

Note: This is a reference cited in AP 42, *Compilation of Air Pollutant Emission Factors, Volume I Stationary Point and Area Sources*. AP42 is located on the EPA web site at www.epa.gov/ttn/chief/ap42/

The file name refers to the reference number, the AP42 chapter and section. The file name "ref02_c01s02.pdf" would mean the reference is from AP42 chapter 1 section 2. The reference may be from a previous version of the section and no longer cited. The primary source should always be checked.

Interpoll Laboratories, Inc.
4500 Ball Road N.E.
Circle Pines, Minnesota 55014-1819

TEL: (612) 786-6020
FAX: (612) 786-7854

**RESULTS OF THE MARCH 18 - 21, 1996
EPA AND STATE AIR EMISSION COMPLIANCE
TESTING AT THE LOUISIANA PACIFIC OSB
PLANT IN HAYWARD, WISCONSIN**

Submitted to:

LOUISIANA-PACIFIC CORPORATION
Route 8, Box 8263
Hayward, Wisconsin 54843

Attention:

Keith Seelig

Reviewed by:



Daniel J. Despen
Manager
Stationary Source Testing Department

Report Number 6-7451
April 15, 1996
SL/sll

TABLE OF CONTENTS

	ABBREVIATIONS	iii
1	INTRODUCTION	1
2	SUMMARY AND DISCUSSION	5
3	RESULTS	25
	3.1 Results of Orsat and Moisture Analyses	26
	3.2 Results of Particulate Loading Determinations	35
	3.3 Results of Oxides of Nitrogen Determinations	40
	3.4 Results of Opacity Observations	50
	3.5 Results of Carbon Monoxide Determinations	54
	3.6 Results of Total Hydrocarbons Determinations	63
	3.7 Results of Formaldehyde Determinations	69
	3.8 Results of Phenol Determinations	73
	3.9 Results of Benzene Determinations	75
	3.10 Results of PAH Determinations	78
4	RESULTS OF FUEL ANALYSES	80

APPENDICES:

A	-	Results of Volumetric Flow Rate Determinations
B	-	Location of Test Ports
C	-	Field Data Sheets
D	-	Interpoll Laboratories Analytical Data
E	-	THC Stripcharts
F	-	NOx and CO Datalogger Printouts
G	-	Measurement System Performance Specifications
H	-	Gas Analyzer Specifications
I	-	Calibration Gas Certification Sheets
J	-	Procedures
K	-	Calculation Equations
L	-	Operational Data
M	-	Sampling Train Calibration Data

ABBREVIATIONS

ACFM	actual cubic feet per minute
cc (ml)	cubic centimeter (milliliter)
DSCFM	dry standard cubic foot of dry gas per minute
DSML	dry standard milliliter
DEG-F (°F)	degrees Fahrenheit
DIA.	diameter
FP	finished product for plant
FT/SEC	feet per second
g	gram
GPM	gallons per minute
GR/ACF	grains per actual cubic foot
GR/DSCF	grains per dry standard cubic foot
g/dscm	grams per dry standard cubic meter
HP	horsepower
HRS	hours
IN.	inches
IN.HG.	inches of mercury
IN.WC.	inches of water
LB	pound
LB/DSCF	pounds per dry standard cubic foot
LB/HR	pounds per hour
LB/10 ⁶ BTU	pounds per million British Thermal Units heat input
LB/MMBTU	pounds per million British Thermal Units heat input
LTPD	long tons per day
MW	megawatt
mg/Nm ³	milligrams per dry standard cubic meter
ug/Nm ³	micrograms per dry standard cubic meter
microns (um)	micrometer
MIN.	minutes
ng	nanograms
ohm-cm	ohm-centimeter
PM	particulate matter
PPH	pounds per hour
PPM	parts per million
ppmC	parts per million carbon
ppm,d	parts per million, dry
ppm,w	parts per million, wet
ppt	parts per trillion
PSI	pounds per square inch
SQ.FT.	square feet
TPD	tons per day
ug	micrograms
v/v	percent by volume
w/w	percent by weight
<	≤ (when following a number)

Standard conditions are defined as 68°F (20°C) and 29.92 IN. of mercury pressure.

1 INTRODUCTION

During March 18 - 21, 1996, Interpoll Laboratories conducted EPA and State air emission compliance tests at the Louisiana Pacific OSB Plant in Hayward, Wisconsin on the following sources:

Source	Parameters
Line 2 Dryer RTO Stack	PM,NO _x ,VE,CO,CH ₂ O,Benzene,THC's,Phenol,PAH's
Line 2 Core Dryer Duct	NO _x ,CO,THC's
Line 2 Surface Dryer Duct	NO _x ,CO,THC's
Line 2 Press Vent RTO Stack	PM,NO _x ,VE,CO,THC's,CH ₂ O
Line 2 Press Vent RTO Inlet	NO _x ,CO,THC's
Line 2 Thermal Oil Heater	PM,NO _x ,VE,CO,CH ₂ O,Benzene
Line 2 Dryer RTO Inlet	PM,NO _x

On-site testing was performed by Ed Trowbridge, Duane Van Hoever, Mark Kaehler, Bob Aschenbach, Ed Juers, Scott Fjelsta, Steve Kelker, Jim Lorenz, Lee Hansen, Mark Peterson, Sheryl Bergeron, and Ken Nuessmeier. Coordination between testing activities and plant operation was provided by Keith Selig of Louisiana-Pacific. The tests were witnessed by Jim Ross of the Wisconsin Department of Natural Resources.

Particulate determinations were performed in accordance with EPA Methods 1 - 5, CFR Title 40, Part 60, Appendix A (revised July 1, 1995). Preliminary volumetric flow rate determinations were used to select the appropriate nozzle diameter for isokinetic sample withdrawal. Interpoll Labs Model 3 M5 sampling trains which meet or exceed specifications in the above-cited reference were used to extract particulate samples by means of heated stainless steel probe. Wet catch samples were collected in the back half of the Method 5 sampling train at the stack test site and analyzed as per Wisconsin DNR protocol.

Oxides of nitrogen, carbon monoxide, oxygen, and carbon dioxide concentrations were determined in accordance with Methods 7E, 10, and 3A (Ibid). A slip stream of sample gas was withdrawn from the exhaust gas stream using a heated stainless steel probe equipped with a filter to remove interfering particulate material. The particulate-free gas was transported to the analyzers by means of a heat-traced probe and filter assembly. After passing

Benzene samples were collected in the accordance with EPA Method 18 (Section 7.4 - Absorption Tube Procedure) using 800/200 mg charcoal tubes. The samples were returned to the laboratory and analyzed by Modified NIOSH 1501.

Total gaseous hydrocarbon concentrations were determined instrumentally using a Ratfisch Model RS 55 heated flame ionization detector (HFID) calibrated against propane in air standards. The THC concentration was continuously monitored by extracting a slipstream of exhaust gas by means of a heated probe and filter holder. A heat-traced teflon line was used to transport the sample gas from the filter holder outlet to the analyzer inlet.

Phenol concentrations were determined using a Method 5 sampling train with a neutral buffered absorbing reagent followed by extraction with methylene chloride and direct analysis by GC/MS with no concentration (EPA Method 8270). The samples were field spiked with 5.33 mg of phenol d5.

Polyaromatic hydrocarbons sampling was conducted using the EPA Modified Method 5 sampling procedure as per EPA Method 010 SW 846. The four-part sample and field blank were extracted, concentrated to 1000 ul and cleaned up as required (column chromatography as per Interpoll Labs Method II-8904-2 or GPC) prior to final concentration and analysis. The samples were then further concentrated to 100 ul and analyzed in accordance with EPA Method 8270 by HRGC/LRMS using electron impact (EI) with total ion monitoring (TIM). Quantification was performed using the six standard M-8270 internal standards. Each XAD-2 resin cartridge was field spiked with 20 ug of d₁₀-fluoroanthene in order to document overall collection and analytical efficiency and recovery. Analytical accuracy and recovery for extraction and cleanup was documented using the six m-8270-recommended surrogate standards.

Integrated flue gas samples were extracted simultaneously with each of the above-referenced sample trains from the sampling train exhaust ports as part of the overall project quality assurance using a specially designed gas sampling system. Integrated flue gas samples were collected in 44-liter Tedlar bags. Prior to sampling, the Tedlar bags are leak checked at 15 IN.HG. vacuum with an in-line rotameter. Bags with any detectable inleakage are discarded. After sampling was complete, the bags were sealed and returned to the laboratory for Orsat analysis.

A summary and discussion of all of the important results of this compliance test is given in the following section. More detailed results of the various samplings are presented in Section 3, together with pertinent sampling parameters. Supplemental information such as field data sheets, laboratory results, procedures and calculation equations are presented in the appendices.

2 SUMMARY AND DISCUSSION

The results of the air emission compliance tests are presented in Tables 1 - 11. An overview of the results is presented in the table below:

PARAMETER	MEASURED
<u>LINE 2 DRYER RTO STACK</u>	
Particulate	
✓ <i>DRY + WET CATCH</i>	
..... (GR/DSCF)	0.0075
..... (LB/HR)	4.5
✓ <i>DRY CATCH ONLY</i>	
..... (GR/DSCF)	0.0044
..... (LB/HR)	2.7
✓ Oxides of Nitrogen	
..... (ppm,d)	16
..... (LB/HR)	8.2
✓ Opacity	0
Carbon Monoxide	
..... (ppm,d)	225
..... (LB/HR)	69
✓ Formaldehyde	
..... (ppm,d)	8.9
..... (LB/HR)	3.0
✓ Benzene	
..... (ppm,d)	0.12
..... (LB/HR)	0.12
✓ TGNMO's	
..... (ppmC,w)	31
..... (LB/HR)	5.6
✓ Phenol	
..... (ppb,d)	< 177
..... (10 ⁻³ LB/HR)	< 180
<u>LINE 2 CORE DRYER DUCT</u>	
✓ Oxides of Nitrogen	
..... (ppm,d)	23
..... (LB/HR)	4.8
✓ Carbon Monoxide	
..... (ppm,d)	1035
..... (LB/HR)	131
✓ TGNMO's	
..... (ppmC,w)	730
..... (LB/HR)	53

PARAMETER	MEASURED
-----------	----------

LINE 2 SURFACE DRYER DUCT

Oxides of Nitrogen

✓	 (ppm,d)	31
	 (LB/HR)	6.1

Carbon Monoxide

✓	 (ppm,d)	1973
	 (LB/HR)	237

TGNMO's

✓	 (ppmC,w)	770
	 (LB/HR)	56

LINE 2 PRESS VENT RTO STACK

Particulate

DRY + WET CATCH

	 (GR/DSCF)	0.0022
	 (LB/HR)	1.3

DRY CATCH ONLY

	 (GR/DSCF)	0.0014
	 (LB/HR)	0.84

✓	Oxides of Nitrogen	
	 (ppm,d)	20
	 (LB/HR)	9.8

Opacity (%)

0

Carbon Monoxide

✓	 (ppm,d)	22
	 (LB/HR)	6.4

Formaldehyde

✓	 (ppm,d)	0.31
	 (LB/HR)	0.10

TGNMO's

	 (ppmC,w)	8
	 (LB/HR)	1.0

LINE 2 PRESS RTO INLET

Oxides of Nitrogen

✓	 (ppm,d)	2.6
	 (LB/HR)	1.4

Carbon Monoxide

✓	 (ppm,d)	11
	 (LB/HR)	3.6

TGNMO's

	 (ppmC,w)	102
	 (LB/HR)	15.1

PARAMETER	MEASURED
LINE 2 THERMAL OIL HEATER	
Particulate	
✓ DRY + WET CATCH	
..... (GR/DSCF)	0.045
..... (LB/10 ⁶ BTU)	0.16
✗ DRY CATCH ONLY	
..... (GR/DSCF)	0.042
..... (LB/10 ⁶ BTU)	0.15
X Oxides of Nitrogen	
..... (ppm,d)	62
..... (LB/HR)	7.7
Opacity	0.25
Carbon Monoxide	
✗	218
..... (LB/HR)	16.5
Formaldehyde	
..... (ppm,d)	0.12
..... (LB/HR)	0.0098
✓ Benzene	
..... (ppm,d)	≤ 0.22
..... (LB/HR)	≤ 0.044

LINE 2 DRYER RTO INLET

Particulate	
✓ DRY + WET CATCH	
..... (GR/DSCF)	0.040
..... (LB/HR)	22
DRY CATCH ONLY	
..... (GR/DSCF)	0.015
..... (LB/HR)	8.0
Oxides of Nitrogen	
✓	9
..... (LB/HR)	4.1

The PAH results are summarized in Table 11. Please note that water injection occurred during some of the testing. These test runs are designated in the following pages with an asterisk.

No difficulties were encountered in the field or in the laboratory evaluation of the samples. On the basis of these facts and a complete review of the data and results, it is our opinion that the concentrations and emission rates reported herein are accurate and closely reflect the actual values which existed at the time the tests were performed.

Table 1a Summary of the Results of the March 19, 1996 Particulate Emission Compliance Test of the Line 2 Dryer RTO Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	* Run 2	Run 3
Date of test	03-19-96	03-19-96	03-19-96
Time runs were done (HRS)	1030/1140	1320/1429	1500/2037
Volumetric flow actual (ACFM) standard (DSCFM)	132280 68859	137925 70732	135372 69238
Gas temperature (DEG-F)	262	264	263
Moisture content (%V/V)	25.85	26.73	27.04
Gas composition (%V/V, dry) carbon dioxide oxygen nitrogen	4.20 15.80 80.00	4.00 16.10 79.90	4.30 15.80 79.90
Isokinetic variation (%)	106.3	99.2	101.0
Particulate concentration actual (GR/ACF) standard (GR/DSCF)	.002670 .005130	.005603 .0109	.003322 .006497
Part. emission rate (LB/HR)	3.03	6.63	3.86

Note: Dry + Organic/Inorganic Wet Catch

* E-TUBE H₂O ON.

Table 1b Summary of the Results of the March 19, 1996 Particulate Emission Compliance Test of the Line 2 Dryer RTO Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	* Run 2	Run 3
Date of test	03-19-96	03-19-96	03-19-96
Time runs were done (HRS)	1030/1140	1320/1429	1500/2037
Volumetric flow actual (ACFM) standard (DSCFM)	132280 68859	137925 70732	135372 69238
Gas temperature (DEG-F)	262	264	263
Moisture content (%V/V)	25.85	26.73	27.04
Gas composition (%V/V, dry) carbon dioxide oxygen nitrogen	4.20 15.80 80.00	4.00 16.10 79.90	4.30 15.80 79.90
Isokinetic variation (%)	106.3	99.2	101.0
Particulate concentration actual (GR/ACF) standard (GR/DSCF)	.000840 .001614	.004241 .008273	.001709 .003342
Part. emission rate (LB/HR)	0.953	5.02	1.98

Note: Dry Catch Only

* E-TUBE H₂O ON.

Table 2a Summary of the Results of the March 20, 1996 Particulate Emission Compliance Test of the Line 2 Press Vent RTO Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	03-20-96	03-20-96	03-20-96
Time runs were done (HRS)	1012/1114	1135/1241	1305/1411
Volumetric flow actual (ACFM)	95284	95834	95693
standard (DSCFM)	69923	70293	69564
Gas temperature (DEG-F)	233	233	233
Moisture content (%V/V)	1.56	1.65	2.47
Gas composition (%V/V, dry)			
carbon dioxide	0.03	0.03	0.03
oxygen	20.90	20.90	20.90
nitrogen	79.07	79.07	79.07
Isokinetic variation (%)	100.0	100.0	100.5
Particulate concentration			
actual (GR/ACF)	.003087	.000705	.001003
standard (GR/DSCF)	.004209	.000961	.001380
Part. emission rate (LB/HR)	2.52	0.579	0.823

Note: Dry + Organic/Inorganic Wet Catch

Table 2b Summary of the Results of the March 20, 1996 Particulate Emission Compliance Test of the Line 2 Press Vent RTO Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	03-20-96	03-20-96	03-20-96
Time runs were done (HRS)	1012/1114	1135/1241	1305/1411
Volumetric flow actual (ACFM)	95284	95834	95693
standard (DSCFM)	69923	70293	69564
Gas temperature (DEG-F)	233	233	233
Moisture content (%V/V)	1.56	1.65	2.47
Gas composition (%V/V, dry)			
carbon dioxide	0.03	0.03	0.03
oxygen	20.90	20.90	20.90
nitrogen	79.07	79.07	79.07
Isokinetic variation (%)	100.0	100.0	100.5
Particulate concentration			
actual (GR/ACF)	.002202	.000201	.000677
standard (GR/DSCF)	.003001	.000275	.000932
Part. emission rate (LB/HR)	1.80	0.165	0.555

Note: Dry Catch Only

Table 3a Summary of the Results of the March 18, 1996 Particulate Emission Compliance Test of the Line 2 Thermal Oil Heater Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	03-19-96	03-19-96	03-19-96
Time runs were done (HRS)	1800/1903	1930/2032	2100/2202
Volumetric flow actual (ACFM) standard (DSCFM)	31644 16834	31697 16089	32275 16292
Gas temperature (DEG-F)	391	410	419
Moisture content (%V/V)	10.50	12.69	12.27
Gas composition (%V/V.dry) carbon dioxide oxygen nitrogen	6.40 13.60 80.00	7.40 12.50 80.10	8.30 11.60 80.10
Isokinetic variation (%)	100.5	102.3	101.2
Particulate concentration actual (GR/ACF) standard (GR/DSCF)	.0223 .0419	.0234 .0461	.0242 .0480
Part. emission rate (LB/HR)	6.04	6.36	6.70
Emission factor (LB/MMBTU)	0.164	0.157	0.148

Note: Dry + Organic/Inorganic Wet Catch

Table 3b Summary of the Results of the March 18, 1996 Particulate Emission Compliance Test of the Line 2 Thermal Oil Heater Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	Run 2	Run 3
Date of test	03-19-96	03-19-96	03-19-96
Time runs were done (HRS)	1800/1903	1930/2032	2100/2202
Volumetric flow actual (ACFM) standard (DSCFM)	31644 16834	31697 16089	32275 16292
Gas temperature (DEG-F)	391	410	419
Moisture content (%V/V)	10.50	12.69	12.27
Gas composition (%V/V, dry) carbon dioxide oxygen nitrogen	6.40 13.60 80.00	7.40 12.50 80.10	8.30 11.60 80.10
Isokinetic variation (%)	100.5	102.3	101.2
Particulate concentration actual (GR/ACF) standard (GR/DSCF)	.0210 .0395	.0204 .0401	.0237 .0470
Part. emission rate (LB/HR)	5.69	5.53	6.56
Emission factor (LB/MMBTU)	0.155	0.137	0.145

Note: Dry Catch Only

Table 4a Summary of the Results of the March 18, 1996 Particulate Emission Compliance Test of the Line 2 Dryer RTO Inlet at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	* Run 2	Run 3
Date of test	03-19-96	03-19-96	03-19-96
Time runs were done (HRS)	1030/1133	1320/1421	1900/2032
Volumetric flow actual (ACFM)	103347	106118	106293
standard (DSCFM)	62517	62594	63759
Gas temperature (DEG-F)	167	170	171
Moisture content (%V/V)	25.05	26.57	25.14
Gas composition (%V/V, dry)			
carbon dioxide	4.20	4.00	4.20
oxygen	15.90	16.20	15.90
nitrogen	79.90	79.80	79.90
Isokinetic variation (%)	108.2	103.9	101.3
Particulate concentration			
actual (GR/ACF)	.0179	.0208	.0335
standard (GR/DSCF)	.0297	.0353	.0559
Part. emission rate (LB/HR)	15.91	18.94	30.55

Note: Dry + Organic/Inorganic Wet Catch

* E-TUBE H₂O On.

Table 4b Summary of the Results of the March 18, 1996 Particulate Emission Compliance Test of the Line 2 Dryer RTO Inlet at the Louisiana Pacific Plant in Hayward, Wisconsin.

ITEM	Run 1	* Run 2	Run 3
Date of test	03-19-96	03-19-96	03-19-96
Time runs were done (HRS)	1030/1133	1320/1421	1900/2032
Volumetric flow actual (ACFM) standard (DSCFM)	103347 62517	106118 62594	106293 63759
Gas temperature (DEG-F)	167	170	171
Moisture content (%V/V)	25.05	26.57	25.14
Gas composition (%V/V, dry) carbon dioxide oxygen nitrogen	4.20 15.90 79.90	4.00 16.20 79.80	4.20 15.90 79.90
Isokinetic variation (%)	108.2	103.9	101.3
Particulate concentration actual (GR/ACF) standard (GR/DSCF)	.007612 .0126	.004437 .007524	.0144 .0239
Part. emission rate (LB/HR)	6.75	4.04	13.09

Note: Dry Catch Only

* E-TUBE H₂O ON.

Table 5a. Summary of the Results of the March 19 & 20, 1996 **Oxides of Nitrogen Determinations** at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppm,d)	Emission Rate (LB/HR)
(Line 2 Dryer RTO Stack)			
*3-19-96	1320-1420	15	7.7
3-20-96	1000-1100	13	6.9
3-20-96	1200-1300	20	10.1
Avg		16	8.2
(Line 2 Core Dryer Duct)			
*3-19-96	1320-1420	23	4.7
3-20-96	1000-1100	23	4.9
3-20-96	1200-1300	24	4.9
Avg		23	4.8
(Line 2 Surface Dryer Duct)			
*3-19-96	1320-1420	30	5.9
3-20-96	1000-1100	30	6.0
3-20-96	1200-1300	32	6.3
Avg		31	6.1
(Line 2 Press Vent RTO Stack)			
3-20-96	1650-1750	22	10.9
3-20-96	1815-1915	20	10.0
3-20-96	2015-2115	19	8.5
Avg		20	9.8

* E-TUBE H₂O ON

Table 5b. Summary of the Results of the March 18 - 20, 1996 **Oxides of Nitrogen Determinations** at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppm,d)	Emission Rate (LB/HR)
(Line 2 Press Vent RTO Inlet)			
3-20-96	1650-1750	2.1	1.1
3-20-96	1815-1915	2.7	1.5
3-20-96	2015-2115	3.1	1.7
Avg		2.6	1.4
(Line 2 Thermal Oil Heater Stack)			
3-18-96	1036-1136	61	7.6
3-18-96	1220-1320	63	7.6
3-18-96	1405-1505	63	8.0
Avg		62	7.7
(Line 2 Dryer RTO Inlet)			
3-19-96	1030-1133	9	3.7
* 3-19-96	1320-1421	7	3.3
3-19-96	1900-2032	12	5.3
Avg		9	4.1

* E-TUBE H₂O ON

Table 6a. Summary of the Results of the March 19 & 20, 1996 **Carbon Monoxide Determinations** at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppm,d)	Emission Rate (LB/HR)
(Line 2 Dryer RTO Stack)			
3-19-96	1030-1140	258	77
*3-19-96	1320-1429	198	61
3-19-96	1500-2037	203	61
Avg		220	66
(Line 2 Dryer RTO Stack)			
*3-19-96	1320-1420	202	62
3-20-96	1000-1100	266	84
3-20-96	1200-1300	218	69
Avg		229	72
(Line 2 Core Dryer Duct)			
*3-19-96	1320-1420	693	86
3-20-96	1000-1100	1282	164
3-20-96	1200-1300	1131	142
Avg		1035	131
(Line 2 Surface Dryer Duct)			
*3-19-96	1320-1420	2328	277
3-20-96	1000-1100	2002	241
3-20-96	1200-1300	1588	193
Avg		1973	237
(Line 2 Press Vent RTO Stack)			
3-20-96	1012-1114	22	6.7
3-20-96	1135-1241	23	7.1
3-20-96	1305-1411	23	7.0
Avg		23	6.9
(Line 2 Press Vent RTO Stack)			
3-20-96	1650-1750	19	5.6
3-20-96	1815-1915	21	6.3
3-20-96	2015-2112	20	5.6
Avg		20	5.8

* E-TUBE H₂O ON

Table 6b. Summary of the Results of the March 18 - 20, 1996 Carbon Monoxide Determinations at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppm,d)	Emission Rate (LB/HR)
(Line 2 Press Vent RTO Inlet)			
3-20-96	1650-1750	11	3.7
3-20-96	1815-1915	8	2.7
3-20-96	2015-2115	13	4.4
Avg		11	3.6
(Line 2 Thermal Oil Heater Stack)			
3-18-96	1036-1136	156	11.9
3-18-96	1220-1320	289	21.4
3-18-96	1405-1505	210	16.2
Avg		218	16.5

Table 7. Summary of the Results of the March 19 & 20, 1996 Total Hydrocarbons Determinations at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppmC,w)	Emission Rate (LB/HR)
(Line 2 Dryer RTO Stack)**			
* 3-19-96	1320-1420	29	5.2
3-20-96	1000-1100	35	6.3
3-20-96	1200-1300	29	5.2
Avg		31	5.6
(Line 2 Core Dryer Duct)			
* 3-19-96	1320-1420	526	37
3-20-96	1000-1100	906	67
3-20-96	1200-1300	759	56
Avg		730	53
(Line 2 Surface Dryer Duct)			
<i>NOT ON SURFACE</i> * 3-19-96	1320-1420	692	49
3-20-96	1000-1100	802	58
3-20-96	1200-1300	817	59
Avg		770	56
(Line 2 Press Vent RTO Stack)			
3-20-96	1650-1750	4	0.5
3-20-96	1815-1915	18	2.4
3-20-96	2015-2112	2	0.2
Avg		8	1.0
(Line 2 Press Vent RTO Inlet)			
3-20-96	1650-1750	118	17.3
3-20-96	1815-1915	112	16.5
3-20-96	2015-2112	77	11.4
Avg		102	15.1

* E-TUBE H₂O ON

** TGNMO = Total Gaseous Non-Methane Organics

Table 8. Summary of the Results of the March 18 - 20, 1996 **Formaldehyde Determinations** at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppm,d)	Emission Rate (LB/HR)
(Line 2 Dryer RTO Stack)			
3-20-96	0830-1017	7.4	2.5
3-20-96	1100-1210	10.0	3.4
3-20-96	1245-1354	9.4	3.2
Avg		8.9	3.0
(Line 2 Press Vent RTO Stack)			
3-19-96	1030-1145	0.33	0.11
3-19-96	1222-1336	0.27	0.09
3-19-96	1440-1554	0.32	0.11
Avg		0.31	0.10
(Line 2 Thermal Oil Heater Stack)			
3-18-96	1036-1142	0.11	0.0090
3-18-96	1220-1323	0.15	0.012
3-18-96	1405-1510	0.10	0.0085
Avg		0.12	0.0098

Table 9. Summary of the Results of the March 18 & 21, 1996 Benzene Determinations at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppm,d)	Emission Rate (LB/HR)
(Line 2 Dryer RTO Stack)			
3-21-96	0816-0906	0.11	0.10
3-21-96	0939-1039	0.17	0.15
3-21-96	1135-1235	0.08	0.10
Avg		0.12	0.12
(Line 2 Thermal Oil Heater Stack)			
3-18-96	1800-1900	< 0.011	< 0.002
3-18-96	1930-2030	0.18	0.035
3-18-96	2100-2200	0.48	0.096
Avg		≤ 0.22	≤ 0.044

Table 10. Summary of the Results of the March 19, 1996 **Phenol Determinations** at the Louisiana Pacific Plant in Hayward, Wisconsin.

Date	Time	Concentration (ppb,d)	Emission Rate (10 ⁻³ LB/HR)
(Line 2 Dryer RTO Stack)			
3-19-96	1030-1138	< 175	< 176
*3-19-96	1320-1424	< 177	< 183
3-19-96	1500-2035	< 178	< 181
Avg		< 177	< 180

* E-TUBE H₂O ON

Table 11 Summary of the Results of the March 20 & 21, 1996 PAH Determinations of the Line 2 Dryer RTO Stack at the Louisiana Pacific Plant in Hayward, Wisconsin.

Item	RUN 1	* RUN 2	RUN 3
(Concentration ug/Nm ³)			
Benzo-a-anthracene	.55<	.56<	.55<
Benzo-b-fluoranthene	.30<	.31<	.31<
Benzo-a-pyrene	.37<	.37<	.37<
Dibenzo-a,h-anthracene	.27<	.27<	.27<
Indeno,1,2,3-pyrene	.27<	.28<	.28<
Dibenzo-a,i-pyrene	6.1<	6.2<	6.2<
Dibenzo-a,h-acridine	4.6<	4.6<	4.6<
Dibenzo-a,j-acridine	.49<	.49<	.49<
7H-Dibenzo-c,g-carbazole	.37<	.37<	.37<
Dibenzo-a,h-pyrene	6.1<	6.2<	6.2<
(Emission Rate 10 ⁻⁶ g/sec)			
Benzo-a-anthracene	19<	19<	19<
Benzo-b-fluoranthene	10<	10<	10<
Benzo-a-pyrene	13<	13<	13<
Dibenzo-a,h-anthracene	9.2<	9.3<	9.3<
Indeno,1,2,3-pyrene	9.4<	9.5<	9.5<
Dibenzo-a,i-pyrene	209<	212<	212<
Dibenzo-a,h-acridine	157<	159<	159<
Dibenzo-a,j-acridine	17<	17<	17<
7H-Dibenzo-c,g-carbazole	13<	13<	13<
Dibenzo-a,h-pyrene	209<	212<	212<

* E-TUBE H₂O ON.

3 RESULTS

The results of all field and laboratory evaluations are presented in this section. Gas composition results (Orsat and moisture) are presented first followed by the computer printout of the gas composition, particulate, oxides of nitrogen, opacity, carbon monoxide, total hydrocarbons, formaldehyde, phenol, benzene, and PAH determinations . Preliminary measurements including test port locations are given in the appendices.

The results have been calculated on a personal computer using programs written in Extended BASIC specifically for source testing calculations. EPA-published equations have been used as the basis of the calculation techniques in these program. Emission rates have been calculated using the product of the concentration times flow method.

3.1 Results of Orsat and Moisture Analyses

Test No. 1
Line 2 Dryer RTO Stack

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

Date of run	Run 1 03-19-96	Run 2 03-19-96	Run 3 03-19-96
Dry basis (orsat)			
carbon dioxide.....	4.20	4.00	4.30
oxygen.....	15.80	16.10	15.80
nitrogen.....	80.00	79.90	79.90
Wet basis (orsat)			
carbon dioxide.....	3.11	2.93	3.14
oxygen.....	11.72	11.80	11.53
nitrogen.....	59.32	58.54	58.29
water vapor.....	25.85	26.73	27.04
Dry molecular weight.....	29.30	29.28	29.32
Wet molecular weight.....	26.38	26.27	26.26
Specific gravity.....	0.911	0.907	0.907
Water mass flow.....(LB/HR)	67336	72399	71991
FO	1.214	1.200	1.186

Test No. 3
Line 2 Dryer RTO Stack

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

Date of run	Run 1 03-20-96	Run 2 03-21-96	Run 3 03-21-96
Dry basis (orsat)			
carbon dioxide.....	4.30	4.30	4.20
oxygen.....	15.70	15.80	15.90
nitrogen.....	80.00	79.90	79.90
Wet basis (orsat)			
carbon dioxide.....	3.18	3.22	3.14
oxygen.....	11.61	11.83	11.88
nitrogen.....	59.16	59.84	59.68
water vapor.....	26.05	25.11	25.31
Dry molecular weight.....	29.32	29.32	29.31
Wet molecular weight.....	26.37	26.48	26.45
Specific gravity.....	0.911	0.915	0.914
Water mass flow.....(LB/HR)	0.00	0.00	0.00
FO	1.209	1.186	1.190

Test No. 4
Line 2 Dryer RTO Stack

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

Date of run	Run 1 03-20-96	Run 2 03-20-96	Run 3 03-20-96
-------------	-------------------	-------------------	-------------------

Dry basis (orsat)

carbon dioxide.....	4.00	4.10	4.20
oxygen.....	16.10	16.00	15.90
nitrogen.....	79.90	79.90	79.90

Wet basis (orsat)

carbon dioxide.....	3.06	3.05	3.15
oxygen.....	12.31	11.90	11.93
nitrogen.....	61.10	59.42	59.97
water vapor.....	23.53	25.63	24.95
Dry molecular weight.....	29.28	29.30	29.31
Wet molecular weight.....	26.63	26.40	26.49
Specific gravity.....	0.920	0.912	0.915
Water mass flow.....(LB/HR)	0.00	0.00	0.00

FO	1.200	1.195	1.190
----	-------	-------	-------

Test No. 9
Line 2 Press Vent RTO Stack

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

Date of run	Run 1 03-19-96	Run 2 03-19-96	Run 3 03-19-96
-------------	-------------------	-------------------	-------------------

Dry basis (orsat)

carbon dioxide.....	0.03	0.03	0.03
oxygen.....	20.90	20.90	20.90
nitrogen.....	79.07	79.07	79.07

Wet basis (orsat)

carbon dioxide.....	0.03	0.03	0.03
oxygen.....	20.69	20.71	20.63
nitrogen.....	78.29	78.35	78.06
water vapor.....	0.99	0.91	1.28
Dry molecular weight.....	28.84	28.84	28.84
Wet molecular weight.....	28.73	28.74	28.70
Specific gravity.....	0.993	0.993	0.991
Water mass flow.....(LB/HR)	0.00	0.00	0.00

Test No. 10
Line 2 Press Vent RTO Stack

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

	Run 1	Run 2	Run 3
Date of run	03-20-96	03-20-96	03-20-96

Dry basis (orsat)

carbon dioxide.....	0.03	0.03	0.03
oxygen.....	20.90	20.90	20.90
nitrogen.....	79.07	79.07	79.07

Wet basis (orsat)

carbon dioxide.....	0.03	0.03	0.03
oxygen.....	20.57	20.56	20.38
nitrogen.....	77.84	77.76	77.12
water vapor.....	1.56	1.65	2.47
Dry molecular weight.....	28.84	28.84	28.84
Wet molecular weight.....	28.67	28.66	28.57
Specific gravity.....	0.990	0.990	0.987
Water mass flow.....(LB/HR)	3101	3309	4938

Test No. 13
Line 2 Konus Stack

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

Date of run	Run 1 03-18-96	Run 2 03-18-96	Run 3 03-18-96
-------------	-------------------	-------------------	-------------------

Dry basis (orsat)

carbon dioxide.....	5.40	6.20	6.30
oxygen.....	15.50	13.80	13.40
nitrogen.....	79.10	80.00	80.30

Wet basis (orsat)

carbon dioxide.....	4.90	5.52	5.91
oxygen.....	14.07	12.28	12.57
nitrogen.....	71.78	71.19	75.32
water vapor.....	9.25	11.01	6.20

Dry molecular weight.....	29.48	29.54	29.54
Wet molecular weight.....	28.42	28.27	28.83
Specific gravity.....	0.982	0.977	0.996
Water mass flow.....(LB/HR)	0.00	0.00	0.00

FO	1.000	1.145	1.190
----	-------	-------	-------

Test No. 14
Line 2 Konus Stack

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

	Run 1	Run 2	Run 3
Date of run	03-19-96	03-19-96	03-19-96

Dry basis (orsat)

carbon dioxide.....	6.40	7.40	8.30
oxygen.....	13.60	12.50	11.60
nitrogen.....	80.00	80.10	80.10

Wet basis (orsat)

carbon dioxide.....	5.73	6.46	7.28
oxygen.....	12.17	10.91	10.18
nitrogen.....	71.60	69.93	70.27
water vapor.....	10.50	12.69	12.27

Dry molecular weight.....	29.57	29.68	29.79
Wet molecular weight.....	28.35	28.20	28.34
Specific gravity.....	0.979	0.974	0.979
Water mass flow.....(LB/HR)	5537	6560	6394

FO	1.141	1.135	1.120
----	-------	-------	-------

Test No. 17
Line 2 Dryer RTO Inlet

Results of Orsat & Moisture Analyses-----Methods 3 & 4(%v/v)

Date of run	Run 1 03-19-96	Run 2 03-19-96	Run 3 03-19-96
-------------	-------------------	-------------------	-------------------

Dry basis (orsat)

carbon dioxide.....	4.20	4.00	4.20
oxygen.....	15.90	16.20	15.90
nitrogen.....	79.90	79.80	79.90

Wet basis (orsat)

carbon dioxide.....	3.15	2.94	3.14
oxygen.....	11.92	11.89	11.90
nitrogen.....	59.89	58.59	59.81
water vapor.....	25.05	26.57	25.14
Dry molecular weight.....	29.31	29.29	29.31
Wet molecular weight.....	26.48	26.29	26.46
Specific gravity.....	0.915	0.908	0.914
Water mass flow.....(LB/HR)	58602	63546	60072

FO	1.190	1.175	1.190
----	-------	-------	-------

3.2 Results of Particulate Loading Determinations

Test No. 1
Line 2 Dryer RTO Stack

Results of Particulate Loading Determinations-----Method 5

	Run 1 03-19-96	Run 2 03-19-96	Run 3 03-19-96
Date of run			
Time run start/end.....(HRS)	1030/1140	1320/1429	1500/2037
Static pressure.....(IN.WC)	-0.65	-0.65	-0.65
Cross sectional area (SQ.FT)	36.23	36.23	36.23
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	311.0	304.0	315.0
desiccant.....(GRAMS)	7.0	15.0	8.0
total.....(GRAMS)	318.0	319.0	323.0
Total particulate material..			
.....collected(grams)	0.0143	0.0292	0.0173
Gas meter coefficient.....	1.0054	1.0054	1.0054
Barometric pressure..(IN.HG)	28.78	28.78	28.78
Avg. orif.pres.drop..(IN.WC)	1.57	1.46	1.45
Avg. gas meter temp..(DEF-F)	66.9	73.1	71.2
Volume through gas meter....			
at meter conditions...(CF)	44.22	42.89	42.60
standard conditions.(DSCF)	43.01	41.22	41.09
Total sampling time....(MIN)	64.00	64.00	64.00
Nozzle diameter.....(IN)	.247	.247	.247
Avg.stack gas temp ..(DEG-F)	262	264	263
Volumetric flow rate.....			
actual.....(ACFM)	132280	137925	135372
dry standard.....(DSCFM)	68859	70732	69238
Isokinetic variation.....(%)	106.3	99.2	101.0
Particulate concentration...			
actual.....(GR/ACF)	0.00267	0.00560	0.00332
dry standard.....(GR/DSCF)	0.00513	0.01093	0.00650
Particle mass rate...(LB/HR)	3.028	6.627	3.856

Test No. 10
Line 2 Press Vent RTO Stack

Results of Particulate Loading Determinations-----Method 5

Date of run	Run 1 03-20-96	Run 2 03-20-96	Run 3 03-20-96
Time run start/end.....(HRS)	1012/1114	1135/1241	1305/1411
Static pressure.....(IN.WC)	-0.40	-0.40	-0.40
Cross sectional area (SQ.FT)	31.71	31.71	31.71
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	4.0	-2.0	9.0
desiccant.....(GRAMS)	11.0	18.0	15.0
total.....(GRAMS)	15.0	16.0	24.0
Total particulate material..collected(grams)	0.0122	0.0028	0.0040
Gas meter coefficient.....	0.9936	0.9936	0.9936
Barometric pressure..(IN.HG)	29.31	29.31	29.31
Avg. orif.pres.drop..(IN.WC)	1.81	1.85	1.84
Avg. gas meter temp..(DEF-F)	61.4	68.6	69.6
Volume through gas meter....			
at meter conditions...(CF)	45.19	46.04	45.89
standard conditions.(DSCF)	44.73	44.95	44.72
Total sampling time....(MIN)	60.00	60.00	60.00
Nozzle diameter.....(IN)	.249	.249	.249
Avg.stack gas temp ..(DEG-F)	233	233	233
Volumetric flow rate.....			
actual.....(ACFM)	95284	95834	95693
dry standard.....(DSCFM)	69923	70293	69564
Isokinetic variation.....(%)	100.0	100.0	100.5
Particulate concentration...			
actual.....(GR/ACF)	0.00309	0.00070	0.00100
dry standard.....(GR/DSCF)	0.00421	0.00096	0.00138
Particle mass rate...(LB/HR)	2.523	0.579	0.823

Test No. 14
Line 2 Konus Stack

Results of Particulate Loading Determinations-----Method 5

	Run 1 03-19-96	Run 2 03-19-96	Run 3 03-19-96
Date of run			
Time run start/end.....(HRS)	1800/1903	1930/2032	2100/2202
Static pressure.....(IN.WC)	-0.35	-0.35	-0.35
Cross sectional area (SQ.FT)	14.47	14.47	14.47
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	80.0	101.0	98.0
desiccant.....(GRAMS)	12.0	10.0	9.0
total.....(GRAMS)	92.0	111.0	107.0
Total particulate material..			
.....collected(grams)	0.1004	0.1076	0.1122
Gas meter coefficient.....	0.9964	0.9964	0.9964
Barometric pressure...(IN.HG)	28.69	28.69	28.69
Avg. orif.pres.drop...(IN.WC)	1.21	1.19	1.21
Avg. gas meter temp...(DEF-F)	50.6	66.1	71.8
Volume through gas meter....			
at meter conditions...(CF)	37.34	37.45	37.91
standard conditions.(DSCF)	36.99	36.01	36.06
Total sampling time....(MIN)	60.00	60.00	60.00
Nozzle diameter.....(IN)	.311	.311	.311
Avg.stack gas temp ..(DEG-F)	391	410	419
Volumetric flow rate.....			
actual.....(ACFM)	31644	31697	32275
dry standard.....(DSCFM)	16834	16089	16292
Isokinetic variation.....(%)	100.5	102.3	101.2
Particulate concentration...			
actual.....(GR/ACF)	0.02227	0.02340	0.02423
dry standard.....(GR/DSCF)	0.04188	0.04611	0.04801
Particle mass rate...(LB/HR)	6.043	6.359	6.705
F-factor(DSCF/MMBTU)	9600	9600	9600
Emission factor...(LB/MMBTU)	0.164	0.157	0.148

Test No. 17
Line 2 Dryer RTO Inlet

Results of Particulate Loading Determinations-----Method 5

	Run 1	Run 2	Run 3
Date of run	03-19-96	03-19-96	03-19-96
Time run start/end.....(HRS)	1030/1133	1320/1421	1900/2032
Static pressure.....(IN.WC)	-1.50	-1.50	-1.50
Cross sectional area (SQ.FT)	22.87	22.87	22.87
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	243.0	243.0	225.0
desiccant.....(GRAMS)	2.0	12.0	10.0
total.....(GRAMS)	245.0	255.0	235.0
Total particulate material..			
.....collected(grams)	0.0665	0.0760	0.1195
Gas meter coefficient.....	1.0042	1.0042	1.0042
Barometric pressure..(IN.HG)	28.78	28.78	28.78
Avg. orif.pres.drop..(IN.WC)	1.09	1.02	1.02
Avg. gas meter temp..(DEF-F)	48.9	51.9	53.8
Volume through gas meter....			
at meter conditions...(CF)	34.41	33.27	33.16
standard conditions.(DSCF)	34.57	33.22	32.99
Total sampling time....(MIN)	60.00	60.00	60.00
Nozzle diameter.....(IN)	.189	.189	.189
Avg.stack gas temp ..(DEG-F)	167	170	171
Volumetric flow rate.....			
actual.....(ACFM)	103347	106118	106293
dry standard.....(DSCFM)	62517	62594	63759
Isokinetic variation.....(%)	108.2	103.9	101.3
Particulate concentration...			
actual.....(GR/ACF)	0.01795	0.02081	0.03352
dry standard.....(GR/DSCF)	0.02968	0.03530	0.05590
Particle mass rate...(LB/HR)	15.906	18.939	30.547

105.253
188.870
62957

3.3 Results of Oxides of Nitrogen Determinations

Test No. 6
Line 2 Dryer RTO Stack

Results of Oxides of Nitrogen Determinations **Method 7E**

	Run 1	Run 2	Run 3
Date of run	3-19-96	3-20-96	3-20-96
Time run start/end (HRS)	1320-1420	1000-1100	1200-1300
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	26.7	25.0	25.0
Oxygen content (%V/V)	16.2	16.4	16.3
Volumetric flow rate (DSCFM)	70700	72250	72250
NO _x concentration (ppm,d)	15	13	20
NO _x emission rate (LB/HR)	7.7	6.9	10.1

Test No. 7
Line 2 Core Dryer Duct

Results of Oxides of Nitrogen Determinations ~~Method 7E~~

	Run 1	Run 2	Run 3
Date of run	3-19-96	3-20-96	3-20-96
Time run start/end (HRS)	1320-1420	1000-1100	1200-1300
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	24.7	25.4	26.9
Oxygen content (%V/V)	16.0	16.3	12.9
Volumetric flow rate (DSCFM)	28356	29359	28827
NO _x concentration (ppm,d)	23	23	24
NO _x emission rate (LB/HR)	4.7	4.9	4.9

28,847

Test No. 8
Line 2 Surface Dryer Duct

Results of Oxides of Nitrogen Determinations **Method 7E**

	Run 1	Run 2	Run 3
Date of run	3-19-96	3-20-96	3-20-96
Time run start/end (HRS)	1320-1420	1000-1100	1200-1300
Total sampling time (MIN)	60	60	60
Moisture content (% V/V)	28.6	28.7	28.3
Oxygen content (% V/V)	14.7	15.1	15.2
Volumetric flow rate (DSCFM)	27324	27592	27872
NO _x concentration (ppm,d)	30	30	32
NO _x emission rate (LB/HR)	5.9	6.0	6.3

Test No. 11
Line 2 Press Vent RTO Stack

Results of Oxides of Nitrogen Determinations-----**Method 7E**

	Run 1	Run 2	Run 3
Date of run	3-20-96	3-20-96	3-20-96
Time run start/end (HRS)	1650-1750	1815-1915	2015-2115
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	2.2	1.7	2.0
Oxygen content (%V/V)	20.9	20.9	20.9
Volumetric flow rate (DSCFM)	67950	68965	64190
NO _x concentration (ppm,d)	22	20	19
NO _x emission rate (LB/HR)	10.9	10.0	8.5

Test No. 12
Line 2 Press RTO Inlet

Results of Oxides of Nitrogen Determinations ~~Method 7E~~

	Run 1	Run 2	Run 3
Date of run	3-20-96	3-20-96	3-20-96
Time run start/end (HRS)	1650-1750	1815-1915	2015-2112
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	2.4	2.4	2.2
Oxygen content (%V/V)	20.9	20.9	20.9
Volumetric flow rate (DSCFM)	76340	77090	77445
NO _x concentration (ppm,d)	2.1	2.7	3.1
NO _x emission rate (LB/HR)	1.1	1.5	1.7

Test No. 16
Line 2 Thermal Oil Heater Stack

Results of Oxides of Nitrogen Determinations ~~Method 7E~~

	Run 1	Run 2	Run 3
Date of run	3-18-96	3-18-96	3-18-96
Time run start/end (HRS)	1036-1136	1220-1320	1405-1505
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	9.3	11.0	6.2
Oxygen content (%V/V)	15.3	13.8	13.4
Volumetric flow rate (DSCFM)	17550	16980	17670
NO _x concentration (ppm,d)	61	63	63
NO _x emission rate (LB/HR)	7.6	7.6	8.0

Test No. 17
Line 2 Dryer RTO Inlet

Results of Oxides of Nitrogen (NOx) Determinations-----Method 7

	Run 1A	Run 1B	Run 1C	Run 1D
Date of run.....	03-19-96	03-19-96	03-19-96	03-19-96
Time of run.....(HRS)	1034	1045	1059	1116
Flask number.....	19	20	21	22
Volume of flask.....(ML)	2069	2060	2068	2031

Data: time of sampling

flask temperature..(DEG-F)	40.00	41.00	41.00	42.00
bar. press.....(IN.HG)	28.78	28.78	28.78	28.78
flask vacuum.....(IN.HG)	26.04	26.07	26.16	26.04
flask abs. press...(IN.HG)	2.74	2.71	2.62	2.74

Data: Time of Flask Opening

flask temperature..(DEG-F)	64.00	65.00	65.00	65.00
lab. bar. press....(IN.HG)	29.33	29.33	29.33	29.33
flask static press.(IN.HG)	-0.37	-0.32	2.27	0.20
flask abs. press...(IN.HG)	28.96	29.01	31.60	29.53
Volume gas sampled....(DSML)	1795	1789	1981	1797
Moisture content.....(%V/V)	25.05	25.05	25.05	25.05
Oxygen content.....(%V/V, DRY)	15.90	15.90	15.90	15.90
Nitrate in gas sample...(JG)	33.5	35.0	44.0	45.0
NO2 in gas sample.....(JG)	24.9	26.0	32.6	33.4

NOx Concentration

(GR/DSCF).....	0.0061	0.0063	0.0072	0.0081
(MG/DSCM).....	14	15	16	19
(PPM-DRY).....	7	8	9	10
(PPM-WET).....	5	6	6	7
NOX Emission rate....(LB/HR)	3.24	3.40	3.86	4.35
NOx emission factor.....				
.....(LB/MMBTU)*	0.031	0.033	0.037	0.042

* F = 8710 DSCF/MMBTU

Test No. 17
Line 2 Dryer RTO Inlet

Results of Oxides of Nitrogen (NOx) Determinations-----Method 7

	Run 2A	Run 2B	Run 2C	Run 2D
Date of run.....	03-19-96	03-19-96	03-19-96	03-19-96
Time of run.....(HRS)	1325	1335	1350	1405
Flask number.....	23	24	31	32
Volume of flask.....(ML)	2056	2031	2009	2092
Data: time of sampling				
flask temperature..(DEG-F)	40.00	38.00	36.00	36.00
bar. press.....(IN.HG)	28.78	28.78	28.78	28.78
flask vacuum.....(IN.HG)	26.02	26.06	26.07	26.02
flask abs. press...(IN.HG)	2.76	2.72	2.71	2.76
Data: Time of Flask Opening				
flask temperature..(DEG-F)	66.00	64.00	67.00	66.00
lab. bar. press....(IN.HG)	29.33	29.33	29.33	29.33
flask static press.(IN.HG)	0.20	-0.58	1.47	-0.06
flask abs. press...(IN.HG)	29.53	28.75	30.80	29.27
Volume gas sampled....(DSML)	1814	1748	1854	1826
Moisture content.....(%V/V)	26.57	26.57	26.57	26.57
Oxygen content.....(%V/V, DRY)	16.20	16.20	16.20	16.20
Nitrate in gas sample...(JG)	38.0	40.0	25.5	35.0
NO2 in gas sample.....(JG)	28.2	29.7	18.9	26.0
<u>NOx Concentration</u>				
(GR/DSCF).....	0.0068	0.0074	0.0045	0.0062
(MG/DSCM).....	16	17	10	14
(PPM-DRY).....	8	9	5	7
(PPM-WET).....	6	7	4	5
NOx Emission rate....(LB/HR)	3.64	3.98	2.39	3.33
NOx emission factor.....				
.....(LB/MMBTU)*	0.038	0.041	0.025	0.034

* F = 8710 DSCF/MMBTU

Test No. 17
Line 2 Dryer RTO Inlet

Results of Oxides of Nitrogen (NOx) Determinations-----Method 7

	Run 3A	Run 3B	Run 3C	Run 3D
Date of run.....	03-19-96	03-19-96	03-19-96	03-19-96
Time of run.....(HRS)	1936	1949	2000	2012
Flask number.....	33	34	35	36
Volume of flask.....(ML)	2088	2071	2071	2127
Data: time of sampling				
flask temperature..(DEG-F)	34.00	32.00	33.00	31.00
bar. press.....(IN.HG)	28.78	28.78	28.78	28.78
flask vacuum.....(IN.HG)	26.01	26.04	26.04	26.03
flask abs. press...(IN.HG)	2.77	2.74	2.74	2.75
Data: Time of Flask Opening				
flask temperature..(DEG-F)	67.00	67.00	66.00	66.00
lab. bar. press....(IN.HG)	29.33	29.33	29.33	29.33
flask static press.(IN.HG)	0.29	0.28	0.15	0.04
flask abs. press...(IN.HG)	29.62	29.61	29.48	29.37
Volume gas sampled....(DSML)	1841	1827	1822	1863
Moisture content.....(%V/V)	25.14	25.14	25.14	25.14
Oxygen content.....(%V/V, DRY)	15.90	15.90	15.90	15.90
Nitrate in gas sample...(JG)	48.0	70.0	56.5	47.0
NO2 in gas sample.....(JG)	35.6	51.9	41.9	34.9
<u>NOx Concentration</u>				
(GR/DSCF).....	0.0085	0.0124	0.0101	0.0082
(MG/DSCM).....	19	28	23	19
(PPM-DRY).....	10	15	12	10
(PPM-WET).....	8	11	9	7
NOx Emission rate....(LB/HR)	4.62	6.79	5.49	4.47
NOx emission factor.....				
.....(LB/MMBTU)*	0.044	0.065	0.052	0.043

* F = 8710 DSCF/MMBTU

3.4 Results of Opacity Observations

Test No. 1
Line 2 Dryer RTO Stack

Results of Opacity Observations ----- EPA Method 9

PERCENT OPACITY	OPTICAL DENSITY	RELATIVE FREQUENCY (%)
0	0.0000	100.00
5	0.0223	0.00
10	0.0458	0.00
15	0.0706	0.00
20	0.0969	0.00
25	0.1249	0.00
30	0.1549	0.00
35	0.1871	0.00
40	0.2219	0.00
45	0.2596	0.00
50	0.3010	0.00
55	0.3468	0.00
60	0.3979	0.00
65	0.4559	0.00
70	0.5229	0.00
75	0.6021	0.00
80	0.6690	0.00
85	0.8239	0.00
90	1.0000	0.00
95	1.3010	0.00
99	2.0000	0.00
Avg Opac 0.00	Avg OD 0.0000	Time average

Observer: Sheryl Bergeron
Cert. Date: 10-04-95
Date of Observation: 03-19-96
Time of Observation: 1030/1130

Test No. 10
Line 2 Press Vent RTO Stack

Results of Opacity Observations ----- EPA Method 9

PERCENT OPACITY	OPTICAL DENSITY	RELATIVE FREQUENCY (%)
0	0.0000	100.00
5	0.0223	0.00
10	0.0458	0.00
15	0.0706	0.00
20	0.0969	0.00
25	0.1249	0.00
30	0.1549	0.00
35	0.1871	0.00
40	0.2219	0.00
45	0.2596	0.00
50	0.3010	0.00
55	0.3468	0.00
60	0.3979	0.00
65	0.4559	0.00
70	0.5229	0.00
75	0.6021	0.00
80	0.6690	0.00
85	0.8239	0.00
90	1.0000	0.00
95	1.3010	0.00
99	2.0000	0.00
Avg Opac 0.00	Avg OD 0.0000	Time average

Observer: Sheryl Bergeron
Cert. Date: 10-04-95
Date of Observation: 03-20-96
Time of Observation: 1014/1114

Test No. 14
Line 2 Thermal Oil Heater Stack

Results of Opacity Observations ----- EPA Method 9

PERCENT OPACITY	OPTICAL DENSITY	RELATIVE FREQUENCY (%)
0	0.0000	96.25
5	0.0223	2.50
10	0.0458	1.25
15	0.0706	0.00
20	0.0969	0.00
25	0.1249	0.00
30	0.1549	0.00
35	0.1871	0.00
40	0.2219	0.00
45	0.2596	0.00
50	0.3010	0.00
55	0.3468	0.00
60	0.3979	0.00
65	0.4559	0.00
70	0.5229	0.00
75	0.6021	0.00
80	0.6690	0.00
85	0.8239	0.00
90	1.0000	0.00
95	1.3010	0.00
99	2.0000	0.00
Avg Opac 0.25	Avg OD 0.0011	Time average

Observer: Sheryl Bergeron
Cert. Date: 10-04-95
Date of Observation: 03-19-96
Time of Observation: 0758/0858

3.5 Results of Carbon Monoxide Determinations

Test No. 1
Line 2 Dryer RTO Stack

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	03-19-96	03-19-96	03-19-96
Time run start/end.....(HRS)	1030/1140	1320/1429	1500/2037
Total sampling time....(MIN)	64.0	64.0	64.0
Moisture content.....(%V/V)	25.85	26.73	26.27
O2 Concentration.....(%V/V)	15.80	16.10	15.80
Volumetric flow rate (DSCFM)	68840	70701	69223
CO concentration.....			
(GR/DSCF).....	0.1313	0.1008	0.1033
(MG/DSCM).....	300.57	230.67	236.50
(PPM-WET).....	191.31	145.07	149.67
(PPM-DRY).....	258.00	198.00	203.00
(PPM-DRY @ 7% O2).....	694.62	565.71	546.54
CO emission rate.....(LB/HR)	77.461	61.054	61.287

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 6
Line 2 Dryer RTO Stack

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	03-19-96	03-20-96	03-20-96
Time run start/end.....(HRS)	1320-1420	1000-1100	1200-1300
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	26.70	25.00	25.00
O2 Concentration.....(%V/V)	16.30	16.50	16.30
Volumetric flow rate (DSCFM)	70700	72250	72250
CO concentration.....			
(GR/DSCF).....	0.1028	0.1354	0.1109
(MG/DSCM).....	235.33	309.89	253.97
(PPM-WET).....	148.07	199.50	163.50
(PPM-DRY).....	202.00	266.00	218.00
(PPM-DRY @ 7% O2).....	601.70	827.56	649.36
CO emission rate.....(LB/HR)	62.286	83.819	68.693

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 7
Line 2 Core Dryer Duct

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	03-19-96	03-20-96	03-20-96
Time run start/end.....(HRS)	1320-1420	1000-1100	1200-1300
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	24.70	25.40	26.90
O2 Concentration.....(%V/V)	16.40	15.70	15.90
Volumetric flow rate (DSCFM)	28356	29359	28827
CO concentration.....			
(GR/DSCF).....	0.3526	0.6523	0.5755
(MG/DSCM).....	807.35	1493.	1317.
(PPM-WET).....	521.83	956.37	826.76
(PPM-DRY).....	693.00	1282.	1131.
(PPM-DRY @ 7% O2).....	2109.	3386.	3104.
CO emission rate.....(LB/HR)	85.704	164.154	142.195

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 8
Line 2 Surface Dryer Duct

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	03-19-96	03-20-96	03-20-96
Time run start/end.....(HRS)	1320-1420	1000-1100	1200-1300
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	28.60	28.70	28.30
O2 Concentration.....(%V/V)	14.70	15.10	15.20
Volumetric flow rate (DSCFM)	27324	27592	27872
CO concentration.....			
(GR/DSCF).....	1.1846	1.0187	0.8081
(MG/DSCM).....	2712.	2332.	1850.
(PPM-WET).....	1662.	1427.	1138.
(PPM-DRY).....	2328.	2002.	1588.
(PPM-DRY @ 7% O2).....	5173.	4750.	3833.
CO emission rate.....(LB/HR)	277.427	240.918	193.037

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 10
Line 2 Press Vent RTO Stack

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	03-20-96	03-20-96	03-20-96
Time run start/end.....(HRS)	1012/1114	1135/1241	1305/1411
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	1.60	1.70	2.50
O2 Concentration.....(%V/V)	20.90	20.90	20.90
Volumetric flow rate (DSCFM)	69920	70290	69560
CO concentration.....			
(GR/DSCF).....	0.0112	0.0117	0.0117
(MG/DSCM).....	25.63	26.79	26.79
(PPM-WET).....	21.65	22.61	22.43
(PPM-DRY).....	22.00	23.00	23.00
CO emission rate.....(LB/HR)	6.709	7.051	6.978

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 11
Line 2 Press Vent RT0 Stack

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	03-20-96	03-20-96	03-20-96
Time run start/end.....(HRS)	1650-1750	1815-1915	2015-2115
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	2.16	1.65	1.97
O2 Concentration.....(%V/V)	20.90	20.90	20.90
Volumetric flow rate (DSCFM)	67951	68965	64190
CO concentration.....			
(GR/DSCF).....	0.0097	0.0107	0.0102
(MG/DSCM).....	22.13	24.47	23.30
(PPM-WET).....	18.59	20.65	19.61
(PPM-DRY).....	19.00	21.00	20.00
CO emission rate.....(LB/HR)	5.631	6.316	5.599

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 12
Line 2 Press Vent RTO Inlet

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	03-20-96	03-20-96	03-20-96
Time run start/end.....(HRS)	1650-1750	1815-1915	2015-2115
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	2.41	2.35	2.18
O2 Concentration.....(%V/V)	20.90	20.90	20.90
Volumetric flow rate (DSCFM)	76341	77087	77444
CO concentration.....			
(GR/DSCF).....	0.0056	0.0041	0.0066
(MG/DSCM).....	12.82	9.32	15.15
(PPM-WET).....	10.73	7.81	12.72
(PPM-DRY).....	11.00	8.00	13.00
CO emission rate.....(LB/HR)	3.662	2.690	4.391

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 16
Line 2 Thermal Oil Heater Stack

Results of CO Determinations -----Method 10

	Run 1	Run 2	Run 3
Date of run	03-18-96	03-18-96	03-18-96
Time run start/end.....(HRS)	1036-1136	1220-1320	1405-1505
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	9.30	11.00	6.20
O2 Concentration.....(%V/V)	15.30	13.80	13.40
Volumetric flow rate (DSCFM)	17550	16980	17670
CO concentration.....			
(GR/DSCF).....	0.0794	0.1471	0.1069
(MG/DSCM).....	181.74	336.69	244.65
(PPM-WET).....	141.49	257.21	196.98
(PPM-DRY).....	156.00	289.00	210.00
(PPM-DRY @ 7% O2).....	383.16	561.94	386.84
CO emission rate.....(LB/HR)	11.941	21.402	16.184

CO = Carbon monoxide

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

3.6 Results of Total Hydrocarbons Determinations

Interpoll Labs Report No. 6-7451
Louisiana Pacific Corporation
Hayward, Wisconsin

Test No. 6
Line 2 Dryer RTO Stack

Results of Total Hydrocarbons Determinations ~~Method 25A~~

	Run 1	Run 2	Run 3
Date of run	3-19-96	3-20-96	3-20-96
Time run start/end (HRS)	1320-1420	1000-1100	1200-1300
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	26.7	25.0	25.0
Oxygen content (%V/V)	16.2	16.4	16.3
Volumetric flow rate (DSCFM)	70700	72250	72250
THC concentration (ppmC,w)	29	35	29
THC emission rate (LB/HR)	5.2	6.3	5.2

Interpoll Labs Report No. 6-7451
Louisiana Pacific Corporation
Hayward, Wisconsin

Test No. 7
Line 2 Core Dryer Duct

Results of Total Hydrocarbons Determinations ~~Method 25A~~

	Run 1	Run 2	Run 3
Date of run	3-19-96	3-20-96	3-20-96
Time run start/end (HRS)	1320-1420	1000-1100	1200-1300
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	24.7	25.4	26.9
Oxygen content (%V/V)	16.0	16.3	12.9
Volumetric flow rate (DSCFM)	28356	29359	28827
THC concentration (ppmC,w)	526	906	759
THC emission rate (LB/HR)	37.0	66.6	55.9

Interpoll Labs Report No. 6-7451
Louisiana Pacific Corporation
Hayward, Wisconsin

Test No. 8
Line 2 Surface Dryer Duct

Results of Total Hydrocarbons Determinations-----**Method 25A**

	Run 1	Run 2	Run 3
Date of run	3-19-96	3-20-96	3-20-96
Time run start/end (HRS)	1320-1420	1000-1100	1200-1300
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	28.6	28.7	28.3
Oxygen content (%V/V)	14.7	15.1	15.2
Volumetric flow rate (DSCFM)	27324	27592	27872
THC concentration (ppmC,w)	692	802	817
THC emission rate (LB/HR)	49.5	58.0	59.3

Test No. 11
Line 2 Press Vent RTO Stack

Results of Total Hydrocarbons Determinations ~~Method 25A~~

	Run 1	Run 2	Run 3
Date of run	3-20-96	3-20-96	3-20-96
Time run start/end (HRS)	1650-1750	1815-1915	2015-2115
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	2.2	1.7	2.0
Oxygen content (%V/V)	20.9	20.9	20.9
Volumetric flow rate (DSCFM)	67951	68965	64190
THC concentration (ppmC,w)	4	18	2
THC emission rate (LB/HR)	0.52	2.4	0.24

Test No. 12
Line 2 Press RTO Inlet

Results of Total Hydrocarbons Determinations ~~Method 25A~~

	Run 1	Run 2	Run 3
Date of run	3-20-96	3-20-96	3-20-96
Time run start/end (HRS)	1650-1750	1815-1915	2015-2112
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	2.4	2.4	2.2
Oxygen content (%V/V)	20.9	20.9	20.9
Volumetric flow rate (DSCFM)	76341	77087	77444
THC concentration (ppmC,w)	118	112	77
THC emission rate (LB/HR)	17.3	16.5	11.4

3.7 Results of Formaldehyde Determinations

Test No. 4
Line 2 Dryer RTO Stack

Results of Formaldehyde Tests ----- EPA Method 0011

	Run 1 03-20-96	Run 2 03-20-96	Run 3 03-20-96
Date of run			
Time run start/end.....(HRS)	830/1017	1100/1210	1245/1354
Static pressure.....(IN.WC)	-0.65	-0.65	-0.65
Cross sectional area (SQ.FT)	36.23	36.23	36.23
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	306.0	354.0	345.0
desiccant.....(GRAMS)	20.0	19.0	17.0
total.....(GRAMS)	326.0	373.0	362.0
Formaldehyde in sample..(uG)	13000	18000	17000
Gas meter coefficient.....	1.0054	1.0054	1.0054
Barometric pressure..(IN.HG)	29.31	29.31	29.31
Avg. orif.pres.drop..(IN.WC)	2.05	2.21	2.21
Avg. gas meter temp..(DEF-F)	59.0	74.5	73.5
Volume through gas meter....			
at meter conditions...(CF)	49.63	52.17	52.41
standard conditions.(DSCF)	49.96	51.02	51.35
Total sampling time....(MIN)	64.00	64.00	64.00
Nozzle diameter.....(IN)	.269	.269	.269
Avg.stack gas temp ..(DEG-F)	261	262	263
Volumetric flow rate.....			
actual.....(ACFM)	133647	135918	137590
dry standard.....(DSCFM)	73163	72254	73736
Isokinetic variation.....(%)	98.0	101.3	99.9
CH2O concentration.....			
(GR/DSCF).....	0.0040	0.0055	0.0051
(MG/DSCM).....	9.24	12.53	11.76
(PPM-DRY).....	7.40	10.04	9.42
(PPM-WET).....	5.66	7.47	7.06
CH2O emission rate...(LB/HR)	2.52949	3.38868	3.24538

CH2O = Formaldehyde

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 9
Line 2 Press Vent RTO Stack

Results of Formaldehyde Tests ----- EPA Method 0011

	Run 1 03-19-96	Run 2 03-19-96	Run 3 03-19-96
Date of run			
Time run start/end.....(HRS)	1030/1145	1222/1336	1440/1554
Static pressure.....(IN.WC)	-0.35	-0.35	-0.35
Cross sectional area (SQ.FT)	31.71	31.71	31.71
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	1.0	3.0	1.0
desiccant.....(GRAMS)	10.0	7.0	14.0
total.....(GRAMS)	11.0	10.0	15.0
Formaldehyde in sample..(uG)	600	490	610
Gas meter coefficient.....	0.9936	0.9936	0.9936
Barometric pressure..(IN.HG)	28.78	28.78	28.78
Avg. orif.pres.drop..(IN.WC)	1.72	1.73	1.95
Avg. gas meter temp..(DEF-F)	61.4	72.6	72.8
Volume through gas meter....			
at meter conditions...(CF)	53.30	54.16	57.49
standard conditions.(DSCF)	51.79	51.52	54.70
Total sampling time....(MIN)	72.00	72.00	72.00
Nozzle diameter.....(IN)	.242	.242	.242
Avg.stack gas temp ..(DEG-F)	234	234	233
Volumetric flow rate.....			
actual.....(ACFM)	100333	99144	104368
dry standard.....(DSCFM)	72598	71842	75431
Isokinetic variation.....(%)	98.4	98.9	100.0
CH2O concentration.....			
(GR/DSCF).....	0.0002	0.0001	0.0002
(MG/DSCM).....	0.41	0.34	0.40
(PPM-DRY).....	0.33	0.27	0.32
(PPM-WET).....	0.33	0.27	0.31
CH2O emission rate...(LB/HR)	0.11168	0.09073	0.11176

CH2O = Formaldehyde

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Test No. 13
Line 2 Konus Stack

Results of Formaldehyde Tests ----- EPA Method 0011

	Run 1 03-18-96	Run 2 03-18-96	Run 3 03-18-96
Date of run			
Time run start/end.....(HRS)	1036/1142	1220/1323	1405/1510
Static pressure.....(IN.WC)	-0.32	-0.32	-0.32
Cross sectional area (SQ.FT)	14.47	14.47	14.47
Pitot tube coefficient.....	.840	.840	.840
Water in sample gas			
condenser.....(ML)	0.0	0.0	0.0
impingers.....(GRAMS)	96.0	119.0	114.0
desiccant.....(GRAMS)	22.0	21.0	18.0
total.....(GRAMS)	118.0	140.0	132.0
Formaldehyde in sample..(uG)	210	280	190
Gas meter coefficient.....	0.9964	0.9964	1.7800
Barometric pressure..(IN.HG)	28.69	28.69	28.69
Avg. orif.pres.drop..(IN.WC)	2.69	2.55	2.51
Avg. gas meter temp..(DEF-F)	56.9	56.2	59.4
Volume through gas meter....			
at meter conditions...(CF)	55.56	54.27	53.97
standard conditions.(DSCF)	54.58	53.36	94.21
Total sampling time....(MIN)	60.00	60.00	60.00
Nozzle diameter.....(IN)	.370	.370	.370
Avg.stack gas temp ..(DEG-F)	391	394	406
Volumetric flow rate.....			
actual.....(ACFM)	32554	32213	32245
dry standard.....(DSCFM)	17552	16976	17666
Isokinetic variation.....(%)	100.5	101.6	172.3
CH2O concentration.....			
(GR/DSCF).....	0.0001	0.0001	0.0001
(MG/DSCM).....	0.14	0.19	0.13
(PPM-DRY).....	0.11	0.15	0.10
(PPM-WET).....	0.10	0.13	0.10
CH2O emission rate...(LB/HR)	0.00899	0.01186	0.00847

CH2O = Formaldehyde

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

3.8 Results of Phenol Determinations

Test No. 2
Line 2 Dryer RTO Stack

Results of Phenol Determinations -----

	Run 1	Run 2	Run 3
Date of run	03-19-96	03-19-96	03-19-96
Time run start/end.....(HRS)	1031/1138	1320/1424	1500/2035
Barometric pressure..(IN.HG)	28.78	28.78	28.78
Meter temperature....(DEG-F)	56.16	67.58	66.12
Meter correction coefficient	1.0023	1.0023	1.0023
Volume through gas meter.... at meter conditions...(CF)	43.870	44.205	43.750
standard conditions (DSCF)	43.465	42.848	42.525
Total sampling time....(MIN)	60.0	60.0	60.0
Moisture content.....(%V/V)	26.10	26.20	26.94
Volumetric flow rate (DSCFM)	68840	70700	69220>
Phenol in sample.....(uG)	840.00<	840.00<	840.00<
Phenol concentration..... (GR/10 ³ DSCF).....	0.2982<	0.3025<	0.3048<
(uG/DSCM).....	682.98<	692.80<	698.07<
(PPB-DRY).....	174.53<	177.04<	178.39<
(PPB-WET).....	128.98<	130.66<	130.33<
Phenol emis. rate(10 ⁻³ LB/HR)	175.947<	183.299<	180.827<

A trailing '<' symbol indicates that the true value
is less than or equal to the reported value

Analysis performed according to NIOSH Method 3502

3.9 Results of Benzene Determinations

Interpoll Labs Report No. 6-7451
Louisiana Pacific Corporation
Hayward, Wisconsin

Test No. 5
Line 2 Dryer RTO Stack

Results of Benzene Determinations **Method 18**

	Run 1	Run 2	Run 3
Date of run	3-21-96	3-21-96	3-21-96
Time run start/end (HRS)	0816-0906	0939-1039	1135-1235
Total sampling time (MIN)	60	60	60
Moisture content (%V/V)	25.1	25.1	25.3
Oxygen content (%V/V)	15.8	15.8	15.8
Volumetric flow rate (DSCFM)	72800	72800	72800
Benzene concentration (ppm,d)	0.11	0.17	0.08
Benzene emission rate (LB/HR)	0.09	0.15	0.07

Test No. 15
Line 2 Thermal Oil Heater Stack

Results of Benzene Determinations ~~Method 18~~

	Run 1	Run 2	Run 3
Date of run	3-18-96	3-18-96	3-18-96
Time run start/end (HRS)	1800-1900	1930-2030	2100-2200
Total sampling time (MIN)	60	60	60
Moisture content (% V/V)	10.5	12.7	12.3
Oxygen content (% V/V)	13.6	12.5	11.6
Volumetric flow rate (DSCFM)	16830	16090	16290
Benzene concentration (ppm,d)	< 0.01	0.18	0.48
Benzene emission rate (LB/HR)	< 0.002	0.035	0.096

3.10 PAH Sampling Data

Test No. 3
Line 2 Dryer RTO Stack

Sampling Data for PAH Determinations-----SW846 Method 0010

	Run 1 03-20-96	Run 2 03-21-96	Run 3 03-21-96
Date of run			
Time run start/end.....(HRS)	1440/1724	815/1050	1135/1409
Static pressure.....(IN.WC)	-0.65	-0.65	-0.65
Cross sectional area (SQ.FT)	36.23	36.23	36.23
Pitot tube coefficient.....	0.840	0.840	0.840
Water in sample gas			
condenser.....(ML)	830.0	749.0	761.0
impingers.....(GRAMS)	0.0	0.0	0.0
desiccant.....(GRAMS)	35.0	66.0	64.0
total.....(GRAMS)	865.0	815.0	825.0
Gas meter coefficient.....	1.0054	1.0054	1.0054
Barometric pressure..(IN.HG)	29.31	29.24	29.24
Avg. orif.pres.drop..(IN.WC)	2.24	2.19	2.23
Avg. gas meter temp..(DEG-F)	82.1	77.5	84.1
Volume through gas meter....			
at meter conditions...(CF)	119.86	117.96	119.58
standard conditions.(DSCF)	115.58	114.43	114.61
standard conditions..(NM ³)	3.273	3.240	3.245
Total sampling time....(MIN)	144.00	144.00	144.00
Nozzle diameter.....(IN)	.269	.269	.269
Avg.stack gas temp ..(DEG-F)	265	262	266
Volumetric flow rate.....			
actual.....(ACFM)	137976	136268	137323
dry standard.....(DSCFM)	72651	72797	72817
Isokinetic variation.....(%)	101.5	100.3	100.4

137189
72255

4 RESULTS OF FUEL ANALYSES

INTERPOLL LABORATORIES, INC.**Fuel Laboratory****(612) 786-6020**

Date: 3/28/96
Client: LOUISIANA-PACIFIC, HAYWARD
Laboratory Log Number: 7451-29-9998
Sample Collected: 3/19/96
Sample Received: 3/21/96
Source: LINE 2 KONUS
Sample Identification: TEST 14, WOOD/BARK

Proximate and Ultimate Analysis WT %**Proximate Analysis WT %**

Parameter	Moisture & Ash Free	Moisture Free	As Received
Moisture, Total			42.26
Ash		2.96	1.71
Volatile Matter	78.68	76.36	44.09
Fixed Carbon (calculation)	21.32	20.69	11.95
Sulfur	0.01	0.01	0.01
Heating Value, BTU/LB.	8738	8480	4896

Ultimate Analysis WT %

Parameter	Moisture & Ash Free	Moisture Free	As Received
Moisture, Total			42.26
Ash		2.96	1.71
Carbon	50.78	49.27	28.45
Hydrogen	5.79	5.62	3.24
Nitrogen	0.06	0.05	0.03
Oxygen (calculated)	43.37	42.08	24.30
Sulfur	0.01	0.01	0.01

Respectfully submitted,



David J. Schneider, Manager
Chemistry Department

9022

APPENDIX A

RESULTS OF VOLUMETRIC FLOW RATE DETERMINATIONS

Test No. 7
Line 2 Core Dryer Duct

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-19-96
Time of Determination.....(HRS)	1326
Barometric pressure.....(IN.HG)	28.87
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	42
Duct area.....(SQ.FT)	9.62
Direction of flow.....	UP
Static pressure.....(IN.WC)	-11
Avg. gas temp.....(DEG-F)	240
Moisture content.....(% V/V)	24.65
Avg. linear velocity.....(FT/SEC)	92.2
Gas density.....(LB/ACF)	.04883
Molecular weight.....(LB/LBMOLE)	29.39
Mass flow of gas.....(LB/HR)	155862
Volumetric flow rate.....	
actual.....(ACFM)	53197
dry standard.....(DSCFM)	28356

Test No. 7
Line 2 Core Dryer Duct

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-20-96
Time of Determination.....(HRS)	1003
Barometric pressure.....(IN.HG)	29.31
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	42
Duct area.....(SQ.FT)	9.62
Direction of flow.....	UP
Static pressure.....(IN.WC)	-11.4
Avg. gas temp.....(DEG-F)	218
Moisture content.....(% V/V)	25.40
Avg. linear velocity.....(FT/SEC)	92.0
Gas density.....(LB/ACF)	.05105
Molecular weight.....(LB/LBMOLE)	29.43
Mass flow of gas.....(LB/HR)	162672
Volumetric flow rate.....	
actual.....(ACFM)	53106
dry standard.....(DSCFM)	29359

Test No. 7
Line 2 Core Dryer Duct

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-20-96
Time of Determination.....(HRS)	1203
Barometric pressure.....(IN.HG)	29.31
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	42
Duct area.....(SQ.FT)	9.62
Direction of flow.....	UP
Static pressure.....(IN.WC)	-12.2
Avg. gas temp.....(DEG-F)	216
Moisture content.....(% V/V)	26.85
Avg. linear velocity.....(FT/SEC)	92.0
Gas density.....(LB/ACF)	.05081
Molecular weight.....(LB/LBMOLE)	29.45
Mass flow of gas.....(LB/HR)	161962
Volumetric flow rate.....	
actual.....(ACFM)	53130
dry standard.....(DSCFM)	28827

Test No. 8
Line 2 Surface Dryer Duct

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-19-96
Time of Determination.....(HRS)	1343
Barometric pressure.....(IN.HG)	28.87
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	42
Duct area.....(SQ.FT)	9.62
Direction of flow.....	UP
Static pressure.....(IN.WC)	-12.2
Avg. gas temp.....(DEG-F)	251
Moisture content.....(% V/V)	28.58
Avg. linear velocity.....(FT/SEC)	95.5
Gas density.....(LB/ACF)	.04722
Molecular weight.....(LB/LBMOLE)	29.47
Mass flow of gas.....(LB/HR)	156123
Volumetric flow rate.....	
actual.....(ACFM)	55103
dry standard.....(DSCFM)	27324

Test No. 8
Line 2 Surface Dryer Duct

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-20-96
Time of Determination.....(HRS)	1014
Barometric pressure.....(IN.HG)	29.31
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	42
Duct area.....(SQ.FT)	9.62
Direction of flow.....	UP
Static pressure.....(IN.WC)	-12
Avg. gas temp.....(DEG-F)	249
Moisture content.....(% V/V)	28.74
Avg. linear velocity.....(FT/SEC)	94.8
Gas density.....(LB/ACF)	.04803
Molecular weight.....(LB/LBMOLE)	29.42
Mass flow of gas.....(LB/HR)	157690
Volumetric flow rate.....	
actual.....(ACFM)	54722
dry standard.....(DSCFM)	27592

Test No. 8
Line 2 Surface Dryer Duct

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-20-96
Time of Determination.....(HRS)	1211
Barometric pressure.....(IN.HG)	29.31
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	42
Duct area.....(SQ.FT)	9.62
Direction of flow.....	UP
Static pressure.....(IN.WC)	-11.8
Avg. gas temp.....(DEG-F)	212
Moisture content.....(% V/V)	28.31
Avg. linear velocity.....(FT/SEC)	90.2
Gas density.....(LB/ACF)	.05078
Molecular weight.....(LB/LBMOLE)	29.41
Mass flow of gas.....(LB/HR)	158581
Volumetric flow rate.....	
actual.....(ACFM)	52052
dry standard.....(DSCFM)	27872

Test No. 9
Line 2 Press Vent RTO Stack

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-19-96
Time of Determination.....(HRS)	843
Barometric pressure.....(IN.HG)	28.78
Pitot tube coefficient.....	.84
Number of sampling ports.....	1
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	76.25
Duct area.....(SQ.FT)	31.71
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.35
Avg. gas temp.....(DEG-F)	233
Moisture content.....(% V/V)	0.00
Avg. linear velocity.....(FT/SEC)	52.1
Gas density.....(LB/ACF)	.05484
Molecular weight.....(LB/LBMOLE)	28.84
Mass flow of gas.....(LB/HR)	326197
Volumetric flow rate.....	
actual.....(ACFM)	99135
dry standard.....(DSCFM)	72589

Test No. 11
Line 2 Press Vent RTO Stack

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-20-96
Time of Determination.....(HRS)	1651
Barometric pressure.....(IN.HG)	28.98
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	24
Shape of duct.....	Round
Stack diameter.....(IN)	76.25
Duct area.....(SQ.FT)	31.71
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.57
Avg. gas temp.....(DEG-F)	233
Moisture content.....(% V/V)	2.16
Avg. linear velocity.....(FT/SEC)	49.5
Gas density.....(LB/ACF)	.05474
Molecular weight.....(LB/LBMOLE)	28.84
Mass flow of gas.....(LB/HR)	309566
Volumetric flow rate.....	
actual.....(ACFM)	94248
dry standard.....(DSCFM)	67951

Test No. 11
Line 2 Press Vent RTO Stack

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-20-96
Time of Determination.....(HRS)	1815
Barometric pressure.....(IN.HG)	28.98
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	24
Shape of duct.....	Round
Stack diameter.....(IN)	76.25
Duct area.....(SQ.FT)	31.71
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.49
Avg. gas temp.....(DEG-F)	234
Moisture content.....(% V/V)	1.65
Avg. linear velocity.....(FT/SEC)	50.1
Gas density.....(LB/ACF)	.05478
Molecular weight.....(LB/LBMOLE)	28.84
Mass flow of gas.....(LB/HR)	313156
Volumetric flow rate.....	
actual.....(ACFM)	95275
dry standard.....(DSCFM)	68965

Test No. 11
Line 2 Press Vent RTO Stack

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-20-96
Time of Determination.....(HRS)	2015
Barometric pressure.....(IN.HG)	28.98
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	24
Shape of duct.....	Round
Stack diameter.....(IN)	76.25
Duct area.....(SQ.FT)	31.71
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.43
Avg. gas temp.....(DEG-F)	228
Moisture content.....(% V/V)	1.97
Avg. linear velocity.....(FT/SEC)	46.3
Gas density.....(LB/ACF)	.05520
Molecular weight.....(LB/LBMOLE)	28.84
Mass flow of gas.....(LB/HR)	292075
Volumetric flow rate.....	
actual.....(ACFM)	88187
dry standard.....(DSCFM)	64190

Test No. 12
Line 2 Press Vent RTO Inlet

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-20-96
Time of Determination.....(HRS)	1700
Barometric pressure.....(IN.HG)	29
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	58.5
Duct area.....(SQ.FT)	18.67
Direction of flow.....	UP
Static pressure.....(IN.WC)	-3.55
Avg. gas temp.....(DEG-F)	120
Moisture content.....(% V/V)	2.41
Avg. linear velocity.....(FT/SEC)	79.9
Gas density.....(LB/ACF)	.06490
Molecular weight.....(LB/LBMOLE)	28.84
Mass flow of gas.....(LB/HR)	348345
Volumetric flow rate.....	
actual.....(ACFM)	89461
dry standard.....(DSCFM)	76341

Test No. 12
Line 2 Press Vent RTO Inlet

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-20-96
Time of Determination.....(HRS)	1820
Barometric pressure.....(IN.HG)	29
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	58.5
Duct area.....(SQ.FT)	18.67
Direction of flow.....	UP
Static pressure.....(IN.WC)	-4.2
Avg. gas temp.....(DEG-F)	122
Moisture content.....(% V/V)	2.35
Avg. linear velocity.....(FT/SEC)	81.0
Gas density.....(LB/ACF)	.06458
Molecular weight.....(LB/LBMOLE)	28.84
Mass flow of gas.....(LB/HR)	351612
Volumetric flow rate.....	
actual.....(ACFM)	90742
dry standard.....(DSCFM)	77087

Test No. 12
Line 2 Press Vent RTO Inlet

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-20-96
Time of Determination.....(HRS)	2017
Barometric pressure.....(IN.HG)	29
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	12
Shape of duct.....	Round
Stack diameter.....(IN)	58.5
Duct area.....(SQ.FT)	18.67
Direction of flow.....	UP
Static pressure.....(IN.WC)	-4.15
Avg. gas temp.....(DEG-F)	121
Moisture content.....(% V/V)	2.18
Avg. linear velocity.....(FT/SEC)	81.1
Gas density.....(LB/ACF)	.06474
Molecular weight.....(LB/LBMOLE)	28.84
Mass flow of gas.....(LB/HR)	352856
Volumetric flow rate.....	
actual.....(ACFM)	90836
dry standard.....(DSCFM)	77444

Test No. 13
Line 2 Konus Stack

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-18-96
Time of Determination.....(HRS)	950
Barometric pressure.....(IN.HG)	28.69
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	24
Shape of duct.....	Round
Stack diameter.....(IN)	51.5
Duct area.....(SQ.FT)	14.47
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.32
Avg. gas temp.....(DEG-F)	386
Moisture content.....(% V/V)	9.25
Avg. linear velocity.....(FT/SEC)	35.7
Gas density.....(LB/ACF)	.04413
Molecular weight.....(LB/LBMOLE)	29.48
Mass flow of gas.....(LB/HR)	82102
Volumetric flow rate.....	
actual.....(ACFM)	31005
dry standard.....(DSCFM)	16825

Test No. 14
Line 2 Konus Stack

Results of Volumetric Flow Rate Determination-----Method 2

Date of Determination.....	03-19-96
Time of Determination.....(HRS)	1730
Barometric pressure.....(IN.HG)	28.69
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	24
Shape of duct.....	Round
Stack diameter.....(IN)	51.5
Duct area.....(SQ.FT)	14.47
Direction of flow.....	UP
Static pressure.....(IN.WC)	-.35
Avg. gas temp.....(DEG-F)	407
Moisture content.....(% V/V)	10.50
Avg. linear velocity.....(FT/SEC)	34.6
Gas density.....(LB/ACF)	.04296
Molecular weight.....(LB/LBMOLE)	29.57
Mass flow of gas.....(LB/HR)	77372
Volumetric flow rate.....	
actual.....(ACFM)	30018
dry standard.....(DSCFM)	15675


Test No. 17
Line 2 Dryer RTO Inlet

Results of Volumetric Flow Rate Determination-----Method 2


Date of Determination.....	03-19-96
Time of Determination.....(HRS)	829
Barometric pressure.....(IN.HG)	28.78
Pitot tube coefficient.....	.84
Number of sampling ports.....	2
Total number of points.....	24
Shape of duct.....	Round
Stack diameter.....(IN)	64.75
Duct area.....(SQ.FT)	22.87
Direction of flow.....	HORIZONTAL
Static pressure.....(IN.WC)	-1.5
Avg. gas temp.....(DEG-F)	145
Moisture content.....(% V/V)	25.05
Avg. linear velocity.....(FT/SEC)	73.3
Gas density.....(LB/ACF)	.05750
Molecular weight.....(LB/LBMOLE)	29.31
Mass flow of gas.....(LB/HR)	346929
Volumetric flow rate.....	
actual.....(ACFM)	100566
dry standard.....(DSCFM)	63034


APPENDIX B

LOCATION OF TEST PORTS




U.S. 12-11-12







NOTE: LINE I DRYER OUTLET
TESTS WILL REQUIRE TWO SETS
OF EQUIPMENT.



TYPICAL TEST PORT PLATFORM





HAYWARD, WI
DRAWING 10
LINE 1
THERMAL OIL HEATER
STACK
ELEVATION

RELOCATE EXISTING SUPPORT
STAND FROM BETWEEN COLS. 38 & 39
TO BETWEEN COLS. 39 & 40
(PROVIDE DUCT SADDLES)

10'-3"
PLAN VIEW

P1
NOTE TWO TEST LOCATIONS
LINE 1 DRYER OUTLETS

P1
17'-6"

N1

10'
RELOCATE EXISTING SUPPORT
STAND FROM BETWEEN COLS. 38 & 39
TO BETWEEN COLS. 39 & 40


NEW DUCT TIE-IN POINT

CL PRIMARY
CYCLONE

CL PRIMARY
CYCLONE

30'-3"

39'



APPENDIX C

FIELD DATA SHEETS

TABLE OF CONTENTS

Line 2 Dryer RTO Stack	1
Line 2 Core Dryer Duct	35
Line 2 Surface Dryer Duct	45
Line 2 Press Vent RTO Stack	55
Line 2 Press RTO Inlet	75
Line 2 Thermal Oil Heater Stack	81
Line 2 Dryer RTO Inlet	98
VE Fiel Data Sheets	106
VE Observer Certification Sheet	112


INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Method 2 Field Data Sheet

Drawing of Test Site

Job L.P. Hayward
Source Line 2 Dryer RTO Stack
Test 1 Run 3/19/96 Date 3/19/96
Stack Dimen. 81.5 IN.
Dry Bulb °F Wet bulb °F
Manometer ☐ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 28.78 IN.HG
Static Pressure -165 IN.WC
Operators D. Van Hoever + S. Kelker
Pitot No. V23-8 C. 184

[illegible]

R or nothing = ~~reg~~ manometer; S = expanded; E = electronic

032594-G:\STACK\WP\FORMS\S-392.1

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 3/19/96 Test 1 Run 1
 Source Line 2 Dyer RTO Stack No. of traverse points 16
 Method 5 Filter holder: glass Filter type: glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0 cfm at 9 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☒ acetone _____☐ other(s) _____

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1		} 200	
Impinger No. 2	511		311
Impinger No. 3			
Condenser			
Desiccant	1243	1236	7
Total			318

Integrated Gas Sampling Data:

Bag Pump No. 23B Box No. 25 Bag No. 1
 Bag Material: 5-layer Aluminized Tedlar Size: 44 L
 Pretest leak check: 0 cc/min at 15 IN.HG
 Time start: 1035 (HRS) Time end: 1139 (HRS)
 Sampling rate: 400 cc/min Operator: Dut

S/N of O₂ Analyzer used to monitor train outlet:4

052394-G:\STACK\WP\FORM55-0046RR

EPA Method 5 Field Data Sheet

Pilot No. 123-8

C_p 1.84

11.0 20

%

7-4

Nozzle No.

Nozzle Dia. 28.78 in.

Bar. Press. 28.78 in. Hg

Operators

Meter Box No. 6

Gas meter Coeff. 1.0054

Job L.P. Hayward

Source Line 1 Dryer Dto Stack

Date 3/18/96 Test 1 Run 1

Date 3/18/96		Test 1		Run 1		Gasmeter Coeff.		1.0034		Bar. Press.		0.0	
Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)					Oxygen (% v/v)	
							Stack	Probe	Oven	Imp.	Gas/In		Gas/Out
A 8	1030	826.00											
7	7	828.77	.76	1.54	8.69	5	257	239	256	41	60	60	16.2
6	8	831.53	.75	1.55	1.43	6	257				59	59	15.9
5	12	834.26	.79	1.62	4.21	6	263				62	59	15.5
4	16	836.97	.74	1.53	6.93	6	257	241	253	42	64	59	15.9
3	20	839.70	.76	1.59	9.70	6	253				69	60	16.2
2	24	843.51	.76	1.59	3.47	6	256	242	254	43	70	60	16.1
1	28	845.26	.73	1.53	5.20	6	256				74	60	15.8
B 8	32	847.80	.65	1.36	7.77	6	260	240	253	44	75	60	15.7
7	36	850.67	.82	1.71	0.64	6	260				68	61	16.1
6	40	853.45	.83	1.70	3.53	6	272	246	254	42	71	62	16.2
5	44	856.40	.86	1.76	6.46	6	272				77	62	16.7
4	48	857.17	.85	1.77	9.41	7	265				80	64	16.5
3	52	862.01	.77	1.60	2.21	7	272				81	64	16.2
2	56	864.88	.75	1.56	4.98	7	272				82	64	16.3
1	60	867.80	.72	1.52	7.72	7	262				83	65	16.0
	64	870.22	.55	1.16	0.12		262				84	65	16.1
	1140												

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 3/19/96 Test 1 Run 2
Source Line 2 Dryer RTO Stack No. of traverse points 76
Method 5 Filter holder: glass Filter type: glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒

Post test: 0 cfm at 8 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used: _____

Recovery solvent(s)

☒ Acetone _____

☐ Other(s) _____

No. of probe wash bottles: _____

Sample recovered by: _____

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	504	200	304
Impinger No. 3			
Condenser			
Desiccant	1379	1364	15
Total			319

Integrated Gas Sampling Data:

Bag Pump No. 23B Box No. 25 Bag No. 2
Bag Material: 5-layer Aluminized Tedlar Size: 44 L
Pretest leak check: 0 cc/min at 15 IN.HG
Time start: 1325 (HRS) Time end: 1429 (HRS)
Sampling rate: 400 cc/min Operator: DWH

S/N of O₂ Analyzer used to monitor train outlet: 4

052394-GASTACKWPFORMSS-0046RR

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 3/19/96 Test 1 Run 3
Source Line 2 Dryer RTO Stack No. of traverse points 16
Method 5 Filter holder: glass Filter type: glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒

Post test: 0 cfm at 8 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☒ Acetone _____

☐ Other(s) _____

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	515	200	315
Impinger No. 3			
Condenser			
Desiccant	1433	1425	8
Total			323

Integrated Gas Sampling Data:

Bag Pump No. 23B Box No. 25 Bag No. 3
Bag Material: 5-layer Aluminized Tedlar Size: 44 L
Pretest leak check: 0 cc/min at 14 IN.HG
Time start: 1500 (HRS) Time end: 2037 (HRS)
Sampling rate: 400 cc/min Operator: DUAL

S/N of O₂ Analyzer used to monitor train outlet: 4

052394-G:STACK\WP\FORMS\S-0046RR

EPA Method 5 Field Data Sheet

Pilot No. V23-8

Operators

Meter Box No. 6 $\Delta I @$ 1.089 in.WCGasmeter Coeff. 1.0054

NOZZLE NO. 1-1
is 1-17 is

$$\begin{array}{r} \text{Nozzle Dia.} \quad 1.291 \quad \text{in.} \\ \hline \quad \quad \quad 1.290 \quad \text{in.} \end{array}$$
Bar. Press. 28.18 in. Hg

1.17

157

187

Nozzle No.

Nozzle Dia.

Bar. Press.

1

in.WC

1

5. K

1.57

54

22

Δ1-10

1.0

Operators

Melter Box No.

Gasometer Coeff.

1844

Mr. Payson Stark

	Page	Date
Source	1	1968
Source	2	1968
Source	3	1968
Source	4	1968
Source	5	1968
Source	6	1968
Source	7	1968
Source	8	1968
Source	9	1968
Source	10	1968
Source	11	1968
Source	12	1968
Source	13	1968
Source	14	1968
Source	15	1968
Source	16	1968
Source	17	1968
Source	18	1968
Source	19	1968
Source	20	1968
Source	21	1968
Source	22	1968
Source	23	1968
Source	24	1968
Source	25	1968
Source	26	1968
Source	27	1968
Source	28	1968
Source	29	1968
Source	30	1968
Source	31	1968
Source	32	1968
Source	33	1968
Source	34	1968
Source	35	1968
Source	36	1968
Source	37	1968
Source	38	1968
Source	39	1968
Source	40	1968
Source	41	1968
Source	42	1968
Source	43	1968
Source	44	1968
Source	45	1968
Source	46	1968
Source	47	1968
Source	48	1968
Source	49	1968
Source	50	1968
Source	51	1968
Source	52	1968
Source	53	1968
Source	54	1968
Source	55	1968
Source	56	1968
Source	57	1968
Source	58	1968
Source	59	1968
Source	60	1968
Source	61	1968
Source	62	1968
Source	63	1968
Source	64	1968
Source	65	1968
Source	66	1968
Source	67	1968
Source	68	1968
Source	69	1968
Source	70	1968
Source	71	1968
Source	72	1968
Source	73	1968
Source	74	1968
Source	75	1968
Source	76	1968
Source	77	1968
Source	78	1968
Source	79	1968
Source	80	1968
Source	81	1968
Source	82	1968
Source	83	1968
Source	84	1968
Source	85	1968
Source	86	1968
Source	87	1968
Source	88	1968
Source	89	1968
Source	90	1968
Source	91	1968
Source	92	1968
Source	93	1968
Source	94	1968
Source	95	1968
Source	96	1968
Source	97	1968
Source	98	1968
Source	99	1968
Source	100	1968

1

4163

Index

[illegible]

(612) 786-6020

Drawing of Test Site

The diagram illustrates the orthographic projection of a cylinder. It is divided into two main sections by a vertical line.

- Left Section (Cross-section View):** This section is labeled "Cross-section View" at the top. It contains a large, empty rectangular area, intended for drawing the cross-section of the cylinder.
- Right Section (Elevation View):** This section is labeled "Elevation View" at the top. It contains a hand-drawn circle representing the cylinder's elevation.
 - At the top of the circle, there is a small semi-circular protrusion.
 - Four points are marked on the circumference of the circle: 'A' at the top right, 'B' at the bottom right, 'C' at the bottom left, and 'D' at the top left.
 - Below the circle, there is a horizontal line with an upward-pointing arrow labeled 'N'.
 - To the left of the circle, there is a vertical line with a downward-pointing arrow labeled 'LADDER'.

R or nothing = reg. manometer; S = expanded; E = electronic

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 3/19/96 Test 2 Run 1
Source Line 2 Dryer RTO Stack No. of traverse points 3
Method Phenol Filter holder: Glass Filter type: Glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☐

Post test: _____ cfm at _____ IN. HG (vac) ☐

Particulate Catch Data:

No. of filters used: _____

Recovery solvent(s)

☐ acetone _____

☐ other(s) _____

No. of probe wash bottles: _____

Sample recovered by: _____

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant			
Total			

Integrated Gas Sampling Data:

Bag Pump No. 23A Box No. 28 Bag No. 1
Bag Material: 5-layer Aluminized Tedlar Size: 44 L
Pretest leak check: 0 cc/min at 15 IN.HG
Time start: 1035 (HRS) Time end: 1137 (HRS)
Sampling rate: 400 cc/min Operator: DUH

S/N of O₂ Analyzer used to monitor train outlet: 7

052394-GASTACKWPFORM55-0046RR

EPA Method 4 and 6 Field Data Sheet

Job L.P. Hayward
 Source Line 2 Dryer RTO STACK
 Date 3/19/96 Test 2 Run 1
 Wet Bulb _____
 Dry Bulb _____

Operator(s) D. Van Hoever & S. Kelker
 Meter Box No. 13 Gasmeter Coef. 1.0023
 $\Delta H@$ 1.82 in.WC Bar.Press 29.78
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 6 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	1031	315.18									
B 3	5	318.83	1.80	3.5	257	256	243	44	51	51	15.8
3	10	322.46	1.80	3.5	257				51	50	15.3
3	15	326.18	1.80	4	263	257	251	42	52	49	15.0
3	20	329.82	1.80	4	253				57	50	15.5
2	25	333.59	1.80	4	256	256	254	41	59	50	14.8
2	30	337.09	1.80	4					59	49	15.1
A 2	35	340.87	1.80	4		254	251	44	56	47	15.6
2	40	344.44	1.80	4	272	272			53	45	15
1	45	348.10	1.80	4		253	254	45	74	61	16.2
1	50	351.86	1.80	4					67	54	15.1
1	55	355.37	1.80	4		258	261	46	72	58	15.6
1	60	359.05	1.80	4	262				73	60	15.5
	1138										
	0 - 60	V _m = 43.87	ΔP = 1.80		$\bar{P}$ =				$\bar{P}_m$ = 56.16		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers	512	200	312
Condenser			
Desiccant	1425	1411	14
	Total		326

Preliminary Results of SO ₂ Concentration Determination		
V _m =	43.465	DSCF
Moisture Gravimetric =	26.10	%v/v
Moisture Psychrometric =		%v/v
SO ₂ , DRY =		PPM
SO ₂ , WET =		PPM
LB/MMBtu =		

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP Hayward Date 2/19/96 Test 2 Run 2
 Source Line 2 Dryer RTO Stack No. of traverse points 3
 Method Phenol Filter holder: Glass Filter type: Glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☐Post test: _____ cfm at _____ IN. HG (vac) ☐

Particulate Catch Data:

No. of filters used: _____

Recovery solvent(s)

☐ acetone _____☐ other(s) _____

No. of probe wash bottles: _____

Sample recovered by: _____

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant			
Total			

Integrated Gas Sampling Data:

Bag Pump No. 23A
 Bag Material: 5-layer Aluminized Tedlar
 Pretest leak check: 0
 Time start: 1324
 Sampling rate: 400

Box No. 28 Bag No. 2
 Size: 44 L
 cc/min at 15 IN.HG
 (HRS) Time end: 1423 (HRS)
 cc/min Operator: DVH

S/N of O₂ Analyzer used to monitor train outlet: 7

052394-G:\STACK\WP\FORMS\S-0046RR

EPA Method 4 and 6 Field Data Sheet

Job LP Hayward
 Source 4p At 2 Dryer RTD Stack
 Date 3/19/96 Test 2 Run 2
 Wet Bulb _____
 Dry Bulb _____

Operator(s) D. Van Haver + S. Kelker
 Meter Box No. 13 Gasmeter Coef. 1.0023
 $\Delta H@$ 1.82 in.WC Bar.Press 28.78
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 7 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	1320	359.235									
B 3	5	363.92	1.80	5	276	253	246	41	57	57	17.0
3	10	366.57	1.80	5					62	57	17.1
3	15	370.17	1.80	5	262	251	250	41	70	56	16.9
3	20	373.73	1.80	5					70	56	16.4
2	25	377.45	1.80	5	272	248	252	41	73	59	16.7
2	30	381.18	1.80	5					74	61	16.5
A 2	35	384.91	1.80	5	259	250	256	42	76	62	16.7
2	40	388.60	1.80	5					75	64	16.1
1	45	392.35	1.80	5	260	258	257	48	79	65	16.2
1	50	396.04	1.80	5					81	66	16.4
1	55	399.75	1.80	5	265	259	256	43	82	68	16.5
1	60	403.44	1.80	5					83	69	16.5
	(11424)										
	0 - 60	V _m = 44.205	ΔH = 1.80		F =				E = 67.58		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers	499	200	299
Condenser			
Desiccant	1594	1570	24
	Total		323

Preliminary Results of SO ₂ Concentration Determination		
V _m =	42.848	DSCF
Moisture Gravimetric =	26.20	%v/v
Moisture Psychrometric =		%v/v
SO ₂ DRY =		PPM
SO ₂ WET =		PPM
LB/MMBtu =		

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP HaywardDate 3/19/96 Test 2 Run 3Source Line 2 dryerNo. of traverse points 3Method Phenol Filter holder: GlassFilter type: Glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☐Post test: _____ cfm at _____ IN. HG (vac) ☐

Particulate Catch Data:

No. of filters used: _____

Recovery solvent(s)

☐ acetone _____☐ other(s) _____

No. of probe wash bottles: _____

Sample recovered by: _____

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant			
Total			

Integrated Gas Sampling Data:

Bag Pump No. 23ABag Material: 5-layer Aluminized TedlarPretest leak check: OKTime start: 1500Sampling rate: 400Box No. 28Bag No. 3Size: 44 Lcc/min at 15

IN.HG

(HRS) Time end: 2034

(HRS)

cc/min Operator: DLHS/N of O₂ Analyzer used to monitor train outlet: 7

052394-G:STACKWPFORMSS-0046R2

EPA Method 4 and 6 Field Data Sheet

Job L.P. Hayward
 Source Ala Line 2 Dwyer RJO Stack
 Date 3/19/96 Test 2 Run 3
 Wet Bulb _____
 Dry Bulb _____

Operator(s) P. Van Hoever + S. Kelter
 Meter Box No. 13 Gasmeter Coef. 1.0023
 $\Delta H@$ 1.82 in.WC Bar.Press 28.78 in.
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 7 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	1500	404.00									
B3	5	407.65	1.80	5	266	257	251	51	69	69	16.0
3	10	411.30	1.80	5					55	58	16.0
3	15	414.87	1.80	5	273	258	250	46	61	55	15.4
3	20	418.46	1.80	5					65	57	15.4
2	25	422.17	1.80	5	263	261	254	42	69	59	15.4
2	30	425.80	1.80	5					72	60	15.7
A2	35	429.47	1.80	5	268	257	254	41	73	60	15.1
2	40	433.15	1.80	5					75	61	15.1
1	45	436.79	1.80	5	261	257	258	44	77	63	15.4
1	50	440.42	1.80	5					78	64	15.3
1	55	444.01	1.80	5	272	256	259	44	78	64	15.3
1	60	447.75	1.80	5					80	65	15.3
	(2035)										
	$\theta = 60$	$V_m = 43.75$	$\Delta P = 1.80$		$E =$				$E = 66.12$		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers	526	200	326
Condenser			
Desiccant	1254	1243	11
	Total		333

Preliminary Results of SO ₂ Concentration Determination		
V _{std} =	42.525	DSCF
Moisture Gravimetric =	26.94	%v/v
Moisture Psychrometric =		%v/v
SO ₂ , DRY =		PPM
SO ₂ , WET =		PPM
LB/MMBtu =		

INTERPOLL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Job L.P. Hayward
 Source Line 2 Dryer RTO Stack
 Test 3 Run Date _____
 Stack Dimen. _____ IN.
 Dry Bulb _____ °F Wet bulb _____ °F
 Manometer ☐ Reg. ☐ Exp ☐ Elec.
 Barometric Pressure 29.31 / 29.24 IN.HG
 Static Pressure 1.65 IN.WC
 Operators D. VanHoever & S. Kelker & J. Lorenz
 Pitot No. V23-8 C_p 1.84

Drawing of Test Site

Cross-section View	Elevation View
--------------------	----------------

Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas
		Port Length:	IN.	Time Start:	HRS
A 1					
2					
3					
4					
5					
6					
7					
8					
B 1					
2					
3					
4					
5					
6					
7					
8					
Temp. Meas. Device & S/N:				Time End:	HRS

R or nothing = reg. manometer; S = expanded; E = electronic

INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Modified Method 5 Sample Log Sheet

Job L.P. Hayward Date 3/20/66 Test 3 Run 1
 Source Line 2 Dyer RTO Stack No. Of Traverse Points 16
 Cyclone ☐ Yes ☒ No Filter Holder MM5 Filter Type 4" Glass Fiber
 Analytes PAH XAD - 2 Resin g Batch No.
 Field Recovery Spike Added ☒ Yes ☐ No Ref. EPA SW-846 Method 0010

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: 0 cfm at 12 IN.HG (vac) ☒

Semivolatile Catch Data:

No. of filters used:

Recovery solvent(s)

☒ MeCl₂ + MeOH (50:50 v/v)
☒ Other(s) Acetone

No. of bottles for condensate trap catch
 Samples recovered by

2
DW

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Condensate Trap	<u>493</u>	<u>0</u>	<u>493</u>
Condensate Trap	<u>337</u>	<u>0</u>	<u>337</u>
Condensate Trap			
Impingers			
Desiccant	<u>1518</u>	<u>1473</u>	<u>35</u>
Total			<u>865</u>

Integrated Gas Sampling Data:

Bag Pump No. 233 Box No. 29 Bag No. 1
 Bag Material: 4-layer Aluminized Tedlar Size: 14 44 L
 Pretest Leak Check: 1445 cc/min at 14 INHG
 Time Start: 1724 (HRS) Time End: 1724 (HRS)
 Sampling Rate: 140 cc/min O₂ Analyzer S/N 4

032194-GASTACKIWPFORMSIS-393

(612) 786-6020

EPA Modified Method 5 Field Data Sheet

101

Source

Date _____

L.P. Hayward

Line 2 Dwyer RTO Stat-Meter Box

Test	Run
12C 96	3

Operators

Meter Box No. $\Delta H @$ in. WC

Gasmeter Coeff.

Nozzle No. _____

Nozzle Dia. _____ in.

Bar. Pres. _____ in. Hg

Pilot No.

U^a

三

of

[illegible]

INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Modified Method 5 Sample Log Sheet

Job L.P. Hayward Date 3/21/96 Test 3 Run 2
 Source Line 2 Dryer Rto Stack No. Of Traverse Points 16
 Cyclone ☐ Yes ☒ No Filter Holder MM5 Filter Type 4" Glass Fiber
 Analytes P.A.H. XAD - 2 Resin g Batch No.
 Field Recovery Spike Added ☒ Yes ☐ No Ref. EPA SW-846 Method 0010

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: 0 cfm at 15 IN.HG (vac) ☒

Semivolatile Catch Data:

No. of filters used:

Recovery solvent(s)

☐ MeCl₂ * MeOH (50:50 v/v)

☒ Other(s) ACETONE

No. of bottles for condensate trap catch
 Samples recovered by

2
D.H.F.

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Condensate Trap	<u>749</u>	<u>0</u>	<u>749</u>
Condensate Trap			
Condensate Trap			
Impingers			
Desiccant	<u>1476</u>	<u>1410</u>	<u>66</u>
Total			<u>815</u>

Integrated Gas Sampling Data:

Bag Pump No. 23 B Box No. 29 Bag No. 2
 Bag Material: 4-layer Aluminized Tedlar Size: 44 L
 Pretest Leak Check: 0 cc/min at 15 INHG
 Time Start: 0820 (HRS) Time End: 1050 (HRS)
 Sampling Rate: 140 cc/min O₂ Analyzer S/N 4

032194-G:STACK\WP\FORMS\S-393

EPA Modified Method 5 Field Data Sheet

Job L.P. Hayward
 Source Line 2 River RTO Stack
 Date 3/21/96 Test 3 Run 3

Operators Dave SC
 Meter Box No. 6 $\Delta H @ 1.89$ in. WC
 Gas meter Coeff. 1.0054

Nozzle No. 6695
 Nozzle Dia. 2.69 in.
 Bar. Pres. 29.34 in. Hg

Pilot No. U23-6
 C_p .84
 H_2O 25 %

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)						Oxygen (% v/v)	
							Stack	Probe	Oven	XAD-2	Imp.	Meter (In/Out)		
	0815	236.40												
A 8	45	240.31	.90	2.46	0.31	11	254	254	251	40	39	52	52	16.6
8	9	243.96	.88	2.27	3.97	16	254					60	52	16.5
7	135	247.35	.84	2.16	7.55	10	262	258	254	41	40	62	54	16.2
7	18	251.20	.90	2.33	1.27	13	262					67	55	16.2
6	22.5	254.82	.85	2.21	4.91	12	262	257	256	41	40	69	57	16.0
6	27	258.41	.83	2.17	8.52	12	262					73	59	16.3
5	31.5	262.13	.86	2.29	2.24	12	252	258	261	42	41	85	59	17.0
5	36	265.83	.81	2.11	5.82	12	268					78	61	17.0
4	405	269.50	.77	2.06	9.36	12	263	249	257	42	41	81	64	17.4
4	45	272.97	.77	2.07	2.92	12	253					84	65	16.6
3	49.5	276.47	.77	2.03	6.46	12	269	254	253	44	42	85	65	16.1
3	54	279.94	.74	1.96	9.93	12	269					86	66	16.1
2	58.5	283.41	.73	1.98	3.42	12	253	256	254	41	40	88	70	16.2
2	63	286.92	.71	1.93	6.89	12	253					88	70	16.0
1	67.5	290.21	.67	1.79	0.21	12	269	258	256	42	41	89	72	15.9
1	72	293.61	.71	1.90	3.65	12	269					89	73	16.4
B 8	76.5	297.41	.83	2.22	7.36	13	269	258	257	44	43	86	73	16.3
8	81	301.10	.83	2.21	1.07	13	269					87	74	17.1
7	85.5	304.87	.88	2.37	4.91	13	262	253	256	44	43	89	74	17.3
7	90	308.61	.78	2.11	8.54	13	260					90	76	16.9
K 6	94.5	312.46	.89	2.42	2.42	14	260	256	257	44	43	91	77	16.8
6	99	316.60	.89	2.42	6.31	14	260					91	78	16.4
5	103.5	320.46	.86	2.35	0.14	13	258	262	258	42	41	85	79	17.2
4.5	108	324.31	.87	2.37	3.98	13	258					90	78	17.1
	01:00													
	0 -	V _m -		ΔH -								Avg. -		

EPA Modified Method 5 Field Data Sheet

L.P. Harrison

Line 7 Driver RTO Stack Meter Box No.

Source	Time	Total	Run	Gasmeter Coeff.
Source	2/11/1961	3	Run	
	2/11/1961	3	Run	

Date: 2/21/18 Test: 2

AHC®	in WC
------	-------

ΔHQ@_____in.WC

Nozzle No.

Nozzle Dia.

Bar. Pres.

Pilot No.

۵

1-1-C

[illegible]

INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Modified Method 5 Sample Log Sheet

Job L.P. Hayward Date 3/21/96 Test 3 Run 3
 Source Line 2 Dryer RTO No. Of Traverse Points 18
 Cyclone ☐ Yes ☒ No Stack Filter Holder MM5 Filter Type 4" Glass Fiber
 Analytes PAH XAD-2 Resin g Batch No.
 Field Recovery Spike Added ☒ Yes ☐ No Ref. EPA SW-846 Method 0010

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: 0 cfm at 15 IN.HG (vac) ☒

Semivolatile Catch Data:

No. of filters used:

Recovery solvent(s)

☒ MeCl₂ * MeOH (50:50 v/v)
☒ Other(s) Acetone

No. of bottles for condensate trap catch
 Samples recovered by D.H.

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Condensate Trap	400	0	400
Condensate Trap	361	0	361
Condensate Trap			
Impingers			
Desiccant	1504	1440	64
Total			825

Integrated Gas Sampling Data:

Bag Pump No. 233 Box No. 29 Bag No. 3
 Bag Material: 4-layer Aluminized Tedlar Size: 44 L
 Pretest Leak Check: 0 cc/min at 15 INHG
 Time Start: 1140 (HRS) Time End: 1409 (HRS)
 Sampling Rate: 140 cc/min O₂ Analyzer S/N 4

032194-GASTACK\WP\FORMS\S-393

Job Source Date: 3/21/96
 L.P. Hayward
 Line 2 Dryer Test 3 Run 3
 EPA Modified Method 5 Field
 Donut 4 S.K.
 Operators: 6 $\Delta H @ 1.89$ in.WC
 Meter Box No. 1.0054
 Gasometer Coeff. 1.0054
 Nozzle No. 269 in. 269
 Nozzle Dia. 29.24 in.Hg
 Bar. Pres. 29.24
 H₂O
 Oxygen
 (% v/v)

L.P. Hayward									
Line 2 Date 10/20/96 Test 3 Run 3									
Source Date 3/21/96									
Meter Box No. 1003-4									
Gas Meter Coeff.									
Traverse Point No.	Sampling Time (min)	Sample Vol. (cc)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cc)	VAC. (in. Hg)	Stack	Probe	Oven
1	1135	354.72	.86	2.33	8.51	10	256	256	75
2	4.5	358.58	.83	2.24	2.32	10	256	256	76
3	9	362.27	.87	2.32	6.01	10	267	258	76
4	13.5	366.11	.83	2.22	9.73	10	267	258	76
5	18	369.71	.85	2.29	3.51	11	273	261	76
6	22.5	373.44	.87	2.37	7.33	11	273	262	77
7	27	377.37	.87	2.33	1.15	12	274	267	77
8	31.5	381.16	.89	2.38	5.00	11	274	267	77
9	36	384.96	.82	2.19	8.71	11	273	264	77
10	40.5	388.77	.82	2.19	2.41	11	273	264	77
11	45	392.58	.84	2.25	6.17	11	273	260	77
12	49.5	396.32	.85	2.28	9.94	11	273	260	78
13	54	399.99	.85	2.33	3.76	11	270	256	75
14	58.5	403.60	.81	2.10	7.50	11	270	264	75
15	63	407.45	.78	2.02	1.13	12	270	264	76
16	67.5	411.21	.75	2.37	8.54	12	270	261	78
17	72	414.94	.88	2.36	2.37	12	263	256	76
18	76.5	418.91	.89	2.37	6.20	12	263	257	76
19	81	422.80	.88	2.30	9.94	12	274	261	77
20	85.5	426.61	.85	2.10	3.87	12	274	264	77
21	90	430.31	.90	2.40	7.67	12	256	264	77
22	94.5	434.24	.86	2.37	1.48	12	256	264	77
23	99	438.00	.85	2.30	5.78	12	256	264	77
24	103.5	441.71	.84	2.30	2.33	12	256	264	77
25	108	445.46	.84	2.30	2.30	12	256	264	77
26	113	449.21	.84	2.30	2.30	12	256	264	77
27	118	452.96	.84	2.30	2.30	12	256	264	77
28	123	456.71	.84	2.30	2.30	12	256	264	77
29	128	460.46	.84	2.30	2.30	12	256	264	77
30	133	464.21	.84	2.30	2.30	12	256	264	77
31	138	467.96	.84	2.30	2.30	12	256	264	77
32	143	471.71	.84	2.30	2.30	12	256	264	77
33	148	475.46	.84	2.30	2.30	12	256	264	77
34	153	479.21	.84	2.30	2.30	12	256	264	77
35	158	482.96	.84	2.30	2.30	12	256	264	77
36	163	486.71	.84	2.30	2.30	12	256	264	77
37	168	490.46	.84	2.30	2.30	12	256	264	77
38	173	494.21	.84	2.30	2.30	12	256	264	77
39	178	497.96	.84	2.30	2.30	12	256	264	77
40	183	501.71	.84	2.30	2.30	12	256	264	77
41	188	505.46	.84	2.30	2.30	12	256	264	77
42	193	509.21	.84	2.30	2.30	12	256	264	77
43	198	512.96	.84	2.30	2.30	12	256	264	77
44	203	516.71	.84	2.30	2.30	12	256	264	77
45	208	520.46	.84	2.30	2.30	12	256	264	77
46	213	524.21	.84	2.30	2.30	12	256	264	77
47	218	527.96	.84	2.30	2.30	12	256	264	77
48	223	531.71	.84	2.30	2.30	12	256	264	77
49	228	535.46	.84	2.30	2.30	12	256	264	77
50	233	539.21	.84	2.30	2.30	12	256	264	77
51	238	542.96	.84	2.30	2.30	12	256	264	77
52	243	546.71	.84	2.30	2.30	12	256	264	77
53	248	550.46	.84	2.30	2.30	12	256	264	77
54	253	554.21	.84	2.30	2.30	12	256	264	77
55	258	557.96	.84	2.30	2.30	12	256	264	77
56	263	561.71	.84	2.30	2.30	12	256	264	77
57	268	565.46	.84	2.30	2.30	12	256	264	77
58	273	569.21	.84	2.30	2.30	12	256	264	77
59	278	572.96	.84	2.30	2.30	12	256	264	77
60	283	576.71	.84	2.30	2.30	12	256	264	77
61	288	580.46	.84	2.30	2.30	12	256	264	77
62	293	584.21	.84	2.30	2.30	12	256	264	77
63	298	587.96	.84	2.30	2.30	12	256	264	77
64	303	591.71	.84	2.30	2.30	12	256	264	77
65	308	595.46	.84	2.30	2.30	12	256	264	77
66	313	599.21	.84	2.30	2.30	12	256	264	77
67	318	602.96	.84	2.30	2.30	12	256	264	77
68	323	606.71	.84	2.30	2.30	12	256	264	77
69	328	610.46	.84	2.30	2.30	12	256	264	77
70	333	614.21	.84	2.30	2.30	12	256	264	77
71	338	617.96	.84	2.30	2.30	12	256	264	77
72	343	621.71	.84	2.30	2.30	12	256	264	77
73	348	625.46	.84	2.30	2.30	12	256	264	77
74	353	629.21	.84	2.30	2.30	12	256	264	77
75	358	632.96	.84	2.30	2.30	12	256	264	77
76	363	636.71	.84	2.30	2.30	12	256	264	77
77	368	640.46	.84	2.30	2.30	12	256	264	77
78	373	644.21	.84	2.30	2.30	12	256	264	77
79	378	647.96	.84	2.30	2.30	12	256	264	77
80	383	651.71	.84	2.30	2.30	12	256	264	77
81	388	655.46	.84	2.30	2.30	12	256	264	77
82	393	659.21	.84	2.30	2.30	12	256	264	77
83	398	662.96	.84	2.30	2.30	12	256	264	77
84	403	666.71	.84	2.30	2.30	12	256	264	77
85	408	670.46	.84	2.30	2.30	12	256	264	77
86	413	674.21	.84	2.30	2.30	12	256	264	77
87	418	677.96	.84	2.30	2.30	12	256	264	77
88	423	681.71	.84	2.30	2.30	12	256	264	77
89	428	685.46	.84	2.30	2.30	12	256	264	77
90	433	689.21	.84	2.30	2.30	12	256	264	77
91	438	692.96	.84	2.30	2.30	12	256	264	77
92	443	696.71	.84	2.30	2.30	12	256	264	77
93	448	700.46	.84	2.30	2.30	12	256	264	77
94	453	704.21	.84	2.30	2.30	12	256	264	77
95	458	707.96	.84	2.30	2.30	12	256	264	77
96	463	711.71	.84	2.30	2.30	12	256	264	77
97	468	715.46	.84	2.30	2.30	12	256	264	77
98	473	719.21	.84	2.30	2.30	12	256	264	77
99	478	722.96	.84	2.30	2.30	12	256	264	77
100	483	726.71	.84	2.30	2.30	12	256	264	77
101	488	730.46	.84	2.30	2.30	12	256	264	77
102	493	734.21	.84	2.30	2.30	12	256	264	77
103	498	737.96	.84	2.30	2.30	12	256	264	77
104	503	741.71	.84	2.30	2.30	12	256	264	77
105	508	745.46	.84	2.30	2.30	12	256	264	77
106	513	749.21	.84	2.30	2.30	12	256	264	77
107	518	752.96	.84	2.30	2.30	12	256	264	77
108	523	756.71	.84	2.30	2.30	12	256	264	77
109	528	760.46	.84	2.30	2.30	12	256	264	77
110	533	764.21	.84	2.30	2.30	12	256	264	77
111	538	767.96	.84	2.30	2.30	12	256	264	77
112	543	771.71	.84	2.30	2.30	12	256	264	77
113	548	775.46	.84	2.30	2.30	12	256	264	77
114	553	779.21	.84	2.30	2.30	12	2		

(612) 786-6020

Drawing of Test Site

Cross-section View	Elevation View 
---------------------------	---

R or nothing = reg. manometer; S = expanded; E = electronic

INTERPOL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP Hazard ADate 3/20/96 Test 4Run 38 1Source Line 2 RTD Dryer StackNo. of traverse points 16Method 0011 Filter holder: NAFilter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.00 cfm at 13 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used: _____

Recovery solvent(s) _____

☐ acetone _____☐ other(s) _____

No. of probe wash bottles: _____

Sample recovered by: _____

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	506	200	306
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1399	1379	20
Total			326

Integrated Gas Sampling Data:

Bag Pump No. 23BBox No. 6Bag No. E1Bag Material: 5-layer Aluminized TedlarSize: 44 LPretest leak check: 0cc/min at 15 IN.HGTime start: 4:05:00 0830(HRS) Time end: 1017 (HRS)Sampling rate: 400cc/min Operator: SKS/N of O₂ Analyzer used to monitor train outlet: 4

052394-G:\STACK\WPA\FORMS\S-0046RR

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP HaywardDate 7/20/96 Test 4 Run 2Source Line 2 Dryer RTD stackNo. of traverse points 16Method 0011 Filter holder: NAFilter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.00 cfm at 13 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

1☐ acetone☒ other(s) MeCl₂, A.C. H₂O

No. of probe wash bottles:

1
IL

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	<u>534</u>	<u>500</u>	<u>354</u>
Impinger No. 3			
Condenser			
Desiccant	<u>1473</u>	<u>1452</u>	<u>19</u>
Total			<u>373</u>

Integrated Gas Sampling Data:

Bag Pump No. 23BBox No. 6 Bag No. 2Bag Material: 5-layer Aluminized TedlarSize: 44 LPretest leak check: 0cc/min at 15 IN.HGTime start: 11:00(HRS) Time end: 12:10 PM (HRS)Sampling rate: 400cc/min Operator: SKS/N of O₂ Analyzer used to monitor train outlet:4

052394-C:\STACK\WP\FORMS\5-0046RR

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 3/20/96 Test 4 Run 3
 Source Line 2 Dryer RTO Stack No. of traverse points 16
 Method 0011 Filter holder: NA Filter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0 cfm at 13 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☐ acetone _____☒ Other(s) MeLL₂

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

1
D.H.

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	<u>545</u>	<u>200</u>	<u>345</u>
Impinger No. 3			
Condenser			
Desiccant	<u>1416</u>	<u>1399</u>	<u>17</u>
Total			<u>362</u>

Integrated Gas Sampling Data:

Bag Pump No. 23B
 Bag Material: 5-layer Aluminized Tedlar
 Pretest leak check: 0
 Time start: 1248
 Sampling rate: 400

Box No. 2356 Bag No. 3
 Size: 44 L
 cc/min at 15 IN.HG
 (HRS) Time end: 1354 (HRS)
 cc/min Operator: D.H.

S/N of O₂ Analyzer used to monitor train outlet:

4

052394-G:STACKWPAFORMSIS-0046RR

(612) 46-66,220

EPA Method 5 Field Data Sheet

Pilot No. U23-8

Class

Nozzle No.

Nozzle Dia.

Bar. Press.

269

29.31

C_p

11.0

%

25

Operators

Meter Box No.

Gas meter Coeff.

DON + SK + J

189 AH@

0.054

Job L.P. HaywardSource Line 2 Dejev RTO StackDate 3-20-96 Test Run 3

Line 2 Drzew RTO Stack										Bar. Press. 29.31		In. Hg		
Date 3-22-96 Test Run 3										0.054				
Meter Box No. 18										Gasmeter Coeff.				
Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)					Oxygen (% v/v)		
							Stack	Probe	Oven	Inp.	Gas/in		Gas/Out	
4	1.045	63.29	.87	2.31	66.63	9	264	250	251	40	68	68	15.6	
5	4	63.29	.84	2.23	9.90	10	255				72	68	15.5	
7	8	69.71	.82	2.17	3.13	11	263	246	239	40	76	68	15.5	
6	12	72.97	.85	2.22	6.42	12	265				79	68	16.1	
5	16	76.36	.83	2.21	9.69	12	262	248	242	41	80	68	15.8	
4	20	79.63	.82	2.20	2.95	12	256				81	68	15.8	
3	24	82.99	.80	2.13	6.16	12	264	251	240	44	82	69	16.0	
2	28	86.23	.84	2.23	9.45	12	268				82	69	16.0	
1	32	89.55	.85	2.26	2.76	10	265	250	245	40	82	68	15.8	
8	36	92.82	.90	2.39	6.16	10	266				80	69	16.2	
7	40	96.08	.88	2.37	9.55	12	256	239	250	42	81	69	15.9	
6	44	99.41	.89	2.34	2.92	12	272				80	69	16.3	
5	48	102.80	.80	2.15	6.15	12	250	245	252	40	79	69	15.8	
4	52	106.10	.78	2.06	9.30	11	269				78	69	16.4	
3	56	109.45	.78	2.08	2.47	10	262	249	253	42	78	69	16.3	
2	60	112.60	.78	2.06	5.63		268				80	69	16.8	
1	64	115.70												
(1354)														
0-64		V _m - 52.41		ΔT -2.21								Avg. - 73.5		

INTERPOL LABORATORIES, INC.

(612) 786-6020

M/18 Field Data SheetJob L.P. HaywardOperator(s) D. Van HoeverSource Line 2 Dryer RTO StackMeter Box No. 65 Meter Coef. 1.0036Date 3/21/96 Test 5 Run 1Barometric Pressure 29.24 IN.HG

Sample Train Leak Check:

Pretest: 0 cc/min at 15 IN.HGPost test: 0 cc/min at 15 IN.HG

Trav. point No.	Sample Time (min)	Sample Volume (cf)	Sample Rate (cc/min)	Vac. (IN.HG)	Temperatures (°F)		
					Stack	Probe	Casimeter
	0816	500.700					
	5	500.874	1000	5	254		60
	10	501.042	1000	6			64
	15	501.220	1000	6			67
	20	501.400	1000	6	261		68
	25	501.567	1000	6			72
	30	501.730	1000	6	262		76
	35	501.902	1000	6			78
	40	502.13	1000	6	253		79
	45	502.300	1000	6			81
	50	502.345	1000	8			84
	55						
	60						
	0-50	V _m = 1.645					t _m = 72.90

(0906)

Stop Test!
Frozen up.V_{STD} = 1.60

121693-G:STACKWPIFORM55-47

INTERPOLL LABORATORIES, INC.
(612) 786-6020

M18 Field Data Sheet

Job L.P. Hayward
Source Line 2 Dryer RTO Stack
Date 3/21/96 Test 5 Run 3

Operator(s) D. Van Hoever
Meter Box No. 65 Meter Coef. 1.0036
Barometric Pressure 29.24 IN.HG

Sample Train Leak Check:

Pretest: 0 cc/min at 5 IN.HG
Post test: 0 cc/min at 5 IN.HG

Trav. point No.	Sample Time (min)	Sample Volume (ci)	Sample Rate (cc/min)	Vac. (IN.HG)	Temperatures (°F)		
					Stack	Probe	Gasmeter
	0939	502.428					
	5	502.577	1000	6	269		88
	10	502.726	1000	8			92
	15	502.980	1000	8	260		94
	20	503.168	1000	8			94
	25	503.357	1000	8	260		96
	30	503.521	1000	9			97
	35	503.722	1000	10	260		99
	40	503.928	1000	10			100
	45	504.123	1000	10	274		102
	50	504.318	1000	10			102
	55	504.505	1000	10	261		102
	60	504.700	1000	10			104
	θ = 60	V _m = 2.272					t _m = 97.5

(1039)

V_{STD} = 2.11

121693-G:STACKWPAFORMSS-476

INTERPOL LABORATORIES, INC.
(612) 786-6020

MIS Field Data Sheet

Job L. A. Hayward
Source Line 2 Dryer RTO Stack
Date 3/21/96 Test 5 Run 3

Operator(s) D. Van Hooser
Meter Box No. 65 Meter Coef 1.0036
Barometric Pressure 29.24 IN.HG

Sample Train Leak Check:

Pretest: 0 cc/min at 15 IN.HG
Post test: 0 cc/min at 15 IN.HG

Trav. point No.	Sample Time (min)	Sample Volume (cf)	Sample Rate (cc/min)	Vac. (IN.HG)	Temperatures (°F)		
					Stack	Probe	Gasmeter
	<u>1135</u>	<u>504.757</u>					
	<u>5</u>	<u>504.961</u>	<u>1000</u>	<u>7</u>	<u>256</u>		<u>94</u>
	<u>10</u>	<u>505.182</u>	<u>1000</u>	<u>8</u>	<u>255</u>		<u>96</u>
	<u>15</u>	<u>505.372</u>	<u>1000</u>	<u>8</u>	<u>259</u>		<u>94</u>
	<u>20</u>	<u>505.560</u>	<u>1000</u>	<u>8</u>			<u>94</u>
	<u>25</u>	<u>505.751</u>	<u>1000</u>	<u>8</u>	<u>267</u>		<u>94</u>
	<u>30</u>	<u>505.948</u>	<u>1000</u>	<u>9</u>			<u>94</u>
	<u>35</u>	<u>506.140</u>	<u>1000</u>	<u>9</u>			<u>94</u>
	<u>40</u>	<u>506.333</u>	<u>1000</u>	<u>9</u>	<u>274</u>		<u>95</u>
	<u>45</u>	<u>506.522</u>	<u>1000</u>	<u>9</u>			<u>95</u>
	<u>50</u>	<u>506.714</u>	<u>1000</u>	<u>10</u>	<u>273</u>		<u>96</u>
	<u>55</u>	<u>506.913</u>	<u>1000</u>	<u>10</u>			<u>98</u>
	<u>60</u>	<u>507.109</u>	<u>1000</u>	<u>10</u>	<u>256</u>		<u>98</u>
	<u>θ = 60</u>	<u>V_m = 2.352</u>					<u>t_m = 95.17</u>

(1235)


$$V_{STD} = 2.19$$

121693-G:\STACK\WP\FORMS\S-476

(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

7b
 Source _____
 Test _____
 Stack Dimen. _____ IN.
 Dry Bulb _____ °F
 Manometer ☒ Reg. ☐ Exp ☐ Elec. _____
 Barometric Pressure _____ IN.HG
 Static Pressure _____ IN.WC
 Operators M. Kaehler & L. Hansen
 Pitot No. 31U-6 _____, 04



Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas (°F)
Port Length: 6.25 IN.			Time Start: 1041 HRS		
A-1	.044	1.94	7.09	1.02	
2	.146	6.10	12.35	1.80	
3	.296	12.36	18.61	1.77	
4	.404	29.39	35.64	2.10	↑
5	.854	35.65	41.90	1.88	
6	.956	39.91	46.16	1.40	244
B-1				1.35	
2				1.50	↓
3				2.14	
4				2.11	
5				1.83	
6				1.38	
Temp. Meas. Device & S/N: PDT-31 / TC				Time End: 1048 HRS	

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:STACKWPFFORMSS-392.1

Sample Train Leak Check:

Pretest: < 0.02 cfm at 15 in. Hg.

Posttest: < 0.02 cfm at 16 in. Hg.

VOID
RUN

Av. Int No.	Samp. Time (min)	Sample Volume (cf)	Drift Meter (inHg) (25)	VAC. inHg	Temperatures (°F)					Oxygen (%v/v)
					Probe	Oven	Impg.	Gas/In	Gas/Out	
	1030	270.017								
7-3	5	270.256	1000	2	243	NA	33	NA	NA	16.0
3	10	270.420	1000	2	250		38			15.9
3	15	270.590	1000	2	248		36			16.0
3	20	270.760	1000	2	246		37			16.0
2	25	270.918	1000	2	243		37			16.1
2	30	270.897	1000	2	245		38			15.9
2	35	271.260	1000	2	248		38			15.5
2	40	271.410	1000	2	243		38			15.9
1	45	271.593	1000	2	248		37			16.0
1	50	271.765	1000	2	244		37			16.0
1	55	271.940	1000	2	247		38			16.0
1	60	272.128	1000	2	245		38			16.1
	(1130)									
	0° 60	V _m = 2.111	(H) _{avg} =					(t _m) _{avg} = 80.0		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	57.0462	44.5790	12.4672
Desiccant	45.5384	42.3937	3.1547
		Total	15.6219

Preliminary results
of SO₂ concentration
determinationV_{std} = 2.0002 DSCF

Moisture = 6.89 %v/v

SO₂, dry = ppmSO₂, wet = ppm

LB/MMBtu =

Drawing of Test Site

Cross-section View	Elevation View
-----------------------	-------------------

[illegible]

Time End: 1337 HRS

C-37

Job L.P. / Hugwood, WI
 Source Line 2 Core Dryer / Dust
 Date 3-19-96 Test 7 Run 2

Operator(s) M. Kachler & L. Hansen
 Meter Box No. 772 Gas meter coef. 1.0047
 ΔH NA in. WC Bar. press 28.87 in. Hg

Sample Train Leak Check:

Pretest: < 0.02 cfm at 15 in. Hg. 8
 Posttest: 0.02 cfm at 16 in. Hg. 8

Trav. Point No.	Samp. Time (min)	Sample Volume (cf)	Orif. Meter (in. WC)	VAC. inHg	Temperatures (°F)					Oxygen (%v/v)
					Probe	Oven	Impg.	Gas/In	Gas/Out	
	1320	272.150								
A-3	5	272.333	1000	2	243 NA	NA	38	68	NA	15.7
3	10	272.515	1000	2	247		37	68		16.2
3	15	272.695	1000	2	241		37	68		16.1
3	20	272.885	1000	2	241		37	68		16.1
L	25	273.048	1000	2	243		38	68		16.2
2	30	273.237	1000	2	245		38	68		16.1
2	35	273.400	1000	2	245		38	68		16.3
2	40	273.585	1000	2	244		38	68		16.2
1	45	273.770	1000	2	248		39	68		16.2
1	50	273.921	1000	2	249		39	68		16.0
1	55	274.100	1000	2	243		39	68		15.9
1	60	274.263	1000	2	240	↓	39	68	↓	16.0
	(1420)									
	$\theta = 60$	$V_m = 2.113$	$(\Delta H)_{avg} =$					$(t_m)_{avg} = 68$		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	48.2937	41.0445	7.2492
Desiccant	50.9984	44.0276	6.9708
		Total	14.2200

Preliminary results of SO ₂ concentration determination	
V _{std}	= 2.0476 DSCF
Moisture	= 24.65 %v/v
SO ₂ , dry	= ppm
SO ₂ , wet	= ppm
LB/MMBtu	=

Drawing of Test Site

Cross-section View	Elevation View
--------------------	----------------

[illegible]

Temp. Meas. Device & S/N:

Time End: 1944 HRS

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:\STACK\WP\FORMS\5-392.1

EPA Method 4 and 6 Field Data Sheet

Job L.P. / Hayward, WI
 Source Core Dryer / Duct
 Date 3-19-96 Test 7 Run 3
 Wet Bulb _____
 Dry Bulb 22.7

Operator(s) Michael + L. Hansen
 Meter Box No. TR2 Gasmeter Coef. 1.0047
 $\Delta H@$ NA in.WC Bar.Press 28.07 in.Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: < 0.02 cfm at 16 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	<u>1935</u> 1500	<u>274.295</u>									
<u>A-3</u> 2-3	<u>5</u>	<u>274.449</u>	<u>1000</u>	<u>2</u>	<u>22.7</u>	<u>240</u>	<u>NA</u>	<u>37</u>	<u>68</u>	<u>NA</u>	<u>16.1</u>
<u>-3</u>	<u>10</u>	<u>274.620</u>	<u>1000</u>	<u>2</u>	<u>22.7</u>	<u>244</u>	<u>1</u>	<u>38</u>	<u>68</u>	<u>1</u>	<u>15.8</u>
<u>3</u>	<u>15</u>	<u>274.768</u>	<u>1000</u>	<u>2</u>	<u>22.7</u>	<u>243</u>	<u>1</u>	<u>38</u>	<u>68</u>	<u>1</u>	<u>15.5</u>
<u>3</u>	<u>20</u>	<u>274.920</u>	<u>1000</u>	<u>2</u>	<u>22.7</u>	<u>246</u>	<u>1</u>	<u>38</u>	<u>68</u>	<u>1</u>	<u>15.6</u>
<u>2</u>	<u>25</u>	<u>275.050</u>	<u>1000</u>	<u>2</u>	<u>22.7</u>	<u>246</u>	<u>1</u>	<u>37</u>	<u>68</u>	<u>1</u>	<u>15.7</u>
<u>2</u>	<u>30</u>	<u>275.210</u>	<u>1000</u>	<u>2</u>	<u>22.7</u>	<u>241</u>	<u>1</u>	<u>37</u>	<u>68</u>	<u>1</u>	<u>15.6</u>
<u>2</u>	<u>35</u>	<u>275.390</u> 275.210	<u>1000</u>	<u>2</u>	<u>22.7</u>	<u>240</u>	<u>1</u>	<u>37</u>	<u>68</u>	<u>1</u>	<u>15.5</u>
<u>2</u>	<u>40</u>	<u>275.563</u>	<u>1000</u>	<u>2</u>	<u>22.7</u>	<u>243</u>	<u>1</u>	<u>38</u>	<u>68</u>	<u>1</u>	<u>15</u>
<u>1</u>	<u>45</u>	<u>275.754</u>	<u>1000</u>	<u>2</u>	<u>22.7</u>	<u>245</u>	<u>1</u>	<u>39</u>	<u>68</u>	<u>1</u>	<u>15.8</u>
<u>1</u>	<u>50</u>	<u>275.922</u>	<u>1000</u>	<u>2</u>	<u>22.7</u>	<u>244</u>	<u>1</u>	<u>39</u>	<u>68</u>	<u>1</u>	<u>15.5</u>
<u>1</u>	<u>55</u>	<u>276.105</u>	<u>1100</u>	<u>2</u>	<u>22.7</u>	<u>246</u>	<u>1</u>	<u>38</u>	<u>68</u>	<u>1</u>	<u>15.8</u>
<u>1</u>	<u>60</u>	<u>276.277</u>	<u>1000</u>	<u>2</u>	<u>22.7</u>	<u>246</u>	<u>1</u>	<u>38</u>	<u>68</u>	<u>1</u>	<u>16.1</u>
	<u>(1035)</u>										
	<u>0 - 60</u>	<u>V_m = 1.992</u>	<u>ΔH =</u>		<u>22.7</u>				<u>68</u>		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
	<u>48.4031</u>	<u>45.3978</u>	<u>3.0053</u>
Desiccant	<u>80.7491</u>	<u>67.9834</u>	<u>12.7657</u>
		Total	<u>15.7710</u>

Preliminary Results of SO ₂ Concentration Determination	
V _m =	<u>1.9304</u> DSCF
Moisture Gravimetric =	<u>27.79</u> %v/v
Moisture Psychrometric =	%v/v
SO ₂ DRY =	PPM
SO ₂ WET =	PPM
LB/MMBtu =	

Drawing of Test Site

Cross-section View	Elevation View
--------------------------------------	----------------------------------

[illegible]

032594-G:\STACK\WP\FORMS\S-392.1

INTERFILL LABORATORIES
EPA Method 4 and 6 Field Data Sheet

Job L.P. / Hayward, WI
Source Line 2 Core Dryer / Steady
Date 3-20-96 Test 7 Run 4

Operator(s) M. Kachler + L. Hansen
Meter Box No. 772 Gasmeter coef. 1.0047
 ΔH NA in.WC Bar. press 29.31 in.Hg

Sample Train Leak Check:

Pretest: < 0.02 cfm at 15 in. Hg.

Posttest: 0.02 cfm at 16 in. Hg.

Trav. Point No.	Samp. Time (min)	Sample Volume (cf)	Orif. Meter (inWC)	VAC. inHg	Temperatures (°F)					Oxygen
					Probe	Oven	Impg.	Gas/In	Gas/Out	(%v/v)
	1000	276.375								
A-3	5	276.540	1000	2	247	NA	39	68	NA	15.8
3	10	276.606	1000	2	239		39	68		15.9
3	15	276.811	1000	2	231		38	68		15.7
3	20	276.985	1000	2	238		39	68		16.1
2	25	277.147	1000	2	235		39	68		16.0
2	30	277.320	1000	2	244		39	68		15.8
2	35	277.495	1000	2	241		39	68		15.9
2	40	277.670	1000	2	240		39	68		15.9
1	45	277.845	1000	2	239		38	68		16.0
1	50	278.020	1000	2	245		38	68		16.1
1	55	278.195	1000	2	244		39	68		15.7
1	60	278.370	1000	2	247		39	68		15.5
(1100)										
	$\theta = 60$	$V_m = 1.995$	$(\Delta H) = 7200$					$(t_m)_{ave.} = 68$		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
	55.0510	48.1337	6.9173
Desiccant	78.1664	70.8974	7.2690
Total			14.1863

Preliminary results of SO₂ concentration determination

$V_{std} = 1.963$ DSCF

Moisture = 15.40 %v/v

SO₂, dry = ppm

SO₂, wet = ppm

LB/MMBtu =

EPA Method 2 Field Data Sheet

Drawing of Test Site

Job W.P. / Hayward, WI
 Source Line 2 Core Dryer / Dust
 Test 7 Run 5 Date 3-10-96
 Stack Dimen. 42 IN.
 Dry Bulb 216 °F Wet bulb _____ °F
 Manometer ☒ Reg. ☐ Exp ☐ Elec.
 Barometric Pressure 29.31 IN.HG
 Static Pressure -12.2 IN.WC
 Operators M. Kaehler + L. Hanson
 Pitot No. 31V-6 C. 184

Cross-section View	Elevation View
-----------------------	-------------------

[illegible]

INTERPOL LABORATORIES
EPA Method 4 and 6 Field Data Sheet

Job L.P. / Hayward, WI
Source Line 2 Core Driven / Stack
Date 3-20-96 Test 7 Run 5

Operator(s) M. Kaehler + L. Hansen
Meter Box No. 722 Gas meter coef. 1.0047
 ΔH NA in.WC Bar. press 29.31 in.Hg

Sample Train Leak Check:

Pretest: < 0.02 cfm at 15 in. Hg. ☒
Posttest: 0.02 cfm at 16 in. Hg. ☒

Trav. Point No.	Samp. Time (min)	Sample Volume (cf)	Drift Meter (in.WC) <u>CC</u>	VAC. inHg	Temperatures (°F)					Oxygen (%v/v)
					Probe	Oven	Impg.	Gas/In	Gas/Out	
	<u>1200</u>	<u>278.398</u>								
<u>A-3</u>	<u>5</u>	<u>278.580</u>	<u>1000</u>	<u>2</u>	<u>243</u>	<u>NA</u>	<u>38</u>	<u>68</u>	<u>NA</u>	<u>16.1</u>
<u>3</u>	<u>10</u>	<u>278.755</u>	<u>1000</u>	<u>2</u>	<u>247</u>	<u>1</u>	<u>38</u>	<u>68</u>	<u>1</u>	<u>15.8</u>
<u>3</u>	<u>15</u>	<u>278.912</u>	<u>1000</u>	<u>2</u>	<u>240</u>		<u>39</u>	<u>68</u>		<u>16.0</u>
<u>3</u>	<u>20</u>	<u>279.090</u>	<u>1000</u>	<u>2</u>	<u>236</u>		<u>38</u>	<u>68</u>		<u>16.3</u>
<u>2</u>	<u>25</u>	<u>279.256</u>	<u>1000</u>	<u>2</u>	<u>236</u>		<u>38</u>	<u>68</u>		<u>16.4</u>
<u>2</u>	<u>30</u>	<u>279.415</u>	<u>1000</u>	<u>2</u>	<u>240</u>		<u>38</u>	<u>68</u>		<u>16.2</u>
<u>2</u>	<u>35</u>	<u>279.591</u>	<u>1000</u>	<u>2</u>	<u>233</u>		<u>38</u>	<u>68</u>		<u>16.1</u>
<u>2</u>	<u>40</u>	<u>279.755</u>	<u>1000</u>	<u>2</u>	<u>238</u>		<u>39</u>	<u>68</u>		<u>16.1</u>
<u>1</u>	<u>45</u>	<u>279.915</u>	<u>1000</u>	<u>2</u>	<u>235</u>		<u>39</u>	<u>68</u>		<u>16.0</u>
<u>1</u>	<u>50</u>	<u>280.094</u>	<u>1000</u>	<u>2</u>	<u>239</u>		<u>40</u>	<u>68</u>		<u>15.8</u>
<u>1</u>	<u>55</u>	<u>280.256</u>	<u>1000</u>	<u>2</u>	<u>244</u>		<u>40</u>	<u>68</u>		<u>15.7</u>
<u>1</u>	<u>60</u>	<u>280.408</u>	<u>1000</u>	<u>2</u>	<u>245</u>	<u>↓</u>	<u>40</u>	<u>68</u>	<u>↓</u>	<u>16.0</u>
	<u>(1300)</u>									
	<u>θ=60</u>	<u>V_m=2.010</u>	<u>(ΔH)_{avg}=1000</u>					<u>(t_m)_{avg}=68</u>		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	<u>91.9243</u>	<u>76.5125</u>	<u>15.4118</u>
		<u>Total</u>	<u>15.4118</u>

Preliminary results of SO ₂ concentration determination	
V _{std}	= <u>1.977</u> DSCF
Moisture	= <u>26.95</u> %v/v
SO ₂ , dry	= ppm
SO ₂ , wet	= ppm
LB/MMBtu	=

Drawing of Test Site

R or nothing = reg. manometer; S = expanded; E = electronic

EPA Method 4 and 6 Field Data Sheet

Job 2P/HAYWARD
 Source SURFACE DRINK
 Date 3-19-86 Test 8 Run 1
 Wet Bulb _____
 Dry Bulb _____

Operator(s) ET-LH
 Meter Box No. 65 Gasmeter Coef. 1.0036
 $\Delta H@$ 0 in.WC Bar.Press 28.87 in.Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ~~X~~
 Post Test: 0.02 cfm at 15 in.WC ~~X~~

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	1030	489.000									
	5	489.190	1000	2					82		
	10	489.380	1000	2					84		
	15	489.568	1000	2					86		
	20	489.760	1000	2					86		
	25	489.950	1000	2					86		
	30	490.140	1000	2					86		
	35	490.320	1000	2					86		
	40	490.505	1000	2					88		
	45	490.685	1000	2					90		
	50	490.872	1000	2					90		
	55	491.060	1000	2					90		
	60	491.238	1000	2					90		
	(1130)										
	0 = 60	V _m = 2.238	$\Delta P = 1000$		$\bar{c} =$				$\bar{c} = 87.0$		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	51.6879	45.0996	6.5893
Desiccant	37.4545	44.3570	13.0975
	Total		19.6868

Preliminary Results of SO ₂ Concentration Determination		
V _m =	2.0911	DSCF
Moisture Gravimetric =	30.72	%v/v
Moisture Psychrometric =		%v/v
SO ₂ , DRY =		PPM
SO ₂ , WET =		PPM
LB/MMBtu =		

Drawing of Test Site

Cross-section View	Elevation View
-----------------------	-------------------

[illegible]

032594-G:\STACK\WP\FORMS\S-392.1

EPA Method 4 and 6 Field Data Sheet

Job L.P. Hayward
 Source LINCOLN 2 Surface Dryer
 Date 3-19-96 Test 8 Run 2
 Wet Bulb _____
 Dry Bulb _____

Operator(s) ET-LH
 Meter Box No. 65 Gasmeter Coef. 1.0036
 ΔH @ _____ in.WC Bar.Press _____ in.WC
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test 0.02 cfm at 15 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	1320	491.270									
	5	491.472	1000	2					90		
	10	491.674	1000	2					90		
	15	491.875	1000	2					92		
	20	492.076	1000	2					92		
	25	492.275	1000	2					92		
	30	492.472	1000	2					92		
	35	492.667	1000	2					92		
	40	492.860	1000	2					92		
	45	493.050	1000	2					92		
	50	493.240	1000	2					92		
	55	493.430	1000	2					92		
	60	493.620	1000	2					92		
	1420										
	$\theta = 60$	$V_n = 2.350$	$\Delta H = 1000$		$E =$				$E_n = 91.7$		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	58.9217	46.9424	11.9793
Desiccant	41.9150	35.4394	6.5156
	Total		18.4949

Preliminary Results of SO ₂ Concentration Determination		
V _{ad} =	2.1771	DSCF
Moisture Gravimetric =	28.58	%v/v
Moisture Psychrometric =		%v/v
SO ₂ DRY =		PPM
SO ₂ WET =		PPM
LB/MMBtu =		

Drawing of Test Site

Cross-section View	Elevation View
--------------------------------------	----------------------------------

[illegible]

032594-G:\STACK\WP\FORMS\S-392.1

INTERPOLL LABORATORIES
EPA Method 4 and 6 Field Data Sheet

Job LP/HAYWARD
Source LINE 2 SURFACE DRAIN
Date 3-20-96 Test 8 Run 3

Operator(s) ET
Meter Box No. 65 Gas meter coef. 1.0036
 $\dot{V}_{HE}$ 2 in.WC Bar. press 29.31 in.Hg

Sample Train Leak Check:

Pretest: < 0.02 cfm at 15 in. Hg.
Posttest: 0 cfm at 15 in. Hg.

VOID
RUN

Trav. Point No.	Samp. Time (min)	Sample Volume (cf)	Orif. Meter (inWC)	VAC. inHg	Temperatures (°F)					Oxygen
					Probe	Oven	Impg.	Gas/In	Gas/Out	(%v/v)
	1000	496.000								
	5	496.180	1000	2				60		
	10	496.365	1000	2				61		
	15	496.550	1000	2				62		
	20	496.738	1000	2				62		
	25	496.905	1000	2				62		
	30	497.145	1000	2				63		
	35	497.333	1000	2				63		
	40	497.515	1000	2				64		
	45	497.700	1000	2				66		
	50	497.890	1000	2				68		
	55	498.077	1000	2				68		
	60	498.265	1000	2				68		
	(1100)									
	$\theta = 60$	$V_m = 2.265$	$(\dot{V}_H)_{avg} = 1000$					$(t_m)_{avg} = 63.9$		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	96.4400	78.0992	18.3408
	Total		18.3408

Preliminary results
of SO₂ concentration
determination

$V_{std} = 2213$ DSCF

Moisture = 27.00 %v/v

SO₂, dry = ppm

SO₂, wet = ppm

LB/MMBtu =

Drawing of Test Site

Cross-section View	Elevation View
-----------------------	-------------------

Temp. Meas. Device & S/N: PDT-3177
R or nothing = reg. manometer; S = expanded; E = electronic

EPA Method 4 and 6 Field Data Sheet

Job LP/HAYWARD
 Source LIND 2 SURFACE DRYER
 Date 3-19-96 Test B Run 34
 Wet Bulb _____
 Dry Bulb _____

Operator(s) ET
 Meter Box No. 65 Gasmeter Coef. 1.0036
 $\Delta H@$ _____ in.WC Bar.Press _____ in.Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0 cfm at 15 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂ (%v/v)
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	
	<u>1935</u>	<u>493.640</u>									
	<u>5</u>	<u>493.840</u>	<u>1000</u>	<u>2</u>					<u>94</u>		
	<u>10</u>	<u>494.025</u>	<u>1000</u>	<u>2</u>					<u>94</u>		
	<u>15</u>	<u>494.218</u>	<u>1000</u>	<u>2</u>					<u>94</u>		
	<u>20</u>	<u>494.402</u>	<u>1000</u>	<u>2</u>					<u>94</u>		
	<u>25</u>	<u>494.585</u>	<u>1000</u>	<u>2</u>					<u>94</u>		
	<u>30</u>	<u>494.778</u>	<u>1000</u>	<u>2</u>					<u>94</u>		
	<u>35</u>	<u>494.965</u>	<u>1000</u>	<u>3</u>					<u>94</u>		
	<u>40</u>	<u>495.154</u>	<u>1000</u>	<u>3</u>					<u>95</u>		
	<u>45</u>	<u>495.350</u>	<u>1000</u>	<u>2</u>					<u>95</u>		
	<u>50</u>	<u>495.541</u>	<u>1000</u>	<u>2</u>					<u>96</u>		
	<u>55</u>	<u>495.740</u>	<u>1000</u>	<u>2</u>					<u>96</u>		
	<u>60</u>	<u>495.935</u>	<u>1000</u>	<u>2</u>					<u>96</u>		
	<u>(2035)</u>										
	<u>0 - 60</u>	<u>V_m 2295</u>	<u>$\Delta H = 1000$ cc</u>		<u>$\bar{t} =$</u>				<u>$\bar{t}_m = 94.7$</u>		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
	<u>53.8894</u>	<u>49.3583</u>	<u>4.5311</u>
Desiccant	<u>87.8126</u>	<u>74.2342</u>	<u>13.5784</u>
	Total		<u>18.1095</u>

Preliminary Results of SO ₂ Concentration Determination		
V _{SO} =	<u>2.1146</u>	DSCF
Moisture Gravimetric =	<u>18.74</u>	%v/v
Moisture Psychrometric =		%v/v
SO ₂ DRY =		PPM
SO ₂ WET =		PPM
LB/MMBtu =		

(612) 786-6020

Drawing of Test Site

Job L.P. / Hayward, WI
 Source Line 2 Surface Dryer / Bunt
 Test 0 Run 5 Date 3-20-96
 Stack Dimen. 42 IN.
 Dry Bulb 212 °F Wet bulb _____ °F
 Manometer ☒ Reg. ☐ Exp ☐ Elec.
 Barometric Pressure 29.31 IN.HG
 Static Pressure - 11.8 IN.WC
 Operators M. Kaehler + L. Hansen
 Pitot No. 31V-6 C .04

Cross-section View	Elevation View
-----------------------	-------------------

[illegible]

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:STACKIWPIFORM5S-392.1

INTERCOLL LABORATORIES
EPA Method 4 and 6 Field Data Sheet

Job UP/HAYWARD
Source LINE 2 SURFACE DRYER
Date 3-20-96 Test 8 Run 5

Operator(s) ET-
Meter Box No. 65 Gasmeter coef. 1.0036
 ΔH 0 in.WC Bar. press 29.31 in.Hg

Sample Train Leak Check:

Pretest: < 0.02 cfm at 15 in. Hg. ☒
Posttest: 0 cfm at 15 in. Hg. ☒

Trav. Point No.	Samp. Time (min)	Sample Volume (cf)	Orif. Meter (inWC)	VAC. inHg	Temperatures (°F)					Oxygen
					Probe	Oven	Impg.	Gas/In	Gas/Out	(%v/v)
	1200	496.350								
	5	498.539	1000	2				82		
	10	498.730	1000	2				82		
	15	498.922	1000	2				82		
	20	499.102	1000	2				82		
	25	499.300	1000	2				82		
	30	499.490	1000	2				83		
	35	499.679	1000	2				83		-
	40	499.868	1000	2				83		
	45	500.057	1000	2				84		
	50	500.250	1000	2				86		
	55	500.435	1000	2				86		
	60	500.620	1000	2				86		
	(1300)									
	$\theta = 120$	$V_m = 2.270$	$(\Delta H)_{avg} = 1000$					$(t_m)_{avg} = 83.4$		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	68.1773	50.0037	18.1736
		Total	18.1736

Preliminary results of SO₂ concentration determination

$V_{std} = 2.168$ DSCF

Moisture = 29.31 %v/v

SO₂, dry = ppm

SO₂, wet = ppm

LB/MMBtu =


INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Method 2 Field Data Sheet

Drawing of Test Site

Job LP/Hayward
 Source Line 2 - Press Vent Stack (C CRD)
 Test 9 Run 0 Date 3-19-96
 Stack Dimen. 76.25 IN.
 Dry Bulb 233 °F Wet bulb 83 °F
 Manometer ☒ Reg. ☐ Exp ☐ Elec.
 Barometric Pressure 28.78 IN.HG
 Static Pressure - .35 IN.WC
 Operators SP/KN
 Pitot No. V22-8 C_p 0.84



Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas
		Port Length: <u>6.25</u> IN.	Time Start: <u>543</u> HRS		
A 1	.021	1.60	7.85	.35	
2	.087	5.11	11.35	.47	
3	.118	9.00	15.25	.55	
4	.177	13.50	19.75	.57	
5	.250	19.06	25.31	.61	
6	.356	27.14	33.40	.62	
7	.644	49.10	55.36	.71	
8	.750	57.19	63.44	.78	
9	.823	62.75	69.00	.78	
10	.882	67.25	73.50	.79	
11	.933	71.14	77.39	.75	
12	.979	74.65	80.90	.67	
B 1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
Temp. Meas. Device & S/N:				Time End: <u>900</u> HRS	

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:\STACK\WP\FORMS\S-392.1

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP/HaywardDate 3-19-96 Test 9 Run 1Source Line 2 Press VentNo. of traverse points 24Method DDU Filter holder: N/AFilter type: N/A

Sample Train Leak Check:

• Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.00 cfm at 8 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☐ acetone☒ other(s) MeCl₂

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	<u>474</u>	<u>475</u>	<u>1</u>
Impinger No. 3			
Condenser			
Desiccant	<u>1346</u>	<u>1336</u>	<u>10</u>
Total			<u>11</u>

Integrated Gas Sampling Data:

Bag Pump No.

223

Box No.

17 Bag No. 1

Bag Material:

5-layer Aluminized Tedlar

Size:

44 L

Pretest leak check:

0.00

cc/min at

16 IN.HG

Time start:

1030

(HRS) Time end:

1145 (HRS)

Sampling rate:

400

cc/min Operator:

SFS/N of O₂ Analyzer used to monitor train outlet:

052394-C:\STACK\WP\FORMS\SS-0046RK-

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP/HaywoodDate 3-19-96 Test 9 Run 2Source Line 2 Press VentNo. of traverse points 24Method 0011 Filter holder: N/AFilter type: N/A

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.00 cfm at 8 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☐ acetone☒ Other(s) MeCl₂

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	479	476	3
Impinger No. 3			
Condenser			
Desiccant	1453	1446	7
Total			10

Integrated Gas Sampling Data:

Bag Pump No. 223Box No. 14 Bag No. 2Bag Material: 5-layer Aluminized TedlarSize: 44 LPretest leak check: 0.00cc/min at 16 IN.HGTime start: 1222(HRS) Time end: 1336 (HRS)Sampling rate: 400cc/min Operator: SFS/N of O₂ Analyzer used to monitor train outlet: —

052394-G:\STACK\WP\FORMS\S-0046RK

EPA Method 5 Field Data Sheet

Job	LP/playward	Operator
Source	Line 2 Press Vert (210)	Meter Box
		Gasmeter

Pilot No. 622-8
 C_p 0.84
 H_2O 1.9

[illegible]

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP/Hayward Date 3-19-96 Test 9 Run 3
 Source Line 2 Press Vent (RTO) No. of traverse points 24
 Method 0211 Filter holder: N/A Filter type: N/A

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.00 cfm at 9 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☐ acetone☒ Other(s) Meth

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	<u>481</u>	<u>480</u>	<u>1</u>
Impinger No. 3			
Condenser			
Desiccant	<u>1360</u>	<u>1346</u>	<u>14</u>
Total			<u>15</u>

Integrated Gas Sampling Data:

Bag Pump No. 223
 Bag Material: 5-layer Aluminized Tedlar
 Pretest leak check: 0.03
 Time start: 1440
 Sampling rate: 400

Box No. 14 Bag No. 3
 Size: 44 L
 cc/min at 16 IN.HG
 (HRS) Time end: 1554 (HRS)
 cc/min Operator: SF

S/N of O₂ Analyzer used to monitor train outlet: —

052394-GASTACKIWPFORMSS-0046K..

EPA Method 5 Field Data Sheet

Job LP/Keywood
Source Line 2 Pias Vent
Date 3-19-96 Test 9 Run 3

Operators SF/KW
Meter Box No. 17 ΔH @ 1.81 in. WC
Gas meter Coeff. 0.9536

Nozzle No. 6455
Nozzle Dia. 1.242 in.
Bar. Press. 28.78 in. Hg

Pilot No. 122-8
C_p 0.84
H₂O 1.0 %

Date 3-19-96 Test 9 Run 3 Gasmeter Coal.													
Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in.WC)	Orifice Meter (in.WC)	Des. Vol. (cf)	VAC. (in.Hg)	Temperatures (°F)					Oxygen (% v/v)	
							Stack	Probe	Oven	Imp.	Gas/In		Gas/Out
	(1440)	35.01											
A 12	3	37.48	0.78	2.18	7.54	6	234	250	245	36	62	62	
11	6	40.03	0.84	2.30	0.12	7	233	252	241	36	63	62	
10	9	42.64	0.87	2.38	2.75	7	235	248	243	36	67	62	
9	12	45.29	0.86	2.34	5.36	7	232	245	243	37	68	62	
8	15	47.79	0.78	2.15	7.84	6	233	252	247	39	70	62	
7	18	50.37	0.90	2.21	0.40	6	234	255	246	39	73	62	
6	21	52.95	0.81	2.24	2.96	7	235	255	242	39	75	63	
5	24	55.37	0.72	2.00	5.38	6.5	233	249	237	41	76	63	
4	27	57.62	0.64	1.78	7.67	5.5	233	247	241	41	79	65	
3	30	59.99	0.65	1.81	9.99	5.5	234	252	240	41	80	85	
2	33	62.14	0.59	1.65	2.20	5	233	243	236	40	83	66	
1	36	64.25	0.50	1.40	4.24	5	232	251	240	39	81	67	
B 12	39	66.39	0.58	1.63	15.77	6	235	255	234	39	83	68	
11	42	68.70	0.65	1.83	1.15	6	235	254	237	39	84	68	
10	45	71.08	0.68	1.91	3.69	7	235	249	241	40	84	69	
9	48	73.61	0.77	2.16	6.29	7	234	247	236	40	85	69	
8	51	76.24	0.81	2.28	8.44	5	233	241	233	41	85	70	
7	54	78.44	0.55	1.55	0.96	6.5	234	239	230	41	85	70	
6	57	80.90	0.75	2.11	3.45	6.5	233	237	230	42	86	70	
5	60	83.37	0.74	2.09	5.85	6	232	237	236	42	86	70	
4	63	85.87	0.68	1.92	8.20	6	231	242	240	41	88	71	
3	66	88.23	0.65	1.84	0.42	5	230	244	237	42	88	71	
2	69	90.38	0.58	1.65	2.49	5	231	247	235	42	88	72	
1	72	92.50	0.50	1.42									
	(1557)												
	0 - 72	V _m - 57.49		1.95								Avg. - 72.8	

INTERPOL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Job LP/Hayward
Source Line 2 Press Vent (RTO)
Test 10 Run 0 Date _____
Stack Dimen. 76.25 IN.
Dry Bulb _____ °F Wet bulb _____ °F
Manometer ☒ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 29.31 IN.HG
Static Pressure -.40 IN.WC
Operators SF/KN
Pitot No. V22-8 C 0.84

Cross-section View	Elevation View
-----------------------	-------------------

Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas
		Port Length: <u>6.25</u> IN.	Time Start: _____ HRS		
A 1	.021	1.60	7.85		
2	.067	5.11	11.35		
3	.118	9.00	15.25		
4	.177	13.50	19.75		
5	.250	19.06	25.31		
6	.356	27.14	33.40		
7	.644	49.10	55.36		
8	.750	57.19	63.44		
9	.823	62.75	69.00		
10	.882	67.25	73.50		
11	.933	71.14	77.39		
12	.979	74.65	80.90		
B 1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
Temp. Meas. Device & S/N: <u>20T-#51</u>				Time End: _____ HRS	

R or nothing = Reg. manometer; S = expanded; E = electronic

032594-G:\STACK\WPI\FORMS\S-392.1

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP/Hayward Date 3-20-96 Test 10 Run 1
Source Line 2 Press Vent No. of traverse points 24
Method 5 Filter holder: Glass Filter type: 2 1/2" 6/655 fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: 0.00 cfm at 16 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

8330

Recovery solvent(s)

☒ Acetone

☐ Other(s)

No. of probe wash bottles:

1

Sample recovered by:

SF

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	494	490	4
Impinger No. 3			
Condenser			
Desiccant	1427	1413	14
Total			15

Integrated Gas Sampling Data:

Bag Pump No. 223
Bag Material: 5-layer Aluminized Tedlar
Pretest leak check: 0.00
Time start: 1012
Sampling rate: 400

Box No. 16 Bag No. 1
Size: 44 L
cc/min at 16 IN.HG
(HRS) Time end: 1114 (HRS)
cc/min Operator: SF

S/N of O₂ Analyzer used to monitor train outlet:

05239-C:STACK\WP\FORMS\S-0046RR

EPA Method 5 Field Data Sheet

Job LP/Hayward
 Source Line 2 Press Vent
 Date 3-20-96 Test 10 Run 1

Operators
 Meter Box No. 12 ΔH @ 1.81 in.WC
 Gas meter Coeff. .9936

Nozzle No. 10-Y
 Nozzle Dia. .289 in.
 Bar. Press. 29.31 in.Hg

Pilot No. V22-8
 C_p 0.84
 H_2O 11.5 %

Date 3-20-96 Test 10 Run 1		Gasmeter Coeff. 54436		Bar. Press. 29.97		m. 7.8							
Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in.WC)	Orifice Meter (in.WC)	Des. Vol. (cf)	VAC. (in.Hg)	Temperatures (°F)					Oxygen (% v/v)	
							Stack	Probe	Oven	Imp.	Gas/In		Gas/Out
	(10.2)	107.59											
A 12	2.5	109.12	0.39	1.22	9.16	6	230	229	227	34	51	45	
11	5	111.95	0.59	1.74	1.68	8	235	226	231	35	57	49	
10	7.5	112.79	0.60	1.79	2.86	9	237	230	229	35	59	48	
9	10	114.72	0.65	1.95	4.81	10	233	233	235	36	61	48	
8	12.5	116.76	0.71	2.13	6.84	11	235	236	242	36	62	49	
7	15	118.59	0.53	1.59	5.60	9	237	236	245	36	62	50	
6	17.5	120.49	0.62	1.86	0.51	10	236	232	239	40	64	51	
5	20	122.40	0.65	1.95	2.47	11	236	234	237	41	65	51	
4	22.5	124.38	0.66	1.99	4.44	11	235	230	239	41	66	51	
3	25	126.22	0.53	1.60	6.21	9	237	231	242	40	67	52	
2	27.5	128.01	0.55	1.68	8.03	9	230	234	245	40	67	52	
1	30	129.52	0.53	1.62	7.82	9	228	233	245	41	68	53	
B 12	32.5	131.63	0.55	1.67	1.63	9	234	230	241	42	69	54	
11	35	133.61	0.67	2.05	3.65	11	228	229	243	42	72	55	
10	37.5	135.62	0.69	2.10	5.69	12	234	235	237	39	73	55	
9	40	137.81	0.80	2.44	7.89	14	234	237	232	39	74	56	
8	42.5	140.94	0.77	2.36	0.06	14	231	242	237	40	74	58	
7	45	142.09	0.72	2.31	2.15	13	234	240	237	40	74	58	
6	47.5	144.03	0.62	1.90	4.10	12	234	247	234	40	74	59	
5	50	145.97	0.58	1.74	5.99	9	232	245	231	40	75	59	
4	52.5	147.82	0.53	1.63	7.79	9	234	239	230	39	76	60	
3	55	149.54	0.52	1.60	9.58	8	234	236	229	39	76	60	
2	57.5	151.25	0.45	1.39	1.25	7	230	231	227	39	82	63	
1	60	152.78	0.35	1.10	2.74	6	228	233	228	40	83	64	
	(114)												
	0-60	V _m = 45.19		ΔT = 1.81							Avg. = 61.4		

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP/Hayward Date 3-20-96 Test 10 Run 2
Source Line 2 Press Vent (RTU) No. of traverse points 2.7
Method 5 Filter holder: Glass Filter type: 4" 6/151 Fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: 0.00 cfm at 15 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

8331

☒ acetone _____
☐ other(s) _____

No. of probe wash bottles:

1
SF

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	481	483	-2
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1521	1503	18
Total			16

Integrated Gas Sampling Data:

Bag Pump No. 228
Bag Material: 5-layer Aluminized Tedlar
Pretest leak check: 0.00
Time start: 1135
Sampling rate: 400

Box No. 16 Bag No. 2
Size: 44 L
cc/min at 16 IN.HG
(HRS) Time end: 1241 (HRS)
cc/min Operator: SF

S/N of O₂ Analyzer used to monitor train outlet: _____

052394-G:STACKWPFORMSS-0046RR

EPA Method 5 Field Data Sheet

Job LP/Hayward
Source Line 2 Press Unit (1770)
Date 3-20-96 Test 10 Run 2

Operators

Meter Box No.

Gasmeter Coeff.

5.0 CF/KW
14 Δ11@ 1.87 in.WC
9936

Nozzle No. 10-4
Nozzle Dia. .249 in.
Bar. Press. 29.31 in.Hg

Pilot No. 622-8
 C_p 0.84
 H_2O 1.8

Date 3-20-96 Test 10 Run 2			Gas meter Conn.			Temperatures (°F)										Oxygen
Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Stack	Probe	Oven	Insp.	Gas/In	Gas/Out	Oxygen (% v/v)			
	(1135)	153.08														
B 12	2.5	154.88	0.55	1.67	4.89	8	235	230	237	38	68	66				
11	5	156.80	0.60	1.84	6.81	9	234	233	242	38	67	64				
10	7.5	158.81	0.65	2.03	8.55	10	235	235	240	38	66	64				
9	10	161.45	0.78	2.38	1.02	14	236	242	235	39	67	62				
8	12.5	163.09	0.75	2.30	3.16	14	230	248	234	39	67	62				
7	15	165.20	0.74	2.26	5.28	13	233	248	230	38	67	61				
6	17.5	167.24	0.65	1.98	7.26	12	236	246	231	39	68	61				
5	20	169.17	0.56	1.71	9.11	10	233	246	233	39	69	61				
4	22.5	170.96	0.54	1.65	0.92	8	234	240	239	40	71	61				
3	25	172.68	0.52	1.59	2.71	8	234	239	231	40	73	61				
2	27.5	174.39	0.47	1.45	4.41	7.5	231	238	232	40	75	62				
1	30	176.03	0.40	1.24	5.99	7	230	243	229	41	77	62				
A 12	32.5	177.21	0.44	1.37	7.65	7	230	245	227	40	77	62				
11	35	179.47	0.55	1.71	9.50	8	230	239	229	39	78	63				
10	37.5	181.51	0.61	2.08	1.54	12	231	236	231	39	79	63				
9	40	183.50	0.63	1.55	3.52	11	237	238	231	39	78	63				
8	42.5	185.54	0.67	2.07	5.56	12	235	233	227	40	79	63				
7	45	187.48	0.59	1.83	7.48	11	234	233	226	35	79	64				
6	47.5	189.49	0.67	2.08	9.52	12	233	237	229	36	80	64				
5	50	191.54	0.71	2.17	1.61	13	236	241	230	36	80	65				
4	52.5	193.59	0.64	1.98	3.61	11	235	244	229	36	79	66				
3	55	195.51	0.57	1.78	5.50	10	231	243	226	37	79	65				
2	57.5	197.35	0.52	1.62	7.31	9	230	247	231	37	80	66				
1	60	199.12	0.50	1.56	9.09	8	230	245	230	36	82	67				
	(1241)															
	0 - 60	V _m = 46, 049		1.85							AVG. =	65.6				

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job C2/Hayward Date 3-20-96 Test 10 Run 3
Source Line 2 Press Vent (RTG) No. of traverse points 24
Method 5 Filter holder: G/ass Filter type: 4" glass fiber

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: 0.00 cfm at 17 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

8473

Recovery solvent(s)

☒ Acetone _____
☐ Other(s) _____

No. of probe wash bottles:

Sample recovered by:

1
SE

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	<u>507</u>	<u>498</u>	<u>9</u>
Impinger No. 3			
Condenser			
Desiccant	<u>1439</u>	<u>1424</u>	<u>15</u>
Total			<u>24</u>

Integrated Gas Sampling Data:

Bag Pump No. 223
Bag Material: 5-layer Aluminized Tedlar
Pretest leak check: 0.00
Time start: 1305
Sampling rate: 400

Box No. 16 Bag No. 3
Size: 44 L
cc/min at 16 IN.HG
(HRS) Time end: 1411 (HRS)
cc/min Operator: SE

S/N of O₂ Analyzer used to monitor train outlet: _____

052394-GASTACKIWPFORMS-0046RR

EPA Method 5 Field Data Sheet

Job 612/Hesperus
 Source Line 2, Press Vent (E70)
 Date 3-20-96 Test 10 Run 3

Operators SP/KM
 Meter Box No. 14 ΔH @ 1.5 in WC
 Gas meter Coeff. 0.9936

Nozzle No. 1004
 Nozzle Dia. 0.245 in.
 Bar. Press. 29.31 in. Hg


Pilot No. 622-18
 C_p 0.54
 H_2O 1.5 %

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)						Oxygen (% v/v)	
							Stack	Probe	Oven	Insp.	Gas/In	Gas/Out		
	(1305)	199.414												
A 12	2.5	201.15	0.47	1.44	1.14	7	236	237	229	34	67	65		
11	5	203.01	0.60	1.84	3.05	9	233	241	230	34	70	65		
10	7.5	205.98	0.62	1.91	5.01	10	233	240	233	35	71	65		
9	10	207.99	0.67	2.06	7.04	11	234	245	233	35	72	64		
8	12.5	209.09	0.72	2.21	9.14	13	236	240	227	36	73	64		
7	15	210.87	0.51	1.57	6.91	8	235	235	228	36	72	63		
6	17.5	212.90	0.68	2.09	2.96	11	236	232	228	34	74	62		
5	20	215.04	0.73	2.24	5.07	13	234	234	229	34	75	63		
4	22.5	217.03	0.64	1.97	2.06	11	235	231	229	35	74	63		
3	25	218.86	0.53	1.64	8.87	8	233	236	232	35	75	63		
2	27.5	220.68	0.54	1.67	0.70	8	233	238	229	35	77	64		
1	30	222.39	0.48	1.49	2.43	8	230	241	227	35	78	64		
B 12	32.5	224.37	0.62	1.92	4.40	10	237	246	229	36	78	65		
11	35	226.39	0.68	2.12	6.47	12	230	241	229	36	79	64		
10	37.5	228.56	0.74	2.30	8.61	14	232	244	228	36	74	68		
9	40	230.71	0.78	2.41	0.82	15	234	240	231	36	73	66		
8	42.5	232.84	0.72	2.22	2.83	14	234	242	228	36	72	66		
7	45	234.83	0.66	1.91	4.88	11	235	238	227	36	72	66		
6	47.5	236.74	0.57	1.82	6.79	10	235	238	229	37	73	66		
5	50	238.58	0.55	1.70	8.64	9	235	239	226	37	74	66		
4	52.5	240.31	0.49	1.52	0.38	8	232	240	233	37	76	66		
3	55	242.08	0.50	1.56	2.15	8	230	242	234	37	78	66		
2	57.5	243.82	0.47	1.47	3.88	8	230	241	230	37	78	66		
1	60	245.33	0.37	1.16	5.41	6	228	247	227	38	79	67		
	(1711)													
	0 - 60	$V_m = 45.89$		$1.84 \Delta H$								Avg. = 69.6		

INTERPOLL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Source LP/Hayward
 Test Line 2 Press Vent (RTO)
 Stack Dimen. 76.25 IN.
 Dry Bulb °F Wet bulb °F
 Manometer ☒ Reg. ☐ Exp ☐ Elec.
 Barometric Pressure 28.98 IN.HG
 Static Pressure -1.57 IN.WC
 Operators SE/KN
 Pitot No. V22-8 C_p 0.84



Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas (°F)
		Port Length: <u>6.25</u> IN.	Time Start: <u>HRS 1651</u>		
A 1	<u>.021</u>	<u>1.60</u>	<u>7.85</u>	<u>.62</u>	
2	<u>.067</u>	<u>5.11</u>	<u>11.35</u>	<u>.62</u>	
3	<u>.118</u>	<u>9.00</u>	<u>15.25</u>	<u>.64</u>	
4	<u>.177</u>	<u>13.50</u>	<u>19.75</u>	<u>.59</u>	
5	<u>.250</u>	<u>19.06</u>	<u>25.31</u>	<u>.63</u>	<u>233</u>
6	<u>.356</u>	<u>27.14</u>	<u>33.40</u>	<u>.62</u>	
7	<u>.444</u>	<u>49.10</u>	<u>55.36</u>	<u>.64</u>	
8	<u>.750</u>	<u>57.19</u>	<u>67.44</u>	<u>.64</u>	
9	<u>.823</u>	<u>62.75</u>	<u>69.00</u>	<u>.60</u>	
10	<u>.882</u>	<u>67.25</u>	<u>73.50</u>	<u>.62</u>	
11	<u>.933</u>	<u>71.14</u>	<u>77.39</u>	<u>.41</u>	
12	<u>.979</u>	<u>74.65</u>	<u>80.90</u>	<u>.37</u>	
B 1				<u>.58</u>	
2				<u>.60</u>	
3				<u>.58</u>	
4		<u>MC = 1/6 = 18.9%</u>		<u>.59</u>	
5		<u>3/6 = 47.3%</u>		<u>.59</u>	
6		<u>5/6 = 69.8%</u>		<u>.62</u>	
7				<u>.60</u>	
8				<u>.56</u>	<u>233</u>
9				<u>.54</u>	
10				<u>.47</u>	
11				<u>.53</u>	
12				<u>.47</u>	
Temp. Meas. Device & S/N: <u>PDT = #51</u>				Time End: <u>1658</u> HRS	

R or nothing ☒ reg. manometer; S = expanded; E = electronic

032594-G:STACK\WP\FORMS\S-392.1

(612) 786-6020

EPA Method 4 and 6 Field Data Sheet

Job 62/Hayward
Source Line 2 Press Vent (RTO)
Date 3-20-96 Test 11 Run 1
Wet Bulb _____
Dry Bulb _____

Operator(s) SF/kN
 Meter Box No. 14 Gas meter Coef. 9936
 $\Delta H @$ 1.81 in.WC Bar.Press 25.78 in.Hg
Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0.04 cfm at 8 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	(%v/v)
	(1650)	245.51									
3	5	249.15	1.81	2		251	242	37	59	43	
3	10	252.79	1.81	2		256	245	37	63	52	
3	15	256.48	1.81	2		256	245	37	70	54	
3	20	260.16	1.81	2		252	249	39	73	58	
2	25	263.84	1.81	2		247	253	38	75	56	
2	30	267.54	1.81	2		243	251	38	80	62	
2	35	271.24	1.81	2		245	252	38	82	63	
2	40	274.95	1.81	2		249	248	39	84	65	
1	45	277.68	1.81	2		245	249	36	84	65	
1	50	282.37	1.81	2		247	252	36	86	66	
1	55	286.13	1.81	2		253	257	36	87	68	
1	60	289.89	1.81						88	68	
	(1760)										
	0-60	V _m = 44.38	ΔP = 1.81	5-					5-	69.63	

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	1510	1490	
		Total	

Preliminary Results of SO ₂ Concentration Determination	
V _{ad} = 42.76	DSCF
Moisture Gravimetric = 2.16	%v/v
Moisture Psychrometric =	%v/v
SO ₂ , DRY =	PPM
SO ₂ , WET =	PPM
LB/MMBtu =	

INTERPOLL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Job LP/Hayward
 Source Line 2 Press Vent (RTO)
 Test 11 Run 2 Date 3-20-96
 Stack Dimen. 76.25 IN.
 Dry Bulb °F Wet bulb °F
 Manometer ☒ Reg. ☐ Exp ☐ Elec.
 Barometric Pressure 29.98 IN.HG
 Static Pressure -0.49 IN.WC
 Operators SE/KN
 Pitot No. V22-B Cp 0.84

Cross-section View	Elevation View
-----------------------	-------------------

Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas (°F)
		Port Length: <u>6.25</u> IN.	Time Start: <u>HRS 1815</u>		
A 1				.43	
2				.53	234
3				.55	
4				.55	
5				.56	
6				.58	
7				.62	
8				.60	
9				.58	
10				.48	
11				.51	
12				.58	
B 1				.51	
2				.70	
3				.63	
4				.52	
5				.61	234
6				.67	
7				.69	
8				.70	
9				.66	
10				.63	
11				.57	
12				.54	
Temp. Meas. Device & S/N: <u>PDT-#51</u>				Time End: <u> </u> HRS	

R or nothing = (reg.) manometer; S = expanded; E = electronic

EPA Method 4 and 6 Field Data Sheet

Job LP/Hayward
 Source Line 2 Press Vent (RTO)
 Date 3-20-96 Test 11 Run 3
 W. Bulb _____
 Dry Bulb _____

Operator(s) SF/kN
 Meter Box No. 14 Gasmeter Coef. .9936
 $\Delta H@$ 1.81 in.WC Bar.Press 28.98 in.Hg
 Sample Train Leak Check:
 Pretest: < 0.02 cfm at 15 in.WC ☒
 Post Test: 0.02 cfm at 10 in.WC ☒

Trav. Point No.	Sample Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	Vac. in.Hg	Temperatures (°F)						O ₂
					Stack	Probe	Oven	Impg.	Gas/ In	Gas/ Out	(%v/v)
	(2015)	334.96									
3	5	338.73	1.81	2		237	244	37	67	73	
3	10	342.39	1.81	2		241	249	37	73	72	
3	15	346.108	1.81	2		238	252	37	78	74	
3	20	349.87	1.81	2		237	249	37	84	76	
2	25	353.64	1.81	2		242	256	38	90	78	
2	30	357.38	1.81	2		245	251	38	90	78	
2	35	361.17	1.81	2		243	247	39	90	81	
2	40	364.98	1.81	2		236	241	39	93	86	
1	45	368.69	1.81	2		240	242	40	93	87	
1	50	372.39	1.81	2		237	244	41	93	86	
1	55	376.15	1.81	2		238	242	41	94	87	
1	60	379.94	1.81	2		237	244	42	95	87	
	(2115)										
	0-60	V _m = 44.98	ΔH = 1.81		F =				83.5		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	152.8	151.0	1.8
	Total		1.8

Preliminary Results of SO ₂ Concentration Determination	
V _{std} =	42.23 DSCF
Moisture Gravimetric =	1.97 %v/v
Moisture Psychrometric =	%v/v
SO ₂ , DRY =	PPM
SO ₂ , WET =	PPM
LB/MMBtu =	

Drawing of Test Site

Cross-section View	Elevation View
--------------------	----------------

R or nothing = reg. manometer; S = expanded; E = electronic

Job L.P. / Hayward, WI
 Source No. 2 Press RTO / Inlet
 Date 3-20-96 Test 12 Run 1

Operator(s) M. Kuehler + L. Hansen
 Meter Box No. 172 Gas meter coef. 1.0047
 ΔH NA in.WC Bar. press 29.00 in.Hg

Sample Train Leak Check:

Pretest: < 0.02 cfm at 15 in. Hg. ☒
 Posttest: 20.02 cfm at 16 in. Hg. ☒

Trav. Point No.	Samp. Time (min)	Sample Volume (cf)	Orif. Meter (in.WC)	VAC. inHg	Temperatures (°F)					Oxygen
					Probe	Oven	Impg.	Gas/In	Gas/Out	(%v/v)
	1650	280.438								
A-3	5	280.629	1000	2	153	NA	NA	68	NA	20.9
3	10	280.820	1000	2	150			68		
3	15	281.010	1000	2	145			68		
3	20	281.200	1000	2	158			68		
2	25	281.387	1000	2	143			68		
2	30	281.573	1000	2	140			68		
2	35	281.762	1000	2	140			68		
2	40	281.947	1000	2	135			68		
1	45	282.137	1000	2	138			68		
1	50	282.324	1000	2	139			68		
1	55	282.511	1000	2	143			68		
1	60	282.698	1000	2	140	↓	↓	68	↓	↓
	(1700)									
	$\theta = 60$	$V_m = 2.260$	$(\Delta H)_{avg} =$					$(t_m)_{avg} = 68$		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	42.4003	41.2453	1.1550
	Total		1.1550

Preliminary results of SO₂ concentration determination

$V_{std} = 2.200$ DSCF

Moisture = 2.41 %v/v

SO₂, dry = ppm

SO₂, wet = ppm

LB/MMBtu =

EPA Method 2 Field Data Sheet

Drawing of Test Site

Job L.P. / Hayward, WI
 Source No. 2 Press RTO / Inlet
 Test 12 Run 2 Date 3-20-96
 Stack Dimen. 58.5 IN.
 Dry Bulb 122 °F Wet bulb _____ °F
 Manometer ☒ Reg. ☐ Exp ☐ Elec.
 Barometric Pressure 29.00 IN.HG
 Static Pressure -4.2 IN.WC
 Operators W. Kuebler + J. Hansen
 Pitot No. 31 V-6 C₂ .04

Cross-section View	Elevation View
-----------------------	-------------------

Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas (°F)
		Port Length:	4 IN.	Time Start: 1920 HRS	
A-1				1.45	
2		Retor to Test 12		1.79	
3				1.90	
4		Run 1 for pts		2.12	
5				2.15	
6				1.83	
B-1				1.65	122
2				1.81	
3				2.10	
4				1.88	
5				1.90	
6				1.10	
Temp. Meas. Device & S/N: PNT-31 / TC				Time End: 1925 HRS	

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:\STACK\WP\FORMS\S-392.1

EPA Method 4 and 6 Field Data Sheet

Job L.P. / Hayward, WI
 Source No. 2 Press 120 / Inlet
 Date 3-20-46 Test 12 Run 2

Operator(s) M. Kaehler + L. Hansen
 Meter Box No. 172 Gasmeter coef. 1.0047
 ^H₂ NA in.WC Bar. press 29.00 in.Hg

Sample Train Leak Check:

Pretest: < 0.02 cfm at 15 in. Hg. ☒
 Posttest: 0.02 cfm at 15 in. Hg. ☒

Trav. Point No.	Samp. Time (min)	Sample Volume (cf)	Drif. Meter (inWC)	VAC. inHg	Temperatures (°F)					Oxygen (%v/v)
					Probe	Oven	Impg.	Gas/In	Gas/Out	
	1015	202.710								
A-3	5	202.900	1000	2	143	NA	NA	68	NA	20.9
3	10	203.005	1000	2	140			68		
3	15	203.267	1000	2	135			68		
3	20	203.448	1000	2	139			68		
2	25	203.630	1000	2	137			68		
2	30	203.789	1000	2	141			68		
2	35	203.920	1000	2	140			68		
2	40	204.140	1000	2	143			68		
1	45	204.313	1000	2	141			68		
1	50	204.485	1000	2	140			68		
1	55	204.648	1000	2	140			68		
1	60	204.810	1000	2	139	↓	↓	68	↓	↓
	(1915)									
	θ=60	V _m =2.110	(^H) _{avg} =					(t _m) _{avg} =68		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	44.2677	43.2188	1.0489
	Total		1.0489

Preliminary results of SO ₂ concentration determination	
V _{std}	= 2.054 DSCF
Moisture	= 2.35 %v/v
SO ₂ , dry	= ppm
SO ₂ , wet	= ppm
LB/MMBtu	=

Drawing of Test Site

Cross-section View	Elevation View
-----------------------	-------------------

11 Temp. Meas. Device & S/N:

Time End: 1223HRS

032594-G:STACK\WP\FORMS\S-392.1

INTERPOL LABORATORIES
EPA Method 4 and 6 Field Data Sheet

Job L.P. / Hugunard, WI
Source No. 2 Press RTO / Inlet
Date 3-20-96 Test 12 Run 3

Operator(s) M. Kachler + J. Hansen
Meter Box No. TR2 Gas meter coef. 1.0047
 ΔH NA in. WC Bar. press 29.00 in. Hg

Sample Train Leak Check:

Pretest: < 0.02 cfm at 15 in. Hg.

Posttest: 0.02 cfm at 16 in. Hg.

Trav. Point No.	Samp. Time (min)	Sample Volume (cf)	Drift Meter (inWC)	VAC. inHg	Temperatures (°F)					Oxygen (%v/v)
					Probe	Oven	Impg.	Gas/In	Gas/Out	
	2015	284.862								
A-3	5	285.020	1000	2	143	NA	NA	68	NA	20.9
3	10	285.190	1000	2	141			68		
3	15	285.356	1000	2	135			68		
3	20	285.522	1000	2	142			68		
2	25	285.688	1000	2	136			68		
2	30	285.861	1000	2	138			68		
2	35	286.015	1000	2	135			68		
2	40	286.345	1000	2	139			68		
1	45	286.508	1000	2	143			68		
1	50	286.660	1000	2	140			68		
1	55	286.741	1000	2	140			68		
1	60	286.822	1000	2	143	↓	↓	68	↓	↓
	(2115)									
	$\theta = 60$	$V_m = 1.960$	$(\Delta H)_{avg} = 1000$					$(t_m)_{avg} = 68$		

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impingers			
Condenser			
Desiccant	42.43.3036	42.4003	.9033
	Total		.9033

Preliminary results of SO₂ concentration determination

$V_{std} = 1.908$ DSCF

Moisture = 2.18 %v/v

SO₂, dry = ppm

SO₂, wet = ppm

LB/MMBtu =


INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Method 2 Field Data Sheet

Drawing of Test Site

Job LP/ Hayward
 Source LINE 2 KONUS STACK
 Test 13 Run 0 Date 3-19-76
 Stack Dimen. 51.5 IN.
 Dry Bulb _____ °F Wet bulb _____ °F
 Manometer ☒ Reg. ☐ Exp. ☐ Elec.
 Barometric Pressure 28.69 IN.HG
 Static Pressure -.32 IN.WC
 Operators BA MP
 Pitot No. 210-59 C_p .840
CH₂O



Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas
		Port Length: <u>3.5</u> IN.	Time Start: <u>0950</u> HRS		
A - 1	.021	1.08	4.58	.20	
2	.067	3.45	6.95	.31	
3	.118	6.08	9.58	.32	
4	.177	9.12	12.62	.31	
5	.250	12.88	16.38	.29	
6	.356	18.33	21.83	.25	389
7	.644	23.17	36.67	.20	
8	.750	39.63	42.13	.20	
9	.823	42.38	45.88	.21	
10	.892	45.42	48.92	.22	
11	.923	48.05	51.55	.24	
12	.979	50.42	53.92	.21	
B - 1				.19	
2				.26	
3	~	MC	8	.28	
4	~	O ₂	14	.28	
5				.25	
6	~	FT/SEC	35.5	.21	
7	~	ACFM	30816	.19	382
8	~	DSCFM	16972	.19	
9				.20	
10				.24	
11				.26	
12				.25	
Temp. Meas. Device & S/N: <u>PDT 33</u>				Time End:	HRS

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:\STACK\WP\FORMS\S-392.1

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job CP/ ALYWARD
Source LINE 2 Korus STALK
Method 0011 Filter holder: NA

Date 3-19-96 Test 3 Run 1
No. of traverse points 24
Filter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒

Post test: 0.0 cfm at 10 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

☐ acetone

☒ Other(s) MCC

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	652	536	96
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1482	1460	22
Total			118

Integrated Gas Sampling Data:

TR7

Bag Pump No.

Bag Material:

Pretest leak check:

Time start:

Sampling rate:

Box No.

Size:

cc/min at

(HRS) Time end:

cc/min Operator:

Bag No.

44 L

IN.HG

(HRS)

S/N of O₂ Analyzer used to monitor train outlet:

052394-C:\STACK\WP\FORMS\SS-0046RR

EPA Method 5 Field Data Sheet

Job CP/ Hayward Operators BA MP Nozzle No. 61235 Pilot No. 310-59
 Source 1205-2 Kauls SMC Meter Box No. 15 ΔH@ 1.78 in.WC Nozzle Dia. 1.370 in. CP
 Date 3-18-96 Test 13 Run 1 Gasmer Coeff. .9564 Bar. Press. 28.67 in.Hg 8 H₂O %

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in.WC)	Orifice Meter (in.WC)	Des. Vol. (cf)	VAC. (in.Hg)	Temperatures (°F)					Oxygen (% v/v)	
							Stack	Probe	Oven	Imp.	Gas/In		Gas/Out
	(1036)	(1010.50)											
B-12	2.5	1013.10	.39	2.98	1013.93	7	379	225	224	39	51	43	
11	5	1015.06	.37	2.73	1015.25	6	386	240	248	39	56	44	
10	7.5	1017.32	.37	2.74	1017.59	6	390	242	255	38	60	44	
9	10	1019.63	.33	2.74	1019.25	6	390	254	257	39	62	48	
8	12.5	1021.68	.22	2.26	1021.89	6	387	254	247	43	62	47	
7	15	1023.77	.20	2.04	1023.91	6	392	256	240	44	64	47	
6	17.5	1025.96	.24	2.44	1022.13	6	397	256	238	45	65	48	
5	20	1028.22	.27	2.25	1028.49	7	395	257	246	43	66	47	
4	22.5	1030.65	.31	3.15	1031.01	8	397	251	230	47	66	48	
3	25	1033.10	.31	3.16	1033.53	8	395	250	231	45	68	48	
2	27.5	1035.72	.27	2.78	1035.50	8	391	246	230	45	67	47	
1	30	1038.24	.29	2.97	1038.35	8	392	247	232	47	67	50	
A-12	32.5	1040.54	.25	2.57	1040.63	6	393	251	240	49	63	49	
11	35	1042.74	.23	2.35	1042.80	6	394	240	241	50	65	47	
10	37.5	1045.01	.25	2.55	1045.07	6.5	394	235	230	52	65	48	
9	40	1047.14	.22	2.26	1047.21	6	389	241	237	52	67	49	
8	42.5	1049.39	.24	2.47	1049.15	6	390	243	240	52	68	51	
7	45	1051.51	.21	2.17	1051.55	6	389	241	238	51	69	51	
6	47.5	1053.79	.26	2.69	1053.88	7	390	245	242	53	69	51	
5	50	1056.16	.30	3.09	1056.38	8	393	245	237	52	70	51	
4	52.5	1058.71	.31	3.18	1058.93	9	395	243	240	53	70	52	
3	55	1061.24	.31	3.20	1061.47	9	393	247	243	51	69	53	
2	57.5	1063.65	.27	2.79	1063.85	8	393	243	240	53	67	51	
1	60	1066.06	.27	2.79	1066.23	8	391	243	242	52	67	52	
	(1142)												
	0-60	V _m - 55.56		2.69 ΔH ₁							AVG.	56.9	

INTERPOL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job CP / HaywardDate 3-9-96 Test 13 Run 2Source LDG 2 Korus STALKNo. of traverse points 24Method 0011 Filter holder: MFilter type: M

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0.0 cfm at 15 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

M☐ acetone☒ Other(s) MELL

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	673	554	119
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1556	1535	21
Total			140

Integrated Gas Sampling Data:

TR7

Bag Pump No. _____

Box No. _____

Bag No. _____

Bag Material: 5-layer Aluminized TedlarSize: 44 L

Pretest leak check: _____

cc/min at _____

IN.HG

Time start: _____

(HRS) Time end: _____

(HRS)

Sampling rate: _____

cc/min Operator: _____

S/N of O₂ Analyzer used to monitor train outlet: _____

052394-CASTACKWPFORM55-0046RR

EPA Method 5 Field Data Sheet

Lab 17/11/2019
Source LEVE & KONUS STACIL
Date 3-11-96 Test 13 Run 2

Operators
Meter Box No.
Gasmeter Coeff.

34 MP
15110
7964

75 in. WC

Nozzle No.
Nozzle Dia.
Bar. Press.

Pilot No. 310-59
C_p .84
H₂O 7

Source (EVE & KANUS STAC)		Date 3-14-96 Test 1 Run 2		Gasmeter Coeff.		Orifice Meter (in. WC)		Velocity Head (in. WC)		Des. Vol. (cf)		VAC. (in. Hg)		Temperatures (°F)					Oxygen (% v/v)	
Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)												Stack	Probe	Oven	Imp.	Gas/In	Gas/Out	
A-12	1000	1064.10												359	230	331	51	47	47	
	25	1068.61												399	231	331	45	49	47	
11	5	1070.67												359	230	327	41	54	46	
10	75	1072.88												397	229	332	42	55	49	
9	10	1075.05												355	232	340	40	58	49	
8	10.5	1077.27												395	235	340	39	60	48	
7	15	1079.26												394	233	330	39	61	47	
6	17.5	1081.50												398	236	330	41	63	47	
5	20	1083.68												399	235	330	40	64	48	
4	22.5	1086.13												396	234	327	42	65	48	
3	25	1088.62												395	235	330	40	65	51	
2	27.5	1090.95												395	236	331	41	65	50	
1	30	1093.58												395	235	334	44	61	48	
B-12	30.5	1095.96												386	245	334	44	65	49	
11	35	1098.20												389	245	340	45	66	50	
10	37.5	1100.50												391	244	346	47	66	50	
9	40	1102.67												390	243	350	47	67	50	
8	40.5	1104.86												391	250	350	49	68	50	
7	45	1106.80												391	247	343	47	68	50	
6	47.5	1108.89												395	245	346	45	69	51	
5	50	1111.20												395	243	341	47	70	52	
4	50.5	1113.45												394	248	340	47	70	52	
3	54	1115.84												394	255	348	49	70	53	
2	57.5	1118.28												391	251	347	45	70	52	
1	60	1120.47																		
	1323																			
	0-100	V _m - 54.27																		

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job CP1 Hayward Date 3-96 Test 13 Run 3
Source LIVE 2 KONUS SPARK No. of traverse points 24
Method 0011 Filter holder: AT Filter type: NA

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: 0.0 cfm at 15 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

1A

☐ acetone
☒ other(s) MELL

No. of probe wash bottles:

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	671	557	114
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1500	1482	18
Total			132

Integrated Gas Sampling Data:

TR7

Bag Pump No. _____
Bag Material: 5-layer Aluminized Tedlar
Pretest leak check: _____
Time start: _____
Sampling rate: _____

Box No. _____ Bag No. _____
Size: 44 L
cc/min at _____ IN.HG
(HRS) Time end: _____ (HRS)
cc/min Operator: _____

S/N of O₂ Analyzer used to monitor train outlet: _____

052394-GASTACKWPAFORMS-00462R

EPA Method 5 Field Data Sheet

Job CP / KAYWARD
Source LEAVE 2 KONGUS STACIK
2 10 9 1 13 2 2
Operators 6A MP
Meter Box No. 15411 @ 5268 in WC
Gas meter Cnoff 1.78
Nozzle No. 61655
Nozzle Dia. .370 in.
Bar. Press. 28.65 in. Hg
Pilot No. 31059
84
18
%
 H_2O
 C_p

[illegible]

INTERPOLL LABORATORIES, INC.
(612) 786-6020
EPA Method 2 Field Data Sheet

Drawing of Test Site

Job LP / Hayward
Source LENG 2 / Korus STALK
Test 14 Run Date 3-15-96
Stack Dimen. 51.5 IN.
Dry Bulb °F Wet bulb °F
Manometer ☐ Reg. ☐ Exp ☐ Elec.
Barometric Pressure 28.67 IN.HG
Static Pressure -1.35 IN.WC
Operators B. Schenker & M. Peterson
Pitot No. 274-68 C_p .84

Cross-section View	Elevation View
-----------------------	-------------------

Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas
Port Length: <u>3.5</u> IN.			Time Start:	HRS	
4-1				.17	
2				.25	
3				.27	
4				.28	
5				.27	
6				.22	
7				.20	421
8				.18	
9				.20	
10				.20	
11				.21	
12				.23	
13-1				.15	
2				.22	
3				.26	
4				.25	
5				.22	
6				.18	394
7				.17	
8		PT/SEC	34.49	.21	
9		ACTM	29938	.21	
10		DCLFM	15720	.23	
11				.23	
12				.24	

Temp. Meas. Device & S/N: PIT 33

Time End: HRS

R or nothing = reg. manometer; S = expanded; E = electronic

032594-G:\STACK\WP\FORMS\S-392.1

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job CP / Hwy work Date 7-5-96 Test 14 Run 1
Source LINE 2 Kenos Shale No. of traverse points 24
Method 5 Filter holder: Glass Filter type: 4" GFF

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) X
Post test: 0.0 cfm at 8 IN. HG (vac) X

Particulate Catch Data:

No. of filters used:

(1) 8368

Recovery solvent(s)

☒ Acetone _____
☐ Other(s) _____

No. of probe wash bottles:

(1)
34

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	583	503	80
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1568	1556	12
Total			92

Integrated Gas Sampling Data:

Bag Pump No. 313 Box No. 8 Bag No. 1
Bag Material: 5-layer Aluminized Tedlar Size: 44 L
Pretest leak check: 0.0 cc/min at 15 IN.HG
Time start: 1800 (HRS) Time end: 1903 (HRS)
Sampling rate: 400 cc/min Operator: BT

S/N of O₂ Analyzer used to monitor train outlet: _____

052394-C:\STACK\WP\FORMS\S-00-6RR

EPA Method 5 Field Data Sheet

Job CP/Key word Operators SA MP Nozzle No. 7-5 Pilot No. 270-65
 Source 12002/Kennos 5 miles Meter Box No. 15 Alt @ 1.25 in. WC Nozzle Dia. .310 in. C_p .84
 Date 3/19/86 Test 1-1 Run 1 Gas meter Coeff. .9964 Bar. Press. 38.69 in. Hg H_2O 10 %

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)					Oxygen (% v/v)	
							Stack	Probe	Oven	Imp.	Gas/In		Gas/Out
B-12	(1806)	175.40					398						
11	2.5	177.27	.28	1.37	177.06	4	386	243				38	40
10	5	178.79	.29	1.37	178.71	4	386	259	246	50		41	38
9	7.5	180.62	.26	1.25	180.27	3	386					43	38
8	10	182.01	.22	1.06	181.72	3	390	243	242	48		48	38
7	12.5	183.27	.20	.96	183.10	3	386					50	42
6	15	184.62	.21	1.02	184.53	3	386	270	256	51		52	42
5	17.5	186.00	.21	1.03	185.98	3	390					54	40
4	20	187.42	.23	1.12	187.45	3	390	271	257	48		56	40
3	22.5	189.02	.28	1.36	189.10	3	390					57	35
2	25	190.67	.30	1.46	190.81	4	388	262	260	52		58	41
1	30	192.35	.27	1.32	192.43	4	389					59	40
A-12	32.5	193.86	.24	1.17	193.96	3.5	390	251	255	50		61	40
11	35	195.36	.22	1.08	195.43	3	388					60	41
10	37.5	196.84	.22	1.08	196.90	3	386	245	246	45		62	42
9	40	198.35	.23	1.13	198.41	3	386					64	43
8	42.5	199.83	.21	1.04	199.86	3	386					64	44
7	45	201.24	.20	.97	201.27	3	399	243	250	43		66	45
6	47.5	202.62	.20	.98	202.68	3	395					66	47
5	50	204.12	.22	1.09	204.16	3	393	250	251	45		67	45
4	52.5	205.70	.24	1.28	205.77	4	397					67	45
3	55	207.41	.29	1.42	207.47	4	396	257	249	47		69	47
2	57.5	209.20	.31	1.52	209.23	5	399					70	46
1	60	210.98	.30	1.48	210.96	5	397	254	265	45		70	47
		212.74	.29	1.43	212.67	5	395					71	48
	(1903)												
	0-60	V _m - 37.34		1.21								Avg. - 50.6	

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP/ Hwy wvd 2 Date 3-15-86 Test 14 Run 2
Source Line 2 Kansas State No. of traverse points 24
Method 5 Filter holder: Class Filter type: 4" GFF

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
Post test: 0-0 cfm at 8 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

(1) 8369

☒ Acetone _____
☐ Other(s) _____

No. of probe wash bottles:

(1)

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	601	500	101
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1510	1500	10
Total			111

Integrated Gas Sampling Data:

Bag Pump No. 313 Box No. 8 Bag No. 2
Bag Material: 5-layer Aluminized Tedlar Size: 44 L
Pretest leak check: 0-0 cc/min at 15 IN.HG
Time start: 1930 (HRS) Time end: 2032 (HRS)
Sampling rate: 400 cc/min Operator: SA

S/N of O₂ Analyzer used to monitor train outlet: _____

EPA Method 5 Field Data Sheet

Job CPI Highway Operators BA MP Nozzle No. 9-5 Pilot No. 27-69
 Source LINE-2 KINGS DAIRY Meter Box No. 15-ΔH@1.75 in.WC Nozzle Dia. .311 in. C_p .81
 Date 3-15-86 Test 14 Run 2 Gasmer Coeff. .5964 Bar. Press. 28.69 in.Hg H_2O 10 %

Date 5-7-56		Test 74 Run 2		Gasometer Conn.		Temperatures (°F)										Oxygen
Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in.WC)	Orifice Meter (in.WC)	Des. Vol. (cf)	VAC. (in.Hg)	Stack	Probe	Oven	Imp.	Gas/In	Gas/Out	(% v/v)			
A-12	(1930)	213.00														
	35	214.62	.24	1.17	214.53	3	393	230	240	47						
	5	216.15	.23	1.13	216.04	3	397				62	52				
	7.5	217.61	.25	1.22	217.62	3	405	222	231	47	67	52				
	10	219.06	.21	1.03	219.07	3	410				71	53				
	12.5	220.42	.20	.98	220.49	3	410	240	231	48	72	54				
	15	221.84	.21	1.03	221.95	3	414				73	56				
	17.5	223.38	.25	1.22	223.53	3.5	415	259	242	47	74	55				
	20	225.11	.29	1.42	225.24	4	415				75	54				
	22.5	226.92	.31	1.57	227.00	5	416	264	253	43	77	57				
B-12	25	228.75	.30	1.47	228.75	5	415				77	58				
	27.5	230.59	.28	1.38	230.44	5	411	260	245	46	77	58				
	30	232.23	.29	1.43	232.16	4	405				77	56				
	32.5	233.82	.26	1.29	233.79	4	405	263	251	43	75	57				
	35	235.36	.25	1.24	235.39	4	407				76	57				
	37.5	236.79	.21	1.03	236.85	3	411	265	261	44	77	57				
	40	238.17	.19	.94	238.25	3	406				77	58				
	42.5	239.52	.18	.89	239.61	3	409	270	260	40	78	58				
	45	240.80	.16	.79	240.89	3	411				78	59				
	47.5	242.15	.18	.84	242.25	3	412	270	270	36	78	59				
	50	243.71	.24	1.18	243.82	4	415				78	60				
	52.5	245.41	.28	1.37	245.50	5	418	276	268	39	79	60				
	55	247.12	.27	1.33	247.17	5	415				80	60				
	57.5	248.71	.25	1.23	248.77	5	416	271	270	41	80	60				
	60	250.45	.28	1.39	250.47	5	467				80	61				
	(2032)															
0-60	V _m - 37.45			ΔH - 1.7							Avg. - 60.1					

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job LP/Daywood Date 3-15-86 Test 14 Run 3
 Source LINE 2 Kenosha Smelter No. of traverse points 24
 Method 5 Filter holder: Class Filter type: 4" GFT

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: 0.0 cfm at 8 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

(1)

Recovery solvent(s)

☒ Acetone _____
☐ Other(s) _____

No. of probe wash bottles:

(4)
SA

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1	593	495	98
Impinger No. 2			
Impinger No. 3			
Condenser			
Desiccant	1577	1568	9
Total			107

Integrated Gas Sampling Data:

Bag Pump No. 313 Box No. 8 Bag No. 3
 Bag Material: 5-layer Aluminized Tedlar Size: 44 L
 Pretest leak check: 0.0 cc/min at 15 IN.HG
 Time start: _____ (HRS) Time end: _____ (HRS)
 Sampling rate: 400 cc/min Operator: SA

S/N of O₂ Analyzer used to monitor train outlet: _____

052394-C:\STACK\WP\FORMS\S-0046RR

INTERPOLL LABORATORIES, INC.

(612) 786-6020

EPA Method 5 Field Data Sheet

Job 1P / New York Operators SA MJS Nozzle No. 9-5 Pilot No. 27-69
 Source 22-2 Kansas State Meter Box No. 13 in WC Des. Vol. (scf) 352.42 C₀ 84
 Date 3-25-96 Test 14 Run 3 Gasmeter Coeff. 9964 Nozzle Dia. 3.1 in. H₂O 11
 Bar. Press. 28.69 in. Hg

Source		Date		3-25-96		Test 14		Run 3		Meter Box No. 23		Bar. Press. 28.67		in. Hg		Oxygen									
Traverse Point No.		Sampling Time (min)		Sample Vol. (cf)		Velocity Head (in. WC)		Orifice Meter (in. WC)		Des. Vol. (cf)		VAC. (in. Hg)		Temperatures (°F)		Gas/Out									
														Slack		Probe		Oven		Imp.		Gas/In			
5-12		2900		250.70		.30		1.14		352.42		3		420		227		231		42		68		64	
11		2.5		252.44		.28		1.33		254.08		3		423								71		63	
10		5		254.05		.28		1.35		255.25		3		415		253		235		45		73		63	
9		7.5		255.70		.22		1.06		257.23		3		415						43		76		63	
8		10		257.17		.20		.97		258.65		3		414		271		255				77		63	
7		12.5		258.61		.18		.87		259.97		3		419		274		241		46		77		63	
6		15		259.91		.22		1.07		261.48		3.5		420						43		78		64	
5		17.5		261.46		.24		1.25		263.10		4		422		275		265				79		65	
4		20		263.07		.28		1.35		264.78		4		418						40		80		64	
3		22.5		264.70		.30		1.45		266.52		4		421		273		270		43		80		65	
2		25		266.48		.25		1.22		268.11		4		415		254		263		43		80		65	
1		27.5		268.18		.23		1.13		271.24		3		412		258		270		39		80		66	
4-12		30		269.77		.22		1.07		272.74		3.5		415						42		81		66	
11		32.5		271.33		.22		1.08		274.24		3		420		264		261		42		81		66	
10		35		272.47		.21		1.02		275.7		3		420						40		81		66	
9		37.5		274.29		.18		.87		277.05		3		420		261		261		38		82		67	
8		40		275.72		.21		1.02		278.52		4		425		270		265		38		83		67	
7		42.5		277.07		.21		1.02		279.58		5		427		263		258		38		83		66	
6		45		278.45		.21		1.02		281.66		5		430		263		258		38		84		68	
5		47.5		279.90		.28		1.35		283.43		4		427											
4		50		281.57		.31		1.49		285.11		5		427											
3		52.5		283.39		.38		1.35		286.86		5		425											
2		55		285.00		.31		1.50		288.65		5		425											
1		57.5		286.78		.31		1.50		288.65		5		425											
1		60		288.61										425											
		(2002)																							
		0-60		V _m - 37.91				ΔH 1.21														AVE. -		71.8	

INTERPOLL LABORATORIES, INC.

(612) 786-6020

18

Field Data Sheet

Job

LP/HAYWARD

Operator(s)

BA MP

Source

LINE 2 KONIX STACK

Meter Box No.

65 Meter Coef. 1.0036

Date

3-19-96 Test 15 Run 1

Barometric Pressure

28.69 IN.HG

Sample Train Leak Check:

Pretest:

0.0cc/min at 15 IN.HG

Post test:

cc/min at IN.HG

Trav. point No.	Sample Time (min)	Sample Volume (cf)	Sample Rate (cc/min)	Vac. (IN.HG)	Temperatures (°F)		
					Stack	Probe	Gasmeter
	<u>100</u>	<u>(482.168)</u>					
	<u>5</u>	<u>482.303</u>	<u>1000</u>	<u>2</u>	<u>388</u>	<u>—</u>	<u>40</u>
	<u>10</u>	<u>482.443</u>	<u>1000</u>	<u>2</u>	<u>386</u>	<u>—</u>	<u>40</u>
	<u>15</u>	<u>482.625</u>	<u>1000</u>	<u>2</u>	<u>388</u>	<u>—</u>	<u>41</u>
	<u>20</u>	<u>482.806</u>	<u>1000</u>	<u>4</u>	<u>386</u>	<u>—</u>	<u>41</u>
	<u>25</u>	<u>482.997</u>	<u>1000</u>	<u>4</u>	<u>390</u>	<u>—</u>	<u>41</u>
	<u>30</u>	<u>483.179</u>	<u>1000</u>	<u>5</u>	<u>388</u>	<u>—</u>	<u>42</u>
	<u>35</u>	<u>483.356</u>	<u>1000</u>	<u>6</u>	<u>390</u>	<u>—</u>	<u>42</u>
	<u>40</u>	<u>483.513</u>	<u>1000</u>	<u>6</u>	<u>388</u>	<u>—</u>	<u>47</u>
	<u>45</u>	<u>483.670</u>	<u>1000</u>	<u>8</u>	<u>397</u>	<u>—</u>	<u>52</u>
	<u>50</u>	<u>483.826</u>	<u>1000</u>	<u>9</u>	<u>393</u>	<u>—</u>	<u>55</u>
	<u>55</u>	<u>484.110</u>	<u>1000</u>	<u>9</u>	<u>397</u>	<u>—</u>	<u>55</u>
	<u>60</u>	<u>484.295</u>	<u>1000</u>	<u>7</u>	<u>397</u>	<u>—</u>	<u>57</u>
	<u>0-60</u>	<u>V_m = 2.127</u>					<u>t_m = 46</u>

V_{STD} = 2.136

121693-G:STACKWPIFORMSS-176

INTERPOLL LABORATORIES, INC.

(612) 786-6020

18 Field Data Sheet

Job LP / HAYWARD
 Source LINE 2 KONUS STACK
 Date 3-96 Test 15 Run 2

Operator(s) PA MP
 Meter Box No. 65 Meter Coef. 1.0036
 Barometric Pressure 28.64 IN.HG

Sample Train Leak Check:

Pretest: 0.0 cc/min at 15 IN.HGPost test: 0.0 cc/min at 15 IN.HG

Trav. point No.	Sample Time (min)	Sample Volume (cc)	Sample Rate (cc/min)	Vac. (IN.HG)	Temperatures (°F)		
					Stack	Probe	Gasmeter
<u>1930</u>	<u>(484.315)</u>	<u>484.315</u>	<u>1000</u>	<u>5</u>	<u>399</u>	<u>—</u>	<u>66</u>
<u>5</u>	<u>10</u>	<u>484.705</u>	<u>1000</u>	<u>5</u>	<u>410</u>	<u>—</u>	<u>66</u>
<u>15</u>	<u>15</u>	<u>484.900</u>	<u>1000</u>	<u>5</u>	<u>412</u>	<u>—</u>	<u>68</u>
<u>20</u>	<u>20</u>	<u>485.095</u>	<u>1000</u>	<u>7</u>	<u>416</u>	<u>—</u>	<u>70</u>
<u>25</u>	<u>25</u>	<u>485.282</u>	<u>1000</u>	<u>7</u>	<u>411</u>	<u>—</u>	<u>70</u>
<u>30</u>	<u>30</u>	<u>485.470</u>	<u>1000</u>	<u>9</u>	<u>409</u>	<u>—</u>	<u>70</u>
<u>35</u>	<u>35</u>	<u>485.650</u>	<u>1000</u>	<u>9</u>	<u>405</u>	<u>—</u>	<u>72</u>
<u>40</u>	<u>40</u>	<u>485.822</u>	<u>1000</u>	<u>9</u>	<u>406</u>	<u>—</u>	<u>72</u>
<u>45</u>	<u>45</u>	<u>486.010</u>	<u>1000</u>	<u>9</u>	<u>411</u>	<u>—</u>	<u>74</u>
<u>50</u>	<u>50</u>	<u>486.203</u>	<u>1000</u>	<u>9</u>	<u>415</u>	<u>—</u>	<u>74</u>
<u>55</u>	<u>55</u>	<u>486.387</u>	<u>1000</u>	<u>10</u>	<u>415</u>	<u>—</u>	<u>78</u>
<u>60</u>	<u>60</u>	<u>486.573</u>	<u>1000</u>	<u>10</u>	<u>416</u>	<u>—</u>	<u>78</u>
<u>0-60</u>	<u>0-60</u>	<u>V_m = 2.253</u>					<u>t_m = 71.5</u>

V_{STD} = 2.155

121693-G:STACKWPFORMSS-476

INTERPOLL LABORATORIES, INC.

(612) 786-6020

18 Field Data Sheet

Job LP / Hayward
 Source Line 2 Konus Stack
 Date 3-19-86 Test 15 Run 1

Operator(s) BA MP
 Meter Box No. 65 Meter Coef. 10036
 Barometric Pressure 28.69 IN.HG

Sample Train Leak Check:

Pretest: 0.0 cc/min at 15 IN.HGPost test: 0.0 cc/min at 15 IN.HG

Trav. point No.	Sample Time (min)	Sample Volume (cf)	Sample Rate (cc/min)	Vac. (IN.HG)	Temperatures (°F)		
					Stack	Probe	Gasmeter
	<u>(2100)</u>	<u>(486.600)</u>					
	<u>5</u>		<u>1000</u>	<u>4</u>	<u>420</u>	<u>—</u>	<u>80</u>
	<u>10</u>		<u>1000</u>	<u>4</u>	<u>415</u>	<u>—</u>	<u>80</u>
	<u>15</u>		<u>1000</u>	<u>5</u>	<u>415</u>	<u>—</u>	<u>80</u>
	<u>20</u>		<u>1000</u>	<u>5</u>	<u>418</u>	<u>—</u>	<u>80</u>
	<u>25</u>	<u>487.605</u>	<u>1000</u>	<u>7</u>	<u>422</u>	<u>—</u>	<u>80</u>
	<u>30</u>	<u>487.810</u>	<u>1000</u>	<u>7</u>	<u>418</u>	<u>—</u>	<u>80</u>
	<u>35</u>	<u>488.023</u>	<u>1000</u>	<u>8</u>	<u>410</u>	<u>—</u>	<u>80</u>
	<u>40</u>		<u>1000</u>	<u>8</u>	<u>409</u>	<u>—</u>	<u>80</u>
	<u>45</u>		<u>1000</u>	<u>8</u>	<u>415</u>	<u>—</u>	<u>80</u>
	<u>50</u>	<u>488.557</u>	<u>1000</u>	<u>8</u>	<u>417</u>	<u>—</u>	<u>80</u>
	<u>55</u>	<u>488.760</u>	<u>1000</u>	<u>9</u>	<u>418</u>	<u>—</u>	<u>80</u>
	<u>60</u>	<u>488.950</u>	<u>1000</u>	<u>9</u>	<u>420</u>	<u>—</u>	<u>80</u>
	<u>0 = 60</u>	<u>V_m = 2.35</u>					<u>t_m = 80</u>


$$V_{std} = 2.211$$

121693-G:STACKIWPFORMSS-476

EPA Method 2 Field Data Sheet

Drawing of Test Site

Job L.P. Hayward
 Source Line 2 Dryer RTD / Inlet
 Test 17 Run 0 Date 3-19-96
 Stack Dimen. 64.75 IN.
 Dry Bulb 145 °F Wet bulb 156 °F
 Manometer ☒ Reg. ☐ Exp ☐ Elec.
 Barometric Pressure 28.78 IN.HG
 Static Pressure -1.50 IN.WC
 Operators E. Jurs & J. Lrenz
 Pitot No. 291-6 C. .870



Traverse Point No.	Fraction of Diameter	Distance From Stack Wall (IN.)	Distance From End of Port (IN.)	Velocity	Temp. of Gas (°F)
		Port Length: <u>8.5"</u> IN.	Time Start: <u>0829</u> HRS		
A 1	.021	1.35	9.86	.91	
2	.067	4.34	12.84	1.20	
3	.118	7.64	16.14	1.32	
4	.177	11.46	19.96	1.30	
5	.240	16.19	24.69	1.10	
6	.316	23.05	31.55	1.20	
7	.444	41.70	50.20	1.35	
8	.750	48.56	57.06	1.50	
9	.823	53.29	61.79	1.50	
10	.882	57.11	65.61	1.40	
11	.933	60.41	68.91	1.55	
12	.979	63.39	71.89	1.40	
D 1				.73	
2				1.25	
3				1.25	
4				1.30	
5				1.30	
6				1.30	
7				1.40	
8				1.50	
9				1.50	
10				1.50	
11				1.50	
12				1.30	
Temp. Meas. Device & S/N: <u>1DT 42 + 47</u>				Time End: <u>0845</u> HRS	

R or nothing = reg. manometer; S = expanded; E = electronic

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 3-19-96 Test 17 Run 1
 Source Dine 2 Drills RTO/Inlet No. of traverse points 24
 Method S Filter holder: MAK Filter type: 3-1/2" 6F

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: 0 cfm at 6 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

1082
☒ Acetone
☐ Other(s)

No. of probe wash bottles:

1
65

Sample recovered by:

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	744	501	243
Impinger No. 3			
Condenser			
Desiccant	1451	1449	2
Total			245

Integrated Gas Sampling Data:

Bag Pump No. 29A Box No. 15 Bag No. 1
 Bag Material: 5-layer Aluminized Tedlar Size: 44 L
 Pretest leak check: 0 cc/min at 22 IN.HG
 Time start: 1030 (HRS) Time end: 1132 (HRS)
 Sampling rate: 400 cc/min Operator: ES

S/N of O₂ Analyzer used to monitor train outlet:29A

052394-G:STACKWPFFORMS5-0046RR

EPA Method 5 Field Data Sheet

Job LP Hayward Operators ES JL Nozzle No. 8-3 Pilot No. 2908
Source Line 2 Rwyer RTO Inlet Meter Box No. 10 A110 194 in WC Nozzle Dia. .189 in. C_p .840
Date 3-19-96 Test 17 Run 1 Gas meter Coeff. 1.0072 Bar. Press. 28.78 in Hg H_2O 20

Traverse Point No.	Sampling Time (min)	Sample Vol. (cf)	Velocity Head (in. WC)	Orifice Meter (in. WC)	Des. Vol. (cf)	VAC. (in. Hg)	Temperatures (°F)				Oxygen (% v/v)		
							Stack	Probe	Oven	Imp.		Gas/In	Gas/Out
	(1030)	(241.40)											
A 12	25	242.92	1.50	1.23	2.88	5	165	231	271		41	40	17.0
11	5	244.39	1.60	1.28	4.39	5	165				41	40	16.7
10	7.5	245.88	1.60	1.28	5.90	5	166	227	272	34	42	40	16.5
9	10	247.35	1.50	1.20	7.35	5	167				47	40	16.3
8	12.5	248.84	1.50	1.21	8.82	5	167	230	269	35	48	40	16.5
7	15	250.29	1.40	1.13	0.24	5	166				50	40	16.4
6	17.5	251.74	1.35	1.09	1.64	5	166	231	266	35	53	40	16.4
5	20	253.06	1.10	.89	2.90	4	165				53	40	16.7
4	22.5	254.46	1.20	.97	4.22	4	168	227	270	36	54	40	16.7
3	24	255.65	1.20	.97	5.54	4.5	167				56	40	16.5
2	27.5	256.98	.92	.75	6.70	4	164	231	271	38	57	41	16.4
1	30	258.14	.67	.82	7.80	3.5	164				57	41	16.3
B 12	32.5	259.66	1.60	1.31	9.34	5.5	164	225	249	39	53	41	16.5
11	35	260.20	1.60	1.30	0.86	5.5	164				58	42	16.3
10	37.5	262.79	1.60	1.30	2.40	5.5	168	232	269	40	59	41	16.7
9	40	264.34	1.55	1.26	3.91	5.5	167				60	41	16.9
8	42.5	265.86	1.50	1.22	5.39	5.5	167	231	268	40	61	42	16.6
7	45	267.39	1.40	1.15	6.83	5.5	166				63	44	16.5
6	47.5	268.88	1.40	1.15	8.28	5	168	232	272	42	63	44	16.6
5	50	270.34	1.35	1.10	9.69	5	171				65	45	16.5
4	52.5	271.80	1.35	1.11	1.11	5	170	234	269	42	65	45	16.1
3	54	273.13	1.30	1.07	2.50	5	169				66	46	16.5
2	57.5	274.66	1.25	1.02	3.87	5	171	231	268	43	66	47	16.7
1	60	275.91	.85	.70	5.00	3.5	170				67	46	16.2
	(1133)												
	0 - 60	$V_m = 34.41$		$\Delta H = 1.09$							AVG. = 48.9		

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job C.P. Hayward
 Source Line 2 Dryer RTO/Inlet
 Method S Filter holder: MACS

Date 3-19-96 Test 17 Run 3
 No. of traverse points 24
 Filter type: 352 * 6F

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒Post test: .012 cfm at 6 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

1031

☒ Acetone _____
☐ other(s) _____

No. of probe wash bottles:

Sample recovered by:

1
ES

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	739	496	243
Impinger No. 3			
Condenser			
Desiccant	1409	1397	12
Total			255

Integrated Gas Sampling Data:

Bag Pump No. 29A
 Bag Material: 5-layer Aluminized Tedlar
 Pretest leak check: 0
 Time start: 1320
 Sampling rate: 400

Box No. 15 Bag No. 2
 Size: 44 L
 cc/min at 22 IN.HG
 (HRS) Time end: 1421 (HRS)
 cc/min Operator: ES

S/N of O₂ Analyzer used to monitor train outlet:29A

052394-G:STACKWPF:FORMS-0046RR

EPA Method 5 Field Data Sheet

 Pilot No. 8-3
 C_p 189
 H₂O 28.76
 % 25

 Nozzle No. 8-3
 Nozzle Dia. 1.89 in.
 Bar. Press. 28.76 in. Hg

 Operators ES JL
 Meter Box No. 10 at 1.94 in WC
 Gas meter Coeff. 60072

 Job CR Hayward
 Source Line 2 Dry RTO Inlet
 Date 3-14-96 Test 17 Run 2

Date		3-14-96		Test		17		Run		1-10-12-13-14-15-16-17-18-19-20-21-22-23-24-25-26-27-28-29-30-31-32-33-34-35-36-37-38-39-40-41-42-43-44-45-46-47-48-49-50-51-52-53-54-55-56-57-58-59-60-61-62-63-64-65-66-67-68-69-70-71-72-73-74-75-76-77-78-79-80-81-82-83-84-85-86-87-88-89-90-91-92-93-94-95-96-97-98-99-100-101-102-103-104-105-106-107-108-109-110-111-112-113-114-115-116-117-118-119-120-121-122-123-124-125-126-127-128-129-130-131-132-133-134-135-136-137-138-139-140-141-142-143-144-145-146-147-148-149-150-151-152-153-154-155-156-157-158-159-160-161-162-163-164-165-166-167-168-169-170-171-172-173-174-175-176-177-178-179-180-181-182-183-184-185-186-187-188-189-190-191-192-193-194-195-196-197-198-199-200-201-202-203-204-205-206-207-208-209-210-211-212-213-214-215-216-217-218-219-220-221-222-223-224-225-226-227-228-229-230-231-232-233-234-235-236-237-238-239-240-241-242-243-244-245-246-247-248-249-250-251-252-253-254-255-256-257-258-259-260-261-262-263-264-265-266-267-268-269-270-271-272-273-274-275-276-277-278-279-280-281-282-283-284-285-286-287-288-289-290-291-292-293-294-295-296-297-298-299-300-301-302-303-304-305-306-307-308-309-310-311-312-313-314-315-316-317-318-319-320-321-322-323-324-325-326-327-328-329-330-331-332-333-334-335-336-337-338-339-340-341-342-343-344-345-346-347-348-349-350-351-352-353-354-355-356-357-358-359-360-361-362-363-364-365-366-367-368-369-370-371-372-373-374-375-376-377-378-379-380-381-382-383-384-385-386-387-388-389-390-391-392-393-394-395-396-397-398-399-400-401-402-403-404-405-406-407-408-409-410-411-412-413-414-415-416-417-418-419-420-421-422-423-424-425-426-427-428-429-430-431-432-433-434-435-436-437-438-439-440-441-442-443-444-445-446-447-448-449-450-451-452-453-454-455-456-457-458-459-460-461-462-463-464-465-466-467-468-469-470-471-472-473-474-475-476-477-478-479-480-481-482-483-484-485-486-487-488-489-490-491-492-493-494-495-496-497-498-499-500-501-502-503-504-505-506-507-508-509-510-511-512-513-514-515-516-517-518-519-520-521-522-523-524-525-526-527-528-529-530-531-532-533-534-535-536-537-538-539-540-541-542-543-544-545-546-547-548-549-550-551-552-553-554-555-556-557-558-559-560-561-562-563-564-565-566-567-568-569-570-571-572-573-574-575-576-577-578-579-580-581-582-583-584-585-586-587-588-589-590-591-592-593-594-595-596-597-598-599-600-601-602-603-604-605-606-607-608-609-610-611-612-613-614-615-616-617-618-619-620-621-622-623-624-625-626-627-628-629-630-631-632-633-634-635-636-637-638-639-640-641-642-643-644-645-646-647-648-649-650-651-652-653-654-655-656-657-658-659-660-661-662-663-664-665-666-667-668-669-670-671-672-673-674-675-676-677-678-679-680-681-682-683-684-685-686-687-688-689-690-691-692-693-694-695-696-697-698-699-700-701-702-703-704-705-706-707-708-709-710-711-712-713-714-715-716-717-718-719-720-721-722-723-724-725-726-727-728-729-730-731-732-733-734-735-736-737-738-739-740-741-742-743-744-745-746-747-748-749-750-751-752-753-754-755-756-757-758-759-760-761-762-763-764-765-766-767-768-769-770-771-772-773-774-775-776-777-778-779-780-781-782-783-784-785-786-787-788-789-790-791-792-793-794-795-796-797-798-799-800-801-802-803-804-805-806-807-808-809-810-811-812-813-814-815-816-817-818-819-820-821-822-823-824-825-826-827-828-829-830-831-832-833-834-835-836-837-838-839-840-841-842-843-844-845-846-847-848-849-850-851-852-853-854-855-856-857-858-859-860-861-862-863-864-865-866-867-868-869-870-871-872-873-874-875-876-877-878-879-880-881-882-883-884-885-886-887-888-889-890-891-892-893-894-895-896-897-898-899-900-901-902-903-904-905-906-907-908-909-910-911-912-913-914-915-916-917-918-919-920-921-922-923-924-925-926-927-928-929-930-931-932-933-934-935-936-937-938-939-940-941-942-943-944-945-946-947-948-949-950-951-952-953-954-955-956-957-958-959-960-961-962-963-964-965-966-967-968-969-970-971-972-973-974-975-976-977-978-979-980-981-982-983-984-985-986-987-988-989-990-991-992-993-994-995-996-997-998-999-1000		Bar. Press.		28.75		in. Hg		Temperatures (°F)		Stack		Probe		Oven		Imp.		Gas/In		Gas/Out		Oxygen (% v/v)	
Traverse Point No.	Sampling Time (min)	Sample Vol. (cc)	Velocity (ft/min)	Orifice Meter (in WC)	Des. Vol. (cc)	VAC. (in. Hg)	Stack	Probe	Oven	Imp.	Gas/In	Gas/Out	Oxygen (% v/v)																				
A-12	1300	276.10	1.65	1.20	7.57	5	171	234	268	35	41	41	170																				
11	25	277.64	1.70	1.22	9.04	5	171				42	40	170																				
10	5	279.19	1.70	1.21	0.50	5	172	231	272	41	48	39	172																				
9	7.5	280.72	1.60	1.14	1.93	5	172				51	38	171.																				
8	10	281.18	1.50	1.08	3.31	5	170	232	271	42	53	37	170																				
7	12.5	283.61	1.45	1.05	4.68	5	168				55	38	170																				
6	15	284.95	1.30	.94	5.98	4.5	169	229	272	44	57	39	166																				
5	17.5	286.30	1.30	.94	7.28	4.5	168				59	40	165																				
4	20	287.63	1.25	.91	8.56	4	171	234	272	44	61	41	164																				
3	22.5	288.96	1.20	.87	9.82	4	170				62	41	164																				
2	25	290.30	.89	.65	0.90	3	170	235	270	44	62	42	16.4																				
1	27.5	291.37	.73	.53	1.89	3	169				59	44	16.3																				
	30	292.36	1.60	1.17	3.34	5	169	229	259	45	63	45	16.5																				
B-12	32.5	293.71	1.60	1.17	4.80	5	169				66	46	16.2																				
11	35	294.17	1.60	1.18	6.26	5	169	231	262	45	66	47	16.3																				
10	37.5	296.68	1.55	1.14	7.71	5	170				67	48	16.3																				
9	40	298.10	1.50	1.11	9.13	5	169	232	268	45	68	48	16.3																				
8	42.5	299.57	1.50	1.11	0.56	5	170				68	49	16.4																				
7	45	300.04	1.45	1.08	1.96	5	169	229	270	46	69	49	16.4																				
6	47.5	302.50	1.40	1.04	3.34	5	169				69	50	16.4																				
5	50	303.88	1.40	1.04	4.73	5	170	230	268	46	70	50	16.3																				
4	52.5	305.30	1.40	1.04	6.11	5	170				71	50	16.3																				
3	55	306.75	1.35	1.01	7.47	5	169	228	269	45	71	50	16.3																				
2	57.5	308.10	.99	.73	8.64	3.5	171				71	51	16.3																				
1	60	309.37																															
	(1421)																																
	0-60	V _m = 33.27		102																													

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Interpoll Laboratories EPA Method 5/17 Sample Log Sheet

Job L.P. Hayward Date 3-19-96 Test 17 Run 3
 Source Line 2 Dryer RTO/Inkt No. of traverse points 24
 Method S Filter holder: MACE Filter type: 3.52" GF

Sample Train Leak Check:

Pretest: ≤ 0.02 cfm at 15 IN.HG (vac) ☒
 Post test: .01 cfm at 6 IN. HG (vac) ☒

Particulate Catch Data:

No. of filters used:

Recovery solvent(s)

1083

☒ acetone
☐ other(s)

No. of probe wash bottles:

Sample recovered by:

1
ES

Condensate Data:

Item	Weight (g)		
	Final	Tare	Difference
Impinger No. 1			
Impinger No. 2	221	496	229
Impinger No. 3			
Condenser			
Desiccant	1439	1429	10
Total			235

Integrated Gas Sampling Data:

Bag Pump No. 29A Box No. 15 Bag No. 3
 Bag Material: 5-layer Aluminized Tedlar Size: 44 L
 Pretest leak check: 0 cc/min at 22 IN.HG
 Time start: 1900 (HRS) Time end: 2032 (HRS)
 Sampling rate: 400 cc/min Operator: ES

S/N of O₂ Analyzer used to monitor train outlet:29A

052394-G:STACK\WPA\FORMS\S-0046RR

EPA Method 5 Field Data Sheet

$$C_p H_2O$$
[illegible]

311.90
~~311.90~~
Leak
Leak
312.10

EPA Method 7 Sampling Collection Field Data Sheet

Job L.P. Hayward Date 3-19-96 Bar Pressure 28.78 IN.HG
Test Location Dryer ATO Inlet Fuel Type Not Gas Sample Train No Green
Technician J. Lorenz Pump No 29A

No.	Test Run Point	Flask No.	Time (HRS)	Vacuum (IN.HG)	Flask Temp. (°F)	Leak Rate <0.4 IN.HG/MIN.	
1	17-1	19	10:30 AM	26.04	40	☒ YES	☐ NO
2		20	10:45	26.07	41	☒ YES	☐ NO
3		21	10:59	26.16	41	☒ YES	☐ NO
4		22	11:16	26.04	42	☒ YES	☐ NO
5	17-2	23	13:25	26.02	40	☒ YES	☐ NO
6		24	13:35	26.06	38	☒ YES	☐ NO
7		31	13:50	26.07	36	☒ YES	☐ NO
8		32	14:05	26.02	36	☒ YES	☐ NO
9	17-3	33	14:36	26.01	34	☒ YES	☐ NO
10		34	14:44	26.04	32	☒ YES	☐ NO
11		35	20:00	26.04	33	☒ YES	☐ NO
12		36	20:12	26.03	31	☒ YES	☐ NO
(L.P. 9) 13	Blank 17-0	49				☐ YES	☐ NO
14						☐ YES	☐ NO
15						☐ YES	☐ NO
16						☐ YES	☐ NO
17						☐ YES	☐ NO
18						☐ YES	☐ NO
19						☐ YES	☐ NO
20						☐ YES	☐ NO
21						☐ YES	☐ NO
22						☐ YES	☐ NO
23						☐ YES	☐ NO
24						☐ YES	☐ NO
25						☐ YES	☐ NO
26						☐ YES	☐ NO
27						☐ YES	☐ NO

VISIBLE EMISSION OBSERVATION FORM 1

Method Used (Circle One)	203A	203B	Other
Method (9)			

Company Name	Louisiana Pacific		
Facility Name			
Street Address			
City	Hayward	State	WI
Zip			

Process	Unit #	Operating Mode
Line 2 KONUS		
Control Equipment		Operating Mode
EEB		

Describe Emission Point	
tallest S-most cylindrical stack	
Height of Emiss. Pt.	Height of Emiss. Pt. Rel. to Observer
Start ~100' End ✓	Start ~100' End ✓
Distance to Emiss. Pt.	Direction to Emiss. Pt. (Degrees)
Start ~320' End ✓	Start 290° End ✓

Vertical Angle to Obs. Pt.	Direction to Obs. Pt. (Degrees)
Start <18° End ✓	Start 290° End ✓
Distance and Direction to Observation Point from Emission Point	
Start NA End ✓	

Describe Emissions	
Start coring	End ✓
Emission Color	Water Droplet Plume
Start gray End ✓	Attached ☐ Detached ☐ None ☒

Describe Plume Background	
Start sky	End ✓
Background Color	Sky Conditions
Start blue/gray End ✓	Start pty cloudy End ✓
Wind Speed	Wind Direction
Start 5-10 mph End ✓	Start S/N End ✓
Ambient Temp.	Wet Bulb Temp.
Start 76° F End ✓	RH Percent

* 10 mph too low to use sling psychrometer

Source Layout Sketch		Draw North Arrow
		☐ TN ☐ MN
Longitude	Latitude	Declination

Additional Information
Occasional Interference from other plumes - Still able to read. Could not read on 3/18/96

VEOF1.1

during PM test due to poor weather/background conditions - snow, overcast

Form Number		Page	Of
Continued on VEO Form Number			

Observation Date	3/19/96	Time Zone	CST	Start Time	0758	End Time	cont'd
Sec	0	15	30	45	Comments		
Min	0	0	0	0			
1	5	5	10	0			
2	0	0	0	0			
3	0	0	0	0			
4	0	0	0	0			
5	0	0	5	5			
6	10	10	5	5			
7	0	0	0	0			
8	0	0	0	0			
9	0	0	0	0			
10	0	0	0	0			
11	0	0	0	0			
12	0	0	0	0			
13	0	0	0	0			
14	0	0	0	0			
15	0	0	0	0			
16	0	0	0	0			
17	0	0	0	0			
18	0	0	0	0			
19	0	0	0	0			
20	0	0	0	0			
21	0	0	0	0			
22	0	0	0	0			
23	0	0	0	0			
24	0	0	0	0			
25	0	0	0	0			
26	0	0	0	0			
27	0	0	0	0			
28	0	0	0	0			
29	0	0	0	0			
30	0	0	0	0			

Observer's Name (Print)	Sheryl Bergeron	
Observer's Signature	Date	3/19/96
Organization	Interpol Laboratories	
Certified By	ETA	Date 8/24/95

VISIBLE EMISSION OBSERVATION FORM 1

Method Used (Circle One)	Method 9	203A	203B	Other
--------------------------	----------	------	------	-------

Company Name	Louisiana Pacific
Facility Name	

Street Address	
----------------	--

City	Hayward	State	WI	Zip
------	---------	-------	----	-----

Process	Line 2 KNOXUS	Unit #		Operating Mode
Control Equipment	EPB			Operating Mode

Describe Emission Point	
-------------------------	--

Height of Emiss. Pt.	Start	End	Same	Height of Emiss. Pt. Rel. to Observer	Start	End	Same
Distance to Emiss. Pt.	Start	End	Same	Direction to Emiss. Pt. (Degrees)	Start	End	Same

Vertical Angle to Obs. Pt.	Start	End	Same	Direction to Obs. Pt. (Degrees)	Start	End	Same
Distance and Direction to Observation Point from Emission Point	Start	End	Same				

Describe Emissions	Start	End	Same
Emission Color	Start	End	Same
Water Droplet Plume	Attached	Detached	None

Describe Plume Background	Start	End	Same
Background Color	Start	End	Same
Wind Speed	Start	End	Same
Wind Direction	Start	End	Same
Ambient Temp.	Start	End	28°F
Wet Bulb Temp.	Start	End	
RH Percent	Start	End	

Source Layout Sketch	Draw North Arrow
	☐ TN ☐ MN ☐ Stack With Plume ☐ Sun ☐ Wind
Longitude	Latitude
Destination	

Additional Information	
------------------------	--

Form Number		Page	Of
Continued on VEO Form Number			

Observation Date	10/19/96	Time Zone	CST	Start Time	cont'd	End Time	0858
Sec	0	15	30	45	Comments		
1	0	0	0	0			
2	0	0	0	0			
3	0	0	0	0			
4	0	0	0	0			
5	0	0	0	0			
6	0	0	0	0			
7	0	0	0	0			
8	0	0	0	0			
9	0	0	0	0			
10	0	0	0	0			
11	0	0	0	0			
12	0	0	0	0			
13	0	0	0	0			
14	0	0	0	0			
15	0	0	0	0			
16	0	0	0	0			
17	0	0	0	0			
18	0	0	0	0			
19	0	0	0	0			
20	0	0	0	0			
21	0	0	0	0			
22	0	0	0	0			
23	0	0	0	0			
24	0	0	0	0			
25	0	0	0	0			
26	0	0	0	0			
27	0	0	0	0			
28	0	0	0	0			
29	0	0	0	0			
30	0	0	0	0			

Observer's Name (Print)	Venil Bergeron	Date	3/19/96
Observer's Signature	Venil Bergeron		
Organization	Interpoll Labs		
Certified By	ETA	Date	10/4/95

VISIBLE EMISSION OBSERVATION FORM 1

Method Used (Circle One)
Method 20A 2038 Other _____Company Name
Louisiana Pacific
Facility Name
Street Address
City Hayward State WI Zip _____Process
Live 2 Dryer RTD Stack Unit # _____ Operating Mode
Control Equipment _____ Operating ModeDescribe Emission Point
S & W most round stack
Height of Emiss. Pt.
Start ~100' End ☒ Height of Emiss. Pt. Rel. to Observer
Start ~100' End ☒
Distance to Emiss. Pt.
Start ~300' End ☒ Direction to Emiss. Pt. (Degrees)
Start 360° End ☒Vertical Angle to Obs. Pt.
Start <19° End ☒ Direction to Obs. Pt. (Degrees)
Start 300° End ☒
Distance and Direction to Observation Point from Emission Point
Start ~60° W of E.P. (~300' down rd) End ☒Describe Emissions
Start looping steam plume End ☒
Emission Color _____ Water Droplet Plume
Start NONE/NA End ☒ Attached ☒ Detached ☐ None ☐Describe Plume Background
Start sky End ☒
Background Color _____ Sky Conditions
Start blue/gray End ☒ Start partly cloudy
Wind Speed/Direction
Start 8-15 mph End ☒ Start E/N End ☒
Ambient Temp. _____ Wet Bulb Temp. _____ RH Percent _____
Start 30°F End ☒ * too cold for sling psychrometerSource Layout Sketch
Draw North Arrow
☐ TN ☐ MN

Observer's Name (Print)
Sheral Bergeron
Observer's Signature
Sheral Bergeron
Date
3/19/96
Organization
Interpoll Labs
Certified By
ETA
Date
10/4/96Additional Information

VEOF1.1

Form Number _____ Page _____ of _____
Continued on VEO Form Number _____

Observation Date	Time Zone	Start Time	End Time		
3/19/96	CST	1030	Cont'd		
Sec Min	0	15	30	45	Comments
1	0	0	0	0	Used lat field position, consider other plumes, direct wind, sun position, & distance needed f/e.
2	0	0	0	0	
3	0	0	0	0	
4	0	0	0	0	
5	0	0	0	0	
6	0	0	0	0	
7	0	0	0	0	
8	0	0	0	0	
9	0	0	0	0	
10	0	0	0	0	
11	0	0	0	0	
12	0	0	0	0	
13	0	0	0	0	
14	0	0	0	0	
15	0	0	0	0	
16	0	0	0	0	
17	0	0	0	0	
18	0	0	0	0	
19	0	0	0	0	
20	0	0	0	0	
21	0	0	0	0	
22	0	0	0	0	
23	0	0	0	0	
24	0	0	0	0	
25	0	0	0	0	
26	0	0	0	0	
27	0	0	0	0	
28	0	0	0	0	
29	0	0	0	0	
30	0	0	0	0	

Observer's Name (Print)
Sheral Bergeron
Observer's Signature
Sheral Bergeron
Date
3/19/96
Organization
Interpoll Labs
Certified By
ETA
Date
10/4/96

VISIBLE EMISSION OBSERVATION FORM 1

Method Used (Circle One) Method 9 203A 203B Other _____

Company Name Louisiana Pacific
 Facility Name _____
 Street Address _____
 City _____ State _____ Zip _____

Process Line 2 Drier BTD Stack Unit # _____ Operating Mode _____
 Control Equipment _____ Operating Mode _____

Describe Emission Point
Same
 Height of Emiss. Pt. Start ~100' End Same Height of Emiss. Pt. Rel. to Observer Start ~100' End Same
 Distance to Emiss. Pt. Start ~300' End Same Direction to Emiss. Pt. (Degrees) Start 335° End Same

Vertical Angle to Obs. Pt. Start 18° End Same Direction to Obs. Pt. (Degrees) Start 300° End Same
 Distance and Direction to Observation Point from Emission Point Start ~35° W + 300' End Same

Describe Emissions
 Start LODDING End Same
 Emission Color Start NA End NA Water Droplet Plume Attached ☒ Detached ☐ None ☐

Describe Plume Background
 Start _____ End Same
 Background Color Start _____ Sky Conditions Start _____ End Same
 Wind Speed Start _____ Wind Direction Start _____ End Same
 Ambient Temp. Start _____ Wet Bulb Temp. Start _____ RH Percent _____
 End 30°F _____

Source Layout Sketch

Draw North Arrow ☐ TN ☐ MN

Observer's Position

Observation Point

100 FEET

300 FEET

1000 FEET

Scale View

Stack With Plume

Sun

Wind

Longitude _____ Latitude _____ Declination _____

Additional Information _____

Form Number _____ Page _____ of _____
 Continued on VEO Form Number _____

Observation Date		Time Zone		Start Time	End Time	
3/19/96		CST		cont'd	1130	
Min	Sec	0	15	30	45	Comments
1		0	0	0	0	
2		0	0	0	0	
3		0	0	0	0	
4		0	0	0	0	
5		0	0	0	0	
6		0	0	0	0	
7		0	0	0	0	
8		0	0	0	0	
9		0	0	0	0	
10		0	0	0	0	
11		0	0	0	0	
12		0	0	0	0	
13		0	0	0	0	
14		0	0	0	0	
15		0	0	0	0	
16		0	0	0	0	
17		0	0	0	0	
18		0	0	0	0	
19		0	0	0	0	
20		0	0	0	0	
21		0	0	0	0	
22		0	0	0	0	
23		0	0	0	0	
24		0	0	0	0	
25		0	0	0	0	
26		0	0	0	0	
27		0	0	0	0	
28		0	0	0	0	
29		0	0	0	0	
30		0	0	0	0	

Observer's Name (Print) Sheri Bergeron
 Observer's Signature Sheri Bergeron Date 3/19/96
 Organization Interpoli Labs
 Certified By ETA Date 10/4/95

VISIBLE EMISSION OBSERVATION FORM 1

Method Used (Circle One)
 Method 9 203A 203B Other _____

Company Name
Louisiana-Pacific
 Facility Name _____
 Street Address _____
 City Hayward State WI Zip _____

Process Line 2 Press RTD Stack Unit # _____ Operating Mode _____
 Control Equipment _____ Operating Mode _____

Describe Emission Point
NE most round stack
 Height of Emiss. Pt. _____ Height of Emiss. Pt. Rel. to Observer _____
 Start _____ End _____ Start _____ End _____
 Distance to Emiss. Pt. _____ Direction to Emiss. Pt. (Degrees) _____
 Start _____ End _____ Start 293° End _____

Vertical Angle to Obs. Pt. _____ Direction to Obs. Pt. (Degrees) _____
 Start < 18° End _____ Start same ↑ End _____
 Distance and Direction to Observation Point from Emission Point _____
 Start NA End _____

Describe Emissions
 Start NONE End _____
 Emission Color _____ Water Droplet Plume _____
 Start NA End _____ Attached ☐ Detached ☐ None ☒

Describe Plume Background
 Start SKY End _____
 Background Color _____ Sky Conditions _____
 Start blue End _____ Start clear End _____
 Wind Speed 20 mph End _____ Wind Direction _____
 Start 20 mph End _____ Start S/NNE End _____
 Ambient Temp. _____ Wet Bulb Temp. _____ RH Percent _____
 Start 180 F End _____ * _____ * _____

* too cold to use sling psychrometer

Source Layout Sketch

Draw North Arrow
☐ TN ☐ MN

Observation Point

max. 12' entrance

Parking Lot

Observer's Position

Sun Location Line

Side View

Stack With Plume

Sun

Wind

Longitude _____ Latitude _____ Declination _____

Additional Information _____

Form Number _____ Page _____ of _____
 Continued on VEO Form Number _____

Observation Date 3/20/96 Time Zone CST Start Time 1014 End Time Cont'd

Sec Min	0	15	30	45	Comments
1	0	0	0	0	
2	0	0	0	0	
3	0	0	0	0	
4	0	0	0	0	
5	0	0	0	0	
6	0	0	0	0	
7	0	0	0	0	
8	0	0	0	0	
9	0	0	0	0	
10	0	0	0	0	
11	0	0	0	0	
12	0	0	0	0	
13	0	0	0	0	
14	0	0	0	0	
15	0	0	0	0	
16	0	0	0	0	
17	0	0	0	0	
18	0	0	0	0	
19	0	0	0	0	
20	0	0	0	0	
21	0	0	0	0	
22	0	0	0	0	
23	0	0	0	0	
24	0	0	0	0	
25	0	0	0	0	
26	0	0	0	0	
27	0	0	0	0	
28	0	0	0	0	
29	0	0	0	0	
30	0	0	0	0	

Observer's Name (Print) Sheryl Bergeron
 Observer's Signature Sheryl Bergeron Date 3/20/96
 Organization Interpoll Labs
 Certified by ETA Date 10/4/95

VEOF1.1

VISIBLE EMISSION OBSERVATION FORM 1

Method Used (Circle One)	203A	203B	Other
--------------------------	------	------	-------

Company Name <u>Louisiana-Pacific</u>		
Facility Name		
Street Address		
City <u>Hayward</u>	State <u>WI</u>	Zip

Process <u>Line 2 Press Vent RTD Stack</u>	Unit #	Operating Mode
Control Equipment		Operating Mode

Describe Emission Point <u>same</u>	
Height of Emiss. Pt. Start End <u>same</u>	Height of Emiss. Pt. Rel. to Observer Start End <u>same</u>
Distance to Emiss. Pt. Start End <u>same</u>	Direction to Emiss. Pt. (Degrees) Start End <u>same</u>

Vertical Angle to Obs. Pt. Start End <u>same</u>	Direction to Obs. Pt. (Degrees) Start End <u>same</u>
Distance and Direction to Observation Point from Emission Point Start End <u>same</u>	

Describe Emissions Start <u>none</u> End <u>none</u>	
Emission Color Start <u>NA</u> End	Water Droplet Plume Attached ☐ Detached ☐ None ☒

Describe Plume Background Start <u>sky</u> End <u>sky</u>	
Background Color Start <u>blue</u> End <u>same</u>	Sky Conditions Start <u>clear</u> End <u>same</u>
Wind Speed Start <u>20-30 mph</u> End <u>same</u>	Wind Direction Start <u>E/NNE</u> End <u>same</u>
Ambient Temp. Start <u>✓</u> End <u>20°F</u>	Wet Bulb Temp. RH Percent

Source Layout Sketch		Draw North Arrow ☐ TN ☐ MN
Longitude	Latitude	Direction

Additional Information	
------------------------	--

Form Number	Page	or
Continued on VEO Form Number		

Observation Date <u>3/20/96</u>		Time Zone	Start Time <u>Continued</u>	End Time <u>1114</u>
Sec Min	0	15	30	45
Comments				
1	0	0	0	0
2	0	0	0	0
3	0	0	0	0
4	0	0	0	0
5	0	0	0	0
6	0	0	0	0
7	0	0	0	0
8	0	0	0	0
9	0	0	0	0
10	0	0	0	0
11	0	0	0	0
12	0	0	0	0
13	0	0	0	0
14	0	0	0	0
15	0	0	0	0
16	0	0	0	0
17	0	0	0	0
18	0	0	0	0
19	0	0	0	0
20	0	0	0	0
21	0	0	0	0
22	0	0	0	0
23	0	0	0	0
24	0	0	0	0
25	0	0	0	0
26	0	0	0	0
27	0	0	0	0
28	0	0	0	0
29	0	0	0	0
30	0	0	0	0

Observer's Name (Print) <u>Sheryl Bergeron</u>		Date <u>3/20/96</u>
Observer's Signature <u>Sheryl Bergeron</u>		Date <u>3/20/96</u>
Organization <u>Interpoll Labs</u>		
Certified By <u>ETA</u>	Date <u>10/4/95</u>	

VISIBLE EMISSIONS EVALUATOR

This is to certify that

Eastern Technical Associates

met the specifications of Federal Reference Method 9 and qualified as a visible emissions evaluator. Maximum deviation on white and black smoke did not exceed 7.5% opacity and no single error exceeding 15% opacity was incurred during the certification test conducted by Eastern Technical Associates of Raleigh, North Carolina. This certificate is valid for six months from date of issue.

Thomas J. Fox
President

William S. Fox
Secretary

David B. Savage, Jr.
Program Manager

250593
Certificate Number

Memorapoint

October 4, 1995
Date of Issue

APPENDIX D

INTERPOLL LABORATORIES ANALYTICAL DATA

TABLE OF CONTENTS

Orsat	1
Carbon Monoxide	10
Particulate	13
Oxides of Nitrogen	25
Methane	27
Benzene	29
Formaldehyde	39
Phenol	40
PAH's	41
Spike Data	42
Sample Deposition Sheets	44



EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job
Team Leader
Date Submitted
Test No.
Date of Analysis

CP / HAYWARD
DVH
1

Source
Test Site
Date of Test
No. of Runs Completed
Technician

Line 2 Diner RTO
5000
3-19-92
3
24

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
1-1	751-12	1	0	4.2	20.0	4.2	15.8	
		2	0	4.2	20.0	4.2	15.8	
		Avg				4.2	15.8	
1-2	13	1	0	4.0	20.1	4.0	16.1	
		2	0	4.0	20.1	4.0	16.1	
		Avg				4.0	16.1	
1-3	14	1	0	4.3	20.1	4.3	15.8	
		2	0	4.3	20.1	4.3	15.8	
		Avg				4.3	15.8	
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						

Ambient Air QA Check
Orsat Analyzer System Leak Check
F₀ Within EPA M-3 Guidelines
for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job LP HAYWARD
 Team Leader ~~3-19-96~~ DVH
 Date Submitted 3/19/96
 Test No. 2
 Date of Analysis 3-20-96

Source LINE 2 DRYER RTO
 Test Site STACK
 Date of Test 3-19-96
 No. of Runs Completed 3
 Technician S. BAIN VELLE

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
2-1	7451	1	0	4.2	20.5	4.2	16.3	1.095
		2	0	4.2	20.5	4.2	16.3	1.095
		Avg				4.2	16.3	
2-2	7451	1	0	4.1	20.6	4.1	16.5	1.073
		2	0	4.1	20.6	4.1	16.5	1.073
		Avg				4.1	16.5	
2-3	7451	1	0	4.3	20.5	4.3	16.2	1.093
		2	0	4.3	20.5	4.3	16.2	1.093
		Avg				4.3	16.2	
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						

- ☐ Ambient Air QA Check
☐ Orsat Analyzer System Leak Check
☐ F₀ Within EPA M-3 Guidelines for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Burane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job
Team Leader
Date Submitted
Test No.
Date of Analysis

LP/HAYWARD
1 DVA
3

Source
Test Site
Date of Test
No. of Runs Completed
Technician

LINE 2 Draper RTO
Stack
3-20
3
ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
3-1	7451-38	1	0	4.3	20.0	4.3	15.7	
		2	0	4.3	20.0	4.3	15.7	
		Avg				4.3	15.7	
3-2	39	1	0	4.3	20.1	4.3	15.8	
		2	0	4.3	20.1	4.3	15.8	
		Avg				4.3	15.8	
3-3	40	1	0	4.2	20.1	4.2	15.9	
		2	0	4.2	20.1	4.2	15.9	
		Avg				4.2	15.9	
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						

☒ Ambient Air QA Check
☒ Orsat Analyzer System Leak Check
☒ F₀ Within EPA M-3 Guidelines for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job
Team Leader
Date Submitted
Test No.
Date of Analysis

LP/HAYWARD
SK
4

Source
Test Site
Date of Test
No. of Runs Completed
Technician

Line 2 Dryer RTD
Stack
3-20-96
3
ET

Test/ Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
4-1	7451-46	1	0	4.0	20.1	4.0	16.1	
		2	0	4.0	20.1	4.0	16.1	
		☒ B ☐ F Avg				4.0	16.1	
4-2	47	1	0	4.1	20.1	4.1	16.0	
		2	0	4.1	20.1	4.1	16.0	
		☒ B ☐ F Avg				4.1	16.0	
4-3	48	1	0	4.2	20.1	4.2	15.9	
		2	0	4.2	20.1	4.2	15.9	
		☒ B ☐ F Avg				4.2	15.9	
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						

Ambient Air QA Check
Orsat Analyzer System Leak Check
F₀ Within EPA M-3 Guidelines
for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job LP/HAYWARD
 Team Leader SE ET
 Date Submitted _____
 Test No. 8
 Date of Analysis _____

Source LINE 2 SURFACE DRYER
 Test Site DUCT
 Date of Test 3-19-20-96
 No. of Runs Completed 3
 Technician ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
8-1	7451-30	1	0	5.5	20.2	5.5	14.7	
		2	0	5.5	20.2	5.5	14.7	
		Avg				5.5	14.7	
8-2	7451-31	1	0	5.1	20.2	5.1	15.1	
		2	0	5.1	20.2	5.1	15.1	
		Avg				5.1	15.1	
8-3	7451-33	1	0	5.0	20.2	5.0	15.2	
		2	0	5.0	20.2	5.0	15.2	
		Avg				5.0	15.2	
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						

- ☐ Ambient Air QA Check
☐ Orsat Analyzer System Leak Check
☐ F₀ Within EPA M-3 Guidelines for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F0 Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job
Team Leader
Date Submitted
Test No.
Date of Analysis

LP/HAYWARD
SF
9

Source
Test Site
Date of Test
No. of Runs Completed
Technician

Green Vent
STP
3-19-96
3
ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F _O
			Zero Pt.	After CO ₂	After O ₂			
9-1	7451-70	1	0	.4	20.6	.4	20.2	
		2	0	.4	20.6	.4	20.2	
		Avg				.4	20.2	
9-2	-71	1	0	.4	20.6	.4	20.2	
		2	0	.4	20.6	.4	20.2	
		Avg				.4	20.2	
9-3	-72	1	0	.4	20.6	.4	20.2	
		2	0	.4	20.6	.4	20.2	
		Avg				.4	20.2	
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						

Ambient Air QA Check
Orsat Analyzer System Leak Check
F_O Within EPA M-3 Guidelines
for fuel type.

EPA Method 3 Guidelines

Fuel Type	F _O Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

Where F_O = $\frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job LP/HAYWARD
 Team Leader SF
 Date Submitted _____
 Test No. 10
 Date of Analysis _____

Source LINE 2 Press Vent R 70
 Test Site Stack
 Date of Test 3-19-96
 No. of Runs Completed 3
 Technician PT

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
10-1	7451-01	1	0	.4	20.6	.4	20.2	
		2	0	.4	20.6	.4	20.2	
		Avg				.4	20.2	
10-2	78	1	0	.4	20.6	.4	20.2	
		2	0	.4	20.6	.4	20.2	
		Avg				.4	20.2	
10-3	79	1	0	.4	20.6	.4	20.2	
		2	0	.4	20.6	.4	20.2	
		Avg				.4	20.2	
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						

Ambient Air QA Check

Orsat Analyzer System Leak Check

F₀ Within EPA M-3 Guidelines
for fuel type.Where $F_0 = \frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job
Team Leader
Date Submitted
Test No.
Date of Analysis

LP/HAYWARD
BA
14

Source
Test Site
Date of Test
No. of Runs Completed
Technician

LINE 2 KANAW 3
STACK
3
ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
14-1	7451	1	0	6.4	20.0	6.4	13.6	
		2	0	6.4	20.0	6.4	13.6	
		☒ B ☐ F Avg				6.4	13.6	
14-2	7451	1	0	7.4	19.9	7.4	12.5	
		2	0	7.4	19.9	7.4	12.5	
		☒ B ☐ F Avg				7.4	12.5	
14-3	7451	1	0	6.3	19.4	8.3	11.6	
		2	0	6.3	19.4	8.3	11.6	
		☒ B ☐ F Avg				8.3	11.6	
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						
		1						
		2						
		☐ B ☐ F Avg						

Ambient Air QA Check
Orsat Analyzer System Leak Check
F₀ Within EPA M-3 Guidelines
for fuel type.

Where $F_0 = \frac{20.9 - O_2}{CO_2}$

F = Flask (250 cc all glass)

B = Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 3 Data Reporting Sheet - Orsat Analysis

Job
Team Leader
Date Submitted
Test No.
Date of Analysis

LP/HAYWARD
ET
17

Source
Test Site
Date of Test
No. of Runs Completed
Technician

Unit 2 Duff RTD
WALLET
3-12-96
5
ET

Test/Run	Sample Log No. and Type	No. of An.	Buret Readings (ml)			Conc. CO ₂ %v/v Dry	Conc. O ₂ %v/v Dry	F ₀
			Zero Pt.	After CO ₂	After O ₂			
17-1	2457-05	1	0	4.2	20.1	4.2	15.9	
		2	0	4.2	20.1	4.2	15.9	
		Avg				4.2	15.9	
17-2	06	1	0	4.0	20.2	4.0	16.2	
		2	0	4.0	20.2	4.0	16.2	
		Avg				4.0	16.2	
17-3	07	1	0	4.2	20.1	4.2	15.9	
		2	0	4.2	20.1	4.2	15.9	
		Avg				4.2	15.9	
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						
		1						
		2						
		Avg						

Ambient Air QA Check
Orsat Analyzer System Leak Check
F₀ Within EPA M-3 Guidelines
for fuel type.

Where F₀ = $\frac{20.9 - O_2}{CO_2}$

F - Flask (250 cc all glass)

B - Tedlar Bag (5 layer)

EPA Method 3 Guidelines

Fuel Type	F ₀ Range
Coal:	
Anthracite/Lignite	1.016-1.130
Bituminous	1.083-1.230
Oil:	
Distillate	1.260-1.413
Residual	1.210-1.370
Gas:	
Natural	1.600-1.836
Propane	1.434-1.586
Butane	1.405-1.553
Wood/Wood Bark	1.000-1.130

EPA Method 10 NDIR Analysis

Job Name
Source
Date of Analysis
Technician

NDIR Analyzer:

Fuji ACS Model 3300
Mon. Lab Model 8310
Dasibi Model 3003
PPM
cc/min

Range: 0 - 500 PPM
Flow rate: 1000 cc/min

Pretest Calibration				
	Concentration	Reading	Vendor	Cyl. No.
Zero Gas	0 PPM	0 PPM		
Upscale Gas	299 PPM	300 PPM		49150230
Upscale Gas	PPM	PPM		
Upscale Gas	PPM	PPM		

[illegible]

Post-Test Calibration			
	Conc.		Reading
Zero Gas	0	PPM	0 PPM
Upscale Gas	299	PPM	300 PPM
Upscale Gas		PPM	PPM
Upscale Gas		PPM	PPM

Note 1: If sample dilution is required, the sample is diluted with CO-free gas prior to analysis.

Note 2: The Fugti ACS model 3300 has a rejection ratio for CO to CO₂ greater than 100,000: 1 and the Mon. Labs Model 8310 and Dasibi Model 3003 have rejection ratios greater than 200,000: 1 and thus CO₂ removal prior to analysis is not required.

Note 3: The analyzer must be zeroed and spanned immediately before and after sample analysis. Additional checks may be performed between sample analyses if required.

111495-G:\STACK\WP\FORMS\S-570

NDIR Analyzer ☒

LP-HAYWARD
LINE 2 SWIFACE DRYER
4-10-74
SUD

Analysis

[illegible]

Post-Test Calibration		Reading	
	Conc.		PPM
Zero Gas	0	0	PPM
Upscale Gas	300	301	PPM
Upscale Gas	600	602	PPM
Upscale Gas			PPM

Upscale Gas	
Upscale Gas	

Note 1: If sample dilution is required, the sample is diluted with CO-free gas prior to analysis.
 Note 2: The Fugate ACS model 3300 has a rejection ratio for CO to CO₂ greater than 100,000: 1 and the Mon. Labs Model 8310 and Dasibi Model 3003 have rejection ratios greater than 200,000: 1 and thus CO₂ removal prior to analysis is not required.
 Note 3: The analyzer must be zeroed and spanned immediately before and after sample analysis. Additional checks may be performed between sample analyses if required.

111495-G:STACKIWPFORMSS-570

EPA Method 10 NDIR Analysis

Job Name
Source
Date of Analysis
Technician

LP/HAYWARD
LINE 2
ET

NDIR Analyzer: ☒

Fuji ACS Model 3300
Mon. Lab Model 8310
Dasibi Model 3003
PPM
cc/min

Concentration		Pretest Calibration		Vendor	Cyl. No.
	PPM	Reading	PPM		
Zero Gas	0	0	0		
Upscale Gas	150	150	150		
Upscale Gas					
Upscale Gas					
					56916503

Sample Description Test/Run	Sample Log No.	CO Conc. (PPM, Dry)		
		Dilution Factor	Reading	Actual PPM
10-1	2451-77			
2	28		22	22
3	29		23	23
			23	23

Post-Test Calibration			
	Conc.		Reading
Zero Gas	0		0
Upscale Gas	150	PPM	150
Upscale Gas		PPM	
Upscale Gas		PPM	
Upscale Gas		PPM	

- Note 1: If sample dilution is required, the sample is diluted with CO-free gas prior to analysis.
- Note 2: The Fuji ACS model 3300 has a rejection ratio for CO to CO₂ greater than 100,000: 1 and the Mon. Labs Model 8310 and Dasibi Model 3003 have rejection ratios greater than 200,000: 1 and thus CO₂ removal prior to analysis is not required.
- Note 3: The analyzer must be zeroed and spanned immediately before and after sample analysis. Additional checks may be performed between sample analyses if required.

INTERPOL LABORATORIES, INC.

(612) 786-6020

Impinger Catch Data Reporting Sheet

Protocol: ☐ Minnesota ☒ Wisconsin ☐ Iowa☐ EPA Method 202 ☐ OtherJob LP / HaywardSource/Site Line 2 Dryer RTO 1 StackDate Submitted 3-21-96Test No. 1Date of Analysis 3-25-96Technician MPR/B.O.

		Solvent Phase		Aqueous Phase	
Test: <u>1</u>	Run: <u>0</u>	Dish No: <u>748</u>		Dish No: <u>105</u>	
Log No: <u>7451-08I</u>		Dish + Sample Wt: <u>45.3864</u>	g	Dish + Sample Wt: <u>38.1286</u>	g
Color & Appearance:		Dish Tare Wt: <u>45.3864</u>	g	Dish Tare Wt: <u>38.1285</u>	g
		Fraction Wt: <u>0.0000</u>	g	Fraction Wt: <u>0.0001</u>	g
Comments:		Smpl Vol: <u>200</u> ml, Alqt: <u>200</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>200</u> ml, Alqt: <u>100</u> ml, Factor: <u>2.000</u>	
		Sample Wt: <u>0.0000</u>	g	Sample Wt: <u>0.0002</u>	g
Test: <u>1</u>	Run: <u>1</u>	Dish No: <u>757</u>		Dish No: <u>161</u>	
Log No: <u>-09I</u>		Dish + Sample Wt: <u>50.8084</u>	g	Dish + Sample Wt: <u>49.1374</u>	g
Color & Appearance:		Dish Tare Wt: <u>50.8069</u>	g	Dish Tare Wt: <u>49.1357</u>	g
		Fraction Wt: <u>0.0015</u>	g	Fraction Wt: <u>0.0017</u>	g
Comments:		Smpl Vol: <u>500</u> ml, Alqt: <u>500</u> ml, Factor <u>1.000</u>		Smpl Vol: <u>500</u> ml, Alqt: <u>100</u> ml, Factor <u>5.000</u>	
		Sample Wt: <u>0.0015</u>	g	Sample Wt: <u>0.0085</u>	g
Test: <u>1</u>	Run: <u>2</u>	Dish No: <u>758</u>		Dish No: <u>200</u>	
Log No: <u>-10I</u>		Dish + Sample Wt: <u>44.9320</u>	g	Dish + Sample Wt: <u>44.9398</u>	g
Color & Appearance:		Dish Tare Wt: <u>44.9288</u>	g	Dish Tare Wt: <u>44.9390</u>	g
		Fraction Wt: <u>0.0032</u>	g	Fraction Wt: <u>0.0008</u>	g
Comments:		Smpl Vol: <u>510</u> ml, Alqt: <u>510</u> ml, Factor <u>1.000</u>		Smpl Vol: <u>510</u> ml, Alqt: <u>100</u> ml, Factor <u>5.100</u>	
		Sample Wt: <u>0.0032</u>	g	Sample Wt: <u>0.0041</u>	g
Test: <u>1</u>	Run: <u>3</u>	Dish No: <u>761</u>		Dish No: <u>208</u>	
Log No: <u>-11I</u>		Dish + Sample Wt: <u>45.0252</u>	g	Dish + Sample Wt: <u>52.7982</u>	g
Color & Appearance:		Dish Tare Wt: <u>45.0217</u>	g	Dish Tare Wt: <u>52.7972</u>	g
		Fraction Wt: <u>0.0035</u>	g	Fraction Wt: <u>0.0010</u>	g
Comments:		Smpl Vol: <u>510</u> ml, Alqt: <u>510</u> ml, Factor <u>1.000</u>		Smpl Vol: <u>510</u> ml, Alqt: <u>100</u> ml, Factor <u>5.100</u>	
		Sample Wt: <u>0.0035</u>	g	Sample Wt: <u>0.0051</u>	g

Note: Factor = Sample Volume/Aliquot Volume

Blank Solvent Wt. 0.0000 g

	RUN <u>0</u>	RUN <u>1</u>	RUN <u>2</u>	RUN <u>3</u>
Results of Solvent Phase g	<u>0.0000</u>	<u>0.0015</u>	<u>0.0032</u>	<u>0.0035</u>
Results of Aqueous Phase D-13g	<u>0.0002</u>	<u>0.0083</u>	<u>0.0039</u>	<u>0.0049</u>

INTERPOLL LABORATORIES, INC.
(612) 786-6020
Solvent Rinse Data Reporting Sheet

☒ EPA Method 5 Probe Wash ☐ EPA Method 29 Probe Wash ☐ EPA Method 202 Cup & Tube Wash

Job: LP/HAYWARD Source/Site: LINE 1 RTODRYER STACK
Date Submitted: _____ Test No.: 1
Date of Analysis: 4-4-96 Technician: SLT
Transport Leakage ☐ None ☒ _____ ml Solvent: _____

Test: <u>1</u>	Run: <u>0</u>	Dish No: <u>859</u>
Log No: <u>7451-08P</u>		Dish + Sample Wt: <u>45.0579</u> g
Volume of Solvent: <u>210</u> ml		Dish Tare Wt: <u>45.0574</u> g
*Solvent Residue: _____ ug/ml		Sample Wt: <u>-0005</u> g
Test: <u>1</u>	Run: <u>1</u>	Dish No: <u>788</u>
Vol. of Solvent: <u>140</u> ml		Dish + Sample Wt: <u>45.4013</u> g
Log Number: <u>-09P</u>		Dish Tare Wt: <u>45.3992</u> g
Comments: _____		Sample Wt: <u>-0021</u> g
Test: <u>1</u>	Run: <u>2</u>	Dish No: <u>18</u>
Vol. of Solvent: <u>120</u> ml		Dish + Sample Wt: <u>80.8345</u> g
Log Number: <u>-10P</u>		Dish Tare Wt: <u>80.8184</u> g
Comments: _____		Sample Wt: <u>.0161</u> g
Test: <u>1</u>	Run: <u>3</u>	Dish No: <u>87</u>
Vol. of Solvent: <u>100 ml</u>		Dish + Sample Wt: <u>73.3607</u> g
Log Number: <u>-11P</u>		Dish Tare Wt: <u>73.3595</u> g
Comments: _____		Sample Wt: <u>.0012</u> g

*Solvent Residue _____ ug/ml = [(Sample Wt. _____ g) (10⁶)]/Vol. of Sol. _____ ml

EPA-M5 Acetone Residue Blank Spec. ≤ 7.8 ug/ml

		RUN <u>0</u>	RUN <u>1</u>	RUN <u>2</u>	RUN <u>3</u>
Results of Solvent Rinse	D-14 g	<u>-0005</u>	<u>.0018</u>	<u>.0158</u>	<u>.0010</u>

INTERPOL LABORATORIES, INC.
(612) 786-6020
Filter Gravimetrics Reporting Sheet

Filter Type: ☒ EPA Method 5 ☐ EPA Method 29 ☐ EPA Method 202 ☐ Other _____

Job: L2/HAYWARD Source/Site: LINE 2 DRY-RO STACK
Date Submitted: _____ Test No.: 1
Date of Analysis: 4-4-86 Technician: SLB

Test: <u>1</u>	Run: <u>0</u>	Filter No: <u>8457</u>
Field Blank:		Filter Type: <u>4" GF</u>
Log No: <u>7451-08F</u>		Filter + Sample Wt: <u>.9471</u> g
Color: <u>WHITE</u>		Filter Tare Wt: <u>.9472</u> g
		Sample Wt: <u>.0000</u> g
Test: <u>1</u>	Run: <u>1</u>	Filter No: <u>8444</u>
Log No: <u>-09F</u>		Filter Type: <u>4" GF</u>
Color: <u>TAN LIGHT</u>		Filter + Sample Wt: <u>.9675</u> g
		Filter Tare Wt: <u>.9648</u> g
		Sample Wt: <u>-.0007</u> <u>.0027</u> g
Test: <u>1</u>	Run: <u>2</u>	Filter No: <u>8419</u>
Log No: <u>-10K</u>		Filter Type: <u>4" GF</u>
Color: <u>LIGHT TAN</u>		Filter + Sample Wt: <u>.9583</u> g
		Filter Tare Wt: <u>.9520</u> g
		Sample Wt: <u>.0063</u> g
Test: <u>1</u>	Run: <u>3</u>	Filter No: <u>8412</u>
Log No: <u>-11F</u>		Filter Type: <u>4" GF</u>
Color: <u>LIGHT TAN</u>		Filter + Sample Wt: <u>0.9690</u> g
		Filter Tare Wt: <u>.9611</u> g
		Sample Wt: <u>.0079</u> g

	RUN <u>0</u>	RUN <u>1</u>	RUN <u>2</u>	RUN <u>3</u>
Results of Filter Analysis g	<u>.0000</u>	<u>-.0007</u> <u>.0027</u> <u>SLB</u>	<u>.0063</u>	<u>.0079</u>

	RUN	RUN	RUN	RUN
Total Mass g		<u>.0143</u>	<u>.0292</u>	<u>.0173</u>

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Impinger Catch Data Reporting Sheet

Protocol: ☐ Minnesota ☒ Wisconsin ☐ Iowa☐ EPA Method 202 ☐ OtherJob LP HaywardSource/Site Line 2 Press Vent Rto 1 StackDate Submitted 3-22-96Test No. 10Date of Analysis 3-27-96Technician D.P.

		Solvent Phase		Aqueous Phase	
Test: <u>10</u>	Run: <u>0</u>	Dish No: <u>4</u>		Dish No: <u>324</u>	
Log No: <u>7451-73E</u>		Dish + Sample Wt: <u>47.3788</u>	g	Dish + Sample Wt: <u>46.2164</u>	g
Color & Appearance:		Dish Tare Wt: <u>47.3788</u>	g	Dish Tare Wt: <u>46.2163</u>	g
		Fraction Wt: <u>0.0000</u>	g	Fraction Wt: <u>0.0001</u>	g
Comments:		Smpl Vol: <u>200</u> ml, Alqt: <u>200</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>200</u> ml, Alqt: <u>100</u> ml, Factor: <u>2.000</u>	
		Sample Wt: <u>0.0000</u>	g	Sample Wt: <u>0.0002</u>	g
Test: <u>10</u>	Run: <u>1</u>	Dish No: <u>5</u>		Dish No: <u>326</u>	
Log No: <u>-74E</u>		Dish + Sample Wt: <u>39.2384</u>	g	Dish + Sample Wt: <u>43.4738</u>	g
Color & Appearance:		Dish Tare Wt: <u>39.2357</u>	g	Dish Tare Wt: <u>43.4733</u>	g
		Fraction Wt: <u>0.0027</u>	g	Fraction Wt: <u>0.0005</u>	g
Comments:		Smpl Vol: <u>200</u> ml, Alqt: <u>200</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>200</u> ml, Alqt: <u>100</u> ml, Factor: <u>2.000</u>	
		Sample Wt: <u>0.0027</u>	g	Sample Wt: <u>0.0010</u>	g
Test: <u>10</u>	Run: <u>2</u>	Dish No: <u>6</u>		Dish No: <u>328</u>	
Log No: <u>-75I</u>		Dish + Sample Wt: <u>48.2724</u>	g	Dish + Sample Wt: <u>41.9676</u>	g
Color & Appearance:		Dish Tare Wt: <u>48.2710</u>	g	Dish Tare Wt: <u>41.9672</u>	g
		Fraction Wt: <u>0.0014</u>	g	Fraction Wt: <u>0.0004</u>	g
Comments:		Smpl Vol: <u>200</u> ml, Alqt: <u>200</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>200</u> ml, Alqt: <u>100</u> ml, Factor: <u>2.000</u>	
		Sample Wt: <u>0.0014</u>	g	Sample Wt: <u>0.0008</u>	g
Test: <u>10</u>	Run: <u>3</u>	Dish No: <u>14</u>		Dish No: <u>340</u>	
Log No: <u>-76I</u>		Dish + Sample Wt: <u>37.7620</u>	g	Dish + Sample Wt: <u>47.9166</u>	g
Color & Appearance:		Dish Tare Wt: <u>37.7613</u>	g	Dish Tare Wt: <u>47.9162</u>	g
		Fraction Wt: <u>0.0007</u>	g	Fraction Wt: <u>0.0004</u>	g
Comments:		Smpl Vol: <u>200</u> ml, Alqt: <u>200</u> ml, Factor: <u>1.000</u>		Smpl Vol: <u>200</u> ml, Alqt: <u>100</u> ml, Factor: <u>2.000</u>	
		Sample Wt: <u>0.0007</u>	g	Sample Wt: <u>0.0008</u>	g

Note: Factor = Sample Volume/Aliquot Volume

Blank Solvent Wt. 0.0000 g

194

	RUN	0	RUN	1	RUN	2	RUN	3
Results of Solvent Phase	g	<u>0.0000</u>	<u>0.0027</u>	<u>0.0014</u>	<u>0.0007</u>			
Results of Aqueous Phase	g	<u>0.0002</u>	<u>0.0008</u>	<u>0.0006</u>	<u>0.0006</u>			

D-16

INTERPOLL LABORATORIES, INC.
(612) 786-6020
Solvent Rinse Data Reporting Sheet

☒ EPA Method 5 Probe Wash ☐ EPA Method 29 Probe Wash ☐ EPA Method 202 Cup & Tube Wash

Job LP / HAYWARD Source/Site LINEX Press Vent (RTO) STACK
 Date Submitted _____ Test No. 10
 Date of Analysis 4-4-96 Technician SLB
 Transport Leakage ☐ None ☒ _____ ml Solvent _____

Test: <u>10</u> Run: <u>0</u>	Dish No: <u>5</u>
Log No: <u>74151-73P</u>	Dish + Sample Wt: <u>37.9447</u> g
Volume of Solvent <u>70</u> ml	Dish Tare Wt: <u>37.9445</u> g
*Solvent Residue _____ ug/ml	Sample Wt: <u>.0002</u> g
Test: <u>10</u> Run: <u>1</u>	Dish No: <u>61</u>
Vol. of Solvent <u>60</u> ml	Dish + Sample Wt: <u>35.9965</u> g
Log Number <u>-74P</u>	Dish Tare Wt: <u>35.9881</u> g
Comments _____	Sample Wt: <u>.0084</u> g
Test: <u>10</u> Run: <u>2</u>	Dish No: <u>63</u>
Vol. of Solvent <u>90</u> ml	Dish + Sample Wt: <u>50.4275</u> g
Log Number <u>-75P</u>	Dish Tare Wt: <u>50.4267</u> g
Comments _____	Sample Wt: <u>.0008</u> g
Test: <u>10</u> Run: <u>3</u>	Dish No: <u>837</u>
Vol. of Solvent <u>90ml</u>	Dish + Sample Wt: <u>35.4936</u> g
Log Number <u>-76P</u>	Dish Tare Wt: <u>35.4909</u> g
Comments _____	Sample Wt: <u>.0027</u> g

*Solvent Residue _____ ug/ml = [(Sample Wt. _____ g) (10⁶)]/Vol. of Sol. _____ ml

EPA-M5 Acetone Residue Blank Spec. ≤ 7.8 ug/ml

194

	RUN <u>0</u>	RUN <u>1</u>	RUN <u>1</u>	RUN <u>3</u>
Results of Solvent Rinse D-17 _g	<u>.0002</u>	<u>.0082</u>	<u>.0005</u>	<u>.0024</u>

INTERPOLL LABORATORIES, INC.
(612) 786-6020
Filter Gravimetrics Reporting Sheet

Filter Type: ☒ EPA Method 5 ☐ EPA Method 29 ☐ EPA Method 202 ☐ Other _____

Job: C. P. Hayward Source/Site: Line 2 Press Vent (RTO) Sta
Date Submitted: _____ Test No.: 10
Date of Analysis: 4-2-96 Technician: ES

Test: 10	Run: 0	Filter No: 8474
Field Blank:		Filter Type: 6F
Log No: 7451-73F		Filter + Sample Wt: .9934 g
Color: white		Filter Tare Wt: .9932 g
		Sample Wt: .0002 g
Test: 10	Run: 1	Filter No: 8330
Log No: 7451-74F		Filter Type: 6F
Color: light yellow		Filter + Sample Wt: .9368 g
		Filter Tare Wt: .9363 g
		Sample Wt: .0005 g
Test: 10	Run: 2	Filter No: 8331
Log No: 7451-75F		Filter Type: 6F
Color: light yellow		Filter + Sample Wt: .9345 g
		Filter Tare Wt: .9342 g
		Sample Wt: .0003 g
Test: 10	Run: 3	Filter No: 8473
Log No: 7451-76F		Filter Type: 6F
Color: light yellow		Filter + Sample Wt: 1.0012 g
		Filter Tare Wt: 1.0009 g
		Sample Wt: .0003 g

	RUN 0	RUN 1	RUN 2	RUN 3
Results of Filter Analysis g	.0002	.0005	.0003	.0003

	RUN	RUN	RUN	RUN
Total Mass g		.0122	.0028	.0040

INTERPOL LABORATORIES, INC.

(612) 786-6020

Impinger Catch Data Reporting Sheet

Protocol: ☐ Minnesota ☒ Wisconsin ☐ Iowa

Job

LP/Hayward

☐ EPA Method 202 ☐ Other

Date Submitted

3-21-96

Source/Site

Line 2 Korus / Stack

Date of Analysis

3-25-96

Test No.

14

Technician

mrl/b.o.

		Solvent Phase		Aqueous Phase	
Test: 14	Run: 0	Dish No: 502		Dish No: 851	
Log No: 7451-22 I		Dish + Sample Wt: 46.9008 g		Dish + Sample Wt: 42.3778 g	
Color & Appearance:		Dish Tare Wt: 46.9008 g		Dish Tare Wt: 42.3777 g	
		Fraction Wt: 0.0000 g		Fraction Wt: 0.0001 g	
Comments:		Smpl Vol: 200 ml, Alqt: 200 ml, Factor: 1.000		Smpl Vol: 200 ml, Alqt: 100 ml, Factor: 2.000	
		Sample Wt: 0.0000 g		Sample Wt: 0.0002 g	
Test: 14	Run: 1	Dish No: 503		Dish No: 852	
Log No: -23 I		Dish + Sample Wt: 48.3159 g		Dish + Sample Wt: 47.4068 g	
Color & Appearance:		Dish Tare Wt: 48.3121 g		Dish Tare Wt: 47.4060 g	
		Fraction Wt: 0.0038 g		Fraction Wt: 0.0008 g	
Comments:		Smpl Vol: 275 ml, Alqt: 275 ml, Factor: 1.000		Smpl Vol: 275 ml, Alqt: 100 ml, Factor: 2.750	
		Sample Wt: 0.0038 g		Sample Wt: 0.0022 g	
Test: 14	Run: 2	Dish No: 509		Dish No: 853	
Log No: -24 I		Dish + Sample Wt: 47.6221 g		Dish + Sample Wt: 47.4036 g	
Color & Appearance:		Dish Tare Wt: 47.6208 g		Dish Tare Wt: 47.3993 g	
		Fraction Wt: 0.0013 g		Fraction Wt: 0.0043 g	
Comments:		Smpl Vol: 300 ml, Alqt: 300 ml, Factor: 1.000		Smpl Vol: 300 ml, Alqt: 100 ml, Factor: 3.000	
		Sample Wt: 0.0013 g		Sample Wt: 0.0043 g	
Test: 14	Run: 3	Dish No: 518		Dish No: 854	
Log No: -25 I		Dish + Sample Wt: 48.1029 g		Dish + Sample Wt: 45.0514 g	
Color & Appearance:		Dish Tare Wt: 48.1024 g		Dish Tare Wt: 45.0507 g	
		Fraction Wt: 0.0005 g		Fraction Wt: 0.0007 g	
Comments:		Smpl Vol: 300 ml, Alqt: 300 ml, Factor: 1.000		Smpl Vol: 300 ml, Alqt: 100 ml, Factor: 3.000	
		Sample Wt: 0.0005 g		Sample Wt: 0.0021 g	

Note: Factor = Sample Volume/Aliquot Volume

Blank Solvent Wt. 0.0000 g

	RUN 0	RUN 1	RUN 2	RUN 3
Results of Solvent Phase g	0.0000	0.0038	0.0013	0.0005
Results of Aqueous Phase D-19g	0.0002	0.0020	0.0127	0.0019

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Solvent Rinse Data Reporting Sheet

☒ EPA Method 5 Probe Wash☐ EPA Method 29 Probe Wash☐ EPA Method 202 Cup & Tube Wash

Job LP HAYWARD Source/Site LIVE 2 KONUS STACK
 Date Submitted Test No. 14
 Date of Analysis 4-4-96 Technician SB

Transport Leakage ☐None ☒

ml

Solvent

Test: <u>14</u>	Run: <u>0</u>	Dish No: <u>769</u>
Log No: <u>7451-22P</u>		Dish + Sample Wt: <u>45.1919</u> g
Volume of Solvent <u>160</u> ml		Dish Tare Wt: <u>45.1912</u> g
*Solvent Residue <u> </u> ug/ml		Sample Wt: <u>.0007</u> g
Test: <u>14</u>	Run: <u>1</u>	Dish No: <u>33</u>
Vol. of Solvent <u>120</u> ml		Dish + Sample Wt: <u>47.9595</u> g
Log Number <u>-23P</u>		Dish Tare Wt: <u>47.9421</u> g
Comments <u> </u>		Sample Wt: <u>.0174</u> g
Test: <u>14</u>	Run: <u>2</u>	Dish No: <u>35</u>
Vol. of Solvent <u>90</u> ml		Dish + Sample Wt: <u>51.1196</u> g
Log Number <u>-24P</u>		Dish Tare Wt: <u>51.0937</u> g
Comments <u> </u>		Sample Wt: <u>.0259</u> g
Test: <u>14</u>	Run: <u>3</u>	Dish No: <u>85B</u>
Vol. of Solvent <u>95ml</u>		Dish + Sample Wt: <u>44.2763</u> g
Log Number <u>-25P</u>		Dish Tare Wt: <u>44.2655</u> g
Comments <u> </u>		Sample Wt: <u>.0108</u> g

*Solvent Residue ug/ml = [(Sample Wt. g) (10⁶)]/Vol. of Sol. ml

EPA-M5 Acetone Residue Blank Spec. ≤ 7.8 ug/ml

Val

	RUN <u>0</u>	RUN <u>1</u>	RUN <u>2</u>	RUN <u>3</u>
Results of Solvent Rinse g	<u>.0007</u>	<u>.0169</u>	<u>.0255</u>	<u>.0104</u>

INTERPOL

Filter Gravi

Filter Type: ☒ EPA Method 5 ☐ EPA M

Job LP/HAYWARD
Date Submitted
Date of Analysis 4-4-96

Test: <u>14</u>
Field Blank:
Log No: <u>7451-22F</u>
Color: <u>WHITE</u>
Test: <u>14</u>
Log No: <u>-23F</u>
Color: <u>TAN</u>
Test: <u>14</u>
Log No: <u>-24F</u>
Color: <u>LIGHT Grey</u>
Test: <u>14</u>
Log No: <u>-25F</u>
Color: <u>Grey</u>

✓
CUL

Results of Filter Analysis g

Total Mass g

INTERPOL LABORATORIES, INC.

(612) 786-6020

Impinger Catch Data Reporting Sheet

rotocol: ☐ Minnesota ☒ Wisconsin ☐ Iowa ☐ EPA Method 202 ☐ Other _____
 Job LP/Hayward Source/Site Line 2 Dryer (RTO / Inlet)
 Date Submitted 3-26-96 Test No. 17
 Date of Analysis 3-25-96 Technician MR. B.D.

		Solvent Phase		Aqueous Phase	
Test: 17	Run: 0	Dish No: 43		Dish No: 700	
Log No: 7451-01I		Dish + Sample Wt: 47.3883 g		Dish + Sample Wt: 43.0549 g	
Color & Appearance:		Dish Tare Wt: 47.3883 g		Dish Tare Wt: 43.0548 g	
		Fraction Wt: 0.0000 g		Fraction Wt: 0.0001 g	
Comments:		Smpl Vol: 200 ml, Alqt: 200 ml, Factor: 1.000		Smpl Vol: 200 ml, Alqt: 100 ml, Factor: 2.000	
		Sample Wt: 0.0000 g		Sample Wt: 0.0002 g	
Test: 17	Run: 1	Dish No: 41		Dish No: 702	
Log No: -02I		Dish + Sample Wt: 45.3384 g		Dish + Sample Wt: 46.2270 g	
Color & Appearance:		Dish Tare Wt: 45.3188 g		Dish Tare Wt: 46.2224 g	
		Fraction Wt: 0.0196 g		Fraction Wt: 0.0046 g	
Comments:		Smpl Vol: 410 ml, Alqt: 410 ml, Factor: 1.000		Smpl Vol: 410 ml, Alqt: 100 ml, Factor: 4.100	
		Sample Wt: 0.0196 g		Sample Wt: 0.0189 g	
Test: 17	Run: 2	Dish No: 32		Dish No: 850	
Log No: -03I		Dish + Sample Wt: 57.8468 g		Dish + Sample Wt: 44.5683 g	
Color & Appearance: light		Dish Tare Wt: 57.8080 g		Dish Tare Wt: 44.5636 g	
yellow tint		Fraction Wt: 0.0388 g		Fraction Wt: 0.0047 g	
Comments:		Smpl Vol: 450 ml, Alqt: 450 ml, Factor: 1.000		Smpl Vol: 450 ml, Alqt: 100 ml, Factor: 4.500	
		Sample Wt: 0.0388 g		Sample Wt: 0.0212 g	
Test: 17	Run: 3	Dish No: 45		Dish No: 867	
Log No: -04I		Dish + Sample Wt: 48.1831 g		Dish + Sample Wt: 45.6129 g	
Color & Appearance: light		Dish Tare Wt: 48.1516 g		Dish Tare Wt: 45.6042 g	
yellow tint, cloudy		Fraction Wt: 0.0315 g		Fraction Wt: 0.0087 g	
Comments:		Smpl Vol: 425 ml, Alqt: 425 ml, Factor: 1.000		Smpl Vol: 425 ml, Alqt: 100 ml, Factor: 4.250	
		Sample Wt: 0.0315 g		Sample Wt: 0.0370 g	

Note: Factor = Sample Volume/Aliquot Volume

Blank Solvent Wt. 0.0000 g

		RUN 0	RUN 1	RUN 2	RUN 3
Results of Solvent Phase	g	0.0000	0.0196	0.0388	0.0315
Results of Aqueous Phase	g	0.0002	0.0187	0.0210	0.0368

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Solvent Rinse Data Reporting Sheet

☒ Method 5 Probe Wash
 ☐ EPA Method 29 Probe Wash
 ☐ EPA Method 202 Cup & Tube Wash

Job LP / HAYWARD Source/Site LINE 2 WATER RTO INLET
 Date Submitted 4-4-96 Test No. 17
 Date of Analysis 4-4-96 Technician SLR

Transport Leakage ☐ None ☒ ml Solvent

Test: <u>17</u>	Run: <u>0</u>	Dish No: <u>29</u>	
Log No: <u>7451-01P</u>		Dish + Sample Wt: <u>48.8895</u>	g
Volume of Solvent <u>150</u> ml		Dish Tare Wt: <u>48.8894</u>	g
*Solvent Residue <u> </u> ug/ml		Sample Wt: <u>.0001</u>	g
Test: <u>17</u>	Run: <u>1</u>	Dish No: <u>764</u>	
Vol. of Solvent <u>180</u> ml		Dish + Sample Wt: <u>46.3962</u>	g
Log Number <u>-02P</u>		Dish Tare Wt: <u>46.3791</u>	g
Comments <u> </u>		Sample Wt: <u>.0171</u>	g
Test: <u>17</u>	Run: <u>2</u>	Dish No: <u>766</u>	
Vol. of Solvent <u>155</u> ml		Dish + Sample Wt: <u>42.2570</u>	g
Log Number <u>-03P</u>		Dish Tare Wt: <u>42.2413</u>	g
Comments <u> </u>		Sample Wt: <u>.0157</u>	g
Test: <u>17</u>	Run: <u>3</u>	Dish No: <u>767</u>	
Vol. of Solvent <u>205 ml</u>		Dish + Sample Wt: <u>42.4526</u>	g
Log Number <u>-04P</u>		Dish Tare Wt: <u>42.4092</u>	g
Comments <u> </u>		Sample Wt: <u>.0434</u>	g

*Solvent Residue ug/ml = [(Sample Wt. g) (10⁶)] / Vol. of Sol. ml

EPA-M5 Acetone Residue Blank Spec. ≤ 7.8 ug/ml

✓SLR

	RUN <u>0</u>	RUN <u>1</u>	RUN <u>2</u>	RUN <u>3</u>
Results of Solvent Rinse D-23 _g	<u>.0001</u>	<u>.0170</u>	<u>.0156</u>	<u>.0433</u>

Page 10

and the results of the investigation of the cause of the accident.

INTERPOL LABORATORIES, INC.
(612) 786-6020
Filter Gravimetrics Reporting Sheet

Filter Type: ☒ EPA Method 5 ☐ EPA Method 29 ☐ EPA Method 202 ☐ Other _____

Job: L.P. Hayward Source/Site: Line 2 Dryer RTO - Inlet
Date Submitted: _____ Test No.: 17
Date of Analysis: 4-2-96 Technician: EJ

Test: 17	Run: 0	Filter No: 1080
Field Blank:		Filter Type: GF
Log No: 7451 - 01 F		Filter + Sample Wt: .5450 g
Color: white		Filter Tare Wt: .5447 g
		Sample Wt: .0003 g
Test: 17	Run: 1	Filter No: 1082
Log No: 7451		Filter Type: GF
Color: Brown		Filter + Sample Wt: .5490 g
		Filter Tare Wt: .5378 g
		Sample Wt: .0112 g
Test: 17	Run: 2	Filter No: 1081
Log No: 7451 - 03 F		Filter Type: GF
Color: Brown		Filter + Sample Wt: .5461 g
		Filter Tare Wt: .5455 g
		Sample Wt: .0006 g
Test: 17	Run: 3	Filter No: 1083
Log No: 7451 - 04 F		Filter Type: GF
Color: Brown		Filter + Sample Wt: .5544 g
		Filter Tare Wt: .5465 g
		Sample Wt: .0085 .0079 ^{SL} g

✓ SL

	RUN 0	RUN 1	RUN 2	RUN 3
Results of Filter Analysis g	.0003	.0112	.0006	^{SL} .0079 .0085

	RUN	RUN	RUN	RUN
Total Mass g		.0665	.0760	.1195

REVIEW

Interpoll Laboratories
(612)786-6020

APR - 3 1996

EPA Method 7A Recovery and Analysis Data Sheet (1)

*****SOURCE*****
Job L.P. Hayward
Source Enviro RTO / Inlet
Date of Sampling 3-19-96
Test No(s) 17

*****RECOVERY*****
Date of Recovery 3-28-96
Recovered by E. J. Jers
Recovery volume 500 ml
Barometric at time 29.33 IN.HG.

*****ANALYSIS*****
Date of Analysis 4/1/96
Analyst TLW
Eluent AS4A
Chromatograph: Dionex System 4000i

Samples collected in accordance with EPA Method 7, CFR Title 40, Part 60, Appendix A. Samples analyzed in accordance with EPA Method 7A by ion chromatography. Mercury manometers used to measure flask pressures/vacuums in sampling and in recovery. Thommen Model TX 19 jewel barometer calibrated against laboratory mercury in glass barometer used to measure field barometric pressure. Three field blanks are prepared and the average used to correct measured nitrate concentrations. All samples are analyzed as a batch using a Dionex Model 4270 Chromatograph Data Integrator. The integrator is programmed to give the actual concentration of the 500 ml recovered sample even if a subsequent dilution was made. The dilution is indicated here as well as on the chromatogram.

$$C_{RS} = DF(C_{DS}) \quad M_{NO_3} = (C_{RS} - \bar{C}_B)V_R \quad \bar{C}_B = (C_{B1} + C_{B2} + C_{B3})/3$$

where:

C_{RS} = concentration of nitrate in 500 ml recovered sample in ug/ml

DF = dilution factor

C_{DS} = concentration of nitrate of a 500 ml recovered sample which has been diluted by a factor of DF to bring it into the proper range for the ion chromatograph. This value is an intermediate number and is not outputted by the electronic integrator which is programmed to output the concentration of the original undiluted 500 ml recovered sample.

M_{NO_3} = total mass of nitrate in micrograms in the 500 ml recovered sample and/or in the 2L flask.

C_B = average conc. of nitrate in 500 ml recovered samples from the three field blanks (ug/ml)

C_{B1}, C_{B2}, C_{B3} = conc. of nitrate in 500 ml recovered samples from the three field blanks (ug/ml)

V_R = recovery volume for samples and field blanks in ml

REVIEWED

APR - 3 1996

Interpoll Laboratories
(612) 786-6020

EPA Method 7A Recovery and Analysis Data Sheet (2)

Darryl M. Holman

Sample Log ID No.	Flask No.	Test/Run	Final Flask Conditions			Chrom Run No.	DF	Nitrate Concentration (ug/ml)		Total Nitrate in Sample (ug) (MNO ₃)
			t _f (°F)	+	-			Uncorr. for blank CRS	Corr. for blank (CRS - Cg)	
1										
2										
3										
4										
5										
6										
7										
8										
9										
10										
11										
12										
13										
14										
15										
16										
17										
18										
19										
20										
21										
22										
23										
24										
25										
26										
27										
Blank 1										
Blank 2										
Blank 3										

CB = 0.049

S-340(2) R-9/85

Blank 1 → 13

Data Reporting Sheet
(With Regulatory Limits)

CLIENT: iD020/LP Hayward

JOB: _____

CLIENT NO: _____

P.O. NO: _____

PROJECT MGR: _____

PHONE: _____

DATE: _____

CONTACT: _____

LABORATORY REPORT #: _____

SAMPLES COLLECTED: _____

SAMPLES RECEIVED: _____

SAMPLE I.D:

1/1	1/2	1/3	
1.6.S. →			
7451-12	-13	-14	

Invoicing Signature Report Routing

PL
Lab Mgr
InO Mgr
Org Mgr

SAMPLE TYPE:

LOG NO:

PARAMETER	UNITS	DET. LIMIT	REG. LIMIT	ANALYSIS DATE & INITIALS	METHOD				
Methane	ppmV	1.0	-	3/26/96 bwn	M25	3.8	2.0	2.9	

Footnotes:

In-House Comments:

Interpoll Laboratories
(612) 786-6020

Due Date: 4/3/96

Data Reporting Sheet
(With Regulatory Limits)

CLIENT: 1D020 / LP Hayward

JOB: _____

CLIENT NO: _____

P.O. NO: _____

PROJECT MGR: _____

PHONE: _____

DATE: _____

CONTACT: _____

LABORATORY REPORT #: _____

SAMPLES COLLECTED: _____

SAMPLES RECEIVED: _____

SAMPLE I.D:

10/1	10/2	10/3	
1.G.S.	→		
7451-77	-78	-79	

Invoicing Signature Report Routing

PL
Lab Mgr
InO Mgr
Org Mgr

SAMPLE TYPE:

LOG NO:

PARAMETER	UNITS	DET. LIMIT	REG. LIMIT	ANALYSIS DATE & INITIALS	METHOD				
Methane	ppmv	1.0	-	3/26/96 Ann	M-25	BDL	BDL	BDL	

Footnotes:

In-House Comments:

Air Samples (Charcoal Tubes) by NIOSH Method 1501 Data Reporting Sheet

Client: 10020/LP Hayward

Sample Collected: _____

Sample Received: _____

Sample Log #: 7451-51

Sample Description: Char. Tube 5/i

Parameter	Units	Analysis Date & Initials	FRONT			BACK		
			Detection Limit Front	Analytical Result Front	Method Blank Front	Detection Limit Back	Analytical Result Back	Method Blank Back
Benzene	Total ug	<i>[Signature]</i>	2.1	<2.1	<2.1	0.61	<0.61	<0.61
	Total ug	3-8-96						
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
Dilution factor								

REVIEWED
1996
[Signature]

Footnotes: _____

In-House Comments: _____

Interpoll Laboratories, Inc.
(612)786-6020

Air Samples (Charcoal Tubes) by NIOSH Method 1501 Data Reporting Sheet

Client: 10020/LP Hayward

Sample Collected: _____

Sample Received: _____

Sample Log #: 7451-53

Sample Description: Char. Tube 5/2

Parameter	Units	Analysis Date & Initials	FRONT			BACK		
			Detection Limit Front	Analytical Result Front	Method Blank Front	Detection Limit Back	Analytical Result Back	Method Blank Back
Benzene	Total ug	5/1/96	2.1	3.7	42.1	0.61	<0.61	<0.61
	Total ug	32996						
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
Dilution factor								

Footnotes: _____

In-House Comments: _____

LCI-136

Dec 4/3/96

Interpoll Laboratories, Inc.
(612)786-6020

Air Samples (Charcoal Tubes) by NIOSH Method 1501 Data Reporting Sheet

Client: 10020/LP Hayward

Sample Collected: _____

Sample Received: _____

Sample Log #: 7451-54

Sample Description: Char. Tube 5/3

Parameter	Units	Analysis Date & Initials	FRONT			BACK		
			Detection Limit Front	Analytical Result Front	Method Blank Front	Detection Limit Back	Analytical Result Back	Method Blank Back
Benzene	Total ug	MMN	2.1	17	42.1	0.61	1.2	<0.61
	Total ug	3.2796						
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
Dilution factor								

REVIEWED
APR 1 1996
[Signature]

Footnotes: _____

In-House Comments: _____

Air Samples (Charcoal Tubes) by NIOSH Method 1501 Data Reporting Sheet

Client: 10020 / LP Hayward

Sample Collected: _____

Sample Received: _____

Sample Log #: 7451-55

Sample Description: Char. Tube 5/3

[illegible]

Footnotes: _____

In-House Comments: _____

Interpoll Laboratories, Inc.
(612)786-6020

Client: 1D020 / LP Hayward

Sample Collected: 319

Sample Received: 3-21

Sample Log #: 7451-19

Sample Description: 15/1

Parameter	Units	Analysis Date & Initials	FRONT			BACK		
			Detection Limit Front	Analytical Result Front	Method Blank Front	Detection Limit Back	Analytical Result Back	Method Blank Back
Benzene	Total ug	JMN.	2.1	<2.1	<2.1	0.61	<0.61	<0.61
	Total ug	39716						
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
	Total ug							
Dilution factor								

Footnotes: _____

In-House Comments: _____

LCI-136

Client: 1D020 / LP Hayward

Sample Received: _____

Sample Log #: 7451 -20

Sample Description: 15/2

REF	Total ug	
	Total ug	
	Total ug	
	Total ug	1996
	Total ug	
	Total ug	
	Total ug	

In-House Comments: _____

INTERPOLL LABORATORIES INC.

Formaldehyde Results Using EPA Method 0011

For Dept. 20/LP Hayward

Collected 3/18, 19, 21/96

	Field Spike #3			Test: 4		Source: Line 2 Dryer RTO Stack	
	Actual	Found	% Recovery	Run 0	Run 1	Run 2	Run 3
Log #		(7451-42)		(7451-41)	(7451-43)	(7451-44)	(7451-45)
Mass (ug)*	750	580	77.3	8.0	13000	18000	17000

	Field Spike #1			Test: 9		Source: Line 2 Press Vent RTO Stack	
	Actual	Found	% Recovery	Run 0	Run 1	Run 2	Run 3
Log #		(7451-66)		(7451-65)	(7451-67)	(7451-68)	(7451-69)
Mass (ug)*	750	620	82.7	2.6	600	490	610

	Field Spike #2			Test: 13		Source: Line 2 Thermal Oil Heater Stack	
	Actual	Found	% Recovery	Run 0	Run 1	Run 2	Run 3
Log #		(7451-81)		(7451-80)	(7451-82)	(7451-83)	(7451-84)
Mass (ug)*	750	230	30.7**	6.7	210	280	190

* = Total Mass of formaldehyde in the sample in ug.

** = A portion of sample 7451-81 was lost during preparation at the laboratory.

Reviewed by:



David J. Schneider, Manager
Chemistry Department

INTERPOLL LABORATORIES INC.

Phenol Result By EPA Method 8270
For Dept. 20/ LP Hayward
Collected 3/19/96

	Test 2				Source: Line 2 Dryer RTO Stack
	Run 0	Run 1	Run 2	Run 3	
Log #	7451-15	7451-16	7451-17	7451-18	
Analysis Date	4/05/96	4/05/96	4/05/96	4/05/96	
Phenol*	< 840	< 840	< 840	< 840	
2-Fluorophenol**	84.3	8.6	18.0	25.8	
D6-Phenol**	66.9	36.8	38.2	32.6	
2,4,6-Tribromophenol***	51.2	57.9	58.4	66.7	

* = Total mass of the specified compound in the sample in ug.

** = Percent recovery of the field surrogate. (60120 ug 2-Fluorophenol and
5006 ug Phenol-D6 was added to the impinger solution before sampling.)

*** = Percent recovery of the lab surrogates.

Reviewed by:



David J. Schneider, Manager
Chemistry Department

INTERPOLL LABORATORIES INC.

Polycyclic Organic Matter Results By EPA Method 8270
For Dept. 20/LP Hayward, Collected 3/20-21/96

	Test : 3				Source: Line 2 Dryer RTO Stack			
	Run 0	Run 1	Run 2	Run 3	Run 0	Run 1	Run 2	Run 3
Log #	7451-34	7451-35	7451-36	7451-36				
Compounds of Interest								
Benz(a)anthracene*	< 1.8	< 1.8	< 1.8	< 1.8				
Benzo(b)fluoranthene*	< 0.99	< 0.99	< 0.99	< 0.99				
Benzo(a)pyrene*	< 1.2	< 1.2	< 1.2	< 1.2				
Dibenz(a,h)acridine*	< 15	< 15	< 15	< 15				
Dibenz(a,j)acridine*	< 1.6	< 1.6	< 1.6	< 1.6				
Dibenz(a,h)anthracene*	< 0.88	< 0.88	< 0.88	< 0.88				
7H-Dibenzo(c,g)carbazole*	< 1.2	< 1.2	< 1.2	< 1.2				
Dibenzo(a,h)pyrene*	< 20	< 20	< 20	< 20				
Dibenzo(a,i)pyrene*	< 20	< 20	< 20	< 20				
Indeno(1,2,3-cd)pyrene*	< 0.90	< 0.90	< 0.90	< 0.90				
Field Surrogate Recovery								
D10-Fluoranthene**	51.2	61.3	67.5	65.9				
Lab Surrogate Recovery								
D5-Nitrobenzene***	42.5	108	105	113				
2-Fluorobiphenyl***	75.7	43.2	55.1	47.5				
D14-Terphenyl***	63.2	71.5	63.7	60.4				

* = Total mass of the specified compound in the sample in ug.

** = Percent recovery of the field surrogate.

*** = Percent recovery of the lab surrogates.

Reviewed by:



David J. Schneider, Manager
Chemistry Department

Interpoll Laboratories
(612) 786-6020

XAD-2 & VOST Trap Preparation Work
Order Form

Project Name: L2/Hayward Order Date: 3-11-96
Date Required: 3-15-96 Delivery Date: 3-15-96

Number of XAD-2 Traps Required: 4

Number of VOST Tubes Required: _____ Tenax
_____ Tenax/Charcoal

XAD-2 TRAP HISTORY

XAD-2 Lot Number: 17212-6 Date of Spiking: 3-15-96
XAD-2 Lot Date: NA Technician: BO
XAD-2 Lot Technician: Alltech

Nature of Spiking Material	Spike Concentration	Spike Volume	Total Mass of Spike
Dio-Fluorathene #95078-9-1	4.0 µg/µl	5.0 µl	20.0 µg

VOST TUBE HISTORY

Date of Thermal Desorption: _____ Technician: _____

Total Hydrocarbon Analysis: _____ ppm

SPECIAL REQUIREMENTS

**Please return this form with the samples.

Interpoll Laboratories
(612) 786-6020

IMPINGER CATCHES

Project Name: LP/Hayward

Order Date: 3-11-96

Date Required: 3-15-96

Delivery Date: 3-15-96

Nature of Spiking Material	Spike Concentration	Spike Volume	Total Mass of Spike
D-6 Phenol #95078-26-A	5.006 mg/ml	1.0 ml	5.006 mg
2-fluorophenol #95078-26-B	50.10 mg/ml	1.2 ml	60.120 mg

SPECIAL REQUIREMENTS

**Please return this form with the samples.

INTERPOIL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job: L.P. Hayward Source: Line 2 Bayar Site: ATO STACK Log No. 7451
 Field Engineer: DH Date of Test: 3/19/96 Test No. 1 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
4	Probe Wash: ☒ Acetone ☐ MeCl ₂	☒ EPA M-5 ☐ EPA M-29		
4	Filter: ☒ 4" Glass ☐ 2.5" Glass	☒ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
4	Impingers: ☒ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ IMN Protocol ☒ IAWI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases		
3	Integrated Gas: ☒ Tedlar Bag	☒ EPA M-3 ☐ METHANE		
	Oxides of Nitrogen:	☐ EPA M-7A		
	Fuel Lab: ☐ Fuel Sample	☐ Per S-0163		
	Particle Sizing:	☐ X-Ray Sdgraph ☐ Cascade Imp		
	Miscellaneous:	☐		

Fuel Type: Coal: ☐ Bituminous ☐ Wood Waste: ☐ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☐ Natural Gas ☐ RDF ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>Diane Van Hower</u>	<u>Carl Interpoll</u>	<u>3/19/96</u>
		<u>3/21/96</u>

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job Field Engineer L.P. Hayward Source Line 2 Dryer Site Rto Stack Log No. 7451
 Date of Test 3/19/96 Test No. 1 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
	Probe Wash: ☐ Acetone ☐ MeCl ₂	☐ DI Water ☐ _____	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A	
	Filter: ☐ 4" Glass ☐ 55 Thimble	☐ Pallflex ☐ 2.5" Glass	☐ EPA M-5 ☐ EPA M-17	
4	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☐ KMnO ₄ /H ₂ SO ₄ ☒ PHENOL #35080N SOLUTION	☐ MN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases ☐ IA Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☐ _____ ☐ EPA M-10	<u>4 & B Spiked bottles</u>
	Integrated Gas: ☐ Tedlar Bag	☐ _____	☐ EPA M-3 ☐ EPA M-7A ☐ _____ ☐ Per S-0163	
	Oxides of Nitrogen:			
	Fuel Lab: ☐ Fuel Sample	☐ Aggregate		
	Particle Sizing:		☐ X-Ray Sdgraph ☐ Cascade Imp	
	Miscellaneous:	☐ _____		

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
 Wood: ☐ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☐ Natural Gas ☐ RDF ☐ _____

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>[Signature]</u>	<u>Carl Interpoll</u>	<u>3/22/96</u>
		<u>3/21/96 0800</u>

INTERPOL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job L.P. Hayward Source Line 2 Dryer ETO Site Stack Log No. 7451
 Field Engineer DJA Date of Test 3/20, 21/96 Test No. 3 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
4 SOLVENT RINSER	Probe Wash: ☒ Acetone ☒ MeCl ₂ Filter: ☒ 4" Glass ☐ SS Thimble	☐ DI Water ☐ Pallflex ☐ 2.5" Glass	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-17 ☐ EPA M-201A	☐ EPA M-201A ☒ 0010 PAHs
3 CONDENSATE TRAP	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☐ KMnO ₄ /H ₂ SO ₄ ☒ Water Catch	☐ MN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases	☐ IA Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☒ 0010
3	Integrated Gas: ☒ Tedlar Bag	☐ _____	☒ EPA M-3 ☐ _____	☐ EPA M-10
	Oxides of Nitrogen:		☐ EPA M-7A ☐ _____	
	Fuel Lab: ☐ Fuel Sample	☐ Aggregate	☐ Per S-0163	
	Particle Sizing:		☐ X-Ray Sdgraph ☐ _____	☐ Cascade Imp
21	Miscellaneous:	☒ Resin Cartridge	☒ 0010	

Fuel Types: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
 Wood: ☐ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☐ Natural Gas ☐ RDF ☐ _____

Refiniquished by/Affiliation	Accepted by/Affiliation	Date
<u>Diane Van Hower</u>	<u>Curl / Interpol</u>	<u>3/22/96</u>
		<u>3/22/96</u>
		<u>1000</u>

{612} 786-6020

Sample Chain of Custody

Job	Source	Line 2 Dryer bro Site	Stack	Log No.
Field Engineer	Date of Test	3/21/96	Test No. 4	No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
3	Probe Wash: ☐ Acetone ☒ DI Water ☒ MeCl ₂	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A ☒ <i>1001</i>		
	Filter: ☐ 4" Glass ☐ 55 Thimble	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A ☐ EPA M-17		
5	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☒ 2,4-DNPH ☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☐ KMnO ₄ /H ₂ SO ₄ ☐ _____	☐ IMN Protocol ☐ IWI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases ☐ IIA Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☒ <i>1001</i>		<i>3 Runs</i> <i>1 blank</i> <i>1 spike</i>
3	Integrated Gas: ☒ Cellar Bag ☐ _____ Oxides of Nitrogen:	☒ EPA M-3 ☐ _____ ☐ EPA M-7A ☐ _____ ☐ Per S-0163		
	Fuel Lab: ☐ Fuel Sample ☐ Aggregate			
	Particle Sizing:	☐ X-Ray Scdgraph ☐ _____ ☐ Cascade Imp		
	Miscellaneous: ☐ _____			

Fuel Type:	Coal:	Bituminous	Wood:	Wood Waste	Oil:	Misc:	Natural Gas
		☐ Bituminous		☐ Wood Waste			☐ Natural Gas
		☐ Anthracite		☐ Dust	☐ No. 2	☐ RDF	☐ RDF
		☐ Lignite		☐ Bark	☐ No. 6		☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
		1000 3/22/96

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Sample Chain of Custody

Job Field Engineer L.P. Hayward Source Line 2 DRYER Date of Test 3/21/96 Site R70 Stack Test No. 5 Log No. 7451 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
	Probe Wash: ☐ Acetone ☐ MeCl ₂	☐ DI Water ☐ _____	☐ EPA M-5 ☐ EPA M-29	☐ EPA M-201A ☐ _____
	Filler: ☐ 4" Glass ☐ SS Thimble	☐ Pallflex ☐ 2.5" Glass	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A	☐ EPA M-17
	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☐ KMnO ₄ /H ₂ SO ₄ ☐ _____	☐ MN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases	☐ IA Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☐ _____
	Integrated Gas: ☐ Tedlar Bag	☐ _____	☐ EPA M-3 ☐ _____	☐ EPA M-10
	Oxides of Nitrogen:		☐ EPA M-7A ☐ _____	
	Fuel Lab: ☐ Fuel Sample	☐ Aggregate	☐ Per S-0163	
	Particle Sizing:		☐ X-Ray Sdgraph ☐ _____	☐ Cascade Imp
4	Miscellaneous:	<u>Benzene</u>	<u>Charcoal Tubes</u>	

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
 Wood: ☐ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☐ Natural Gas ☐ RDF ☐ _____

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>Joanne Van Haver</u>	<u>OLL / Interpoll</u>	<u>3/21/96</u>
		<u>3/21/96 1000</u>

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Sample Chain of Custody

Job LP/HARVARD Source Surface Drilled Site 7451
Field Engineer PT Date of Test 3-19-96 Test No. 8 Log No. 4
No. of Runs

No. Items	Sample Type	Analysis	Sequence No.	Comments
	Probe Wash: ☐ Acetone ☐ MeCl ₃	☐ DI Water ☐ _____	☐ EPA M-5 ☐ EPA M-29	☐ EPA M-201A ☐ _____
	Filter: ☐ 4" Glass ☐ SS Thimble	☐ Pallflex ☐ 2.5" Glass	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A	☐ EPA M-17 _____ _____ _____
	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☐ KMnO ₄ /H ₂ SO ₄ ☐ _____	☐ MN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases	☐ IA Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☐ _____ _____ _____
1	Integrated Gas: ☒ Tedlar Bag	☐ _____	☐ EPA M-3 ☒ METHANE ☐ EPA M-7A ☐ _____	☒ EPA M-10 (30-33) _____ _____ _____
	Oxides of Nitrogen:			_____ _____ _____
	Fuel Lab: ☐ Fuel Sample	☐ Aggregate	☐ Per S-0163	_____ _____ _____
	Particle Sizing:		☐ X-Ray Sdgraph ☐ _____	☐ Cascade Imp _____ _____ _____
	Miscellaneous:	☐ _____	☐ _____	_____ _____ _____

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
Wood: ☐ Wood Waste ☐ Dust ☐ Bark
Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
Misc: ☐ Natural Gas ☐ RDF ☐ _____

Relinquished by/Affiliation <u>E. Tawley / Interpoll</u>	Accepted by/Affiliation <u>Paul Interpoll</u>	Date <u>1315 3/21/96</u>

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job Field Engineer Scott Fitzgerald Source Lee 2 Pies (est. Site) Log No. 7451
 Date of Test 3-17-96 (date) Test No. 9 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
4	Probe Wash: ☐ Acetone ☒ MeCl ₂	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-17 ☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		1 cells Blank
	Filter: ☐ 4" Glass ☐ SS Thimble	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
5	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☒ 2,4-DNPH	☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☐ KMnO ₄ /H ₂ SO ₄ ☐ Acid Gases		3 samples 1 Blank 1 Spike
3	Integrated Gas: ☒ Tedlar Bag	☒ EPA M-3 ☐ EPA M-10		
	Oxides of Nitrogen:	☐ EPA M-7A ☐		
	Fuel Lab: ☐ Fuel Sample	☐ Per S-0163		
	Particle Sizing:	☐ X-Ray Sdgraph ☐ Cascade Imp		
	Miscellaneous:	☐		

Fuel Type: Coal: ☐ Bituminous
☐ Anthracite
☐ Lignite
 Wood: ☒ Wood Waste
☐ Dust
☐ Bark
 Oil: ☐ Waste Oil
☐ No. 2
☐ No. 6
 Misc: ☐ Natural Gas
☐ RDF
☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>Scott Fitzgerald</u>	<u>OK Interpoll</u>	<u>3-22-96</u>

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job LP/Hayward Source Line 2 Paved Unit (K10) Site 5 truck Log No. 7451
 Field Engineer S. Ziegler Date of Test 3-20-96 Test No. 10 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
4	Probe Wash: ☒ DI Water ☐ Acetone ☐ MeCl ₂	☒ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
4	Filter: ☒ 4" Glass ☐ SS Thimble	☒ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
4	Impingers: ☒ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ MN Protocol ☒ IAWI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases		
3	Integrated Gas: ☒ Tedlar Bag	☒ EPA M-3 ☒ METHANE		
	Oxides of Nitrogen:	☐ EPA M-7A ☐		
	Fuel Lab: ☐ Fuel Sample	☐ Per S-0163		
	Particle Sizing:	☐ X-Ray Scdgraph ☐ Cascade Imp		
	Miscellaneous:	☐		

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
 Wood: ☒ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☐ Natural Gas ☐ RDF ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>S. Ziegler Interpoll Labs</u>	<u>Carl Interpoll</u>	<u>3-22-96</u>

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job Field Engineer BA Source LAKE 2 KONUS Date of Test 3-18-96 Site STACIC Log No. 7415 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
5	Probe Wash: ☐ Acetone ☒ MeCl ₃	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-17 ☐ EPA M-29 ☐ EPA M-201A ☐ EPA M-17 ☐ EPA M-29 ☐ EPA M-202 ☐ EPA M-26 ☐ Acid Gases ☐ IJA Protocol ☒ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☒ CEPI		
—	Filter: ☐ 4" Glass ☐ SS Thimble	☐ Pallflex ☐ 2.5" Glass		
5	Impingers: ☐ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☒ SO ₂ 4-DNPH	☐ H ₂ SO ₄ ☐ HNO ₃ /H ₂ O ₂ ☐ KMnO ₄ /H ₂ SO ₄ ☐ —		
—	Integrated Gas: ☐ Tedlar Bag	☐ EPA M-3 ☐ EPA M-10		
—	Oxides of Nitrogen:	☐ EPA M-7A ☐ —		
—	Fuel Lab: ☐ Fuel Sample	☐ Per S-0163		
—	Particle Sizing:	☐ X-Ray Scigraph ☐ Cascade Imp		
—	Miscellaneous:	☐ —		

Fuel type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
Wood: ☒ Wood Waste ☐ IDust ☐ Bark
Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
Misc: ☐ Natural Gas ☐ RDF ☐ —

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>[Signature]</u>	<u>Carl Interpoll</u>	<u>3-22-96</u>

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job CP / Hayward Source LTDC 2 Keweenaw Site STACIC Log No. 14
 Field Engineer SA Date of Test 3-96 Test No. 14 No. of Runs 14

No. Items	Sample Type	Analysis	Sequence No.	Comments
4	Probe Wash: ☒ Acetone ☐ MeCl ₃	☒ EPA M-5 ☐ EPA M-29		3 Sep 10 1 blank
4	Filter: ☒ 4" Glass ☐ 55 Thimble	☒ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		3 Sep 10 1 blank
4	Impingers: ☒ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ MN Protocol ☒ MWI Protocol ☐ EPA M-202 ☐ EPA M-29 ☐ EPA M-26 ☐ Acid Gases		3 Sep 10 1 blank
3	Integrated Gas: ☒ Tedlar Bag	☒ EPA M-3		
1	Oxides of Nitrogen:	☐ EPA M-7A		
1	Fuel Lab: ☒ Fuel Sample	☒ Per S-0163		
	Particle Sizing:	☐ X-Ray Sdgraph ☐ Cascade Imp		
12	Miscellaneous: ☒ Wood Waste ☐ Dust ☐ Bark	☐ EPA M-10		9 Silica Gel 3 Carcav

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
 Wood: ☒ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☐ Natural Gas ☐ RDF ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
	<u>Carl / Interpoll</u>	3/21/96 0800

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job Field Engineer L.P. Hayward Source Ans 2 Apr RD Date of Test 3-19-96 Test No. 17 Log No. 7451 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
	Probe Wash: ☐ DI Water ☐ Acetone ☐ MeCl ₂	☐ EPA M-5 ☐ EPA M-29	☐ EPA M-201A ☐	
	Filter: ☐ 4" Glass ☐ SS Thimble	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A	☐ EPA M-17	
	Impingers: ☐ DI Water ☐ 3% I ₂ /O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ MN Protocol ☐ WI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases	☐ IA Protocol ☐ Formaldehyde ☐ EPA M-29 ☐ EPA M-26 ☐	
	Integrated Gas: ☐ Tedlar Bag	☐ EPA M-3 ☐	☐ EPA M-10	
13	Oxides of Nitrogen:	☒ EPA M-7A ☐		
	Fuel Lab: ☐ Fuel Sample	☐ Per S-0163		
	Particle Sizing:	☐ X-Ray Scigraph ☐	☐ Cascade Imp	
	Miscellaneous: ☐	☐		

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
 Wood: ☐ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☐ Natural Gas ☐ RDF ☐

Relinquished by Affiliation	Accepted by Affiliation	Date
	<u>OK / Interpoll</u>	<u>3-25-96</u>

INTERPOL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

Job Field Engineer C.P. Hayward Source Line 2 Dept RTO Site Date of Test 3-19-96 Test No. 17 Log No. 7851 No. of Runs 3

No. Items	Sample Type	Analysis	Sequence No.	Comments
4	Probe Wash: ☒ Acetone ☐ MeCl ₄	☒ EPA M-5 ☐ EPA M-29		
4	Filler: "X" Glass ☐ 55 Thimble	☒ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
4	Impingers: ☒ H ₂ O ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 12.4-DNPH	☒ MIN Protocol ☒ EPA M-202 ☐ EPA M-6, B ☐ Acid Gases		
3	Integrated Gas: ☒ Cellular Bag	☒ EPA M-3		
—	Oxides of Nitrogen:	☐ EPA M-7A		
—	Fuel Lab: ☐ Fuel Sample	☐ Per S-0163		
—	Particle Sizing:	☐ X-Ray Sedgraph ☐ Cascade Imp		
—	Miscellaneous:	☐		

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
Waste: ☐ Wood ☐ Waste Oil ☐ No. 2 ☐ No. 6
Misc: ☒ Natural Gas ☐ LRD ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
<u>[Signature]</u>	<u>R. Zagar Interpol</u>	<u>3-20-96</u>

INTERPOLL LABORATORIES, INC.

(612) 786-6020

Sample Chain of Custody

LP/HAYWARD Source L-116 No. 1 Kous Site

J. BATHVILLE Date of Test 3-21-96

Log No. 7451

No. of Runs 4

Job

Field Engineer

No. Items	Sample Type	Analysis	Sequence No.	Comments
	Probe Wash: ☒ Acetone ☐ MeCl ₂	☒ EPA M-5 ☐ EPA M-29		
	Filter: ☒ 4" Glass ☐ SS Thimble	☐ EPA M-5 ☐ EPA M-29 ☐ EPA M-201A		
	Impingers: ☒ DI Water ☐ 3% H ₂ O ₂ ☐ 1N NaOH ☐ 2,4-DNPH	☐ IMN Protocol ☒ WVI Protocol ☐ EPA M-202 ☐ EPA M-6,8 ☐ Acid Gases		
	Integrated Gas: ☒ Tedlar Bag	☐ EPA M-3 ☐ EPA M-10		
	Oxides of Nitrogen:	☐ EPA M-7A		
	Fuel Lab: ☒ Fuel Sample	☐ Per S-0163		
	Particle Sizing:	☐ X-Ray Sdgraph ☐ Cascade Imp		
	Miscellaneous:	☐		

Fuel Type: Coal: ☐ Bituminous ☐ Anthracite ☐ Lignite
 Wood: ☒ Wood Waste ☐ Dust ☐ Bark
 Oil: ☐ Waste Oil ☐ No. 2 ☐ No. 6
 Misc: ☐ Natural Gas ☐ RDF ☐

Relinquished by/Affiliation	Accepted by/Affiliation	Date
James Bannister Interpoll Labs	Rel Interpoll	3/20/96 1115

APPENDIX E

NO_x/CO/THC STRIPCHART

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100

CHART NO. UC-3100-0011

00 10 20 30 40 50 60 70 80 90 100

00 10 20 30 40 50 60 70 80 90 100

RUN 3

200 RPM
9/10/68

R2

TEST

00 10 20 30 40 50 60 70 80 90 100

00 10 20 30 40 50 60 70 80 90 100

CHART NO. UC-3100-0011

J. Hayward
THC'S

Scale
0-1000


3-19-96

TBR3 →
End
1300 HRS

TBR3 →
Start
1200 HRS

TBR2 →
End
1100 HRS

TBR2 →
Start
1000 HRS





J.P. Hayward
THE's

3-20-96

Line 2 Surface Dyer
Duct

Scale
0-1000






J.P. Hayward
Nox

TBR, →
End
1420 HRS

100

TBR, →
Start
1315 HRS
3-19-96



Scale
0-100
(chart reads
backwards)

LP-Hayward
NOx

Scale
0-100

Line 2 Surface
Dyer


Line 2
Surface
Dryer

JP-Hayward
Mo
3-20-96

T8R3
Start
1200HRS

JF-Hayward
 Line 2 Propane
 RTD Stack
 3-20-96

TIR Start
 1650 HRS →



INSTRUMENT

T₁₁R₂
Start
1815 HRS

Run No. 2 1815

JP Thompson
State President
RTO Stack
3-20-64

T₁₁R₁ End
1750 HRS

CA No. 2

NO_x 0-250
THC's 0-100
CO 0-500

INSTRUMENT

LP Hayward
 Line 2 Proponent
 RTO Stack
 32096

MBEVEL

THC's

CO

NOx

Row No. 2 1815

NOx 0-250
 CO 0-500
 THC's 0-100

-cc

KONTROLL

J. Heyward
Line & Product
Rm Stock
3-20-96

JP Haywood
Line 2 Pressure
RDS Stack
3-20-96

MARKETWELL

T₁ P₃ →
Start

TEST 1 RUN 3


CAL 3

TEST 2 RUN 1

CHART NO. 4488703-08

*LP Hydrated
Line & Product
270 Sack
3-20-96*

INCHES



ROSEHILL

CHART NO. 4382777-00

ROSEHILL

T6R1
Start
1320 HRS

TEST 6 Run 2

THC's
Scale
0-100

THC's

LP Hayward
Line 2 Dryer 2 TO Stack
3-19-96

TRAILER

TEST 6 RUN 3

TOR End
→
1420 HRS

CAL 3

UP Hayward
Line 2 Paper
RTD Stack
319-9L

THE'S

Scale
0-100

POSTWELL

T6R2
Start
1000HRS

TEST 6 Run 4

Scale 0-100

JP Hazardous
Line 2 Dye
RTO Stack
320-96

CAL 4

TEST 6 Run 4

CAL 4

Page 6 RKN


T622 End
1100 PPS

JP Haywood
Line 2000
ETD Stack

THALP


Count no. 462723-01

THALP



TOULSON

CHART NO. 168107-107



HOUSTON

HOUSTON

CAL 9

← T₆R₃ and
BOOTHES

JP Haywood
Line Editor
RTD Stack
3-20-96

THE'S


1650 HRS
T221
Start →

LP Hayward
Line 2 Chevrolet LTD
Dale H

[Handwritten notes on graph paper:]


- THC'S
- CO D-500
- NOx 0-100
- THC'S 0-500
- LA TILR
- 2 Harvard
- 2 Chevrolet LTD
- Dale
- 29 ppm THC
- 60 ppm CO
- 79 ppm NOx





OSAT NO. 402207-00


FOATYELL




100 E. 20th St. 2nd Fl. New York, N.Y. 10003

Physical
Line Product
Market

TRAKASHION





TPR
 End
 1420HRS


J. P. Hayward
 Line 2 core dryer
 Duct
 3-19-96

THEME



1042102


CHART NO. 6082107-001



DUART NO. 402573-00

10-6-96

END 300H2S



APPENDIX F

NO_x AND CO DATALOGGER PRINTOUTS

Louisiana - Pacific/Hayward
Line 2 Dryer RTO Stack
Test 6 Run 1

DATE	TIME	NOX (ppm)	O2 (%)	CO (ppm)	CO2 (%)
3/19/96	1:21:00 PM	18.11	16.37	140.38	3.88
	1:22:00 PM	15.46	16.31	184.73	4.00
	1:23:00 PM	14.45	16.39	197.75	4.00
	1:24:00 PM	16.79	15.94	201.82	4.26
	1:25:00 PM	13.02	16.41	199.38	3.93
	1:26:00 PM	15.77	16.26	158.69	4.10
	1:27:00 PM	13.53	16.16	207.93	4.10
	1:28:00 PM	16.58	16.43	203.45	3.92
	1:29:00 PM	20.75	16.16	161.13	4.08
	1:30:00 PM	16.89	16.30	189.21	3.98
	1:31:00 PM	11.80	16.18	189.21	4.09
	1:32:00 PM	17.29	16.01	227.05	4.22
	1:33:00 PM	13.53	16.43	212.00	3.93
	1:34:00 PM	17.29	16.25	179.44	4.11
	1:35:00 PM	13.22	16.18	400.80	4.08
	1:36:00 PM	14.85	16.24	358.48	4.04
	1:37:00 PM	11.70	16.11	325.93	4.18
	1:38:00 PM	9.26	16.38	228.27	3.96
	1:39:00 PM	13.12	16.32	163.17	3.98
	1:40:00 PM	16.38	16.21	206.30	4.05
	1:41:00 PM	16.48	16.41	194.09	3.92
	1:42:00 PM	14.55	16.28	154.62	4.00
	1:43:00 PM	17.29	16.41	179.85	3.84
	1:44:00 PM	22.58	16.50	163.57	3.83
	1:45:00 PM	18.21	16.20	191.65	4.11
	1:46:00 PM	13.94	16.42	192.46	3.95
	1:47:00 PM	11.90	16.16	164.80	4.11
	1:48:00 PM	16.79	16.18	219.32	4.09
	1:49:00 PM	17.40	16.32	218.51	4.03
	1:50:00 PM	14.55	16.35	169.27	3.95
	1:51:00 PM	15.36	16.48	173.34	3.81
	1:52:00 PM	18.51	16.35	161.95	3.98
	1:53:00 PM	17.40	16.14	203.86	4.13
	1:54:00 PM	14.95	16.37	204.67	3.98
	1:55:00 PM	17.29	15.88	177.82	4.32
	1:56:00 PM	14.14	16.13	231.12	4.13
	1:57:00 PM	17.70	16.24	212.81	4.05
	1:58:00 PM	15.46	16.03	203.45	4.21
	1:59:00 PM	16.58	16.47	189.62	3.87
	2:00:00 PM	18.41	16.12	161.54	4.17
	2:01:00 PM	19.43	16.00	223.80	4.25
	2:02:00 PM	15.26	16.29	219.32	4.03
	2:03:00 PM	23.09	16.01	177.00	4.24
	2:04:00 PM	16.38	16.25	209.15	4.00
	2:05:00 PM	21.97	16.26	179.44	4.04
	2:06:00 PM	20.55	16.07	216.06	4.18
	2:07:00 PM	14.04	16.37	198.57	3.92
	2:08:00 PM	22.07	16.11	155.03	4.13
	2:09:00 PM	16.17	16.14	209.55	4.09
	2:10:00 PM	19.94	16.25	210.78	4.05
	2:11:00 PM	14.14	16.00	196.13	4.29
	2:12:00 PM	20.75	16.23	215.25	4.09
	2:13:00 PM	16.38	16.02	187.17	4.22
	2:14:00 PM	13.73	16.00	237.22	4.22
	2:15:00 PM	19.02	16.28	214.84	4.00
	2:16:00 PM	11.70	16.10	162.76	4.10
	2:17:00 PM	14.24	16.14	204.26	4.08
	2:18:00 PM	19.74	16.18	212.40	4.12
	2:19:00 PM	15.06	16.07	207.52	4.13
	2:20:00 PM	14.14	16.43	184.33	3.88
AVERAGES		16.30	16.20	202.10	4.10

Louisiana - Pacific/Hayward
Line 2 Dryer RTO Stack
Test 6 Run 2

DATE	TIME	NOX (ppm)	O2 (%)	CO (ppm)	CO2 (%)
3/20/96	10:01:58 AM	16.07	16.61	262.45	4.13
	10:02:58 AM	14.04	16.71	234.38	3.99
	10:03:58 AM	12.41	16.69	209.15	4.05
	10:04:58 AM	9.97	16.88	209.55	3.96
	10:05:58 AM	15.46	16.41	200.20	4.34
	10:06:58 AM	14.95	16.23	292.56	4.39
	10:07:58 AM	15.16	16.57	265.30	4.18
	10:08:58 AM	14.04	16.23	214.84	4.52
	10:09:58 AM	16.99	16.09	296.63	4.53
	10:10:58 AM	12.61	16.33	301.51	4.35
	10:11:58 AM	17.50	16.18	253.91	4.45
	10:12:58 AM	16.79	16.54	263.67	4.13
	10:13:58 AM	14.24	16.46	446.37	4.23
	10:14:58 AM	11.29	16.55	538.33	4.17
	10:15:58 AM	14.24	16.65	379.23	4.10
	10:16:58 AM	12.41	16.17	249.84	4.46
	10:17:58 AM	15.36	16.23	305.99	4.44
	10:18:58 AM	11.80	16.30	305.58	4.40
	10:19:58 AM	13.73	16.21	246.99	4.44
	10:20:58 AM	12.82	16.69	262.86	4.04
	10:21:58 AM	13.63	16.55	225.42	4.24
	10:22:58 AM	14.55	16.23	280.76	4.47
	10:23:58 AM	14.55	16.40	267.74	4.28
	10:24:58 AM	16.79	16.06	223.39	4.57
	10:25:58 AM	13.94	16.21	302.33	4.45
	10:26:58 AM	13.84	16.54	271.00	4.19
	10:27:58 AM	13.02	16.44	202.23	4.22
	10:28:58 AM	15.26	16.52	252.28	4.20
	10:29:58 AM	13.63	16.37	257.16	4.25
	10:30:58 AM	14.75	16.46	237.63	4.26
	10:31:58 AM	13.63	16.56	250.24	4.22
	10:32:58 AM	13.22	16.36	207.11	4.40
	10:33:58 AM	14.04	16.27	290.12	4.38
	10:34:58 AM	13.84	16.56	256.76	4.20
	10:35:58 AM	16.28	16.52	184.73	4.20
	10:36:58 AM	14.14	16.69	230.31	4.01
	10:37:58 AM	14.14	16.66	226.24	4.10
	10:38:58 AM	14.04	16.23	220.95	4.42
	10:39:58 AM	15.56	16.61	240.89	4.15
	10:40:58 AM	16.17	16.29	204.26	4.35
	10:41:58 AM	15.46	16.20	272.22	4.47
	10:42:58 AM	16.07	16.36	268.56	4.36
	10:43:58 AM	13.73	16.37	192.46	4.31
	10:44:58 AM	15.56	16.98	209.96	3.84
	10:45:58 AM	15.46	16.79	205.89	4.02
	10:46:58 AM	18.41	16.25	197.75	4.44
	10:47:58 AM	15.67	16.41	244.55	4.24
	10:48:58 AM	15.36	16.49	402.43	4.13
	10:49:58 AM	15.46	16.27	541.99	4.31
	10:50:58 AM	13.02	16.52	388.18	4.22
	10:51:58 AM	16.38	16.28	236.00	4.45
	10:52:58 AM	16.68	16.30	289.31	4.40
	10:53:58 AM	16.17	16.44	264.89	4.35
	10:54:58 AM	19.63	16.36	192.46	4.36
	10:55:58 AM	16.89	16.23	256.35	4.44
	10:56:58 AM	18.31	16.36	246.18	4.30
	10:57:58 AM	17.40	16.12	244.55	4.55
	10:58:58 AM	18.82	16.42	253.91	4.29
	10:59:58 AM	19.33	16.25	207.52	4.49
	11:00:58 AM	16.68	16.44	265.30	4.23
AVERAGES		15.02	16.42	265.86	4.28

Louisiana - Pacific/Hayward
Line 2 Dryer RTO Stack
Test 6 Run 3

DATE	TIME	NOX (ppm)	O2 (%)	CO (ppm)	CO2 (%)
3/20/96	12:01:58 PM	15.67	16.79	169.27	3.95
	12:02:58 PM	19.33	16.17	229.09	4.38
	12:03:58 PM	19.12	16.36	232.34	4.24
	12:04:58 PM	19.53	16.14	174.15	4.46
	12:05:58 PM	19.43	16.16	251.47	4.41
	12:06:58 PM	15.26	16.60	233.97	4.06
	12:07:58 PM	19.63	16.56	150.96	4.12
	12:08:58 PM	19.53	16.82	181.48	3.85
	12:09:58 PM	18.01	16.73	168.86	3.95
	12:10:58 PM	19.02	16.27	190.84	4.39
	12:11:58 PM	21.57	16.43	214.84	4.20
	12:12:58 PM	19.63	16.20	179.44	4.44
	12:13:58 PM	21.46	16.20	236.82	4.36
	12:14:58 PM	21.46	16.46	223.39	4.22
	12:15:58 PM	21.26	16.17	168.46	4.43
	12:16:58 PM	21.77	16.16	220.95	4.35
	12:17:58 PM	23.60	16.25	225.02	4.32
	12:18:58 PM	24.11	16.05	202.64	4.50
	12:19:58 PM	20.96	16.50	319.42	4.10
	12:20:58 PM	19.12	16.40	328.37	4.19
	12:21:58 PM	23.30	16.24	387.78	4.31
	12:22:58 PM	18.11	16.62	207.52	4.01
	12:23:58 PM	19.94	16.26	148.93	4.31
	12:24:58 PM	22.58	16.29	214.03	4.31
	12:25:58 PM	19.53	16.36	227.87	4.31
	12:26:58 PM	18.51	16.24	178.63	4.35
	12:27:58 PM	22.38	16.51	195.72	4.05
	12:28:58 PM	20.55	16.31	193.69	4.31
	12:29:58 PM	20.96	16.17	216.06	4.32
	12:30:58 PM	19.23	16.40	208.33	4.22
	12:31:58 PM	23.70	15.92	184.73	4.54
	12:32:58 PM	20.75	16.14	256.76	4.45
	12:33:58 PM	19.53	16.38	231.12	4.25
	12:34:58 PM	20.35	16.16	171.71	4.35
	12:35:58 PM	22.38	16.46	211.18	4.11
	12:36:58 PM	21.36	16.32	210.37	4.34
	12:37:58 PM	19.23	16.07	206.30	4.42
	12:38:58 PM	19.74	16.24	231.12	4.38
	12:39:58 PM	23.50	15.96	205.49	4.62
	12:40:58 PM	22.28	15.92	262.86	4.59
	12:41:58 PM	24.11	16.38	231.53	4.26
	12:42:58 PM	21.06	16.35	158.29	4.19
	12:43:58 PM	19.84	16.44	205.89	4.22
	12:44:58 PM	23.91	16.16	224.20	4.44
	12:45:58 PM	21.36	15.93	193.69	4.58
	12:46:58 PM	21.26	16.23	225.42	4.32
	12:47:58 PM	24.01	16.16	201.42	4.40
	12:48:58 PM	23.70	16.09	224.20	4.40
	12:49:58 PM	22.48	16.34	209.55	4.26
	12:50:58 PM	21.06	15.99	170.09	4.57
	12:51:58 PM	23.60	15.99	246.58	4.50
	12:52:58 PM	23.30	16.22	254.31	4.34
	12:53:58 PM	22.07	15.96	220.13	4.50
	12:54:58 PM	20.45	15.95	279.95	4.56
	12:55:58 PM	22.28	16.02	233.56	4.46
	12:56:58 PM	24.41	16.11	218.51	4.44
	12:57:58 PM	22.99	16.50	204.26	4.13
	12:58:58 PM	21.46	16.31	160.73	4.28
	12:59:58 PM	24.11	15.91	233.97	4.57
	1:00:58 PM	24.41	16.29	239.26	4.33
AVERAGES:		21.15	16.26	216.46	4.32

INTERPOLL LABS
EXTRACTION CEM TR2

LP / HAYWARD WA
LINE 2 CORE DRYER / DUCT
TEST 7 / RUN 1

DATE	TIME	NOX (ppm)	O2 (%)	CO (ppm)	CO2 (%)
3/19/98	1:21:18 PM	22.01	16.36	201.46	4.06
	1:22:18 PM	23.20	16.41	428.59	4.51
	1:23:18 PM	23.46	16.16	623.58	4.77
	1:24:18 PM	23.46	15.88	912.15	4.94
	1:25:18 PM	22.79	16.05	955.04	4.80
	1:26:18 PM	23.24	16.27	796.19	4.60
	1:27:18 PM	22.92	16.33	691.86	4.55
	1:28:18 PM	22.17	16.58	590.45	4.32
	1:29:18 PM	21.77	16.66	496.14	4.28
	1:30:18 PM	22.04	16.40	536.99	4.51
	1:31:18 PM	22.08	16.49	569.62	4.38
	1:32:18 PM	22.10	16.46	528.12	4.44
	1:33:18 PM	21.75	16.74	476.28	4.20
	1:34:18 PM	21.77	16.43	483.85	4.52
	1:35:18 PM	22.78	16.15	697.23	4.74
	1:36:18 PM	22.56	16.30	715.38	4.60
	1:37:18 PM	22.19	16.39	631.80	4.50
	1:38:18 PM	22.46	16.55	551.80	4.37
	1:39:18 PM	23.47	16.44	539.27	4.48
	1:40:18 PM	22.20	16.46	565.23	4.48
	1:41:18 PM	21.71	16.55	552.62	4.38
	1:42:18 PM	22.86	16.70	515.67	4.19
	1:43:18 PM	22.87	16.78	366.83	4.19
	1:44:18 PM	21.93	16.45	464.48	4.52
	1:45:18 PM	22.01	16.31	634.16	4.57
	1:46:18 PM	21.68	16.38	633.83	4.53
	1:47:18 PM	21.71	16.54	598.27	4.41
	1:48:18 PM	22.21	16.38	577.84	4.59
	1:49:18 PM	22.49	16.37	682.58	4.47
	1:50:18 PM	22.08	16.95	442.92	4.04
	1:51:18 PM	23.20	16.44	432.26	4.50
	1:52:18 PM	22.95	16.35	607.47	4.61
	1:53:18 PM	22.10	16.31	683.96	4.57
	1:54:18 PM	22.35	16.10	687.97	4.85
	1:55:18 PM	22.78	16.04	905.16	4.91
	1:56:18 PM	23.86	16.17	792.61	4.76
	1:57:18 PM	24.59	16.09	838.34	4.83
	1:58:18 PM	23.72	16.21	788.54	4.68
	1:59:18 PM	24.16	16.30	678.19	4.67
	2:00:18 PM	25.94	15.90	770.72	5.05
	2:01:18 PM	24.85	15.95	991.66	4.88
	2:02:18 PM	24.71	16.12	887.35	4.63
	2:03:18 PM	23.95	16.17	935.61	4.39
	2:04:37 PM	23.99	16.27	772.26	4.68
	2:05:37 PM	24.29	16.22	782.43	4.69
	2:06:37 PM	23.54	16.49	651.01	4.44
	2:07:37 PM	24.55	16.44	527.31	4.49
	2:08:37 PM	23.86	16.24	638.80	4.77
	2:09:37 PM	25.01	16.07	823.29	4.82
	2:10:37 PM	24.03	16.15	797.81	4.81
	2:11:37 PM	24.08	16.01	894.98	4.93
	2:12:37 PM	24.99	15.99	967.33	4.90
	2:13:37 PM	24.66	16.02	952.19	4.90
	2:14:37 PM	24.74	16.04	925.26	4.92
	2:15:37 PM	24.42	16.10	930.95	4.80
	2:16:37 PM	24.53	16.26	757.21	4.70
	2:17:37 PM	24.28	16.15	813.60	4.80
	2:18:37 PM	23.97	16.23	828.82	4.68
	2:19:37 PM	24.15	16.36	692.75	4.60
	2:20:37 PM	24.78	16.33	640.83	4.66
AVERAGES		23.25	16.32	680.78	4.59

INTERPOLL LABS
EXTRACTION CEM TR2

LP / HAYWARD, WI
LINE 2 CORE DRYER / DUCT
TEST 7 / RUN 2

DATE	TIME	NOX (ppm)	O2 (%)	CO (ppm)	CO2 (%)
3/20/96	10:01:59 AM	21.24	15.48	1551.22	5.16
	10:02:59 AM	20.05	16.19	1242.55	4.68
	10:03:59 AM	20.00	16.39	891.47	4.59
	10:04:59 AM	20.75	16.24	967.22	4.74
	10:05:59 AM	22.82	15.61	1168.86	5.24
	10:06:59 AM	22.41	15.46	1512.81	5.25
	10:07:59 AM	22.37	15.63	1453.89	5.14
	10:08:59 AM	23.33	15.60	1421.18	5.22
	10:09:59 AM	23.61	15.24	1540.56	5.39
	10:10:59 AM	22.29	15.80	1443.15	5.06
	10:11:59 AM	22.91	15.67	1406.61	5.14
	10:12:59 AM	23.98	15.62	1380.89	5.21
	10:13:59 AM	22.89	15.65	1449.34	5.08
	10:14:59 AM	23.16	15.79	1293.00	5.10
	10:15:59 AM	23.55	15.63	1386.02	5.22
	10:16:59 AM	23.62	15.50	1480.59	5.26
	10:17:59 AM	24.03	15.58	1458.78	5.26
	10:18:59 AM	24.31	15.66	1460.89	5.13
	10:19:59 AM	22.86	16.29	1270.79	4.60
	10:20:59 AM	22.17	16.72	737.91	4.39
	10:21:59 AM	22.95	16.19	769.32	4.81
	10:22:59 AM	24.37	15.87	1139.36	5.04
	10:23:59 AM	25.60	15.40	1454.46	5.37
	10:24:59 AM	26.49	15.41	1585.48	5.31
	10:25:59 AM	25.00	15.70	1540.07	5.02
	10:26:59 AM	24.68	16.01	1264.11	4.87
	10:27:59 AM	23.85	16.34	1083.78	4.62
	10:28:59 AM	26.47	15.91	1039.75	5.05
	10:29:59 AM	25.89	15.85	1346.63	4.93
	10:30:59 AM	26.34	15.95	1177.44	5.01
	10:31:59 AM	26.26	15.74	1342.48	5.02
	10:32:59 AM	25.48	15.85	1291.54	5.02
	10:33:59 AM	25.16	15.99	1315.87	4.86
	10:34:59 AM	25.64	16.00	1172.15	4.91
	10:35:59 AM	25.79	15.94	1226.92	4.91
	10:36:59 AM	25.52	16.00	1166.95	4.89
	10:37:59 AM	26.92	15.79	1214.15	5.05
	10:38:59 AM	26.51	15.79	1332.80	5.08
	10:39:59 AM	26.49	15.96	1288.77	4.89
	10:40:59 AM	27.05	15.87	1214.63	4.96
	10:41:59 AM	28.05	15.85	1212.03	5.09
	10:42:59 AM	27.57	15.67	1417.03	5.15
	10:43:59 AM	27.10	15.78	1368.14	4.99
	10:44:59 AM	26.72	15.94	1191.36	4.90
	10:45:59 AM	27.69	15.87	1225.38	5.02
	10:46:59 AM	27.88	15.78	1270.14	5.06
	10:47:59 AM	28.05	15.92	1279.74	4.90
	10:48:59 AM	27.80	16.20	989.46	4.78
	10:50:03 AM	27.89	15.98	1036.82	4.92
	10:51:03 AM	27.04	15.86	1218.22	4.97
	10:52:03 AM	27.10	15.72	1277.22	5.10
	10:53:03 AM	27.90	15.84	1257.44	4.99
	10:54:03 AM	28.50	15.74	1236.29	5.15
	10:55:03 AM	27.78	15.47	1404.90	5.24
	10:56:03 AM	27.31	15.69	1400.91	5.13
	10:57:03 AM	27.91	15.70	1354.04	5.14
	10:58:03 AM	28.13	15.60	1363.48	5.20
	10:59:03 AM	27.48	15.83	1345.17	5.03
	11:00:03 AM	27.74	15.78	1351.43	4.99

AVERAGES 25.26 15.82 1281.38 5.02

INTERPOLL LABS
EXTRACTION CEM TR2

LP / HAYWARD, WI
LINE 2 CORE DRYER / DUCT
TEST 7 / RUN 3

DATE	TIME	NOX (ppm)	O2 (%)	CO (ppm)	CO2 (%)
3/20/96	12:01:49 PM	21.36	16.13	900.83	4.90
	12:02:49 PM	23.06	15.68	1255.72	5.28
	12:03:49 PM	23.34	15.78	1449.24	5.15
	12:04:49 PM	24.06	15.66	1447.63	5.24
	12:05:49 PM	23.93	15.85	1387.61	5.12
	12:06:49 PM	21.83	16.47	1162.67	4.53
	12:07:49 PM	22.61	16.36	750.33	4.71
	12:08:49 PM	22.74	16.47	772.65	4.64
	12:09:49 PM	23.13	16.30	783.20	4.76
	12:10:49 PM	25.13	15.86	1017.97	5.20
	12:11:49 PM	24.36	15.90	1297.78	5.05
	12:12:49 PM	24.84	15.93	1199.65	5.09
	12:13:49 PM	25.55	15.83	1205.69	5.16
	12:14:49 PM	25.44	15.95	1294.40	5.11
	12:15:49 PM	25.96	15.91	1211.17	5.08
	12:16:49 PM	26.80	15.87	1143.74	5.19
	12:17:49 PM	27.41	15.82	1205.85	5.22
	12:18:49 PM	26.41	15.91	1266.92	4.96
	12:19:49 PM	25.90	16.41	793.03	4.69
	12:20:49 PM	26.12	16.30	685.73	4.81
	12:21:49 PM	26.28	16.15	764.43	4.89
	12:22:49 PM	26.47	16.05	872.63	5.01
	12:23:49 PM	26.87	15.82	1103.61	5.19
	12:24:49 PM	28.13	15.56	1250.16	5.42
	12:25:49 PM	28.00	15.70	1343.30	5.24
	12:26:49 PM	26.53	16.03	1175.16	4.85
	12:27:49 PM	25.22	16.61	662.92	4.58
	12:28:49 PM	26.85	16.08	765.96	4.97
	12:29:49 PM	26.95	16.14	910.09	4.91
	12:30:49 PM	28.13	15.73	1031.67	5.32
	12:31:49 PM	29.19	15.48	1423.14	5.44
	12:32:49 PM	28.03	15.81	1366.90	5.11
	12:33:49 PM	27.83	16.04	1115.62	5.00
	12:34:49 PM	27.09	16.12	1019.66	4.83
	12:35:49 PM	26.84	16.49	772.32	4.68
	12:36:49 PM	27.34	15.97	870.45	5.07
	12:37:49 PM	27.91	15.82	1160.25	5.25
	12:38:49 PM	29.36	15.36	1458.02	5.54
	12:39:49 PM	30.75	15.40	1526.51	5.56
	12:40:49 PM	29.92	15.61	1525.78	5.27
	12:41:49 PM	28.82	16.02	1214.79	4.91
	12:42:49 PM	26.97	16.55	781.11	4.57
	12:43:49 PM	27.60	16.26	691.68	4.86
	12:44:49 PM	31.04	15.45	1158.16	5.54
	12:45:49 PM	30.09	15.70	1370.29	5.26
	12:46:49 PM	29.82	15.64	1287.30	5.29
	12:47:49 PM	28.40	15.88	1245.17	5.11
	12:48:49 PM	28.53	15.94	1137.05	5.10
	12:49:49 PM	29.09	15.82	1103.05	5.21
	12:50:49 PM	29.44	15.73	1215.44	5.24
	12:51:49 PM	29.23	15.77	1200.62	5.22
	12:52:49 PM	28.90	15.77	1213.75	5.21
	12:53:49 PM	29.80	15.82	1160.25	5.24
	12:54:49 PM	31.15	15.48	1330.33	5.48
	12:55:49 PM	31.39	15.39	1412.34	5.51
	12:56:49 PM	29.89	15.83	1320.34	5.16
	12:57:49 PM	29.23	16.06	1046.89	4.93
	12:58:49 PM	28.94	16.40	760.72	4.71
	12:59:49 PM	32.30	15.51	970.60	5.49
	1:00:49 PM	30.58	15.70	1335.89	5.27
AVERAGES		27.23	15.92	1121.27	5.09

Louisiana - Pacific/Hayward
Line 2 Konus Stack
Test 16 Run 1

DATE	TIME	NOX (ppm)	O2 (%)	CO (ppm)	CO2 (%)
3/18/96	10:37:57 AM	47.27	18.17	321.53	3.28
	10:38:57 AM	44.63	18.09	229.57	3.03
	10:39:57 AM	46.88	18.29	261.15	3.20
	10:40:57 AM	55.69	18.14	314.45	3.76
	10:41:57 AM	59.44	17.59	184.41	4.20
	10:42:57 AM	61.16	17.12	132.57	4.40
	10:43:57 AM	60.65	16.88	120.20	4.28
	10:44:57 AM	61.20	16.94	133.14	4.41
	10:45:57 AM	62.83	16.74	129.56	4.81
	10:46:57 AM	63.13	16.22	121.42	4.69
	10:47:57 AM	61.10	16.31	119.47	4.28
	10:48:57 AM	59.89	16.72	126.79	4.02
	10:49:57 AM	55.77	16.99	137.29	3.81
	10:50:57 AM	54.42	17.23	140.38	3.98
	10:51:57 AM	54.26	17.12	122.31	3.91
	10:52:57 AM	54.22	17.21	130.70	3.83
	10:53:57 AM	54.46	17.26	153.81	3.82
	10:54:57 AM	53.04	17.31	145.35	3.85
	10:55:57 AM	58.71	17.27	137.70	4.28
	10:56:57 AM	60.95	16.90	106.61	4.54
	10:57:57 AM	63.65	16.60	139.08	5.11
	10:58:57 AM	62.95	16.07	146.00	5.57
	10:59:57 AM	62.79	15.51	121.09	5.53
	11:00:57 AM	63.49	15.41	108.15	5.17
	11:01:57 AM	63.52	15.71	119.79	4.76
	11:02:57 AM	61.78	16.12	104.57	4.50
	11:03:57 AM	58.46	16.47	115.23	4.09
	11:04:57 AM	56.50	16.88	119.22	4.05
	11:05:57 AM	56.76	17.00	108.97	4.14
	11:06:57 AM	57.41	16.94	117.35	4.44
	11:07:57 AM	60.77	16.67	125.24	4.96
	11:08:57 AM	61.61	16.22	95.87	5.09
	11:09:57 AM	60.82	16.03	88.54	4.88
	11:10:57 AM	59.93	16.17	84.31	4.86
	11:11:57 AM	64.49	16.15	89.93	5.33
	11:12:57 AM	66.76	15.69	105.31	5.74
	11:13:57 AM	68.51	15.20	99.04	5.98
	11:14:57 AM	65.78	14.84	87.00	6.14
	11:15:57 AM	64.09	14.60	91.47	6.28
	11:16:57 AM	64.05	14.37	104.74	6.41
	11:17:57 AM	63.62	14.17	85.45	6.38
	11:18:57 AM	63.27	14.16	84.31	6.44
	11:19:57 AM	65.45	14.06	90.90	6.57
	11:20:57 AM	64.88	13.88	78.04	6.65
	11:21:57 AM	65.28	13.75	85.12	6.62
	11:22:57 AM	66.33	13.75	127.12	6.76
	11:23:57 AM	65.72	13.60	118.25	7.03
	11:24:57 AM	64.88	13.28	181.97	7.04
	11:25:57 AM	62.07	13.25	153.81	6.93
	11:26:57 AM	63.18	13.36	138.67	7.04
	11:27:57 AM	61.61	13.20	468.02	7.43
	11:28:57 AM	60.92	12.74	666.42	7.47
	11:29:57 AM	62.79	12.67	285.97	7.27
	11:30:57 AM	63.96	12.91	221.35	7.03
	11:31:57 AM	62.33	13.09	340.09	7.31
	11:32:57 AM	62.77	12.77	301.11	7.08
	11:33:57 AM	63.45	13.02	210.37	7.30
	11:34:57 AM	66.04	12.85	157.47	7.21
	11:35:57 AM	65.90	13.12	105.14	6.59
	11:36:57 AM	67.24	13.74	87.48	6.49
AVERAGES		60.92	15.51	157.11	5.37

Louisiana - Pacific/Hayward

Line2 Konus Stack

Test 16 Run 2

DATE	TIME	NOX (ppm)	O2 (%)	CO (ppm)	CO2 (%)
3/18/96	12:21:57 PM	63.33	14.84	92.77	5.52
	12:22:57 PM	67.33	14.60	127.28	5.49
	12:23:57 PM	65.38	14.63	101.32	5.56
	12:24:57 PM	64.97	14.47	108.64	5.50
	12:25:57 PM	64.08	14.49	101.16	5.49
	12:26:57 PM	62.04	14.52	174.15	5.80
	12:27:57 PM	57.68	14.17	644.61	6.15
	12:28:57 PM	59.16	13.83	577.39	5.98
	12:29:57 PM	62.09	14.01	153.81	5.93
	12:30:57 PM	62.12	13.94	194.09	6.31
	12:31:57 PM	57.61	13.50	502.69	6.28
	12:32:57 PM	61.70	13.51	284.34	6.19
	12:33:57 PM	63.49	13.62	99.85	6.39
	12:34:57 PM	62.68	13.50	109.86	6.34
	12:35:57 PM	64.58	13.58	106.36	6.22
	12:36:57 PM	64.58	13.74	108.72	5.99
	12:37:57 PM	63.20	13.95	90.25	5.75
	12:38:57 PM	63.62	14.34	75.20	5.18
	12:39:57 PM	63.74	14.78	91.88	5.26
	12:40:57 PM	65.52	14.74	105.39	5.44
	12:41:57 PM	64.59	14.61	96.84	5.60
	12:42:57 PM	63.26	14.47	108.07	5.85
	12:43:57 PM	62.91	14.24	107.67	5.76
	12:44:57 PM	62.61	14.32	91.96	5.68
	12:45:57 PM	62.57	14.36	100.51	5.73
	12:46:57 PM	62.93	14.14	122.72	6.08
	12:47:57 PM	64.89	13.76	150.55	6.33
	12:48:57 PM	66.84	13.76	99.69	6.02
	12:49:57 PM	63.11	13.98	171.39	6.12
	12:50:57 PM	56.14	13.67	953.86	6.39
	12:51:57 PM	56.86	13.51	642.66	6.07
	12:52:57 PM	61.59	13.81	288.66	6.12
	12:53:57 PM	63.57	13.69	136.72	6.21
	12:54:57 PM	62.35	13.68	107.18	6.09
	12:55:57 PM	61.72	13.80	96.60	6.04
	12:56:57 PM	63.73	14.00	126.71	5.59
	12:57:57 PM	65.38	14.46	169.11	5.43
	12:58:57 PM	62.62	14.49	170.49	5.81
	12:59:57 PM	58.98	13.96	358.32	6.28
	1:00:57 PM	60.22	13.61	239.10	6.46
	1:01:57 PM	61.66	13.39	170.49	6.31
	1:02:57 PM	61.65	13.62	123.05	6.18
	1:03:57 PM	60.57	13.70	115.97	6.04
	1:04:57 PM	62.07	13.80	91.47	6.18
	1:05:57 PM	61.13	13.55	235.19	6.45
	1:06:57 PM	60.93	13.33	311.77	6.37
	1:07:57 PM	62.04	13.46	107.59	6.36
	1:08:57 PM	65.02	13.44	78.78	6.31
	1:09:57 PM	65.10	13.73	68.44	5.96
	1:10:57 PM	63.65	13.78	65.51	6.28
	1:11:57 PM	63.90	13.44	91.39	6.54
	1:12:57 PM	64.74	13.14	221.60	6.95
	1:13:57 PM	66.59	12.70	231.04	7.12
	1:14:57 PM	64.67	12.34	528.08	7.28
	1:15:57 PM	62.19	12.29	1006.27	7.02
	1:16:57 PM	59.74	12.49	1283.45	6.80
	1:17:57 PM	59.99	12.68	970.22	6.92
	1:18:57 PM	60.82	12.35	1718.91	7.12
	1:19:57 PM	61.67	12.42	734.29	7.20
	1:20:57 PM	62.78	12.20	535.97	7.29
AVERAGES		62.61	13.75	281.30	6.15

Louisiana - Pacific/Hayward

Line 2 Konus Stack

Test 16 Run 3

DATE	TIME	NOX (ppm)	O2 (%)	CO (ppm)	CO2 (%)
3/18/96	2:06:57 PM	57.28	13.27	677.08	6.72
	2:07:57 PM	60.05	12.71	962.32	7.00
	2:08:57 PM	62.48	12.45	420.25	6.83
	2:09:57 PM	63.26	12.65	209.15	6.86
	2:10:57 PM	61.33	12.70	485.11	6.76
	2:11:57 PM	64.81	12.70	321.86	7.26
	2:12:57 PM	60.44	12.10	344.65	7.45
	2:13:57 PM	59.64	11.79	874.35	7.76
	2:14:57 PM	62.91	11.38	615.40	7.36
	2:15:57 PM	65.00	11.95	163.74	7.02
	2:16:57 PM	65.42	12.36	130.45	7.12
	2:17:57 PM	64.51	12.22	275.39	7.60
	2:18:57 PM	64.76	11.75	359.70	7.69
	2:19:57 PM	67.40	11.69	218.02	7.56
	2:20:57 PM	66.01	11.80	240.89	7.29
	2:21:57 PM	66.65	12.09	227.05	7.24
	2:22:57 PM	63.84	12.08	366.86	7.36
	2:23:57 PM	64.43	12.05	177.00	7.20
	2:24:57 PM	65.19	12.25	167.89	7.26
	2:25:57 PM	66.46	12.00	235.51	7.67
	2:26:57 PM	64.10	11.59	136.31	7.67
	2:27:57 PM	61.82	11.74	151.61	7.22
	2:28:57 PM	59.11	12.18	194.74	6.84
	2:29:57 PM	59.48	12.59	311.52	6.88
	2:30:57 PM	61.43	12.73	280.84	6.61
	2:31:57 PM	61.64	13.08	132.73	6.42
	2:32:57 PM	61.59	13.35	120.12	6.01
	2:33:57 PM	63.70	13.96	93.51	5.60
	2:34:57 PM	65.72	14.30	86.10	5.78
	2:35:57 PM	66.92	14.09	101.73	5.81
	2:36:57 PM	64.91	14.36	94.56	5.27
	2:37:57 PM	63.33	14.85	72.27	5.04
	2:38:57 PM	62.16	15.12	65.02	4.99
	2:39:57 PM	60.35	15.16	85.29	4.98
	2:40:57 PM	62.61	15.17	98.96	5.04
	2:41:57 PM	61.30	15.18	79.10	4.85
	2:42:57 PM	64.35	15.27	69.34	5.10
	2:43:57 PM	66.55	15.00	71.62	5.35
	2:44:57 PM	66.96	14.72	67.22	5.91
	2:45:57 PM	65.20	14.00	77.39	6.36
	2:46:57 PM	68.05	13.59	81.71	6.54
	2:47:57 PM	65.59	13.28	109.62	6.84
	2:48:57 PM	65.56	12.79	116.70	6.68
	2:49:57 PM	66.59	13.03	92.86	6.46
	2:50:57 PM	67.34	13.17	99.12	6.47
	2:51:57 PM	67.54	13.19	97.01	6.78
	2:52:57 PM	63.62	12.86	178.39	7.24
	2:53:57 PM	59.03	12.29	392.33	7.13
	2:54:57 PM	62.78	12.37	316.49	6.91
	2:55:47 PM	67.60	12.59	129.23	6.76
	2:56:47 PM	67.62	12.87	90.50	6.01
	2:57:47 PM	65.30	13.68	91.80	5.52
	2:58:47 PM	63.77	14.35	102.13	5.32
	2:59:47 PM	62.03	14.64	101.97	5.08
	3:00:47 PM	61.04	15.10	89.52	4.56
	3:01:47 PM	59.62	15.64	80.73	4.23
	3:02:47 PM	58.18	15.97	80.97	4.09
	3:03:47 PM	58.09	16.15	97.90	4.10
	3:04:47 PM	59.63	16.17	89.36	4.22
	3:05:47 PM	65.16	15.90	99.37	5.09
AVERAGES		63.49	13.37	206.67	6.31

APPENDIX G

MEASUREMENT SYSTEM PERFORMANCE SPECIFICATIONS

(612) 786-6020

Drawing of Test Site

Cross-section View	Elevation View
--------------------	----------------

R or nothing = reg. manometer; S = expanded; E = electronic

Calibration Error Check

Job

LP/HAMANO

Test

6 Run 0 Date 3-14-96

Operator

S. BARNWELL

THL

SO₂ Calibration:

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0	0	100	0%
Low Level	27.9	28.8	1.1	100	1.1%
High Level	286	270	16	1000	1.6%
High Level	2960	3100	140	1000	1.4%

NO_x Calibration:

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	2	2	250	-0.1%
Mid Level	145	145	0	250	0
High Level	240	240	0	250	0

O₂ Calibration:

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0	0	25%	0
Mid Level	13.1	13	-1	25%	.40%
High Level	21	21.0	0	25%	0

CO₂ Calibration

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0	0	20%	0
Mid Level	10.5	10.4	-1	20%	.5%
High Level	16.8	16.8	0	20%	0

CO Calibration

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	1	1	1000	.1%
Mid Level	299	298	1	1000	.1%
High Level	600	600	0	1000	0%

INTERPOL LABORATORIES, INC

(612) 786-6020

System Bias Check

Job

LP/HAYWARD

Source

LINE 2 PNEUMATIC STACK

Test

6 Run 0 Date 3-14-96

Site

STACK

Operator

S. BARNES

Instrument	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		Diff. CE-SB (PPM)	Span Val. (PPM)	% of Span
			Cal. Err.	Sys. Bias			
THL	Zero Gas	0	0	1	1	100	1%
	Upscale	27.9	29	28	1	100	1%
NO _x	Zero Gas	0	2	0	2	250	.01%
	Upscale	145	145	146	1	250	.01%
O ₂	Zero Gas	0	0	0	0	25%	0
	Upscale	13.1	13	13.1	-1	25%	.4%
CO ₂	Zero Gas	0	0	0	0	20%	0
	Upscale	10.4	10.4	10.5	-1	20%	.5%
CO	Zero Gas	0	1	0	1	1000	.1%
	Upscale	299	298	299	1	1000	.1%
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

THL Cal Drift Check

Job

Test

Operator

LP/MAY WIND6

Run

Date 3-19-96

Source

Site

LINE 2 PNYC NTO STALKSTALK

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C ₀	C _m	C _{sp}
				Initial	Final			
1		Zero Gas	0	1	-1	0	██████	
		Upscale	27.4	28	29	██████	28.5	
2		Zero Gas	0	0	1	.5	██████	
		Upscale	27.4	28	30	██████	29	
3		Zero Gas	0	0	0	0	██████	
		Upscale	30	30	29	██████	29.5	
4		Zero Gas	0	0	0	0	██████	
		Upscale	30	30	29	██████	29.5	
5		Zero Gas	0	0	1	.5	██████	
		Upscale	30	30	30	██████	30	
6		Zero Gas	0				██████	
		Upscale				██████		
7		Zero Gas	0				██████	
		Upscale				██████		
8		Zero Gas	0				██████	
		Upscale				██████		
9		Zero Gas	0				██████	
		Upscale				██████		
10		Zero Gas	0				██████	
		Upscale				██████		
11		Zero Gas	0				██████	
		Upscale				██████		
12		Zero Gas	0				██████	
		Upscale				██████		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

NOA Cal Drift Check

Job

LP MAYWOOD

Source

LINE 2 DRY ON NTO STACK

Test

6 RunDate 3-19-96

Site

STACK

Operator

S. BARNES

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_{10}	C_{gas}
				Initial	Final			
1 VOID		Zero Gas	0	0	2	1	XXXX	
		Upscale	145	146	143	XXXX	144.5	
2 Jun 1	16.3	Zero Gas	0	1.2	1.2	1.2	XXXX	15.2
		Upscale	145	145	145	XXXX	145	
3 VOID		Zero Gas	0	1.2	0	.61	XXXX	
		Upscale	145	145	140	XXXX	146.5	
4 Jun 2	15.0	Zero Gas	0	1	2.2	1.6	XXXX	13.4
		Upscale	145	145	149	XXXX	147	
5 Jun 3	21.2	Zero Gas	0	1	3	2	XXXX	19.6
		Upscale	145	145	143	XXXX	144	
6		Zero Gas	0				XXXX	
		Upscale				XXXX		
7		Zero Gas	0				XXXX	
		Upscale				XXXX		
8		Zero Gas	0				XXXX	
		Upscale				XXXX		
9		Zero Gas	0				XXXX	
		Upscale				XXXX		
10		Zero Gas	0				XXXX	
		Upscale				XXXX		
11		Zero Gas	0				XXXX	
		Upscale				XXXX		
12		Zero Gas	0				XXXX	
		Upscale				XXXX		

Must be within 5% of the span for the zero or upscale cal. gas.

C0 Cal Drift Check

Job

LP / MAYWOOD

Source

LEL - ONYON RTD E

Test

6 Run 3-19-96 Date

Site

STAL

Operator

S. BROWNELL

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C ₀	C _m	C _{gas}
				Initial	Final			
1 VOID	202.7	Zero Gas	0	0	1.6	.8		
		Upscale	299	299	302		300.5	
2 Run 1	202.1	Zero Gas	0	0	0	0		
		Upscale	299	300	299		299.5	201.8
3 VOID		Zero Gas	0	0	1	.5		
		Upscale	299	300	297		298.5	
4 Run 2	265.9	Zero Gas	0	0	0	0		
		Upscale	299	299	299		299	265.9
5 Run 3	216.5	Zero Gas	0	0	0	0		
		Upscale	299	299	294		296.5	218.3
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

CO₂ Cal Drift Check

Job

LP HAYWARD

Source

LINE 2 DRYER RTU STACK

Test

6

Run

Date 3-19-96

Site

STACK

Operator

S. BARNES

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1 VOID		Zero Gas	0	0	0	0	XXXX	
		Upscale	10.5	10.5	10.5	XXXX	10.5	
2 RUN1	4.1	Zero Gas	0	0	0	0	XXXX	4.1
		Upscale	10.5	10.5	10.4	XXXX	10.45	
3 VOID		Zero Gas	0	0	0	0	XXXX	
		Upscale	10.5	10.5	10.5	XXXX	10.5	
4 RUN2	4.3	Zero Gas	0	0	0	0	XXXX	4.3
		Upscale	10.5	10.5	10.5	XXXX	10.5	
5 RUN3	4.3	Zero Gas	0	0	0	0	XXXX	4.3
		Upscale	10.5	10.5	10.4	XXXX	10.45	
6		Zero Gas	0				XXXX	
		Upscale				XXXX		
7		Zero Gas	0				XXXX	
		Upscale				XXXX		
8		Zero Gas	0				XXXX	
		Upscale				XXXX		
9		Zero Gas	0				XXXX	
		Upscale				XXXX		
10		Zero Gas	0				XXXX	
		Upscale				XXXX		
11		Zero Gas	0				XXXX	
		Upscale				XXXX		
12		Zero Gas	0				XXXX	
		Upscale				XXXX		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

02 Cal Drift Check

Job

LP / HAYWARD

Test

6

Run

Date

3-19-96

Source

LENCZ DRYCHARTO STACK

Operator

3. BATHVILLE

Site

STACK

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_m	C_{gas}
				Initial	Final			
1 VOID		Zero Gas	0	0	0	0		
		Upscale	13.1	13.1	13.1		13.1	
2 RUN 1	16.2	Zero Gas	0	0	0	0		16.3
		Upscale	13.1	13.1	12.9		13	
3 VOID		Zero Gas	0	0	-1	-0.5		
		Upscale	13.1	13.1	13.1		13.1	
4 RUN 2	16.4	Zero Gas	0	0	1	.5		16.5
		Upscale	13.1	13.1	13.1		13.1	
5 RUN 3	16.3	Zero Gas	0	.1	0	.05		16.3
		Upscale	13.1	13.1	13.1		13.1	
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

Calibration Error Check

Job L.P. / Hugulard, WI
 Test 7 Run 0 Date 3-19-96
 Operator M. Kachler

SO₂ Calibration:

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0 <u>2 ML</u>			
Mid Level					
High Level					

NO_x Calibration:

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0	0	500	0
Mid Level	239	240	1	500	.20
High Level	451.4	452	.6	500	.12

O₂ Calibration:

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0.0	0	25.0	0
Mid Level	13.5	13.5	0.0	25.0	0
High Level	21.0	21.0	0.0	25.0	0

CO₂ Calibration

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0.0	0.0	20.0	0
Mid Level	10.9	10.9	0.0	20.0	0
High Level	17.0	17.0	0.0	20.0	0

CO Calibration

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0 & 2 ML	0	1000	0
Mid Level	289	303	14	1000	1.4
High Level	620	623	3	1000	.3

Calibration Error Check & Drift Determination

Job L.P. / Hayward, WITest 7 Run 2 Date 3-19-96Operator McKachler

THC Calibration (Low Range):

Time (HRS) _____

***	Cylinder Value (ppm)	Analyzer Response (ppm)	Difference (ppm)	Span Value (ppm)	Percent of Span
Zero gas	0	0.0	0	100	0
Low level	30	29.8	.2	100	.2
Mid level	299	301	2	1,000	.2
High level	3150	3025	125	10,000	1.25

THC Calibration (High Range):

Time (HRS) _____

***	Cylinder Value (ppm)	Analyzer Response (ppm)	Difference (ppm)	Span Value (ppm)	Percent of Span
Zero gas	0				
Span					

O₂ Calibration:

Time (HRS) _____

***	Cylinder Value (%)	Analyzer Response (%)	Difference (%)	Span Value (%)	Percent of Span
Zero gas	0				
Mid level					
High level					

CO₂ Calibration:

Time (HRS) _____

***	Cylinder Value (%)	Analyzer Response (%)	Difference (%)	Span Value (%)	Percent of Span
Zero gas	0				
Mid level					
High level					

Must be within 2% of the span for each calibration gas

S-420-14

INTERPOL LABORATORIES, INC

(612) 786-6020

System Bias Check

Job h.7. / Hayward, CA Source Core Dryer
 Test 7 Run 0 Date 3-19-96 Site Duct
 Operator M. Kachlaw

Instrument	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		Diff. CE-SB (PPM)	Span Val. (PPM)	% of Span
			Cal. Err.	Sys. Bias			
O ₂	Zero Gas	0	0.0	0.0	0.0	25.0	0
	Upscale	13.5	13.5	13.5	0.0	25.0	0
CO ₂	Zero Gas	0	0.0	0.0	0.0	20.0	0
	Upscale	10.9	10.9	10.9	0.0	20.0	0
NO _x	Zero Gas	0	0	0	0	500	0
	Upscale	239	236	236	0	500	0
CO	Zero Gas	0	0	0	0	1000	0
	Upscale	620	623	620	3	1,000	3
THC	Zero Gas	0	0	.3	.3	1,000	.03
	Upscale	299	301	299	4	1,000	.4
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

NOx Cal Drift Check

Job

R.P. Hayward, WI

Source

Core Dryer

Test

7 Run 1,2,3,4,5 Date 3-19-86

Site

Duct

Operator

M. Laehle

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C ₀	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	0				
		Upscale	239	239				
2	VOID 27.05	Zero Gas	0	0	4	2		
		Upscale	239	236	235		235.5	25.64
3		Zero Gas	0	4				
		Upscale	239	235				
4	RUN 23.25	Zero Gas	0	0	1	1.5		
		Upscale	73.7	74	71		72.5	23.29
5		Zero Gas	0	1				
		Upscale	73.7	72				
6	VOID 25.95	Zero Gas	0	0	0	0		
		Upscale	73.7	72	76		74	25.84
7	7 RUN 25.26	Zero Gas	0	0	3	1.5		
		Upscale	73.7	76	77		76.5	25.50
8	8 RUN 27.23	Zero Gas	0	3	4	3.5		
		Upscale	73.7	77	79		77.5	23.63
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

CO Cal Drift Check

Job

L.P. / Hayward, Ill

Source

No. 2 Core Dryer

Test

Run 1, 2, 3, 4, 5 Date 3-19-96

Site

Diet

Operator

M. Kachler

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_m	C_{gs}
				Initial	Final			
1		Zero Gas	0	0				
		Upscale	620	621				
2 VOID	937.76	Zero Gas	0	2	0	1		
		Upscale	620	619	612		615.5	945.14
3 Run 1	680.78	Zero Gas	0	0	-3	-1.5		
		Upscale	620	612	607		609.5	692.90
4		Zero Gas	0	-3				
		Upscale	620	607				
5		Zero Gas	0					
		Upscale	620	614				
6 VOID	1206.81	Zero Gas	0	0	-3	-1.5		
		Upscale	620	612	615		613.5	1218.13
7 Run 1 3-20-96	1201.38	Zero Gas	0	4	4	4		
		Upscale	620	624	620		622	1201.51
8 Run 3	1121.67	Zero Gas	0	4	3	3.5		
		Upscale	620	620	613		616.5	1130.53
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

CO averages should be taken from I.G.S.
located on strip chart

INTERPOLL LABORATORIES, INC

(612) 786-6020

CO₂ Cal Drift Check

Job

L.P. / Hayward, W

Source

No. 2 Core Dryer

Test

7 Run 1,2,3,4,5 Date 3-19-96

Site

DIST

Operator

M. Laehler

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	0.0			XXXX	
		Upscale	10.9	10.9		XXXX		
2 VOID	4.94	Zero Gas	0	0.0	0.2	0.1	XXXX	4.93
		Upscale	10.9	10.8	10.8	XXXX	10.8	
3 RUN1	4.54	Zero Gas	0	0.2	0.3	0.25	XXXX	4.48
		Upscale	10.9	10.3	10.8	XXXX	10.9	
4		Zero Gas	0	0.3			XXXX	
		Upscale	10.9	11.1		XXXX		
5		Zero Gas	0	-0.1			XXXX	
		Upscale	10.9	10.8		XXXX		
6 VOID	3.49	Zero Gas	0	0.0	0.0	0.0	XXXX	3.49
		Upscale	10.9	10.9	10.9	XXXX	10.9	
7 3-20-96	5.02	Zero Gas	0	0.0	-0.1	-0.05	XXXX	5.05
		Upscale	10.9	11.0	10.8	XXXX	10.9	
8 RUN3	5.09	Zero Gas	0	0.0	0.0	0.0	XXXX	5.11
		Upscale	10.9	10.8	10.9	XXXX	10.85	
9		Zero Gas	0				XXXX	
		Upscale				XXXX		
10		Zero Gas	0				XXXX	
		Upscale				XXXX		
11		Zero Gas	0				XXXX	
		Upscale				XXXX		
12		Zero Gas	0				XXXX	
		Upscale				XXXX		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

O₂ Cal Drift Check

Job

L.P. / Hayward, WI

Source

No. 2 Core Driller

Test

7 Run 1, 2, 3, 4, 5 Date 7-19-96

Site

Duct

Operator

M. K. L. L. L.

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	0.0				
		Upscale	13.5	13.5				
<u>2</u> VOID	16.00	Zero Gas	0	0.0	0.0	0.0		16.72
		Upscale	13.5	13.4	13.4		13.4	
<u>3</u> RUN 1	16.32	Zero Gas	0	0.0	0.1	0.05		16.39
		Upscale	13.5	13.4	13.5		13.45	
4		Zero Gas	0	0.1				
		Upscale	13.5	13.5				
5		Zero Gas	0	0.0				
		Upscale	13.5	13.5				
<u>6</u> VOID	12.90	Zero Gas	0	0.0	-0.1	-0.05		13.00
		Upscale	13.5	13.4	13.4		13.4	
<u>7</u> RUN 2 3-20-96	15.92	Zero Gas	0	0.0	0.0	0.0		15.70
		Upscale	13.5	13.6	13.6		13.6	
<u>8</u> RUN 3	15.92	Zero Gas	0	0.0	0.0	0.0		15.86
		Upscale	13.5	13.6	13.5		13.5	
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

TIC Cal Drift Check

Job L.P. / Hayward, WI
Test 2 Run 1, 2, 3, 4, 5 Date 3-19-96
Operator M. Kachner

Source No. 2 Case-Dryer
Site Duct

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	0				
		Upscale	299	301				
2		Zero Gas	0	.3	5.4			
		Upscale	299	300	291			
3		Zero Gas	0	.5	.3			
		Upscale	299	291	284			
4		Zero Gas	0	.3				
		Upscale	299	297				
5		Zero Gas	0	2.0				
		Upscale	299	301				
6 VOID		Zero Gas	0	.3	-5			
		Upscale	299	300				
7 3-20-96		Zero Gas	0	.5	5			
		Upscale	299	305	298			
8		Zero Gas	0	1	2			
		Upscale	299	298	312			
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

NOX Cal Drift Check

Job

LP-HAYWARD

Test

8

Run

Date

3-19-96

Source

LINE 2 SURFACE DRYER

Site

PACT

Operator

ET

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_m	C_{gas}
				Initial	Final			
1 VOID		Zero Gas	0	0	0		XXXX	
		Upscale	239	240	240	XXXX		
2 RUN 1	29.9	Zero Gas	0	0	0		XXXX	30.0
		Upscale	73.7	74	73	XXXX		
3 VOID		Zero Gas	0	0	0		XXXX	
		Upscale	73.7	73	74	XXXX		
4 RUN 2	30.3	Zero Gas	0	0	0		XXXX	30.2
		Upscale	73.7	74	74	XXXX		
5 RUN 3	31.9	Zero Gas	0	0	0		XXXX	31.8
		Upscale	73.7	74	74.7	XXXX		
6		Zero Gas	0	0	0		XXXX	
		Upscale	73.7	74.7	76	XXXX		
7		Zero Gas	0	0	0		XXXX	
		Upscale	73.7	76	73	XXXX		
8		Zero Gas	0	0	0		XXXX	
		Upscale	73.7	73	73	XXXX		
9		Zero Gas	0				XXXX	
		Upscale				XXXX		
10		Zero Gas	0				XXXX	
		Upscale				XXXX		
11		Zero Gas	0				XXXX	
		Upscale				XXXX		
12		Zero Gas	0				XXXX	
		Upscale				XXXX		

Must be within 5% of the span for the zero or upscale cal. gas.

THC Cal Drift Check

Job

1P/HAYWARD

Test

8

Run

Date

3-19-96

Source

LINE 2 SURFACE DRYER

Site

DUCT

Operator

ET

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C ₀	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	0	0		██████	
		Upscale	299	300	300	██████		
2		Zero Gas	0	0	0		██████	
		Upscale	294	300	300	██████		
3		Zero Gas	0	10	0		██████	
		Upscale	294	300	300	██████		
4		Zero Gas	0	0	0		██████	
		Upscale	299	300	300	██████		
5		Zero Gas	0	0	0		██████	
		Upscale	299	300	300	██████		
6		Zero Gas	0	0	1		██████	
		Upscale	299	300	300	██████		
7		Zero Gas	0	1	0		██████	
		Upscale	299	300	300	██████		
8		Zero Gas	0	0	0		██████	
		Upscale	299	300	300	██████		
9		Zero Gas	0	0	0		██████	
		Upscale	299	300	298	██████		
10		Zero Gas	0	0	0		██████	
		Upscale	299	298	299	██████		
11		Zero Gas	0				██████	
		Upscale				██████		
12		Zero Gas	0				██████	
		Upscale				██████		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

ALL System Bias Check

Job

LP/HAYWARD

Source

LINE 2 SURFACE DRYER

Test

8

Run

Date 3-15-96

Site

Operator

ET

Instrument	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		Diff. CE-SB (PPM)	Span Val. (PPM)	% of Span
			Cal. Err.	Sys. Bias			
<u>NOX</u>	Zero Gas	0	0	0	0	1000	
	Upscale	239	239	240	1	1000	
<u>CO</u>	Zero Gas	0	0	0		1000	
	Upscale	620	620	620		1000	
<u>THC</u>	Zero Gas	0	0	0	0	1000	0
	Upscale	299	300	300	0	1000	0
<u>NOX</u>	Zero Gas	0	0	0	0	100	0
	Upscale	73.7	74	74	0	100	0
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						
	Zero Gas	0					
	Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

070595-G:\STACK\WP\FORMS\5-562

Calibration Error Check

Job

Test

Operator

1 P/HAYWARD
8 Run Date 3-18-96

SO₂ Calibration:Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	Ø				
Mid Level					
High Level					

NO₂ Calibration:Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	Ø	0	0	1000	0
Mid Level	239	240	1	1000	.1
High Level	458	462	2	1000	.2

O₂ Calibration:Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	Ø				
Mid Level					
High Level					

CO₂ CalibrationTime (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	Ø				
Mid Level					
High Level					

CO Calibration

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	Ø				
Mid Level					
High Level					

INTERPOL LABORATORIES, INC

(612) 786-6020

EPA Method 25 A

Calibration Error Check & Drift Determination

Job

LP/HAYWARD

Test

8

Run

Date 3-19-96

Operator

ET

THC Calibration (Low Range):

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0	0	1000	0
Low Level	30	29	1	100	1
Mid Level	299	300	1	1000	1.1
High Level	3150	3100	50	10,000	0.5

THC Calibration (High Range):

Time (HRS)

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0				
Span					

O₂ Calibration:

Time (HRS)

***	Cylinder Value (%)	Analyzer Response (%)	Difference (%)	Span Value (%)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

CO₂ Calibration:

Time: (HRS)

***	Cylinder Value (%)	Analyzer Response (%)	Difference (%)	Span Value (%)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

Must be within 2% of the span for each calibration gas.

052394-G:\STACK\WP\FORMS\S-420-14

(612) 786-6020

Drawing of Test Site

Cross-section View	Elevation View
-------------------------------	---------------------------

[illegible]

032594-G:\STACK\WPI\FORMS\S-392.1

INTERPOLL LABORATORIES, INC

(612) 786-6020

NOX Cal Drift Check

Job

LP/MAYWOOD

Source

LINE 2 PRESSURE RTD

Test

11 Run 1-3 Date 3-20-96

Site

STALN

Operator

S. BAINBRIDGE

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_m	C_{gas}
				Initial	Final			
1	24.2	Zero Gas	0	0	3.38	1.68	██████	22.4
		Upscale	145	145	149.4	██████	142.2	
2	22.5	Zero Gas	0	1.42	4	2.71	██████	20.3
		Upscale	145	146.7	148.5	██████	146.6	
3	19.1	Zero Gas	0	2	0	1	██████	18.5
		Upscale	145	145	140	██████	142.5	
4		Zero Gas	0				██████	
		Upscale				██████		
5		Zero Gas	0				██████	
		Upscale				██████		
6		Zero Gas	0				██████	
		Upscale				██████		
7		Zero Gas	0				██████	
		Upscale				██████		
8		Zero Gas	0				██████	
		Upscale				██████		
9		Zero Gas	0				██████	
		Upscale				██████		
10		Zero Gas	0				██████	
		Upscale				██████		
11		Zero Gas	0				██████	
		Upscale				██████		
12		Zero Gas	0				██████	
		Upscale				██████		

Must be within 5% of the span for the zero or upscale cal. gas.

1650
1750
1815
1930
2015
2115

INTERPOL LABORATORIES, INC

(612) 786-6020

CO Cal Drift Check

Job

LP HAYWARD

Test

11 Run 1-3 Date 3-20-26

Source

LINEZ PRESS VENT RTD

Operator

B. BAIN

Site

STARK

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_m	C_{gas}
				Initial	Final			
1	18.1	Zero Gas	0	0	-1	-1.5	XXXX	18.6
		Upscale	299	299	296.4	XXXX	292.7	
2	21.3	Zero Gas	0	.5	0	.25	XXXX	21.4
		Upscale	299	296.4	292	XXXX	294.2	
3	19.6	Zero Gas	0	0	0	0	XXXX	19.7
		Upscale	299	299.5	295	XXXX	297	
4		Zero Gas	0				XXXX	
		Upscale				XXXX		
5		Zero Gas	0				XXXX	
		Upscale				XXXX		
6		Zero Gas	0				XXXX	
		Upscale				XXXX		
7		Zero Gas	0				XXXX	
		Upscale				XXXX		
8		Zero Gas	0				XXXX	
		Upscale				XXXX		
9		Zero Gas	0				XXXX	
		Upscale				XXXX		
10		Zero Gas	0				XXXX	
		Upscale				XXXX		
11		Zero Gas	0				XXXX	
		Upscale				XXXX		
12		Zero Gas	0				XXXX	
		Upscale				XXXX		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

02 Cal Drift Check

Job

LPHAY WARD

Source

Line 2 Press Vents RTU

Test

11 Run 1-3 Date 3-20-96

Site

STACK

Operator

J BAEUVALE

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_m	C_{gas}
				Initial	Final			
1		Zero Gas	0	0	.03	.02	XXXX	
		Upscale	13.1	13.1	13.26	XXXX	13.18	
2		Zero Gas	0	.03	.2	.12	XXXX	
		Upscale	13.1	13.19	13.19	XXXX	13.19	
3		Zero Gas	0	.2	0	.1	XXXX	
		Upscale	13.1	13.19	13.1	XXXX	13.15	
4		Zero Gas	0				XXXX	
		Upscale				XXXX		
5		Zero Gas	0				XXXX	
		Upscale				XXXX		
6		Zero Gas	0				XXXX	
		Upscale				XXXX		
7		Zero Gas	0				XXXX	
		Upscale				XXXX		
8		Zero Gas	0				XXXX	
		Upscale				XXXX		
9		Zero Gas	0				XXXX	
		Upscale				XXXX		
10		Zero Gas	0				XXXX	
		Upscale				XXXX		
11		Zero Gas	0				XXXX	
		Upscale				XXXX		
12		Zero Gas	0				XXXX	
		Upscale				XXXX		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOL LABORATORIES, INC

(612) 786-6020

CO₂ Cal Drift Check

Job

LP MAYWOOD

Test

11 Run 1-3Date 3-20-96

Source

LEUC 2 PRESS VENT RTO

Operator

S. BASINUM

Site

STACK

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C ₀	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	0	.04	.02	████	
		Upscale	10.5	10.5	10.43	████	10.47	
2		Zero Gas	0	.04	.03	.04	████	
		Upscale	10.5	10.45	10.4	████	10.43	
3		Zero Gas	0	.03	0	.02	████	
		Upscale	10.5	10.45	10.4	████	10.43	
4		Zero Gas	0				████	
		Upscale				████		
5		Zero Gas	0				████	
		Upscale				████		
6		Zero Gas	0				████	
		Upscale				████		
7		Zero Gas	0				████	
		Upscale				████		
8		Zero Gas	0				████	
		Upscale				████		
9		Zero Gas	0				████	
		Upscale				████		
10		Zero Gas	0				████	
		Upscale				████		
11		Zero Gas	0				████	
		Upscale				████		
12		Zero Gas	0				████	
		Upscale				████		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

THE Cal Drift Check

Job

LP HAY WARD

Source

LINE 2 PRESS VENT MTD

Test

11 Run 1-3Date 3-20-96

Site

STALC

Operator

B BARNHART

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	0	0	0	██████	
		Upscale	30	30	29	██████	29.5	
2		Zero Gas	0	0	1	.5	██████	
		Upscale	30	29	29	██████	29	
3		Zero Gas	0	0	0	0	██████	
		Upscale	30	30	30	██████	30	
4		Zero Gas	0				██████	
		Upscale				██████		
5		Zero Gas	0				██████	
		Upscale				██████		
6		Zero Gas	0				██████	
		Upscale				██████		
7		Zero Gas	0				██████	
		Upscale				██████		
8		Zero Gas	0				██████	
		Upscale				██████		
9		Zero Gas	0				██████	
		Upscale				██████		
10		Zero Gas	0				██████	
		Upscale				██████		
11		Zero Gas	0				██████	
		Upscale				██████		
12		Zero Gas	0				██████	
		Upscale				██████		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC.
(6120 786-6020)

EPA Method 6C/7E Response Time

Job LP MAYWOOD
Source LEAD DRYER RTD STACK
Date of Test 3-19-96

Technician S. BIRNILLÉ
System Flow Rate 1 l/min

Moisture removal: Via Model MK-1 Condenser

	Response Time (secs)		
Analyzer Type	SO ₂ /NO _x	O ₂	CO ₂
Analyzer S/N			
Analyzer Range			
High Level Span Gas Conc. (PPM or %)			
Upscale 1			
Upscale 2			
Upscale 3			
Average			
Downscale 1			
Downscale 2			
Downscale 3			
Average			

System response time 60 seconds

1. Introduce gases at the 3-way valve on the probe. Use zero and stack gas for the upscale tests and high-level span gas and stack gas for the downscale tests. Alternatively, use zero and high-level gases for a more stringent test. Record the time in seconds from the moment of introduction until a stable response is achieved.
2. The response time test need only be conducted prior to the initial field use of the measurement system.
3. Attach a copy of the flow system schematic to this test.

INTERPOL LABORATORIES, INC

(612) 786-6020

NOx Cal Drift Check

Job

LP-Hayward

Source

Line 2 Pressurant RTO

Test

12 Run 1-3 Date 3-20-96

Site

Inlet

Operator

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1	2.1	Zero Gas	0	0	0	0	██████	1.9
		Upscale	73.7	79	80	██████	79.5	
2	2.7	Zero Gas	0	0	0	0	██████	2.5
		Upscale	73.7	80	78	██████	79	
3	3.1	Zero Gas	0	0	0	0	██████	2.9
		Upscale	73.7	78	78	██████	78	
4		Zero Gas	0				██████	
		Upscale				██████		
5		Zero Gas	0				██████	
		Upscale				██████		
6		Zero Gas	0				██████	
		Upscale				██████		
7		Zero Gas	0				██████	
		Upscale				██████		
8		Zero Gas	0				██████	
		Upscale				██████		
9		Zero Gas	0				██████	
		Upscale				██████		
10		Zero Gas	0				██████	
		Upscale				██████		
11		Zero Gas	0				██████	
		Upscale				██████		
12		Zero Gas	0				██████	
		Upscale				██████		

Must be within 5% of the span for the zero or upscale cal. gas.

CO

Cal Drift Check

Job

Test

Operator

L.P. Hayward
12 Run 1-3 Date 3-20-96

Source

Site

Line 2 Press Vent RTD
Inlet

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C ₀	C _m	C _{gas}
				Initial	Final			
1	10.7	Zero Gas	0	0	0	0	██████	10.7
		Upscale	150	150	150	██████	150	
2	8.2	Zero Gas	0	0	0	0	██████	8.2
		Upscale	150	150	150	██████	150	
3	13.4	Zero Gas	0	0	0	0	██████	13.4
		Upscale	150	150	150	██████	150	
4		Zero Gas	0				██████	
		Upscale				██████		
5		Zero Gas	0				██████	
		Upscale				██████		
6		Zero Gas	0				██████	
		Upscale				██████		
7		Zero Gas	0				██████	
		Upscale				██████		
8		Zero Gas	0				██████	
		Upscale				██████		
9		Zero Gas	0				██████	
		Upscale				██████		
10		Zero Gas	0				██████	
		Upscale				██████		
11		Zero Gas	0				██████	
		Upscale				██████		
12		Zero Gas	0				██████	
		Upscale				██████		

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

THC's Cal Drift Check

Job

Test

Operator

LP Hayward
12 Run 1-3 Date 3-20-96

Source

Site

Line 2 PressVent RTO
Inlet

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _o	C _m	C _{gas}
				Initial	Final			
1		Zero Gas	0	0	0	0	XXXX	
		Upscale	299	299	299	XXXX	299	
2		Zero Gas	0	0	0	0	XXXX	
		Upscale	299	299	299	XXXX	299	
3		Zero Gas	0	0	0	0	XXXX	
		Upscale	299	299	299	XXXX	299	
4		Zero Gas	0				XXXX	
		Upscale				XXXX		
5		Zero Gas	0				XXXX	
		Upscale				XXXX		
6		Zero Gas	0				XXXX	
		Upscale				XXXX		
7		Zero Gas	0				XXXX	
		Upscale				XXXX		
8		Zero Gas	0				XXXX	
		Upscale				XXXX		
9		Zero Gas	0				XXXX	
		Upscale				XXXX		
10		Zero Gas	0				XXXX	
		Upscale				XXXX		
11		Zero Gas	0				XXXX	
		Upscale				XXXX		
12		Zero Gas	0				XXXX	
		Upscale				XXXX		

Must be within 5% of the span for the zero or upscale cal. gas.

Calibration Error Check

Job LP Hayward No 2 Korus
 Test 16 Run _____ Date 3/18/96
 Operator RPI RA

SO₂ Calibration:

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0				
Mid Level					
High Level					

NO_x Calibration:

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0		250	
Mid Level	73.7	74.74		250	
High Level	148	147.85		250	

O₂ Calibration:

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0		25	
Mid Level	13.45	13.50		25	
High Level	20.8	20.77		25	

CO₂ Calibration

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	0		20	
Mid Level	10.95	11.00		20	
High Level	17.2	17.04	.16	20	

CO Calibration

Time (HRS) _____

***	Cylinder Value (PPM)	Analyzer Response (PPM)	Difference (PPM)	Span Value (PPM)	Percent of Span
Zero Gas	0	8.0		2000	
Mid Level	296	296.39		2000	
High Level	593	581		2000	

INTERPOLL LABORATORIES, INC.
(6120 786-6020)

EPA Method 6C/7E Response Time

Job L.P. / Hagerman, WI
Source Core Dryer / Duct
Date of Test 3-19-96

Technician Mark Boehle
System Flow Rate 4000 PC/min

Moisture removal: Via Model MK-1 Condenser

	Response Time (secs)		
Analyzer Type	SO ₂ /NO _x	O ₂	CO ₂
Analyzer S/N			
Analyzer Range			
High Level Span Gas Conc. (PPM or %)	239	13.5	13.5
Upscale 1	45.3	50.1	50.7
Upscale 2	40.2	50.9	50.2
Upscale 3	47.9	43.9	44.5
Average	44.43	48.27	48.47
Downscale 1	48.4	47.5	48.3
Downscale 2	51.3	48.1	45.2
Downscale 3	53.3	44.2	49.7
Average	51.17	46.60	47.73

System response time 46.44 seconds 23.22 seconds

1. Introduce gases at the 3-way valve on the probe. Use zero and stack gas for the upscale tests and high-level span gas and stack gas for the downscale tests. Alternatively, use zero and high-level gases for a more stringent test. Record the time in seconds from the moment of introduction until a stable response is achieved.
2. The response time test need only be conducted prior to the initial field use of the measurement system.
3. Attach a copy of the flow system schematic to this test.

INTERPOL LABORATORIES, INC
(612) 786-6020

Nox Cal Drift Check

Job

Test

Operator

LP/HAYWARD

16 Run

Date 3-18-96

Source

Site

No. 2 Korus

STACK

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_o	C_m	C_{gas}
				Initial	Final			
1	60.92	Zero Gas	0	0	0			60.8
		Upscale	73.7	74.74	72.96			
2	62.6	Zero Gas	0	0	0			62.6
		Upscale	73.7	72.96	74.36			
3	63.5	Zero Gas	0	0	0			62.9
		Upscale	73.7	74.36	74.38			
4		Zero Gas	0					
		Upscale						
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

0945
114
1200
135
1405

INTERPOL LABORATORIES, INC

(612) 786-6020

CO

Cal Drift Check

Job

LP / Hayward

Source

No. 2 KONUS

Test

16 RunDate 3-10-96

Site

STACK

Operator

RR / RA

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _g	C _m	C _{gas}
				Initial	Final			
1	157.1	Zero Gas	0	8.0	3.91			156.0
		Upscale	593	581	580			
2	281.3	Zero Gas	0	3.91	6.02			289.0
		Upscale	593	573	571			
3	206.7	Zero Gas	0	6.02	4.31			210.1
		Upscale	593	571	577			
4		Zero Gas	0					
		Upscale						
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

CO₂ Cal Drift Check

Job

Test

Operator

LP-Hayward76

Run

Date

3/18/96

Source

Site

No. 2 KONUSStack

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C _s	C _m	C _{gas}
				Initial	Final			
1	5.37	Zero Gas	0	0	.03			5.34
		Upscale	10.95	11.00	10.98			
2	6.15	Zero Gas	0	.03	.03			6.13
		Upscale	10.95	10.98	10.94			
3	6.31	Zero Gas	0	.03	.01			6.33
		Upscale	10.95	10.94	10.86			
4		Zero Gas	0					
		Upscale						
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

INTERPOLL LABORATORIES, INC

(612) 786-6020

02 Cal Drift Check

Job

Test

Operator

LP-Hayward16 RunDate 3-18-96

Source

Site

No. 2 kerosStack

Run	$\bar{C}$	***	Cylinder Value (PPM)	Analyzer Resp (PPM)		C_0	C_m	C_{gas}
				Initial	Final			
1	15.5	Zero Gas	0	0	.40			15.3
		Upscale	13.45	13.50	13.83			
2	13.8	Zero Gas	0	.01	.05			13.8
		Upscale	13.45	13.48	13.45			
3	13.4	Zero Gas	0	.05	.23			13.4
		Upscale	13.45	13.45	13.52			
4		Zero Gas	0					
		Upscale						
5		Zero Gas	0					
		Upscale						
6		Zero Gas	0					
		Upscale						
7		Zero Gas	0					
		Upscale						
8		Zero Gas	0					
		Upscale						
9		Zero Gas	0					
		Upscale						
10		Zero Gas	0					
		Upscale						
11		Zero Gas	0					
		Upscale						
12		Zero Gas	0					
		Upscale						

Must be within 5% of the span for the zero or upscale cal. gas.

APPENDIX H

GAS ANALYZER SPECIFICATIONS

Servomex

INTERPOL LABORATORIES
4500 BALL ROAD N.E.
CIRCLE PINES, MN 55014-1819
(612) 786-6020

1420 Oxygen Analyser Instruction Manual

Ref : 01420/001A/0

Order as part No. 01420001A

was (7982-2842)

INTERPOL LABORATORIES
4500 BALL ROAD N.E.
CIRCLE PINES, MN 55014-1819
(612) 786-6020

1.3 Sampling System

The sampling system of the analyser includes a combination filter/automatic flow control device, designed to keep a constant flow of sample gas through the measuring cell for varying input pressures and to prevent the entrance of particulate matter into the measuring cell. Excess flow is vented to the by-pass.

1.4 Specification

Performance Specification (typical)

Repeatability: Better than $\pm 0.2\%$ O₂ under constant conditions.

Drift: Less than 0.2% O₂ per week under constant conditions. (Excluding variation due to barometric pressure changes; reading is proportional to barometric pressure.)

Outputs

Display: 3 1/2 digit LCD reading 0.0 to 100.0% oxygen with overrange capability.

Output: 0 to 1V (non-isolated) for 0 to 100% oxygen available on 'D' type connector located on the back panel of the instrument. Output impedance is less than 10 ohms.

Option: 4 - 20mA isolated, Max impedance 500 ohms.

Flow alarm output: Change over relay contact rated at 3A/115V ac, 1A/240V ac or 1A/28V dc. 4 sets of single pole changeover contacts. Alarm becomes active when sample gas flow through the analyser fails.

Sample requirements

Condition: Clean, dry gas with dew point 5 deg C below ambient temperature.

Inlet pressure: 0.5 to 3psig (3.5 to 21kPa). Inlet pressure changes within this range will change the reading by less than 0.1% O₂. May be operated up to 10psig (70kPa) with degraded stability.

Flowrate: 1.5 to 6 litres/minute approximately depending on sample pressure.

Filtering: 0.6 micron replaceable filter integral to the automatic flow control device.

Response time: Less than 15 secs. to 90% at an inlet pressure of 3psig (21kPa).

Inlet/vent connections: 1/4 inch OD tube (stainless steel) suitable for 6mm ID flexible tubing or 1/4 inch OD compression fittings.

Materials exposed to the sample: Stainless steel, Pyrex glass, brass, platinum, epoxy resin, Viton, polypropylene and glass fibre filter.

Physical Characteristics

Case: Steel and aluminium finished in epoxy powder paint.

Case classification: IP 20 (IEC 529) when fitted into the Servomex 1400 series 19 inch case.

Dimensions: See Figure 2.1.

Weight: 10Kg (22lb) approximately.

Electrical

AC Supply: 110 to 120V AC or 220 to 240V AC, +/-10%, 48 to 62Hz. Voltage selected by a voltage selector integral to the IEC supply plug.

Power required: 15VA maximum.

Environmental Limits

Operating ambient temperature: 0 to +40 deg C (32 to 104 deg F)

Storage temp. range: -20 to +70 deg C (-4 to 158 deg F)

Relative humidity: 0-85%, non-condensing.

SPECIFICATIONS FOR ACS MODEL 3300 CO₂ NDIR

Measuring principle	NDIR single beam method
Measurable gas components and measuring range	0 - 20%
Reproducibility	±0.5% of full scale
Stability	Zero drift; ±% of full scale/24H Span drift; ±% of full scale/24H
Noise	0.5% of full scale
Ambient temperature	-5 to 45°C
Ambient humidity	Less than 90% RH
Response time (90% of final reading)	Electrical system; 2 sec, 3 sec, 5 sec (selectable with connector) Response of actual gas; Within 15 sec (depending on cell length)
Indicator	100 linear division
Output signal	OUTPUT 1; DC 0 - 1 V OUTPUT 2; DC 0 - 10 mV or DC 0 - 100 mV or DC 0 - 1 V or DC 4 - 20 mA (Allowable load resistance 500Ω max.)
Linearity	Better than ±2% of full scale (when linearizer is used)
Power supply	AC 115 V ± 10%, 60 Hz

Power consumption	Approx. 30 VA
Materials of gas- contacting parts	Measuring cell; SUS304 Window; CaF ₂ Piping; Polyethylene
Sample gas flow rate	1ℓ/min ± 0.5ℓ/min
Sample gas temperature	0 to 55°C
Purging gas flow rate	1ℓ/min (to be flowed as occasion demands)
Warmup time	Approx. 2 hours
External dimensions	200 x 250 x 541 (H x W x D) mm
Weight	Approx. 11 kg
Finish Color	MUNSELL N1.5
Remarks:	For combinations of measuring ranges for the dualcomponent analyzer, inquiry should be made to the manufacturer.

SPECIFICATIONS FOR MODEL 10A
ROCK MOUNTED CHEMILUMINESCENT
NO-NO_x GAS ANALYZER

Sensitivity	Each instrument is equipped with the following ranges: 0 - 2.5 ppm 0 - 10 ppm 0 - 25 ppm 0 - 100 ppm 0 - 250 ppm 0 - 1000 ppm 0 - 2500 ppm 0 - 10000 ppm
Accuracy	Derived from the NO or NO ₂ calibration gas, $\pm 1\%$ of fullscale
Response time (0-90%) Typical	1.5 seconds - NO Mode 1.7 seconds - NO _x Mode
Output	0 - 10mV and 0 - 10V
Zero Drift	Negligible after 1/2-hour warm-up
Linearity	$\pm 1\%$ of full scale
Input Power Requirements	115v/50Hz; 115v/60Hz

SPECIFICATIONS FOR ACS MODEL 3300 CO NDIR

Measuring principle	NDIR single beam method
Operating ranges	0 - 500 ppm 0 - 1000 ppm
Reproducibility	$\pm 0.5\%$ of full scale
Stability	Zero drift; $\pm 1\%$ of full scale/24H Span drift; $\pm 1\%$ of full scale/24H
Noise	0.5% of full scale
Ambient temperature	-5 to 45°C
Ambient humidity	Less than 90% RH
Response time (90% of final reading)	Electrical system; 2 sec, 3 sec, 5 sec (selectable with connector) Response of actual gas; Within 15 sec (depending on cell length)
Indicator	100 linear division
Output signal	OUTPUT 1; DC 0 - 1 V OUTPUT 2; DC 0 - 10 mV or DC 0 - 100 mV or DC 0 - 1 V or DC 4 - 20 mA (Allowable load resistance 500 Ω max.)
Linearity	Better than $\pm 2\%$ of full scale (when linearizer is used)
Power supply	AC 115 V $\pm 10\%$, 60 Hz

Power consumption	Approx. 30 VA
Materials of gas- contacting parts	Measuring cell; SUS304 Window; CaF ₂ Piping; Polyethylene
Sample gas flow rate	1ℓ/min ± 0.5ℓ/min
Sample gas temperature	0 to 55°C
Purging gas flow rate	1ℓ/min (to be flowed as occasion demands)
Warmup time	Approx. 2 hours
External dimensions	200 x 250 x 541 (H x W x D) mm
Weight	Approx. 11 kg
Finish Color	MUNSELL N1.5
Remarks:	For combinations of measuring ranges for the dualcomponent analyzer, inquiry should be made to the manufacturer.



TOTAL HYDROCARBON ANALYZER (FLAME IONIZATION)
Model RS 55

TECHNICAL DATA

MAINS : 115V/60H

RECORDER OUTPUT : 0 - 5 V / 4-20mA

MODEL: ☒ Manual switching
 ☐ Solenoid valves

HOUSING: ☐ Case, ☐ 19"-Rack

MEASURING RANGES:	1 = 0 - 10	C ₁ -
	2 = 0 - 100	C ₁
	3 = 0 - 1,000	C ₁
	4 = 0 - 10,000	C ₁

SPECIAL OPTIONS :

.. Flame out alarm

.. 1 Alarm

.. Sample line

.....

ANALYZER CONDITIONS:

Temperature : ..160.°C

Zero Point : ..3,90...

Gain :7,70.....

Pressure Setting: Sample/Spangas/Zerogas: 200 mbar


Fuel: Hydrogen :... ..0,35 bar


Combustion Air :0,80 bar

Span Gases : ..300. ppm C₁

24.000. ppm C₁

CALIBRATION DIAGRAMM






- 1 Inlet regulator
- 2 Pressure regulator
- 3 Manometer
- 4 Gauge
- 5 Zündventil/ Ignition valve
- 6 Needle valve
- 7 3 way valve
- 8 Turbine
- 9 Capillary
- 10 Magnetron
- 11 Solenoid valve
- 12 Pump
- 13 Fuel direct regulator
- 14 Fuel pressure regulator

Zündventil/
Ignition valve
P-A angled
engaged
P-A stop
of test

Handumrüstung
Manual switching




FLAMMEN IONISATIONS DETECTOR
Flame Ionization detector

Flame photo
Flame detector

AS SS

13.01.18

CEM TRAILER



E = EXHAUST
FC = FLOW CONTROL
I = IMPINGER (METHOD 10a)

CEMTRAIL

APPENDIX I

CALIBRATION GAS CERTIFICATION SHEETS

NATIONAL SPECIALTY GASES
630 UNITED DRIVE
DURHAM, NC 27713
(919)544-3772

CERTIFICATE OF ANALYSIS-EPA PROTOCOL MIXTURES

REFERENCE #: 88-40607 CYLINDER #:CC46348 CYL. PRESSURE:2000PSIG
EXPIRATION DATE: 6/2/98 LAST ANALYSIS DATE:6/2/95
CUSTOMER: TWIN CITY OXYGEN P.O.# 17405

METHOD: ANALYZED ACCORDING TO EPA TRACEABILITY PROTOCOL FOR ASSAY AND CERTIFICATION
OF GASEOUS CALIBRATION STANDARDS-SEPTEMBER 1993-G-1.
THIS STANDARD SHOULD NOT BE USED WHEN ITS GAS PRESSURE IS BELOW 1.0
MEGAPASCALS (150 PSIG).

STANDARD:	INSTRUMENT:BECKMAN NDIR BECKMAN PARAMAGNETIC
SRM #: 1675B 2659A	MODEL #:880 755
CYL #: CLM6413 CLM6737	SERIAL #-2000418 1001419
CONC.: 14.01% 20.72%	LAST CAL.:5/22/95 6/1/95

COMPONENT:CO2	COMPONENT: O2	COMPONENT:
MEAN CONC:16.8%	MEAN CONC: 21.0%	MEAN CONC:
REPLICATE CONC.	REPLICATE CONC.	REPLICATE CONC.
DATE:6/2/95 DATE:	DATE:6/2/95 DATE:	DATE: DATE:
16.8%	21.0%	
16.8%	21.0%	
16.9%	21.1%	

BALANCE GAS:N2

REPLICATE DATA

DATE: 6/2/95

Z	0	R	168.0	C	201.5
R	168.5	Z	0	C	202.1
Z	0	C	203.9	R	169.0

COMPONENT:CO2

DATE:

Z		R		C
R		Z		C
Z		C		R

REPLICATE DATA

DATE: 6/2/95

Z	0	R	210.0	C	212.8
R	210.5	Z	0	C	213.0
Z	0	C	214.9	R	211.0

COMPONENT:O2

DATE:

Z		R		C
R		Z		C
Z		C		R

REPLICATE DATA

DATE:

Z		R		C
R		Z		C
Z		C		R

COMPONENT:

DATE:

Z		R		C
R		Z		C
Z		C		R

Z=ZERO C=CANDIDATE R=REFERENCE

ANALYST: *Mary A. Savage*

APPROVED BY: *Jana Rowe*

"THIS REPORT STATED ACCURATELY THE RESULTS OF THE INVESTIGATION MADE UPON THE MATERIAL SUBMITTED TO THE ANALYTICAL LABORATORY. EVERY EFFORT HAS BEEN MADE TO DETERMINE OBJECTIVELY, THE INFORMATION REQUESTED; HOWEVER, IN CONNECTION WITH ITS RENDERING OF THIS REPORT, NATIONAL SPECIALTY GASES SHALL HAVE NO LIABILITY IN EXCESS OF ITS ESTABLISHED CHARGE FOR THE SERVICE."

NATIONAL SPECIALTY GASES

630 UNITED DRIVE

DURHAM, NC

27713

(919)544-3772

CERTIFICATE OF ANALYSIS EPA PROTOCOL MIXTURES

REFERENCE #:	88-44358	CYLINDER #:	GC117373	CYL. PRESSURE:	2000 PSIG	P. O. CODE #	20388
EXP. DATE:	11/30/98	LAST ANALYSIS DATE:	11/30/95	CUSTOMER:	TWIN CITY OXYGEN		
METHOD: ANALYZED ACCORDING TO EPA TRACEABILITY PROTOCOL FOR ASSAY AND CERTIFICATION OF GASEOUS CALIBRATION STANDARDS-SEPTEMBER 1993-G-1 THIS STANDARD SHOULD NOT BE USED WHEN ITS GAS PRESSURE IS BELOW 1.0 MEGAPASCALS (150 PSIG).							

COMPONENT:	CARBON MONOXIDE
STANDARD	
SRM #:	1681B
CYL. #:	GC117373
CONC:	975 PPM
INSTRUMENT:	ROSEMOUNT NDIR
MODEL #:	880A
SERIAL #:	2000172
LAST CAL.:	11/8/95

MEAN CONC.:	600 PPM	+/-	4.80 PPM
REPLICATE CONC.			
DATE:	11/23/95	DATE:	11/30/95
600 PPM		599 PPM	
600 PPM		599 PPM	
600 PPM		600 PPM	

BALANCE GAS: NITROGEN			
REPLICATE DATA		REPLICATE DATA	
DATE:	11/23/95		
Z 0	R 975	C 600.0	
R 975	Z 0	C 600.0	
Z 0	C 600.6	R 976	
DATE:	11/30/95		
Z 0	R 974	C 598.4	
R 974	Z 0	C 598.4	
Z 0	C 600.0	R 975	

ANALYST: *Wally A. Sawyer*

Z= ZERO C=CANDIDATE R=REFERENCE

APPROVED BY: *Jim Moore*

THIS REPORT STANDS AS A TESTIMONY TO THE ACCURACY OF THE ANALYSIS. THE RESULTS OF THIS INVESTIGATION MADE UPON THE MATERIAL SUBMITTED TO THE ANALYTICAL LABORATORY. EVERY EFFORT HAS BEEN MADE TO DETERMINE THE QUALITY OF THE INFORMATION REQUESTED. (DOWNEY, IN CONNECTION WITH THIS REPORT, NATIONAL SPECIALTY GASES SHALL HAVE NO LIABILITY IN EXCESS OF ITS ESTABLISHED CHARGE FOR THE SERVICE ASSAYED AT: NATIONAL SPECIALTY GASES, 630 UNITED DRIVE, DURHAM, NC 27713. (919)544-3772

INTERPOL LABORATORIES, INC.
(612) 786-6020

Certificate of Analysis for Standard Gas

Vendor Air Products
Cylinder No. SG 916 8051
Date of Preparation 4-5-96 12-11-95
Label Nitric Oxide
Blend Specification 240 ppm Balance N₂

Results of Analysis of Standard Gas			
Date of Analysis	Run	NO _x	
4-5-96	1	236.1781	
4-5-96	2	235.1613	
4-5-96	3	236.5035	
	4		
	5		
	6		
	Avg	235.6143	-1.82%

Analyst Bob A

- ☒ Results are within 2% of the vendor tag value; use tag value.
- ☐ Results are not within 2% of the vendor tag value; conduct another set of triplicate analyses.
- ☐ All results within $\pm 2\%$ of the average; relabel as above.
- ☐ All results not within $\pm 2\%$ of the average; perform another set of triplicate analyses.

Date: April 5, 1996
Approved by: [Signature]

012696-G:STACKWPF:FORMSS-425

INTERPOL LABS

TANK CERT
TANK NUMBER SG9168051
4/5/96

4/5/96	11:32:00 AM			
0	236.768	0	0	0
4/5/96	11:32:06 AM			
0	237.175	0	0	0
4/5/96	11:32:12 AM			
0	237.175	0	0	0
4/5/96	11:32:18 AM			
0	237.175	0	0	0
4/5/96	11:32:24 AM			
0	236.768	0	0	0
4/5/96	11:32:30 AM			
0	236.361	0	0	0
4/5/96	11:32:36 AM			
0	236.361	0	0	0
4/5/96	11:32:42 AM			
0	236.768	0	0	0
4/5/96	11:32:48 AM			
0	235.141	0	0	0
4/5/96	11:32:54 AM			
0	235.954	0	0	0
4/5/96	11:33:00 AM			
0	235.548	0	0	0
4/5/96	11:33:06 AM			
0	235.548	0	0	0
4/5/96	11:33:12 AM			
0	236.768	0	0	0
4/5/96	11:33:18 AM			
0	235.141	0	0	0
4/5/96	11:33:24 AM			
0	235.548	0	0	0
4/5/96	11:33:30 AM			
0	235.954	0	0	0
4/5/96	11:33:36 AM			
0	235.954	0	0	0
4/5/96	11:33:42 AM			
0	235.954	0	0	0
4/5/96	11:33:48 AM			
0	235.548	0	0	0
4/5/96	11:33:54 AM			
0	235.954	0	0	0

236.17815

INTERPOL LABS

TANK CERT
TANK NUMBER SQ9168051
4/5/96

4/5/96	11:39:00 AM			
0	235.141	0	0	0
4/5/96	11:39:06 AM			
0	235.141	0	0	0
4/5/96	11:39:12 AM			
0	235.141	0	0	0
4/5/96	11:39:18 AM			
0	235.141	0	0	0
4/5/96	11:39:24 AM			
0	235.141	0	0	0
4/5/96	11:39:30 AM			
0	235.141	0	0	0
4/5/96	11:39:36 AM			
0	235.548	0	0	0
4/5/96	11:39:42 AM			
0	235.141	0	0	0
4/5/96	11:39:48 AM			
0	234.734	0	0	0
4/5/96	11:39:54 AM			
0	235.141	0	0	0
4/5/96	11:40:00 AM			
0	234.734	0	0	0
4/5/96	11:40:06 AM			
0	235.548	0	0	0
4/5/96	11:40:12 AM			
0	235.141	0	0	0
4/5/96	11:40:18 AM			
0	235.548	0	0	0
4/5/96	11:40:24 AM			
0	234.734	0	0	0
4/5/96	11:40:30 AM			
0	235.141	0	0	0
4/5/96	11:40:36 AM			
0	235.141	0	0	0
4/5/96	11:40:42 AM			
0	235.141	0	0	0
4/5/96	11:40:48 AM			
0	235.548	0	0	0
4/5/96	11:40:54 AM			
0	235.141	0	0	0

235.16135

INTERPOLL LABS

TANK CERT
TANK NUMBER SG9168061
4/5/96

4/5/96	11:46:01 AM			
0	235.954	0	0	0
4/5/96	11:46:07 AM			
0	235.954	0	0	0
4/5/96	11:46:13 AM			
0	236.361	0	0	0
4/5/96	11:46:19 AM			
0	235.954	0	0	0
4/5/96	11:46:25 AM			
0	236.361	0	0	0
4/5/96	11:46:31 AM			
0	236.361	0	0	0
4/5/96	11:46:37 AM			
0	235.954	0	0	0
4/5/96	11:46:43 AM			
0	235.548	0	0	0
4/5/96	11:46:49 AM			
0	236.361	0	0	0
4/5/96	11:46:55 AM			
0	236.361	0	0	0
4/5/96	11:47:01 AM			
0	237.175	0	0	0
4/5/96	11:47:07 AM			
0	236.768	0	0	0
4/5/96	11:47:13 AM			
0	236.768	0	0	0
4/5/96	11:47:19 AM			
0	236.768	0	0	0
4/5/96	11:47:25 AM			
0	237.175	0	0	0
4/5/96	11:47:31 AM			
0	236.768	0	0	0
4/5/96	11:47:37 AM			
0	237.175	0	0	0
4/5/96	11:47:43 AM			
0	236.768	0	0	0
4/5/96	11:47:48 AM			
0	236.768	0	0	0
4/5/96	11:47:55 AM			
0	236.768	0	0	0

236.5035

Air Quality Inc
SPECIALT AS DEPARTMENT
12722 S. WENTWORTH AVENUE
CHICAGO, IL 60628

Certificate of Analysis - EPA Protocol Gas Standard

Page 1 of 1

PERFORMED ACCORDING TO EPA TRACEABILITY PROTOCOL FOR ASSAY AND CERTIFICATION OF GASEOUS CALIBRATION STANDARDS (PROCEDURE #G1)

Customer:

AIR PRODUCTS & CHEMICALS, INC.
373 CANTERBURY ROAD
SHAKOPEE MN 55379

Notes:

PO: Rel:

*** Certified Concentration ***
Certified

Component Concentration Cylinder #
NITRIC OXIDE 240 ±1.0 PPM SG9151438BAL GNIS

Balance Gas: NITROGEN

Contaminant

Nitrogen Dioxide 3.80 PPM

***** Reference Standards *****
Standard

Concentration Make/Model
244.8000 PPM Rosemount 951a 0101877

Instrument Serial Last
Analytical Instrumentation ***** Measurement

Number Calibration Principal
11/20/95 CHEMILUMINESCENCE

Order No:
Batch No:

CSS-320132-01
861-29294

Cylinder No: SG9168051BAL
Cylinder Pressure*: 2000 psig
Certification Date: 12/11/95
Expiration Date: 12/11/97


* Standard should not be used below 150 psig


Analyst:

Joe Estafanous

Approved By:


Richard Fry





APPENDIX J

PROCEDURES



Particulate Loading and Emission Rates

The particulate emission rates were determined per EPA Methods 1 - 5, CFR Title 40, Part 60, Appendix A (revised July 1, 1992). In this procedure, a preliminary velocity profile of the gases in the flue is obtained by means of a temperature and velocity traverse. On the basis of these values, sampling nozzles of appropriate diameter are selected to allow isokinetic sampling, a necessary prerequisite for obtaining a representative sample.

The sampling train consists of a heated glass or stainless steel-lined sampling probe equipped with a Type S pitot and a thermocouple. The probe is attached to a sampling module which houses the all-glass in line filter holder in a temperature controlled oven. In addition, the sampling module also houses the impinger case and a Drierite drying column. The sampling module is connected by means of an umbilical cord to the control module which houses the dry test gas meter, the calibrated orifice, a leakless pump, two inclined manometers, and all controls required for operating the sampling train.

Particulate samples were collected as follows: The sample gas was drawn in through the sampling probe isokinetically and passed through a 4-inch diameter Gelman Type AE glass fiber filter. The particulates were removed at this point and collected on the filter. The gases then passed through an ice-cooled impinger train and a desiccant-packed drying column which quantitatively absorb all moisture from the sample gas stream after which the sample gas passes through the pump and the dry test gas meter which integrates the sample gas flow throughout the course of the test. A calibrated orifice attached to the outlet of the gas meter provides instantaneous flow rate data.

A representative particulate sample was acquired by sampling for equal periods of time at the centroid of a number of equal area regions in the duct. The sampling rate is adjusted at each site such that an isokinetic sampling condition prevails. Nomographs are used to aid in the rapid determination of the sampling rate.

Particulate Loading and Emission Rates

After sampling is complete, the filter is removed and placed in a clean container. The nozzle and inlet side of the filter holder are quantitatively washed with acetone and the washings are stored in a second container. A brush is often used in the cleaning step to help dislodge deposits. The samples are returned to the laboratory where they are logged in and analyzed. The volume of the acetone rinse ("probe wash") is noted and then the rinse is quantitatively transferred to a tared 120 cc porcelain evaporating dish and the acetone evaporated off at 97-105 °F. This temperature is used to prevent condensation of atmospheric moisture due to the cooling effect induced by the evaporation of acetone. The acetone-free sample is then transferred to an oven and dried at 105 °C for 30 minutes, cooled in a desiccator over Drierite, and then weighed to the nearest .01 mg. The filter sample is quantitatively transferred to a 6-inch watch glass and dried in an oven at 105 °C for two hours. The filter and watch glass are then cooled in a desiccator and the filter weighed to the nearest .01 mg. All weighings are performed in a balance room where the relative humidity is hydrostatted to less than 50% relative humidity. Microscopic examination of the samples is performed if any unusual characteristics are observed. The weight of the acetone rinse is corrected for the acetone blank. The Drierite column is weighed on-site and the water collected by Drierite is added to the condensate so that the total amount of absorbed water may be ascertained.

Integrated flue gas samples for Orsat analysis were collected simultaneously with each pollutant sample. The samples were collected in 15-liter gas sampling bags at a constant flow rate throughout each particulate run. The bags were at a constant flow rate throughout each particulate run. The bags were then returned to the laboratory and analyzed by Orsat analysis. Standard commercially prepared solutions were used in the Orsat analyzer (sat. KOH for carbon dioxide and reduced methylene blue for oxygen).

Condensible Organic Compounds Analysis

(State of Wisconsin - EPA Method 5)

Method II-8672-WI

Equipment: Separatory funnel - 500 cc with Teflon stopcock

 Powder funnel - 75 mm ID with a glass wool plug

 Evaporating dish(es) - 200 cc or 250 cc beaker

Reagents: Methylene chloride

 Sodium sulfate - (ACS) granular anhydrous (purified by heating for four hours in a shallow tray)

SAMPLING

An all-glass impinger assembly is used in the back half of the EPA Method 5 sampling train when an organic wet catch is to be collected. The impinger assembly consists of a modified impinger, a Greenburg Smith impinger followed by another modified impinger. The third impinger should have a temperature measuring device at the outlet upstream of a final impinger or desiccant column to monitor the temperature of the outlet gas stream. Prior to the start of the test, each of the first two impingers should be charged with 100 g of Class I water. The Method 5 train should be operated as provided for in EPA Method 5. Ice should be added to the impinger bath to keep the temperature of the gas at the outlet at or less than 68°F. After the post test leak check, the impinger train is removed and impinger contents poured into a tared all-glass sample bottle and closed with a Teflon-lined cap. The sample bottle is then weighed and the total condensate calculated by subtraction of the bottle tare weight and the weight of initial water added to the impingers (200 g). A label is affixed and the sample is returned to the laboratory for analysis. The sample should be stored at 4°C if the analysis is not conducted within 48 hours.

030894-G:\STACK\WP\METHODS\II-8672.WI

ANALYSIS

1. Sample bottles are removed from storage and the contents quantitatively transferred to a clean 500 cc separatory funnel equipped with a Teflon stopcock.
2. Rinse the sample container with distilled water and add to separatory funnel.
3. Then rinse the sample container with acetone and pour through sodium sulfate into a tare beaker marked A.
4. The sample is then extracted consecutively with three 50 cc aliquots of methylene chloride. The extraction is performed according to normal laboratory practice observing the customary safety precaution of releasing excess pressure after each shaking.
5. After each of the three extractions are completed, the organic solvent should be dried by passing it through a funnel containing anhydrous sodium sulfate and collecting it and two 50 cc rinses in the tared beaker marked A (the same one used to catch the acetone container rinse).
6. Evaporate to dryness in a hood at 70°F or less. Do not evaporate so quickly as to allow evaporative cooling to lower the temperature of the container below the dew point otherwise water will be condensed in the container.
7. Desiccate for two hours in a sealed desiccator and final weigh. Report all results in grams. All weighings should be made to nearest 0.1 mg (four places).
8. The remaining liquid in the separatory funnel is then transferred to a tared beaker marked B and is evaporated to dryness at $220^{\circ}\text{F} \pm 10^{\circ}\text{F}$. The analyst may take an aliquot of the sample, transferring it to a tared beaker and evaporate to dryness at $220^{\circ}\text{F} \pm 10^{\circ}\text{F}$. If an aliquot is used, the weight of the sample and aliquot will have to be taken to correct for the total sample weight.

030894-G:STACK\WP\METHODS\I-8672.WI

9. After the drying step, the sample is cooled in a desiccator and weighted to a constant weight to the nearest 0.1 mg.


Calculation (if aliquot is taken):

$$\text{grams} = \frac{(\text{grams recovered from aliquot}) \times (\text{total volume (ml) or grams of sample})}{(\text{aliquot volume (ml) or grams used})}$$

If volume is used, it must be used for both the aliquot and sample. The same goes for using weight.

10. A field blank should be analyzed in an identical manner. If a field blank is not submitted, take an aliquot of Class I water equal in volume to the samples and analyze in a similar manner.
11. The results for container A are to be marked in the organic section of Interpoll Form #LSC-03G.
12. The results for container B are to be marked in the inorganic section of Interpoll Form #LSC-03G.

PARTICULATE SAMPLING TRAIN



Method 3A—Determination of Oxygen and Carbon Dioxide Concentrations in Emissions From Stationary Sources (Instrumental Analyzer Procedure)

1. Applicability and Principle

1.1 Applicability. This method is applicable to the determination of oxygen (O_2) and carbon dioxide (CO_2) concentrations in emissions from stationary sources only when specified within the regulations.

1.2 Principle. A sample is continuously extracted from the effluent stream: a portion of the sample stream is conveyed to an instrumental analyzer(s) for determination of O_2 and CO_2 concentration(s). Performance specifications and test procedures are provided to ensure reliable data.

2. Range and Sensitivity

Same as Method 6C, Sections 2.1 and 2.2, except that the span of the monitoring system shall be selected such that the average O_2 or CO_2 concentration is not less than 20 percent of the span.

3. Definitions

3.1 Measurement System. The total equipment required for the determination of the O_2 or CO_2 concentration. The measurement system consists of the same major subsystems as defined in Method 6C, Sections 3.1.1, 3.1.2, and 3.1.3.

3.2 Span, Calibration Gas, Analyzer Calibration Error, Sampling System Bias, Zero Drift, Calibration Drift, Response Time, and Calibration Curve. Same as Method 6C, Sections 3.2 through 3.8, and 3.10.

3.3 Interference Response. The output response of the measurement system to a component in the sample gas, other than the gas component being measured.

4. Measurement System Performance Specifications

Same as Method 6C, Sections 4.1 through 4.4.

5. Apparatus and Reagents

5.1 Measurement System. Any measurement system for O_2 or CO_2 that meets the specifications of this method. A schematic of an acceptable measurement system is shown in Figure 6C-1 of Method 6C. The essential components of the measurement system are described below:

5.1.1 Sample Probe. A leak-free probe, of sufficient length to traverse the sample points.

5.1.2 Sample Line. Tubing, to transport the sample gas from the probe to the moisture removal system. A heated sample line is not required for systems that measure the O_2 or CO_2 concentration on a dry basis, or transport dry gases.

5.1.3 Sample Transport Line, Calibration Value Assembly, Moisture Removal System, Particulate Filter, Sample Pump, Sample Flow Rate Control, Sample Gas Manifold, and Data Recorder. Same as Method 6C, Sections 5.1.3 through 5.1.9, and 5.1.11, except that the requirements to use stainless steel, Teflon, and nonreactive glass filters do not apply.

5.1.4 Gas Analyzer. An analyzer to determine continuously the O₂ or CO₂ concentration in the sample gas stream. The analyzer shall meet the applicable performance specifications of Section 4. A means of controlling the analyzer flow rate and a device for determining proper sample flow rate (e.g., precision rotameter, pressure gauge downstream of all flow controls, etc.) shall be provided at the analyzer. The requirements for measuring and controlling the analyzer flow rate are not applicable if data are presented that demonstrate the analyzer is insensitive to flow variations over the range encountered during the test.

5.2 Calibration Gases. The calibration gases for CO₂ analyzers shall be CO₂ in N₂ or CO₂ in air. Alternatively, CO₂/SO₂, O₂/SO₂, or O₂/CO₂/SO₂ gas mixtures in N₂ may be used. Three calibration gases, as specified Section 5.3.1 through 5.3.3 of Method 6C, shall be used. For O₂ monitors that cannot analyze zero gas, a calibration gas concentration equivalent to less than 10 percent of the span may be used in place of zero gas.

6. Measurement System Performance Test Procedures

Perform the following procedures before measurement of emissions (Section 7).

6.1 Calibration Concentration Verification. Follow Section 6.1 of Method 6C, except if calibration gas analysis is required, use Method 3 and change the acceptance criteria for agreement among Method 3 results to 5 percent (or 0.2 percent by volume, whichever is greater).

6.2 Interference Response. Conduct an interference response test of the analyzer prior to its initial use in the field. Thereafter, recheck the measurement system if changes are made in the instrumentation that could alter the interference response (e.g., changes in the type of gas detector). Conduct the interference response in accordance with Section 5.4 of Method 20.

6.3 Measurement System Preparation, Analyzer Calibration Error, and Sampling System Bias Check. Follow Sections 6.2 through 6.4 of Method 6C.

7. Emission Test Procedure

7.1 Selection of Sampling Site and Sampling Points. Select a measurement site and sampling points using the same criteria that are applicable to tests performed using Method 3.

7.2 Sample Collection. Position the sampling probe at the first measurement point, and begin sampling at the same rate as used during the sampling system bias check. Maintain constant rate sampling (i.e., ± 10 percent) during the entire run. The sampling time per run shall be the same as for tests conducted using Method 3 plus twice the system response time. For each run, use only those measurements obtained after twice the response time of the measurement system has elapsed to determine the average effluent concentration.

7.3 Zero and Calibration Drift Test. Follow Section 7.4 of Method 6C.

8. Quality Control Procedures

The following quality control procedures are recommended when the results of this method are used for an emission rate correction factor, or excess air determination. The tester should select one of the following options for validating measurement results:

8.1 If both O₂ and CO₂ are measured using Method 3A, the procedures described in Section 4.4 of Method 3 should be followed to validate the O₂ and CO₂ measurement results.

8.2 If only O₂ is measured using Method 3A, measurements of the sample stream CO₂ concentration should be obtained at the sample by-pass vent discharge using an Orsat or Fyrite analyzer, or equivalent. Duplicate samples should be obtained concurrent with at least one run. Average the duplicate Orsat or Fyrite analysis results for each run. Use the average CO₂ values for comparison with the O₂ measurements in accordance with the procedures described in Section 4.4 of Method 3.

8.3 If only CO₂ is measured using Method 3A, concurrent measurements of the sample stream CO₂ concentration should be obtained using an Orsat or Fyrite analyzer as described in Section 8.2. For each run, differences greater than 0.5 percent between the Method 3A results and the average of the duplicate Fyrite analysis should be investigated.

9. Emission Calculation

For all CO₂ analyzers, and for O₂ analyzers that can be calibrated with zero gas, follow Section 8 of Method 6C, except express all concentrations as percent, rather than ppm.

For O₂ analyzers that use a low-level calibration gas in place of a zero gas, calculate the effluent gas concentration using Equation 3A-1.

$$C_{gas} = \frac{C_{ma} - C_{oa}}{C_m - C_o} - (\bar{C} - C_m) + C_{ma} \text{ Eq. 3A-1}$$

Where:

C_{gas} = Effluent gas concentration, dry basis, percent.

C_{ma} = Actual concentration of the upscale calibration gas, percent.

C_{oa} = Actual concentration of the low-level calibration gas, percent.

C_m = Average of initial and final system calibration bias check responses for the upscale calibration gas, percent.

C_o = Average of initial and final system calibration bias check responses for the low-level gas, percent.

$\bar{C}$ = Average gas concentration indicated by the gas analyzer, dry basis, percent.

10. Bibliography

Same as bibliography of Method 6C.

Method 7E—Determination of Nitrogen Oxides Emissions From Stationary Sources (Instrumental Analyzer Procedure)

1. Applicability and Principle

1.1 **Applicability.** This method is applicable to the determination of nitrogen oxides (NO_x) concentrations in emissions from stationary sources only when specified within the regulations.

1.2 **Principle.** A gas sample is continuously extracted from a stack, and a portion of the sample is conveyed to an instrumental chemiluminescent analyzer for determination of NO_x concentration. Performance specifications and test procedures are provided to ensure reliable data.

2. Range and Sensitivity

Same as Method 6C, Sections 2.1 and 2.2.

3. Definitions

3.1 **Measurement System.** The total equipment required for the determination of NO_x concentration. The measurement system consists of the following major subsystems:

3.1.1 **Sample Interface, Gas Analyzer, and Data Recorder.** Same as Method 6C, Sections 3.1.1, 3.1.2, and 3.1.3.

3.1.2 **NO_2 to NO Converter.** A device that converts the nitrogen dioxide (NO_2) in the sample gas to nitrogen oxide (NO).

3.2 **Span, Calibration Gas, Analyzer Calibration Error, Sampling System Bias, Zero Drift, Calibration Drift, and Response Time.** Same as Method 6C, Sections 3.2 through 3.8.

3.3 **Interference Response.** The output response of the measurement system to a component in the sample gas, other than the gas component being measured.

4. Measurement System Performance Specifications

Same as Method 6C, Sections 4.1 through 4.4.

5. Apparatus and Reagents

5.1 **Measurement System.** Any measurement system for NO_x that meets the specifications of this method. A schematic of an acceptable measurement system is shown in Figure 6C-1 of Method 6C. The essential components of the measurement system are described below:

5.1.1 Sample Probe, Sample Line, Calibration Valve Assembly, Moisture Removal System, Particulate Filter, Sample Pump, Sample Flow Rate Control, Sample Gas Manifold, and Data Recorder. Same as Method 6C, Sections 5.1.1 through 5.1.9, and 5.1.11.

5.1.2 NO₂ to NO Converter. That portion of the system that converts the nitrogen dioxide (NO₂) in the sample gas to nitrogen oxide (NO). An NO₂ to NO converter is not necessary if data are presented to demonstrate that the NO₂ portion of the exhaust gas is less than 5 percent of the total NO_x concentration.

5.1.3 NO_x Analyzer. An analyzer based on the principles of chemiluminescence, to determine continuously the NO_x concentration in the sample gas stream. The analyzer shall meet the applicable performance specifications of Section 4. A means of controlling the analyzer flow rate and a device for determining proper sample flow rate (e.g., precision rotameter, pressure gauge downstream of all flow controls, etc.) shall be provided at the analyzer.

5.2 NO_x Calibration Gases. The calibration gases for the NO_x analyzer shall be NO in N₂. Three calibration gases, as specified in Sections 5.3.1 through 5.3.3. of Method 6C, shall be used. Ambient air may be used for the zero gas.

6. Measurement System Performance Test Procedures

Perform the following procedures before measurement of emissions (Section 7).

6.1 Calibration Gas Concentration Verification. Follow Section 6.1 of Method 6C, except if calibration gas analysis is required, use Method 7, and change all 5 percent performance values to 10 percent (or 10 PPM, whichever is greater).

6.2 Interference Response. Conduct an interference response test of the analyzer prior to its initial use in the field. Thereafter, recheck the measurement system if changes are made in the instrumentation that could alter the interference response (e.g., changes in the gas detector). Conduct the interference response in accordance with Section 5.4 of Method 20.

6.3 Measurement System Preparation, Analyzer Calibration Error, and Sample System Bias Check. Follow Sections 6.2 through 6.4 of Method 6C.

6.4 NO₂ to NO Conversion Efficiency. Unless data are presented to demonstrate that the NO₂ concentration within the sample stream is not greater than 5 percent of the NO_x concentration, conduct an NO₂ to NO conversion efficiency test in accordance with Section 5.6 of Method 20.

7. Emission Test Procedure

7.1 Selection of Sampling Site and Sampling Points. Select a measurement site and sampling points using the same criteria that are applicable to tests performed using Method 7.

7.2 Sample Collection. Position the sampling probe at the first measurement point, and begin sampling at the same rate as used during the system calibration drift test. Maintain constant rate sampling (i.e., ± 10 percent) during the entire run. The sampling time per run shall be the same as the total time required to perform a run using Method 7, plus twice the system response time. For each run, use only those measurements obtained after twice the response time of the measurement system has elapsed, to determine the average effluent concentration.

7.3 Zero and Calibration Drift Test. Follow Section 7.4 of Method 6C.

8. Emission Calculation

Follow Section 8 of Method 6C.

9. Bibliography

Same as bibliography of Method 6C.

Method 10—Determination of Carbon Monoxide Emissions From Stationary Sources

1. Principle and Applicability

1.1 Principle. An integrated or continuous gas sample is extracted from a sampling point and analyzed for carbon monoxide (CO) content using a Luft-type nondispersive infrared analyzer (NDIR) or equivalent.

1.2 Applicability. This method is applicable for the determination of carbon monoxide emissions from stationary sources only when specified by the test procedures for determining compliance with new source performance standards. The test procedure will indicate whether a continuous or an integrated sample is to be used.

2. Range and Sensitivity

2.1 Range. 0 to 1,000 PPM.

2.2 Sensitivity. Minimum detectable concentration is 20 PPM for a 0 to 1,000 PPM span.

3. Interferences

Any substance having a strong absorption of infrared energy will interfere to some extent. For example, discrimination ratios for water (H₂O) and carbon dioxide (CO₂) are 3.5 percent H₂O per 7 PPM CO and 10 percent CO₂ per 10 PPM CO, respectively, for devices measuring in the 1,500 to 3,000 PPM range. For devices measuring in the 0 to 100 PPM range, interference ratios can be as high as 3.5 percent H₂O per 25 PPM CO and 10 percent CO₂ per 50 PPM CO. The use of silica gel and ascarite traps will alleviate the major interference problems. The measured gas volume must be corrected if these traps are used.

4. Precision and Accuracy

4.1 Precision. The precision of most NDIR analyzers is approximately ± 2 percent of span.

4.2 Accuracy. The accuracy of most NDIR analyzers is approximately ± 5 percent of span after calibration.

5. Apparatus

5.1 Continuous Sample (Figure 10-1).

5.1.1 Probe. Stainless steel or sheathed Pyrex\1\ glass, equipped with a filter to remove particulate matter.

5.1.2 Air-Cooled Condenser or Equivalent. To remove any excess moisture.

5.2 Integrated Sample (Figure 10-2).

042694-G:\STACK\WPMETHODSS-METH.10

5.2.1 **Probe.** Stainless steel or sheathed Pyrex glass, equipped with a filter to remove particulate matter.

5.2.2 **Air-Cooled Condenser or Equivalent.** To remove any excess moisture.

5.2.3 **Valve.** Needle valve, or equivalent, to adjust flow rate.

5.2.4 **Pump.** Leak-free diaphragm type, or equivalent, to transport gas.

5.2.5 **Rate Meter.** Rotameter, or equivalent, to measure a flow range from 0 to 1.0 liter per min (0.035 cfm).

5.2.6 **Flexible Bag.** Tedlar, or equivalent, with a capacity of 60 to 90 liters (2 to 3 ft³). Leak-test the bag in the laboratory before using by evacuating bag with a pump followed by a dry gas meter. When evacuation is complete, there should be no flow through the meter.

5.2.7 **Pitot Tube.** Type S, or equivalent, attached to the probe so that the sampling rate can be regulated proportional to the stack gas velocity when velocity is varying with the time or a sample traverse is conducted.

5.3 Analysis (Figure 10-3).

5.3.1 **Carbon Monoxide Analyzer.** Nondispersive infrared spectrometer, or equivalent. This instrument should be demonstrated, preferably by the manufacturer, to meet or exceed manufacturer's specifications and those described in this method.

5.3.2 **Drying Tube.** To contain approximately 200 g of silica gel.

5.3.3 **Calibration Gas.** Refer to section 6.1.

5.3.4 **Filter.** As recommended by NDIR manufacturer.

|_See_CFR_paper_publication_for_illustration_18A

5.3.5 **CO₂ Removal Tube.** To contain approximately 500 g of ascarite.

5.3.6 **Ice Water Bath.** For ascarite and silica gel tubes.

5.3.7 **Valve.** Needle valve, or equivalent, to adjust flow rate

5.3.8 **Rate Meter.** Rotameter or equivalent to measure gas flow rate of 0 to 1.0 liter per min (0.035 cfm) through NDIR.

5.3.9 **Recorder (optional).** To provide permanent record of NDIR readings.

042694-G:STACKWPMETHODS-METH.10

6. Reagents

6.1 Calibration Gases. Known concentration of CO in nitrogen (N₂) for instrument span, prepurified grade of N₂ for zero, and two additional concentrations corresponding approximately to 60 percent and 30 percent span. The span concentration shall not exceed 1.5 times the applicable source performance standard. The calibration gases shall be certified by the manufacturer to be within ± 2 percent of the specified concentration.

|_See_CFR_paper_publication_for_illustration_19A

6.2 Silica Gel. Indicating type, 6 to 16 mesh, dried at 175°C (347°F) for 2 hours.

6.3 Ascarite. Commercially available.

7. Procedure

7.1 Sampling.

7.1.1 Continuous Sampling. Set up the equipment as shown in Figure 10-1 making sure all connections are leak free. Place the probe in the stack at a sampling point and purge the sampling line. Connect the analyzer and begin drawing sample into the analyzer. Allow 5 minutes for the system to stabilize, then record the analyzer reading as required by the test procedure. (See section 7.2 and 8). CO₂ content of the gas may be determined by using the Method 3 integrated sample procedure, or by weighing the ascarite CO₂ removal tube and computing CO₂ concentration from the gas volume sampled and the weight gain of the tube.

7.1.2 Integrated Sampling. Evacuate the flexible bag. Set up the equipment as shown in Figure 10-2 with the bag disconnected. Place the probe in the stack and purge the sampling line. Connect the bag, making sure that all connections are leak free. Sample at a rate proportional to the stack velocity. CO₂ content of the gas may be determined by using the Method 3 integrated sample procedures, or by weighing the ascarite CO₂ removal tube and computing CO₂ concentration from the gas volume sampled and the weight gain of the tube.

7.2 CO Analysis. Assemble the apparatus as shown in Figure 10-3, calibrate the instrument, and perform other required operations as described in section 8. Purge analyzer with N₂ prior to introduction of each sample. Direct the sample stream through the instrument for the test period, recording the readings. Check the zero and span again after the test to assure that any drift or malfunction is detected. Record the sample data on Table 10-1.

8. Calibration

Assemble the apparatus according to Figure 10-3. Generally an instrument requires a warm-up period before stability is obtained. Follow the manufacturer's instructions for specific procedure. Allow a minimum time of 1 hour for warm-up. During this time check the sample conditioning apparatus, i.e., filter, condenser, drying tube, and CO₂ removal tube, to ensure that each component is in good operating condition. Zero and calibrate the instrument according to the manufacturer's procedures using, respectively, nitrogen and the calibration gases.

Table 10-1—Field data

Comments _____	

Location _____	
Test _____	
Date _____	
Operator _____	

Clock time	Rotameter setting, liters per minute (cubic feet per minute)

9. Calculation

Calculate the concentration of carbon monoxide in the stack using Equation 10-1.

$$\text{CCO stack} = \text{CCO NDIR}(1 - \text{FCO}_2) \quad \text{Eq. 10-1}$$

Where:

CCO stack = Concentration of CO in stack, PPM by volume (dry basis).

CCO NDIR = Concentration of CO measured by NDIR analyzer, PPM by volume (dry basis).

FCO₂ = Volume fraction of CO₂ in sample, i.e., percent CO₂ from Orsat analysis divided by 100.

10. Alternative Procedures

10.1 Interference Trap. The sample conditioning system described in Method 10A, sections 2.1.2 and 4.2, may be used as an alternative to the silica gel and ascarite traps.

11. Bibliography

1. McElroy, Frank, The Intertech NDIR-CO Analyzer, Presented at 11th Methods Conference on Air Pollution, University of California, Berkeley, CA. April 1, 1970.
2. Jacobs, M. B., et al., Continuous Determination of Carbon Monoxide and Hydrocarbons in Air by a Modified Infrared Analyzer, J. Air Pollution Control Association, 9(2): 110-114. August 1959.
3. MSA LIRA Infrared Gas and Liquid Analyzer Instruction Book, Mine Safety Appliances Co., Technical Products Division, Pittsburgh, PA.
4. Models 215A, 315A, and 415A Infrared Analyzers, Beckman Instruments, Inc., Beckman Instructions 1635-8, Fullerton, CA. October 1967.
5. Continuous CO Monitoring System, Model A5611, Intertech Corp., Princeton, NJ.
6. UNOR Infrared Gas Analyzers, Bendix Corp., Ronceverte, WV

Agenda

A. Performance Specifications for NDIR Carbon Monoxide Analyzers

Range (minimum)	0—1000 PPM.
Output (minimum)	0—10mV.
Minimum detectable sensitivity	20 PPM.
Rise time, 90 percent (maximum)	30 seconds.
Fall time, 90 percent (maximum)	30 seconds.
Zero drift (maximum)	10% in 8 hours.
Span drift (maximum)	10% in 8 hours.
Precision (minimum)	± 2% of full scale.
Noise (maximum)	± 1% of full scale.
Linearity (maximum deviation)	2% of full scale.
Interference rejection ratio	CO ₂ —1000 to 1, H ₂ O—500 to 1.

B. Definitions of Performance Specifications.

Range—The minimum and maximum measurement limits.

Output—Electrical signal which is proportional to the measurement; intended for connection to readout or data processing devices. Usually expressed as millivolts or milliamps full scale at a given impedance.

Full scale—The maximum measuring limit for a given range.

Minimum detectable sensitivity—The smallest amount of input concentration that can be detected as the concentration approaches zero.

042694-G:STACKWPMETHODSS-METH.10

Accuracy—The degree of agreement between a measured value and the true value; usually expressed as $\pm$ percent of full scale.

Time to 90 percent response—The time interval from a step change in the input concentration at the instrument inlet to a reading of 90 percent of the ultimate recorded concentration.

Rise Time (90 percent)—The interval between initial response time and time to 90 percent response after a step increase in the inlet concentration.

Fall Time (90 percent)—The interval between initial response time and time to 90 percent response after a step decrease in the inlet concentration.

Zero Drift—The change in instrument output over a stated time period, usually 24 hours, of unadjusted continuous operation when the input concentration is zero; usually expressed as percent full scale.

Span Drift—The change in instrument output over a stated time period, usually 24 hours, of unadjusted continuous operation when the input concentration is a stated upscale value; usually expressed as percent full scale.

Precision—The degree of agreement between repeated measurements of the same concentration, expressed as the average deviation of the single results from the mean.

Noise—Spontaneous deviations from a mean output not caused by input concentration changes.

Linearity—The maximum deviation between an actual instrument reading and the reading predicted by a straight line drawn between upper and lower calibration points.

Method 10A—Determination of Carbon Monoxide Emissions in Certifying Continuous Emission Monitoring Systems at Petroleum Refineries

1. Applicability and Principle

1.1 Applicability. This method applies to the measurement of carbon monoxide (CO) at petroleum refineries. This method serves as the reference method in the relative accuracy test for nondispersive infrared (NDIR) CO continuous emission monitoring systems (CEMS's) that are required to be installed in petroleum refineries on fluid catalytic cracking unit catalyst regenerators [40 CFR Part 60.105(a)(2)].

1.2 Principle. An integrated gas sample is extracted from the stack, passed through an alkaline permanganate solution to remove sulfur and nitrogen oxides, and collected in a Tedlar bag. The CO concentration in the sample is measured spectrophotometrically using the reaction of CO with p-sulfaminobenzoic acid.

1.3. Range and Sensitivity.

1.3.1 Range. Approximately 3 to 1800 PPM CO. Samples having concentrations below 400 PPM are analyzed at 425 nm, and samples having concentrations above 400 PPM are analyzed at 600 nm.

1.3.2 Sensitivity. The detection limit is 3 PPM based on three times the standard deviation of the mean reagent blank values.

042694-G:\STACK\WPMETHODS-METH.10

7.4 Adsorption Tube Procedure (Alternative Procedure). It is suggested that the tester refer to the National Institute of Occupational Safety and Health (NIOSH) method for the particular organics to be sampled. The principal interferent will be water vapor. If water vapor is present at concentrations above 3 percent, silica gel should be used in front of the charcoal. Where more than one compound is present in the emissions, then develop relative adsorptive capacity information.

7.4.1 Additional Apparatus. In addition to the equipment listed in the NIOSH method for the particular organic(s) to be sampled, the following items (or equivalent) are suggested.

7.4.1.1 Probe (Optional). Borosilicate glass or stainless steel, approximately 6-mm ID, with a heating system if water condensation is a problem, and a filter (either in-stack or out-stack heated to stack temperature) to remove particulate matter. In most instances, a plug of glass wool is a satisfactory filter.

7.4.1.2 Flexible Tubing. To connect probe to adsorption tubes. Use a material that exhibits minimal sample adsorption.

7.4.1.3 Leakless Sample Pump. Flow controlled, constant rate pump, with a set of limiting (sonic) orifices to provide pumping rates from approximately 10 to 100 cc/min.

7.4.1.4 Bubble-Tube Flowmeter. Volume accuracy within ± 1 percent, to calibrate pump.

7.4.1.5 Stopwatch. To time sampling and pump rate calibration.

7.4.1.6 Adsorption Tubes. Similar to ones specified by NIOSH, except the amounts of adsorbent per primary/backup sections are 800/200 mg for charcoal tubes and 1040/260 mg for silica gel tubes. As an alternative, the tubes may contain a porous polymer adsorbent such as Tenax GC or XAD-2.

7.4.1.7 Barometer. Accurate to 5 mm Hg, to measure atmospheric pressure during sampling and pump calibration.

7.4.1.8 Rotameter. 0 to 100 cc/min, to detect changes in flow rate during sampling.

7.4.2 Sampling and Analysis. It is suggested that the tester follow the sampling and analysis portion of the respective NIOSH method section entitled "Procedure." Calibrate the pump and limiting orifice flow rate through adsorption tubes with the bubble tube flowmeter before sampling. The sample system can be operated as a "recirculating loop" for this operation. Record the ambient temperature and barometric pressure. Then, during sampling, use the ro-

METHOD 18—MEASUREMENT OF GASEOUS ORGANIC COMPOUND EMISSIONS BY GAS CHROMATOGRAPHY

tameter to verify that the pump and orifice sampling rate remains constant.

Use a sample probe, if required, to obtain the sample at the centroid of the duct, or at a point no closer to the walls than 1 m. Minimize the length of flexible tubing between the probe and adsorption tubes. Several adsorption tubes can be connected in series, if the extra adsorptive capacity is needed. Provide the gas sample to the sample system at a pressure sufficient for the limiting orifice to function as a sonic orifice. Record the total time and sample flow rate (or the number of pump strokes), the barometric pressure, and ambient temperature. Obtain a total sample volume commensurate with the expected concentration(s) of the volatile organic(s) present, and recommended sample loading factors (weight sample per weight adsorption media). Laboratory tests prior to actual sampling may be necessary to predetermine this volume. When more than one organic is present in the emissions, then develop relative adsorptive capacity information. If water vapor is present in the sample at concentrations above 2 to 3 percent, the adsorptive capacity may be severely reduced. Operate the gas chromatograph according to the manufacturer's instructions. After establishing optimum conditions, verify and document these conditions during all operations. Analyze the audit samples (see Section 7.4.4.3), then the emission samples. Repeat the analysis of each sample until the relative deviation of two consecutive injections does not exceed 5 percent.

7.4.3 Standards and Calibration. The standards can be prepared according to the respective NIOSH method. Use a minimum of three different standards; select the concentrations to bracket the expected average sample concentration. Perform the calibration before and after each day's sample analyses. Prepare the calibration curve by using the least squares method.

7.4.4 Quality Assurance.

7.4.4.1 Determination of Desorption Efficiency. During the testing program, determine the desorption efficiency in the expected sample concentration range for each batch of adsorption media to be used. Use an internal standard. A minimum desorption efficiency of 50 percent shall be obtained. Repeat the desorption determination until the relative deviation of two consecutive determinations does not exceed 5 percent. Use the average desorption efficiency of these two consecutive determinations for the correction specified in Section 7.4.4.5. If the desorption efficiency of the compound(s) of interest is questionable under actual sampling conditions, use of the Method of Standard Additions may be helpful to determine this value.

7.4.4.2 Determination of Sample Collection Efficiency. For the source samples, ana-

lyze the primary and backup portions of the adsorption tubes separately. If the backup portion exceeds 10 percent of the total amount (primary and backup), repeat the sampling with a larger sampling portion.

7.4.4.3 Analysis Audit. Immediately before the sample analyses, analyze the two audits in accordance with Section 7.4.2. The analysis audit shall agree with the audit concentration within 10 percent.

7.4.4.4 Pump Leak Checks and Volume Flow Rate Checks. Perform both of these checks immediately after sampling with all sampling train components in place. Perform all leak checks according to the manufacturer's instructions, and record the results. Use the bubble-tube flowmeter to measure the pump volume flow rate with the orifice used in the test sampling, and the result. If it has changed by more than 5 but less than 20 percent, calculate an average flow rate for the test. If the flow rate has changed by more than 20 percent, recalibrate the pump and repeat the sampling.

7.4.4.5 Calculations. All calculations can be performed according to the respective NIOSH method. Correct all sample volumes to standard conditions. If a sample dilution system has been used, multiply the results by the appropriate dilution ratio. Correct all results by dividing by the desorption efficiency (decimal value). Report results as ppm by volume, dry basis.

7.5 Reporting of Results. At the completion of the field analysis portion of the study, ensure that the data sheets shown in Figure 18-11 have been completed. Summarize this data on the data sheets shown in Figure 18-15.

8. Bibliography

1. American Society for Testing and Materials. C. Through C. Hydrocarbons in the Atmosphere by Gas Chromatography. ASTM D 2820-72, Part 23. Philadelphia, Pa. 23:950-958. 1973.
2. Corazon, V. V. Methodology for Collecting and Analyzing Organic Air Pollutants. U.S. Environmental Protection Agency. Publication No. EPA-600/2-79-042. February 1979.
3. Dravnieks, A., B. K. Krotoszynski, J. Whitfield, A. O'Donnell, and T. Burgwald. Environmental Science and Technology. 5(12):1200-1222. 1971.
4. Eggertsen, F. T., and F. M. Nelsen. Gas Chromatographic Analysis of Engine Exhaust and Atmosphere. Analytical Chemistry. 30(6): 1040-1043. 1958.
5. Fearheller, W. R., P. J. Marn, D. H. Harris, and D. L. Harris. Technical Manual for Process Sampling Strategies for Organic Materials. U.S. Environmental Protection Agency. Research Triangle Park, NC. Publication No. EPA 600/2-76-122. April 1976. 172 p.

Sampling Equipment. Environmental Protection Agency. Research Triangle Park, N.C. APTD-0576. March, 1972.

4. Smith, W. S., R. T. Shigehara, and W. F. Todd. A Method of Interpreting Stack Sampling Data. Paper Presented at the 63rd Annual Meeting of the Air Pollution Control Association, St. Louis, Mo. June 14-19, 1970.

5. Smith, W. S., et al., Stack Gas Sampling Improved and Simplified with New Equipment. APCA Paper No. 67-119. 1967.

6. Specifications for Incinerator Testing at Federal Facilities. PHS, NCAPC. 1967.

7. Shigehara, R. T., Adjustments in the EPA Nomograph for Different Pitot Tube Coefficients and Dry Molecular Weights. Stack Sampling News 2:4-11. October, 1974.

8. Vollaro, R. F., A Survey of Commercially Available Instrumentation for the Measurement of Low-Range Gas Velocities. U.S. Environmental Protection Agency, Emission Measurement Branch. Research Triangle Park, N.C. November, 1976 (unpublished paper).

9. Annual Book of ASTM Standards. Part 26. Gaseous Fuels; Coal and Coke; Atmospheric Analysis. American Society for Testing and Materials. Philadelphia, Pa. 1974. pp. 617-622.

10. Vollaro, R. F., Recommended Procedure for Sample Traverses in Ducts Smaller than 12 Inches in Diameter. U.S. Environmental Protection Agency, Emission Measurement Branch. Research Triangle Park, N.C. November, 1976.

METHOD 18—MEASUREMENT OF GASEOUS ORGANIC COMPOUND EMISSIONS BY GAS CHROMATOGRAPHY

Introduction

This method should not be attempted by persons unfamiliar with the performance characteristics of gas chromatography, nor by those persons who are unfamiliar with source sampling. Particular care should be exercised in the area of safety concerning choice of equipment and operation in potentially explosive atmospheres.

1. Applicability and Principle

1.1 Applicability. This method applies to the analysis of approximately 90 percent of the total gaseous organics emitted from an industrial source. It does not include techniques to identify and measure trace amounts of organic compounds, such as those found in building air and fugitive emission sources.

This method will not determine compounds that (1) are polymeric (high molecular weight), (2) can polymerize before analysis, or (3) have very low vapor pressures at stack or instrument conditions.

1.2 Principle.

The major organic components of a gas mixture are separated by gas chromatography (GC) and individually quantified by flame ionization, photoionization, electron capture, or other appropriate detection principles.

The retention times of each separated component are compared with those of known compounds under identical conditions. Therefore, the analyst confirms the identity and approximate concentrations of the organic emission components beforehand. With this information, the analyst then prepares or purchases commercially available standard mixtures to calibrate the GC under conditions identical to those of the samples. The analyst also determines the need for sample dilution to avoid detector saturation, gas stream filtration to eliminate particulate matter, and prevention of moisture condensation.

2. Range and Sensitivity

2.1 Range. The range of this method is from about 1 part per million (ppm) to the upper limit governed by GC detector saturation or column overloading. The upper limit can be extended by diluting the stack gases with an inert gas or by using smaller gas sampling loops.

2.2 Sensitivity. The sensitivity limit for a compound is defined as the minimum detectable concentration of that compound, or the concentration that produces a signal-to-noise ratio of three to one. The minimum detectable concentration is determined during the presurvey calibration for each compound.

3. Precision and Accuracy

Gas chromatographic techniques typically provide a precision of 5 to 10 percent relative standard deviation (RSD), but an experienced GC operator with a reliable instrument can readily achieve 5 percent RSD. For this method, the following combined GC/operator values are required.

(a) Precision. Duplicate analyses are within 5 percent of their mean value.

(b) Accuracy. Analysis results of prepared audit samples are within 10 percent of preparation values.

4. Interferences

Resolution interferences that may occur can be eliminated by appropriate GC column and detector choice or by shifting the retention times through changes in the column flow rate and the use of temperature programming.

The analytical system is demonstrated to be essentially free from contaminants by periodically analyzing blanks that consist of hydrocarbon-free air or nitrogen.

Sample cross-contamination that occurs when high-level and low-level samples or standards are analyzed alternately, is best

Method 25A-Determination of Total Gaseous Organic Concentration Using a Flame Ionization Analyzer

1. Applicability and Principle

1.1 Applicability. This method applies to the measurement of total gaseous organic concentration of vapors consisting primarily of alkanes, alkenes, and/or arenes (aromatic hydrocarbons). The concentration is expressed in terms of propane (or other appropriate organic calibration gas) or in terms of carbon.

1.2 Principle. A gas sample is extracted from the source through a heated sample line, if necessary, and glass fiber filter to a flame ionization analyzer (FIA). Results are reported as volume concentration equivalents of the calibration gas or as carbon equivalents.

2. Definitions

2.1 Measurement Systems. The total equipment required for the determination of the gas concentration. The system consists of the following major subsystems:

2.1.1 Sample Interface. That portion of the system that is used for one or more of the following: sample acquisition, sample transportation, sample conditioning, or protection of the analyzer from the effects of the stack effluent.

2.1.2 Organic Analyzer. That portion of the system that senses organic concentration and generates an output proportional to the gas concentration.

2.2 Span Value. The upper limit of a gas concentration measurement range that is specified for affected source categories in the applicable part of the regulations. The span value is established in the applicable regulation and is usually 1.5 to 2.5 times the applicable emission limit. If no span value is provided, use a span value equivalent to 1.5 to 2.5 times the expected concentration. For convenience, the span value should correspond to 100 percent of the recorder scale.

2.3 Calibration Gas. A known concentration of a gas in an appropriate diluent gas.

2.4 Zero Drift. The difference in the measurement system response to a zero level calibration gas before and after a stated period of operation during which no unscheduled maintenance, repair, or adjustment took place.

2.5 Calibration drift. The difference in the measurement system response to a midlevel calibration gas before and after a stated period of operation during which no unscheduled maintenance, repair or adjustment took place.

2.6 Response Time. The time interval from a step change in pollutant concentration at the inlet to the emission measurement system to the time at which 95 percent of the corresponding final value is reached as displayed on the recorder.

2.7 Calibration Error. The difference between the gas concentration indicated by the measurement system and the known concentration of the calibration gas.

3. Apparatus

A schematic of an acceptable measurement system is shown in Figure 25A-1. The essential components of the measurement system are described below:

3.1 Organic Concentration Analyzer. A flame ionization analyzer (FIA) capable of meeting or exceeding the specifications in this method.

3.2 Sample Probe. Stainless steel, or equivalent, three-hole rake type. Sample holes shall be 4 mm in diameter or smaller and located at 16.7, 50, and 83.3 percent of the equivalent stack diameter. Alternatively, a single opening probe may be used so that a gas sample is collected from the centrally located 10 percent area of the stack cross-section.

3.3 Sample Line. Stainless steel or Teflon * tubing to transport the sample gas to the analyzer. The sample line should be heated, if necessary, to prevent condensation in the line.

3.4 Calibration Valve Assembly. A three way valve assembly to direct the zero and calibration gases to the analyzers is recommended. Other methods, such as quick-connect lines, to route calibration gas to the analyzers are applicable.

3.5 Particulate Filter. An in-stack or an out-of-stack glass fiber filter is recommended if exhaust gas particulate loading is significant. An out-of-stack filter should be heated to prevent any condensation.

* Mention of trade names or specific products does not constitute endorsement by the Environmental Protection Agency.

3.6 Recorder. A strip-chart recorder, analog computer, or digital recorder for recording measurement data. The minimum data recording requirement is one measurement value per minute. Note: This method is often applied in highly explosive areas. Caution and care should be exercised in choice of equipment and installation.

4. Calibration and Other Gases.

Gases used for calibrations, fuel, and combustion air (if required) are contained in compressed gas cylinders. Preparation of calibration gases shall be done according to the procedure in Protocol No. 1, listed in Citation 2 of Bibliography. Additionally, the manufacturer of the cylinder should provide a recommended shelf life for each calibration gas cylinder over which the concentration does not change more than ± 2 percent from the certified value. For calibration gas values not generally available (i.e., organics between 1 and 10 percent by volume), alternative methods for preparing calibration gas mixtures, such as dilution systems, may be used with prior approval of the Administrator.

Calibration gases usually consist of propane in air or nitrogen and are determined in terms of the span value. Organic compounds other than propane can be used following the above guidelines and making the appropriate corrections for response factor.

4.1 **Fuel.** A 40 percent H₂/60 percent N₂ gas mixture is recommended to avoid an oxygen synergism effect that reportedly occurs when oxygen concentration varies significantly from a mean value.

4.2 **Zero Gas.** High purity air with less than 0.1 parts per million by volume (PPMv) of organic material (propane or carbon equivalent) or less than 0.1 percent of the span value, whichever is greater.

4.3 **Low-level Calibration Gas.** An organic calibration gas with a concentration equivalent to 25 to 35 percent of the applicable span value.

4.4 **Mid-level Calibration Gas.** An organic calibration gas with a concentration equivalent to 45 to 55 percent of the applicable span value.

4.5 **High-level Calibration Gas.** An organic calibration gas with a concentration equivalent to 80 to 90 percent of the applicable span value.

5. Measurement System Performance Specifications

5.1 **Zero Drift.** Less than ± 3 percent of the span value.

5.2 **Calibration Drift.** Less than ± 3 percent of span value.

5.3 **Calibration Error.** Less than ± 5 percent of the calibration gas value.

6. Pretest Preparations

6.1 **Selection of Sampling Site.** The location of the sampling site is generally specified by the applicable regulation or purpose of the test; i.e., exhaust stack, inlet line, etc. The sample port shall be located at least 1.5 meters or 2 equivalent diameters upstream of the gas discharge to the atmosphere.

6.2 **Location of Sample Probe.** Install the sample probe so that the probe is centrally located in the stack, pipe, or duct and is sealed tightly at the stack port connection.

6.3 **Measurement System Preparation.** Prior to the emission test, assemble the measurement system following the manufacturer's written instructions in preparing the sample interface and the organic analyzer. Make the system operable.

FIA equipment can be calibrated for almost any range of total organics concentrations. For high concentrations of organics (> 1.0 percent by volume as propane) modifications to most commonly available analyzers are necessary. One accepted method of equipment modification is to decrease the size of the sample to the analyzer through the use of a smaller diameter sample capillary. Direct and continuous measurement of organic concentration is a necessary consideration when determining any modification design.

6.4 Calibration Error Test. Immediately prior to the test series, (within 2 hours of the start of the test) introduce zero gas and high-level calibration gas at the calibration valve assembly. Adjust the analyzer output to the appropriate levels, if necessary. Calculate the predicted response for the low-level and mid-level gases based on a linear response line between the zero and high-level responses. Then introduce low-level and mid-level calibration gases successively to the measurement system. Record the analyzer responses for low-level and mid-level calibration gases and determine the differences between the measurement system responses and the predicted responses. These differences must be less than 5 percent of the respective calibration gas value. If not, the measurement system is not acceptable and must be replaced or repaired prior to testing. No adjustments to the measurement system shall be conducted after the calibration and before the drift check (Section 7.3). If adjustments are necessary before the completion of the test series, perform the drift checks prior to the required adjustments and repeat the calibration following the adjustments. If multiple electronic ranges are to be used, each additional range must be checked with a mid-level calibration gas to verify the multiplication factor.

6.5 Response Time Test. Introduce Zero gas into the measurement system at the calibration valve assembly. When the system output has stabilized, switch quickly to the high-level calibration gas. Record the time from the concentration change to the measurement system response equivalent to 95 percent of the step change. Repeat the test three times and average the results.

7. Emission Measurement Test Procedure

7.1 Organic Measurement. Begin sampling at the start of the test period, recording time and any required process information as appropriate. In particular, note on the recording chart periods of process interruption or cyclic operation.

7.2 Drift Determination. Immediately following the completion of the test period and hourly during the test period, reintroduce the zero and mid-level calibration gases, one at a time, to the measurement system at the calibration valve assembly. (Make no adjustments to the measurement system until after both the zero and calibration drift checks are made.) Record the analyzer response. If the drift values exceed the specified limits, invalidate the test results preceding the check and repeat the test following corrections to the measurement system. Alternatively, recalibrate the test measurement system as in Section 6.4 and report the results using both sets of calibration data (i.e., data determined prior to the test period and data determined following the test period).

8. Organic Concentration calculations

Determine the average organic concentration in terms of PPMv as propane or other calibration gas. The average shall be determined by the integration of the output recording over the period specified in the applicable regulation. If results are required in terms of PPMv as carbon, adjust measured concentrations using Equation 25A-1.

$$C_c = K C_{\text{meas}} \quad \text{Eq. 25A-1}$$

Where:

- C_c = Organic concentration as carbon, PPMv.
- C_{meas} = Organic concentration as measured, PPMv.
- K = Carbon equivalent correction factor.
 - $K = 2$ for ethane.
 - $K = 3$ for propane.
 - $K = 4$ for butane.
 - K = Appropriate response factor for other organic calibration gases.

9. Bibliography

1. Measurement of Volatile Organic Compounds-Guideline Series. U.S. Environmental Protection Agency. Research Triangle Park, NC. Publication No. EPA-450/2-78-041. June 1978. p. 46-54.
2. Traceability Protocol for Establishing True Concentrations of Gases Used for Calibration and Audits of Continuous Source Emission Monitors (Protocol No. 1). U.S. Environmental Protection Agency, Environmental Monitoring and Support Laboratory. Research Triangle Park, NC. June 1978.
3. Gasoline Vapor Emission Laboratory Evaluation-Part 2. U.S. Environmental Protection Agency, Office of Air Quality Planning and Standards. Research Triangle Park, NC. EMB Report No. 75-GAS-6. August 1975.

PHENOL

Phenol samples were collected using a Method 5 sampling train at 0.75 CFM using neutral-buffered absorbing reagent. The first impinger in each sampling was spiked with isotopically-labeled phenol (phenol- d_5) and 2-fluorophenol for sampling and recovery efficiency surrogates. The recovered samples were extracted and the extracts analyzed by GC/MS for phenol, phenol- d_5 , and 2-fluorophenol as per EPA Method 8270. The recoveries of phenol- d_5 and 2-fluorophenol were used to adjust the measured phenol concentrations.

SAMPLING FOR FORMALDEHYDE EMISSIONS FROM STATIONARY SOURCES JUL 16 1990

INTERPOLL LABORATORIES

1.0 SCOPE AND APPLICATION

1.1 This method is applicable to the determination of Destruction and Removal Efficiency (DRE) of formaldehyde, CAS Registry number 50-00-0, and possibly other aldehydes and ketones from stationary sources as specified in the regulations. The methodology has been applied specifically to formaldehyde; however, many laboratories have extended the application to other aldehydes and ketones. Compounds derivatized with 2,4-dinitrophenylhydrazine can be detected as low as 6.4×10^{-8} lbs/cu ft (1.8 ppbv) in stack gas over a 1 h sampling period, sampling approximately 45 cu ft.

2.0 SUMMARY OF METHOD

2.1 Gaseous and particulate pollutants are withdrawn isokinetically from an emission source and are collected in aqueous acidic 2,4-dinitrophenylhydrazine. Formaldehyde present in the emissions reacts with the 2,4-dinitrophenylhydrazine to form the formaldehyde dinitrophenylhydrazone derivative. The dinitrophenylhydrazone derivative is extracted, solvent-exchanged, concentrated, and then analyzed by high performance liquid chromatography.

3.0 INTERFERENCES

3.1 A decomposition product of 2,4-dinitrophenylhydrazine, 2,4-dinitroaniline, can be an analytical interferent if concentrations are high. 2,4-dinitroaniline can coelute with the 2,4-dinitrophenylhydrazone of formaldehyde under high performance liquid chromatography conditions which may be used for the analysis. High concentrations of highly oxygenated compounds, especially acetone, that have the same retention time or nearly the same retention time as the dinitrophenylhydrazone of formaldehyde and that also absorb at 360 nm will interfere with the analysis.

Formaldehyde, acetone, and 2,4-dinitroaniline contamination of the aqueous acidic 2,4-dinitrophenylhydrazine (DNPH) reagent is frequently encountered. The reagent must be prepared within five days of use in the field and must be stored in an uncontaminated environment both before and after sampling in order to minimize blank problems. Some level of acetone contamination is unavoidable, because acetone is ubiquitous in laboratory and field operations. However, the acetone contamination must be minimized.

4.0 APPARATUS AND MATERIALS

4.1 A schematic of the sampling train is shown in Figure 1. This sampling train configuration is adapted from EPA Method 5 procedures. The sampling train consists of the following components: Probe Nozzle, Pitot Tube, Differential Pressure Gauge, Metering System, Barometer, and Gas Density Determination Equipment.

4.1.1 Probe Nozzle: Quartz or glass with sharp, tapered (30° angle) leading edge. The taper shall be on the outside to preserve a constant inner diameter. The nozzle shall be buttonhook or elbow design. A range of nozzle sizes suitable

INTERPOLL LABORATORIES

4500 BALL ROAD N.E.

ALBUQUERQUE, NEW MEXICO 87110

for isokinetic sampling should be available in increments of 0.16 cm (1/16 in), e.g., 0.32 to 1.27 cm (1/8 to 1/2 in), or larger if higher volume sampling trains are used. Each nozzle shall be calibrated according to the procedures outlined in Section 8.1.

4.1.2 Probe Liner: Borosilicate glass or quartz shall be used for the probe liner. The tester should not allow the temperature in the probe to exceed $120 \pm 14^{\circ}\text{C}$ ($248 \pm 25^{\circ}\text{F}$).

4.1.3 Pitot Tube: The Pitot tube shall be Type S, as described in Section 2.1 of EPA Method 2, or any other appropriate device. The pitot tube shall be attached to the probe to allow constant monitoring of the stack gas velocity. The impact (high pressure) opening plane of the pitot tube shall be even with or above the nozzle entry plane (see EPA Method 2, Figure 2-6b) during sampling. The Type S pitot tube assembly shall have a known coefficient, determined as outlined in Section 4 of EPA Method 2.

4.1.4 Differential Pressure Gauge: The differential pressure gauge shall be an inclined manometer or equivalent device as described in Section 2.2 of EPA Method 2. One manometer shall be used for velocity-head readings and the other for orifice differential pressure readings.

4.1.5 Impingers: The sampling train requires a minimum of four impingers, connected as shown in Figure 1, with ground glass (or equivalent) vacuum-tight fittings. For the first, third, and fourth impingers, use the Greenburg-Smith design, modified by replacing the tip with a 1.3-cm inside diameter (1/2 in) glass tube extending to 1.3 cm (1/2 in) from the bottom of the flask. For the second impinger, use a Greenburg-Smith impinger with the standard tip. Place a thermometer capable of measuring temperature to within 1°C (2°F) at the outlet of the fourth impinger for monitoring purposes.

4.1.6 Metering System: The necessary components are a vacuum gauge, leak-free pump, thermometers capable of measuring temperature within 3°C (5.4°F), dry-gas meter capable of measuring volume to within 1%, and related equipment as shown in Figure 1. At a minimum, the pump should be capable of 4 cfm free flow, and the dry gas meter should have a recording capacity of 0-999.9 cu ft with a resolution of 0.005 cu ft. Other metering systems may be used which are capable of maintaining sampling rates within 10% of isokinetic collection and of determining sample volumes to within 2%. The metering system may be used in conjunction with a pitot tube to enable checks of isokinetic sampling rates.

4.1.7 Barometer: The barometer may be mercury, aneroid, or other barometer capable of measuring atmospheric pressure to within 2.5 mm Hg (0.1 in Hg). In many cases, the barometric reading may be obtained from a nearby National Weather Service Station, in which case the station value (which is the absolute barometric pressure) is requested and an adjustment for elevation differences between the weather station and sampling point is applied at a rate of minus 2.5 mm Hg (0.1 in Hg) per 30 m (100 ft) elevation increase (vice versa for elevation decrease).

4.1.8 Gas Density Determination Equipment: Temperature sensor and pressure gauge (as described in Sections 2.3 and 2.4 of EPA Method 2), and gas analyzer, if necessary (as described in EPA Method 3). The temperature sensor ideally should be permanently attached to the pitot tube or sampling probe in a fixed

configuration such that the tip of the sensor extends beyond the leading edge of the probe sheath and does not touch any metal. Alternatively, the sensor may be attached just prior to use in the field. Note, however, that if the temperature sensor is attached in the field, the sensor must be placed in an interference-free arrangement with respect to the Type S pitot tube openings (see EPA Method 2, Figure 2-7). As a second alternative, if a difference of no more than 1% in the average velocity measurement is to be introduced, the temperature gauge need not be attached to the probe or pitot tube.

4.2 Sample Recovery

4.2.1 Probe Liner: Probe nozzle and brushes; Teflon® bristle brushes with stainless steel wire handles are required. The probe brush shall have extensions of stainless steel, Teflon®, or inert material at least as long as the probe. The brushes shall be properly sized and shaped to brush out the probe liner, the probe nozzle, and the impingers.

4.2.2 Wash Bottles: Three wash bottles are required. Teflon® or glass wash bottles are recommended; polyethylene wash bottles should not be used because organic contaminants may be extracted by exposure to organic solvents used for sample recovery.

4.2.3 Graduated Cylinder and/or Balance: A graduated cylinder or balance is required to measure condensed water to the nearest 1 mL or 1 g. Graduated cylinders shall have divisions not >2 mL. Laboratory balances capable of weighing to ± 0.5 g are required.

4.2.4 Amber Glass Storage Containers: One-liter wide-mouth amber flint glass bottles with Teflon®-lined caps are required to store impinger water samples. The bottles must be sealed with Teflon® tape.

4.2.5 Rubber Policeman and Funnel: A rubber policeman and funnel are required to aid in the transfer of materials into and out of containers in the field.

5.0 REAGENTS

Reagent grade chemicals or better grades shall be used in all tests. Unless otherwise indicated, all reagents shall conform to the specifications of the Committee on Analytical Reagents of the American Chemical Society, where such specifications are available.

5.1 Water: HPLC-grade water is used in preparation of DNPH reagent and in all other applications in the sampling train.

5.2 Silica Gel: Silica gel shall be indicating type, 6-16 mesh. If the silica gel has been used previously, dry at 175°C (350°F) for 2 h before using. New silica gel may be used as received. Alternatively, other types of desiccants (equivalent or better) may be used.

5.3 Crushed Ice: Quantities ranging from 10-50 lb may be necessary during a sampling run, depending upon ambient temperature. Samples which have been taken must be stored and shipped cold; sufficient ice for this purpose must be allowed.

5.4 2,4-Dinitrophenylhydrazine Reagent: The 2,4-dinitrophenylhydrazine reagent must be prepared in the laboratory within five days of sampling use in the field. Preparation of DNPH can also be done in the field, with consideration of appropriate procedures required for safe handling of solvent in the field. When a container of prepared DNPH reagent is opened in the field, the contents of the opened container should be used within 48 hours. All laboratory glassware must be washed with detergent and water and rinsed with water, methanol, and methylene chloride prior to use.

NOTE: The glassware must not be rinsed with acetone or unacceptable levels of acetone contamination will be introduced. If field preparation of DNPH is performed, caution must be exercised in avoiding acetone contamination.

Reagent bottles for storage of cleaned DNPH derivatizing solution must be rinsed with acetonitrile and dried before use. Baked glassware is not essential for preparation of DNPH reagent.

NOTE: DNPH crystals or DNPH solution should be handled with plastic gloves at all times, with prompt and extensive use of running water in case of skin exposure.

5.4.1 Preparation of Aqueous Acidic DNPH: The following materials and reagents are required for preparation of the reagent.

5.4.1.1 Bottles/Caps: amber 1- or 4 L bottles with Teflon®-lined caps are required for storing cleaned DNPH solution. Additional 4-L bottles are required to collect waste organic solvents.

5.4.1.2 Large Glass Container: at least one large glass container (8 to 16 L) is required for mixing the aqueous acidic DNPH solution.

5.4.1.3 Stir Plate/Large Stir Bars/Stir Bar Retriever: a magnetic stir plate and large stir bar are required for the mixing of the aqueous acidic DNPH solution. A stir bar retriever is needed for removing the stir bar from the large container holding the DNPH solution.

5.4.1.4 Buchner Filter/Filter Flask/Filter Paper: a large filter flask (2-4 L) with a buchner filter, appropriate rubber stopper, filter paper, and connecting tubing are required for filtering the aqueous acidic DNPH solution prior to cleaning.

5.4.1.5 Separatory Funnels: at least one large separatory funnel (2 L) is required for cleaning the DNPH prior to use.

5.4.1.6 Beakers: beakers (150 mL, 250 mL, and 400 mL) are useful for holding/measuring organic liquids when cleaning the aqueous acidic DNPH solution and for weighing DNPH crystals.

5.4.1.7 Funnels: at least one large funnel is needed for pouring the aqueous acidic DNPH into the separatory funnel.

5.4.1.8 Graduated Cylinders: at least one large graduated cylinder (1 to 2 L) is required for measuring HPLC-grade water and acid when preparing the DNPH solution.

5.4.1.9 Top-Loading Balance: a one-place top loading balance is needed for weighing out the DNPH crystals used to prepare the aqueous acidic DNPH solution.

5.4.1.10 Spatulas: spatulas are needed for weighing out DNPH when preparing the aqueous DNPH solution.

5.4.1.11 HPLC-Grade Water: water (HPLC-grade) is required to mix the aqueous DNPH solution.

5.4.1.12 Hydrochloric Acid: reagent grade hydrochloric acid (approximately 12N) is required for acidifying the aqueous DNPH solution.

5.4.1.13 2,4-Dinitrophenylhydrazine: a supply of moist solid 2,4-dinitrophenylhydrazine (DNPH) is required for preparation of aqueous acidic DNPH solution. The quantity of water may vary from 10 to 30%. Reagent grade or equivalent is required.

5.4.1.14 Methylene Chloride: methylene chloride (suitable for residue and pesticide analysis, GC/MS, HPLC, GC, Spectrophotometry or equivalent) is required for cleaning the aqueous acidic DNPH solution, rinsing glassware, and recovery of sample trains.

5.4.1.15 Cyclohexane: cyclohexane (HPLC grade) is required for cleaning the aqueous acidic DNPH solution.

NOTE: Do not use spectroanalyzed grades of cyclohexane if this sampling methodology is extended to aldehydes and ketones with four or more carbon atoms.

5.4.1.16 Methanol: methanol (HPLC grade or equivalent) is required for rinsing glassware.

5.4.1.17 Acetonitrile: acetonitrile (HPLC grade or equivalent) is required for rinsing glassware.

5.4.1.18 Formaldehyde: Analytical grade or equivalent formaldehyde is required for preparation of standards. If other aldehydes or ketones are used, analytical grade or equivalent is required.

5.4.2 Preparation of Aqueous Acidic DNPH Derivatizing Reagent: Each batch of DNPH reagent should be prepared and purified within five days of sampling, according to the procedure described below.

5.4.2.1 Place an 8-L container under a fume hood on a magnetic stirrer. Add a large stir bar and fill the container half full of HPLC-grade water. Save the empty bottle from HPLC-grade water. Start the stirring bar and adjust the stir rate to be as fast as possible. Using a graduated cylinder, measure 1.4 mL of concentrated hydrochloric acid. Slowly pour the acid into the stirring water. Fumes may be generated and the water may become warm. Weigh the DNPH crystals on a one-place balance (see Table 1 for approximate amounts) and add to the stirring acid solution. Fill the 8 L container to the 8 L mark with HPLC water and stir overnight. If all of the DNPH crystals have dissolved overnight, add additional DNPH and stir for two more hours. Continue the process of adding DNPH with additional stirring until a saturated solution has been formed. Filter the DNPH solution using vacuum filtration. Gravity filtration may be used, but a

much longer time is required. Store the filtered solution in an amber bottle at room temperature.

TABLE 1. APPROXIMATE AMOUNT OF CRYSTALLINE DNPB USED
TO PREPARE A SATURATED SOLUTION

Amount of Moisture in DNPB	Weight Required per 8 L of Solution
10 weight percent	31 g
15 weight percent	33 g
30 weight percent	40 g

Within five days of proposed use, place about 1.6 L of the DNPB reagent in a 2 L separatory funnel. Add approximately 200 mL of methylene chloride and stopper the funnel. Wrap the stopper of the funnel with paper towels to absorb any leakage. Invert and vent the funnel. Then shake vigorously for 3 minutes. Initially, the funnel should be vented frequently (every 10 - 15 sec). After the layers have separated, discard the lower (organic) layer.

Extract the DNPB a second time with methylene chloride and finally with cyclohexane. When the cyclohexane layer has separated from the DNPB reagent, the cyclohexane layer will be the top layer in the separatory funnel. Drain the lower layer (the cleaned extracted DNPB reagent solution) into an amber bottle that has been rinsed with acetonitrile and allowed to dry.

5.4.3 Quality Control: Take two aliquots of the extracted DNPB reagent. The size of the aliquots is dependent upon the exact sampling procedure used, but 100 mL is reasonably representative. To ensure that the background in the reagent is acceptable for field use, analyze one aliquot of the reagent according to the procedure of EPA Draft Method 8315. Save the other aliquot of aqueous acidic DNPB for use as a method blank when the analysis is performed.

5.4.4 Shipment to the Field: Tightly cap the bottle containing extracted DNPB reagent using a Teflon®-lined cap. Seal the bottle with Teflon® tape. After the bottle is labeled, the bottle may be placed in a friction-top can (paint can or equivalent) containing a 1 -2 inch layer of granulated charcoal and stored at ambient temperature until use.

If the DNPB reagent has passed the Quality Control criteria, the reagent may be packaged to meet necessary shipping requirements and sent to the sampling area. If the Quality Control criteria are not met, the reagent solution may be re-extracted or the solution may be re-prepared and the extraction sequence repeated.

If the DNPB reagent is not used in the field within five days of extraction, an aliquot may be taken and analyzed as described Draft Method 8315. If the reagent meets the Quality Control requirements, the reagent may be used. If the reagent does not meet Quality Control requirements, the reagent must be discarded and new reagent must be prepared and tested.

5.4.5 Calculation of Acceptable Levels of Impurities in DNPH Reagent: The acceptable impurity level (AIL, $\mu\text{g/mL}$) is calculated from the expected analyte level in the sampled gas (EAL, ppbv), the volume of air that will be sampled at standard conditions (SVOL, L), the formula weight of the analyte (FW, g/mol), and the volume of DNPH reagent that will be used in the impingers (RVOL, mL):

$$\text{AIL} = 0.1 \times [\text{EAL} \times \text{SVOL} \times \text{FW} / 22.4 \times (\text{FW} + 180) / \text{FW}] / (\text{RVOL} \times 1000).$$

where 0.1 is the acceptable contaminant level, 22.4 is a factor relating ppbv to g/L, 180 is a factor relating the underivatized analyte to the derivatized analyte, and 1000 is a unit conversion factor.

5.4.6 Disposal of Excess DNPH Reagent: Excess DNPH reagent may be returned to the laboratory and recycled or treated as aqueous waste for disposal purposes. 2,4-Dinitrophenylhydrazine is a flammable solid when dry so water should not be evaporated from the solution of the reagent.

5.5 Field Spike Standard Preparation: To prepare a formaldehyde field spiking standard at 4.01 mg/mL, use a 500 μL syringe to transfer 0.5 mL of 37% by weight of formaldehyde (401 mg/mL) to a 50 mL volumetric flask containing approximately 40 mL of methanol. Dilute to 50 mL with methanol.

6.0 SAMPLE COLLECTION, PRESERVATION, AND HANDLING

6.1 Because of the complexity of this method, field personnel should be trained in and experienced with the test procedures in order to obtain reliable results.

6.2 Laboratory Preparation:

6.2.1 All the components shall be maintained and calibrated according to the procedure described in APTD-0576, unless otherwise specified.

6.2.2 Weigh several 200- to 300-g portions of silica gel in airtight containers to the nearest 0.5 g. Record on each container the total weight of the silica gel plus containers. As an alternative to preweighing the silica gel, it may instead be weighed directly in the impinger or sampling holder just prior to train assembly.

6.3 Preliminary Field Determinations:

6.3.1 Select the sampling site and the minimum number of sampling points according to EPA Method 1 or other relevant criteria. Determine the stack pressure, temperature, and range of velocity heads using EPA Method 2. A leak-check of the pitot lines according to EPA Method 2, Section 3.1, must be performed. Determine the stack gas moisture content using EPA Approximation Method 4 or its alternatives to establish estimates of isokinetic sampling-rate settings. Determine the stack gas dry molecular weight, as described in EPA Method 2, Section 3.6. If integrated EPA Method 3 sampling is used for molecular weight determination, the integrated bag sample shall be taken simultaneously with, and for the same total length of time as, the sample run.

6.3.2 Select a nozzle size based on the range of velocity heads so that it is not necessary to change the nozzle size in order to maintain isokinetic sampling rates below 28 L/min (1.0 cfm). During the run, do not change the nozzle.

Ensure that the proper differential pressure gauge is chosen for the range of velocity heads encountered (see Section 2.2 of EPA Method 2).

6.3.3 Select a suitable probe liner and probe length so that all traverse points can be sampled. For large stacks, to reduce the length of the probe, consider sampling from opposite sides of the stack.

6.3.4 A minimum of 45 ft³ of sample volume is required for the determination of the Destruction and Removal Efficiency (DRE) of formaldehyde from incineration systems (45 ft³ is equivalent to one hour of sampling at 0.75 dscf). Additional sample volume shall be collected as necessitated by the capacity of the DNPH reagent and analytical detection limit constraints. To determine the minimum sample volume required, refer to sample calculations in Section 10.

6.3.5 Determine the total length of sampling time needed to obtain the identified minimum volume by comparing the anticipated average sampling rate with the volume requirement. Allocate the same time to all traverse points defined by EPA Method 1. To avoid timekeeping errors, the length of time sampled at each traverse point should be an integer or an integer plus 0.5 min.

6.3.6 In some circumstances (e.g., batch cycles) it may be necessary to sample for shorter times at the traverse points and to obtain smaller gas-volume samples. In these cases, careful documentation must be maintained in order to allow accurate calculation of concentrations.

6.4 Preparation of Collection Train:

6.4.1 During preparation and assembly of the sampling train, keep all openings where contamination can occur covered with Teflon® film or aluminum foil until just prior to assembly or until sampling is about to begin.

6.4.2 Place 100 mL of cleaned DNPH solution in each of the first two impingers, and leave the third impinger empty. If additional capacity is required for high expected concentrations of formaldehyde in the stack gas, 200 mL of DNPH per impinger may be used or additional impingers may be used for sampling. Transfer approximately 200 to 300 g of pre-weighed silica gel from its container to the fourth impinger. Care should be taken to ensure that the silica gel is not entrained and carried out from the impinger during sampling. Place the silica gel container in a clean place for later use in the sample recovery. Alternatively, the weight of the silica gel plus impinger may be determined to the nearest 0.5 g and recorded.

6.4.3 With a glass or quartz liner, install the selected nozzle using a Viton-A O-ring when stack temperatures are <260°C (500°F) and a woven glass-fiber gasket when temperatures are higher. See APTD-0576 (Rom, 1972) for details. Other connecting systems utilizing either 316 stainless steel or Teflon® ferrules may be used. Mark the probe with heat-resistant tape or by some other method to denote the proper distance into the stack or duct for each sampling point.

6.4.4 Assemble the train as shown in Figure 1. During assembly, do not use any silicone grease on ground-glass joints upstream of the impingers. Use Teflon® tape, if required. A very light coating of silicone grease may be used on ground-glass joints downstream of the impingers, but the silicone grease should be limited to the outer portion (see APTD-0576) of the ground-glass joints to

necessary, a leak check shall be conducted immediately after the interruption of sampling and before the change is made. The leak check shall be done according to the procedure described in Section 6.5.1, except that it shall be done at a vacuum greater than or equal to the maximum value recorded up to that point in the test. If the leakage rate is found to be no greater than 0.00057 m³/min (0.02 cfm) or 4% of the average sampling rate (whichever is less), the results are acceptable. If a higher leakage rate is obtained, the tester must void the sampling run.

NOTE: Any correction of the sample volume by calculation reduces the integrity of the pollutant concentration data generated and must be avoided.

6.5.2.2 Immediately after a component change and before sampling is re-initiated, a leak check similar to a pre-test leak check must also be conducted.

6.5.3 Post-test Leak Check:

6.5.3.1 A leak check is mandatory at the conclusion of each sampling run. The leak check shall be done with the same procedures as the pre-test leak check, except that the post-test leak check shall be conducted at a vacuum greater than or equal to the maximum value reached during the sampling run. If the leakage rate is found to be no greater than 0.00057 m³/min (0.02 cfm) or 4% of the average sampling rate (whichever is less), the results are acceptable. If, however, a higher leakage rate is obtained, the tester shall record the leakage rate and void the sampling run.

6.6 Sampling Train Operation:

6.6.1 During the sampling run, maintain an isokinetic sampling rate to within 10% of true isokinetic, below 28 L/min (1.0 cfm). Maintain a temperature around the probe of 120° ± 14°C (248° ± 25°F).

6.6.2 For each run, record the data on a data sheet such as the one shown in Figure 2. Be sure to record the initial dry-gas meter reading. Record the dry-gas meter readings at the beginning and end of each sampling time increment, when changes in flow rates are made, before and after each leak check, and when sampling is halted. Take other readings required by Figure 2 at least once at each sample point during each time increment and additional readings when significant adjustments (20% variation in velocity head readings) necessitate additional adjustments in flow rate. Level and zero the manometer. Because the manometer level and zero may drift due to vibrations and temperature changes, make periodic checks during the traverse.

6.6.3 Clean the stack access ports prior to the test run to eliminate the chance of sampling deposited material. To begin sampling, remove the nozzle cap, verify that the filter and probe heating systems are at the specified temperature, and verify that the pitot tube and probe are properly positioned. Position the nozzle at the first traverse point, with the tip pointing directly into the gas stream. Immediately start the pump and adjust the flow to isokinetic conditions. Nomographs, which aid in the rapid adjustment of the isokinetic sampling rate without excessive computations, are available. These nomographs are designed for use when the Type S pitot tube coefficient is 0.84 ± 0.02 and the stack gas equivalent density (dry molecular weight) is equal to 29 ± 4. APTD-0576 details the procedure for using the nomographs. If the stack gas molecular weight and

minimize silicone grease contamination. If necessary, Teflon® tape may be used to seal leaks. Connect all temperature sensors to an appropriate potentiometer/display unit. Check all temperature sensors at ambient temperature.

6.4.5 Place crushed ice all around the impingers. . .

6.4.6 Turn on and set the probe heating system at the desired operating temperature. Allow time for the temperature to stabilize. . . .

6.5 Leak-Check Procedures:

6.5.1 Pre-test Leak Check:

6.5.1.1 After the sampling train has been assembled, turn on and set the probe heating system at the desired operating temperature. Allow time for the temperature to stabilize. If a Viton-A O-ring or other leak-free connection is used in assembling the probe nozzle to the probe liner, leak-check the train at the sampling site by plugging the nozzle and pulling a 381-mm Hg (15 in Hg) vacuum.

NOTE: A lower vacuum may be used, provided that the lower vacuum is not exceeded during the test.

6.5.1.2 If an asbestos string is used, do not connect the probe to the train during the leak check. Instead, leak-check the train by first attaching a carbon-filled leak check impinger to the inlet and then plugging the inlet and pulling a 381-mm Hg (15 in Hg) vacuum. (A lower vacuum may be used if this lower vacuum is not exceeded during the test.) Then connect the probe to the train and leak-check at about 25 mm Hg (1 in Hg) vacuum. Alternatively, leak-check the probe with the rest of the sampling train in one step at 381 mm Hg (15 in Hg) vacuum. Leakage rates in excess of 4% of the average sampling rate or >0.00057 m³/min (0.02 cfm), whichever is less, are acceptable.

6.5.1.3 The following leak check instructions for the sampling train described in APTD-0576 and APTD-0581 may be helpful. Start the pump with the fine-adjust valve fully open and coarse-adjust valve completely closed. Partially open the coarse-adjust valve and slowly close the fine-adjust valve until the desired vacuum is reached. Do not reverse direction of the fine-adjust valve, as liquid will back up into the train. If the desired vacuum is exceeded, either perform the leak check at this higher vacuum or end the leak check, as shown below, and start over.

6.5.1.4 When the leak check is completed, first slowly remove the plug from the inlet to the probe. When the vacuum drops to 127 mm (5 in) Hg or less, immediately close the coarse-adjust valve. Switch off the pumping system and reopen the fine-adjust valve. Do not reopen the fine-adjust valve until the coarse-adjust valve has been closed to prevent the liquid in the impingers from being forced backward into the sampling line and silica gel from being entrained backward into the third impinger.

6.5.2 Leak Checks During Sampling Runs:

6.5.2.1 If, during the sampling run, a component change (i.e., impinger) becomes

the pitot tube coefficient are outside the above ranges, do not use the nomographs unless appropriate steps are taken to compensate for the deviations.

6.6.4 When the stack is under significant negative pressure (equivalent to the height of the impinger stem), take care to close the coarse-adjust valve before inserting the probe into the stack in order to prevent liquid from backing up through the train. If necessary, the pump may be turned on with the coarse-adjust valve closed.

6.6.5 When the probe is in position, block off the openings around the probe and stack access port to prevent unrepresentative dilution of the gas stream.

6.6.6 Traverse the stack cross section, as required by EPA Method 1, being careful not to bump the probe nozzle into the stack walls when sampling near the walls or when removing or inserting the probe through the access port, in order to minimize the chance of extracting deposited material.

6.6.7 During the test run, make periodic adjustments to keep the temperature around the probe at the proper levels. Add more ice and, if necessary, salt, to maintain a temperature of $<20^{\circ}\text{C}$ (68°F) at the silica gel outlet. Also, periodically check the level and zero of the manometer.

6.6.8 A single train shall be used for the entire sampling run, except in cases where simultaneous sampling is required in two or more separate ducts or at two or more different locations within the same duct, or in cases where equipment failure necessitates a change of trains. An additional train or additional trains may also be used for sampling when the capacity of a single train is exceeded.

6.6.9 When two or more trains are used, separate analyses of components from each train shall be performed. If multiple trains have been used because the capacity of a single train would be exceeded, first impingers from each train may be combined, and second impingers from each train may be combined.

6.6.10 At the end of the sampling run, turn off the coarse-adjust valve, remove the probe and nozzle from the stack, turn off the pump, record the final dry gas meter reading, and conduct a post-test leak check. Also, leak check the pitot lines as described in EPA Method 2. The lines must pass this leak check in order to validate the velocity-head data.

6.6.11 Calculate percent isokineticity (see Method 2) to determine whether the run was valid or another test should be made.

7.0 SAMPLE RECOVERY

7.1 Preparation:

7.1.1 Proper cleanup procedure begins as soon as the probe is removed from the stack at the end of the sampling period. Allow the probe to cool. When the probe can be handled safely, wipe off all external particulate matter near the tip of the probe nozzle and place a cap over the tip to prevent losing or gaining particulate matter. Do not cap the probe tip tightly while the sampling train is cooling because a vacuum will be created, drawing liquid from the impingers back through the sampling train.

7.1.2 Before moving the sampling train to the cleanup site, remove the probe from the sampling train and cap the open outlet, being careful not to lose any condensate that might be present. Remove the umbilical cord from the last impinger and cap the impinger. If a flexible line is used, let any condensed water or liquid drain into the impingers. Cap off any open impinger inlets and outlets. Ground glass stoppers, Teflon® caps, or caps of other inert materials may be used to seal all openings.

7.1.3 Transfer the probe and impinger assembly to an area that is clean and protected from wind so that the chances of contaminating or losing the sample are minimized.

7.1.4 Inspect the train before and during disassembly, and note any abnormal conditions.

7.1.5 Save a portion of all washing solutions (methylene chloride, water) used for cleanup as a blank. Transfer 200 mL of each solution directly from the wash bottle being used and place each in a separate, pre-labeled sample container.

7.2 Sample Containers:

7.2.1 Container 1: Probe and Impinger Catches. Using a graduated cylinder, measure to the nearest mL, and record the volume of the solution in the first three impingers. Alternatively, the solution may be weighed to the nearest 0.5 g. Include any condensate in the probe in this determination. Transfer the impinger solution from the graduated cylinder into the amber flint glass bottle. Taking care that dust on the outside of the probe or other exterior surfaces does not get into the sample, clean all surfaces to which the sample is exposed (including the probe nozzle, probe fitting, probe liner, first impinger, and impinger connector) with methylene chloride. Use less than 500 mL for the entire wash (250 mL would be better, if possible). Add the washings to the sample container.

7.2.1.1 Carefully remove the probe nozzle and rinse the inside surface with methylene chloride from a wash bottle. Brush with a Teflon® bristle brush, and rinse until the rinse shows no visible particles or yellow color, after which make a final rinse of the inside surface. Brush and rinse the inside parts of the Swagelok® fitting with methylene chloride in a similar way.

7.2.1.2 Rinse the probe liner with methylene chloride. While squirting the methylene chloride into the upper end of the probe, tilt and rotate the probe so that all inside surfaces will be wetted with methylene chloride. Let the methylene chloride drain from the lower end into the sample container. The tester may use a funnel (glass or polyethylene) to aid in transferring the liquid washes to the container. Follow the rinse with a Teflon® brush. Hold the probe in an inclined position, and squirt methylene chloride into the upper end as the probe brush is being pushed with a twisting action through the probe. Hold the sample container underneath the lower end of the probe, and catch any methylene chloride, water, and particulate matter that is brushed from the probe. Run the brush through the probe three times or more. With stainless steel or other metal probes, run the brush through in the above prescribed manner at least six times since there may be small crevices in which particulate matter can be entrapped. Rinse the brush with methylene chloride or water, and quantitatively collect these washings in the sample container. After the brushings, make a final rinse

of the probe as described above.

NOTE: Two people should clean the probe in order to minimize sample losses. Between sampling runs, brushes must be kept clean and free from contamination.

7.2.1.3 Rinse the inside surface of each of the first three impingers (and connecting tubing) three separate times. Use a small portion of methylene chloride for each rinse, and brush each surface to which sample is exposed with a Teflon® bristle brush to ensure recovery of fine particulate matter. Water will be required for the recovery of the impingers in addition to the specified quantity of methylene chloride. There will be at least two phases in the impingers. This two-phase mixture does not pour well, and a significant amount of the impinger catch will be left on the walls. The use of water as a rinse makes the recovery quantitative. Make a final rinse of each surface and of the brush, using both methylene chloride and water.

7.2.1.4 After all methylene chloride and water washings and particulate matter have been collected in the sample container, tighten the lid so that solvent, water, and DNPH reagent will not leak out when the container is shipped to the laboratory. Mark the height of the fluid level to determine whether leakage occurs during transport. Seal the container with Teflon® tape. Label the container clearly to identify its contents.

7.2.1.5 If the first two impingers are to be analyzed separately to check for breakthrough, separate the contents and rinses of the two impingers into individual containers. Care must be taken to avoid physical carryover from the first impinger to the second. The formaldehyde hydrazone is a solid which floats and froths on top of the impinger solution. Any physical carryover of collected moisture into the second impinger will invalidate a breakthrough assessment.

7.2.2 Container 2: Sample Blank. Prepare a blank by using an amber flint glass container and adding a volume of DNPH reagent and methylene chloride equal to the total volume in Container 1. Process the blank in the same manner as Container 1.

7.2.3 Container 3: Silica Gel. Note the color of the indicating silica gel to determine whether it has been completely spent and make a notation of its condition. The impinger containing the silica gel may be used as a sample transport container with both ends sealed with tightly fitting caps or plugs. Ground-glass stoppers or Teflon® caps may be used. The silica gel impinger should then be labeled, covered with aluminum foil, and packaged on ice for transport to the laboratory. If the silica gel is removed from the impinger, the tester may use a funnel to pour the silica gel and a rubber policeman to remove the silica gel from the impinger. It is not necessary to remove the small amount of dust particles that may adhere to the impinger wall and are difficult to remove. Since the gain in weight is to be used for moisture calculations, do not use water or other liquids to transfer the silica gel. If a balance is available in the field, the spent silica gel (or silica gel plus impinger) may be weighed to the nearest 0.5 g.

7.2.4 Sample containers should be placed in a cooler, cooled by although not in contact with ice. Sample containers must be placed vertically and, since they are glass, protected from breakage during shipment. Samples should be cooled during shipment so they will be received cold at the laboratory.

8.0 CALIBRATION

8.1 Probe Nozzle: Probe nozzles shall be calibrated before their initial use in the field. Using a micrometer, measure the inside diameter of the nozzle to the nearest 0.025 mm (0.001 in). Make measurements at three separate places across the diameter and obtain the average of the measurements. The difference between the high and low numbers shall not exceed 0.1 mm (0.004 in). When the nozzles become nicked or corroded, they shall be replaced and calibrated before use. Each nozzle must be permanently and uniquely identified.

8.2 Pitot tube: The Type S pitot tube assembly shall be calibrated according to the procedure outlined in Section 4 of EPA Method 2, or assigned a nominal coefficient of 0.84 if it is not visibly nicked or corroded and if it meets design and intercomponent spacing specifications.

8.3 Metering system:

8.3.1 Before its initial use in the field, the metering system shall be calibrated according to the procedure outlined in APTD-0576. Instead of physically adjusting the dry-gas meter dial readings to correspond to the wet-test meter readings, calibration factors may be used to correct the gas meter dial readings mathematically to the proper values. Before calibrating the metering system, it is suggested that a leak check be conducted. For metering systems having diaphragm pumps, the normal leak check procedure will not detect leakages within the pump. For these cases, the following leak check procedure will apply: make a ten-minute calibration run at 0.00057 m³/min (0.02 cfm). At the end of the run, take the difference of the measured wet-test and dry-gas meter volumes and divide the difference by 10 to get the leak rate. The leak rate should not exceed 0.00057 m³/min (0.02 cfm).

8.3.2 After each field use, check the calibration of the metering system by performing three calibration runs at a single intermediate orifice setting (based on the previous field test). Set the vacuum at the maximum value reached during the test series. To adjust the vacuum, insert a valve between the wet-test meter and the inlet of the metering system. Calculate the average value of the calibration factor. If the calibration has changed by more than 5%, recalibrate the meter over the full range of orifice settings, as outlined in APTD-0576.

8.3.3 Leak check of metering system: The portion of the sampling train from the pump to the orifice meter (see Figure 1) should be leak-checked prior to initial use and after each shipment. Leakage after the pump will result in less volume being recorded than is actually sampled. Use the following procedure: Close the main valve on the meter box. Insert a one-hole rubber stopper with rubber tubing attached into the orifice exhaust pipe. Disconnect and vent the low side of the orifice manometer. Close off the low side orifice tap. Pressurize the system to 13 - 18 cm (5 - 7 in) water column by blowing into the rubber tubing. Pinch off the tubing and observe the manometer for 1 min. A loss of pressure on the manometer indicates a leak in the meter box. Leaks must be corrected.

NOTE: If the dry-gas-meter coefficient values obtained before and after a test series differ by >5%, either the test series must be voided or calculations for test series must be performed using whichever meter coefficient value (i.e., before or after) gives the lower value of total sample volume.

8.4 Probe heater: The probe heating system must be calibrated before its initial use in the field according to the procedure outlined in APTD-0576. Probes constructed according to APTD-0581 need not be calibrated if the calibration curves in APTD-0576 are used.

8.5 Temperature gauges: Each thermocouple must be permanently and uniquely marked on the casting. All mercury-in-glass reference thermometers must conform to ASTM E-1 63C or 63F specifications. Thermocouples should be calibrated in the laboratory with and without the use of extension leads. If extension leads are used in the field, the thermocouple readings at ambient air temperatures, with and without the extension lead, must be noted and recorded. Correction is necessary if the use of an extension lead produces a change $>1.5\%$.

8.5.1 Impinger and dry-gas meter thermocouples: For the thermocouples used to measure the temperature of the gas leaving the impinger train, three-point calibration at ice water, room air, and boiling water temperatures is necessary. Accept the thermocouples only if the readings at all three temperatures agree to $\pm 2^{\circ}\text{C}$ (3.6°F) with those of the absolute value of the reference thermometer.

8.5.2 Probe and stack thermocouple: For the thermocouples used to indicate the probe and stack temperatures, a three-point calibration at ice water, boiling water, and hot oil bath temperatures must be performed. Use of a point at room air temperature is recommended. The thermometer and thermocouple must agree to within 1.5% at each of the calibration points. A calibration curve (equation) may be constructed (calculated) and the data extrapolated to cover the entire temperature range suggested by the manufacturer.

8.6 Barometer: Adjust the barometer initially and before each test series to agree to within ± 2.5 mm Hg (0.1 in Hg) of the mercury barometer or the corrected barometric pressure value reported by a nearby National Weather Service Station (same altitude above sea level).

8.7 Triple-beam balance: Calibrate the triple-beam balance before each test series, using Class S standard weights. The weights must be within $\pm 0.5\%$ of the standards, or the balance must be adjusted to meet these limits.

9.0 CALCULATIONS

Carry out calculations, retaining at least one extra decimal figure beyond that of the acquired data. Round off figures after final calculation.

9.1 Calculation of Total Formaldehyde:

To determine the total formaldehyde in mg, use the following equation:

Total mg formaldehyde = $C_d \times V \times DF \times$

$\left(\frac{[\text{g/mole aldehyde}]}{[\text{g/mole DNPH derivative}]} \right) \times$

$10^{-3} \text{ mg/}\mu\text{g}$

where:

C_d = measured concentration of DNPH-formaldehyde derivative, $\mu\text{g/mL}$.

V = organic extract volume, mL

DF = dilution factor

9.2 Formaldehyde concentration in stack gas:

Determine the formaldehyde concentration in the stack gas using the following equation:

$$C_f = K \left[\text{total formaldehyde, mg} \right] / V_{m(\text{std})}$$

where:

$K = 35.31 \text{ ft}^3/\text{m}^3$ if $V_{m(\text{std})}$ is expressed in English units

$= 1.00 \text{ m}^3/\text{m}^3$ if $V_{m(\text{std})}$ is expressed in metric units

$V_{m(\text{std})}$ = volume of gas sample as measured by dry gas meter, corrected to standard conditions, dscm (dscf)

9.3 Average Dry Gas Meter Temperature and Average Orifice Pressure Drop are obtained from the data sheet.

9.4 Dry Gas Volume: Calculate $V_{m(\text{std})}$ and adjust for leakage, if necessary, using the equation in Section 6.3 of EPA Method 5.

9.5 Volume of Water Vapor and Moisture Content: Calculate the volume of water vapor and moisture content from equations 5-2 and 5-3 of EPA Method 5.

10.0 DETERMINATION OF VOLUME TO BE SAMPLED

To determine the minimum sample volume to be collected, use the following sequence of equations.

10.1 From prior analysis of the waste feed, the concentration of formaldehyde (FORM) introduced into the combustion system can be calculated. The degree of destruction and removal efficiency that is required is used to determine the maximum amount of FORM allowed to be present in the effluent. This amount may be expressed as:

Max FORM₁ Mass =

$$[(WF) (FORM_1 \text{ conc}) (100 - XDRE)] / 100$$

where:

WF = mass flow rate of waste feed per h, g/h (lb/h)

FORM₁ = concentration of FORM (wt %) introduced into the combustion process

DRE = percent Destruction and Removal Efficiency required

Max FORM = mass flow rate (g/h [lb/h]) of FORM emitted from the combustion source

10.2 The average discharge concentration of the FORM in the effluent gas is determined by comparing the Max FORM with the volumetric flow rate being exhausted from the source. Volumetric flow rate data are available as a result of preliminary EPA Method 1 - 4 determinations:

$$\text{Max FORM}_1 \text{ conc} = [\text{Max FORM}_1 \text{ Mass}] / DV_{\text{eff(Std)}}$$

where:

DV_{eff(Std)} = volumetric flow rate of exhaust gas, dscm (dscf)

FORM₁ conc = anticipated concentration of the FORM in the exhaust gas stream, g/dscm (lb/dscf)

10.3 In making this calculation, it is recommended that a safety margin of at least ten be included.

$$[LDL_{\text{FORM}} \times 10] / [FORM_1 \text{ conc}] = V_{\text{tbc}}$$

where:

LDL_{FORM} = detectable amount of FORM in entire sampling train

V_{tbc} = minimum dry standard volume to be collected at dry-gas meter

10.4 The following analytical detection limits and DNPH Reagent Capacity (based on a total volume of 200 mL in two impingers) must also be considered in determining a volume to be sampled.

Table 2. Instrument Detection Limits and Reagent Capacity for Formaldehyde Analysis¹

Analyte	Detection Limit, ppbv ²	Reagent Capacity, ppmv
formaldehyde	1.8	66
acetaldehyde	1.7	70
acrolein	1.5	75
acetone/propionaldehyde	1.5	75
butyraldehyde	1.5	79
methyl ethyl ketone	1.5	79
valeraldehyde	1.5	84
isovaleraldehyde	1.4	84
hexaldehyde	1.3	88
benzaldehyde	1.4	84
o-/m-/p-tolualdehyde	1.3	89
dimethylbenzaldehyde	1.2	93

¹ Oxygenated compounds in addition to formaldehyde are included for comparison with formaldehyde; extension of the methodology to other compounds is possible.

² Detection limits are determined in solvent. These values therefore represent the optimum capability of the methodology.

11.0 QUALITY CONTROL

11.1 Sampling: See EPA Manual 600/4-77-027b for Method 5 quality control.

11.2 Analysis: The quality assurance program required for this method includes the analysis of field and method blanks, procedure validations, and analysis of field spikes. The assessment of combustion data and positive identification and quantitation of formaldehyde are dependent on the integrity of the samples received and the precision and accuracy of the analytical methodology. Quality Assurance procedures for this method are designed to monitor the performance of the analytical methodology and to provide the required information to take corrective action if problems are observed in laboratory operations or in field sampling activities.

11.2.1 Field Blanks: Field blanks must be submitted with the samples collected at each sampling site. The field blanks include the sample bottles containing aliquots of sample recovery solvents, methylene chloride and water, and unused DNPH reagent. At a minimum, one complete sampling train will be assembled in the field staging area, taken to the sampling area, and leak-checked at the beginning and end of the testing (or for the same total number of times as the actual sampling train). The probe of the blank train must be heated during the sample test. The train will be recovered as if it were an actual test sample. No gaseous sample will be passed through the Blank sampling train.

11.2.2 Method Blanks: A method blank must be prepared for each set of analytical operations, to evaluate contamination and artifacts that can be derived from glassware, reagents, and sample handling in the laboratory.

11.2.3 Field Spike: A field spike is performed by introducing 200 μ L of the Field Spike Standard into an impinger containing 200 mL of DNPH solution. Standard impinger recovery procedures are followed and the field spike sample is returned to the laboratory for analysis. The field spike is used as a check on field handling and recovery procedures. An aliquot of the field spike standard is retained in the laboratory for derivatization and comparative analysis.

12.0 METHOD PERFORMANCE

12.1 Method performance evaluation: The following expected method performance parameters for precision, accuracy, and detection limits are provided in Table 3.


Table 3. Expected Method Performance for Formaldehyde

Parameter	Precision	¹ Accuracy ²	Detection Limit ³
Matrix: Dual trains	$\pm 15\%$ RPD	$\pm 20\%$	1.5×10^{-7} lb/ft ³ (1.8 ppbv)

¹ Relative percent difference limit for dual trains.

² Limit for field spike recoveries.

³ The lower reporting limit having less than 1% probability of false positive detection.



Formaldehyde Sampling Train



Filter No. _____

Ambient Temperature _____
 Barometric Pressure _____
 Assumed Molature % _____
 Probe Length, m(ft) _____
 Nozzle Identification No. _____
 Average Calibrated Nozzle Diameter, cm (in) _____
 Probe Heating Setting _____
 Leak Rate, m³/min. (cfm) _____
 Probe Liner Material _____
 Stallo Pressure, mm Hg (in. Hg) _____
 Filter No. _____

340437

Figure 2. Field Data Sheet

Interpoll Laboratories
4500 Ball Road N.E.
Circle Pines, Minnesota 55014

Telephone (612)786-6020
Facsimile (612)786-7854

COLLECTION OF SEMIVOLATILE COMPOUNDS

EPA METHOD 0010

(Interpoll Method II-8788 - Version 1.0)

EPA Method SW846 USEPA Office of Solid Waste and Emergency Response 3rd
Ed., November 1986: Test Methods for Evaluating Solid Waste Volume 2:
Field Manual Physical/Chemical Methods Method 0010.

MODIFIED METHOD 5 SAMPLING TRAIN

1.0 SCOPE AND APPLICATION

1.1 This method is applicable to the determination of Destruction and Removal Efficiency (DRE) of semivolatile Principal Organic Hazardous Compounds (POHCs) from incineration systems (PHS, 1967). This method also may be used to determine particulate emission rates from stationary sources as per EPA Method 5 (see References at end of this method).

2.0 SUMMARY OF METHOD

2.1 Gaseous and particulate pollutants are withdrawn from an emission source at an isokinetic sampling rate and are collected in a multicomponent sampling train. Principal components of the train include a high-efficiency glass- or quartz-fiber filter and a packed bed of porous polymeric adsorbent resin. The filter is used to collect organic-laden particulate materials and the porous polymeric resin to adsorb semivolatile organic species. Semivolatile species are defined as compounds with boiling points $>100^{\circ}\text{C}$.

2.2 Comprehensive chemical analyses of the collected sample are conducted to determine the concentration and identity of the organic materials.

3.0 INTERFERENCES

3.1 Oxides of nitrogen (NO_x) are possible interferents in the determination of certain water-soluble compounds such as dioxane, phenol, and urethane; reaction of these compounds with NO_x in the presence of moisture will reduce their concentration. Other possibilities that could result in positive or negative bias are (1) stability of the compounds in methylene chloride, (2) the formation of water-soluble organic salts on the resin in the presence of moisture, and (3) the solvent extraction efficiency of water-soluble compounds from aqueous media. Use of two or more ions per compound for qualitative and quantitative analysis can overcome interference at one mass. These concerns should be addressed on a compound-by-compound basis before using this method.

4.0 APPARATUS AND MATERIALS

4.1 Sampling train:

4.1.1 A schematic of the sampling train used in this method is shown in Figure 1. This sampling train configuration is adapted from EPA Method 5 procedures, and, as such, the majority of the required equipment

0010 - 1

Revision 0
Date September 1986




Figure 1. Modified Method 5 Sampling Train.

is identical to that used in EPA Method 5 determinations. The new components required are a condenser coil and a sorbent module, which are used to collect semivolatile organic materials that pass through the glass- or quartz-fiber filter in the gas phase.

4.1.2 Construction details for the basic train components are given in APTD-0581 (see Martin, 1971, in Section 13.0, References); commercial models of this equipment are also available. Specifications for the sorbent module are provided in the following subsections. Additionally, the following subsections list changes to APTD-0581 and identify allowable train configuration modifications.

4.1.3 Basic operating and maintenance procedures for the sampling train are described in APTD-0576 (see Rom, 1972, in Section 13.0, References). As correct usage is important in obtaining valid results, all users should refer to APTD-0576 and adopt the operating and maintenance procedures outlined therein unless otherwise specified. The sampling train consists of the components detailed below.

4.1.3.1 Probe nozzle: Stainless steel (316) or glass with sharp, tapered (30° angle) leading edge. The taper shall be on the outside to preserve a constant I.D. The nozzle shall be buttonhook or elbow design and constructed from seamless tubing (if made of stainless steel). Other construction materials may be considered for particular applications. A range of nozzle sizes suitable for isokinetic sampling should be available in increments of 0.16 cm (1/16 in.), e.g., 0.32-1.27 cm (1/8-1/2 in.), or larger if higher volume sampling trains are used. Each nozzle shall be calibrated according to the procedures outlined in Paragraph 9.1.

4.1.3.2 Probe liner: Borosilicate or quartz-glass tubing with a heating system capable of maintaining a gas temperature of $120 \pm 14^{\circ}\text{C}$ ($248 \pm 25^{\circ}\text{F}$) at the exit end during sampling. (The tester may opt to operate the equipment at a temperature lower than that specified.) Because the actual temperature at the outlet of the probe is not usually monitored during sampling, probes constructed according to APTD-0581 and utilizing the calibration curves of APTD-0576 (or calibrated according to the procedure outlined in APTD-0576) are considered acceptable. Either borosilicate or quartz-glass probe liners may be used for stack temperatures up to about 480°C (900°F). Quartz liners shall be used for temperatures between 480 and 900°C (900 and 1650°F). (The softening temperature for borosilicate is 820°C (1508°F), and for quartz 1500°C (2732°F).) Water-cooling of the stainless steel sheath will be necessary at temperatures approaching and exceeding 500°C .

4.1.3.3 Pitot tube: Type S, as described in Section 2.1 of EPA Method 2, or other appropriate devices (Vollaro, 1976). The pitot tube shall be attached to the probe to allow constant monitoring of the stack-gas velocity. The impact (high-pressure) opening plane of the pitot tube shall be even with or above the nozzle entry plane (see EPA Method 2, Figure 2-6b) during sampling. The Type S pitot tube assembly shall have a known coefficient, determined as outlined in Section 4 of EPA Method 2.

0010 - 3

Revision 0
Date September 1986

4.1.3.4 Differential pressure gauge: Inclined manometer or equivalent device as described in Section 2.2 of EPA Method 2. One manometer shall be used for velocity-head (ΔP) readings and the other for orifice differential pressure (ΔH) readings.

4.1.3.5 Filter holder: Borosilicate glass, with a glass frit filter support and a sealing gasket. The sealing gasket should be made of materials that will not introduce organic material into the gas stream at the temperature at which the filter holder will be maintained. The gasket shall be constructed of Teflon or materials of equal or better characteristics. The holder design shall provide a positive seal against leakage at any point along the filter circumference. The holder shall be attached immediately to the outlet of the cyclone or cyclone bypass.

4.1.3.6 Filter heating system: Any heating system capable of maintaining a temperature of $120 \pm 14^{\circ}\text{C}$ ($248 \pm 25^{\circ}\text{F}$) around the filter holder during sampling. Other temperatures may be appropriate for particular applications. Alternatively, the tester may opt to operate the equipment at temperatures other than that specified. A temperature gauge capable of measuring temperature to within 3°C (5.4°F) shall be installed so that the temperature around the filter holder can be regulated and monitored during sampling. Heating systems other than the one shown in APTD-0581 may be used.

4.1.3.7 Organic sampling module: This unit consists of three sections, including a gas-conditioning section, a sorbent trap, and a condensate knockout trap. The gas-conditioning system shall be capable of conditioning the gas leaving the back half of the filter holder to a temperature not exceeding 20°C (68°F). The sorbent trap shall be sized to contain approximately 20 g of porous polymeric resin (Rohm and Haas XAD-2 or equivalent) and shall be jacketed to maintain the internal gas temperature at $17 \pm 3^{\circ}\text{C}$ ($62.5 \pm 5.4^{\circ}\text{F}$). The most commonly used coolant is ice water from the impinger ice-water bath, constantly circulated through the outer jacket, using rubber or plastic tubing and a peristaltic pump. The sorbent trap should be outfitted with a glass well or depression, appropriately sized to accommodate a small thermocouple in the trap for monitoring the gas entry temperature. The condensate knockout trap shall be of sufficient size to collect the condensate following gas conditioning. The organic module components shall be oriented to direct the flow of condensate formed vertically downward from the conditioning section, through the adsorbent media, and into the condensate knockout trap. The knockout trap is usually similar in appearance to an empty impinger directly underneath the sorbent module; it may be oversized but should have a shortened center stem (at a minimum, one-half the length of the normal impinger stems) to collect a large volume of condensate without bubbling and overflowing into the impinger train. All surfaces of the organic module wetted by the gas sample shall be fabricated of borosilicate glass, Teflon, or other inert materials. Commercial versions of the

complete organic module are not currently available, but may be assembled from commercially available laboratory glassware and a custom-fabricated sorbent trap. Details of two acceptable designs are shown in Figures 2 and 3 (the thermocouple well is shown in Figure 2).

4.1.3.8 Impinger train: To determine the stack-gas moisture content, four 500-ml impingers, connected in series with leak-free ground-glass joints, follow the knockout trap. The first, third, and fourth impingers shall be of the Greenburg-Smith design, modified by replacing the tip with a 1.3-cm (1/2-in.) I.D. glass tube extending about 1.3 cm (1/2 in.) from the bottom of the outer cylinder. The second impinger shall be of the Greenburg-Smith design with the standard tip. The first and second impingers shall contain known quantities of water or appropriate trapping solution. The third shall be empty or charged with a caustic solution, should the stack gas contain hydrochloric acid (HCl). The fourth shall contain a known weight of silica gel or equivalent desiccant.

4.1.3.9 Metering system: The necessary components are a vacuum gauge, leak-free pump, thermometers capable of measuring temperature to within 3°C (5.4°F), dry-gas meter capable of measuring volume to within 1%, and related equipment, as shown in Figure 1. At a minimum, the pump should be capable of 4 cfm free flow, and the dry-gas meter should have a recording capacity of 0-999.9 cu ft with a resolution of 0.005 cu ft. Other metering systems capable of maintaining sampling rates within 10% of isokineticity and of determining sample volumes to within 2% may be used. The metering system must be used in conjunction with a pitot tube to enable checks of isokinetic sampling rates. Sampling trains using metering systems designed for flow rates higher than those described in APTD-0581 and APTD-0576 may be used, provided that the specifications of this method are met.

4.1.3.10 Barometer: Mercury, aneroid, or other barometer capable of measuring atmospheric pressure to within 2.5 mm Hg (0.1 in. Hg). In many cases the barometric reading may be obtained from a nearby National Weather Service station, in which case the station value (which is the absolute barometric pressure) is requested and an adjustment for elevation differences between the weather station and sampling point is applied at a rate of minus 2.5 mm Hg (0.1 in. Hg) per 30-m (100 ft) elevation increase (vice versa for elevation decrease).

4.1.3.11 Gas density determination equipment: Temperature sensor and pressure gauge (as described in Sections 2.3 and 2.4 of EPA Method 2), and gas analyzer, if necessary (as described in EPA Method 3). The temperature sensor ideally should be permanently attached to the pitot tube or sampling probe in a fixed configuration such that the tip of the sensor extends beyond the leading edge of the probe sheath and does not touch any metal.




Figure 2. Adsorbent Sampling System.

0010 - 6

Revision 0
Date September 1986




Figure 3. Adsorbent Sampling System.

0010 - 7

Revision 0
Date September 1986

Alternatively, the sensor may be attached just prior to use in the field. Note, however, that if the temperature sensor is attached in the field, the sensor must be placed in an interference-free arrangement with respect to the Type S pitot tube openings (see EPA Method 2, Figure 2-7). As a second alternative, if a difference of no more than 1% in the average velocity measurement is to be introduced, the temperature gauge need not be attached to the probe or pitot tube.

4.1.3.12 Calibration/field-preparation record: A permanently bound laboratory notebook, in which duplicate copies of data may be made as they are being recorded, is required for documenting and recording calibrations and preparation procedures (i.e., filter and silica gel tare weights, clean XAD-2, quality assurance/quality control check results, dry-gas meter, and thermocouple calibrations, etc.). The duplicate copies should be detachable and should be stored separately in the test program archives.

4.2 Sample Recovery:

4.2.1 Probe liner: Probe nozzle and organic module conditioning section brushes; nylon bristle brushes with stainless steel wire handles are required. The probe brush shall have extensions of stainless steel, Teflon, or inert material at least as long as the probe. The brushes shall be properly sized and shaped to brush out the probe liner, the probe nozzle, and the organic module conditioning section.

4.2.2 Wash bottles: Three. Teflon or glass wash bottles are recommended; polyethylene wash bottles should not be used because organic contaminants may be extracted by exposure to organic solvents used for sample recovery.

4.2.3 Glass sample storage containers: Chemically resistant, borosilicate amber and clear glass bottles, 500-mL or 1,000-mL. Bottles should be tinted to prevent action of light on sample. Screw-cap liners shall be either Teflon or constructed so as to be leak-free and resistant to chemical attack by organic recovery solvents. Narrow-mouth glass bottles have been found to exhibit less tendency toward leakage.

4.2.4 Petri dishes: Glass, sealed around the circumference with wide (1-in.) Teflon tape, for storage and transport of filter samples.

4.2.5 Graduated cylinder and/or balances: To measure condensed water to the nearest 1 mL or 1 g. Graduated cylinders shall have subdivisions not >2 mL. Laboratory triple-beam balances capable of weighing to ± 0.5 g or better are required.

4.2.6 Plastic storage containers: Screw-cap polypropylene or polyethylene containers to store silica gel.

4.2.7 Funnel and rubber policeman: To aid in transfer of silica gel to container (not necessary if silica gel is weighed in field).

4.2.8 Funnels: Glass, to aid in sample recovery.

4.3 Filters: Glass- or quartz-fiber filters, without organic binder, exhibiting at least 99.95% efficiency ($<0.05\%$ penetration) on 0.3- μ m dioctyl phthalate smoke particles. The filter efficiency test shall be conducted in accordance with ASTM standard method D2986-71. Test data from the supplier's quality control program are sufficient for this purpose. In sources containing SO_2 or SO_3 , the filter material must be of a type that is unreactive to SO_2 or SO_3 . Reeve Angel 934 AH or Schleicher and Schuell #3 filters work well under these conditions.

4.4 Crushed ice: Quantities ranging from 10-50 lb may be necessary during a sampling run, depending on ambient air temperature.

4.5 Stopcock grease: Solvent-insoluble, heat-stable silicone grease. Use of silicone grease upstream of the module is not permitted, and amounts used on components located downstream of the organic module shall be minimized. Silicone grease usage is not necessary if screw-on connectors and Teflon sleeves or ground-glass joints are used.

4.6 Glass wool: Used to plug the unfritted end of the sorbent module. The glass-wool fiber should be solvent-extracted with methylene chloride in a Soxhlet extractor for 12 hr and air-dried prior to use.

5.0 REAGENTS

5.1 Adsorbent resin: Porous polymeric resin (XAD-2 or equivalent) is recommended. These resins shall be cleaned prior to their use for sample collection. Appendix A of this method should be consulted to determine appropriate precleaning procedure. For best results, resin used should not exhibit a blank of higher than 4 mg/kg of total chromatographable organics (TCO) (see Appendix B) prior to use. Once cleaned, resin should be stored in an airtight, wide-mouth amber glass container with a Teflon-lined cap or placed in one of the glass sorbent modules tightly sealed with Teflon film and elastic bands. The resin should be used within 4 wk of the preparation.

5.2 Silica gel: Indicating type, 6-16 mesh. If previously used, dry at 175°C (350°F) for 2 hr before using. New silica gel may be used as received. Alternatively, other types of desiccants (equivalent or better) may be used, subject to the approval of the Administrator.

5.3 Impinger solutions: Distilled organic-free water (Type II) shall be used, unless sampling is intended to quantify a particular inorganic gaseous species. If sampling is intended to quantify the concentration of additional species, the impinger solution of choice shall be subject to Administrator approval. This water should be prescreened for any compounds of interest. One hundred mL will be added to the specified impinger; the third impinger in the train may be charged with a basic solution (1 N sodium hydroxide or sodium acetate) to protect the sampling pump from acidic gases. Sodium acetate should be used when large sample volumes are anticipated because sodium hydroxide will react with carbon dioxide in aqueous media to form sodium carbonate, which may possibly plug the impinger.

0010 - 9

Revision 0
Date September 1986

5.4 Sample recovery reagents:

5.4.1 Methylene chloride: Distilled-in-glass grade is required for sample recovery and cleanup (see Note to 5.4.2 below).

5.4.2 Methyl alcohol: Distilled-in-glass grade is required for sample recovery and cleanup.

NOTE: Organic solvents from metal containers may have a high residue blank and should not be used. Sometimes suppliers transfer solvents from metal to glass bottles; thus blanks shall be run prior to field use and only solvents with low blank value ($<0.001\%$) shall be used.

5.4.3 Water: Water (Type II) shall be used for rinsing the organic module and condenser component.

6.0 SAMPLE COLLECTION, PRESERVATION, AND HANDLING

6.1 Because of complexity of this method, field personnel should be trained in and experienced with the test procedures in order to obtain reliable results.

6.2 Laboratory preparation:

6.2.1 All the components shall be maintained and calibrated according to the procedure described in APTD-0576, unless otherwise specified.

6.2.2 Weigh several 200- to 300-g portions of silica gel in airtight containers to the nearest 0.5 g. Record on each container the total weight of the silica gel plus containers. As an alternative to preweighing the silica gel, it may instead be weighed directly in the impinger or sampling holder just prior to train assembly.

6.2.3 Check filters visually against light for irregularities and flaws or pinhole leaks. Label the shipping containers (glass Petri dishes) and keep the filters in these containers at all times except during sampling and weighing.

6.2.4 Desiccate the filters at $20 \pm 5.6^{\circ}\text{C}$ ($68 \pm 10^{\circ}\text{F}$) and ambient pressure for at least 24 hr, and weigh at intervals of at least 6 hr to a constant weight (i.e., $<0.5\text{-mg}$ change from previous weighing), recording results to the nearest 0.1 mg. During each weighing the filter must not be exposed for more than a 2-min period to the laboratory atmosphere and relative humidity above 50%. Alternatively (unless otherwise specified by the Administrator), the filters may be oven-dried at 105°C (220°F) for 2-3 hr, desiccated for 2 hr, and weighed.

0010 - 10

Revision 0
Date September 1986

6.3 Preliminary field determinations:

6.3.1 Select the sampling site and the minimum number of sampling points according to EPA Method 1 or as specified by the Administrator. Determine the stack pressure, temperature, and range of velocity heads using EPA Method 2. It is recommended that a leak-check of the pitot lines (see EPA Method 2, Section 3.1) be performed. Determine the stack-gas moisture content using EPA Approximation Method 4 or its alternatives to establish estimates of isokinetic sampling-rate settings. Determine the stack-gas dry molecular weight, as described in EPA Method 2, Section 3.6. If integrated EPA Method 3 sampling is used for molecular weight determination, the integrated bag sample shall be taken simultaneously with, and for the same total length of time as, the sample run.

6.3.2 Select a nozzle size based on the range of velocity heads so that it is not necessary to change the nozzle size in order to maintain isokinetic sampling rates. During the run, do not change the nozzle. Ensure that the proper differential pressure gauge is chosen for the range of velocity heads encountered (see Section 2.2 of EPA Method 2).

6.3.3 Select a suitable probe liner and probe length so that all traverse points can be sampled. For large stacks, to reduce the length of the probe, consider sampling from opposite sides of the stack.

6.3.4 A minimum of 3 dscm (105.9 dscf) of sample volume is required for the determination of the Destruction and Removal Efficiency (DRE) of POHCs from incineration systems. Additional sample volume shall be collected as necessitated by analytical detection limit constraints. To determine the minimum sample volume required, refer to sample calculations in Section 10.0.

6.3.5 Determine the total length of sampling time needed to obtain the identified minimum volume by comparing the anticipated average sampling rate with the volume requirement. Allocate the same time to all traverse points defined by EPA Method 1. To avoid timekeeping errors, the length of time sampled at each traverse point should be an integer or an integer plus one-half min.

6.3.6 In some circumstances (e.g., batch cycles) it may be necessary to sample for shorter times at the traverse points and to obtain smaller gas-sample volumes. In these cases, the Administrator's approval must first be obtained.

6.4 Preparation of collection train:

6.4.1 During preparation and assembly of the sampling train, keep all openings where contamination can occur covered with Teflon film or aluminum foil until just prior to assembly or until sampling is about to begin.

6.4.2 Fill the sorbent trap section of the organic module with approximately 20 g of clean adsorbent resin. While filling, ensure that the trap packs uniformly, to eliminate the possibility of channeling. When freshly cleaned, many adsorbent resins carry a static charge, which will cause clinging to trap walls. This may be minimized by filling the trap in the presence of an antistatic device. Commercial antistatic devices include Model-204 and Model-210 manufactured by the 3M Company, St. Paul, Minnesota.

6.4.3 If an impinger train is used to collect moisture, place 100 mL of water in each of the first two impingers, leave the third impinger empty (or charge with caustic solution, as necessary), and transfer approximately 200-300 g of preweighed silica gel from its container to the fourth impinger. More silica gel may be used, but care should be taken to ensure that it is not entrained and carried out from the impinger during sampling. Place the container in a clean place for later use in the sample recovery. Alternatively, the weight of the silica gel plus impinger may be determined to the nearest 0.5 g and recorded.

6.4.4 Using a tweezer or clean disposable surgical gloves, place a labeled (identified) and weighed filter in the filter holder. Be sure that the filter is properly centered and the gasket properly placed to prevent the sample gas stream from circumventing the filter. Check the filter for tears after assembly is completed.

6.4.5 When glass liners are used, install the selected nozzle using a Viton-A O-ring when stack temperatures are $<260^{\circ}\text{C}$ (500°F) and a woven glass-fiber gasket when temperatures are higher. See APTD-0576 (Rom, 1972) for details. Other connecting systems utilizing either 316 stainless steel or Teflon ferrules may be used. When metal liners are used, install the nozzle as above, or by a leak-free direct mechanical connection. Mark the probe with heat-resistant tape or by some other method to denote the proper distance into the stack or duct for each sampling point.

6.4.6 Set up the train as in Figure 1. During assembly, do not use any silicone grease on ground-glass joints that are located upstream of the organic module. A very light coating of silicone grease may be used on all ground-glass joints that are located downstream of the organic module, but it should be limited to the outer portion (see APTD-0576) of the ground-glass joints to minimize silicone-grease contamination. Subject to the approval of the Administrator, a glass cyclone may be used between the probe and the filter holder when the total particulate catch is expected to exceed 100 mg or when water droplets are present in the stack. The organic module condenser must be maintained at a temperature of $17 \pm 3^{\circ}\text{C}$. Connect all temperature sensors to an appropriate potentiometer/display unit. Check all temperature sensors at ambient temperature.

6.4.7 Place crushed ice around the impingers and the organic module condensate knockout.

6.4.8 Turn on the sorbent module and condenser coil coolant recirculating pump and begin monitoring the sorbent module gas entry temperature. Ensure proper sorbent module gas entry temperature before proceeding and again before any sampling is initiated. It is extremely important that the XAD-2 resin temperature never exceed 50°C (122°F), because thermal decomposition will occur. During testing, the XAD-2 temperature must not exceed 20°C (68°F) for efficient capture of the semivolatile species of interest.

6.4.9 Turn on and set the filter and probe heating systems at the desired operating temperatures. Allow time for the temperatures to stabilize.

6.5 Leak-check procedures

6.5.1 Pre-test leak-check:

6.5.1.1 Because the number of additional intercomponent connections in the Semi-VOST train (over the M5 Train) increases the possibility of leakage, a pre-test leak-check is required.

6.5.1.2 After the sampling train has been assembled, turn on and set the filter and probe heating systems at the desired operating temperatures. Allow time for the temperatures to stabilize. If a Viton A O-ring or other leak-free connection is used in assembling the probe nozzle to the probe liner, leak-check the train at the sampling site by plugging the nozzle and pulling a 381-mm Hg (15-in. Hg) vacuum.

(NOTE: A lower vacuum may be used, provided that it is not exceeded during the test.)

6.5.1.3 If an asbestos string is used, do not connect the probe to the train during the leak-check. Instead, leak-check the train by first attaching a carbon-filled leak-check impinger (shown in Figure 4) to the inlet of the filter holder (cyclone, if applicable) and then plugging the inlet and pulling a 381-mm Hg (15-in. Hg) vacuum. (Again, a lower vacuum may be used, provided that it is not exceeded during the test.) Then, connect the probe to the train and leak-check at about 25-mm Hg (1-in. Hg) vacuum; alternatively, leak-check the probe with the rest of the sampling train in one step at 381-mm Hg (15-in. Hg) vacuum. Leakage rates in excess of 4% of the average sampling rate or $>0.00057 \text{ m}^3/\text{min}$ (0.02 cfm), whichever is less, are unacceptable.

6.5.1.4 The following leak-check instructions for the sampling train described in APTD-0576 and APTD-0581 may be helpful. Start the pump with fine-adjust valve fully open and coarse-adjust valve completely closed. Partially open the coarse-adjust valve and slowly close the fine-adjust valve until the desired vacuum is reached. Do not reverse direction of the fine-adjust valve; this will cause water to back up into the organic module. If the desired vacuum is exceeded, either leak-check at this higher vacuum or end the leak-check, as shown below, and start over.

0010 - 13

Revision 0
Date September 1986

CROSS SECTIONAL VIEW
Leak Testing Apparatus




Figure 4. Leak-check impinger.

0010 - 14

Revision 0
Date September 1986

6.5.1.5 When the leak-check is completed, first slowly remove the plug from the inlet to the probe, filter holder, or cyclone (if applicable). When the vacuum drops to 127 mm (5 in.) Hg or less, immediately close the coarse-adjust valve. Switch off the pumping system and reopen the fine-adjust valve. Do not reopen the fine-adjust valve until the coarse-adjust valve has been closed. This prevents the water in the impingers from being forced backward into the organic module and silica gel from being entrained backward into the third impinger.

6.5.2 Leak-checks during sampling run:

6.5.2.1 If, during the sampling run, a component (e.g., filter assembly, impinger, or sorbent trap) change becomes necessary, a leak-check shall be conducted immediately after the interruption of sampling and before the change is made. The leak-check shall be done according to the procedure outlined in Paragraph 6.5.1, except that it shall be done at a vacuum greater than or equal to the maximum value recorded up to that point in the test. If the leakage rate is found to be no greater than $0.00057 \text{ m}^3/\text{min}$ (0.02 cfm) or 4% of the average sampling rate (whichever is less), the results are acceptable, and no correction will need to be applied to the total volume of dry gas metered. If a higher leakage rate is obtained, the tester shall void the sampling run. (It should be noted that any "correction" of the sample volume by calculation by calculation reduces the integrity of the pollutant concentrations data generated and must be avoided.)

6.5.2.2 Immediately after a component change, and before sampling is reinitiated, a leak-check similar to a pre-test leak-check must also be conducted.

6.5.3 Post-test leak-check:

6.5.3.1 A leak-check is mandatory at the conclusion of each sampling run. The leak-check shall be done with the same procedures as those with the pre-test leak-check, except that it shall be conducted at a vacuum greater than or equal to the maximum value reached during the sampling run. If the leakage rate is found to be no greater than $0.00057 \text{ m}^3/\text{min}$ (0.02 cfm) or 4% of the average sampling rate (whichever is less), the results are acceptable, and no correction need be applied to the total volume of dry gas metered. If, however, a higher leakage rate is obtained, the tester shall either record the leakage rate, correct the sample volume (as shown in the calculation section of this method), and consider the data obtained of questionable reliability, or void the sampling run.

6.6 Sampling-train operation:

6.6.1 During the sampling run, maintain an isokinetic sampling rate to within 10% of true isokinetic, unless otherwise specified by the Administrator. Maintain a temperature around the filter of $120 \pm 14^\circ\text{C}$ ($248 \pm 25^\circ\text{F}$) and a gas temperature entering the sorbent trap at a maximum of 20°C (68°F).

6.6.2 For each run, record the data required on a data sheet such as the one shown in Figure 5. Be sure to record the initial dry-gas meter reading. Record the dry-gas meter readings at the beginning and end of each sampling time increment, when changes in flow rates are made before and after each leak-check, and when sampling is halted. Take other readings required by Figure 5 at least once at each sample point during each time increment and additional readings when significant changes (20% variation in velocity-head readings) necessitate additional adjustments in flow rate. Level and zero the manometer. Because the manometer level and zero may drift due to vibrations and temperature changes, make periodic checks during the traverse.

6.6.3 Clean the stack access ports prior to the test run to eliminate the chance of sampling deposited material. To begin sampling, remove the nozzle cap, verify that the filter and probe heating systems are at the specified temperature, and verify that the pitot tube and probe are properly positioned. Position the nozzle at the first traverse point, with the tip pointing directly into the gas stream. Immediately start the pump and adjust the flow to isokinetic conditions. Nomographs, which aid in the rapid adjustment of the isokinetic sampling rate without excessive computations, are available. These nomographs are designed for use when the Type S pitot-tube coefficient is 0.84 ± 0.02 and the stack-gas equivalent density (dry molecular weight) is equal to 29 ± 4 . APTD-0576 details the procedure for using the nomographs. If the stack-gas molecular weight and the pitot-tube coefficient are outside the above ranges, do not use the nomographs unless appropriate steps (Shigehara, 1974) are taken to compensate for the deviations.

6.6.4 When the stack is under significant negative pressure (equivalent to the height of the impinger stem), take care to close the coarse-adjust valve before inserting the probe into the stack, to prevent water from backing into the organic module. If necessary, the pump may be turned on with the coarse-adjust valve closed.

6.6.5 When the probe is in position, block off the openings around the probe and stack access port to prevent unrepresentative dilution of the gas stream.

6.6.6 Traverse the stack cross section, as required by EPA Method 1 or as specified by the Administrator, being careful not to bump the probe nozzle into the stack walls when sampling near the walls or when removing or inserting the probe through the access port, in order to minimize the chance of extracting deposited material.

6.6.7 During the test run, make periodic adjustments to keep the temperature around the filter holder and the organic module at the proper levels; add more ice and, if necessary, salt to maintain a temperature of $<20^{\circ}\text{C}$ (68°F) at the condenser/silica gel outlet. Also, periodically check the level and zero of the manometer.

Ambient Temperature _____
 Barometric Pressure _____
 Assumed Moisture % _____
 Probe Length, m (ft) _____
 Nozzle Identification No. _____
 Average Calibrated Nozzle Diameter, cm (in) _____
 Probe Heater Setting _____
 Leak Rate, m³/min, (cfm) _____
 Probe Liner Material _____
 Static Pressure, mm Hg (in. Hg) _____
 Filter No. _____

Schematic of Stack Cross Section

[illegible]

Figure 5. Particulate field data.

6.6.8 If the pressure drop across the filter or sorbent trap becomes too high, making isokinetic sampling difficult to maintain, the filter/sorbent trap may be replaced in the midst of a sample run. Using another complete filter holder/sorbent trap assembly is recommended, rather than attempting to change the filter and resin themselves. After a new filter/sorbent trap assembly is installed, conduct a leak-check. The total particulate weight shall include the summation of all filter assembly catches.

6.6.9 A single train shall be used for the entire sample run, except in cases where simultaneous sampling is required in two or more separate ducts or at two or more different locations within the same duct, or in cases where equipment failure necessitates a change of trains. In all other situations, the use of two or more trains will be subject to the approval of the Administrator.

6.6.10 Note that when two or more trains are used, separate analysis of the front-half (if applicable) organic-module and impinger (if applicable) catches from each train shall be performed, unless identical nozzle sizes were used on all trains. In that case, the front-half catches from the individual trains may be combined (as may the impinger catches), and one analysis of front-half catch and one analysis of impinger catch may be performed.

6.6.11 At the end of the sample run, turn off the coarse-adjust valve, remove the probe and nozzle from the stack, turn off the pump, record the final dry-gas meter reading, and conduct a post-test leak-check. Also, leak-check the pitot lines as described in EPA Method 2. The lines must pass this leak-check in order to validate the velocity-head data.

6.6.12 Calculate percent isokineticity (see Section 10.8) to determine whether the run was valid or another test run should be made.

7.0 SAMPLE RECOVERY

7.1 Preparation:

7.1.1 Proper cleanup procedure begins as soon as the probe is removed from the stack at the end of the sampling period. Allow the probe to cool. When the probe can be safely handled, wipe off all external particulate matter near the tip of the probe nozzle and place a cap over the tip to prevent losing or gaining particulate matter. Do not cap the probe tip tightly while the sampling train is cooling down because this will create a vacuum in the filter holder, drawing water from the impingers into the sorbent module.

7.1.2 Before moving the sample train to the cleanup site, remove the probe from the sample train and cap the open outlet, being careful not to lose any condensate that might be present. Cap the filter inlet.

Remove the umbilical cord from the last impinger and cap the impinger. If a flexible line is used between the organic module and the filter holder, disconnect the line at the filter holder and let any condensed water or liquid drain into the organic module.

7.1.3 Cap the filter-holder outlet and the inlet to the organic module. Separate the sorbent trap section of the organic module from the condensate knockout trap and the gas-conditioning section. Cap all organic module openings. Disconnect the organic-module knockout trap from the impinger train inlet and cap both of these openings. Ground-glass stoppers, Teflon caps, or caps of other inert materials may be used to seal all openings.

7.1.4 Transfer the probe, the filter, the organic-module components, and the impinger/condenser assembly to the cleanup area. This area should be clean and protected from the weather to minimize sample contamination or loss.

7.1.5 Save a portion of all washing solutions (methanol/methylene chloride, Type II water) used for cleanup as a blank. Transfer 200 mL of each solution directly from the wash bottle being used and place each in a separate, prelabeled glass sample container.

7.1.6 Inspect the train prior to and during disassembly and note any abnormal conditions.

7.2 Sample containers:

7.2.1 Container no. 1: Carefully remove the filter from the filter holder and place it in its identified Petri dish container. Use a pair or pairs of tweezers to handle the filter. If it is necessary to fold the filter, ensure that the particulate cake is inside the fold. Carefully transfer to the Petri dish any particulate matter or filter fibers that adhere to the filter-holder gasket, using a dry nylon bristle brush or sharp-edged blade, or both. Label the container and seal with 1-in.-wide Teflon tape around the circumference of the lid.

7.2.2 Container no. 2: Taking care that dust on the outside of the probe or other exterior surfaces does not get into the sample, quantitatively recover particulate matter or any condensate from the probe nozzle, probe fitting, probe liner, and front half of the filter holder by washing these components first with methanol/methylene chloride (1:1 v/v) into a glass container. Distilled water may also be used. Retain a water and solvent blank and analyze in the same manner as with the samples. Perform rinses as follows:

7.2.2.1 Carefully remove the probe nozzle and clean the inside surface by rinsing with the solvent mixture (1:1 v/v methanol/-methylene chloride) from a wash bottle and brushing with a nylon bristle brush. Brush until the rinse shows no visible particles; then make a final rinse of the inside surface with the solvent mix. Brush and rinse the inside parts of the Swagelok fitting with the solvent mix in a similar way until no visible particles remain.

7.2.2.2 Have two people rinse the probe liner with the solvent mix by tilting and rotating the probe while squirting solvent into its upper end so that all inside surfaces will be wetted with solvent. Let the solvent drain from the lower end into the sample container. A glass funnel may be used to aid in transferring liquid washes to the container.

7.2.2.3 Follow the solvent rinse with a probe brush. Hold the probe in an inclined position and squirt solvent into the upper end while pushing the probe brush through the probe with a twisting action; place a sample container underneath the lower end of the probe and catch any solvent and particulate matter that is brushed from the probe. Run the brush through the probe three times or more until no visible particulate matter is carried out with the solvent or until none remains in the probe liner on visual inspection. With stainless steel or other metal probes, run the brush through in the above-prescribed manner at least six times (metal probes have small crevices in which particulate matter can be entrapped). Rinse the brush with solvent and quantitatively collect these washings in the sample container. After the brushing, make a final solvent rinse of the probe as described above.

7.2.2.4 It is recommended that two people work together to clean the probe to minimize sample losses. Between sampling runs, keep brushes clean and protected from contamination.

7.2.2.5 Clean the inside of the front half of the filter holder and cyclone/cyclone flask, if used, by rubbing the surfaces with a nylon bristle brush and rinsing with methanol/methylene chloride (1:1 v/v) mixture. Rinse each surface three times or more if needed to remove visible particulate. Make a final rinse of the brush and filter holder. Carefully rinse out the glass cyclone and cyclone flask (if applicable). Brush and rinse any particulate material adhering to the inner surfaces of these components into the front-half rinse sample. After all solvent washings and particulate matter have been collected in the sample container, tighten the lid on the sample container so that solvent will not leak out when it is shipped to the laboratory. Mark the height of the fluid level to determine whether leakage occurs during transport. Label the container to identify its contents.

7.2.3 Container no. 3: The sorbent trap section of the organic module may be used as a sample transport container, or the spent resin may be transferred to a separate glass bottle for shipment. If the sorbent trap itself is used as the transport container, both ends should be sealed with tightly fitting caps or plugs. Ground-glass stoppers or Teflon caps may be used. The sorbent trap should then be labeled, covered with aluminum foil, and packaged on ice for transport to the laboratory. If a separate bottle is used, the spent resin should be quantitatively transferred from the trap into the clean bottle. Resin that adheres to the walls of the trap should be recovered using a rubber policeman or spatula and added to this bottle.

0010 - 20

Revision 0
Date September 1986

7.2.4 Container no. 4: Measure the volume of condensate collected in the condensate knockout section of the organic module to within +1 mL by using a graduated cylinder or by weighing to within +0.5 g using a triple-beam balance. Record the volume or weight of liquid present and note any discoloration or film in the liquid catch. Transfer this liquid to a prelabeled glass sample container. Inspect the back half of the filter housing and the gas-conditioning section of the organic module. If condensate is observed, transfer it to a graduated or weighing bottle and measure the volume, as described above. Add this material to the condensate knockout-trap catch.

7.2.5 Container no. 5: All sampling train components located between the high-efficiency glass- or quartz-fiber filter and the first wet impinger or the final condenser system (including the heated Teflon line connecting the filter outlet to the condenser) should be thoroughly rinsed with methanol/methylene chloride (1:1 v/v) and the rinsings combined. This rinse shall be separated from the condensate. If the spent resin is transferred from the sorbent trap to a separate sample container for transport, the sorbent trap shall be thoroughly rinsed until all sample-wetted surfaces appear clean. Visible films should be removed by brushing. Whenever train components are brushed, the brush should be subsequently rinsed with solvent mixture and the rinsings added to this container.

7.2.6 Container no. 6: Note the color of the indicating silica gel to determine if it has been completely spent and make a notation of its condition. Transfer the silica gel from the fourth impinger to its original container and seal. A funnel may make it easier to pour the silica gel without spilling. A rubber policeman may be used as an aid in removing the silica gel from the impinger. It is not necessary to remove the small amount of dust particles that may adhere strongly to the impinger wall. Because the gain in weight is to be used for moisture calculations, do not use any water or other liquids to transfer the silica gel. If a balance is available in the field, weigh the container and its contents to 0.5 g or better.

7.3 Impinger water:

7.3.1 Make a notation of any color or film in the liquid catch. Measure the liquid in the first three impingers to within +1 mL by using a graduated cylinder or by weighing it to within +0.5 g by using a balance (if one is available). Record the volume or weight of liquid present. This information is required to calculate the moisture content of the effluent gas.

7.3.2 Discard the liquid after measuring and recording the volume or weight, unless analysis of the impinger catch is required (see Paragraph 4.1.3.7). Amber glass containers should be used for storage of impinger catch, if required.

7.3.3 If a different type of condenser is used, measure the amount of moisture condensed either volumetrically or gravimetrically.

7.4 Sample preparation for shipment: Prior to shipment, recheck all sample containers to ensure that the caps are well secured. Seal the lids of all containers around the circumference with Teflon tape. Ship all liquid samples upright on ice and all particulate filters with the particulate catch facing upward. The particulate filters should be shipped unrefrigerated.

8.0 ANALYSIS

8.1 Sample preparation:

8.1.1 General: The preparation steps for all samples will result in a finite volume of concentrated solvent. The final sample volume (usually in the 1- to 10-mL range) is then subjected to analysis by GC/MS. All samples should be inspected and the appearance documented. All samples are to be spiked with surrogate standards as received from the field prior to any sample manipulations. The spike should be at a level equivalent to 10 times the MDL when the solvent is reduced in volume to the desired level (i.e., 10 mL). The spiking compounds should be the stable isotopically labeled analog of the compounds of interest or a compound that would exhibit properties similar to the compounds of interest, be easily chromatographed, and not interfere with the analysis of the compounds of interest. Suggested surrogate spiking compounds are: deuterated naphthalene, chrysene, phenol, nitrobenzene, chlorobenzene, toluene, and carbon-13-labeled pentachlorophenol.

8.1.2 Condensate: The "condensate" is the moisture collected in the first impinger following the XAD-2 module. Spike the condensate with the surrogate standards. The volume is measured and recorded and then transferred to a separatory funnel. The pH is to be adjusted to pH 2 with 6 N sulfuric acid, if necessary. The sample container and graduated cylinder are sequentially rinsed with three successive 10-mL aliquots of the extraction solvent and added to the separatory funnel. The ratio of solvent to aqueous sample should be maintained at 1:3. Extract the sample by vigorously shaking the separatory funnel for 5 min. After complete separation of the phases, remove the solvent and transfer to a Kuderna-Danish concentrator (K-D), filtering through a bed of precleaned, dry sodium sulfate. Repeat the extraction step two additional times. Adjust the pH to 11 with 6 N sodium hydroxide and reextract combining the acid and base extracts. Rinse the sodium sulfate into the K-D with fresh solvent and discard the desiccant. Add Teflon boiling chips and concentrate to 10 mL by reducing the volume to slightly less than 10 mL and then bringing to volume with fresh solvent. In order to achieve the necessary detection limit, the sample volume can be further reduced to 1 mL by using a micro column K-D or nitrogen blow-down. Should the sample start to exhibit precipitation, the concentration step should be stopped and the sample redissolved with fresh solvent taking the volume to some finite amount. After adding a standard (for the purpose of quantitation by GC/MS), the sample is ready for analysis, as discussed in Paragraph 8.2.

0010 - 22

Revision 0
Date September 1986

8.1.3 Impinger: Spike the sample with the surrogate standards; measure and record the volume and transfer to a separatory funnel. Proceed as described in Paragraph 8.1.2.

8.1.4 XAD-2: Spike the resin directly with the surrogate standards. Transfer the resin to the all-glass thimbles by the following procedure (care should be taken so as not to contaminate the thimble by touching it with anything other than tweezers or other solvent-rinsed mechanical holding devices). Suspend the XAD-2 module directly over the thimble. The glass frit of the module (see Figure 2) should be in the up position. The thimble is contained in a clean beaker, which will serve to catch the solvent rinses. Using a Teflon squeeze bottle, flush the XAD-2 into the thimble. Thoroughly rinse the glass module with solvent into the beaker containing the thimble. Add the XAD-2 glass-wool plug to the thimble. Cover the XAD-2 in the thimble with a precleaned glass-wool plug sufficient to prevent the resin from floating into the solvent reservoir of the extractor. If the resin is wet, effective extraction can be accomplished by loosely packing the resin in the thimble. If a question arises concerning the completeness of the extraction, a second extraction, without a spike, is advised. The thimble is placed in the extractor and the rinse solvent contained in the beaker is added to the solvent reservoir. Additional solvent is added to make the reservoir approximately two-thirds full. Add Teflon boiling chips and assemble the apparatus. Adjust the heat source to cause the extractor to cycle 5-6 times per hr. Extract the resin for 16 hr. Transfer the solvent and three 10-mL rinses of the reservoir to a K-D and concentrate as described in Paragraph 8.1.2.

8.1.5 Particulate filter (and cyclone catch): If particulate loading is to be determined, weigh the filter (and cyclone catch, if applicable). The particulate filter (and cyclone catch, if applicable) is transferred to the glass thimble and extracted simultaneously with the XAD-2 resin.

8.1.6 Train solvent rinses: All train rinses (i.e., probe, impinger, filter housing) using the extraction solvent and methanol are returned to the laboratory as a single sample. If the rinses are contained in more than one container, the intended spike is divided equally among the containers proportioned from a single syringe volume. Transfer the rinse to a separatory funnel and add a sufficient amount of organic-free water so that the methylene chloride becomes immiscible and its volume no longer increases with the addition of more water. The extraction and concentration steps are then performed as described in Paragraph 8.1.2.

8.2 Sample analysis:

8.2.1 The primary analytical tool for the measurement of emissions from hazardous waste incinerators is GC/MS using fused-silica capillary GC columns, as described in Method 8270 in Chapter Four of this manual. Because of the nature of GC/MS instrumentation and the cost associated

with sample analysis, prescreening of the sample extracts by gas chromatography/flame ionization detection (GC/FID) or with electron capture (GC/ECD) is encouraged. Information regarding the complexity and concentration level of a sample prior to GC/MS analysis can be of enormous help. This information can be obtained by using either capillary columns or less expensive packed columns. However, the FID screen should be performed with a column similar to that used with the GC/MS. Keep in mind that GC/FID has a slightly lower detection limit than GC/MS and, therefore, that the concentration of the sample can be adjusted either up or down prior to analysis by GC/MS.

8.2.2 The mass spectrometer will be operated in a full scan (40-450) mode for most of the analyses. The range for which data are acquired in a GC/MS run will be sufficiently broad to encompass the major ions, as listed in Chapter Four, Method 8270, for each of the designated POHCs in an incinerator effluent analysis.

8.2.3 For most purposes, electron ionization (EI) spectra will be collected because a majority of the POHCs give reasonable EI spectra. Also, EI spectra are compatible with the NBS Library of Mass Spectra and other mass spectral references, which aid in the identification process for other components in the incinerator process streams.

8.2.4 To clarify some identifications, chemical ionization (CI) spectra using either positive ions or negative ions will be used to elucidate molecular-weight information and simplify the fragmentation patterns of some compounds. In no case, however, should CI spectra alone be used for compound identification. Refer to Chapter Four, Method 8270, for complete descriptions of GC conditions, MS conditions, and quantitative and quantitative identification.

9.0 CALIBRATION

9.1 Probe nozzle: Probe nozzles shall be calibrated before their initial use in the field. Using a micrometer, measure the inside diameter of the nozzle to the nearest 0.025 mm (0.001 in.). Make measurements at three separate places across the diameter and obtain the average of the measurements. The difference between the high and low numbers shall not exceed 0.1 mm (0.004 in.). When nozzles become nicked, dented, or corroded, they shall be reshaped, sharpened, and recalibrated before use. Each nozzle shall be permanently and uniquely identified.

9.2 Pitot tube: The Type S pitot tube assembly shall be calibrated according to the procedure outlined in Section 4 of EPA Method 2, or assigned a nominal coefficient of 0.84 if it is not visibly nicked, dented, or corroded and if it meets design and intercomponent spacing specifications.

9.3 Metering system:

9.3.1 Before its initial use in the field, the metering system shall be calibrated according to the procedure outlined in APTD-0576. Instead of physically adjusting the dry-gas meter dial readings to correspond to the wet-test meter readings, calibration factors may be used to correct the gas meter dial readings mathematically to the proper values. Before calibrating the metering system, it is suggested that a leak-check be conducted. For metering systems having diaphragm pumps, the normal leak-check procedure will not detect leakages within the pump. For these cases the following leak-check procedure is suggested: Make a 10-min calibration run at $0.00057 \text{ m}^3/\text{min}$ (0.02 cfm); at the end of the run, take the difference of the measured wet-test and dry-gas meter volumes and divide the difference by 10 to get the leak rate. The leak rate should not exceed $0.00057 \text{ m}^3/\text{min}$ (0.02 cfm).

9.3.2 After each field use, the calibration of the metering system shall be checked by performing three calibration runs at a single intermediate orifice setting (based on the previous field test). The vacuum shall be set at the maximum value reached during the test series. To adjust the vacuum, insert a valve between the wet-test meter and the inlet of the metering system. Calculate the average value of the calibration factor. If the calibration has changed by more than 5%, recalibrate the meter over the full range of orifice settings, as outlined in APTD-0576.

9.3.3 Leak-check of metering system: That portion of the sampling train from the pump to the orifice meter (see Figure 1) should be leak-checked prior to initial use and after each shipment. Leakage after the pump will result in less volume being recorded than is actually sampled. The following procedure is suggested (see Figure 6): Close the main valve on the meter box. Insert a one-hole rubber stopper with rubber tubing attached into the orifice exhaust pipe. Disconnect and vent the low side of the orifice manometer. Close off the low side orifice tap. Pressurize the system to 13-18 cm (5-7 in.) water column by blowing into the rubber tubing. Pinch off the tubing and observe the manometer for 1 min. A loss of pressure on the manometer indicates a leak in the meter box. Leaks, if present, must be corrected.

NOTE: If the dry-gas-meter coefficient values obtained before and after a test series differ by >5%, either the test series shall be voided or calculations for test series shall be performed using whichever meter coefficient value (i.e., before or after) gives the lower value of total sample volume.

9.4 Probe heater: The probe-heating system shall be calibrated before its initial use in the field according to the procedure outlined in APTD-0576. Probes constructed according to APTD-0581 need not be calibrated if the calibration curves in APTD-0576 are used.




Figure 6. Leak-check of meter box.

0010 - 26

Revision 0
Date September 1986

9.5 Temperature gauges: Each thermocouple must be permanently and uniquely marked on the casting; all mercury-in-glass reference thermometers must conform to ASTM E-1 63C or 63F specifications. Thermocouples should be calibrated in the laboratory with and without the use of extension leads. If extension leads are used in the field, the thermocouple readings at ambient air temperatures, with and without the extension lead, must be noted and recorded. Correction is necessary if the use of an extension lead produces a change $>1.5\%$.

9.5.1 Impinger, organic module, and dry-gas meter thermocouples: For the thermocouples used to measure the temperature of the gas leaving the impinger train and the XAD-2 resin bed, three-point calibration at ice-water, room-air, and boiling-water temperatures is necessary. Accept the thermocouples only if the readings at all three temperatures agree to $+2^{\circ}\text{C}$ (3.6°F) with those of the absolute value of the reference thermometer.

9.5.2 Probe and stack thermocouple: For the thermocouples used to indicate the probe and stack temperatures, a three-point calibration at ice-water, boiling-water, and hot-oil-bath temperatures must be performed; it is recommended that room-air temperature be added, and that the thermometer and the thermocouple agree to within 1.5% at each of the calibration points. A calibration curve (equation) may be constructed (calculated) and the data extrapolated to cover the entire temperature range suggested by the manufacturer.

9.6 Barometer: Adjust the barometer initially and before each test series to agree to within ± 25 mm Hg (0.1 in. Hg) of the mercury barometer or the corrected barometric pressure value reported by a nearby National Weather Service Station (same altitude above sea level).

9.7 Triple-beam balance: Calibrate the triple-beam balance before each test series, using Class-S standard weights; the weights must be within $\pm 0.5\%$ of the standards, or the balance must be adjusted to meet these limits.

10.0 CALCULATIONS

10.1 Carry out calculations. Round off figures after the final calculation to the correct number of significant figures.

10.2 Nomenclature:

A_n = Cross-sectional area of nozzle, m^2 (ft^2).

B_{ws} = Water vapor in the gas stream, proportion by volume.

C_d = Type S pitot tube coefficient (nominally 0.84 ± 0.02), dimensionless.

I = Percent of isokinetic sampling.

0010 - 27

Revision 0
Date September 1986

- L_a = Maximum acceptable leakage rate for a leak-check, either pre-test or following a component change; equal to 0.00057 m³/min (0.02 cfm) or 4% of the average sampling rate, whichever is less.
- L_i = Individual leakage rate observed during the leak-check conducted prior to the "ith" component change ($i = 1, 2, 3 \dots n$) m³/min (cfm).
- L_p = Leakage rate observed during the post-test leak-check, m³/min (cfm).
- M_d = Stack-gas dry molecular weight, g/g-mole (lb/lb-mole).
- M_w = Molecular weight of water, 18.0 g/g-mole (18.0 lb/lb-mole).
- P_{bar} = Barometric pressure at the sampling site, mm Hg (in. Hg).
- P_s = Absolute stack-gas pressure, mm Hg (in. Hg).
- P_{std} = Standard absolute pressure, 760 mm Hg (29.92 in. Hg).
- R = Ideal gas constant, 0.06236 mm Hg-m³/K-g-mole (21.85 in. Hg-ft³/°R-lb-mole).
- T_m = Absolute average dry-gas meter temperature (see Figure 6), K (°R).
- T_s = Absolute average stack-gas temperature (see Figure 6), K (°R).
- T_{std} = Standard absolute temperature, 293K (528°R).
- V_{lc} = Total volume of liquid collected in the organic module condensate knockout trap, the impingers, and silica gel, mL.
- V_m = Volume of gas sample as measured by dry-gas meter, dscm (dscf).
- $V_m(std)$ = Volume of gas sample measured by the dry-gas meter, corrected to standard conditions, dscm (dscf).
- $V_w(std)$ = Volume of water vapor in the gas sample, corrected to standard conditions, scm (scf).
- V_s = Stack-gas velocity, calculated by Method 2, Equation 2-9, using data obtained from Method 5, m/sec (ft/sec).
- W_a = Weight of residue in acetone wash, mg.
- γ = Dry-gas-meter calibration factor, dimensionless.
- ΔH = Average pressure differential across the orifice meter (see Figure 2), mm H₂O (in. H₂O).

P_w = Density of water, 0.9982 g/mL (0.002201 lb/mL).

θ = Total sampling time, min.

θ_1 = Sampling time interval from the beginning of a run until the first component change, min.

θ_i = Sampling time interval between two successive component changes, beginning with the interval between the first and second changes, min.

θ_p = Sampling time interval from the final (n^{th}) component change until the end of the sampling run, min.

13.6 = Specific gravity of mercury.

60 = sec/min.

100 = Conversion to percent.

10.3 Average dry-gas-meter temperature and average orifice pressure drop: See data sheet (Figure 5, above).

10.4 Dry-gas volume: Correct the sample measured by the dry-gas meter to standard conditions (20°C, 760 mm Hg [68°F, 29.92 in. Hg]) by using Equation 1:

$$V_{m(\text{std})} = V_m \gamma \frac{T_{\text{std}}}{T_m} \frac{P_{\text{bar}} + \Delta H/13.6}{P_{\text{std}}} = K_1 V_m \gamma \frac{P_{\text{bar}} + \Delta H/13.6}{T_m} \quad (1)$$

where:

$K_1 = 0.3858 \text{ K/mm Hg}$ for metric units, or
 $K_1 = 17.64^\circ\text{R/in. Hg}$ for English units.

It should be noted that Equation 1 can be used as written, unless the leakage rate observed during any of the mandatory leak-checks (i.e., the post-test leak-check or leak-checks conducted prior to component changes) exceeds L_a . If L_p or L_i exceeds L_a , Equation 1 must be modified as follows:

- a. Case I (no component changes made during sampling run): Replace V_m in Equation 1 with the expression:

$$V_m - (L_p - L_a)$$

- b. Case II (one or more component changes made during the sampling run): Replace V_m in Equation 1 by the expression:

$$V_m = (L_1 - L_a)\theta_1 - \sum_{i=2}^n (L_i - L_a)\theta_i - (L_p - L_a)\theta_p$$

and substitute only for those leakage rates (L_1 or L_p) that exceed L_a .

10.5 Volume of water vapor:

$$V_{w(std)} = V_{lc} \frac{P_w}{M_w} \frac{RT_{std}}{P_{std}} = K_2 V_{lc} \quad (2)$$

where:

$K_2 = 0.001333 \text{ m}^3/\text{mL}$ for metric units, or
 $K_2 = 0.04707 \text{ ft}^3/\text{mL}$ for English units.

10.6 Moisture content:

$$B_{ws} = \frac{V_{w(std)}}{V_{m(std)} + V_{w(std)}} \quad (3)$$

NOTE: In saturated or water-droplet-laden gas streams, two calculations of the moisture content of the stack gas shall be made, one from the impinger analysis (Equation 3) and a second from the assumption of saturated conditions. The lower of the two values of B_w shall be considered correct. The procedure for determining the moisture content based upon assumption of saturated conditions is given in the Note to Section 1.2 of Method 4. For the purposes of this method, the average stack-gas temperature from Figure 6 may be used to make this determination, provided that the accuracy of the in-stack temperature sensor is $\pm 1^\circ\text{C}$ (2°F).

10.7 Conversion factors:

From	To	Multiply by
scf	m^3	0.02832
g/ft^3	gr/ft^3	15.43
g/ft^3	lb/ft^3	2.205×10^{-3}
g/ft^3	g/m^3	35.31

0010 - 30

Revision 0
Date September 1986

10.8 Isokinetic variation:

10.8.1 Calculation from raw data:

$$I = \frac{100 T_s [K_3 F_{1c} + (V_m/T_m) (P_{bar} + \Delta H/13.6)]}{608 V_s P_s A_n} \quad (4)$$

where:

$K_3 = 0.003454 \text{ mm Hg-m}^3/\text{mL-K}$ for metric units, or
 $K_3 = 0.002669 \text{ in. Hg-ft}^3/\text{mL-}^\circ\text{R}$ for English units.

10.8.2 Calculation for intermediate values:

$$I = \frac{T_s V_{m(std)} P_{std}^{100}}{T_{std} V_{s BA} P_{s 60(1-B_{ws})}} \quad (5)$$

$$= K_4 \frac{T_s V_{m(std)}}{P_s V_{s n} A_B (1-B_{ws})}$$

where:

$K_4 = 4.320$ for metric units, or
 $K_4 = 0.09450$ for English units.

10.8.3 Acceptable results: If $90\% \leq I \leq 110\%$, the results are acceptable. If the results are low in comparison with the standard and I is beyond the acceptable range, or if I is less than 90%, the Administrator may opt to accept the results.

10.9 To determine the minimum sample volume that shall be collected, the following sequence of calculations shall be used.

10.9.1 From prior analysis of the waste feed, the concentration of POHCs introduced into the combustion system can be calculated. The degree of destruction and removal efficiency that is required is used to determine the maximum amount of POHC allowed to be present in the effluent. This may be expressed as:

$$\frac{(WF) (POHC_i \text{ conc}) (100 - \%DRE)}{100} = \text{Max POHC}_i \text{ Mass} \quad (6)$$

where:

WF = mass flow rate of waste feed per hr, g/hr (lb/hr).

POHC_i = concentration of Principal Organic Hazardous Compound (wt %) introduced into the combustion process.

DRE = percent Destruction and Removal Efficiency required.

Max POHC = mass flow rate (g/hr [lb/hr]) of POHC emitted from the combustion source.

10.9.2 The average discharge concentration of the POHC in the effluent gas is determined by comparing the Max POHC with the volumetric flow rate being exhausted from the source. Volumetric flow rate data are available as a result of preliminary Method 1-4 determinations:

$$\frac{\text{Max POHC}_i \text{ Mass}}{DV_{\text{eff}}(\text{std})} = \text{Max POHC}_i \text{ conc} \quad (7)$$

where:

$DV_{\text{eff}}(\text{std})$ = volumetric flow rate of exhaust gas, dscm (dscf).

$\text{POHC}_i \text{ conc}$ = anticipated concentration of the POHC in the exhaust gas stream, g/dscm (lb/dscf).

10.9.3 In making this calculation, it is recommended that a safety margin of at least ten be included:

$$\frac{LDL_{\text{POHC}} \times 10}{\text{POHC}_i \text{ conc}} = V_{\text{TBC}} \quad (8)$$

where:

LDL_{POHC} = detectable amount of POHC in entire sampling train.

NOTE: The whole extract from an XAD-2 cartridge is seldom if ever, injected at once. Therefore, if aliquoting factors are involved, the LDL_{POHC} is not the same as the analytical (or column) detection limit.

V_{TBC} = minimum dry standard volume to be collected at dry-gas meter.

10.10 Concentration of any given POHC in the gaseous emissions of a combustion process:

1) Multiply the concentration of the POHC as determined in Method 8270 by the final concentration volume, typically 10 mL.

$$C_{\text{POHC}} (\text{ug/mL}) \times \text{sample volume (mL)} = \text{amount (ug) of POHC in sample} \quad (9)$$

where:

C_{POHC} = concentration of POHC as analyzed by Method 8270.

2) Sum the amount of POHC found in all samples associated with a single train.

$$\text{Total (ug)} = \text{XAD-2 (ug)} + \text{condensate (ug)} + \text{rinses (ug)} + \text{impinger (ug)} \quad (10)$$

3) Divide the total ug found by the volume of stack gas sampled (m³).

$$(\text{Total ug})/(\text{train sample volume}) = \text{concentration of POHC (ug/m}^3\text{)} \quad (11)$$

11.0 QUALITY CONTROL

11.1 Sampling: See EPA Manual 600/4-77-027b for Method 5 quality control.

11.2 Analysis: The quality assurance program required for this study includes the analysis of field and method blanks, procedure validations, incorporation of stable labeled surrogate compounds, quantitation versus stable labeled internal standards, capillary column performance checks, and external performance tests. The surrogate spiking compounds selected for a particular analysis are used as primary indicators of the quality of the analytical data for a wide range of compounds and a variety of sample matrices. The assessment of combustion data, positive identification, and quantitation of the selected compounds are dependent on the integrity of the samples received and the precision and accuracy of the analytical methods employed. The quality assurance procedures for this method are designed to monitor the performance of the analytical method and to provide the required information to take corrective action if problems are observed in laboratory operations or in field sampling activities.

11.2.1 Field Blanks: Field blanks must be submitted with the samples collected at each sampling site. The field blanks include the sample bottles containing aliquots of sample recovery solvents, unused filters, and resin cartridges. At a minimum, one complete sampling train will be assembled in the field staging area, taken to the sampling area, and leak-checked at the beginning and end of the testing (or for the same total number of times as the actual test train). The filter housing and probe of the blank train will be heated during the sample test. The train will be recovered as if it were an actual test sample. No gaseous sample will be passed through the sampling train.

11.2.2 Method blanks: A method blank must be prepared for each set of analytical operations, to evaluate contamination and artifacts that can be derived from glassware, reagents, and sample handling in the laboratory.

11.2.3 Refer to Method 8270 for additional quality control considerations.

0010 - 33

Revision 0
Date September 1986

12.0 METHOD PERFORMANCE

12.1 Method performance evaluation: Evaluation of analytical procedures for a selected series of compounds must include the sample-preparation procedures and each associated analytical determination. The analytical procedures should be challenged by the test compounds spiked at appropriate levels and carried through the procedures.

12.2 Method detection limit: The overall method detection limits (lower and upper) must be determined on a compound-by-compound basis because different compounds may exhibit different collection, retention, and extraction efficiencies as well as instrumental minimum detection limit (MDL). The method detection limit must be quoted relative to a given sample volume. The upper limits for the method must be determined relative to compound retention volumes (breakthrough).

12.3 Method precision and bias: The overall method precision and bias must be determined on a compound-by-compound basis at a given concentration level. The method precision value would include a combined variability due to sampling, sample preparation, and instrumental analysis. The method bias would be dependent upon the collection, retention, and extraction efficiency of the train components. From evaluation studies to date using a dynamic spiking system, method biases of -13% and -16% have been determined for toluene and 1,1,2,2-tetrachloroethane, respectively. A precision of 19.9% was calculated from a field test data set representing seven degrees of freedom which resulted from a series of paired, unspiked Semivolatile Organic Sampling trains (Semi-VOST) sampling emissions from a hazardous waste incinerator.

13.0 REFERENCES

1. Addendum to Specifications for Incinerator Testing at Federal Facilities, PHS, NCAPC, December 6, 1967.
2. Bursey, J., Homolya, J., McAllister, R., and McGangley, J., Laboratory and Field Evaluation of the Semi-VOST Method, Vols. 1 and 2, U.S. Environmental Protection Agency, EPA/600/4-851/075A, 075B (1985).
3. Martin, R.M., Construction Details of Isokinetic Source-Sampling Equipment, Research Triangle Park, NC, U.S. Environmental Protection Agency, April 1971, PB-203 060/BE, APTD-0581, 35 pp.
4. Rom, J.J., Maintenance, Calibration, and Operation of Isokinetic Source-Sampling Equipment, Research Triangle Park, NC, U.S. Environmental Protection Agency, March 1972, PB-209 022/BE, APTD-0576, 39 pp.
5. Schlickerrieder, L.M., Adams, J.W., and Thrun, K.E., Modified Method 5 Train and Source Assessment Sampling System: Operator's Manual, U.S. Environmental Protection Agency, EPA/600/8-85/003, (1985).

6. Shigehara, R.T., Adjustments in the EPA Nomography for Different Pitot Tube Coefficients and Dry Molecular Weights, Stack Sampling News, 2:4-11 (October 1974).

7. U.S. Environmental Protection Agency, CFR 40 Part 60, Appendix A, Methods 1-5.

8. Vollaro, R.F., A Survey of Commercially Available Instrumentation for the Measurement of Low-Range Gas Velocities, Research Triangle Park, NC, U.S. Environmental Protection Agency, Emissions Measurement Branch, November 1976 (unpublished paper).

0010 - 35

Revision 0
Date September 1986

PREPARATION OF XAD-2 SORBENT RESIN

1.0 SCOPE AND APPLICATION

1.1 XAD-2 resin as supplied by the manufacturer is impregnated with a bicarbonate solution to inhibit microbial growth during storage. Both the salt solution and any residual extractable monomer and polymer species must be removed before use. The resin is prepared by a series of water and organic extractions, followed by careful drying.

2.0 EXTRACTION

2.1 Method 1: The procedure may be carried out in a giant Soxhlet extractor. An all-glass thimble containing an extra-coarse frit is used for extraction of XAD-2. The frit is recessed 10-15 mm above a crenellated ring at the bottom of the thimble to facilitate drainage. The resin must be carefully retained in the extractor cup with a glass-wool plug and stainless steel screen because it floats on methylene chloride. This process involves sequential extraction in the following order.

<u>Solvent</u>	<u>Procedure</u>
Water	Initial rinse: Place resin in a beaker, rinse once with Type II water, and discard. Fill with water a second time, let stand overnight, and discard.
Water	Extract with H ₂ O for 8 hr.
Methyl alcohol	Extract for 22 hr.
Methylene chloride	Extract for 22 hr.
Methylene chloride (fresh)	Extract for 22 hr.

2.2 Method 2:

2.2.1 As an alternative to Soxhlet extraction, a continuous extractor has been fabricated for the extraction sequence. This extractor has been found to be acceptable. The particular canister used for the apparatus shown in Figure A-1 contains about 500 g of finished XAD-2. Any size may be constructed; the choice is dependent on the needs of the sampling programs. The XAD-2 is held under light spring tension between a pair of coarse and fine screens. Spacers under the bottom screen allow for even distribution of clean solvent. The three-necked flask should be of sufficient size (3-liter in this case) to hold solvent




Figure A-1. XAD-2 cleanup extraction apparatus.

equal to twice the dead volume of the XAD-2 canister. Solvent is refluxed through the Snyder column, and the distillate is continuously cycled up through the XAD-2 for extraction and returned to the flask. The flow is maintained upward through the XAD-2 to allow maximum solvent contact and prevent channeling. A valve at the bottom of the canister allows removal of solvent from the canister between changes.

2.2.2 Experience has shown that it is very difficult to cycle sufficient water in this mode. Therefore the aqueous rinse is accomplished by simply flushing the canister with about 20 liters of distilled water. A small pump may be useful for pumping the water through the canister. The water extraction should be carried out at the rate of about 20-40 mL/min.

2.2.3 After draining the water, subsequent methyl alcohol and methylene chloride extractions are carried out using the refluxing apparatus. An overnight or 10- to 20-hr period is normally sufficient for each extraction.

2.2.4 All materials of construction are glass, Teflon, or stainless steel. Pumps, if used, should not contain extractable materials. Pumps are not used with methanol and methylene chloride.

3.0 DRYING

3.1 After evaluation of several methods of removing residual solvent, a fluidized-bed technique has proved to be the fastest and most reliable drying method.

3.2 A simple column with suitable retainers, as shown in Figure A-2, will serve as a satisfactory column. A 10.2-cm (4-in.) Pyrex pipe 0.6 m (2 ft) long will hold all of the XAD-2 from the extractor shown in Figure A-1 or the Soxhlet extractor, with sufficient space for fluidizing the bed while generating a minimum resin load at the exit of the column.

3.3 Method 1: The gas used to remove the solvent is the key to preserving the cleanliness of the XAD-2. Liquid nitrogen from a standard commercial liquid nitrogen cylinder has routinely proved to be a reliable source of large volumes of gas free from organic contaminants. The liquid nitrogen cylinder is connected to the column by a length of precleaned 0.95-cm (3/8-in.) copper tubing, coiled to pass through a heat source. As nitrogen is bled from the cylinder, it is vaporized in the heat source and passes through the column. A convenient heat source is a water bath heated from a steam line. The final nitrogen temperature should only be warm to the touch and not over 40°C. Experience has shown that about 500 g of XAD-2 may be dried overnight by consuming a full 160-liter cylinder of liquid nitrogen.

3.4 Method 2: As a second choice, high-purity tank nitrogen may be used to dry the XAD-2. The high-purity nitrogen must first be passed through a bed

0010 - A - 3

Revision 0
Date September 1986




Figure A-2. XAD-2 fluidized-bed drying apparatus.

of activated charcoal approximately 150 mL in volume. With either type of drying method, the rate of flow should gently agitate the bed. Excessive fluidization may cause the particles to break up.

4.0 QUALITY CONTROL PROCEDURES

4.1 For both Methods 1 and 2, the quality control results must be reported for the batch. The batch must be reextracted if the residual extractable organics are >20 ug/mL by TCO analysis or the gravimetric residue is >0.5 mg/20 g XAD-2 extracted. (See also section 5.1, Method 0010.)

4.2 Four control procedures are used with the final XAD-2 to check for (1) residual methylene chloride, (2) extractable organics (TCO), (3) specific compounds of interest as determined by GC/MS, as described in Section 4.5 below, and (4) residue (GRAV).

4.3 Procedure for residual methylene chloride:

4.3.1 Description: A 1 ± 0.1 -g sample of dried resin is weighed into a small vial, 3 mL of toluene are added, and the vial is capped and well shaken. Five uL of toluene (now containing extracted methylene chloride) are injected into a gas chromatograph, and the resulting integrated area is compared with a reference standard. The reference solution consists of 2.5 uL of methylene chloride in 100 mL of toluene, simulating 100 ug of residual methylene chloride on the resin. The acceptable maximum content is 1,000 ug/g resin.

4.3.2 Experimental: The gas chromatograph conditions are as follows:

6-ft x 1/8-in. stainless steel column containing 10% OV-101 on 100/120 Supelcoport;

Helium carrier at 30 mL/min;

FID operated on 4×10^{-11} A/mV;

Injection port temperature: 250°C;

Detector temperature: 305°C;

Program: 30°C(4 min) 40°C/min 250°C (hold); and

Program terminated at 1,000 sec.

4.4 Procedure for residual extractable organics:

4.4.1 Description: A 20 ± 0.1 -g sample of cleaned, dried resin is weighed into a precleaned alundum or cellulose thimble which is plugged with cleaned glass wool. (Note that 20 g of resin will fill a thimble, and the

TOTAL CHROMATOGRAPHABLE ORGANIC MATERIAL ANALYSIS

1.0 SCOPE AND APPLICATION

1.1 In this procedure, gas chromatography is used to determine the quantity of lower boiling hydrocarbons (boiling points between 90° and 300°C) in the concentrates of all organic solvent rinses, XAD-2 resin and LC fractions - when Method 1 is used (see References, Method 0010) - encountered in Level 1 environmental sample analyses. Data obtained using this procedure serve a twofold purpose. First, the total quantity of the lower boiling hydrocarbons in the sample is determined. Then whenever the hydrocarbon concentrations in the original concentrates exceed 75 ug/m³, the chromatography results are reexamined to determine the amounts of individual species.

The extent of compound identification is limited to representing all materials as normal alkanes based upon comparison of boiling points. Thus the method is not qualitative. In a similar manner, the analysis is semiquantitative; calibrations are prepared using only one hydrocarbon. They are replicated but samples routinely are not.

1.2 Application: This procedure applies solely to the Level 1 C7-C16 gas chromatographic analysis of concentrates of organic extracts, neat liquids, and of LC fractions. Throughout the procedure, it is assumed the analyst has been given a properly prepared sample.

1.3 Sensitivity: The sensitivity of this procedure, defined as the slope of a plot of response versus concentration, is dependent on the instrument and must be verified regularly. TRW experience indicates the nominal range is of the order of 77 uV·V·sec·uL/ng of n-heptane and 79 uV·sec·uL/ng of n-hexadecane. The instrument is capable of perhaps one hundredfold greater sensitivity. The level specified here is sufficient for Level 1 analysis.

1.4 Detection limit: The detection limit of this procedure as written is 1.3 ng/uL for a 1 uL injection of n-decane. This limit is arbitrarily based on defining the minimum detectable response as 100 uv·sec. This is an easier operational definition than defining the minimum detection limit to be that amount of material which yields a signal twice the noise level.

1.5 Range: The range of the procedure will be concentrations of 1.3 ng/uL and greater.

1.6 Limitations

1.6.1 Reporting limitations: It should be noted that a typical environmental sample will contain compounds which: (a) will not elute in the specified boiling ranges and thus will not be reported, and/or (b)

resin will float out unless well plugged.) The thimble containing the resin is extracted for 24 hr with 200-mL of pesticide-grade methylene chloride (Burdick and Jackson pesticide-grade or equivalent purity). The 200-mL extract is reduced in volume to 10-mL using a Kuderna-Danish concentrator and/or a nitrogen evaporation stream. Five μ L of that solution are analyzed by gas chromatography using the TCO analysis procedure. The concentrated solution should not contain >20 μ g/mL of TCO extracted from the XAD-2. This is equivalent to 10 μ g/g of TCO in the XAD-2 and would correspond to 1.3 mg of TCO in the extract of the 130-g XAD-2 module. Care should be taken to correct the TCO data for a solvent blank prepared (200 mL reduced to 10 mL) in a similar manner.

4.4.2 Experimental: Use the TCO analysis conditions described in the revised Level 1 manual (EPA 600/7-78-201).

4.5 GC/MS Screen: The extract, as prepared in paragraph 4.4.1, is subjected to GC/MS analysis for each of the individual compounds of interest. The GC/MS procedure is described in Chapter Four, Method 8270. The extract is screened at the MDL of each compound. The presence of any compound at a concentration >25 μ g/mL in the concentrated extract will require the XAD-2 to be recleaned by repeating the methylene chloride step.

4.6 Methodology for residual gravimetric determination: After the TCO value and GC/MS data are obtained for the resin batch by the above procedures, dry the remainder of the extract in a tared vessel. There must be <0.5 mg residue registered or the batch of resin will have to be extracted with fresh methylene chloride again until it meets this criterion. This level corresponds to 25 μ g/g in the XAD-2, or about 3.25 mg in a resin charge of 130 g.

0010 - A - 6

Revision 0
Date September 1986

will not elute from the column at all and thus will not be reported. Consequently, the organic content of the sample as reported is a lower bound and should be regarded as such.

1.6.2 Calibration limitations: Quantitation is based on calibration with n-decane. Data should therefore be reported as, e.g., mg C₈/m³ as n-decane. Since response varies linearly with carbon number (over a wide range the assumption may involve a 20% error), it is clear that heptane (C₇) detected in a sample and quantitated as decane will be overestimated. Likewise, hexadecane (C₁₆) quantitated as decane will be underestimated. From previous data, it is estimated the error involved is on the order of 6-7%.

1.6.3 Detection limitations: The sensitivity of the flame ionization detector varies from compound to compound. However, n-alkanes have a greater response than other classes. Consequently, using an n-alkane as a calibrant and assuming equal responses of all other compounds tends to give low reported values.

2.0 SUMMARY OF METHOD

2.1 A mL aliquot of all 10-mL concentrates is disbursed for GC-TCO analysis. With boiling point-retention time and response-amount calibration curves, the data (peak retention times and peak areas) are interpreted by first summing peak areas in the ranges obtained from the boiling point-retention time calibration. Then, with the response-amount calibration curve, the area sums are converted to amounts of material in the reported boiling point ranges.

2.2 After the instrument is set up, the boiling point-retention time calibration is effected by injecting a mixture of n-C₇ through n-C₁₆ hydrocarbons and operating the standard temperature program. Response-quantity calibrations are accomplished by injecting n-decane in n-pentane standards and performing the standard temperature program.

2.3 Definitions

2.3.1 GC: Gas chromatography or gas chromatograph.

2.3.2 C₇-C₁₆ n-alkanes: Heptane through hexadecane.

2.3.3 GCA temperature program: 4 min isothermal at 60°C, 10°C/min from 60° to 220°C.

2.3.4 TRW temperature program: 5 min isothermal at room temperature, then program from 30°C to 250°C at 15°C/min.

3.0 INTERFERENCES

Not applicable.

4.0 APPARATUS AND MATERIALS

4.1 Gas chromatograph: This procedure is intended for use on a Varian 1860 gas chromatograph, equipped with dual flame ionization detectors and a linear temperature programmer. Any equivalent instrument can be used provided that electrometer settings, etc., be changed appropriately.

4.2 Gases:

4.2.1 Helium: Minimum quality is reactor grade. A 4A or 13X molecular sieve drying tube is required. A filter must be placed between the trap and the instrument. The trap should be recharged after every third tank of helium.

4.2.2 Air: Zero grade is satisfactory.

4.2.3 Hydrogen: Zero grade.

4.3 Syringe: Syringes are Hamilton 701N, 10 uL, or equivalent.

4.4 Septa: Septa will be of such quality as to produce very low bleed during the temperature program. An appropriate septum is Supelco Microsep 138, which is Teflon-backed. If septum bleed cannot be reduced to a negligible level, it will be necessary to install septum swingers on the instrument.

4.5 Recorder: The recorder of this procedure must be capable of not less than 1 mV full-scale display, a 1-sec time constant and 0.5 in. per min chart rate.

4.6 Integrator: An integrator is required. Peak area measurement by hand is satisfactory but too time-consuming. If manual integration is required, the method of "height times width at half height" is used.

4.7 Columns:

4.7.1 Preferred column: 6 ft x 1/8 in. O.D. stainless steel column of 10% OV-101 on 100/120 mesh Supelcoport.

4.7.2 Alternate column: 6 ft x 1/8 in. O.D. stainless steel column of 10% OV-1 (or other silicon phase) on 100/120 mesh Supelcoport.

4.8 Syringe cleaner: Hamilton syringe cleaner or equivalent connected to a suitable vacuum source.

5.0 REAGENTS

5.1 Pentane: "Distilled-in-Glass" (reg. trademark) or "Nanograde" (reg. trademark) for standards and for syringe cleaning.

0010 - 8 - 3

Revision 0
Date September 1986

5.2 Methylene chloride: "Distilled-in-Glass" (reg. trademark) or "Nanograde" (reg. trademark) for syringe cleaning.

6.0 SAMPLING HANDLING AND PRESERVATION

6.1 The extracts are concentrated in a Kuderna-Danish evaporator to a volume less than 10 mL. The concentrate is then quantitatively transferred to a 10-mL volumetric flask and diluted to volume. A 1-mL aliquot is taken for both this analysis and possible subsequent GC/MS analysis and set aside in the sample bank. For each GC-TCO analysis, obtain the sample sufficiently in advance to allow it to warm to room temperature. For example, after one analysis is started, return that sample to the sample bank and take the next sample.

7.0 PROCEDURES

7.1 Setup and checkout: Each day, the operator will verify the following:

7.1.1 That supplies of carrier gas, air and hydrogen are sufficient, i.e., that each tank contains > 100 psig.

7.1.2 That, after replacement of any gas cylinder, all connections leading to the chromatograph have been leak-checked.

7.1.3 That the carrier gas flow rate is 30 ± 2 mL/min, the hydrogen flow rate is 30 ± 2 mL/min, and the air flow rate is 300 ± 20 mL/min.

7.1.4 That the electrometer is functioning properly.

7.1.5 That the recorder and integrator are functioning properly.

7.1.6 That the septa have been leak-checked (leak-checking is effected by placing the soap bubble flow meter inlet tube over the injection port adaptors), and that no septum will be used for more than 20 injections.

7.1.7 That the list of samples to be run is ready.

7.2 Retention time calibration:

7.2.1 To obtain the temperature ranges for reporting the results of the analyses, the chromatograph is given a normal boiling point-retention time calibration. The n-alkanes, their boiling points, and data reporting ranges are given in the table below:

	<u>NBP, °C</u>	<u>Reporting Range, °C</u>	<u>Report As</u>
n-heptane	98	90-110	C7
n-octane	126	110-140	C8
n-nonane	151	140-160	C9
n-decane	174	160-180	C10
n-undecane	194	180-200	C11
n-dodecane	214	200-220	C12
n-tridecane	234	220-240	C13
n-tetradecane	252	240-260	C14
n-pentadecane	270	260-280	C15
n-hexadecane	288	280-300	C16

7.2.2 Preparation of standards: Preparing a mixture of the C7-C16 alkanes is required. There are two approaches: (1) use of a standards kit (e.g., Polyscience Kit) containing bottles of mixtures of selected n-alkanes which may be combined to produce a C7-C16 standard; or (2) use of bottles of the individual C7-C16 alkanes from which accurately known volumes may be taken and combined to give a C7-C16 mixture.

7.2.3 Procedure for retention time calibration: This calibration is performed at the start of an analytical program; the mixture is chromatographed at the start of each day. To attain the required retention time precision, both the carrier gas flow rate and the temperature program specifications must be observed. Details of the procedure depend on the instrument being used. The general procedure is as follows:

7.2.3.1 Set the programmer upper limit at 250°C. If this setting does not produce a column temperature of 250°C, find the correct setting.

7.2.3.2 Set the programmer lower limit at 30°C.

7.2.3.3 Verify that the instrument and samples are at room temperature.

7.2.3.4 Inject 1 µL of the n-alkane mixture.

7.2.3.5 Start the integrator and recorder.

7.2.3.6 Allow the instrument to run isothermally at room temperature for five min.

7.2.3.7 Shut the oven door.

7.2.3.8 Change the mode to Automatic and start the temperature program.

7.2.3.9 Repeat Steps 1-9 a sufficient number of times so that the relative standard deviation of the retention times for each peak is <5%.

0010 - B - 5

Revision 0
Date September 1986

7.3 Response calibration:

7.3.1 For the purposes of a Level 1 analysis, response-quantity calibration with n-decane is adequate. A 10- μ L volume of n-decane is injected into a tared 10 mL volumetric flask. The weight injected is obtained and the flask is diluted to the mark with n-pentane. This standard contains about 730 ng n-decane per μ L n-pentane. The exact concentration depends on temperature, so that a weight is required. Two serial tenfold dilutions are made from this standard, giving standards at about 730, 73, and 7.3 ng n-decane per μ L n-pentane, respectively.

7.3.2 Procedure for response calibration: This calibration is performed at the start of an analytical program and monthly thereafter. The most concentrated standard is injected once each day. Any change in calibration necessitates a full calibration with new standards. Standards are stored in the refrigerator locker and are made up monthly.

7.3.2.1 Verify that the instrument is set up properly.

7.3.2.2 Set electrometer at 1×10^{-10} A/mV.

7.3.2.3 Inject 1 μ L of the highest concentration standard.

7.3.2.4 Run standard temperature program as specified above.

7.3.2.5 Clean syringe.

7.3.2.6 Make repeated injections of all three standards until the relative standard deviations of the areas of each standard are $\leq 5\%$.

7.4 Sample analysis procedure:

7.4.1 The following apparatus is required:

7.4.1.1 Gas chromatograph set up and working.

7.4.1.2 Recorder, integrator working.

7.4.1.3 Syringe and syringe cleaning apparatus.

7.4.1.4 Parameters: Electrometer setting is 1×10^{-10} A/mV; recorder is set at 0.5 in./min and 1 mV full-scale.

7.4.2 Steps in the procedure are:

7.4.2.1 Label chromatogram with the data, sample number, etc.

7.4.2.2 Inject sample.

7.4.2.3 Start integrator and recorder.

7.4.2.4 After isothermal operation for 5 min, begin temperature program.

7.4.2.5 Clean syringe.

7.4.2.6 Return sample; obtain new sample.

7.4.2.7 When analysis is finished, allow instrument to cool. Turn chromatogram and integrator output and data sheet over to data analyst.

7.5 Syringe cleaning procedure:

7.5.1 Remove plunger from syringe.

7.5.2 Insert syringe into cleaner; turn on aspirator.

7.5.3 Fill pipet with pentane; run pentane through syringe.

7.5.4 Repeat with methylene chloride from a separate pipet.

7.5.5 Flush plunger with pentane followed by methylene chloride.

7.5.6 Repeat with methylene chloride.

7.6 Sample analysis decision criterion: The data from the TCO analyses of organic extract and rinse concentrates are first used to calculate the total concentration of C7-C16 hydrocarbon-equivalents (Paragraph 7.7.3) in the sample with respect to the volume of air actually sampled, i.e., ug/m^3 . On this basis, a decision is made both on whether to calculate the quantity of each n-alkane equivalent present and on which analytical procedural pathway will be followed. If the total organic content is great enough to warrant continuing the analysis -- $>500 \text{ ug}/\text{m}^3$ -- a TCO of less than $75 \text{ ug}/\text{m}^3$ will require only LC fractionation and gravimetric determinations and IR spectra to be obtained on each fraction. If the TCO is greater than $75 \text{ ug}/\text{m}^3$, then the first seven LC fractions of each sample will be reanalyzed using this same gas chromatographic technique.

7.7 Calculations:

7.7.1 Boiling Point - Retention Time Calibration: The required data for this calibration are on the chromatogram and on the data sheet. The data reduction is performed as follows:

7.7.1.1 Average the retention times and calculate relative standard deviations for each n-hydrocarbon.

0010 - B - 7

Revision 0
Date September 1986

7.7.1.2 Plot average retention times as abscissae versus normal boiling points as ordinates.

7.7.1.3 Draw in calibration curve.

7.7.1.4 Locate and record retention times corresponding to boiling ranges 90-100, 110-140, 140-160, 160-180, 180-200, 200-220, 220-240, 240-260, 260-280, 280-300°C.

7.7.2 Response-amount calibration: The required data for this calibration are on the chromatogram and on the data sheet. The data reduction is performed as follows:

7.7.2.1 Average the area responses of each standard and calculate relative standard deviations.

7.7.2.2 Plot response (uv-sec) as ordinate versus ng/uL as abscissa.

7.7.2.3 Draw in the curve. Perform least squares regression and obtain slope (uV-sec·uL/ng).

7.7.3 Total C7-C16 hydrocarbons analysis: The required data for this calculation are on the chromatogram and on the data sheet. The data reduction is performed as follows:

7.7.3.1 Sum the areas of all peaks within the retention time range of interest.

7.7.3.2 Convert this area (uV-sec) to ng/uL by dividing by the weight response for n-decane (uV-sec.uL/ng).

7.7.3.3 Multiply this weight by the total concentrate volume (10 mL) to get the weight of the C7-C16 hydrocarbons in the sample.

7.7.3.4 Using the volume of gas sampled or the total weight of sample acquired, convert the result of Step 7.7.3.3 above to ug/m³.

7.7.3.5 If the value of total C7-C16 hydrocarbons from Step 7.7.3.4 above exceeds 75 ug/m³, calculate individual hydrocarbon concentrations in accordance with the instructions in Paragraph 7.7.5.5 below.

7.7.4 Individual C7-C16 n-Alkane Equivalent Analysis: The required data from the analyses are on the chromatogram and on the data sheet. The data reduction is performed as follows:

7.7.4.1 Sum the areas of peaks in the proper retention time ranges.

0010 - B - 8

Revision 0
Date September 1986

7.7.4.2 Convert areas ($\mu\text{V}\cdot\text{sec}$) to $\text{ng}/\mu\text{L}$ by dividing by the proper weight response ($\mu\text{V}\cdot\text{sec}\cdot\mu\text{L}/\text{ng}$).

7.7.4.3 Multiply each weight by total concentrate volume (10 mL) to get weight of species in each range of the sample.

7.7.4.4 Using the volume of gas sampled on the total weight of sample acquired, convert the result of Step 7.7.4.3 above to $\mu\text{g}/\text{m}^3$.

8.0 QUALITY CONTROL

8.1 Appropriate QC is found in the pertinent procedures throughout the method.

9.0 METHOD PERFORMANCE

9.1 Even relatively comprehensive error propagation analysis is beyond the scope of this procedure. With reasonable care, peak area reproducibility of a standard should be of the order of 1% RSD. The relative standard deviation of the sum of all peaks in a fairly complex waste might be of the order of 5-10%. Accuracy is more difficult to assess. With good analytical technique, accuracy and precision should be of the order of 10-20%.

10.0 REFERENCES

1. Emissions Assessment of Conventional Stationary Combustion Systems: Methods and Procedure Manual for Sampling and Analysis, Interagency Energy/Environmental R&D Program, Industrial Environmental Research Laboratory, Research Triangle Park, NC 27711, EPA-600/7-79-029a, January 1979.

APPENDIX K
CALCULATION EQUATIONS

METHOD 2
CALCULATION EQUATIONS

$$\bar{V}_s = 85.49 C_p (\sqrt{\Delta p})_{avg} \sqrt{\frac{T_{s(avg)}}{P_s M_s}}$$

$$Q_{s,d} = 60 (1 - B_{ws}) \bar{V}_s A \left(\frac{528}{T_{s(avg)}} \right) \left(\frac{P_s}{29.92} \right)$$

$$Q_a = 60 \bar{V}_s A$$

$$\dot{m}_s = \frac{4.995 Q_{s,d} G_d}{1 - B_{ws}}$$

$$RH^* = 100 (vp_{wdb} - 0.0003641 P_s (T_{db} - T_{wdb})) / vp_{wdb}$$

$$B_{ws}^* = RH(vp_{wdb}) / P_s$$

$$\rho = \frac{4.585 \times 10^{-2} P_s M_s}{T_s (avg)}$$

*Alternate equations for calculating moisture content from wet bulb and dry bulb data.

032294-G:STACKWPMETHODS-EQ.15

SYMBOLS

A	=	Cross Sectional area of stack, SQ. FT.
A_n	=	Cross sectional area of nozzle, SQ. FT.
B_{wv}	=	Water vapor in gas stream, proportion by volume
C_p	=	Pitot tube coefficient, dimensionless
C_s	=	Concentration of particulate matter in stack gas, wet basis, GR/ACF
C_d	=	Concentration of particulate matter in stack gas, dry basis, corrected to standard conditions, GR/DSCF
EA	=	Excess air, percent by volume
γ	=	Dry test meter correction factor, dimensionless
G_d	=	Specific gravity (relative to air), dimensionless
I	=	Isokinetic variation, percent by volume
M_d	=	Molecular weight of stack gas, dry basis, g/g - mole.
m_w	=	Mass flow of wet flue gas, LB/HR
m_p	=	Particulate mass flow, LB/HR
M_s	=	Molecular weight of stack gas, wet basis, g/g mole.
M_p	=	Total amount of particulate matter collected, g
P_{bar}	=	Atmospheric pressure, IN. HG. (uncompensated)
P_s	=	Stack static gas pressure, IN. WC.
P_s	=	Absolute pressure of stack gas, IN. HG.
P_{std}	=	Standard absolute pressure, 29.92 IN. HG.
A_s	=	Actual volumetric stack gas flow rate, ACFM
$Q_{s,d}$	=	Dry volumetric stack gas flow rate corrected to standard conditions, DSCFM
RH	=	Relative humidity, %

032294-G:STACKWPMETHODSS-EQ.15

T_{db}	=	Dry bulb temperature of stack gas, °F
T_{wb}	=	Wet bulb temperature of stack gas, °F
$T_{m(avg)}$	=	Absolute average dry gas meter temperature, °R
$T_{s(avg)}$	=	Absolute average stack temperature, °R
T_{std}	=	Standard absolute temperature, 528 °R (68 °F)
θ	=	Total sampling time, min.
V_{lc}	=	Total volume of liquid collected in impingers and silica gel, ml
V_m	=	Volume of gas sample as measured by dry gas meter, CF
$V_{m(std)}$	=	Volume of gas sample measured by the dry gas meter corrected to standard conditions, DSCF
$V_{w(std)}$	=	Volume of water vapor in the gas sample corrected to standard conditions, SCF
$\bar{V}_s$	=	Average actual stack gas velocity, FT/SEC
vp_{db}	=	Vapor pressure at T_{db} , IN. HG.
vp_{wb}	=	Vapor pressure at T_{wb} , IN. HG.
$\overline{\Delta H}$	=	Average pressure differential across the orifice meter, IN. WC.
ΔP	=	Velocity pressure of stack gas, IN. WC.
γ	=	Dry test meter correction coefficient, dimensionless
ρ	=	Actual gas density, LB/ACF

METHOD 3
CALCULATION EQUATIONS

$$\%EA = \frac{100(\%O_2 - 0.5\% CO)}{0.264\% N_2 - \%O_2 + 0.5\% CO}$$

$$M_d = 0.44(\%CO_2) + 0.32 (\%O_2) + 0.28 (\%N_2 + \%CO)$$

$$M_s = M_d (I - B_{ws}) + 0.18 B_{ws}$$

$$B_{ws} = \frac{V_{w(sst)}}{V_{w(sst)} + V_{m(sst)}}$$

032294-G:STACKWPMETHODSS-EQ.15

METHOD 5
CALCULATION EQUATIONS

$$V_{m(std)} = 17.63 V_m \gamma \left(\frac{P_{bar} + \overline{\Delta H}/13.6}{T_{m(avg)}} \right)$$

$$V_{w(std)} = 0.0472 V_{Is}$$

$$B_{ws} = \frac{V_{w(std)}}{V_{w(std)} + V_{m(std)}}$$

$$I = 0.0944 \left(\frac{T_{s(avg)} V_{m(std)}}{P_s V_s A_n \theta (I - B_{ws})} \right)$$

$$C_s = \frac{15.43 M_p}{V_{m(std)}}$$

$$C_d = \frac{272.3 M_p P_s}{T_{s(avg)} (V_{w(std)} + V_{m(std)})}$$

$$(\dot{m}_p)_1 = 8.5714 \times 10^{-3} C_s Q_{s,d}$$

$$(\dot{m}_p)_2 = \frac{1.3228 \times 10^{-1} M_p A}{\theta A_n}$$

$$\dot{m}_p = \frac{(\dot{m}_p)_1 + (\dot{m}_p)_2}{2}$$

CALCULATION EQUATIONS

METHOD 7

$$V_{m(std)} = 17.64 (V_f - 25) \left[\frac{P_f}{T_f} - \frac{P_i}{T_i} \right]$$

$$C_s = 6.243 \times 10^{-5} \frac{M}{V_{m(std)}}$$

$$E = \frac{2090 C_s F}{20.9 - \bar{B} \alpha_2}$$

$$C_s (GR/DSCF) = 7000 C_s$$

$$C_s (MG/DSCM) = 1.60186 \times 10^7 C_s$$

$$C_s (ppm-dry) = 8.37552 \times 10^6 C_s$$

$$C_s (ppm-3\% O_2) = 8.37552 \times 10^6 C_s \left\{ 1 + \left[\frac{\bar{B} \alpha_2 - 3}{20.9 - \bar{B} \alpha_2} \right] \right\}$$

$$C_s (ppm-wet) = 8.37552 \times 10^6 C_s \left(1 - \frac{MC}{100} \right)$$

GASTACK\WP\METHODS\EQ.M7

SYMBOLS

$\bar{B} \text{ O}_2$	=	Average oxygen content in flue gas, % v/v
C_s	=	Concentration of nitrogen oxides in flue gas, dry basis, corrected to standard conditions, LB/DSCF
$C_s \text{ (GR/DSCF)}$	=	Concentration of nitrogen oxides in flue gas, dry basis, corrected to standard conditions, GR/DSCF
$C_s \text{ (MG/DSCM)}$	=	Concentration of nitrogen oxides in flue gas, dry basis, corrected to standard conditions, MG/DSCM
E	=	Emission factor, LB/10 ⁶ BTU
F	=	F-Factor for given fuel type, DSCF/10 ⁶ BTU
M	=	Mass of nitrogen oxides as nitrogen dioxide in gas sample, ug
MC	=	Moisture content of flue gas, %
P_f	=	Final absolute pressure in flask, IN. HG
P_i	=	Initial absolute pressure in flask, IN. HG
$C_s \text{ (ppm-dry)}$	=	Concentration of nitrogen oxides in flue gas, dry basis, (v/v), ppm
$C_s \text{ (ppm-3% O}_2\text{)}$	=	Concentration of nitrogen oxides in flue gas, dry basis, corrected to 3% O ₂ , (v/v) ppm
$C_s \text{ (ppm-wet)}$	=	Concentration of nitrogen oxides in flue gas, wet basis, (v/v), ppm
T_f	=	Final absolute temperature in flask, °R
T_i	=	Initial absolute temperature in flask, °R
V_f	=	Volume of flask and valve, cc
$V_{\text{m(std)}}$	=	Sample volume at standard conditions, dry basis, cc

G:\STACK\WP\METHODS\SEQ.M7

CALCULATION EQUATIONS

METHOD 10

$$CO\text{-}PPM\text{-}DRY = CO_{CO_2} - \text{free, dry, avg} (1 - CO_{2,d}/100)$$

$$CO\text{-}PPM\text{-}WET = CO\text{-}PPM\text{-}DRY (1 - MC/100)$$

$$GR/DSCF = 5.0885 \times 10^{-4} (CO\text{-}PPM\text{-}DRY)$$

$$mg/dscm = 1.165 (CO\text{-}PPM\text{-}DRY)$$

$$\dot{m} = 8.5714 \times 10^{-3} (GR/DSCF) (Q_{s,d})$$

$$E = \frac{2.9857 \times 10^{-3} F_d (GR/DSCF)}{20.9 - O_{2,d}}$$

where:

$CO_{CO_2} - \text{free, dry, avg}$

= average of two determinations of carbon monoxide on a dry, CO_2 - free integrated flue gas sample reported in ppm by volume

$CO_{2,d}$ = carbon dioxide concentration of flue gas on a dry percent by volume basis

$O_{2,d}$ = oxygen concentration of flue gas on a dry percent by volume basis

G:\STACK\WPMETHODS\EQ.M10

MC	=	moisture content of flue gas on a percent by volume basis
CO-PPM-DRY	=	carbon monoxide concentration in ppm by volume on a dry basis
CO-PPM-WET	=	carbon monoxide concentration in ppm by volume on a wet or actual basis
GR/DSCF	=	concentration of carbon monoxide in flue gas on a grains per dry standard cubic foot basis (68 °F, 29.92 IN. HG.)
mg/dscm	=	concentration of carbon monoxide in flue gas on a milligrams per dry standard cubic meter basis (60 °F, 29.92 IN. HG.)
$\dot{m}$	=	emissions or mass rate of carbon monoxide on a LB/HR basis
$Q_{s,d}$	=	volumetric flow rate of flue gas in dry standard cubic feet per minute
E	=	emission factor of carbon monoxide in pounds of carbon monoxide emitted per million BTU heat input (LB/MMBTU)
F_d	=	F-Factor of respective fuel in dry standard cubic feet of exhaust gas at 0% oxygen per million BTU of heat input (DSCF/MMBTU)

G:\STACK\WP\METHODS\SEQ.M10

METHOD 25A

Total Gaseous Organics Calculation Equation

$$\text{GR C/SCF} = 2.180 \times 10^{-4} (\text{ppm, w})$$

$$\text{GR C/DSCF} = 2.180 \times 10^{-4} (\text{ppm, w}) / (1 - \text{MC}/100)$$

$$\text{LB C/HR} = 8.5714 \times 10^{-3} (\text{GR/DSCF}) (\text{DSCFM})$$

where:

GR C/SCF = grains of total gaseous organics as carbon per actual (wet) standard cubic foot

GR C/DSCF = grains of total gaseous organics as carbon per dry standard cubic foot

LB C/HR = pounds of total gaseous organics as carbon emitted per hour

Note 1: The Ratfisch Model RS 55 Heated FID Analyzer as normally operated with a heated filter, sample line and heated detector oven gives ppm, w.

Note 2: ppm, C = ppm as carbon = 3(ppm propane)

031894-G:\STACK\WPMETHODSS-EQ.07

Concentration Calculation Equations for Benzene

1. Structure:



2. Molecular weight:

78.11 g/g-mole

3. Mass/volume Concentration:

$$C_{ug/Nm^3} = \frac{35.314 \text{ m}}{V_{std}}$$

where m = Total mass of Benzene
in sample in micrograms (ug), and

V_{std} = Total volume of exhaust gas or air
sampled in dry standard cubic feet
(DSCF).

4. Volume/volume Concentration:

$$\frac{C_6H_6}{C_{ppmv}} = \left(\frac{mg}{Nm^3} \right) \times \left(\frac{24,054 \text{ mL}}{78.11 \text{ mg}} \right) = ppmv$$

$$\frac{C_6H_6}{C_{ppmv}} = 0.3080 \left(\frac{C_6H_6}{C_{mg/Nm^3}} \right)$$

$$C_{ppmv} = 3.08 \times 10^{-5} \cdot C_{ug/Nm^3}$$

5. Notes:

see Excel spreadsheet

6: \STACK\EXCEL\TEMPLATE\BENZENE.TEM

Derived by: D. DESPENDate: 9-10-90

CALCULATION EQUATIONS

Chromotropic Acid Method for Formaldehyde

$$m_t = \frac{m_a V_{soln}}{V_{aliquot}}$$

where:

m_t	=	mass of formaldehyde in total sample in ug
m_a	=	mass of formaldehyde in aliquot in ug
V_{soln}	=	volume of total sample in cc (500 cc normally)
$V_{aliquot}$	=	volume of aliquot taken for analysis in cc
PPM-DRY	=	$\frac{0.0283 m_t}{V_{std}}$
PPM-WET	=	PPM-DRY (1-MC/100)
GR/DSCF	=	5.45×10^{-4} (PPM-DRY)
mg/dscm	=	1.249 (PPM-DRY)
$\dot{m}$	=	8.5714×10^{-3} (GR/DSCF) ($Q_{g,d}$)

where:

PPM-DRY	=	concentration of formaldehyde in parts per million by volume on a dry basis
PPM-WET	=	concentration of formaldehyde in parts per million by volume on an actual or wet basis
MC	=	moisture content of gas on a percent by volume basis
GR/DSCF	=	concentration of formaldehyde in gas on a grains per dry standard cubic foot basis (68 °F, 29.92 IN. HG.)
$\dot{m}$	=	emission or mass rate of formaldehyde in pounds per hour (LB/HR)
V_{std}	=	dry gas volume as measured by the dry gas meter, corrected to standard conditions (at 68 °F and 1 atmosphere) DSCF

031894-G:\STACK\WPMETHODSS-EQ.03

CALCULATION EQUATIONS

Gas Chromatographic Method for Phenol in Air

$$\text{PPM-DRY} = \frac{9.03 \times 10^{-3} m_t}{V_{std}}$$

$$\text{PPM-WET} = \text{PPM-DRY} (1 - \text{MC}/100)$$

$$\text{GR/DSCF} = 1.709 \times 10^{-3} (\text{PPM-DRY})$$

$$\text{mg/dscm} = 3.913 (\text{PPM-DRY})$$

$$m = 8.5714 \times 10^{-3} (\text{GR/DSCF}) (Q_{std})$$

where:

PPM-DRY = concentration of phenol in gas in parts per million by volume on a dry basis

PPM-WET = concentration of phenol in gas in parts per million by volume on an actual or wet basis

MC = moisture content of gas on a percent by volume basis

GR/DSCF = concentration of phenol in gas on a grains per dry standard cubic foot basis (68 °F, 29.92 IN. HG.)

m = emission or mass rate of phenol in pounds per hour (LB/HR)

Q_{std} = volumetric flow rate of stack gas in dry standard cubic feet per minute (DSCFM)

030994-GASTACK\WPMETHODS-EQ.01

CALCULATION OF PAH EMISSION RATES

in g/sec and 10⁻⁶g/sec

$\dot{m}$ (g/sec)

$$= 4.716 \times 10^{-10} C_s (\text{ug/m}^3) Q_{s,d} (\text{DSCFM})$$

$\dot{m}$ (10⁻³g/sec)

$$= 4.716 \times 10^{-7} C_a (\text{ug/m}^3) Q_{s,d} (\text{DSCFM})$$

$\dot{m}$ (10⁻⁶g/sec)

$$= 4.716 \times 10^{-4} C_s (\text{ug/m}^3) Q_{s,d} (\text{DSCFM})$$

where:

$$Q_s = \text{ug/dsm}^3$$

$$Q_{s,d} = \text{DSCF/MIN}$$

K-16

Page 1

Page 2

6-7451.BEZ

Report No. 6-7451

LOUISIANA PACIFIC CORPORATION
Hayward, Wisconsin

BENZENE

TEST 5 LINE 2 DRYER RTO STACK

RUN	Vstd (DSCF)	MASS (ug)	CONC (ug/Nm3)	CONC (ppmv)	CONC (GR/DSCF)	FLOW (DSCFM)	E-RATE (LB/HR)
1	1.6	16	353	0.108767	0.00015432	72800	0.096297
2	2.11	33	552	0.170110	0.00024136	72800	0.150606
3	2.19	17	274	0.084431	0.00011979	72800	0.074751
AVG				0.121103			0.10722

TEST 15 Line 2 Thermal Oil Heater Stack

RUN	Vstd (DSCF)	MASS (ug)	CONC (ug/Nm3)	CONC (ppmv)	CONC (GR/DSCF)	FLOW (DSCFM)	E-RATE (LB/HR)
1	2.136	2.1	35	0.010693	1.5172E-05	16830	< 0.002189
2	2.155	35	574	0.176652	0.00025064	16090	0.034567
3	2.211	98	1565	0.482098	0.00068402	16290	0.095508
				0.223148			0.04409

		LOUISIANA PACIFIC	Report No. 6-7451
		HAYWARD, WI	
		Oxides of Nitrogen Calculations	
LINE 2 DRYER RTO STACK			
TEST 6	NOX ppm	Flow	LB/HR
1	15.2	70700	7.70
2	13.4	72250	6.94
3	19.6	72250	10.14
AVG	18.1		8.26
LINE 2 CORE DRYER DUCT			
TEST 7	NOX ppm	Flow	LB/HR
1	23.3	28356	4.73057
2	23.3	29359	4.900473
3	23.6	28827	4.873627
AVG	23.4		4.8
LINE 2 SURFACE DRYER DUCT			
TEST 8	NOX ppm	Flow	LB/HR
1	30	27324	5.872275
2	30.2	27592	5.969404
3	31.8	27872	6.34945
AVG	30.7		6.1
LINE 2 PRESS VENT RTO STACK			
TEST 11	NOX ppm	Flow	LB/HR
1	22.4	67951	10.90397
2	20.3	68965	10.02918
3	18.5	64190	8.507069
AVG	20.4		9.8
LINE 2 PRESS RTO INLET			
TEST 12	NOX ppm	Flow	LB/HR
1	2.1	76341	1.148466
2	2.7	77087	1.491028
3	3.1	77444	1.719849
AVG	2.6		1.5
LINE 2 THERMAL OIL HEATER STACK			
TEST 16	NOX ppm	Flow	LB/HR
1	60.8	17550	7.644015
2	62.6	16980	7.614701
3	62.9	17670	7.962108
AVG	62.1		7.7

LOUISIANA PACIFIC CORPORATION					Report No. 6-7451				
Hayward, Wisconsin									
TEST 6	LINE 2 DRYER RTO STACK								
Gas Concentration Correction Calculations									
NOX Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	16.3	1.2	1.2	1.20	145	145	145	145.00	15.2
2	15.0	2.2	1.0	1.60	145	149	145	147.00	13.4
3	21.2	3.0	1.0	2.00	145	143	145	144.00	19.6
Avg									16.1
CO Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	202.1	0	0	0.00	299	299	300	299.50	201.8
2	265.9	0	0	0.00	299	299	299	299.00	265.9
3	216.5	0	0	0.00	299	294	299	296.50	218.3
Avg									228.7
CO2 Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	4.1	0	0	0.00	10.5	10.4	10.5	10.45	4.1
2	4.3	0	0	0.00	10.5	10.5	10.5	10.50	4.3
3	4.3	0	0	0.00	10.5	10.4	10.5	10.45	4.3
Avg									4.2
O2 Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	16.2	0	0	0.00	13.1	12.9	13.1	13.00	16.3
2	16.4	1	0	0.50	13.1	13.1	13.1	13.10	16.5
3	16.3	0	0.1	0.05	13.1	13.1	13.1	13.10	16.3
Avg									16.4

TEST 7	LINE 2 CORE DRYER DUCT								
	Gas Concentration Correction Calculations								
	NOx Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	23.3	1	0	0.50	73.7	71	74	72.50	23.3
2	25.26	3	0	1.50	73.7	77	76	76.50	23.3
3	27.23	4	3	3.50	73.7	78	77	77.50	23.6
Avg									23.4
	CO Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	680.78	-3	0	-1.50	620	607	612	609.50	692.3
2	1281.38	4	4	4.00	620	620	624	622.00	1281.5
3	1121.27	3	4	3.50	620	613	620	616.50	1130.5
avg									1034.8
	CO2 Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	4.59	0.3	0.2	0.25	10.9	10.8	10.8	10.80	4.5
2	5.02	-0.1	0	-0.05	10.9	10.8	11	10.90	5.0
3	5.09	0	0	0.00	10.9	10.9	10.8	10.85	5.1
Avg									4.9
	O2 Calculations								
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	16.32	0.1	0	0.05	13.5	13.5	13.4	13.45	16.4
2	15.82	0	0	0.00	13.5	13.6	13.6	13.60	15.7
3	15.92	0	0	0.00	13.5	13.5	13.6	13.55	15.9
Avg									16.0

TEST 8 LINE 2 SURFACE DRYER DUCT									
Gas Concentration Correction Calculations									
NOX Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	29.9	0	0	0.00	73.7	73	74	73.50	30.0
2	30.3	0	0	0.00	73.7	74	74	74.00	30.2
3	31.9	0	0	0.00	73.7	74	74	74.00	31.8
Avg									30.6
TEST 11 LINE 2 PRESS VENT RTO STACK									
Gas Concentration Correction Calculations									
NOX Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	24.2	3.36	0	1.68	145	149.4	145	147.20	22.4
2	22.5	4	1.42	2.71	145	146.5	141.7	144.10	20.3
3	19.1	0	2	1.00	145	140	145	142.50	18.5
Avg									20.4
CO Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cga
1	18.1	-1	0	-0.50	299	296.4	299	297.70	18.6
2	21.3	0	0.5	0.25	299	292	296.4	294.20	21.4
3	19.6	0	0	0.00	299	295	299.5	297.25	19.7
Avg									19.9
TEST 12 LINE 2 PRESS RTO INLET									
Gas Concentration Correction Calculations									
NOX Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	2.1	0	0	0.00	73.7	80	79	79.50	1.9
2	2.7	0	0	0.00	73.7	78	80	79.00	2.5
3	3.1	0	0	0.00	73.7	78	78	78.00	2.9
Avg									2.5
CO Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	10.7	0	0	0.00	150	150	150	150.00	10.7
2	8.2	0	0	0.00	150	150	150	150.00	8.2
3	13.4	0	0	0.00	150	150	150	150.00	13.4
Avg									10.8

TEST 16 LINE 2 THERMAL OIL HEATER STACK									
Gas Concentration Correction Calculations									
NOx Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	60.9	0	0	0.00	73.7	72.96	74.74	73.85	60.8
2	62.6	0	0	0.00	73.7	74.36	72.96	73.66	62.6
3	63.5	0	0	0.00	73.7	74.38	74.36	74.37	62.9
Avg									62.1
CO Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	157.1	3.91	8	5.96	593	580	581	580.50	156.0
2	281.3	6.02	3.91	4.97	593	571	573	572.00	289.0
3	206.7	4.31	6.02	5.17	593	577	571	574.00	210.1
.vg									218.4
CO2 Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	5.37	0.03	0	0.02	10.95	10.98	11.00	10.99	5.34
2	6.15	0.03	0.03	0.03	10.95	10.94	10.98	10.96	6.13
3	6.31	0.01	0.03	0.02	10.95	10.86	10.94	10.90	6.33
Avg									5.93
O2 Calculations									
	<i>Cbar</i>				<i>Cma</i>				
	OUR CONC	ZERO	ZERO		CONC	Upscale	Upscale		
RUN #	(ppm,d)	(Final)	(Initial)	Co	(Upscale)	(Final)	(Initial)	Cm	Cgas
1	15.5	0.40	0.00	0.20	13.45	13.83	13.50	13.67	15.3
2	13.8	0.05	0.01	0.03	13.45	13.45	13.48	13.47	13.8
3	13.4	0.23	0.05	0.14	13.45	13.52	13.45	13.49	13.4
Avg									14.1

APPENDIX L
OPERATIONAL DATA

HAYWARD LINE 2 THERMAL OIL , DRYER & PRESS TESTS

<u>CONTENTS</u>	<u>PAGE</u>
TEST SCHEDULES	1
LINE 2 THERMAL OIL , DRYER & PRESS DATA SUMMARY	2-3
 LINE 2 THERMAL OIL HEATER MARCH 18, 1996 FORMALDEHYDE,NOX,CO,CO2,O2 BENZENE,PM,VE,FORMALDEHYDE	
PRODUCTION/SUMMARY	4-5
PRESS REPORT	6-7
PRESS CHARTS	8-10
BOARD WEIGHTS/THICKNESSES	11-12
 LINE 2 DRYER RTO STACK & INLET MARCH 19, 1996 PM,METH.,CO,VE,PHENOL,NOX	
PRODUCTION/SUMMARY	13
PRESS REPORT	14-15
PRESS CHARTS	16-18
DRYER READINGS	19-20
DRYER CHARTS	21-24
CORE E- TUBE CHARTS	25
SURFACE E- TUBE CHARTS	26
DRYER RTO READINGS	27
DRYER RTO CHART	28
BOARD WEIGHTS/THICKNESSES	29-31
 LINE 2 DRYER RTO STACK MARCH 20, 1996 FORMALDEHYDE	
PRODUCTION/SUMMARY	32
PRESS REPORT	33-34
PRESS CHARTS	35-37
DRYER READINGS	38-39
DRYER CHARTS	40-43
CORE E- TUBE CHARTS	44
SURFACE E- TUBE CHARTS	45
DRYER RTO READINGS	46
DRYER RTO CHART	47
BOARD WEIGHTS/THICKNESSES	48-50
 LINE 2 DRYER RTO STACK MARCH 20-21, 1996 POM	
PRODUCTION/SUMMARY	51
PRESS REPORT	52-54
PRESS CHARTS	55-59
DRYER READINGS	60-62
DRYER CHARTS	63-70
CORE E- TUBE CHARTS	71-72
SURFACE E- TUBE CHARTS	73-74
DRYER RTO READINGS	75-76
DRYER RTO CHART	77-78
BOARD WEIGHTS/THICKNESSES	79-83

LINE 2 DRYER RTO STACK & CORE/SRF. DUCT MARCH 19-20, 1996
NOX,CO,CO2,THC,M2

PRODUCTION/SUMMARY	84
PRESS REPORT	85-88
PRESS CHARTS	89-94
DRYER READINGS	95-98
DRYER CHARTS	99-106
CORE E- TUBE CHARTS	107-108
SURFACE E- TUBE CHARTS	109-110
DRYER RTO READINGS	111-112
DRYER RTO CHART	113-114
BOARD WEIGHTS/THICKNESSES	115-120

LINE 2 DRYER RTO STACK MARCH 21, 1996
BENZENE

PRODUCTION/SUMMARY	121
PRESS REPORT	122
PRESS CHARTS	123-124
DRYER READINGS	125
DRYER CHARTS	126-129
CORE E- TUBE CHARTS	130
SURFACE E- TUBE CHARTS	131
DRYER RTO READINGS	132
DRYER RTO CHART	133
BOARD WEIGHTS/THICKNESSES	134-135

LINE 2 PRESS VENT RTO STACK MARCH 19, 1996
FORMALDEHYDE

PRODUCTION/SUMMARY	136
PRESS REPORT	137-138
PRESS CHARTS	139-141
PRESS RTO REPORT	142
PRESS RTO CHARTS	143
MICRO-MOTIONS RESIN USAGE	144-146
BOARD WEIGHTS/THICKNESSES	147-149

LINE 2 PRESS VENT RTO STACK/RTO INLET MARCH 20, 1996
PM,METHANE,CO,VE

PRODUCTION/SUMMARY	150
PRESS REPORT	151-152
PRESS CHARTS	153-155
PRESS RTO REPORT	156-157
PRESS RTO CHARTS	158
MICRO-MOTIONS RESIN USAGE	159-163
BOARD WEIGHTS/THICKNESSES	164-166

LINE 2 PRESS VENT RTO STACK/RTO INLET MARCH 20, 1996
NOX,CO,CO2,THC,M2,O2

PRODUCTION/SUMMARY	167
PRESS REPORT	168-169
PRESS CHARTS	170-172
PRESS RTO REPORT	173-174
PRESS RTO CHARTS	175
MICRO-MOTIONS RESIN USAGE	176-180
BOARD WEIGHTS/THICKNESSES	181-183

KONUS EFB REPORTS	184-189
-------------------	---------

HAYWARD TESTING MARCH 18th - 21st
Test schedule

Line 2 Thermal Oil Stack

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
3-18	FORM./NOX/CO	1036-1142	1220-1323	1405-1510
	CO2/O2			
3-18	BENZ./PM/VE	1800-1903	1930-2032	2100-2202

Line 2 Dryer RTO Stack & Inlet

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
3-19	PM/METH./CO/VE	1030-1140	1320-1429	1500-2037
	PHENOL/NOX	(E-TUBE H2O OFF)	(E-TUBE H2O ON)	

Line 2 Press Vent RTO Stack

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
3-19	FORMALDEHYDE	1030-1145	1222-1336	1440-1554

Line 2 Dryer RTO Stack

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
3-20	FORMALDEHYDE	0830-1017	1100-1210	1245-1354

Line 2 Dryer RTO Stack

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
3-20	POM	1440-1724		
		(E-TUBE H2O ON)		
3-21	POM		0815-1050	1135-1408
			(E-TUBE H2O ON)	(E-TUBE H2O OFF)

Line 2 Dryer RTO Stack & Core/Surf. Dryer Duct

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
3-19	NOX/CO/CO2/THC	1320-1420		
	M2	(E-TUBE H2O ON)		
3-20	NOX/CO/CO2/THC		1000-1100	1200-1300
	M2		(E-TUBE H2O OFF)	(E-TUBE H2O OFF)

Line 2 Press Vent RTO Stack/ RTO Inlet

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
3-20	PM/METH./CO/VE	1012-1114	1135-1241	1305-1411
3-20	NOX/CO/CO2/THC	1650-1750	1815-1930	2015-2115
	M2/O2			

Line 2 Dryer RTO Stack

	<u>POLLUTANT</u>	<u>RUN #1</u>	<u>RUN #2</u>	<u>RUN #3</u>
3-21	BENZENE	0816-0906	0939-1038	1135-1235

APPROXIMATE TEST TIMES ONLY - SEE INTERPOLL SHEETS
 FOR EXACT TIMES.

HAYWARD LINE 2 TESTING MARCH 18 - 21, 1996

Line 2 process data summary

LINE 2 THERMAL OIL HEATER MARCH 18, 1996 - FORMALDEHYDE,NOX,CO,CO2,O2

20.04 =Production rate in Tons per hour
1.09 =K3 estimated Tons per hour of fuel burned based on fuel measurement
19.61 =K3 estimated mmBTU per hour input based on fuel measurement
1.03 =K4 estimated Tons per hour of fuel burned based on fuel measurement
18.49 =K4 estimated mmBTU per hour input based on fuel measurement
2.12 =Total tons of dry bark per hour input
38.11 =Total mmBTU per hour input

LINE 2 THERMAL OIL HEATER MARCH 18, 1996 - BENZENE,PM,VE

19.43 =Production rate in Tons per hour
1.06 =K3 estimated Tons per hour of fuel burned based on fuel measurement
19.02 =K3 estimated mmBTU per hour input based on fuel measurement
1.02 =K4 estimated Tons per hour of fuel burned based on fuel measurement
18.35 =K4 estimated mmBTU per hour input based on fuel measurement
2.08 =Total tons of dry bark per hour input
37.37 =Total mmBTU per hour input

LINE 2 DRYER RTO STACK & INLET MARCH 19, 1996 - PM,METH.,CO,VE,PHENOL,NOX

20.50 =PressProduction rate in Tons per hour
49,675 = Production rate of both dryers in pounds per hour
2.09 =Surface fuel burned in tons per hour
2.26 =Core fuel burned in tons per hour
4.34 =Total fuel (both dryers) burned in tons per hour
49.98% =average incoming moisture percent (both dryers)
5.59% =average dry moisture percent (both dryers)
1,479 =average inlet temperature (both dryers)

LINE 2 DRYER RTO STACK MARCH 20, 1996 - FORMALDEHYDE

21.03 =PressProduction rate in Tons per hour
52,161 = Production rate of both dryers in pounds per hour
2.37 =Surface fuel burned in tons per hour
2.68 =Core fuel burned in tons per hour
5.05 =Total fuel (both dryers) burned in tons per hour
46.95% =average incoming moisture percent (both dryers)
5.55% =average dry moisture percent (both dryers)
1,452 =average inlet temperature (both dryers)

LINE 2 DRYER RTO STACK MARCH 20-21, 1996 - POM

20.96 =PressProduction rate in Tons per hour
51,952 = Production rate of both dryers in pounds per hour
2.34 =Surface fuel burned in tons per hour
2.67 =Core fuel burned in tons per hour
5.01 =Total fuel (both dryers) burned in tons per hour
47.34% =average incoming moisture percent (both dryers)
5.65% =average dry moisture percent (both dryers)
1,474 =average inlet temperature (both dryers)

**LINE 2 DRYER RTO STACK &CORE/SRF. DUCT MARCH 19-20, 1996
NOX,CO,CO2,THC,M2**

20.34 =PressProduction rate in Tons per hour
50,630 = Production rate of both dryers in pounds per hour
2.37 =Surface fuel burned in tons per hour
2.61 =Core fuel burned in tons per hour
4.98 =Total fuel (both dryers) burned in tons per hour
48.50% =average incoming moisture percent (both dryers)
5.53% =average dry moisture percent (both dryers)
1,496 =average inlet temperature (both dryers)

LINE 2 DRYER RTO STACK MARCH 21, 1996 - BENZENE

20.01 =PressProduction rate in Tons per hour
50,148 = Production rate of both dryers in pounds per hour
2.39 =Surface fuel burned in tons per hour
2.67 =Core fuel burned in tons per hour
5.06 =Total fuel (both dryers) burned in tons per hour
46.63% =average incoming moisture percent (both dryers)
5.86% =average dry moisture percent (both dryers)
1,458 =average inlet temperature (both dryers)

LINE 2 PRESS VENT RTO STACK MARCH 19, 1996 - FORMALDEHYDE

20.15 =Plant Production rate in Tons per hour
505.33 =MDI resin usage in pounds per hour
1.25% =MDI resin usage as % of finished product
913.00 =Liquid phenolic resin usage in pounds per hour (100% solids)
2.27% =Liquid phenolic resin usage as % of finished product (100% solids)
271.00 =Wax usage in pounds per hour
0.67% =Wax usage as % of finished product

**LINE 2 PRESS VENT RTO STACK/RTO INLET MARCH 20, 1996
PM,METHANE,CO,VE**

19.81 =Plant Production rate in Tons per hour
468.50 =MDI resin usage in pounds per hour
1.18% =MDI resin usage as % of finished product
888.00 =Liquid phenolic resin usage in pounds per hour (100% solids)
2.24% =Liquid phenolic resin usage as % of finished product (100% solids)
277.00 =Wax usage in pounds per hour
0.70% =Wax usage as % of finished product

**LINE 2 PRESS VENT RTO STACK/RTO INLET MARCH 20, 1996
NOX,CO,CO2,THC,M2,O2**

20.46 =Plant Production rate in Tons per hour
453.00 =MDI resin usage in pounds per hour
1.11% =MDI resin usage as % of finished product
877.67 =Liquid phenolic resin usage in pounds per hour (100% solids)
2.14% =Liquid phenolic resin usage as % of finished product (100% solids)
311.00 =Wax usage in pounds per hour
0.76% =Wax usage as % of finished product

HAYWARD LINE 2 MARCH 18, 1996

THERMAL OIL STACK - FORMALDEHYDE/NOX/CO/CO2/O2

DATA TIME: START= 10:30 END= 15:15 HOURS= 4.75

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices per unit over the testing period.

7/16"
per/peice 47.78
per/ 8' x 16' 191.12

PLANT PRODUCTION RATE

4.75 =hours during testing
83 =pressloads
996 =no. of 8'x16' boards produced (pressloads x 8 boards per load)
190,360 =lbs of finished product (boards produced x weight of finished board)
40,076 =lbs of finished product per hour (lbs of finished product / hours)
20.04 =tons of finished product per hour (lbs of finished product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY BARK INPUT

K3

12.3 =K3 fuel calibration in pounds per count
1,398 =K3 counts during testing hours
17,195 =K3 lbs of wet fuel burned during testing
4.75 =hours during testing
39.80% =average moisture content of fuel
10,352 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))
2,179.29 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
1.09 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
9,000 =estimated BTU content per pound of dry fuel,
19.61 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

K4

13.4 =K4 fuel calibration in pounds per count
1,210 =K4 counts during testing hours
16,214 =K4 lbs of wet fuel burned during testing
4.75 =hours during testing
39.80% =average moisture content of fuel
9,761 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))
2,054.91 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
1.03 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
9,000 =estimated BTU content per pound of dry fuel,
18.49 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

FUEL BURNING RATE ESTIMATED TEMPERATURE DIFFERENTIAL

K3

451.80 =average incoming oil temperature on degrees f.
491.90 =average outgoing oil temperature on degrees f.
60 =temperature differential at 100% capacity in degrees f
40.1 =actual temperature differential
23.9 =maximum mmbtu input at 100% capacity
15.97 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input
9,000 =estimated BTU content per pound of dry fuel,
0.89 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

K4

455.60 =average incoming oil temperature on degrees f.
490.60 =average outgoing oil temperature on degrees f.
60 =temperature differential at 100% capacity in degrees f
35.0 =actual temperature differential
23.9 =maximum mmbtu input at 100% capacity
13.94 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input
9,000 =estimated BTU content per pound of dry fuel,
0.77 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

HAYWARD LINE 2 MARCH 18, 1996
THERMAL OIL STACK - BENZENE/PM/VE
DATA TIME START= 18:00 END= 22:15 HOURS= 4.25

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices
per unit over the testing period.

7/16"
per/peice 47.78
per/ 8' x 16' 191.12

PLANT PRODUCTION RATE

4.25 =hours during testing
72 =pressloads
864 =no. of 8'x16' boards produced (pressloads x 8 boards per load)
165,131 =lbs of finished product (boards produced x weight of finished board)
38,854 =lbs of finished product per hour (lbs of finished product / hours)
19.43 =tons of finished product per hour (lbs of finished product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY BARK INPUT

K3

12.3 =K3 fuel calibration in pounds per count
1,221 =K3 counts during testing hours
15,018 =K3 lbs of wet fuel burned during testing
4.25 =hours during testing
40.18% =average moisture content of fuel
8,984 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))
2,113.87 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
1.06 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
9,000 =estimated BTU content per pound of dry fuel,
19.02 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

K4

13.4 =K4 fuel calibration in pounds per count
1,081 =K4 counts during testing hours
14,485 =K4 lbs of wet fuel burned during testing
4.25 =hours during testing
40.18% =average moisture content of fuel
8,665 =total pounds of dry fuel burned during testing (wet pounds x (1- moisture content))
2,038.86 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
1.02 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
9,000 =estimated BTU content per pound of dry fuel,
18.35 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

FUEL BURNING RATE ESTIMATED TEMPERATURE DIFFERENTIAL

K3

461.14 =average incoming oil temperature on degrees f.
500.53 =average outgoing oil temperature on degrees f.
60 =temperature differential at 100% capacity in degrees f
39.4 =actual temperature differential
23.9 =maximum mmbtu input at 100% capacity
15.69 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input
9,000 =estimated BTU content per pound of dry fuel,
0.87 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

K4

463.26 =average incoming oil temperature on degrees f.
501.91 =average outgoing oil temperature on degrees f.
60 =temperature differential at 100% capacity in degrees f
38.6 =actual temperature differential
23.9 =maximum mmbtu input at 100% capacity
15.39 =estimated mmbtu input per hour (actual temp. diff. / max temp. diff.) x max mmbtu input
9,000 =estimated BTU content per pound of dry fuel,
0.86 =estimated tons of dry fuel burned per hour during testing (btu input / btu content of dry fuel/2000)

PRESS REPORT - LINE 1 ②
 OPERATOR Holverson SHIFT: 1st DATE: 3-18-96 CREW: B-II
 THICKNESS 1/4 7/16 PRESS LOS: 16 1/4" 167 7/16
 OVERALL DECOMPRESSION
 TIMER: 157 TIME: 15
 PRESS TOTAL
 TEMP: 215° REJECTS:

LINE SPEED	THICKNESS	FROM	TO
52	1/4 S.R.	7:00	8:10
59	7/16	8:10	12:40
53	7/16	12:40	1:10
59	7/16	1:10	2:00

LOG COUNT: 906

F.C.O.S. HYD. RADIATOR: ✓ TIME
 PRESS BLOWN DOWN: ✓
 SPINNER HEADS FLUSHED: ✓ TIME
 SURFACE BLENDER HOSED: ✓ TIME
 FORMER HYD RADIATOR: ✓ TIME

DOWNTIME		DOWNTIME (MINS)			K E Y	REASONS FOR DOWNTIME
FROM	TO	M	E	O		
8:00	8:07	7				Changed F.C.O.S. Hydr. hose
8:19	8:20	1				Delay at saws - Board change
12:20	12:34		14			Bad contact in F.C.O.S. beam c
3:50	3:52		2			Unloader occupied limit back
3:56	3:58	2				Manual Unload ↗
4:08	4:12		4			Changed out Unloader occupie
4:26	4:28	2				Stalled & conv.
4:50	5:21	31				BS. Former rake-back jamme
						in doffing roles.

DOWNTIME CODE: M - MECHANICAL ⑥3 E - ELECTRICAL O - OPERATOR

PRESS REPORT - LINE 1 Q
OPERATOR D. SATELDATE: 3-18-96SHIFT: PMCREW: ATHICKNESS 7/16PRESS LBS. 2017/16OVERALL
TIMER: 157DECOMPRESSION
TIME: 115PRESS
TEMP: 215TOTAL
REJECTS: =LOG COUNT: 1357

LINE SPEED	THICKNESS	FROM	TO
59	7/16	7:00	
43	9/16	6:39	

F.C.O.S. HYD. RADIATOR: 5:20 TIMEPRESS BLOWN DOWN: 5:20SPINNER HEADS FLUSHED: = TIMESURFACE BLENDER HOSED: = TIMEFORMER HYD RADIATOR: = TIME

DOWNTIME		DOWNTIME (MINS)			KEY	REASONS FOR DOWNTIME
FROM	TO	M	E	O		
8:43	8:46				3	STAKES JAMMED
2:25	2:27				2	STAKES JAMMED
6:35	6:39				4	DEER BAGHOUSE PLUGGED

DOWNTIME CODE:

M - MECHANICAL


E - ELECTRICAL

O - OPERATOR


PRESS CHAR

3/18/96


0700 - 150



LINE 4
 PRESS CHART
 3/18/96
 1500 - 1900



LINE 4
PRESS CL
3/18/96
1900-C



DATE: 3-18-96
 SHIFT/CREW: 1-B
 OPERATOR: JmW

8 2 4320
 1/4"
 7/16"
 18 2-3
 9036

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
2		36 1/2 ^{called 70 1/2}	64	4338 lbs	39 5/8
4	4326 ^{called 73}	37 ^{called 74 1/2}	66		39 1/2
6		36 1/4	68	4227 lbs	39 1/4
			70		39 1/8
2		39 3/4	72	4204 ^{called 456}	39 3/8
4	4293 lbs	39 1/2	74		39 5/8
6		39 5/8	76	4361 lbs	39 5/8
8	4362 lbs	39 3/4	78		39 3/4
10		39 1/4	80	4266 lbs	39 5/8
12	4386 ^{called 452}	39 7/8	82		39 1/2
14		39 5/8	84	4251 lbs	39 1/2
16	4325 lbs	39 3/8			
18		39 1/2			
20	4351 lbs	39 1/2			
22		39 1/2			
24	4338 lbs	39 5/8			
26		39 1/2			
28	4331 lbs	39 1/2			
30		39 1/2			
32	4401 ^{called 120 1/2}	39 5/8			
34		39 1/2			
36	4295 lbs	39 1/4			
38		39 1/4			
40	4284 lbs	39 1/4			
42		39 call			
44	4197 lbs	39 1/8			
46		39 1/2			
48	4233 lbs	39 5/8			
50		39 1/2			
52	4246 lbs	39 1/2			
54		39 3/8			
56	4228 lbs	39 3/8			
58		39 1/2			
60	4304 lbs	39 5/8			
62		39 1/2			

DATE: _____
 SHIFT/CREW: _____
 OPERATOR: _____

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
71	6000	39 3/4			
72	✓ #4292	39 3/8			
73		39 3/8			
74		39 1/2			
75		39 1/2			
76	#4405	39 3/4			
77		39 3/8			
78		39 3/4			
79		40			
80	#4514	39 1/2			
81		39 3/8			
82		39 3/8			
83		39 3/8			
84	#4511	39 1/2			
85		39 3/8			
86		39 1/2			
87		39 3/8			
88	#4555	39 3/8			
89		39 1/2			
90		39 1/2			
91		39 1/2			
92	#4624	40			
93		39 3/4			
94		39 3/4			
95		39 3/4			
96	#4448	39 3/4			
97		39 1/2			
98		39 1/2			
99		39 1/2			
100	#4366	39 3/4			
101		39 3/4			
102		39 1/2			
103		39 1/2			
104		39 1/2			

HAYWARD LINE 2 DRYER RTO STACK & INLET MARCH 19th 1996

PM/METH/CO/VE/PHENOL/NOX

DATA TIME: START= 10:30 END= 20:37 HOURS= 10.12

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices per unit over the testing period.

1/2"

per/peice 54.34

per/ 8' x 16' 217.34

PLANT PRODUCTION RATE

10.12 =hours during testing

159 =pressloads

1,908 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

414,692 =lbs of finished product (boards produced x weight of finished board)

40,991 =lbs of finished product per hour (lbs of finished product / hours)

20.50 =tons of finished product per hour (lbs of finished product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY DRY FUEL INPUT

SURFACE

10 =SURFACE fuel calibration in pounds per count

4,222 =SURFACE counts during testing hours

42,220 =SURFACE lbs of fuel burned during testing

10.12 =hours during testing

4,173 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.09 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

35.9 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,506 =average inlet temperature

49.98 =average incoming moisture percent

5.34 =average dry moisture percent

CORE

10 =CORE fuel calibration in pounds per count

4,563 =CORE counts during testing hours

45,630 =CORE lbs of fuel burned during testing

10.12 =hours during testing

4,510 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.26 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

38.8 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,451 =average inlet temperature

49.98 =average incoming moisture percent

5.83 =average dry moisture percent

DRYER THROUGHPUT RATE

8,684 =Total pounds of fuel burned per hour in Core and Surface Dryer

40,991 =lbs of finished product per hour (lbs of finished product / hours)

49,675 =Pounds of material produced by the dryer per hour (dry basis, assumming fuel balances)

2,756 = weight of trim per hour at 6.3% of finished product

5,928 =weight of screened fines per hour (total fuel - trim)

11.93% =resulting loss to fines as percentage of dryer throughput

PRESS REPORT - LINE 1 ②
 OPERATOR H. Johnson SHIFT: 1st DATE: 3-19-96 CREW: VS-LT
 THICKNESS 714 PRESS LBS: 137 1/2 156 1/2
 OVERALL TIMER: 157 | 174 DECOMPRESSION TIME: 15 | 18
 PRESS TEMP: 205 TOTAL REJECTS: _____

LINE SPEED	TURNS	FROM	TO
43	7/14	7:00	8:00
42	1/2	8:00	8:30
50	1/2	8:30	8:45
55	1/2	8:45	7:00

LOG COUNT: 1346


F.C.O.S. HYD. RADIATOR: ✓ TIME
 PRESS BLOWN DOWN: _____
 SPINNER HEADS FLUSHED: ✓ TIME
 SURFACE BLENDER HOSED: _____ TIME
 FORMER HYD RADIATOR: ✓ TIME

DOWNTIME		DOWNTIME (MINS)			K E Y	REASONS FOR DOWNTIME
FROM	TO	M	E	O		
7:01	7:04	3				Stacker Jam
9:20	10:05	45				No Surface Infeed
11:51	1:54	3				Pulsed Backhouse
2:32	2:35	3				" "
6:01	6:05	4				" " "


DOWNTIME CODE: M - MECHANICAL 50 E - ELECTRICAL O - OPERATOR

15


LINE II
 PRESS CHART
 3/19/96
 0700-1500



LINE II
PRESS CHART
3/19/96
1500-1900



LINE II
PRESS CHART
3/19/96
0700-1500



15min

Dryer DATA
fuel calibration lb/coun face

core

date 3/19/96
by Smith
page 1 of 1

2 L # Duxer

TIME	FACE					CORE					WET BIN		DRY BIN		EVERY HOUR		
	OUT. SET POINT	FEED RATE	INLET TEMP	OUTLET TEMP	FUEL COUNT	WET BIN LEVEL	OUT. SET POINT	FEED RATE	INLET TEMP	OUTLET TEMP	FUEL COUNT	WET BIN LEVEL	LEVEL		CORE	FLAKE MOISTURE	
													FACE	WET BIN		IN	FACE
10:30	250	70	1483	249	990	75%	218	62	1327	217	1232	75%	60%	75%	482	59	7.2
10:45	250	71	1512	250	1100	70%	222	62	1426	218	1362	70%	55%	70%		53	6.4
11:00	250	71	1536	250	1215	70%	224	62	1449	224	1475	75%	60%	70%		54	7.8
11:15	250	71	1555	249	1227	70%	224	62	1497	223	1400	75%	60%	75%		51	5.4
11:30	248	71	1605	244	1443	70%	222	60	1462	220	1715	80%	65%	80%	480	52	5.5
11:45	248	71	1555	244	1560	65%	222	60	1455	221	1634	80%	65%	80%		51	5.8
12:00	248	71	1567	245	1677	70%	222	60	1495	222	1957	75%	70%	85%		50	5.1
12:15	248	69	1560	247	1804	80%	222	58	1488	219	2097	80%	70%	90%		52	5.6
12:30	248	69	1552	245	1911	76%	222	58	1451	222	2210	75%	80%	90%	492	52	5.5
12:45	248	69	1565	243	2028	85%	222	58	1449	220	2335	85%	80%	90%		55	5.6
1:00	248	69	1510	241	2136	70%	222	57	1371	221	2445	90%	70%	90%		56	5.2
1:15	248	69	1515	246	2254	75%	222	57	1369	220	2568	90%	80%	80%		52	5.2
1:30	250	69	1504	242	2369	70%	222	57	1367	221	2688	80%	80%	80%	486	57	5.7
1:45	250	69	1469	248	2489	70%	222	57	1360	220	2808	70%	80%	75%		52	5.5
2:00	250	69	1472	249	2597	60%	222	57	1406	221	2927	70%	80%	75%		51	5.2
2:15	250	69	1482	247	2718	70%	222	59	1425	221	3058	100%	80%	70%		53	5.8
2:30	250	69	1456	238	2832	90%	222	59	1412	219	3180	100%	80%	70%	498	64	5.2
2:45	250	69	1453	240	2953	90%	222	61	1405	217	3309	90%	80%	70%		58	5.6
3:00	250	69	1455	240	3075	100%	222	59	1408	209	3441	90%	80%	70%		55	6.0
3:15	250	66	1471	247	3184	100%	222	59	1403	218	3559	100%	80%	70%		53	5.4
3:30	250	66	1478	244	3294	90%	222	59	1427	217	3683	90%	80%	65%	538	51	5.8
3:45	250	66	1422	248	3421	90%	222	61	1398	218	3818	90%	80%	65%		53	6.0
4:00	250	66	1487	242	3533	90%	222	61	1422	228	3940	90%	80%	60%		54	6.4
4:15	250	66	1508	249	3659	100%	222	62	1496	220	4080	100%	80%	70%		50	5.6
4:30	250	66	1525	245	3780	100%	222	62	1489	216	4213	100%	75%	70%	404	55	5.7
4:45	250	66	1468	241	3893	100%	220	62	1474	212	4343	100%	70%	65%		57	5.8
5:00	250	68	1492	248	4006	100%	220	62	1493	218	4470	100%	70%	70%		50	5.0
5:15																	
5:30	250	69	1576	243	4261	80%	220	62	1547	219	4737	80%	75%	75%	532	53	5.6
5:45	250	69	1544	247	4372	90%	220	63	1521	219	4865	80%	75%	75%		54	5.8
6:00																	
6:15																	
6:30																	
6:45																	
7:00																	
7:15																	

fuel calibration lb/coun face

core

L II Nyas


page 2 of 2

date 3/19/96
by Smith


page 2 of 2

[illegible]


LINE II
CORE DRYER
3/19/96
0700-1900




LINE II
CORE DRYER
3/19/96
1900 - 0700




LINE II
SURFACE DRYER
3/19/96
0700-1900




LINE II
SURFACE DRYER
3/19/96
1900-0700



Line II
CORE E-TUBE
3/19/96




LINE II
SURF. E-TUBE
3/19/96



L-II Dryer R10

RECORD EVERY 15 MIN.						HAYWARD AIR TESTING WORKSHEET						
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust	Exhaust	Press.	Gas
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage
9:00	425	378	428	318	418	1.5	1572	1571	1525	252	23.5	✓
9:15	422	373	429	315	418	0.9	1568	1564	1517	248	25.4	
Down												
10:30	401	363	412	325	407	1.1	1582	1593	1511	244	23.2	
10:45	408	365	420	324	413	1.3	1562	1560	1523	256	22.7	
11:00	409	370	418	324	409	1.4	1579	1593	1526	248	23.7	
11:15	411	371	419	323	410	1.1	1580	1592	1528	249	23.2	
11:30	411	371	423	332	415	1.3	1559	1554	1528	259	23.9	
11:45	413	370	425	324	414	1.0	1565	1567	1531	254	23.3	
12:00	411	375	420	338	413	0.7	1569	1580	1535	263	23.5	
12:15	414	373	422	323	410	1.1	1578	1590	1534	250	23.4	
12:30	413	378	427	338	415	1.3	1565	1580	1533	257	23.8	
12:45	414	373	427	332	415	1.1	1579	1595	1529	255	23.6	
1:00	417	371	429	323	411	1.4	1563	1566	1529	253	23.6	
1:15	416	372	429	320	410	0.2	1571	1567	1525	251	23.6	
1:30	414	376	427	340	413	0.2	1567	1573	1524	263	23.8	
1:45	414	376	427	339	414	0.9	1575	1590	1523	261	23.9	
2:00	417	374	429	322	411	0.5	1574	1571	1526	251	23.7	
2:15	415	378	425	333	411	1.2	1577	1595	1527	259	23.8	
2:30	415	377	429	340	415	1.3	1556	1550	1525	261	24.2	
2:45	414	379	427	341	412	0.8	1576	1598	1526	260	23.8	
3:00	418	376	428	321	411	0.9	1566	1561	1528	256	23.4	
3:15	414	378	426	340	412	1.4	1573	1589	1527	263	23.8	
3:30	414	379	426	341	412	0.8	1577	1593	1525	261	23.9	
3:45	415	379	426	334	412	0.8	1575	1593	1522	261	23.8	
4:00	418	375	432	327	415	0.9	1566	1562	1523	256	23.3	
4:15	418	376	428	324	412	1.4	1578	1573	1526	251	23.9	
4:30	418	376	430	325	414	0.9	1572	1565	1526	256	23.2	
4:45	417	375	430	338	417	1.5	1558	1551	1520	260	23.5	
5:00	415	379	426	336	413	0.9	1578	1592	1527	256	23.5	
Down												
5:30	418	375	433	332	417	0.9	1566	1571	1535	258	23.0	
5:45	418	377	427	327	414	1.4	1579	1580	1533	252	23.8	
Down												
7:30	420	374	431	326	417	0.2	1571	1575	1531	252	23.6	
7:45	412	378	426	332	415	1.1	1579	1594	1529	256	23.5	
8:00	420	377	427	328	415	1.2	1574	1594	1531	255	23.4	
8:15	422	375	431	328	419	0.9	1564	1567	1534	258	23.4	
8:30	421	377	427	327	412	0.9	1565	1566	1534	258	23.3	
8:45	421	376	431	337	422	1.4	1560	1558	1534	263	24.2	

Line II
DRYER RTO
3/19/96



DATE: 3-19-96
SHIFT/CREW: 1-B
OPERATOR: J. W.

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
2		39 $\frac{3}{8}$	31	4328 lbs	
4	4366 lbs	39 $\frac{3}{8}$	32	4349 lbs	40 $\frac{1}{8}$
6		39 $\frac{3}{4}$	33	4337 lbs	
8	4312 lbs	39 $\frac{3}{4}$	34	4343 lbs	40
			35	4339 lbs	
1	4493 lbs CALLED FROM 8126		36	4315 lbs	39 $\frac{5}{8}$
2	4491 lbs	40 $\frac{1}{8}$	37	4358 lbs	
3	4484 lbs		38	4347 lbs	39 $\frac{3}{4}$
4	4419 lbs	40	39	4316 lbs	
5	4397 lbs		40	4288 lbs	39 $\frac{3}{8}$
6	4326 lbs	40 $\frac{1}{8}$	41	4296 lbs	
7	4293 lbs		42	4286 lbs	39 $\frac{3}{4}$
8	4362 lbs	40	43	4273 lbs	
9	4404 lbs		44	4247 lbs	39 $\frac{3}{8}$
10	4366 lbs	40 $\frac{1}{8}$	45	4224 CALLED FROM 1003	
11	4275 lbs		46	4233 lbs	39 $\frac{3}{8}$
12	4291 lbs	40 $\frac{1}{4}$	47	4276 lbs	
13	4327 lbs		48	4278 lbs	39 $\frac{3}{8}$
14	4381 lbs	40 $\frac{1}{4}$	49	4335 lbs	
15	4385 lbs		50	4333 lbs	40
16	4460 lbs CALLED FROM 1051	40 $\frac{1}{8}$	51	4378 lbs	
17	4529 lbs		52	4367 lbs	40
18	4501 lbs	40 $\frac{1}{8}$	53	4378 lbs	
19	4461 lbs		54	4235 CALLED FROM 312	39 $\frac{3}{4}$
20	4435 lbs	40	55	4314 lbs	
21	4430 lbs		56	4346 lbs	40
22	4376 lbs	40	57	4359 lbs	
23	4361 lbs		58	4404 CALLED FROM 325	40 $\frac{1}{8}$
24	4326 lbs	40	59	4424 lbs	
25	4356 lbs		60	4383 lbs	40
26	4275 lbs	40	61	4366 lbs	
27	4229 lbs CALLED FROM 1207		62	4356 lbs	39 $\frac{3}{8}$
28	4231 lbs	39 $\frac{3}{4}$	63	4375 lbs	
29	4239 lbs		64	4368 lbs	39 $\frac{3}{8}$
30	4276 lbs	40	65	4352 lbs	

7/16"

1/2"

$\frac{1}{2}$ "

30

DATE: 3-19-96
 SHIFT/CREW: 2 / D
 OPERATOR: M. Riley

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
1/2	1	4346	22	4253	39 3/4
	2	4313	24		
	3	4280	26	4321	40 CP
	4	4329	28		39 1/2
	5	4345	30	4356	39 5/8
	6	4367	32		39 1/2
	7	4400	34	4514	40 CP
	8	4377	36		40 CP
	9	4399	38	4604	40 CP
	10	4328	40		39 1/2
	11	4354	42	4512	39 1/2
	12	4341	44		39 3/4
	13	4339	46	4457	39 1/2
	14	4306	48		39
	15	4293	50	4347	38 3/4 CP
	16	4278	52		39 1/4
	17	4314	54	4312	39 1/4
	18	4310	56		39 3/8
	19	4322	58	4360	39 3/8
	20	4322	60		39 1/4
	21	4311	62	4504	39 1/2
	22	4282	64		39 3/4
	24		66	4398	39 1/2
	26	4277	68		39 3/4
7/11	X X X X X X X X X		70	4481	39 7/8 CP
	2	4178 CP	72		39 1/2
	4		74	4303	39 1/2
	6	4127 CP	76		39 1/2
	8		78	4309	+
	10	4167	80		+
	12				
	14	4179			
	16				
	18	4258			
	20				

HAYWARD LINE 2 DRYER RTO STACK MARCH 20th 1996

FORMALDEHYDE

DATA TIME:	START=	08:30	END=	09:02	HOURS=	0.53
	START=	09:28	END=	14:00	HOURS=	4.53
					TOTAL=	5.07

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices per unit over the testing period.

1/2"

per/peice 54.80
per/ 8' x 16' 219.20

PLANT PRODUCTION RATE

5.07 =hours during testing
81 =pressloads
972 =no. of 8'x16' boards produced (pressloads x 12 boards per load)
213,062 =lbs of finished product (boards produced x weight of finished board)
42,052 =lbs of finished product per hour (lbs of finished product / hours)
21.03 =tons of finished product per hour (lbs of finished product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY DRY FUEL INPUT

SURFACE

10 =SURFACE fuel calibration in pounds per count
2,403 =SURFACE counts during testing hours
24,030 =SURFACE lbs of fuel burned during testing
5.07 =hours during testing
4,743 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
2.37 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
8,600 =estimated BTU content per pound of dry fuel,
40.8 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)
1,432 =average inlet temperature
46.95 =average incoming moisture percent
5.37 =average dry moisture percent

CORE

10 =CORE fuel calibration in pounds per count
2,719 =CORE counts during testing hours
27,190 =CORE lbs of fuel burned during testing
5.07 =hours during testing
5,366 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
2.68 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
8,600 =estimated BTU content per pound of dry fuel,
46.2 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)
1,472 =average inlet temperature
46.95 =average incoming moisture percent
5.73 =average dry moisture percent

DRYER THROUGHPUT RATE

10,109 =Total pounds of fuel burned per hour in Core and Surface Dryer
42,052 =lbs of finished product per hour (lbs of finished product / hours)
52,161 =Pounds of material produced by the dryer per hour (dry basis, assumming fuel balances)
2,827 = weight of trim per hour at 6.3% of finished product
7,282 =weight of screened fines per hour (total fuel - trim)
13.96% =resulting loss to fines as percentage of dryer throughput

PRESS REPORT - ~~LINE~~ 1 6

OPERATOR

DATE: 3-20-94

SHIFT:

CREW:

THANKS

PRESS LOS:

OVERALL

DECOMPRESSION

TIME:

TIME:

FEES

TOTAL

TEMP:

REFLECTS:

LOG COUNT:

$$\frac{3}{8} = 374,311$$

F.C.O.S. HYD. RADIATOR:

PRESS BLOWN DOWN:

SPINNER HEADS FLUSHED:

SURFACE BLENDER HOSED:

FORMER HYD RADIATOR:

DOWNTIME CODE:


M - MECHANIC

E - ELECTRICAL


O - OPERATOR

34


Line II
PRESS chart
3/20/96
0700-1500



LINE II
PRESS CHART
3/20/96
1500-1900



LINE II
PRESS CHART
3/20/96
1900-0300



fuel calibration lb/coun face

core


page / of

date by


3/20/96

[illegible]


LINE II
CORE DRYER
3/20/96
0700-1900




LINE II
SURFACE DRYER
3/20/96
0700-1900



LINE II
CORE DRYER
3/20/96
1900-0700




2100-11
SURFACE DRYER
3/20/96
1900-0700



(This Page is Intentionally Left Blank)


LINE II
CORE E-TUBE
3/20/96



A circular radar plot from a Honeywell weather instrument. The plot features concentric circles representing distance (0 to 200 miles) and radial lines representing direction. A central label reads "HONEYWELL", "Loop 307537", and "Tulane, LA, U.S.A.". The plot is filled with a dense, dark, circular pattern, likely representing a weather system or a specific data set. The outer edge of the plot is marked with time intervals from 00:20 to 23:20.

RECORD EVERY 15 MIN.											
HAYWARD AIR TESTING WORKSHEET											
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust	Exhaust	Press.
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Temp.
8:30	409	380	426	338	412	1.3	1575	1597	1531	257	24.0
8:45	409	380	431	339	416	1.4	1555	1556	1523	257	23.6
9:00	410	377	433	330	415	1.5	1580	1581	1530	248	23.9
9:15			427	322					Down		
9:30			427	322					Down		
9:45	394	361	408	315	395	1.3	1572	1591	1506	245	24.8
10:00	401	365	417	313	399	1.0	1587	1594	1523	245	23.9
10:15	403	371	424	329	409	1.1	1562	1559	1520	249	23.4
10:30	407	372	422	322	405	1.4	1576	1599	1531	255	24.0
10:45	406	374	426	333	412	1.1	1563	1570	1529	253	23.7
11:00	410	373	425	318	407	1.2	1569	1569	1531	246	24.4
11:15	410	373	430	317	409	1.5	1577	1581	1533	248	24.2
11:30	409	375	430	329	414	0.9	1565	1577	1532	252	23.9
11:45	411	375	430	326	413	0.2	1574	1586	1537	251	23.7
12:00	411	375	430	327	413	0.7	1577	1585	1538	251	23.5
12:15	412	376	426	320	408	1.1	1582	1577	1534	254	23.8
12:30	410	378	429	335	414	1.5	1562	1558	1524	256	23.5
12:45	410	380	426	339	412	1.0	1560	1557	1527	260	24.2
1:00	410	380	426	337	411	0.7	1559	1561	1528	260	24.2
1:15	411	379	429	335	413	1.5	1559	1566	1531	254	23.4
1:30	414	378	432	329	413	0.9	1567	1570	1535	254	23.7
1:45	415	377	433	327	412	1.5	1570	1572	1533	250	24.0
2:00	417	377	432	320	410	1.3	1575	1581	1533	248	24.4
2:15	416	380	428	323	408	1.2	1578	1575	1535	257	23.9
2:30	414	382	432	338	415	1.4	1560	1563	1532	256	22.7
2:45	415	384	428	338	411	1.3	1566	1575	1538	257	23.4
3:00	415	384	429	340	412	0.3	1568	1581	1543	262	24.2
3:15	416	384	429	338	412	0.6	1570	1581	1544	263	24.1
3:30	416	383	433	339	416	1.3	1563	1567	1540	259	23.5
3:45	420	382	433	322	412	1.0	1576	1600	1545	257	23.6
4:00	417	380	433	343	416	1.3	1564	1575	1541	252	24.1
4:15	422	382	434	323	413	1.3	1580	1575	1543	254	23.4
4:30	420	385	431	334	414	0.8	1579	1600	1544	265	23.5
4:45	420	386	432	337	415	0.3	1560	1564	1537	261	23.4
5:00	423	382	437	330	418	0.2	1574	1582	1540	251	24.1
5:15	422	382	439	330	419	1.4	1574	1594	1540	260	23.4
5:30	422	383	434	325	416	0.9	1584	1594	1539	255	24.1
5:45	418	385	435	343	422	1.7	1583	1565	1534	258	23.2
6:00	417	386	433	347	421	1.3	1561	1564	1538	262	23.4

LINE II
DRYER RTO
3/20/96



DATE: 3-20-96
SHIFT/CREW: 1-C
OPERATOR: AL RANG

UNIT/	THICKNESS	WEIGHT	HEIGHT	UNIT/	THICKNESS	WEIGHT	HEIGHT
1	1 1/2	4357	39 1/2	29	4270 (11:17)	40	
2	2 1/2		39 1/2	30	4250 (11:23)	39 3/4	
3	3 1/2		39 1/2	31	4248 (11:31)	39 3/4	
4	4 1/2		39 3/4	32	4198 (11:35)	39 3/4	
5	5 1/2	4448	39 1/2	33	4187 (11:41)	39 3/4	
6	6 1/2		39 3/4	34	4189 (11:45)	40	
7	7 1/2		39 3/4	35	4215 (11:54)	40	
8	8 1/2	4448	40 1/4	36	4266 (12:00)	40	
9	9 1/2	4485 (5:10)	40 1/4	37	4306 (12:06)	40	
10	10 1/2	4393 (5:10)	40	38	4342 (12:30)	40 1/8	
11	11 1/2	4279 (8:10)	40	39	4342 (12:19)	40	
12	12 1/2	4330 (8:20)	40	40	4335 (12:26)	40	
13	13 1/2	4362 (8:27)	40	41	4332 (12:32)	40	
14	14 1/2	4375 (8:35)	40	42	4350 (12:39)	40 1/4	
15	15 1/2	4371 (8:40)	40	43	4392 (12:44)	40 1/4	
16	16 1/2	4389 (8:46)	40	44	4380 (12:52)	40 1/4	
17	17 1/2	4390 (8:55)	40	45	4388 (12:58)	40 1/4	
18	18 1/2	4432 (9:59)	40 1/4	46	4379 (1:03)	40 1/4	
19	19 1/2	4391 (10:06)	40	47	4388 (1:05)	40 1/4	
20	20 1/2	4323 (9:30)	40	48	4387 (1:15)	40 1/2	
21	21 1/2	4371 (9:42)	40	49	4353 (1:21)	40 1/2	
22	22 1/2	4313 (9:46)	40	50	4343 (1:28)	40 1/4	
23	23 1/2	4279 (9:55)	40	51	4319 (1:34)	40 1/4	
24	24 1/2	4426 (10:01)	40	52	4325 (1:40)	40 1/8	
25	25 1/2	4437 (10:08)	40 1/4	53	4355 (1:47)	40 1/8	
26	26 1/2	4450 (10:17)	40	54	4347 (1:54)	40	
27	27 1/2	4472 (10:22)	40	55	4301 (1:59)	40	
28	28 1/2	4426 (10:24)	40	56	4333 (2:06)	40	
29	29 1/2	4427 (10:34)	40	57	4339 (2:13)	40	
30	30 1/2	4445 (10:39)	40	58	4411 (2:18)	40	
31	31 1/2	4389 (10:44)	40	59	4440 (2:25)	40	
32	32 1/2	4351 (10:51)	40	60	4520 (2:32)	40 1/2	
33	33 1/2	4360 (10:57)	40	61	4510 (2:37)	40 1/2	
34	34 1/2	4289 (11:04)	40	62	4608 (2:44)	40 3/4	
35	35 1/2	4283 (11:10)	40	63	4613 (2:49)	41	

DATE: _____
 SHIFT/CREW: _____
 OPERATOR: _____

1/5

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
64	4592 (2:56)	41 CP	99	4496 (6:30)	40 1/4
65	4618 (3:03)	41	100	4471 (6:41)	40 1/4
66	4659 (3:09)	41 1/4 CP	101	4460 (6:40)	40 1/4
67	4584 (3:07)	40 3/4	102	4482 (6:53)	40 1/4
68	4521 (3:21)	40 1/2	103	4486 (6:57)	40 1/4
69	4450 (3:28)	40 1/2			
70	4430 (3:33)	40 1/4			
71	4418 (3:41)	40 1/4			
72	4437 (3:47)	40 1/2			
73	4420 (3:52)	40 1/2			
74	4421 (3:59)	40 1/4			
75	4418 (4:05)	40 1/4			
76	4422 (4:13)	40 1/4			
77	4452 (4:18)	40 1/4			
78	4433 (4:24)	40 1/4			
79	4437 (4:29)	40 1/4			
80	4440 (4:35)	40 1/2			
81	4373 (4:43)	40			
82	4323 (4:50)	40			
83	4327 (4:56)	40			
84	4270 (4:50)	40			
85	4210 (5:07)	40			
86	4243 (5:15)	40			
87	4390 (5:20)	40			
88	4316 (5:28)	40			
89	4306 (5:31)	40			
90	4310 (5:39)	40 1/4			
91	4356 (5:45)	40 1/4			
92	4366 (5:52)	40			
93	4366 (5:59)	40			
94	4367 (6:04)	40			
95	4425 (6:10)	40			
96	4472 (6:17)	40 1/2			
97	4444 (6:21)	40 1/4			
98	4493 (6:29)	40 1/4			

DATE: 3-20-96
SHIFT/CREW: A-2
OPERATOR: Amy

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
1/2 1	4441#		22	4486#	39 3/4
2	4403#	40 1/4	24		39 3/8
3	4391#		26		39 1/2
4	4354#	40 1/8	28	4292#	39 1/4
5	4386#		30 <i>collapser</i>	4371#	40 3/8
6	4377#	40	32 <i>collapser</i>	4294#	39
7	4395#		34	4443#	39 1/2
8	4413#	40 1/4	36		39 7/8
9	4427#		38	4372#	39 3/4
10	4405#	40 1/4	40		39 5/8
11	4407#		42	4404#	39 3/4
12	4418#	40	44		39 5/8
13	4435#		46	4387#	39 3/4
14	4422#	40 1/4	48		39 1/2
15	4401#		50	4378	39 1/2
16	4405#	40 1/8	52		39 1/2
17	4355#		54	4454#	39 3/8
18	4360#	39 3/8	56		39 3/8
19	4400#		58	4330#	39 1/2
20	4331#	40	60		39 1/2
21	4286#		62		39 3/8
22	4284#	39 1/8	64		39 3/8
23 <i>collapser</i>	4208#		66		
24		40 7/8	68		
25	4192	39 3/4	70		
26	4393#	39 3/8	72 <i>collapser</i>	4502#	37 1/2
27		40	2		35 5/8
28	4541#	40	4		35 1/2
29		40	6		
30		40	8		36 1/2
31	4539#	39 3/4	10		
32		40 1/4			
33		40 3/8			
34		40 7/8			
35		40 7/8			
36	4544#	40 7/8			
37		40			
38		40			

HAYWARD LINE 2 DRYER RTO STACK MARCH 20th & 21st 1996

POM

DATA TIME:	START=	14:30	END=	17:30	HOURS=	3.00
DATA TIME:	START=	08:15	END=	14:15	HOURS=	6.00
					TOTAL=	9.00

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices per unit over the testing period.

1/2"

per/peice 54.59

per/ 8' x 16' 218.36

PLANT PRODUCTION RATE

9.00 =hours during testing

144 =pressloads

1728 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

377,326 =lbs of finished product (boards produced x weight of finished board)

41,925 =lbs of finished product per hour (lbs of finshed product / hours)

20.96 =tons of finished product per hour (lbs of finshed product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY DRY FUEL INPUT

SURFACE

10 =SURFACE fuel calibration in pounds per count

4,213 =SURFACE counts during testing hours

42,130 =SURFACE lbs of fuel burned during testing

9.00 =hours during testing

4,681 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.34 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

40.3 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,439 =average inlet temperature

47.34 =average incoming moisture percent

5.45 =average dry moisture percent

CORE

10 =CORE fuel calibration in pounds per count

4,811 =CORE counts during testing hours

48,110 =CORE lbs of fuel burned during testing

9.00 =hours during testing

5,346 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.67 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

46.0 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,509 =average inlet temperature

47.34 =average incoming moisture percent

5.85 =average dry moisture percent

DRYER THROUGHPUT RATE

10,027 =Total pounds of fuel burned per hour in Core and Surface Dryer

41,925 =lbs of finished product per hour (lbs of finshed product / hours)

51,952 =Pounds of material produced by the dryer per hour (dry basis, assumming fuel balances)

2,819 = weight of trim per hour at 6.3% of finished product

7,208 =weight of screened fines per hour (total fuel - trim)

13.87% =resulting loss to fines as percentage of dryer throughput

PRESS REPORT - ~~LINE~~ 1 ②

OPERATOR

SHIFT:

DATE: 3-20-94

CREW:

THICKNESS

PRESS Lcs:

OVERALL

DECOMPRESSION

TIME:

TIME:

5555

TOTAL

TEMP:

REFLECTS:

[illegible]

LOG COUNT:

F.C.D.S. HYD. RADWATER:

PRESS SLOWLY DOWN:

SPINNER HEADS FLUSHED:

SURFACE BLENDER HOSED:

FORMER HYD RADIATOR:

[illegible]

DOWNTIME CODE:


M - MECHANICS

E - ELECTRICAL


O - OPERATOR

1-55


Line II
 PRESS chart
 3/20/96
 0700-1500




LINE II
PRESS CHART
3/20/96
1500-1900




LINE II
 PRESS CHART
 3/20/96
 1900-0300



LINE II
 PRESS CHART
 3/21/96
 0700-1500



LINE II
PRESS CHART
3/21/96
1500-1900



Dryer DATA

fuel calibration lb/coun face

core

date 3/20/94
by
page 1 of

TIME	FACE				CORE				WET BIN		FACE		CORE		EVERY HOUR	
	OUT. SET POINT	FEED RATE	INLET TEMP	OUTLET TEMP	FUEL COUNT	WET BIN LEVEL	OUT. SET POINT	FEED RATE	INLET TEMP	OUTLET TEMP	FUEL COUNT	WET BIN LEVEL	FACE LEVEL	CORE LEVEL	IN	FACE MOISTURE
8:30	252	63	1404	250	659	60%	213	67	1547	209	765	60%	90%	70%	45.4	5.2
8:45	252	63	1411	250	762	70%	213	67	1505	208	890	60%	80%	70%	5.4	5.4
9:00	252	63	1386	250	873	80%	213	67	1500	213	1019	70%	90%	80%	5.2	5.3
9:15						100%		DRYER DOWN				100%	100%	100%		
9:30						100%		DRYER DOWN				100%	100%	100%		
9:45	252	63	1197	249	1028	100%	213	63	1187	212	1211	100%	75%	75%	6.0	6.4
10:00	252	67	1383	248	1133	100%	213	67	1437	211	1329	100%	75%	75%	5.6	5.8
10:15	250	70	1394	245	1284	90%	213	68	1488	211	1501	90%	75%	75%	5.6	5.8
10:30	250	70	1433	247	1366	100%	213	68	1457	214	1588	100%	75%	75%	5.1	5.9
10:45	250	70	1461	250	1492	100%	215	68	1467	214	1731	100%	75%	75%	5.8	6.0
11:00	250	70	1466	247	1617	100%	215	68	1489	214	1677	100%	75%	75%	5.1	5.4
11:15	252	70	1453	246	1752	100%	215	68	1467	214	3030	100%	75%	75%	4.7	5.0
11:30	252	70	1494	251	1858	100%	215	68	1439	212	2146	100%	75%	75%	4.7	5.0
11:45	252	70	1485	251	1984	100%	215	68	1473	213	2291	100%	80%	80%	4.7	5.3
12:00	250	70	1459	260	2089	90%	215	68	1458	213	2409	90%	80%	80%	4.9	5.2
12:15	250	70	1467	246	2212	70%	215	68	1452	213	2547	70%	75%	80%	5.3	5.8
12:30	250	70	1496	245	2329	70%	215	68	1436	214	2676	70%	75%	80%	5.8	5.5
12:45	250	70	1498	248	2461	60%	215	68	1475	211	2820	60%	75%	80%	5.0	5.9
1:00	250	70	1489	249	2546	60%	215	68	1474	214	2934	60%	75%	80%	5.0	6.0
1:15	250	70	1489	241	2700	60%	215	68	1530	211	3036	60%	80%	80%	5.6	5.8
1:30	250	70	1485	244	2822	60%	215	68	1545	211	3232	60%	80%	80%	4.4	6.0
1:45	250	70	1455	247	2972	60%	215	68	1532	213	3354	60%	80%	80%	6.4	5.8
2:00	253	70	1444	246	3062	65%	215	68	1496	215	3484	65%	75%	80%	5.9	6.2
2:15	253	70	1478	251	3192	65%	215	68	1477	214	3625	65%	75%	75%	4.9	5.8
2:30	253	70	1457	252	3310	45%	215	68	1513	214	3753	45%	80%	80%	4.3	5.8
2:45	253	70	1423	251	3420	65%	215	68	1555	213	3862	65%	75%	80%	5.0	5.7
3:00	253	70	1459	250	3531	65%	215	68	1458	213	4011	65%	75%	80%	4.9	5.1
3:15	253	70	1538	251	3646	60%	215	68	1555	214	4145	60%	75%	80%	5.3	5.9
3:30	253	70	1453	250	3762	70%	215	68	1444	214	4274	70%	75%	90%	5.8	5.5
3:45	253	70	1453	251	3885	70%	215	68	1514	211	4419	70%	75%	90%	5.2	5.7
4:00	253	70	1528	250	4020	75%	215	68	1549	208	4545	75%	80%	80%	5.2	6.0
4:15	253	70	1491	250	4119	75%	215	68	1533	213	4689	75%	75%	90%	4.9	5.4
4:30	253	70	1536	249	4227	75%	215	68	1546	216	4810	75%	75%	90%	5.0	5.5
4:45	251	70	1470	248	4349	80%	215	63	1491	214	4957	80%	80%	90%	5.1	5.6
5:00	251	70	1501	250	4453	90%	216	63	1454	212	5074	90%	80%	90%	6.0	6.0
5:15	251	70	1425	250	4578	75	216	63	1478	214	5222	75	80%	90%	5.1	5.6

page 2 of 2

64


core

date by page


3/21/96

page 7 of _____[illegible]


LINE II
CORE DRYER
3/20/96
0700-1900




LINE II
SURFACE DRYER
3/20/96
0700-1900




LINE II
CORE DRYER
3/20/96
1900-0700




LINE II
SURFACE DRYER
3/20/96
1900-0700




LINE II
CORE DRYER
3/21/96
0700 - 1900




LINE II
SURFACE DRYER
3/21/96
0700-1900




LINE II
 CORE DRYER
 3/21/96
 1900-0700




LINE II
SURFACE DRYER
3/21/96
1900 - 0700




LINE II
CORE E-TUBE
3/20/96




Line II
CORE E-TUBE
3/21/94



Line II
SURF. E-TUBE
3/20/96



LINE II
SURF. E-TUBE
3/21/96



LII HAYWARD RTO

3/20/96

RECORD EVERY 15 MIN.

HAYWARD AIR TESTING WORKSHEET


WATER

Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust	Exhaust	Press.	
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage
8:30	409	380	426	338	412	1.3	1575	1597	1531	257	24.0	
8:45	409	380	431	339	416	1.4	1555	1556	1523	257	23.6	10210
9:00	410	377	433	330	415	1.5	1580	1589	1530	248	23.9	
9:15			62702					Down				
9:30			07402					Down				
9:45	394	361	408	315	395	1.3	1572	1591	1506	245	24.8	10560
10:00	401	365	417	313	399	1.0	1587	1594	1523	245	23.9	
10:15	403	371	424	329	409	1.1	1562	1559	1520	249	23.4	10740
10:30	407	372	422	322	405	1.4	1576	1599	1531	255	24.0	
10:45	406	374	426	330	412	1.1	1563	1570	1529	253	23.7	10900
11:00	410	373	425	318	407	1.2	1569	1569	1531	246	24.4	
11:15	410	373	430	317	409	1.5	1577	1584	1533	248	24.2	11090
11:30	409	375	430	329	414	0.9	1565	1577	1532	252	23.9	NO H2O
11:45	411	375	430	326	413	0.2	1574	1586	1537	251	23.7	
12:00	411	375	430	327	413	0.7	1577	1585	1538	251	23.5	NO H2O
12:15	412	376	426	320	408	1.1	1582	1577	1534	254	23.8	
12:30	410	378	429	335	414	1.5	1562	1558	1524	256	23.5	NO H2O
12:45	410	380	426	339	412	1.0	1560	1557	1527	260	24.2	NO
1:00	410	380	426	337	411	0.7	1557	1561	1528	260	24.2	NO H2O
1:15	411	379	429	335	413	1.5	1557	1566	1531	254	23.4	
1:30	414	378	432	329	413	0.9	1567	1570	1535	254	23.7	NO H2O
1:45	415	377	433	327	412	1.5	1570	1572	1533	250	24.0	
2:00	417	377	432	320	410	1.3	1578	1581	1533	248	24.4	11240
2:15	416	380	428	323	408	1.2	1578	1598	1535	257	23.9	
2:30	414	382	432	338	415	1.4	1560	1563	1532	256	22.7	NO H2O
2:45	415	384	428	338	411	1.3	1566	1575	1538	257	23.4	
3:00	415	384	429	340	412	0.3	1568	1581	1543	262	24.2	11400
3:15	416	384	429	338	412	0.6	1570	1587	1544	263	24.1	
3:30	416	383	433	339	416	1.3	1563	1567	1540	259	23.5	11600
3:45	420	382	433	322	412	1.0	1576	1600	1545	257	23.6	
4:00	417	386	433	343	416	1.3	1564	1575	1541	252	24.1	11850
4:15	422	382	434	323	413	1.3	1580	1575	1543	254	23.4	12100
4:30	420	385	431	334	414	0.8	1579	1600	1544	265	23.5	
4:45	420	386	432	337	415	0.3	1560	1564	1537	261	23.4	12220
5:00	423	382	439	330	418	0.2	1574	1582	1540	251	24.1	
5:15	422	382	439	330	419	1.4	1574	1574	1540	260	23.6	12450
5:30	422	383	434	325	416	0.9	1584	1594	1539	255	24.1	
5:45	418	385	435	343	422	1.7	1558	1565	1534	258	23.2	12700
6:00	417	386	433	347	421	1.3	1561	1564	1538	262	23.4	

RECORD EVERY 15 MIN.						HAYWARD AIR TESTING WORKSHEET						WATER	
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas	
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage	
8:15	408	360	414	320	409	1.2	1581	1594	1515	252	23.9		
8:30	410	362	422	327	414	1.1	1572	1569	1577	244	23.6	17740	
8:45	413	364	419	320	409	1.3	1565	1573	1515	256	23.6		
9:00	413	365	419	325	409	1.4	1580	1593	1528	256	23.6	17910	
9:15	412	366	424	332	416	1.1	1565	1565	1525	253	23.2		
9:30	412	368	422	337	416	1.1	1599	1576	1531	261	23.7	18070	
9:45	414	366	424	331	414	0.9	1569	1570	1534	252	23.7		
10:00	414	368	420	331	410	0.7	1573	1564	1536	257	23.3	18270	
10:15	412	369	417	334	411	0.7	1566	1569	1542	256	23.7		
10:30	416	369	427	331	417	0.8	1567	1574	1535	253	23.8	18450	
10:45	418	369	427	333	418	0.8	1561	1568	1530	254	24.0		
11:00	421	367	428	321	416	0.4	1576	1582	1534	249	24.5	18620	
11:15	418	370	426	334	420	1.4	1572	1577	1532	248	24.4		
11:30	418	373	423	336	417	1.4	1563	1556	1525	256	24.1	187120	
11:45	420	371	428	332	421	0.9	1558	1561	1520	254	24.0		
12:00	421	368	429	324	420	1.4	1567	1566	1519	248	24.2	18820	
12:15	423	369	429	319	417	1.6	1580	1584	1524	249	23.9		
12:30	423	370	431	325	422	0.8	1574	1575	1527	249	23.8	18960	
12:45	420	374	427	339	421	1.2	1561	1555	1520	259	23.4		
1:00	423	371	437	328	421	1.6	1565	1567	1523	250	24.0	190720	
1:15	422	371	430	333	421	0.8	1564	1563	1523	255	23.6		
1:30	422	373	424	335	416	0.9	1568	1588	1531	263	24.2	191720	
1:45	425	369	431	323	417	0.1	1581	1579	1535	248	24.2		
2:00	424	371	427	322	415	1.1	1586	1596	1533	258	24.1	192720	
2:15	421	373	427	340	418	1.1	1570	1560	1533	260	24.1		
	</												

The image shows a circular radar chart, likely a weather or navigation instrument. The central logo reads "HONEYWELL" and "TUNING". The chart is divided into concentric circles and radial lines, with various numerical and alphanumeric labels around the perimeter and within the grid. Handwritten notes and signatures are visible on the chart.

LINE II
DRYER RTO
3/21/96



DATE: 3-20-96
 SHIFT/CREW: 1-C
 OPERATOR: AL RANG

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
7/1	4357	39 1/2	29	4270 (11:17)	40"
7/16		39 1/2	30	4250 (11:23)	39 3/4
2		39 1/2	31	4218 (11:39)	39 3/4
4		39 3/4	32	4198 (11:35)	39 3/4
5	4448	39 1/2	33	4187 (11:41)	39 3/4
6		39 3/4	34	4189 (11:45)	40
7		39 3/4	35	4215 (11:59)	40
1	4445	40 1/4	36	4266 (12:00)	40
2	4485 (8:10)	40 1/4	37	4306 (12:06)	40
3	4393 (8:10)	40	38	4342 (12:30)	40 1/8
4	4279 (8:10)	40	39	4342 (12:19)	40
5	4330 (8:22)	40	40	4335 (12:26)	40
6	4362 (8:22)	40	41	4332 (12:32)	40
7	4375 (8:35)	40	42	4380 (12:39)	40 1/4
8	4371 (8:40)	40	43	4392 (12:44)	40 1/4
9	4388 (8:56)	40	44	4380 (12:52)	40 1/4
10	4340 (8:55)	40	45	4388 (12:58)	40 1/4
11	4432 (9:59)	40 1/4	46	4379 (1:03)	40 1/4
12	4391 (10:06)	40	47	4388 (1:09)	40 1/4
13	4323 (10:36)	40	48	4387 (1:15)	40 1/2
14	4371 (10:42)	40	49	4353 (1:21)	40 1/2
15	4313 (10:46)	40	50	4343 (1:28)	40 1/4
16	4279 (10:55)	40	51	4319 (1:34)	40 1/4
17	4426 (10:00)	40	52	4325 (1:40)	40 1/8
18	4437 (10:00)	40 1/4	53	4335 (1:47)	40 1/8
19	4450 (10:12)	40	54	4347 (1:54)	40
20	4472 (10:22)	40	55	4301 (1:59)	40
21	4426 (10:24)	40	56	4333 (2:06)	40
22	4427 (10:31)	40	57	4339 (2:13)	40
23	4445 (10:39)	40	58	4411 (2:18)	40
24	4389 (10:44)	40	59	4440 (2:25)	40
25	4351 (10:51)	40	60	4520 (2:32)	40 1/2
26	4360 (10:57)	40	61	4510 (2:37)	40 1/2
27	4299 (11:01)	40"	62	4608 (2:44)	40 3/4 CR
28	4283 (11:10)	40"	63	4613 (2:49)	41

DATE: _____
 SHIFT/CREW: _____
 OPERATOR: _____

1/2'

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
64	4592 (2:56)	41 CP	99	4496 (6:30)	40 1/4
65	4618 (3:03)	41	100	4471 (6:41)	40 1/4
66	4659 (3:09)	41 1/4 CP	101	4480 (6:40)	40 1/4
67	4584 (3:07)	40 3/4	102	4482 (6:51)	40 1/4
68	4521 (3:21)	40 1/2	103	4486 (6:57)	40 1/4
69	4450 (3:28)	40 1/2			
70	4430 (3:35)	40 1/4			
71	4418 (3:41)	40 1/4			
72	4437 (3:47)	40 1/2			
73	4420 (3:52)	40 1/2			
74	4421 (3:59)	40 1/4			
75	4418 (4:05)	40 1/4			
76	4422 (4:11)	40 1/4			
77	4452 (4:18)	40 1/4			
78	4433 (4:24)	40 1/4			
79	4437 (4:29)	40 1/4			
80	4440 (4:35)	40 1/2			
81	4373 (4:43)	40			
82	4383 (4:50)	40			
83	4327 (4:56)	40			
84	4270 (5:02)	40			
85	4260 (5:09)	40			
86	4243 (5:15)	40			
87	4350 (5:21)	40			
88	4316 (5:28)	40			
89	4306 (5:31)	40			
90	4240 (5:39)	40 1/4			
91	4356 (5:45)	40 1/4			
92	4366 (5:52)	40			
93	4366 (5:59)	40			
94	4367 (6:04)	40			
95	4425 (6:10)	40			
96	4472 (6:17)	40 1/2			
97	4444 (6:23)	40 1/4			
98	4493 (6:29)	40 1/4			

DATE: 3-20-76
SHIFT/CREW: A-2
OPERATOR: Amir

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
1	4441#		22	4486#	39 3/4
2	4403#	40 1/4	24		39 3/8
3	4391#		26		39 1/2
4	4354#	40 1/8	28	4292#	39 1/4
5	4386#		30 <i>collap</i>	4371#	40 3/8
6	4377#	40	32 <i>collap</i>	4294#	39
7	4395#		34	4343#	39 1/4
8	4413#	40 1/4	36		39 7/8
9	4427#		38	4372#	39 3/4
10	4405#	40 1/4	40		39 5/8
11	4407#		42	4404#	39 3/4
12	4418#	40	44		39 5/8
13	4435#		46	4387#	39 3/4
14	4422#	40 1/4	48		39 1/2
15	4401#		50	4378	39 1/2
16	4405#	40 1/8	52		39 1/2
17	4355#		54	4459#	39 3/8
18	4360#	39 7/8	56		39 3/8
19	4400#		58	4330#	39 1/2
20	4331#	40	60		39 1/2
21	4286#		62		39 3/8
22	4284#	39 7/8	64		39 3/8
23 <i>collap</i>	4208#		66		
24		40 1/8	68		
25	4192	39 3/4	70		
26	4392#	39 3/8	71 <i>collap</i>	4472#	37 1/2
4 <i>collap</i>		40	2		35 3/8
5 " "	4541#	40	4 9C		35 1/2
8 <i>collap</i>		40	6		
10 " "	4539#	39 3/4	8		36 1/2
12		40 1/4	10		
14		40 3/8			
16		40 1/8			
18 <i>collap</i>	4544#	40 3/8			
20 " "		40			

DATE: 3-21-56
SHIFT/CREW: LC
OPERATOR: *[Signature]*

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
1	4411	39 1/2"	30	4340 (10:55)	40
2		39 3/4"	31	4298 (11:01)	40
3		39 3/4"	32	4311 (11:08)	40
4	4420	39 3/4"	33	4320 (11:14)	40
5		39 3/4"	34	4328 (11:20)	40
6		39 3/4"	35	4331 (11:27)	40
7	4423 (7:50)	40	36	4327 (11:34)	40
8	4480 (7:56)	40 1/4"	37	4300 (11:39)	40
9	4426 (8:05)	40 1/4"	38	4303 (11:45)	40
10	4470 (8:11)	40	39	4280 (11:51)	40
11	4356 (8:17)	40	40	4240 (11:57)	40
12	4295 (8:25)	39 3/4"	41	4226 (12:04)	40
13	4327 (8:30)	40	42	4219 (12:11)	40
14	4340 (8:36)	40	43	4216 (12:16)	40
15	4323 (8:42)	40	44	4227 (12:22)	39 3/4"
16	4350 (8:49)	40	45	4200 (12:29)	39 3/4"
17	4358 (8:56)	40	46	4215 (12:35)	39 1/2"
18	4327 (9:02)	40	47	4270 (12:41)	40
19	4329 (9:07)	40	48	4293 (12:48)	39 3/4"
20	4360 (9:14)	40	49	4219 (12:53)	40
21	4372 (9:21)	40	50	4232 (1:07)	40
22	4369 (9:26)	40	51	4329 (1:10)	40
23	4354 (9:33)	40	52	4230 (1:16)	40
24	4390 (9:39)	40 1/4"	53	4357 (1:23)	40
25	4343 (9:43)	40	54	4479 (1:29)	40
26	4353 (9:52)	40	55	4431 (1:35)	40
27	4308 (9:58)	40	56	4430 (1:41)	40
28	4228 (10:04)	40	57	4424 (1:47)	40
29	4322 (10:11)	40	58	4431 (1:54)	40
30	4328 (10:17)	40	59	4412 (2:01)	40
31	4360 (10:23)	40	60	4429 (2:07)	40
32	4265 (10:29)	40	61	4445 (2:14)	40
33	4305 (10:35)	40	62	4452 (2:19)	40
34	4346 (10:41)	40	63	4454 (2:28)	40
35	4329 (10:48)	40	64	4465 (2:33)	40 3/4"

42 1/2 26 1/4 126 7/16

15-15

215

REJECTS:

1/00

T4.13

TIVE

TIME

THE

338438

O-OPERATOR

DATE: _____
 SHIFT/CREW: _____
 OPERATOR: _____

1/2"

UNIT/	THICKNESS	WEIGHT	HEIGHT	UNIT/	THICKNESS	WEIGHT	HEIGHT
65		4478 (2:42)	40 1/4	100			40 1/4
66		4446 (2:42)	40 1/4	101		4485	40 1/4
67		4369 (2:50)	40	102			40 1/2
68		4466 (2:58)	40 1/4	103			40 1/2
69		4413 (3:05)	40 1/4	104			40 1/2
70		4396 (3:11)	40 1/4	105		4504	40 1/2
71		4403 (3:18)	40 1/4	106			40 1/4
72		4407 (3:24)	40 1/4	107			40 1/4
73		4396 (3:30)	40 1/4				
74		4411 (3:36)	40 1/4				
75		4390 (3:42)	40 1/4				
76		4366 (3:49)	40				
77		4361 (3:58)	40				
78		4356 (4:02)	40				
79		4380 (4:08)	40				
80		4370 (4:14)	40 1/4				
81		4353 (4:22)	40 1/4				
82			40 1/4				
83			40 1/2				
84			40 1/2				
85		4478	40 1/2				
86			40 3/4				
87			40 3/4				
88			40 3/4				
89		4452	41				
90			40 1/2				
91			40 1/4				
92			40 1/4				
93		4526	40 1/4				
94			40 1/4				
95			40 3/4 CP				
96			40 3/4 CP				
97		4600	40 1/2				
98			40 1/2 CP				
99			40 1/2				

HAYWARD LINE 2 DRYER RTO STACK & CORE/SURF. DUCT MARCH 19th & 20th 1996

NOX/CO/CO2/THC/M2

DATA TIME:	START=	13:15	END=	14:30	HOURS=	1.25
DATA TIME:	START=	10:00	END=	13:00	HOURS=	3.00
					TOTAL=	4.25

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices per unit over the testing period.

1/2"
per/peice 54.57
per/ 8' x 16' 218.28

PLANT PRODUCTION RATE

4.25 =hours during testing
66 =pressloads
792 =no. of 8'x16' boards produced (pressloads x 12 boards per load)
172,878 =lbs of finished product (boards produced x weight of finished board)
40,677 =lbs of finished product per hour (lbs of finshed product / hours)
20.34 =tons of finished product per hour (lbs of finshed product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY DRY FUEL INPUT

SURFACE

10 =SURFACE fuel calibration in pounds per count

2,011 =SURFACE counts during testing hours
20,110 =SURFACE lbs of fuel burned during testing
4.25 =hours during testing
4,732 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
2.37 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
8,600 =estimated BTU content per pound of dry fuel,
40.7 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)
1,556 =average inlet temperature
48.50 =average incoming moisture percent
5.42 =average dry moisture percent

CORE

10 =CORE fuel calibration in pounds per count
2,219 =CORE counts during testing hours
22,190 =CORE lbs of fuel burned during testing
4.25 =hours during testing
5,221 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)
2.61 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)
8,600 =estimated BTU content per pound of dry fuel,
44.9 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)
1,436 =average inlet temperature
48.50 =average incoming moisture percent
5.64 =average dry moisture percent

DRYER THROUGHPUT RATE

9,953 =Total pounds of fuel burned per hour in Core and Surface Dryer
40,677 =lbs of finished product per hour (lbs of finshed product / hours)
50,630 =Pounds of material produced by the dryer per hour (dry basis, assumming fuel balances)
2,735 = weight of trim per hour at 6.3% of finished product
7,218 =weight of screened fines per hour (total fuel - trim)
14.26% =resulting loss to fines as percentage of dryer throughput

OPERATOR D. SCATEL

DATE: 3-19-56

SHIFT:

१३

CREW:

2

THICKNESS $1/2 \times 7/16$

PRESS LCS:

43 1/2 57 7/8

OVERALL

TIME:

174 - 157

DECOMPRESSION

TIME:

18-15

PRESS

TEMP:

215

TOTAL

REJECTS:

Z

LOG COUNT:

1435

[illegible]

F.C.O.S. HYD. RADIATOR:

2.50

Time

FRESS BLOWN DOWN:

7:20

SPINNER HEADS FLUSHED:

1

FIVE

SURFACE BLENDER HOSED:

5

TME

FORMER HYD RADIATOR:

—

TINE

[illegible]

DOWNTIME CODE:

M - MECHANICAL

F - ELECTRICAL

O - OPERATOR

LOUISIANA-PACIFIC CORPORATION

PRESS REPORT - LINE 1 (5)

OPERATOR Anderson

SHIFT:

DATE: 3-20-96

CREW: C

THICKNESS 7/16 - 1/2

PRESS LBS: 10714 17512

OVERALL

TIMER: 157-174

DECOMPRESSION

TIME: 15

PRESS

TEMP: 210-215 N.O.R.

TOTAL

REJECTS: 0

LINE SPEED	THICKNESS	FROM	TO
54'	7/16	17:00	17:38
54'	1/2	17:38	17:00

LOG COUNT: 153.7

F.C.O.S. HYD. RADIATOR: 8:00 TIME

PRESS BLOWN DOWN: 8:21

SPINNER HEADS FLUSHED: X TIME

SURFACE BLENDER HOSED: X TIME


FORMER HYD RADIATOR: X TIME

3/8' 374,317


DOWNTIME		DOWNTIME (MINS)			KEY	REASONS FOR DOWNTIME
FROM	TO	M	E	O		
7:02	26				24	Top Surface Transfer Conv. tripped out causing Flg - Gate and Haul-Up to plug

DOWNTIME CODE: M - MECHANICAL 24 E - ELECTRICAL O - OPERATOR

LINE II
 PRESS CHART
 3/19/96
 0700-1500




LINE II
PRESS CHART
3/19/96
1500-1900




0700-1500




LINE II
 PRESS CHART
 3/20/96
 0700-1500



LINE II
PRESS CHART
3/20/96
1500-1900



LINE II
PRESS CHART
3/20/96
1900-0300



date 3/19/96
by Smith
page 1 of 1

Dryer DATA
fuel calibration lb/coun face

core

max 11.2

tb/coun face

Dryer DATA
fuel calibration

TIME	FACE				GORE				WET BIN		FLAKE MOISTURE		
	OUT. SET POINT	FEED RATE	INLET TEMP	OUTLET TEMP	FUEL COUNT	WET BIN LEVEL	INLET TEMP	OUTLET TEMP	FUEL COUNT	WET BIN LEVEL	EVERY HOUR		
											FACE	CORE	
10:30	250	70	1483	249	990	75%	1337	217	1232	75%	48.2	5.9	7.2
10:45	250	71	1512	250	1100	70%	1426	218	1762	70%		5.3	6.4
11:00	250	71	1551	250	1215	70%	1449	224	1475	75%		5.4	7.8
11:15	250	71	1555	249	1227	70%	1497	223	1400	75%		5.1	5.4
11:30	248	71	1605	244	1443	70%	1412	220	1715	80%	48.0	5.2	5.5
11:45	248	71	1555	244	1360	65%	1455	221	1634	80%		5.1	3.8
12:00	248	71	1567	245	1477	70%	1495	222	1967	75%		5.2	5.1
12:15	248	69	1560	247	1804	80%	1488	219	3097	80%	49.2	5.2	5.8
12:30	248	69	1532	245	1911	75%	1451	220	2210	75%		5.5	5.6
12:45	248	69	1565	243	2038	85%	1449	220	2335	85%		5.6	5.2
1:00	248	69	1510	241	2136	70%	1371	221	2145	90%		5.2	5.2
1:15	248	69	1515	246	2254	75%	1369	220	2568	90%		5.7	5.7
1:30	250	69	1504	242	2369	70%	1367	221	2188	80%	48.6	5.2	5.5
1:45	250	69	1469	248	2482	70%	1406	221	2927	70%		5.1	5.3
2:00	250	69	1472	249	2597	60%	1423	221	3058	100%		5.3	5.8
2:15	250	69	1482	247	2718	70%	1412	219	3180	100%	49.8	6.4	5.3
2:30	250	69	1456	238	2832	90%	1405	217	3309	90%		5.8	5.6
2:45	250	69	1453	240	2955	90%	1408	209	3441	90%		5.5	6.0
3:00	250	66	1471	247	3184	100%	1403	218	3559	100%		5.3	5.4
3:15	250	66	1478	249	3299	100%	1427	217	3683	90%	53.8	5.1	5.8
3:30	250	66	1422	248	3421	90%	1398	218	3818	90%		5.3	6.0
3:45	250	66	1487	242	3533	90%	1422	208	3940	90%		5.4	6.2
4:00	250	66	1508	249	3659	100%	1496	220	4080	100%		5.0	5.6
4:15	250	66	1525	245	3780	100%	1489	214	4213	100%	40.4	5.5	5.7
4:30	250	66	1468	241	3893	100%	1474	212	4343	100%		5.7	5.8
4:45	250	66	1492	248	4006	100%	1493	218	4470	100%		5.0	5.0
5:00	250	68									53.2	5.3	5.6
5:15	250	69					1547	219	4737	80%		5.4	5.8
5:30	250	69					1515	219	4863	80%		5.4	5.8
5:45	250	69											
6:00													
6:15													
6:30													
6:45													
7:00													
7:15													

fuel calibration lb/coun face

core

by page

date by

page / of

3/20/96

10

TIME	FACE					CORE					WET BIN		CORE		WET BIN		CORE		FLAKE MOISTURE			
	OUT. SET POINT	FEED RATE	INLET TEMP	OUTLET TEMP	FUEL COUNT	WET BIN LEVEL	OUT. SET POINT	FEED RATE	INLET TEMP	OUTLET TEMP	FUEL COUNT	WET BIN LEVEL	FACE LEVEL	CORE LEVEL	FACE COUNT	WET BIN LEVEL	FACE LEVEL	CORE LEVEL	FACE COUNT	IN	FACE	CORE
8:30	252	63	1404	250	659	60%	213	67	1347	209	765	60%	90%	70%	765	60%	90%	70%	45.4	5.2	2.4	
8:45	252	63	1411	250	742	70%	213	67	1605	208	890	60%	80%	70%	890	60%	80%	70%	5.4	5.4	5.4	
9:00	252	63	1386	250	873	80%	213	67	1500	213	1019	70%	90%	80%	1019	70%	90%	80%	5.2	5.2	5.3	
9:15						100%		DRYER	DOWN			100%	100%	100%		100%	100%	100%				
9:30						100%		DRYER	DOWN			100%	100%	100%		100%	100%	100%	50.1			
9:45	252	63	1197	249	1028	100%	213	63	1187	212	1211	100%	75%	75%	1211	100%	75%	75%	6.0	6.0	6.4	
10:00	252	67	1383	248	1133	100%	213	67	1437	211	1329	100%	75%	75%	1329	100%	75%	75%	5.6	5.6	5.8	
10:15	250	70	1394	245	1284	90%	213	68	1488	211	1501	90%	75%	75%	1501	90%	75%	75%	5.2	5.2	5.6	
10:30	250	70	1433	247	1366	100%	213	68	1457	214	1588	90%	75%	75%	1588	90%	75%	75%	5.6	5.6	5.8	
10:45	250	70	1461	250	1492	100%	213	68	1467	214	1731	100%	75%	75%	1731	100%	75%	75%	5.4	5.4	5.9	
11:00	250	70	1466	247	1617	100%	213	68	1489	214	1877	100%	75%	75%	1877	100%	75%	75%	5.8	5.8	6.0	
11:15	252	70	1453	246	1752	100%	213	68	1467	214	2030	100%	75%	75%	2030	100%	75%	75%	5.1	5.1	5.6	
11:30	252	70	1494	251	1858	100%	215	68	1439	212	2146	100%	80%	80%	2146	100%	80%	80%	4.8	4.8	5.0	
11:45	252	70	1485	251	1984	100%	215	68	1473	213	2291	100%	80%	80%	2291	100%	80%	80%	4.7	4.7	5.3	
12:00	250	70	1459	260	2089	90%	215	68	1458	213	2409	90%	80%	80%	2409	90%	80%	80%	4.9	4.9	5.2	
12:15	250	70	1467	246	2212	70%	215	68	1452	213	2547	70%	80%	80%	2547	70%	80%	80%	5.5	5.5	5.8	
12:30	250	70	1496	245	2329	70%	215	68	1436	214	2676	70%	80%	80%	2676	70%	80%	80%	5.2	5.2	5.5	
12:45	250	70	1498	248	2461	60%	215	68	1475	211	2830	60%	80%	80%	2830	60%	80%	80%	5.0	5.0	5.5	
1:00	250	70	1489	249	2546	60%	215	68	1476	214	2936	60%	80%	80%	2936	60%	80%	80%	5.0	5.0	6.0	
1:15	250	70	1489	241	2700	60%	215	68	1530	211	3086	60%	80%	80%	3086	60%	80%	80%	5.6	5.6	5.8	
1:30	250	70	1465	244	2822	60%	215	68	1545	211	3232	60%	80%	80%	3232	60%	80%	80%	48.4	6.2	6.6	
1:45	250	70	1455	247	2942	60%	215	68	1532	213	3354	65%	80%	80%	3354	65%	80%	80%	5.4	5.4	5.8	
2:00	253	70	1444	246	3062	65%	215	68	1496	215	3484	65%	75%	80%	3484	65%	80%	80%	5.9	5.9	6.2	
2:15	253	70	1478	251	3192	65%	215	68	1477	214	3625	65%	75%	75%	3625	65%	75%	75%	4.9	4.9	5.8	
2:30	253	70	1457	252	3310	65%	215	68	1513	214	3753	65%	80%	80%	3753	65%	80%	80%	5.0	5.0	5.8	
2:45	253	70	1423	251	3420	65%	215	68	1555	213	3882	65%	75%	80%	3882	65%	80%	80%	5.0	5.0	5.7	
3:00	253	70	1459	250	3531	65%	215	68	1458	213	4011	65%	75%	80%	4011	65%	75%	80%	4.9	4.9	5.1	
3:15	253	70	1528	251	3646	60%	215	68	1555	214	4145	60%	75%	80%	4145	60%	75%	80%	5.3	5.3	5.9	
3:30	253	70	1453	250	3762	70%	215	68	1464	214	4274	70%	75%	80%	4274	70%	75%	80%	4.8	4.8	5.5	
3:45	253	70	1485	251	3885	70%	215	68	1574	211	4419	70%	75%	90%	4419	70%	75%	90%	5.2	5.2	5.7	
4:00	253	70	1528	250	4000	75%	215	68	1549	208	4545	75%	80%	80%	4545	75%	80%	80%	5.2	5.2	6.0	
4:15	253	70	1491	250	4119	75%	215	66	1573	213	4689	75%	75%	90%	4689	75%	75%	90%	4.9	4.9	5.4	
4:30	253	70	1536	249	4227	75%	215	65	1546	216	4810	75%	75%	90%	4810	75%	75%	90%	5.0	5.0	5.5	
4:45	251	70	1470	248	4349	80%	215	63	1491	214	4957	80%	80%	90%	4957	80%	80%	90%	5.1	5.1	5.6	
5:00	251	70	1501	250	4453	80%	216	63	1454	212	5074	80%	80%	90%	5074	80%	80%	90%	5.0	5.0	5.6	
5:15	251	70	1425	250	4578	75	216	63	1478	214	5222	75	80%	90%	5222	75	80%	90%	5.1	5.1	5.6	

fuel calibration lb/coun face

core

dale.

by


page

2 of 2


2 of 2

[illegible]


LINE II
CORE DRYER
3/19/96
0700-1900




LINE II
SURFACE DRYER
3/19/96
0700-1900




LINE II
CORE DRYER
3/20/96
0700-1900




LINE II
SURFACE DRYER
3/20/96
0700-1900




LINE II
 CORE DRYER
 3/19/96
 1900 - 0700




LINE II
SURFACE DRYER
3/20/96
1900-0700




LINE II
 CORE DRYER
 3/20/96
 1900-0700




LINE II
SURFACE DRYER
3/19/96
1900-0700




LINE II
CORE E-TUBE
3/19/96




LINE II
CORE E-TUBE
3/20/96



LINE II
SURF. E-TUBE
3/19/96



Line II
SURF. E-TUBE
3/20/96



L-II Dryer R10

3/19/96


RECORD EVERY 15 MIN.

HAYWARD AIR TESTING WORKSHEET


Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage
9:00	425	378	428	318	418	1.5	1572	1571	1525	252	23.5	
9:15	422	373	429	315	418	0.9	1568	1564	1517	248	25.4	
Down												
10:30	401	363	412	325	407	1.1	1582	1593	1511	244	23.2	
10:45	408	365	420	324	413	1.3	1562	1560	1523	256	22.7	
11:00	409	370	418	324	409	1.4	1579	1593	1526	248	23.7	
11:15	411	371	419	323	410	1.1	1580	1592	1528	249	23.2	
11:30	411	371	423	332	415	1.3	1559	1554	1528	259	23.9	
11:45	413	370	425	324	414	1.0	1565	1567	1531	254	23.3	
12:00	411	375	420	338	413	0.7	1569	1580	1535	263	23.5	
12:15	414	373	422	323	410	1.1	1578	1590	1534	250	23.4	
12:30	413	378	427	338	415	1.3	1565	1580	1533	250	23.8	
12:45	414	373	427	332	415	1.1	1579	1595	1529	255	23.6	
1:00	417	371	429	323	411	1.4	1563	1566	1529	253	23.6	
1:15	416	372	429	320	410	0.2	1571	1567	1525	251	23.6	
1:30	414	376	427	340	413	0.2	1567	1578	1524	263	23.8	
1:45	414	376	427	339	414	0.9	1575	1590	1523	261	23.9	
2:00	417	374	429	322	411	0.5	1574	1571	1526	251	23.7	
2:15	415	378	425	333	411	1.2	1577	1595	1527	259	23.8	
2:30	415	377	429	340	415	1.3	1556	1550	1525	261	24.2	
2:45	414	379	427	341	412	0.8	1576	1598	1526	260	23.8	
3:00	418	376	428	321	411	0.9	1566	1561	1528	256	23.4	
3:15	414	378	426	340	412	1.4	1573	1589	1527	263	23.8	
3:30	414	379	426	341	412	0.8	1577	1593	1525	261	23.9	
3:45	415	379	426	334	412	0.8	1575	1593	1522	261	23.8	
4:00	418	375	432	327	415	0.9	1566	1562	1523	256	23.3	
4:15	418	376	428	324	412	1.4	1578	1578	1526	251	23.9	
4:30	418	376	430	325	414	0.9	1572	1565	1526	256	23.2	
4:45	417	375	430	338	417	1.5	1559	1551	1524	260	23.5	
5:00	415	379	426	336	413	0.9	1578	1594	1527	256	23.5	
Down												
5:30	414	375	433	332	417	0.8	1566	1571	1535	258	23.0	
5:45	418	377	427	327	414	1.4	1579	1580	1533	252	23.8	
Down												
7:30	420	374	431	326	417	0.2	1571	1575	1531	252	23.6	
7:45	419	378	426	332	415	1.1	1579	1594	1529	256	23.5	
8:00	420	377	427	328	415	1.2	1579	1594	1531	255	23.4	
8:15	422	375	431	328	419	0.9	1564	1567	1534	258	23.4	
8:30	421	377	427	327	416	0.9	1565	1566	1534	258	23.5	
8:45	421	376	431	337	422	1.4	1560	1558	1534	263	24.2	

RECORD EVERY 15 MIN.						HAYWARD AIR TESTING WORKSHEET						WATER	
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust	Exhaust	Press.	Usage	
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop		
8:30	409	380	426	338	412	1.3	1575	1597	1531	257	24.0		
8:45	409	380	431	339	416	1.4	1555	1556	1523	257	23.6	10210	
9:00	410	377	433	330	415	1.5	1580	1589	1530	248	23.9		
9:15			DRYER					DOWN					
9:30			DRYER					DOWN					
9:45	394	361	408	315	395	1.3	1572	1591	1506	245	24.8	10560	
10:00	401	365	417	313	399	1.0	1587	1594	1523	245	23.8		
10:15	403	371	424	329	405	1.1	1560	1559	1520	249	23.4	10740	
10:30	407	372	422	322	405	1.4	1576	1597	1531	255	24.0		
10:45	406	374	426	330	412	1.1	1563	1570	1529	253	23.7	10900	
11:00	410	373	425	318	407	1.2	1569	1567	1531	246	24.4		
11:15	410	373	430	317	409	1.5	1577	1584	1533	248	24.2	11090	
11:30	409	375	430	329	414	0.9	1565	1577	1532	252	23.9	NO H2O	
11:45	411	375	430	326	413	0.2	1574	1586	1537	251	23.9		
12:00	411	375	430	327	413	0.7	1577	1585	1538	251	23.5	NO H2O	
12:15	412	376	426	320	408	1.1	1582	1577	1534	254	23.8		
12:30	410	378	429	335	414	1.5	1562	1558	1524	256	23.5	NO H2O	
12:45	410	380	426	339	412	1.0	1560	1559	1527	260	24.2	NO	
1:00	410	380	426	337	411	0.7	1559	1561	1528	260	24.2	NO H2O	
1:15	411	379	429	335	413	1.5	1559	1566	1531	254	23.4		
1:30	414	378	432	329	413	0.9	1567	1570	1535	254	23.7	NO H2O	
1:45	415	377	433	327	412	1.5	1570	1572	1533	250	24.0		
2:00	417	377	432	320	410	1.3	1578	1581	1533	248	24.4	11240	
2:15	416	380	428	323	408	1.2	1578	1593	1535	257	23.9		
2:30	414	382	432	333	415	1.4	1560	1563	1532	256	22.7	NO H2O	
2:45	415	384	428	338	411	1.3	1566	1575	1538	257	23.4		
3:00	415	384	429	340	412	0.3	1568	1581	1543	262	24.2	11400	
3:15	416	384	429	338	412	0.6	1570	1587	1544	263	24.1		
3:30	416	383	433	339	416	1.3	1563	1567	1540	259	23.5	11600	
3:45	420	382	433	322	412	1.0	1576	1600	1545	257	23.6		
4:00	417	386	433	343	416	1.3	1564	1575	1541	252	24.1	11850	
4:15	422	382	434	323	413	1.3	1580	1575	1543	254	23.4	12100	
4:30	420	385	431	334	414	0.8	1579	1600	1544	265	23.5		
4:45	420	386	432	337	415	0.3	1560	1564	1539	261	23.4	12220	
5:00	423	382	439	330	415	0.2	1574	1582	1540	251	24.1		
5:15	422	382	439	230	419	1.4	1574	1594	1540	260	23.6	12450	
5:30	422	383	434	325	416	0.9	1587	1594	1539	255	24.1		
5:45	418	385	435	343	422	1.7	1553	1565	1534	258	23.2	12700	
6:00	417	386	433	347	421	1.3	1561	1564	1538	262	23.4		

Line II
DRYER RTO
3/19/96



LINE II
DRYER RTO
3/20/96



DATE: 3-19-96
 SHIFT/CREW: 1-B
 OPERATOR: Jim W

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
2		39 $\frac{7}{8}$	31	4328 lbs	
4	4366 lbs	39 $\frac{7}{8}$	32	4349 lbs	40 $\frac{1}{8}$
6		39 $\frac{3}{4}$	33	4337 lbs	
8	4312 lbs	39 $\frac{3}{4}$	34	4343 lbs	40
			35	4339 lbs	
1	4493 lbs CALLED 1220, 8126		36	4315 lbs	39 $\frac{7}{8}$
2	4491 lbs	40 $\frac{1}{8}$	37	4358 lbs	
3	4484 lbs		38	4347 lbs	39 $\frac{3}{4}$
4	4419 lbs	40	39	4316 lbs	
5	4397 lbs		40	4288 lbs	39 $\frac{7}{8}$
6	4326 lbs	40 $\frac{1}{8}$	41	4296 lbs	
7	4293 lbs		42	4286 lbs	39 $\frac{3}{4}$
8	4362 lbs	40	43	4273 lbs	
9	4404 lbs		44	4247 lbs	39 $\frac{7}{8}$
10	4366 lbs	40 $\frac{1}{8}$	45	4224 CALLED 1220, 1003	
11	4225 lbs		46	4233 lbs	39 $\frac{7}{8}$
12	4297 lbs	40 $\frac{1}{4}$	47	4276 lbs	
13	4327 lbs		48	4278 lbs	39 $\frac{7}{8}$
14	4386 lbs	40 $\frac{1}{4}$	49	4335 lbs	
15	4385 lbs		50	4333 lbs	40
16	4460 lbs CALLED 1220, 1051	40 $\frac{1}{8}$	51	4378 lbs	
17	4529 lbs		52	4367 lbs	40
18	4501 lbs	40 $\frac{1}{8}$	53	4378 lbs	
19	4466 lbs		54	4335 CALLED 1220, 1003	39 $\frac{3}{4}$
20	4435 lbs	40	55	4314 lbs	
21	4430 lbs		56	4346 lbs	40
22	4376 lbs	40	57	4359 lbs	
23	4361 lbs		58	4404 CALLED 1220, 3221	40 $\frac{1}{8}$
24	4326 lbs	40	59	4424 lbs	
25	4356 lbs		60	4383 lbs	40
26	4275 lbs	40	61	4366 lbs	
27	4229 lbs CALLED 1220, 1207		62	4356 lbs	39 $\frac{7}{8}$
28	4221 lbs	39 $\frac{3}{4}$	63	4375 lbs	
29	4239 lbs		64	4368 lbs	39 $\frac{7}{8}$
30	4276 lbs	40	65	4352 lbs	

3/19/26

12

 $\frac{1}{2}$ "

DATE: 3-19-96
 SHIFT/CREW: 2 / D
 OPERATOR: M. Riley

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
1/2	1 4346		22	4253	39 3/4
	2 4313	39 1/2 ep	24		
	3 4280		26	4321	40 ep
	4 4319	39 1/2 "	28		39 1/2
	5 4345		30	4356	39 5/8
	6 4367	40	32		39 1/2
	7 4400		34	4514	40 ep
	8 4377	40 1/4	36		40 ep
	9 4399		38	4604	40 ep
	10 4328	40 1/4	40		39 1/2
	11 4354		42	4512	39 1/2
	12 4341	40 1/4	44		39 3/4
	13 4339		46	4457	39 1/2
	14 4306	40	48		39
	15 4293		50	4347	38 3/4 ep
	16 4278	40 1/8	52		39 1/4
	17 4314		54	4312	39 1/4
	18 4310	40 1/8	56		39 3/8
	19 4332		58	4360	39 3/8
	20 4322	40 1/4	60		39 1/4
	21 4311		62	4504	39 1/2
	22 4282	40	64		39 3/4
	24	40 1/8	66	4398	39 1/2
	26 4277	40 1/8	68		39 3/4
7/11	X X X X X X X X		70	4481	39 7/8 ep
1/11	2 4178	40	72		39 1/2
	4	39 3/4	74	4203	39 1/2
	6 4127	39 1/2	76		39 1/2
	8	39 1/2	78	4309	+
	10 4116	39 1/2	80		+
	12	39 1/2			
	14 4179	39 5/8			
	16	39 3/4			
	18 4258	39 5/8			
	20	39 3/4			

DATE: 3-20-96
 SHIFT/CREW: 1-C
 OPERATOR: AL RANG

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
7/1 2	4357	39 1/2	29	4270 (11:17)	40
7/16 2 4		39 1/2	30	4250 (11:23)	39 3/4
3 6		39 1/2	31	4218 (11:34)	39 3/4
4 8		39 3/4	32	4198 (11:35)	39 3/4
5 10	4448	39 1/2	33	4187 (11:41)	39 3/4
6		39 3/4	34	4189 (11:45)	40
7		39 3/4	35	4215 (11:54)	40
1 1/2	4445	40 1/4	36	4266 (12:00)	40
2	4485 (8:10)	40 1/4	37	4306 (12:06)	40
3	4393 (8:10)	40	38	4342 (12:30)	40 1/8
4	4279 (8:14)	40	39	4392 (12:19)	40
5	4330 (8:20)	40	40	4335 (12:26)	40
6	4362 (8:20)	40	41	4332 (12:32)	40
7	4375 (8:35)	40	42	4350 (12:35)	40 1/4
8	4371 (8:40)	40	43	4392 (12:44)	40 1/4
9	4388 (8:46)	40	44	4380 (12:52)	40 1/4
10	4390 (8:5)	40	45	4388 (12:58)	40 1/4
11	4432 (8:59)	40 1/4	46	4379 (1:03)	40 1/4
12	4391 (9:06)	40	47	4388 (1:09)	40 1/4
13	4323 (9:36)	40	48	4387 (1:15)	40 1/2
14	4371 (9:42)	40	49	4353 (1:21)	40 1/2
15	4313 (9:49)	40	50	4343 (1:28)	40 1/4
16	4279 (9:55)	40	51	4319 (1:34)	40 1/4
17	4426 (10:0)	40	52	4325 (1:40)	40 1/8
18	4437 (10:00)	40 1/4	53	4355 (1:47)	40 1/8
19	4450 (10:12)	40	54	4347 (1:54)	40
20	4472 (10:22)	40	55	4301 (1:59)	40
21	4426 (10:26)	40	56	4333 (2:06)	40
22	4427 (10:31)	40	57	4339 (2:13)	40
23	4445 (10:39)	40	58	4411 (2:18)	40
24	4389 (10:44)	40	59	4440 (2:25)	40
25	4351 (10:51)	40	60	4520 (2:32)	40 1/2
26	4360 (10:57)	40	61	4510 (2:37)	40 1/2
27	4295 (11:01)	40	62	4608 (2:44)	40 3/4 CR
28	4283 (11:10)	40	63	4613 (2:49)	41

DATE: _____
 SHIFT/CREW: _____
 OPERATOR: _____

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
64	4592 (2:56)	41 CP	99	4496 (6:30)	40 1/4
65	4618 (3:03)	41	100	4471 (6:41)	40 1/4
66	4659 (3:09)	41 1/4 CP	101	4483 (6:40)	40 1/4
67	4584 (3:07)	40 3/4	102	4482 (6:58)	40 1/4
68	4521 (3:21)	40 1/2	103	4486 (6:57)	40 1/4
69	4450 (3:28)	40 1/2			
70	4430 (3:33)	40 1/4			
71	4418 (3:41)	40 1/4			
72	4437 (3:47)	40 1/2			
73	4420 (3:52)	40 1/2			
74	4421 (3:59)	40 1/4			
75	4418 (4:05)	40 1/4			
76	4422 (4:13)	40 1/4			
77	4452 (4:18)	40 1/4			
78	4433 (4:24)	40 1/4			
79	4437 (4:29)	40 1/4			
80	4440 (4:35)	40 1/2			
81	4373 (4:43)	40			
82	4383 (4:50)	40			
83	4327 (4:56)	40			
84	4270 (5:00)	40			
85	4260 (5:09)	40			
86	4293 (5:15)	40			
87	4350 (5:21)	40			
88	4316 (5:28)	40			
89	4306 (5:31)	40			
90	4340 (5:39)	40 1/4			
91	4356 (5:45)	40 1/4			
92	4366 (5:52)	40			
93	4346 (5:59)	40			
94	4367 (6:04)	40			
95	4425 (6:10)	40			
96	4472 (6:17)	40 1/2			
97	4444 (6:23)	40 1/4			
98	4493 (6:29)	40 1/4			

DATE: 3-20-96
 SHIFT/CREW: A-2
 OPERATOR: Amir

1/2

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
1	4441#		22	4486#	39 3/4
2	4403#	40 1/4	24		39 3/8
3	4391#		26		39 1/2
4	4354#	40 1/8	28	4292#	39 1/4
5	4386#		30 collapser	4371#	40 7/8
6	4377#	40	32 collapser	4294#	39
7	4395#		34	4343#	39 1/4
8	4413#	40 1/4	36		39 7/8
9	4427#		38	4372#	39 3/4
10	4405#	40 1/4	40		39 5/8
11	4407#		42	4404#	39 3/4
12	4418#	40	44		39 5/8
13	4435#		46	4287#	39 1/4
14	4422#	40 1/4	48		39 1/2
15	4401#		50	4378	39 1/2
16	4405#	40 1/8	52		39 1/2
17	4355#		54	4454#	39 5/8
18	4360#	39 7/8	56		39 3/8
19	4400#		58	4330#	39 1/2
20	4331#	40	60		39 1/2
21	4286#		62		39 3/8
22	4284#	39 1/8	64		39 3/8
23 collapser	4208#		66		
24		40 7/8	68		
25	4192	39 3/4	70		
26	4397#	39 7/8	72 collapser	4502#	37 1/2
2		40	2		35 5/8
4 collapser		40	4		35 1/2
6 11 11	4541#	40	48C		
8 collapser		40	6		
10 11 11	4539#	39 3/4	8		36 1/2
12		40 1/4	10		
14		40 3/8			
16		40 7/8			
18 collapser	6544#	40 5/8			
20 11 11		40			

7/16

HAYWARD LINE 2 DRYER RTO STACK MARCH 21st 1996

BENZENE

DATA TIME: START= 08:15 END= 12:45 HOURS= 4.50

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices per unit over the testing period.

1/2"

per/peice 54.38

per/ 8' x 16' 217.51

PLANT PRODUCTION RATE

4.50 =hours during testing

69 =pressloads

828 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

180,097 =lbs of finished product (boards produced x weight of finished board)

40,021 =lbs of finished product per hour (lbs of finished product / hours)

20.01 =tons of finished product per hour (lbs of finished product per hour / 2000 lb)

FUEL BURNING RATE ESTIMATED BY DRY FUEL INPUT

SURFACE

10 =SURFACE fuel calibration in pounds per count

2,151 =SURFACE counts during testing hours

21,510 =SURFACE lbs of fuel burned during testing

4.50 =hours during testing

4,780 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.39 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

41.1 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,420 =average inlet temperature

46.63 =average incoming moisture percent

5.76 =average dry moisture percent

CORE

10 =CORE fuel calibration in pounds per count

2,406 =CORE counts during testing hours

24,060 =CORE lbs of fuel burned during testing

4.50 =hours during testing

5,347 =lbs of dry fuel burned per hour during testing (pounds of dry fuel / testing hours)

2.67 =tons of dry fuel burned per hour during testing (pounds of dry fuel / 2000 lbs)

8,600 =estimated BTU content per pound of dry fuel,

46.0 =estimated mmbtu input per hour (lbs of dry fuel per hour x btu content)

1,496 =average inlet temperature

46.63 =average incoming moisture percent

5.95 =average dry moisture percent

DRYER THROUGHPUT RATE

10,127 =Total pounds of fuel burned per hour in Core and Surface Dryer

40,021 =lbs of finished product per hour (lbs of finished product / hours)


50,148 =Pounds of material produced by the dryer per hour (dry basis, assumming fuel balances)

2,691 = weight of trim per hour at 6.3% of finished product

7,436 =weight of screened fines per hour (total fuel - trim)


14.83% =resulting loss to fines as percentage of dryer throughput

Line II
PRESS CHART
3/21/96
0700-1500



123

LINE II
PRESS CHART
3/21/96
1500-1900




Dryer DATA
fuel calibration lb/coun face

core


page 1 of _____

TIME	FACE						CORE						DRY BIN		EVERY HOUR		
	OUT. SET POINT	FEED RATE	INLET TEMP	OUTLET TEMP	FUEL COUNT	WET BIN LEVEL	OUT. SET POINT	FEED RATE	INLET TEMP	OUTLET TEMP	FUEL COUNT	WET BIN LEVEL	FACE	LEVEL	IN	FACE	CORE
8:15	244	71	1392	242	578	100%	213	66	1399	211	620	100%	87%	80%	44.9	5.6	7.4
8:30	244	71	1379	241	684	100%	213	67	1459	212	643	100%	75%	75%		5.6	6.0
8:45	244	71	1419	243	796	90%	212	67	1473	212	769	90%	30%	75%		5.1	5.9
9:00	244	71	1497	242	914	80%	213	69	1521	211	905	80%	80%	75%		3.2	6.0
9:15	244	71	1503	241	1041	50%	213	69	1539	210	1043	80%	90%	75%	44.4	5.5	6.3
9:30	244	71	1462	242	1153	80%	213	69	1573	209	1170	80%	90%	75%		5.1	6.2
9:45	244	71	1463	244	1287	70%	213	69	1539	209	1318	70%	90%	80%		5.0	6.4
10:00	244	70	1455	240	1398	70%	213	69	1542	209	1443	70%	90%	80%		5.7	6.3
10:15	244	70	1460	242	1517	70%	213	67	1549	211	1578	70%	90%	90%	48.2	5.9	6.2
10:30	244	70	1455	242	1636	70%	213	67	1536	209	1709	70%	90%	90%		5.8	5.9
10:45	244	70	1400	242	1754	70%	213	67	1484	213	1844	70%	90%	90%		5.8	5.3
11:00	244	70	1385	241	1877	10%	217	65	1469	213	1981	70%	90%	90%		5.5	5.0
11:15	244	70	1396	241	2001	60%	217	65	1476	215	2126	70%	90%	90%	48.0	5.7	5.5
11:30	246	70	1392	246	2121	60%	217	65	1484	215	2263	70%	90%	90%		6.1	5.3
11:45	246	70	1318	232	2254	60%	217	65	1447	214	2405	70%	90%	90%		5.8	5.7
12:00	246	68	1377	238	2372	70%	217	65	1457	213	2534	60%	80%	80%		6.8	5.6
12:15	248	68	1375	241	2498	70%	219	65	1432	216	2674	70%	80%	80%	45.0	5.8	5.2
12:30	248	68	1419	245	2612	70%	219	65	1480	217	2805	80%	80%	80%		6.1	5.3
12:45	248	68	1437	240	2729	75%	219	65	1528	219	2924	75%	75%	75%		7.1	6.4
1:00	251	68	1373	250	2878	75%	219	66	1528	210	3094	80%	75%	75%		5.7	8.3
1:15	251	68	1452	248	2976	75%	220	66	1518	219	3205	80%	75%	75%	46.2	5.3	5.9
1:30	253	71	1441	252	3105	60%	221	66	1558	220	3346	70%	75%	75%		5.1	5.4
1:45	253	71	1466	251	3223	50%	221	66	1553	219	3475	60%	70%	75%		5.5	5.8
2:00	253	71	1437	250	3357	50%	221	66	1500	220	3613	60%	70%	75%		5.6	6.7
2:15	255	71	1381	250	3419	50%	221	66	1457	220	3743	60%	70%	75%		5.3	5.3

Line II
CORE DRYER
3/21/96
0700 - 1900




LINE II
SURFACE DRYER
3/21/96
0700-1900




127


LINE II
CORE DRYER
3/21/96
1900-0700



LINE II
SURFACE DRYER
3/21/96
1900 - 0700



Line II
CORE E-TUBE
3/21/96



A circular radar chart from a ship's log. The center features a logo with the text "HONEYWELL" and "Tulane". The chart is overlaid with a grid of concentric circles representing distance (0 to 200 miles) and radial lines representing bearing (0 to 360 degrees). The outer edge of the chart is marked with time in 24-hour format, ranging from 02:24 to 17:24. A dense, dark, circular pattern is visible in the center, likely representing a target or a large vessel. The chart is labeled "HONEYWELL" and "Tulane" in the center. The outer ring shows time in 24-hour format, ranging from 02:24 to 17:24. The inner rings show distance in miles (0 to 200) and bearing in degrees (0 to 360).

RECORD EVERY 15 MIN.						HAYWARD AIR TESTING WORKSHEET						WATER	
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas	
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage	
8:15	408	360	414	320	409	1.2	1581	1594	1515	252	23.9		
8:30	410	362	422	327	414	1.1	1572	1569	1517	244	23.6	17746	
8:45	413	364	419	320	409	1.3	1565	1573	1515	256	23.6		
9:00	413	365	419	325	409	1.4	1580	1593	1528	256	23.6	17910	
9:15	412	366	424	332	416	1.1	1565	1565	1525	253	23.2		
9:30	412	368	422	337	416	1.1	1599	1578	1531	261	23.7	18070	
9:45	414	366	424	331	414	0.9	1564	1570	1534	252	23.7		
10:00	414	368	420	331	410	0.2	1523	1564	1536	257	23.3	18270	
10:15	412	369	411	334	411	0.7	1566	1569	1542	256	23.7		
10:30	416	369	421	331	417	0.8	1567	1574	1535	253	23.8	18450	
10:45	418	369	427	333	418	0.8	1561	1568	1530	254	24.0		
11:00	421	367	428	321	416	0.4	1576	1582	1534	249	24.5	18620	
11:15	418	370	426	334	420	1.4	1572	1577	1532	248	24.4		
11:30	418	373	423	336	417	1.4	1563	1556	1525	256	24.1	NO H2O	
11:45	420	371	428	332	421	0.9	1558	1561	1520	254	24.0		
12:00	421	368	429	324	420	1.4	1567	1566	1519	248	24.2	NO H2O	
12:15	423	369	429	319	417	1.6	1580	1584	1524	249	23.9		
12:30	423	370	431	325	420	0.8	1574	1575	1527	249	23.8	NO H2O	
12:45	420	374	427	339	421	1.2	1561	1555	1520	259	23.4		
1:00	423	371	437	328	421	1.6	1565	1567	1523	250	24.0	NO H2O	
1:15	422	376	430	333	421	0.8	1564	1563	1523	255	23.6		
1:30	422	373	424	335	416	0.7	1568	1588	1531	263	24.2	NO H2O	
1:45	425	369	431	323	417	0.1	1581	1579	1535	248	24.2		
2:00	424	371	427	322	415	1.1	1586	1596	1533	258	24.1	NO H2O	
2:15	421	373	427	340	418	1.1	1570	1560	1533	260	24.1		

DATE: 3-21-56
SHIFT/CREW: LC
OPERATOR: Ramp

7/16"

1/2"

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
1	4411	39 1/2"	30	4340 (10:55)	40
2		39 3/4"	31	4298 (11:01)	40
3		39 3/4"	32	4311 (11:08)	40
4	4420	39 3/4"	33	4320 (11:14)	40
5		39 3/4"	34	4338 (11:20)	40
6		39 3/4"	35	4331 (11:27)	40
7	4413 (7:50)	40	36	4327 (11:34)	40
8	4480 (7:56)	40 1/4"	37	4300 (11:39)	40
9	4426 (8:05)	40 1/4"	38	4303 (11:45)	40
10	4470 (8:11)	40	39	4280 (11:51)	40
11	4356 (8:17)	40	40	4240 (11:57)	40
12	4295 (8:25)	39 3/4"	41	4226 (12:04)	40
13	4327 (8:30)	40	42	4219 (12:11)	40
14	4340 (8:36)	40	43	4216 (12:16)	40
15	4323 (8:42)	40	44	4227 (12:22)	39 3/4"
16	4350 (8:49)	40	45	4200 (12:29)	39 3/4"
17	4358 (8:55)	40	46	4215 (12:35)	39 1/2" CP
18	4327 (9:02)	40	47	4270 (12:41)	40
19	4329 (9:07)	40	48	4243 (12:48)	39 3/4"
20	4360 (9:14)	40	49	4219 (12:53)	40
21	4372 (9:21)	40	50	4232 (1:07)	40
22	4364 (9:26)	40	51	4329 (1:10)	40
23	4394 (9:33)	40	52	4330 (1:16)	40
24	4390 (9:39)	40 1/4"	53	4397 (1:23)	40
25	4343 (9:43)	40	54	4419 (1:29)	40
26	4283 (9:52)	40	55	4431 (1:35)	40
27	4308 (9:58)	40	56	4430 (1:41)	40
28	4228 (10:04)	40	57	4424 (1:47)	40
29	4322 (10:11)	40	58	4431 (1:54)	40
30	4338 (10:20)	40	59	4412 (2:01)	40
31	4360 (10:23)	40	60	4429 (2:07)	40
32	4265 (10:29)	40	61	4445 (2:14)	40
33	4305 (10:35)	40	62	4452 (2:19)	40
34	4346 (10:41)	40	63	4454 (2:28)	40
35	4329 (10:48)	40	64	4465 (2:33)	40 3/4"

DATE: _____
 SHIFT/CREW: _____
 OPERATOR: _____

1/2"

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
65	4478 (2:40)	40 1/4	100		40 1/4
66	4446 (2:40)	40 1/4	101	4485	40 1/4
67	4369 (2:50)	40	102		40 1/2
68	4466 (2:58)	40 1/4	103		40 1/2
69	4413 (3:05)	40 1/4	104		40 1/2
70	4396 (3:11)	40 1/4	105	4504	40 1/2
71	4403 (3:18)	40 1/4	106		40 1/4
72	4407 (3:21)	40 1/4	107		40 1/4
73	4396 (3:30)	40 1/4			
74	4411 (3:36)	40 1/4			
75	4390 (3:42)	40 1/4			
76	4366 (3:49)	40			
77	4361 (3:58)	40			
78	4356 (4:02)	40			
79	4380 (4:08)	40			
80	4370 (4:14)	40 1/4			
81	4353 (4:22)	40 1/4			
82		40 1/4			
83		40 1/2			
84		40 1/2			
85	4478	40 1/2			
86		40 3/4			
87		40 3/4			
88		40 3/4			
89	4483	41			
90		40 1/2			
91		40 1/4			
92		40 1/4			
93	4526	40 1/4			
94		40 1/4			
95		40 3/4 CP			
96		40 3/4 CP			
97	4600	40 1/2			
98		40 1/2 CP			
99		40 1/2			

HAYWARD LINE 2 MARCH 19th 1996

PRESS VENT RTO STACK - FORMALDEHYDE

DATA TIME: START= 10:30 END= 16:00 HOURS= 5.50

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices
per unit over the testing period.

1/2"

per/peice 54.34

per/ 8' x 16' 217.34

PLANT PRODUCTION RATE

5.50 =hours during testing

85 =pressloads

1020 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

221,691 =lbs of finished product (boards produced x weight of finished board)

40,307 =lbs of finished product per hour (lbs of finished product / hours)

20.15 =tons of finished product per hour (lbs of finished product per hour / 2000 lb)

RESIN USAGE TAKEN FROM MICRO - MOTIONS

TIME	MDI	PHENOL	WAX
10:30-11:30	450	861	332
12:20-13:20	525	792	222
14:40-15:40	541	1,086	268
AVERAGE	505.33	913.00	271.00

40,307 =average lbs. per hour finished product produced during testing

505.33 =average lbs. per hour of MDI resin used during testing

1.25% = MDI resin used as % of finished product

913.00 =average lbs. per hour of phenolic resin (100% solids) used during testing

2.27% =Phenolic resin used as % of finished product

271.00 =average lbs. per hour of wax (100% solids) used during testing

0.67% =wax used as % of finished product

PRESS REPORT - LINE 1 ②

OPERATOR

H. J. J. J.

SHIFT:

1st

CREW:

VB - LT

THICKNESS

714

PRESS LDS:

13 3/4 156 1/2

OVERALL

TIMER:

157 | 174

DECOMPRESSION

TIME:

15 / 18

PRESS

TEMP:

205

TOTAL

REJECTS:

LINE SPEED	THICKNESS	FROM	TO
43	7/16	7:00	8:00
45	1/2	8:00	8:30
50	1/2	8:30	8:45
55	1/2	8:45	9:00

LOG COUNT:

1346

F.C.O.S. HYD. RADIATOR:

✓ TIME

PRESS BLOWN DOWN:

✓ TIME

SPINNER HEADS FLUSHED:

✓ TIME

SURFACE BLENDER HOSED:

✓ TIME

FORMER HYD RADIATOR:

✓ TIME

DOWNTIME		DOWNTIME (MINS)			K E Y	REASONS FOR DOWNTIME
FROM	TO	M	E	O		
7:01	7:04	3				Stalling In
9:20	10:05	45				No Surface Infeed
11:51	1:54	3				Pulsed Baghouse
2:32	3:35	3				" "
6:01	7:05	4				" " "

DOWNTIME CODE:

M - MECHANICAL


50

E - ELECTRICAL


O - OPERATOR

120


LINE II
PRESS CHART
3/19/46
0700-1500



LINE II
PRESS CHART
3/19/96
1500-1900



LINE II
PRESS CHART
3/19/96
0700-1500




LT Press RTO 3-19-96

RECORD EVERY 15 MIN.					HAYWARD AIR TESTING WORKSHEET							
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage
10:30	409	414	401	419	420	3.6	1559	1560	1503	220	18.1	N/A
10:45	404	416	399	422	420	3.8	1563	1554	1503	220	18.2	NA
11:00	405	415	400	420	421	3.8	1561	1566	1502	219	18.1	NA
11:15	402	417	398	422	422	3.6	1557	1554	1501	222	18.1	N/A
11:30	401	419	396	425	420	3.7	1562	1553	1504	221	18.1	NA
11:45	402	419	396	426	419	3.6	1564	1553	1504	221	18.1	NA
12:00	402	419	396	428	417	3.6	1581	1577	1508	222	18.0	NA
12:15	405	418	399	421	418	2.5	1593	1586	1513	219	18.3	NA
12:30	404	417	397	421	418	3.6	1563	1596	1514	219	18.2	NA
12:45	404	417	396	422	417	2.5	1593	1589	1514	218	18.2	NA
1:00	405	418	396	423	416	3.4	1598	1590	1512	219	18.2	NA
1:15	400	419	395	425	416	3.9	1562	1567	1503	219	18.4	NA
1:30	399	418	396	427	416	2.6	1558	1559	1503	221	18.1	NA
1:45	399	417	398	423	417	3.6	1560	1564	1504	220	18.2	NA
2:00	400	418	398	425	417	3.6	1560	1555	1501	221	18.1	NA
2:15	402	420	395	431	416	3.7	1568	1556	1505	221	18.1	NA
2:30	406	419	397	428	416	3.8	1605	1603	1513	221	18.1	NA
2:45	404	419	397	430	415	3.6	1576	1562	1508	222	18.2	NA
3:00	406	418	400	422	417	3.8	1605	1585	1512	222	18.0	NA
3:15	403	418	400	421	418	3.4	1590	1584	1512	220	18.2	NA
3:30	404	419	399	423	418	3.5	1605	1597	1516	223	18.1	NA

Line II

PRESS RTO

3/19/96



3-19-96 Press Test # 1 10:30 AM - 11:30 AM

Solids	Micro-Motions	100% Solids
	Pounds	
100% MDI Core -	470	470
57% PF Surf. -	1557	888
58% Wax Core -	167	-275
58% Wax Surf. -	307	

Tanks

Solids		Before	After	Pounds	100% Solids
100% Core MDI -		123.5"	122.75"	450	450
2 ÷ 61% Surf PF -		141"	141"	0	
7 ÷ 57% Day Tank PF -		918	621	1511	
2 ÷ 57% Mix Tank PF -		4	2	209	861
2 ÷ 58% Wax -		42"	41"	191	111

Factors per inch

MDI Tank - 600.466
 PF Tank - 727.583
 Wax Tank - 381.86

Factors per gallon

Day Tank - 10.11
 Mix Tank - 10.11

		Micro-Motions	
Solids		Pounds	100% Solids
100%	MDI Core -	476	476
57%	PF Surf. -	1552	885
58%	Wax Core -	165	267
58%	Wax Surf. -	295	

		Tanks		Pounds	100% Solids
Solids		Before	After		
100%	Core MDI -	122.25"	121.375	525	525
2 ÷ 61%	Surf PF -	130.25"	130.25	0	0
2 ÷ 57%	Day Tank PF -	391 (1210)	928	1390	792
2 ÷ 57%	Mix Tank PF -	819	7		
2 ÷ 58%	Wax -	40"	38.5	573	332

Factors per inch	
MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon	
Day Tank -	10.11
Mix Tank -	10.11

3-19-96 Press Test # 3 2:40 PM - 3:55 PM

Solids	Micro-Motions	100% Solids
	Pounds	
100% MDI Core -	590	590
57% PF Surf. -	1953	1113
58% Wax Core -	204	118
58% Wax Surf. -	374	217

Tanks		Before	After	Pounds	100% Solids
Solids					
100% Core MDI -		120.5	119.375	676	676
2 ÷ 61% Surf PF -		130.25	119.25		
2 ÷ 57% Day Tank PF -		551	1012	2380	1357
2 ÷ 57% Mix Tank PF -		3	13		
2 ÷ 58% Wax -		37.5	35.75	334	194

Factors per inch	
MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon	
Day Tank -	10.11
Mix Tank -	10.11

DATE: 3-19-96
 SHIFT/CREW: 1-B
 OPERATOR: Jim W

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
2		39 $\frac{7}{8}$	31 31	4328 lbs	
4	4366 lbs	39 $\frac{7}{8}$	32 32	4349 lbs	40 $\frac{1}{8}$
6		39 $\frac{3}{4}$	33	4337 lbs	
8	4312 lbs	39 $\frac{3}{4}$	34	4343 lbs	40
			35	4339 lbs	
1	4493 lbs called 1220, 8126		36	4315 lbs	39 $\frac{5}{8}$
2	4491 lbs	40 $\frac{1}{8}$	37	4358 lbs	
3	4484 lbs		38	4342 lbs	39 39 $\frac{3}{4}$
4	4419 lbs	40	39	4316 lbs	
5	4397 lbs		40	4288 lbs	39 $\frac{5}{8}$
6	4326 lbs	40 $\frac{1}{8}$	41	4296 lbs	
7	4293 lbs		42	4286 lbs	39 $\frac{3}{4}$
8	4362 lbs	40	43	4273 lbs	
9	4404 lbs		44	4247 lbs	39 $\frac{7}{8}$
10	4366 lbs	40 $\frac{1}{8}$	45	4224 called 1220, 203	
12	4275 lbs		46	4233 lbs	39 $\frac{7}{8}$
12	4297 lbs	40 $\frac{1}{4}$	47	4276 lbs	
13	4327 lbs		48	4278 lbs	39 $\frac{7}{8}$
14	4386 lbs	40 $\frac{1}{4}$	49	4335 lbs	
15	4385 lbs		50	4333 lbs	40
16	4460 lbs	40 $\frac{1}{2}$ called 1220, 1051	51	4378 lbs	
17	4529 lbs		52	4367 lbs	40
18	4501 lbs	40 $\frac{1}{8}$	53	4378 lbs	
19	4466 lbs		54	4335 called 1220, 302	39 $\frac{3}{4}$
20	4435 lbs	40	55	4314 lbs	
21	4436 lbs		56	4346 lbs	40
22	4376 lbs	40	57	4359 lbs	
23	4361 lbs		58	4464 called 1220, 321	40 $\frac{1}{8}$
24	4320 lbs	40	59	4424 lbs	
25	4356 lbs		60	4383 lbs	40
26	4275 lbs	40	61	4366 lbs	
27	4229 lbs called 1220, 1207		62	4356 lbs	39 $\frac{7}{8}$
28	4221 lbs	39 $\frac{3}{4}$	63	4375 lbs	
29	4239 lbs		64	4368 lbs	39 $\frac{7}{8}$
30	4276 lbs	40	65	4332 lbs	

7/16"

1/2"

$\frac{1}{2}$ "148

DATE: 3-19-96
 SHIFT/CREW: 21D
 OPERATOR: M. Riley

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
1/1	1 4346		20	4253	39 3/4
1/2	2 4313	39 1/2 up	24		
	3 4280		26	4321	40 up
	4 4319	39 1/2 "	28		39 1/2
	5 4345		30	4356	39 5/8
	6 4367	40	32		39 1/2
	7 4400		34	4514	40 CP
	8 4377	40 1/4	36		40 CP
	9 4399		38	4604	40 CP
	10 4328	40 1/4	40		39 1/2
	11 4354		42	4572	39 1/2
	12 4341	40 1/4	44		39 3/4
	13 4339		46	4457	39 up
	14 4306	40	48		39
	15 4293		50	4347	38 3/4 up
	16 4278	40 1/8	52		39 1/4
	17 4314		54	4372	39 1/4
	18 4310	40 1/8	56		39 3/8
	19 4322		58	4360	39 3/8
	20 4322	40 1/4	60		39 1/4
	21 4311		62	4304	39 1/2
	22 4282	40	64		39 3/4
	24	40 1/8	66	4398	39 1/2
	26 4277	40 1/8	68		39 3/4
7/1	X X X X X X X X		70	4481	39 7/8 up
7/11	2 4178 up	40	72		39 1/2
	4	39 3/4	74	4003	39 1/2
	6 4127 CP	39 1/2	76		39 1/2
	8	39 1/2	78	4309	+
	10 4116 #	39 1/2	80		+
	12	39 1/2			
	14 4179	39 5/8			
	16	39 3/4			
	18 4258	39 5/8			
	20	39 3/4			

HAYWARD LINE 2 MARCH 20th 1996

PRESS VENT RTO STACK PM/METH/CO/VE

DATA TIME: START= 10:00 END= 14:15 HOURS= 4.25

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices
per unit over the testing period.

1/2"

per/peice 54.80

per/ 8' x 16' 219.21

PLANT PRODUCTION RATE

4.25 =hours during testing

64 =pressloads

768 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

168,355 =lbs of finished product (boards produced x weight of finished board)

39,613 =lbs of finished product per hour (lbs of finshed product / hours)

19.81 =tons of finished product per hour (lbs of finshed product per hour / 2000 lb)

RESIN USAGE TAKEN FROM MICRO - MOTIONS

TIME	MDI	PHENOL	WAX
11:35-12:35	487	841	332
13:05-14:05	450	935	222
AVERAGE	468.50	888.00	277.00

39,613 =average lbs. per hour finished product produced during testing

468.50 =average lbs. per hour of MDI resin used during testing

1.18% = MDI resin used as % of finished product

888.00 =average lbs. per hour of phenolic resin (100% solids) used during testing


2.24% =Phenolic resin used as % of finished product

277.00 =average lbs. per hour of wax (100% solids) used during testing


0.70% =wax used as % of finished product

15)


LINE II
PRESS CHART
3/20/96
0700-1500



LINE II
PRESS CHART
3/20/96
1500-1900



LINE II
PRESS CHART
3/20/96
1900-030~



LII Press RTO


3/20/96

RECORD EVERY 15 MIN.						HAYWARD AIR TESTING WORKSHEET						
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage
9:00	410	394	404	426	406	3.8	1566	1553	1509	216	18.5	
9:15	417	394	405	228	405	3.8	1604	1605	1516	222	18.3	
9:30	418	394	406	227	405	3.5	1572	1569	1502	218	18.5	
9:45	412	395	405	429	405	3.7	1588	1586	1507	222	18.2	
10:00	418	393	406	425	404	3.5	1575	1577	1507	216	18.7	
10:15	410	395	405	427	406	3.7	1588	1566	1506	222	18.2	
10:30	412	395	405	424	406	3.7	1558	1556	1501	221	18.2	
10:45	416	397	403	430	405	3.6	1588	1584	1507	217	18.6	
11:00	416	399	402	426	408	3.9	1562	1551	1503	221	18.3	
11:15	414	400	401	427	406	3.5	1566	1571	1503	218	18.3	
11:30	410	403	397	435	404	3.8	1602	1607	1512	222	18.1	
11:45	414	402	398	433	403	3.8	1585	1583	1507	216	18.7	
12:00	409	403	399	429	405	3.7	1559	1556	1506	221	18.2	
12:15	410	401	400	427	405	3.6	1557	1562	1502	222	18.2	
12:30	411	403	399	434	403	3.8	1607	1605	1515	220	18.2	
12:45	405	405	399	426	409	3.7	1558	1560	1503	222	18.2	
1:00	404	408	399	427	411	3.9	1566	1554	1505	221	18.3	
1:15	405	410	396	435	409	3.8	1604	1603	1515	221	18.3	
1:30	406	411	395	436	409	3.7	1608	1608	1516	222	18.2	
1:45	405	413	394	437	409	3.8	1606	1603	1514	220	18.3	
2:00	408	414	395	434	409	3.6	1589	1587	1510	218	18.5	
2:15	408	414	396	433	410	3.6	1601	1596	1514	220	18.3	
2:30	403	415	396	432	412	3.7	1591	1593	1515	222	18.1	
2:45	405	415	399	424	414	3.5	1566	1572	1504	220	18.4	
3:00	400	418	396	431	414	3.8	1607	1606	1513	222	18.0	
3:15	397	419	395	427	416	3.8	1570	1565	1508	222	18.3	
3:30	398	419	394	429	416	3.7	1565	1559	1508	222	18.2	
3:45	398	420	393	431	416	3.7	1581	1580	1510	222	18.1	
4:00	403	420	394	433	415	3.7	1605	1602	1515	221	18.2	
4:15	405	419	396	428	416	3.8	1582	1584	1510	220	18.4	
4:30	403	420	396	431	417	3.7	1604	1603	1515	222	18.2	
4:45	399	420	397	427	419	3.7	1570	1563	1509	223	18.2	
5:00	405	420	397	431	417	3.6	1604	1603	1515	222	18.2	
5:15	401	421	395	432	418	3.8	1605	1606	1514	222	18.1	
5:30	406	420	395	426	418	3.5	1569	1577	1504	220	18.4	
5:45	401	420	397	426	419	3.7	1559	1559	1504	222	18.1	
6:00	410	417	398	430	414	3.4	1577	1582	1507	219	18.5	
6:15	408	417	397	435	412	3.8	1609	1606	1515	222	18.1	
6:30	408	416	397	434	412	3.7	1605	1603	1516	221	18.2	
6:45	402	418	398	424	418	3.7	1561	1558	1503	222	18.1	

3/20/96

157

3/20/96



Press Test #2 3-20-96

11:35 A.M. - 12:35 P.

Solids	Micro-Motions Pounds	100% Solids
100% MDI Core - 453		453
57% PF Surf. - 1557		887
58% Wax Core - 215		332
58% Wax Surf. - 358		

Tanks

Solids	Before	After	Pounds	100% Solid
100% Core MDI - 105.625"	104.813"		487	487
2 ÷ 61% Surf PF - 42.75"				
2 ÷ 57% Day Tank PF - 406	890		2952	841
2 ÷ 57% Mix Tank PF - 778	2			
2 ÷ 58% Wax - 6'11.5" (83.50")	6'8.5" (80.5")		1146	335

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

Press Test #3 3-20-96 1:05 P.M. - 2:05 P.M.

Micro-Motions

Solids	Pounds	100% Solids
100% MDI Core -	454	454
57% PF Surf. -	1560	889
58% Wax Core -	216	329
58% Wax Surf. -	352	

4721

Tanks

Solids	Before	After	Pounds	100% Solids
100% Core MDI -	104.438"	103.688"	450	450
2 ÷ 61% Surf PF -	42.813"	31.813"		
2 ÷ 57% Day Tank PF -	738	491	3282	935
2 ÷ 57% Mix Tank PF -	1	7.5		
2 ÷ 58% Wax -	79.00"	77.00"	764	223

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

160

Press Test #4 3-20-96 4:50 P.M.-

Micro-Motions

Solids	Pounds	100% Solids
100% MDI Core -	454	454
57% PF Surf. -	1554	886
58% Wax Core -	209	335
58% Wax Surf. -	369	

Tanks

Solids	Before	After	Pounds	100% Solids
100% Core MDI -	101.75"	101.125"	375	375
2 ÷ 61% Surf PF -	31.375"			
2 ÷ 57% Day Tank PF -	511	1034	3750	106%
2 ÷ 57% Mix Tank PF -	67	15		
2 ÷ 58% Wax -	69.00"	69.00"	573	332

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

Press Test #5 3-20-96 6:15 P.M. - 7:15 P.M.

Micro-Motions

Solids	Pounds	100% Solids
100% MDI Core - 454	454	
57% PF Surf. - 1543	880	
58% Wax Core - 207	327	
58% Wax Surf. - 357		

Tanks

Solids	Before	After	Pounds	100% Solids
100% Core MDI - 100.75"	99.938"	488	488	
2 ÷ 61% Surf PF -				
2 ÷ 57% Day Tank PF - 908	604	3094	882	
2 ÷ 57% Mix Tank PF - 6	4			
2 ÷ 58% Wax - 65"	62"	573	332	

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

Press Test #6 3-20-96 8:15 P.M. - 9:15 P.M.

Micro-Motions

Solids	Pounds	100% Solids
100% MOI Core -	451	451
57% PF Surf. -	1522	867
58% Wax Core -	192	271
58% Wax Surf. -	276	

Tanks

Solids	Before	After	Pounds	100% Solids
100% Core MOI -	99.125"	98.125"	600	600
2 ÷ 61% Surf PF -	32.875"			
2 ÷ 57% Day Tank PF -	750	872	2528	72
2 ÷ 57% Mix Tank PF -	375	3		
2 ÷ 58% Wax -	60.5" 60"	60"	190	111

Factors per inch

MOI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

DATE: 3-20-96
SHIFT/CREW: 1-C
OPERATOR: AL RANG

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
7/1 1	4357	39 1/2	29	4270 (11:17)	40
7/16 2		39 1/2	30	4250 (11:23)	39 3/4
3		39 1/2	31	4218 (11:39)	39 3/4
4		39 3/4	32	4198 (11:35)	39 3/4
5	4448	39 1/2	33	4187 (11:41)	39 3/4
6		39 3/4	34	4189 (11:45)	40
7		39 3/4	35	4215 (11:54)	40
1/2 1	4445	40 1/4	36	4266 (12:00)	40
2	4485 (8:12)	40 1/4	37	4306 (12:06)	40
3	4393 (8:12)	40	38	4342 (12:30)	40 1/8
4	4279 (8:14)	40	39	4342 (12:19)	40
5	4330 (8:20)	40	40	4335 (12:26)	40
6	4362 (8:22)	40	41	4332 (12:32)	40
7	4375 (8:35)	40	42	4350 (12:35)	40 1/4
8	4371 (8:40)	40	43	4392 (12:44)	40 1/4
9	4388 (8:48)	40	44	4380 (12:52)	40 1/4
10	4390 (8:55)	40	45	4368 (12:58)	40 1/4
11	4432 (9:59)	40 1/4	46	4379 (1:03)	40 1/4
12	4397 (9:06)	40	47	4388 (1:09)	40 1/4
13	4523 (9:13)	40	48	4387 (1:15)	40 1/2
14	4371 (9:12)	40	49	4353 (1:21)	40 1/2
15	4313 (9:46)	40	50	4393 (1:28)	40 1/4
16	4275 (9:55)	40	51	4319 (1:34)	40 1/4
17	4426 (10:01)	40	52	4355 (1:46)	40 1/8
18	4437 (10:08)	40 1/4	53	4355 (1:47)	40 1/8
19	4450 (10:12)	40	54	4347 (1:54)	40
20	4472 (10:22)	40	55	4301 (1:59)	40
21	4426 (10:28)	40	56	4333 (2:06)	40
22	4427 (10:34)	40	57	4339 (2:13)	40
23	4445 (10:35)	40	58	4411 (2:18)	40
24	4385 (10:44)	40	59	4440 (2:25)	40
25	4351 (10:51)	40	60	4520 (2:32)	40 1/2
26	4360 (10:57)	40	61	4510 (2:37)	40 1/2
27	4295 (11:04)	40	62	4608 (2:44)	40 3/4
28	4293 (11:10)	40	63	4613 (2:49)	41

DATE: _____
 SHIFT/CREW: _____
 OPERATOR: _____

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
64	4592 (2.36)	41 CP	94	4496 (6.30)	40 3/4
65	4618 (3.03)	41	100	4471 (6.41)	40 1/4
66	4659 (3.09)	41 1/4 CP	101	4482 (6.40)	40 1/4
67	4584 (3.07)	40 3/4	102	4482 (6.53)	40 1/4
68	4521 (3.21)	40 1/2	103	4486 (6.57)	40 1/4
69	4450 (3.28)	40 1/2			
70	4430 (3.33)	40 1/4			
71	4418 (3.41)	40 1/4			
72	4437 (3.47)	40 1/2			
73	4420 (3.52)	40 1/2			
74	4421 (3.59)	40 1/4			
75	4418 (4.05)	40 1/4			
76	4422 (4.13)	40 1/4			
77	4452 (4.18)	40 1/4			
78	4433 (4.24)	40 1/4			
79	4437 (4.29)	40 1/4			
80	4440 (4.35)	40 1/2			
81	4373 (4.43)	40			
82	4323 (4.50)	40			
83	4327 (4.56)	40			
84	4270 (4.50)	40			
85	4260 (5.07)	40			
86	4293 (5.15)	40			
87	4350 (5.21)	40			
88	4316 (5.28)	40			
89	4306 (5.31)	40			
90	4340 (5.39)	40 1/4			
91	4356 (5.45)	40 1/4			
92	4366 (5.52)	40			
93	4366 (5.59)	40			
94	4367 (6.04)	40			
95	4425 (6.10)	40			
96	4472 (6.17)	40 1/2			
97	4444 (6.23)	40 1/4			
98	4493 (6.29)	40 1/4			

DATE: 3-20-76
SHIFT/CREW: A-2
OPERATOR: Am...

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
1	4441#		22	4486#	39 3/4
2	4403#	40 1/4	24		39 3/8
3	4391#		26		39 1/2
4	4354#	40 1/8	28	4292#	39 1/4
5	4386#		30 <i>collap</i>	4371#	40 3/8
6	4377#	40	32 <i>collap</i>	4294#	39
7	4395#		34	4343#	39 1/4
8	4413#	40 1/4	36		39 7/8
9	4427#		38	4372#	39 3/4
10	4405#	40 1/4	40		39 5/8
11	4407#		42	4404#	39 3/4
12	4418#	40	44		39 5/8
13	4435#		46	4387#	39 3/4
14	4422#	40 1/4	48		39 1/2
15	4401#		50	4378	39 1/2
16	4405#	40 1/8	52		39 1/2
17	4355#		54	4454#	39 3/8
18	4360#	39 3/8	56		39 3/8
19	4400#		58	4330#	39 1/2
20	4331#	40	60		39 1/2
21	4286#		62		39 3/8
22	4284#	39 1/8	64		39 3/8
23 <i>collap</i>	4208#		66		-
24		40 1/8	68		-
26	4192	39 3/4	70		-
2	4392#	39 7/8	74 <i>collap</i>	4502#	37 1/2
4 <i>collap</i>		40	2		35 5/8
5 " "	4541#	40	49C		35 1/2
8 <i>collap</i>		40	6		-
10 " "	4539#	39 3/4	8		36 1/2
12		40 1/4	10		-
14		40 3/8			-
16		40 1/8			-
18 <i>collap</i>	4544#	40 1/4			-
20 " "		40			-

HAYWARD LINE 2 PRESS VENT RTO INLET MARCH 20th 1996

NOX/CO/CO2/THC/M2/O2

DATA TIME: START= 16:45 END= 21:15 HOURS= 4.50

BOARD WEIGHTS - LBS

average weights determined by taking bundle weights divided by peices per unit over the testing period.

1/2"

per/peice 54.80

per/ 8' x 16' 219.21

PLANT PRODUCTION RATE

4.50 =hours during testing

70 =pressloads

840 =no. of 8'x16' boards produced (pressloads x 12 boards per load)

184,138 =lbs of finished product (boards produced x weight of finished board)

40,920 =lbs of finished product per hour (lbs of finshed product / hours)

20.46 =tons of finished product per hour (lbs of finshed product per hour / 2000 lb)

RESIN USAGE TAKEN FROM MICRO - MOTIONS

TIME	MDI	PHENOL	WAX
16:50-17:50	454	886	335
18:15-19:15	454	880	327
20:15-21:15	451	867	271
AVERAGE	453.00	877.67	311.00

40,920 =average lbs. per hour finished product produced during testing

453.00 =average lbs. per hour of MDI resin used during testing

1.11% = MDI resin used as % of finished product

877.67 =average lbs. per hour of phenolic resin (100% solids) used during testing

2.14% =Phenolic resin used as % of finished product

311.00 =average lbs. per hour of wax (100% solids) used during testing

0.76% =wax used as % of finished product

PRESS REPORT - ~~UNE~~ - 1 (6)

OPERATOR

DATE: 3-20-90

SHIFT:

CREW:

THICKNESS

FRESS LEE:

OVERALL

DECOMPRESSION

TIME:

TIME:

ESS

TOTAL

TEMP:

REFLECTS:

LOG COUNT:

F.C.O.S. HYD. REACTOR:

PRESS SLOWLY DOWN:

SPINNER HEADS FLUSHED:

SURFACE BLENDER HOSED:

FORMER HYD RADIATOR:


$$\frac{3}{8} = 374,371$$
DOWNTIME CODE:

M - MECHANICS


E - ELECTRICAL

O - OPERATOR

Line II
PRESS CHART
3/20/96
0700-1500



LINE II
 PRESS CHART
 3/20/96
 1500-1900



100



LII Press RTO


3/20/96

RECORD EVERY 15 MIN.												
HAYWARD AIR TESTING WORKSHEET												
Time	RTO Chamber Bed Temp.					Inlet	Burners		Combust.	Exhaust	Press.	Gas
	#1	#2	#3	#4	#5	Press.	B#1	B#2	Temp.	Temp.	Drop	Usage
9:00	410	394	404	426	406	3.8	1566	1553	1509	216	18.5	
9:15	417	394	405	428	405	3.8	1604	1605	1516	222	18.3	
9:30	418	394	406	427	405	3.5	1572	1569	1502	218	18.5	
9:45	412	395	405	429	405	3.7	1588	1586	1507	222	18.2	
10:00	418	393	406	425	404	3.5	1575	1577	1507	216	18.7	
10:15	410	395	405	427	406	3.7	1585	1566	1506	222	18.2	
10:30	412	395	405	424	406	3.7	1558	1556	1501	221	18.2	
10:45	416	397	403	430	405	3.6	1588	1584	1507	217	18.6	
11:00	410	399	402	426	408	3.9	1562	1551	1503	221	18.3	
11:15	414	400	401	427	406	3.5	1566	1571	1503	218	18.3	
11:30	410	403	397	435	404	3.8	1602	1607	1512	222	18.1	
11:45	414	402	398	433	403	3.8	1585	1583	1507	216	18.7	
12:00	409	403	399	429	405	3.7	1559	1556	1506	221	18.2	
12:15	410	401	400	427	405	3.6	1557	1562	1502	222	18.2	
12:30	411	403	399	434	403	3.8	1607	1605	1515	220	18.2	
12:45	405	405	399	426	409	3.7	1558	1560	1503	222	18.2	
1:00	404	408	399	427	411	3.9	1560	1554	1505	221	18.3	
1:15	405	410	396	435	409	3.8	1604	1603	1515	221	18.3	
1:30	406	411	395	436	409	3.7	1608	1608	1516	222	18.2	
1:45	405	413	394	437	409	3.8	1666	1603	1514	220	18.3	
2:00	408	414	395	434	409	3.6	1589	1587	1510	218	18.5	
2:15	408	414	396	433	410	3.6	1601	1596	1514	220	18.3	
2:30	403	415	396	432	412	3.7	1591	1593	1515	222	18.1	
2:45	405	415	399	424	414	3.5	1566	1572	1504	220	18.4	
3:00	400	418	396	431	414	3.8	1607	1606	1513	222	18.0	
3:15	397	419	395	427	416	3.8	1570	1565	1508	222	18.3	
3:30	398	419	394	429	416	3.7	1565	1559	1508	222	18.2	
3:45	398	420	393	431	416	3.7	1581	1580	1510	222	18.1	
4:00	403	420	394	433	415	3.7	1605	1602	1515	221	18.2	
4:15	405	419	396	428	416	3.8	1582	1584	1510	220	18.4	
4:30	403	420	396	431	417	3.7	1604	1603	1515	222	18.2	
4:45	399	420	397	427	419	3.7	1570	1563	1509	223	18.2	
5:00	405	420	397	431	417	3.6	1604	1600	1515	222	18.2	
5:15	401	421	395	432	418	3.8	1605	1606	1514	222	18.1	
5:30	406	420	395	426	418	3.5	1569	1577	1504	220	18.4	
5:45	401	420	397	426	419	3.7	1559	1559	1504	222	18.1	
6:00	410	417	398	430	414	3.4	1577	1582	1507	219	18.5	
6:15	408	417	397	435	412	3.8	1609	1606	1515	222	18.1	
6:30	408	416	397	434	412	3.7	1605	1603	1516	221	18.2	
6:45	402	418	398	424	418	3.7	1561	1558	1503	222	18.1	

3/20/96

174

3/20/96



Press Test #2 3-20-96

11:35 A.M. - 12:35 P.

Solids	Micro-Motions	100% Solids
	Pounds	
100% MDI Core -	453	453
57% PF Surf. -	1557	887
58% Wax Core -	315	332
58% Wax Surf. -	358	

Solids	Tanks	Before	After	Pounds	100% Solids
100% Core MDI -	105.835"	104.813"		487	487
2 ÷ 61% Surf PF -	42.75"				
2 ÷ 57% Day Tank PF -	406	890		2952	841
2 ÷ 57% Mix Tank PF -	778	2			
2 ÷ 58% Wax	-6'11.5" (83.50")	-6'8.5" (80.5")		1146	332

Factors per inch	
MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon	
Day Tank -	10.11
Mix Tank -	10.11

Press Test #3 3-20-96 1:05 P.M. - 2:05 P.M.

Micro-Motions

Solids	Pounds	100% Solids
100% MDI Core - 454	454	
57% PF Surf. - 1560	889	
58% Wax Core - 216	329	
58% Wax Surf. - 352		

4721

Tanks

Solids	Before	After	Pounds	100% Solids
100% Core MDI -	104.438"	103.688"	450	450
2 ÷ 61% Surf PF -	42.813"	31.813"		
2 ÷ 57% Day Tank PF -	738	491	3282	935
2 ÷ 57% Mix Tank PF -	1	715		
2 ÷ 58% Wax -	79.00"	77.00"	764	222

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

177

Press Test #4 3-30-96 4:50 P.M. -

Micro-Motions

Solids	Pounds	100% Solids
100% MDI Core -	454	454
57% PF Surf. -	1554	886
58% Wax Core -	209	335
58% Wax Surf. -	369	

Tanks

Solids	Before	After	Pounds	100% Solids
100% Core MDI -	101.75"	101.125"	375	375
2 ÷ 61% Surf PF -	31.375"			
2 ÷ 57% Day Tank PF -	511	1034	3750	1069
2 ÷ 57% Mix Tank PF -	67	15		
2 ÷ 58% Wax -	69.00"	100.00"	573	332

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

Press Test #5 3-20-96 6:15 P.M. - 7:15 P.M.

Micro-Motions

Solids	Pounds	100% Solids
100% MDI Core - 454	454	
57% PF Surf. - 1543	880	
58% Wax Core - 207	327	
58% Wax Surf. - 357		

Tanks

Solids	Before	After	Pounds	^{100%} Solids
100% Core MDI -	100.75"	99.938"	488	488
2 ÷ 61% Surf PF -				
2 ÷ 57% Day Tank PF -	908	604	3094	881
2 ÷ 57% Mix Tank PF -	6	4		
2 ÷ 58% Wax -	65"	62"	573	332

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

Press Test #6 3-20-96 8:15 P.M. - 9:15 P.M.

Micro-Motions

Solids	Pounds	100% Solids
100% MDI Core -	451	451
57% PF Surf. -	1522	867
58% Wax Core -	192	271
58% Wax Surf. -	276	

Tanks

Solids	Before	After	Pounds	100% Solids
100% Core MDI -	99.125"	98.125"	600	600
2 ÷ 61% Surf PF -	32.875"			
2 ÷ 57% Day Tank PF -	750	872	2528	720
2 ÷ 57% Mix Tank PF -	375	3		
2 ÷ 58% Wax -	60.5" 60"	60"	190	111

Factors per inch

MDI Tank -	600.466
PF Tank -	727.583
Wax Tank -	381.86

Factors per gallon

Day Tank -	10.11
Mix Tank -	10.11

DATE: 3-20-96
 SHIFT/CREW: 1-C
 OPERATOR: AL RANG

UNIT/	THICKNESS	WEIGHT	HEIGHT	UNIT/	THICKNESS	WEIGHT	HEIGHT
1	1 1/2	4357	39 1/2	29	4270 (11:17)	40	
2	2 1/2		39 1/2	30	4250 (11:23)	39 3/4	
3	3 1/2		39 1/2	31	4248 (11:29)	39 3/4	
4	4 1/2		39 3/4	32	4198 (11:35)	39 3/4	
5	5 1/2	4448	39 1/2	33	4187 (11:41)	39 3/4	
6			39 3/4	34	4189 (11:45)	40	
7			39 3/4	35	4215 (11:54)	40	
1 1/2	1	4445	40 1/4	36	4266 (12:00)	40	
2		4485 (8:10)	40 1/4	37	4306 (12:06)	40	
3		4393 (8:13)	40	38	4342 (12:30)	40 1/8	
4		4279 (8:14)	40	39	4392 (12:19)	40	
5		4330 (8:20)	40	40	4335 (12:26)	40	
6		4362 (8:27)	40	41	4332 (12:32)	40	
7		4375 (8:35)	40	42	4380 (12:39)	40 1/4	
8		4371 (8:40)	40	43	4392 (12:44)	40 1/4	
9		4385 (8:46)	40	44	4380 (12:52)	40 1/4	
10		4340 (8:55)	40	45	4388 (12:58)	40 1/4	
11		4432 (9:39)	40 1/4	46	4379 (1:03)	40 1/4	
12		4397 (9:06)	40	47	4388 (1:09)	40 1/4	
13		4323 (9:16)	40	48	4387 (1:15)	40 1/2	
14		4371 (9:12)	40	49	4353 (1:21)	40 1/2	
15		4313 (9:49)	40	50	4393 (1:28)	40 1/4	
16		4279 (9:55)	40	51	4319 (1:34)	40 1/4	
17		4426 (10:01)	40	52	4325 (1:40)	40 1/8	
18		4437 (10:00)	40 1/4	53	4355 (1:47)	40 1/8	
19		4450 (10:12)	40	54	4347 (1:54)	40	
20		4472 (10:32)	40	55	4301 (1:59)	40	
21		4426 (10:22)	40	56	4333 (2:06)	40	
22		4427 (10:34)	40	57	4339 (2:13)	40	
23		4445 (10:39)	40	58	4411 (2:18)	40	
24		4389 (10:44)	40	59	4440 (2:25)	40	
25		4351 (10:51)	40	60	4520 (2:32)	40 1/2	
26		4360 (10:57)	40	61	4510 (2:37)	40 1/2	
27		4295 (11:01)	40	62	4608 (2:44)	40 3/4	
28		4293 (11:10)	40	63	4613 (2:49)	41	

DATE: _____
 SHIFT/CREW: _____
 OPERATOR: _____

1/2'

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
64	4592 (2:56)	41 CP	99	4496 (6:30)	40 1/4
65	4618 (3:03)	41	100	4471 (6:41)	40 1/4
66	4659 (3:09)	41 1/4 CP	101	4480 (6:40)	40 1/4
67	4584 (3:05)	40 3/4	102	4482 (6:53)	40 1/4
68	4521 (3:21)	40 1/2	103	4486 (6:57)	40 1/4
69	4450 (3:28)	40 1/2			
70	4430 (3:35)	40 1/4			
71	4418 (3:41)	40 1/4			
72	4437 (3:47)	40 1/2			
73	4420 (3:52)	40 1/2			
74	4421 (3:59)	40 1/4			
75	4418 (4:05)	40 1/4			
76	4422 (4:11)	40 1/4			
77	4452 (4:18)	40 1/4			
78	4433 (4:24)	40 1/4			
79	4437 (4:29)	40 1/4			
80	4440 (4:35)	40 1/2			
81	4373 (4:43)	40			
82	4383 (4:50)	40			
83	4327 (4:56)	40			
84	4270 (5:02)	40			
85	4260 (5:07)	40			
86	4243 (5:15)	40			
87	4350 (5:21)	40			
88	4316 (5:28)	40			
89	4306 (5:31)	40			
90	4340 (5:39)	40 1/4			
91	4356 (5:45)	40 1/4			
92	4366 (5:52)	40			
93	4346 (5:59)	40			
94	4367 (6:04)	40			
95	4475 (6:10)	40			
96	4472 (6:17)	40 1/2			
97	4444 (6:23)	40 1/4			
98	4493 (6:29)	40 1/4			

DATE: 3-20-96
 SHIFT/CREW: A-2
 OPERATOR: Amir

UNIT/ THICKNESS	WEIGHT	HEIGHT	UNIT/ THICKNESS	WEIGHT	HEIGHT
1/2 1	4441#		22	4486#	39 3/4
2	4403#	40 1/4	24		39 3/8
3	4391#		26		39 1/2
4	4354#	40 1/8	28	4292#	39 1/4
5	4386#		30 <i>collap</i>	4371#	40 7/8
6	4377#	40	32 <i>collap</i>	4294#	39
7	4395#		34	4343#	39 1/4
8	4413#	40 1/4	36		39 7/8
9	4427#		38	4372#	39 3/4
10	4405#	40 1/4	40		39 5/8
11	4407#		42	4404#	39 3/4
12	4418#	40	44		39 5/8
13	4435#		46	4387#	39 3/4
14	4422#	40 1/4	48		39 1/2
15	4401#		50	4378	39 1/2
16	4405#	40 1/8	52		39 1/2
17	4355#		54	4459#	39 5/8
18	4360#	39 7/8	56		39 5/8
19	4400#		58	4330#	39 1/2
20	4331#	40	60		39 1/2
21	4286#		62		39 5/8
22	4284#	39 1/8	64		39 3/8
23 <i>collap</i>	4208#		66		-
24		40 7/8	68		-
25		39 3/4	70		-
7/16 2	4392#	39 7/8	74 <i>collap</i>	4502#	37 1/4
4 <i>collap</i>		40	2		35 5/8
5 11 11	4541#	40	48C		35 1/2
8 <i>collap</i>		40	6		-
10 11 11	4539#	39 3/4	8		36 1/2
12		40 1/4	10		-
14		40 3/8			-
16		40 1/8			-
18 <i>collap</i>	4544#	40			-
20 11 11		40			-

SHIFT: (1) OR II
 LINES 1 & 2

K-1 - K-2

 Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
14										135	2
.06										.06	.10
3A										25	25
1.2										3.2	3.2
0										1.4	1.4
312										406	414
267										242	282
OK										OK	OK
OK	8	8	8	8	8	8	8	8	8	4	3

 Rock Usage/Shift: Added 1 Bag of Rock to Storage

K-3 - K-4

 Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
10.5	10.5	10.5	10.5	10.5	10.5	10.5	10.5	10.5	10	10	10.5
.28	.28	.26	.26	.26	.32	.28	.27	.26	.26	.28	.26
25	25	24	24	24	25	25	25	24	24	24	24
3.2	3.2	3.4	3.2	3.2	3.2	3.0	2.8	3.3	3.7	3.6	3.2
.04	.04	.04	.04	.04	.04	.04	.04	.04	.04	.04	.04
460	466	477	475	472	492	489	472	472	476	488	490
399	392	390	388	378	381	386	392	389	389	391	384
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift:

 Baghouse
 Pressure
 Drop: (in.)

	7	8	9	10	11	12	1	2	3	4	5	6
L-I	3.5										3.5	3.9
L-II	4.6	4.7	4.4	4.4	4.4	4.3	4.4	4.4	4.4	4.3	4.3	4.2

Comments/Problems:

Cleaned Line I Ionizers, Changed top LH pipe and Bounce pad.

*Condition Codes

- 1) Start up/shutdown
- 2) Konus down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Konus on oil
- 8) Maintenance

VOLUME PER SHIFT

LINE I	1
LINE II	2

SHIFT: 1 OR (II)
 LINES 1 & 2

K-1 - K-2

Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
1.0	8.0	10.5	10.0	12.0	12.0	11.0	11.5	12.0	12.0	14.0	15.0
1.2	1.6	1.2	1.4	1.6	1.6	1.6	1.8	1.6	1.4	1.6	1.2
28	28	28	28	28	28	28	28	28	28	28	28
3.8	3.6	3.6	3.6	3.4	3.4	3.4	3.4	3.4	3.4	2.2	1.8
1.6	1.6	1.6	1.6	1.6	1.6	1.4	1.4	1.6	1.6	1.8	0
421	422	417	416	412	411	411	409	408	378	297	178
309	311	311	312	313	311	310	309	310	316	293	217
ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
3	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok

Rock Usage/Shift: _____

K-3 - K-4

Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
11.0	11.0	11.0	11.0	10.5	10.5	10.0	10.0	10.0	11.0	11.0	11.0
2.6	2.8	2.8	2.8	3.0	3.0	3.0	3.0	2.6	2.6	2.8	3.0
24	24	24	24	25	25	24	24	24	24	24	24
2.8	3.0	3.0	3.2	3.2	3.2	3.2	3.0	3.2	3.4	3.4	3.4
.4	.4	.4	.4	.4	.4	.4	.4	.4	.4	.4	.4
465	483	519	521	522	527	530	530	529	501	508	51
385	381	380	380	380	381	382	383	375	365	369	372
ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok

Rock Usage/Shift: _____

Baghouse
 Pressure
 Drop: (in.)

	7	8	9	10	11	12	1	2	3	4	5	6
L-I	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0
L-II	4.4	4.4	4.4	4.4	4.4	4.4	4.2	4.2	4.4	4.4	4.6	4.6

Comments/Problems: _____

*Condition Codes

- 1) Start up/shutdown
- 2) Konus down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Konus on oil
- 8) Maintenance

VOLUME PER SHIFT

LINE I	3
LINE II	3

SHIFT: ① OR II
 LINES 1 & 2

K-1 - K-2

 Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
14	16	14	12.5	13	13			1	1.5	1	1.5
.01	.0	0	0	0	0			.28	.34	0	.08
28	28	15	23	30	30			20	19.5	26	20
2.8	2.0	1.8	1.8	1.2	1.4			2.6	2.8	2.6	1.2
0	.09	0	1.0	.05	.08			.06	0	0	0
177	175	161	151	152	150			393	407	405	394
199	166	135	121	109	108			125	258	301	302
OK	OK	OK	OK	OK	OK			OK	OK	OK	OK
8	8	8	8	8	8	8	8	3	3	3	OK

Rock Usage/Shift: _____

K-3 - K-4

 Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
10	5	5.5	6	5.5	5.5	5.5	5.5	5.5	7	6.5	6.5
.30	.20	.18	.13	.18	.16	.16	.17	.17	.20	.20	.20
24	25	25	24	24	24	24	24	24	25	24	24
3.2	2.8	3.0	3.3	3.2	3.3	3.5	3.2	2.9	3.2	3.4	3.4
.05	.09	.04	.04	.04	.04	.04	.04	.05	.03	.04	.04
511	527	500	492	493	489	470	487	475	479	494	512
372	387	390	364	386	390	391	394	396	389	390	389
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

 Baghouse
 Pressure
 Drop: (in.)

	7	8	9	10	11	12	1	2	3	4	5	6
L-I	3.7	3.3	3.2	3.4	3.4	3.4			2.5	1.5	2.0	2.0
L-II	4.8	4.8	4.4	4.6	4.6	4.6	4.7	4.8	4.6	4.5	4.5	4.6

Comments/Problems: _____

*Condition Codes

- 1) Start up/shutdown
- 2) Konus down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Konus on oil
- 8) Maintenance

VOLUME PER SHIFT

LINE I	1
LINE II	2

SHIFT: I OR **II**
 LINES 1 & 2

K-1 - K-2

Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
14	14	14	14	14	14	14	14	14	14	14	13
.06	.06	.05	.06	.05	.08	.08	.10	.10	.08	.08	.08
30	30	28	28	28	28	28	28	28	28	28	28
3.8	3.8	2.8	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
0	0	0	.08	.08	.01	.01	.01	.01	0	0	0
400	396	361	344	396	386	384	385	386	382	384	377
297	297	294	285	287	288	287	289	290	291	293	290
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

K-3 - K-4

Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

7	8	9	10	11	12	1	2	3	4	5	6
7	7	7	7	7	7	7	7	7	7	7	7
2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
25	25	22	22	22	20	20	20	20	20	20	20
3.0	3.0	2.8	3.6	3.8	2.0	2.0	2.0	2.0	2.0	2.0	2.0
.04	.04	.04	.03	.03	.03	.04	.04	.04	.03	.03	.03
515	504	500	504	507	531	533	516	494	509	500	520
384	390	392	396	348	392	343	362	387	395	396	39
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

Baghouse
 Pressure
 Drop: (in.)

	7	8	9	10	11	12	1	2	3	4	5	6
L-I	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
L-II	4.5	4.5	4.4	4.6	4.8	4.5	4.5	4.6	4.8	4.5	4.5	4.5

Comments/Problems: _____

*Condition Codes

- 1) Start up/shutdown
- 2) Konus down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Konus on oil
- 8) Maintenance

VOLUME PER SHIFT

LINE I	1 1/2
LINE II	1 1/2

SHIFT: ① OR II
 LINES 1 & 2

K-1 - K-2

 Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

	7	8	9	10	11	12	1	2	3	4	5	6
Bed Voltage (KV)	13	12.5	12	12	11.5	11.5	11.5	11.5	10	11	11	11
Bed Amperage (MA)	108	110	114	115	117	120	114	118	120	121	122	122
Ionizer Voltage (KV)	27	28	28	27	29	29	28	29	28	28	28	26
Ionizer Amperage (MA)	30	32	34	38	39	34	36	39	40	34	30	34
EFB Pressure Drop (In.)	0	1.7	1.7	2.2	2.6	2.2	2.4	2.1	2.0	1.8	1.6	1.6
Inlet Temperature	378	375	401	411	416	418	403	411	418	419	420	419
Outlet Temperature	290	297	303	312	320	323	323	323	327	327	330	329
Rock Flow	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
Condition Code*	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift:

K-3 - K-4

 Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

	7	8	9	10	11	12	1	2	3	4	5	6
Bed Voltage (KV)	6.5	6.5	6.5	6.5	6.5	6.5	6.9	7	7	7	7	7
Bed Amperage (MA)	120	120	120	119	113	118	120	120	118	118	118	117
Ionizer Voltage (KV)	21	21	21	21	20	20	21	21	21	21	21	21
Ionizer Amperage (MA)	20	20	20	21	20	20	20	22	20	20	21	22
EFB Pressure Drop (In.)	1.04	1.04	1.05	1.04	1.04	1.04	1.05	1.04	1.04	1.04	1.04	1.04
Inlet Temperature	499	475	484	449	437	439	443	435	449	453	448	480
Outlet Temperature	395	398	396	397	403	403	407	403	404	405	407	400
Rock Flow	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
Condition Code*	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift:

 Baghouse
 Pressure
 Drop: (in.)

	7	8	9	10	11	12	1	2	3	4	5	6
L-I	2.4	2.3	2.5	2.4	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.1
L-II	4.8	4.8	4.8	4.7	4.7	4.7	4.4	4.4	4.6	4.4	4.4	4.6

Comments/Problems:

*Condition Codes

- 1) Start up/shutdown
- 2) Konus down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Konus on oil
- 8) Maintenance

VOLUME PER SHIFT

LINE I	1 1/2
LINE II	1 1/2

SHIFT: I OR II
 LINES 1 & 2

K-1 - K-2

 Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

	7	8	9	10	11	12	1	2	3	4	5	6
Bed Voltage (KV)	10	10	7	7	7	7	7	7	7	5	6	5
Bed Amperage (MA)	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	1.8
Ionizer Voltage (KV)	28	28	26	26	26	24	24	24	24	24	24	24
Ionizer Amperage (MA)	3.0	3.0	3.0	3.0	3.0	3.0	3.0	2.5	2.5	2.5	2.4	2.4
EFB Pressure Drop (In.)	1.8	1.8	1.8	1.8	1.8	1.5	1.5	1.5	1.0	1.0	0	0
Inlet Temperature	434	436	449	460	466	455	453	444	445	443	447	460
Outlet Temperature	330	332	348	361	371	370	371	368	365	363	369	355
Rock Flow	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
Condition Code*	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

K-3 - K-4

 Bed Voltage (KV)
 Bed Amperage (MA)
 Ionizer Voltage (KV)
 Ionizer Amperage (MA)
 EFB Pressure Drop (In.)
 Inlet Temperature
 Outlet Temperature
 Rock Flow
 Condition Code*

	7	8	9	10	11	12	1	2	3	4	5	6
Bed Voltage (KV)	7	7	7	7	7	7	7	7	7	7	7	7
Bed Amperage (MA)	1.8	1.8	1.8	1.8	1.8	2.0	2.0	2.0	2.0	2.0	2.0	2.0
Ionizer Voltage (KV)	20	20	20	20	20	20	20	20	20	20	20	20
Ionizer Amperage (MA)	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
EFB Pressure Drop (In.)	.04	.04	.04	.03	.03	.03	.03	.04	.04	.04	.04	.0
Inlet Temperature	478	480	389	496	495	531	533	346	349	551	561	545
Outlet Temperature	401	403	402	400	402	404	406	405	406	407	405	402
Rock Flow	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
Condition Code*	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Rock Usage/Shift: _____

 Baghouse
 Pressure
 Drop: (in.)

	7	8	9	10	11	12	1	2	3	4	5	6
L-I	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
L-II	4.5	4.5	4.5	4.5	4.5	4.5	4.5	4.5	4.5	4.5	4.5	4.5

Comments/Problems: _____

*Condition Codes

- 1) Start up/shutdown
- 2) Konus down
- 3) Moisture in bed
- 4) Adding rock

- 5) Power Outage
- 6) Checking EFB
- 7) Konus on oil
- 8) Maintenance

VOLUME PER SHIFT

LINE I	1 1/2
LINE II	1 1/2

APPENDIX M

SAMPLING TRAIN CALIBRATION DATA

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job L.P. Hayward Date 3/18/94
Operator D. VanHoever Module No. 6

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 28.74 in.Hg $\theta =$ 1.0054 $\Delta H@$ 1.89 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(818.30)		
2.5	820.17	48	45
5.0	821.98	54	46
7.5	823.85	57	47
10	825.70	59	47
	$V_m = 7.40$	Avg(t_m) = 50.38 °F	

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(t_m - 460)}{P_b} \right]^{0.5}$$

$$Y_m = \frac{1.786}{(1.0054)(7.4)} \left[\frac{(50.38) + 460}{(28.74)} \right]^{0.5}$$

$$Y_m = 1.01$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job L.P. Hayward Date 3-9-96
Operator EJ Module No. 10

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 28.76 in.Hg $\theta =$ 1.0012 $\Delta H@$ 1.94 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(233.00)		
2.5	234.89	46	30
5.0	236.75	47	30
7.5	238.65	47	27
10	240.49	48	27
	$V_m = 7.49$	$Avg(t_m) = 37.75$	°F

Calculate Y_{cn} as follows:

$$Y_{cn} = \frac{1.786}{\theta V_m} \left[\frac{(t_m + 460)}{P_b} \right]^{0.5}$$

$$Y_{cn} = \frac{1.786}{(7.49)(1.0012)} \left[\frac{(37.75 + 460)}{(28.76)} \right]^{0.5} 4.14$$

$$Y_{cn} = .985$$

If Y_{cn} is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job CP Hayward Date 3/18/96
Operator SK Module No. 13

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 28.74 in.Hg $\theta =$ 1.0023 $\Delta H@$ 1.82 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(307.600)		
2.5	309.434	56	36
5.0	311.265	58	36
7.5	313.140	61	37
10	314.995	62	38
	$V_m = 7.395$	Avg(t_m) = 48	°F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(t_m + 460)}{P_b} \right]^{0.5}$$

$$Y_m = \frac{1.786}{(1.0023)(7.395)} \left[\frac{(48 + 460)}{(28.74)} \right]^{0.5}$$

$$Y_m = \underline{1.013}$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job LP Hayward Date 3-21-96
Operator J. BAEJVILLE S. LONCIE Module No. 13

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 29.26 in.Hg $\theta =$ 1.023 $\Delta H@$ 1.82 in.WC

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(450.90)		
2.5	452.74	32	18
5.0	454.57	36	19
7.5	456.36	37	20
10	458.14	40	21
	$V_m = 7.24$	$Avg(t_m) = 27.9$	°F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(t_m + 460)}{P_b} \right]^{1.05}$$

$$Y_m = \frac{1.786}{(1.023)(7.24)} \left[\frac{(27.9 + 460)}{(29.26)} \right]^{1.05}$$

$$Y_m = 1.005$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job LP/Hayward Date 3-19-96
Operator S. J. L. B. Module No. 14

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 28.78 in.Hg $\theta =$.9936 $\Delta H@$ 1.81 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(919.00)		
2.5	920.83	42	29
5.0	922.64	44	29
7.5	924.49	46	31
10	926.30	48	31
	$V_m = 7.30$	$Avg(t_m) =$	37.5 °F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(t_m + 460)}{P_b} \right]^{0.5}$$

$$Y_m = \frac{1.786}{() ()} \left[\frac{() + 460}{()} \right]^{0.5}$$

$$Y_m = \underline{1.02357}$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job LP/Hayward Date 3-20-96
Operator S. Gabele Module No. 14

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 29.31 in.Hg $\theta =$ ~~0.9934~~ 0.9934 $\Delta H@$ 1.81 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(097.30)		
2.5	099.15	34	25
5.0	161.00	41	26
7.5	102.74	44	26
10	104.49	45	27
	$V_m = 7.19$	$Avg(t_m) = 33.5$	°F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(t_m - 460)}{P_s} \right]^{0.5}$$

$$Y_m = \frac{1.786}{() ()} \left[\frac{() + 460}{()} \right]^{0.5}$$

$$Y_m = \underline{1.02583}$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

EPA Method 5 Gas Metering System Quality Control Check Data Sheet

Job CPI New York Date 3-19-96
Operator _____ Module No. 15

Instructions:

Operate the control module at a flow rate equal to $\Delta H@$ for 10 minutes before attaching the umbilical.

Record the following data:

Bar press 28.69 in.Hg $\theta =$.9164 $\Delta H@$ 1.78 in.WC.

Time (min)	Volume (CF)	Meter Temp (°F)	
		Inlet	Outlet
	(994.70)		
2.5	996.52	50	39
5.0	998.37	54	39
7.5	1000.17	56	40
10	1002.00	58	40
	$V_m = 7.30$	Avg(T_m) =	47.0 °F

Calculate Y_m as follows:

$$Y_m = \frac{1.786}{\theta V_m} \left[\frac{(T_m + 460)}{P_b} \right]^{0.5}$$

$$Y_m = \frac{1.786}{(.9164)(7.30)} \left[\frac{(47.0 + 460)}{(28.69)} \right]^{0.5}$$

$$Y_m = \underline{1}$$

If Y_m is not within the range of 0.97 to 1.03, "the volume metering system should be investigated before beginning."

CFR Title 40, Part 60, Appendix A, Method 5, Section 4.4.1

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: March 26, 1996

Meter Box No. : 6 (Rockwell Dry Test Meter Serial No. 964548)

Date of Last Calibration: January 11, 1996

Calibration Technician: S. Fjelsta

Wet Test Meter No.: American Meter AL-20

Date of Use	Report No.	Initial Meter Reading	Final Meter Reading	Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
February 22, 1996	6-7318	437.32	595.20	157.88	157.88
March 05, 1996	6-7378	607.00	816.99	209.99	367.87
March 18, 1996	6-7451	826.00	1474.30	648.30	1016.17

* Total volume through meter since last calibration.

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: March 26, 1996

Meter Box No. : 10 (Rockwell Dry Test Meter Serial No. 1334112)

Date of Last Calibration: March 11, 1996

Calibration Technician: E. Juers

Wet Test Meter No.: American Meter AL-20

Date of Use	Report No.	Initial Meter		Final Meter		Volume/job (cu. ft.)	Total Volume* (cu. ft.)
		Reading		Reading			
March 15, 1996	6-7446	40.80		214.48		173.68	173.68
March 19, 1996	6-7451	241.40		342.86		101.46	275.14

* Total volume through meter since last calibration.

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: March 26, 1996

Meter Box No. : 13 (Rockwell Dry Test Meter Serial No. 1334119)

Date of Last Calibration: January 5, 1996

Calibration Technician: S. Fjelsta

Wet Test Meter No.: American Meter AL-20

Date of Use	Report No.	Initial Meter Reading	Final Meter Reading	Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
March 19, 1996	6-7451	315.18	639.72	324.54	324.54

* Total volume through meter since last calibration.

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: March 26, 1996

Meter Box No.: 14 (Rockwell Dry Test Meter Serial No. 1334123)

Date of Last Calibration: January 10, 1996

Calibration Technician: S. Fjelsta

Wet Test Meter No.: American Meter AL-20

Date of Use	Report No.	Initial Meter Reading	Final Meter Reading	Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
February 20, 1996	6-7331	670.87	770.94	100.07	100.07
February 21, 1996	6-7319	781.55	909.89	128.34	228.41
March 19, 1996	6-7451	926.79	1245.33	318.54	546.95

* Total volume through meter since last calibration.

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: March 26, 1996

Meter Box No. : 15 (Rockwell Dry Test Meter Serial No. 1334118)

Date of Last Calibration: March 12, 1996

Calibration Technician: S. Kelker

Wet Test Meter No.: American Meter AL-20

Date of Use	Report No.	Initial Meter Reading	Final Meter Reading	Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
March 19, 1996	6-7451	10.50	288.61	278.11	278.11

* Total volume through meter since last calibration.

Interpoll Laboratories, Inc.
(612) 786-6020

Meter Box Calibration and Usage Status

Date of Report: March 26, 1996

Meter Box No. : 6-S (Rockwell Dry Test Meter Serial No. 649078)

Date of Last Calibration: January 11, 1996

Calibration Technician: S. Fjelsta

Wet Test Meter No.: American Meter AL-17 (0.05 CF/REV)

Date of Use	Report No.	Initial Meter Reading	Final Meter Reading	Volume/Job (cu. ft.)	Total Volume* (cu. ft.)
February 13, 1996	6-7285	463.200	465.830	2.630	2.630
February 20, 1996	6-7318	466.403	473.379	6.976	9.606
March 21, 1996	6-7451	482.168	507.109	24.941	34.547

* Total volume through meter since last calibration.

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Meter Calibration Sheet EPA/Method 5

Date 1-11-96
Bar. Press. 28.97
Wet Test Meter No. AL-20
Control Module No. 6
Serial No. DTM 964568
Technician SF

ΔH (IN.WC)		Gas Volume Wet Test Meter (ft³)	Cal. Index φ	Diff. Wet Test Meter ΔP _w (IN.WC.)	Gas Volume Dry Test Meter (ft³)		Gas Temperatures			Time θ (Min/Sec)	Meter Coeff.	Orifice Const.	C ₁
					V _{at}	V _{at}	Wet Test I _w (°F)	Dry Test					
Nominal	Actual		(%)					I _{at} (°F)	I _{do} (°F)		Y	ΔH@	
0.5	0.5	2	99.85	0.01	969.132	971.446	69.5	81	70	5/08	1.0015	1.830	
1.2	1.2	3	99.91	0.025	971.451	974.465	69.5	86	71	5/02	1.0053	1.864	
2.0	2.0	3	99.93	0.055	965.629	968.626	69.5	80	69	3/56	1.0046	1.910	
3.3	3.3	5	100.00	0.09	974.975	980.022	69.5	91	72	5/09	1.0047	1.931	
4.7	4.7	5	100.02	0.12	980.635	985.673	69.5	95	73	4/2	1.0029	1.939	

Positive leak check performed by _____

Meter was in tolerance ☒ 5F _____

Approved by  _____

Meter was not in tolerance ☐ readjusted linkage

Meter was not in tolerance ☐ changed dry test meter

Date 11/7/96

*Based on AL-20 wet test meter calibration in Nov. 1991 against Bell Prover (NBS Traceable) - Carl Poe Co.

Meter Calibration Sheet EPA/Method 5

[illegible]

031794-G:\STACK\WP\FORMS\5-0102RR

Meter Calibration Sheet EPA/Method 5

75.

031794-G:STACK\WP\FORMS\S-0102RR

(612) 786-6020

14

✓ 334123

331

i-10-96

29.15 IN.HG

A1-20

Wet Test Meter No. _____

Wet Test Meter No. _____

Wet Test Meter No. _____

[illegible]

☐: readjusted linkage
☐: changed dry test meter

Meter was not in tolerance

Meler was not in tolerance

11/7/96

L
V

Positive leak check performed by

Meter was in tolerance

Approved by

*Based on Al-20 wet test meter calibration in Nov. 1991 against Bell Prover (NBS Traceable) - Carl Poe Co.

031794-G:\STACK\WP\FORMS\5-0102RR

Meter Calibration Sheet EPA/Method 5

3/12/96
28.97

IN-HG

AL-20

Control Module No.

Serial No. DTM

Technician

5

13341158

Stene Kolman

[illegible]

Meter was not in tolerance

Meter was not in tolerance

Date

□: readjusted linkage

☐: changed dry test meter

3/14/96

031794-G:STACK\WIP\FORMS\5-0102RR

(612) 786-6020

Minimodule Calibration Sheet/Flow Rate Range 0-0.13 CFM/(0-4 LPM)

Date _____

1-11-96

Bar. Press.

28.98

Wet Test Meter No. AL-17 (.05 CF/FEV)

AL-17 (.05 CF/FEV)

Meter Box No.

Serial No. DTM

Technician

63

64078

35

Wet Test Meter No. AL-17 (03 CITEV)											
Rota-meter Reading (cc/Min)	ΔP_d (IN.WC)	Gas Volume Wet Test Meter (ft ³)	** Cal Index ϕ (%)	Diff. Wet Test Meter ΔP_w (IN.WC)	Gas Volume Dry Test Meter (ft ³)		Gas Temperature		Time θ (Min/Sec)	Meter Coeff.	Rota-meter Coeff.
					V _d	V _d	Wet Test t _w (°F)	Dry Test t _d (°F)			
1000	.001	0.2	99.55	0.04	433.453	434.152	69.5	72		1.0087	Z
1000	.001	0.2	99.55	0.04	434.417	434.618	69.5	77		1.0081	
1000	.001	0.2	99.55	0.04	434.637	434.842	69.5	80		0.9939	
Avg.											
1.0036											

Meter was in tolerance

Meter was not in tolerance

Meter was not in tolerance

Approved by

☒

✓: readjusted linkage

☐: changed dry test meters

Date / /

Gas Meter Bimetallic Therm.

 $\square \geq \pm 5^{\circ}\text{F (Out of control)}$ $\Delta \leq \pm 5^{\circ}\text{F (In control)}$

1011 Avg.


Gas Meter Bimetallic Therm. Calibration Verification *

☐ Recalibrated / ☒ No action required

*Verified against mercury in glass thermometer or calibrated platinum resistance thermometer.

*Based on AL-17 wet test meter calibration in Aug. 1989 against Bell Prover (NBS Traceable) - Carl Poe Co.

DIFFERENTIAL PRESSURE PROOF CALIBRATION CURVE




DIFFERENTIAL - INCHES H₂O

M-21

WET TEST HEAD

PULSATION RANGE



Calibrated with a 10 ft. American Bell Prover, Serial No. 3157. Traceable to the Bureau of Standards. Reference No. 5249060, PI-TAPE.

AL-20 American Wet Test Meter

Serial No. p-717

Stainless Steel w/Removable Back

Calibrated w/Saturated Air

Water Temp. 74° F.

Air Temp. 74° F.

Inlet Pressure 2" H₂O Constant

Calibration Rate: 60 CFH Per/Hr.

Capacity Rate: 120 CFH Per/Hr.

Restricted Outlet for Rate Deviation

PROOF

101

100

99

CORRECT VOLUME = INDEX READING x PROOF + 100

20

40

60

80

100

120

FLOW RATE - CUBIC FEET OF AIR PER HOUR

DAVID DARRKS

Temperature Measurement Device Calibration Sheet

Unit Under Test: 35
Vendor: OMEGA
Model: HH81 Serial Number: 74JX0332
Range: 0-2100 °F Thermocouple Type: K
Date of Calibration: 2/20/96 Technician: MARK PETERSEN
Method of Calibration: PDT No. 35

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☒ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0	0	-3	3	0.65
100	100	98	2	0.36
200	200	200	0	0
300	300	298	2	0.26
400	400	398	2	0.23
500	500	499	1	0.10
600	600	600	0	0
700	700	699	1	0.09
800	800	801	1	0.08
900	900	900	0	0
1000	1000	1000	0	0
1100	1100	1100	0	0
1200	1200	1201	1	0.06
1300	1300	1299	1	0.06
1400	1400	1402	2	0.11
1500	1500	1500	0	0
1600	1600	1603	3	0.15
1700	1700	1701	1	0.05
1800	1800	1803	3	0.13
1900	1900	1901	1	0.04
2000	2000	2001	1	0.04
2100	2100	2099	1	0.04
		Averages:	1.18	0.11

OF = off scale response by unit under test (°F)

% dev = $100 \Delta t / (460 + t)$

☐ Unit in tolerance

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACKWP\FORM55-433

Interpoll Laboratories
(612) 786-6020

Nozzle Calibration Data Sheet

Date of Calibration: 03-19-96
Technician: Duane Van Hoever
Nozzle Number: 7-4

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	0.247
2	0.247
3	0.248
Average	0.247

Interpoll Laboratories
(612) 786-6020

Nozzle Calibration Data Sheet

Date of Calibration: 03-19-96
Technician: Ed Juers
Nozzle Number: 8-3

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	0.189
2	0.189
3	0.190
Average	0.189

Interpoll Laboratories
(612) 786-6020

Nozzle Calibration Data Sheet

Date of Calibration: 03-19-96
Technician: Bob Aschenbach
Nozzle Number: 9-5

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	0.311
2	0.311
3	0.310
Average	0.311

Interpoll Laboratories
(612) 786-6020

Nozzle Calibration Data Sheet

Date of Calibration: 03-19-96
Technician: Bob Aschenbach
Nozzle Number: GLASS

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	0.370
2	0.370
3	0.370
Average	0.370

Interpoll Laboratories
(612) 786-6020

Nozzle Calibration Data Sheet

Date of Calibration: 03-19-96
Technician: Scott Fjelsta
Nozzle Number: GLASS

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	0.242
2	0.242
3	0.242
Average	0.242

Interpoll Laboratories
(612) 786-6020

Nozzle Calibration Data Sheet

Date of Calibration: 03-20-96
Technician: Scott Fjelsta
Nozzle Number: 10-4

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	0.250
2	0.248
3	0.248
Average	0.249

Interpoll Laboratories
(612) 786-6020

Nozzle Calibration Data Sheet

Date of Calibration: 03-20-96
Technician: Duane Van Hoever
Nozzle Number: GLASS

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	0.269
2	0.269
3	0.270
Average	0.269

Interpoll Laboratories
(612) 786-6020

Nozzle Calibration Data Sheet

Date of Calibration: 03-21-96
Technician: Jamie Bainville
Nozzle Number: 5-7

The nozzle is rotated in 60 degree increments and the diameter at each point is measured to the nearest 0.001 inch. The observed readings and average are shown below.

Position	Diameter (inches)
1	0.432
2	0.431
3	0.432
Average	0.432

Interpoll Laboratories, Inc.

Temperature Measurement Device
Calibration Sheet

Unit under test:

Vendor Brickman Industrial
Model HD 110 T °F
Range _____
Date of Calibration 12/8/85
Serial Number PDT #18
Thermocouple Type K
Technician D. Van Hoever

Method of Calibration:

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☐ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100 °F) ± 1 degree (for negative temperatures add ± 2 degrees. The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0		-1	1	.217
100		95	5	.89
200		198	2	.3
300		296	4	.52
400		394	6	.7
500		493	7	.81
600		596	4	.38
700		697	3	.26
800		802	2	.16
900		904	4	.29
1000		1010	10	.68
1100		1113	13	.83
1200		1220	20	1.2
1300		1320	20	1.14
1400		1424	24	1.27
1500		1523	23	1.17
1600		1624	24	1.16
1700		1720	20	.92
1800		1818	18	.80
1900		1911	11	.46
2000				
2100				
		Averages:		.71

OF = off scale response by unit under test (°F)
% dev = $100 \Delta t / (460 + t)$

- ☐ Unit in tolerance
☐ Unit was not in tolerance; recalibrated - See new calibration sheet.

Temperature Measurement Device Calibration Sheet

Unit Under Test:

Vendor:

Model:

Range:

Date of Calibration:

Method of Calibration:

Omega
44 Bi
0-2000 °F
12-26-95

Serial Number: 73 J x 1495
Thermocouple Type: K
Technician: Mark Kaehler
PDT No.: 31

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☐ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δ (°F)	(%)
0		-3	3	.65
100		97	3	.54
200		200	0	0
300		298	2	.26
400		397	3	.35
500		497	3	.31
600		599	1	.09
700		698	2	.17
800		800	0	0
900		899	1	.07
1000		999	1	.07
1100		1099	1	.06
1200		1199	1	.06
1300		1298	2	.11
1400		1400	0	0
1500		1498	2	.10
1600		1600	0	0
1700		1699	1	.05
1800		1800	0	0
1900		1897	3	.13
2000		1998	2	.08
2100		2095	5	.20
		Averages:	1.64	.15

OF = off scale response by unit under test (°F)

☒ Unit in tolerance

% dev = $100 \Delta / (460 + t)$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:\STACK\WP\FORMS\5-33

Temperature Measurement Device Calibration Sheet

Unit Under Test:

Model

Range

Date of Calibration

Method of Calibration:

Omega

CL-300

0-2200

2-2-96

Serial Number

Thermocouple Type

Technician

PDT No.

74JX 0723

K

BA

33

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☒ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0	0	-4	-4	.008
100	100	97	3	.535
200	200	199	1	.151
300	300	298	2	.263
400	400	397	3	.348
500	500	497	3	.312
600	600	599	1	.094
700	700	698	2	.172
800	800	800	0	0
900	900	899	1	.073
1000	1000	999	1	.068
1100	1100	1098	2	.128
1200	1200	1199	1	.060
1300	1300	1298	2	.113
1400	1400	1400	0	0
1500	1500	1499	1	.051
1600	1600	1602	2	.097
1700	1700	1699	1	.046
1800	1800	1802	2	.088
1900	1900	1899	1	.042
2000	2000	2000	0	0
2100	2100	2097	3	.117
		Averages:	1.272	.125

OF = off scale response by unit under test (°F)

☐ Unit in tolerance

% dev = $100 \Delta t / 1460 + 1$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACKWPFORM55-433

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Temperature Measurement Device Calibration Sheet

Unit Under Test:

Vendor

Model

Range

Date of Calibration

Method of Calibration:

OMEGA
H H 21
-160°C to 1322°C ±
2-6-96

Serial Number

Thermocouple Type

Technician

PDT No.

741X1327
K
EJ
42

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☒ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0	0	-3	3	.65
100	100	97	3	.53
200	200	199	1	.15
300	300	297	3	.39
400	400	397	3	.35
500	500	497	3	.31
600	600	599	1	.09
700	700	698	2	.17
800	800	800	0	0
900	900	899	1	.07
1000	1000	1000	0	0
1100	1100	1098	2	.13
1200	1200	1200	0	0
1300	1300	1298	2	.11
1400	1400	1401	1	.05
1500	1500	1499	1	.05
1600	1600	1602	2	.09
1700	1700	1701	1	.05
1800	1800	1802	2	.09
1900	1900	1901	1	.04
2000	2000	2000	0	0
2100	2100	2099	1	.04
Averages:			1.5	.153

OF = off scale response by unit under test (°F)

☒ Unit in tolerance

% dev = $100 \Delta t / (460 + t)$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACK\WP\FORMS\433

Temperature Measurement Device Calibration Sheet

Unit Under Test:

Vendor
Model

Range

Date of Calibration

Method of Calibration:

Omega

HH 81

0-2000

2-16-96

°F

Serial Number

Thermocouple Type

Technician

PDT No.

743X1539

K

LH

43

☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.

☒ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0	0	-3	3	.650
100	100	98	2	.357
200	200	200	0	0
300	300	299	1	-.132
400	400	398	2	-.233
500	500	499	1	-.104
600	600	600	0	0
700	700	699	1	-.086
800	800	801	1	.079
900	900	899	1	-.074
1000	1000	1000	0	0
1100	1100	1098	2	-.128
1200	1200	1200	0	0
1300	1300	1298	2	-.113
1400	1400	1401	1	-.054
1500	1500	1499	1	-.051
1600	1600	1602	2	-.097
1700	1700	1700	0	0
1800	1800	1802	2	-.088
1900	1900	1900	0	0
2000	2000	2000	0	0
2100	2100	2097	3	-.117
		Averages:	1.137	-.107

OF = off scale response by unit under test (°F)

☒ Unit in tolerance

% dev = $100 \Delta t / (460 + t)$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACKWPFORM55-433

Temperature Measurement Device Calibration Sheet

Unit Under Test:

Vendor

Model

Range

Date of Calibration

Method of Calibration:

Omega

HH B1

0-2000

12-26-95

°F

Serial Number

Thermocouple Type

Technician

PDT No.

743X1560

K

Mark Baehler

45

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☐ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0		-2	2	.43
100		98	2	.36
200		200	0	0
300		298	2	.26
400		398	2	.23
500		499	1	.10
600		600	0	0
700		699	1	.09
800		801	1	.08
900		900	0	0
1000		1001	1	.07
1100		1099	1	.06
1200		1201	1	.06
1300		1299	1	.06
1400		1402	2	.11
1500		1499	1	.05
1600		1602	2	.10
1700		1701	1	.05
1800		1802	2	.09
1900		1901	1	.04
2000		2001	1	.04
2100		2099	1	.04
		Averages:	1.18	.11

OF = off scale response by unit under test (°F)

☒ Unit in tolerance

% dev = $100 \Delta t / (460 + t)$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACK\WP\FORMS-433

Temperature Measurement Device Calibration Sheet

Unit Under Test:

Model

Range

Date of Calibration

Method of Calibration:

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☒ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

OMEGA
HH81
-160 to +1,372 °C
2-6-96

Serial Number
753X1176
K
ES
47

Thermocouple Type
Technician
PDT No.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0	0	-3	3	.65
100	100	98	2	.36
200	200	200	0	0
300	300	298	2	.26
400	400	398	2	.24
500	500	499	1	.10
600	600	600	0	0
700	700	699	1	.09
800	800	801	1	.08
900	900	901	1	.07
1000	1000	1001	1	.07
1100	1100	1099	1	.06
1200	1200	1201	1	.06
1300	1300	1299	1	.06
1400	1400	1402	2	.11
1500	1500	1500	0	0
1600	1600	1602	2	.09
1700	1700	1701	1	.05
1800	1800	1803	3	.13
1900	1900	1901	1	.04
2000	2000	2001	1	.04
2100	2100	2099	1	.04
		Averages:	1.27	.12

OF = off scale response by unit under test (°F)

☒ Unit in tolerance

% dev = $100 \Delta t / 1460 \div 0$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACKWPFORMSS-433

Temperature Measurement Device Calibration Sheet

Unit Under Test: 49

Vendor: Omega

Model: HH 81

Range: 0 - 2100 °F

Date of Calibration: 2/20/96

Method of Calibration:

Serial Number: 75 JX2567

Thermocouple Type: K

Technician: MARK PETERSEN

PDT No.: 49

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostatted and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☒ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δt (°F)	(%)
0	0	-3	3	0.007 ^{°F} 0.65
100	100	97	3	0.54
200	200	200	0	0
300	300	298	2	0.26
400	400	397	3	0.35
500	500	498	2	0.21
600	600	600	0	0
700	700	699	1	0.086
800	800	800	0	0
900	900	900	0	0
1000	1000	1000	0	0
1100	1100	1098	2	0.13
1200	1200	1200	0	0
1300	1300	1298	2	0.11
1400	1400	1401	1	0.05
1500	1500	1499	1	0.05
1600	1600	1602	2	0.10
1700	1700	1700	0	0
1800	1800	1802	2	0.09
1900	1900	1901	1	0.04
2000	2000	2000	0	0
2100	2100	2099	1	0.04
		Averages:	1.18	0.123

OF = off scale response by unit under test (°F)

☐ Unit in tolerance

% dev = $100 \Delta t / (460 + t)$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACK\WP\FORMS\5-433

Temperature Measurement Device Calibration Sheet

Unit Under Test: #51

Vendor: Omega Serial Number: 75.5 x 2114
 Model: 0-2000 °F Thermocouple Type: K
 Range: 100 17-1996 Technician: HN
 Date of Calibration: 10-17-1996 PDT No.: 251
 Method of Calibration:

- ☐ Comparison against ASTM mercury in glass thermometer using a thermostated and insulated aluminum block designed to provide uniform temperature. The temperature is adjusted by adjusting the voltage on the block heater cartridge.
- ☐ Omega Model CL-300 Type K Thermocouple Simulator which provides 22 precise temperature equivalent millivolt signals. The CL-300 is cold junction compensated. Calibration accuracy is $\pm 0.1\%$ of span (2100°F) ± 1 degree (for negative temperatures add ± 2 degrees). The CL-300 simulates exactly the millivoltage of a Type K thermocouple at the indicated temperature.

Desired Temp (°F) Nominal	Temperature of Standard or Simulated Temp (°F)	Response of Unit Under Test (°F)	Deviation	
			Δ (°F)	(%)
0	0	99 -1	0 1	.2174
100	100	100	0	0
200	200	202	2	.303
300	300	300	0	0
400	400	399	-1	.1163
500	500	500	0	0
600	600	601	+1	.09433
700	700	700	0	0
800	800	803	+3	.2380
900	900	901	+1	.0735
1000	1000	1001	+1	.0625 .0085
1100	1100	1100	0	0
1200	1200	1201	+1	.0602
1300	1300	1300	0	0
1400	1400	1404	+4	.2154 .2151
1500	1500	1501	+1	.0511
1600	1600	1604	+4	.1942
1700	1700	1701	+1	.0463
1800	1800	1804	+4	.1870
1900	1900	1901	+1	.0429
2000	2000	2001	+1	.0407
2100	2100	2100 2099	-1	.0391
Totals		Averages:	1.273	.0903

OF = off scale response by unit under test (°F)
☒ Unit in tolerance

% dev = $100 \Delta / 1460 + 0$

☐ Unit was not in tolerance: recalibrated - See new calibration sheet.

011995-G:STACK\WP\FORMS-433

S-Type Pitot Tube Inspection Sheet

Pitot Tube No. 22-8

Pitot tube dimensions:

1. External tubing diameter (D) .316 IN.
2. Base to Side A opening plane (P_A) .460 IN.
3. Base to Side B opening plane (P_B) .460 IN.

Alignment:

4. α_1 < 10° 0
5. α_2 < 10° 0

6. B₁ < 5° 0
7. B₂ < 5° 0

8. Z < .125" .0
9. W < .0625" .01

Distance from Pitot to Probe Components:

10. Pitot to 0.500 IN. nozzle .760 IN.
11. Pitot to probe sheath 3.0 IN.
12. Pitot to thermocouple (parallel to probe) 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) .760 IN.

- ☒ Meets all EPA design criteria thus C_p = 0.84
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
C_p = _____

Date of Inspection:

1-8-94

Inspected by:

[Signature]

CFR Title 40 Part 60 Appendix A Method 2

S-348

S-Type Pitot Tube Inspection Sheet

Pitot Tube No 23-5

Pitot tube dimensions:

1. External tubing diameter (D_t) _____, 3.16 IN.
2. Base to Side A opening plane (P_A) _____, 4.60 IN.
3. Base to Side B opening plane (P_B) _____, 4.60 IN.

Alignment:

4. α_1 < 10° 0
5. α_2 < 10° 0
6. B_1 < 5° 0
7. B_2 < 5° 0
8. Z < .125" .02
9. W < .0625" .01

Distance from Pitot to Probe Components:

10. Pitot to 0.500 IN. nozzle _____, 7.60 IN.
11. Pitot to probe sheath _____, 3.0 IN.
12. Pitot to thermocouple (parallel to probe) _____, 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) _____, 7.60 IN.

- ☒ Meets all EPA design criteria thus $C_p = 0.84$
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
 $C_p =$ _____

Date of Inspection:

2/8-94

Inspected by:

[Signature]

S-Type Pitot Tube Inspection Sheet

Pitot Tube No. 23-8

Pitot tube dimensions:

1. External tubing diameter (D) 3/16 IN.
2. Base to Side A opening plane (P_A) 760 IN.
3. Base to Side B opening plane (P_B) 460 IN.

Alignment:

4. α_1 < 10° 0
5. α_2 < 10° 0
6. β_1 < 5° 0
7. β_2 < 5° 0
8. Z < .125" .03
9. W < .0625" .02

Distance from Pitot to Probe Components:

10. Pitot to 0.500 IN. nozzle 760 IN.
11. Pitot to probe sheath 3.0 IN.
12. Pitot to thermocouple (parallel to probe) 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) 760 IN.

- ☒ Meets all EPA design criteria thus $C_p = 0.84$
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
 $C_p =$ _____

Date of Inspection:

4-8-84

Inspected by:

[Signature]

S-Type Pitot Tube Inspection Sheet

Pitot Tube No. 27-6

Pitot tube dimensions:

1. External tubing diameter (D) .316 IN.
2. Base to Side A opening plane (P_A) .460 IN.
3. Base to Side B opening plane (P_B) .460 IN.

Alignment:

4. α_1 < 10° 0
5. α_2 < 10° 0

6. B_1 < 5° 0
7. B_2 < 5° 0

8. Z < .125" .01
9. W < .0625" .02

Distance from Pitot to Probe Components:

10. Pitot to 0.500 IN. nozzle .750 IN.
11. Pitot to probe sheath 3.0 IN.
12. Pitot to thermocouple (parallel to probe) 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) .760 IN.

- ☒ Meets all EPA design criteria thus $C_p = 0.84$
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
 $C_p =$ _____

Date of Inspection:

4-7-94

Inspected by:

[Signature]

S-Type Pitot Tube Inspection Sheet

Pitot Tube No. 29-6

Pitot tube dimensions:

1. External tubing diameter (D) 1.316 IN.
2. Base to Side A opening plane (P_A) 4.60 IN.
3. Base to Side B opening plane (P_B) 4.60 IN.

Alignment:

4. α_1 < 10° 0
5. α_2 < 10° 0
6. B_1 < 5° 0
7. B_2 < 5° 0
8. Z < .125" .02
9. W < .0625" .02

Distance from Pitot to Probe Components:

10. Pitot to 0.500 IN. nozzle 1.750 IN.
11. Pitot to probe sheath 3.0 IN.
12. Pitot to thermocouple (parallel to probe) 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) 1.760 IN.

- ☒ Meets all EPA design criteria thus $C_p = 0.84$
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
 $C_p =$ _____

Date of Inspection:

4-7-94

Inspected by:

[Signature]

S-Type Pitot Tube Inspection Sheet

Pitot Tube No. 31-5

Pitot tube dimensions:

1. External tubing diameter (D) 316 IN.
2. Base to Side A opening plane (P_A) 460 IN.
3. Base to Side B opening plane (P_B) 460 IN.

Alignment:

4. α_1 < 10° 0
5. α_2 < 10° 0
6. B_1 < 5° 0
7. B_2 < 5° 0
8. Z < .125" 0
9. W < .0625" .02

Distance from Pitot to Probe Components:


10. Pitot to 0.500 IN. nozzle 750 IN.
11. Pitot to probe sheath 3.0 IN.
12. Pitot to thermocouple (parallel to probe) 3.0 IN.
13. Pitot to thermocouple (perpendicular to probe) 757 IN.

- ☒ Meets all EPA design criteria thus $C_p = 0.84$
☐ Does not meet EPA design criteria - thus calibrate in wind tunnel.
 $C_p =$ _____

Date of Inspection:

4-7-94

Inspected by:



INTERPOLL LABORATORIES, INC.
(612) 786-6020

Stack Sampling Department - QA
Aneroid Barometer Calibration Sheet

Date

Technician

Mercury Column Barometer No.

Aneroid Barometer No.

2-2-96
Bob
Company 1
10723029

Actual Mercury Barometer Read	Ambient Temp.	Temperature Correction Factor	Adjusted Mercury Barometer Read	Initial Aneroid Barometer Read	Difference ($P_{ba} - P_{bm}$)
29.79	69	.107	29.68	29.69	.01

Has this barometer shown any consistent problems with calibration? Yes/No. If yes, explain. _____

Has problem been alleviated? Yes/No. How? _____

Note: Aneroid barometers will be calibrated periodically against a mercury column barometer. The aneroid barometer to be calibrated should be placed in close proximity to the mercury barometer and left to equilibrate for 20 - 30 minutes before calibrating. Aneroid barometer will be calibrated to the adjusted mercury barometer readings.

INTERPOL LABORATORIES, INC.
(612) 786-6020

Stack Sampling Department - QA
Aneroid Barometer Calibration Sheet

Date 1-17-96
Technician S. Fjelsta
Mercury Column Barometer No. Lab / Balance Room
Aneroid Barometer No. 20901010

Actual Mercury Barometer Read	Ambient Temp.	Temperature Correction Factor	Adjusted Mercury Barometer Read	Initial Aneroid Barometer Read	Difference ($P_{ba} - P_{bm}$)
<u>28.85</u>	<u>70</u>	<u>-107</u>	<u>28.843</u>	<u>28.850</u>	<u>.007</u>

Has this barometer shown any consistent problems with calibration? Yes/No. If yes, explain. _____

NO

Has problem been alleviated? Yes/No. How? _____

Note: Aneroid barometers will be calibrated periodically against a mercury column barometer. The aneroid barometer to be calibrated should be placed in close proximity to the mercury barometer and left to equilibrate for 20 - 30 minutes before calibrating. Aneroid barometer will be calibrated to the adjusted mercury barometer readings.

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Stack Sampling Department - QA
Aneroid Barometer Calibration Sheet

Date 2-9-96
Technician E. J. J. S.
Mercury Column Barometer No. 1
Aneroid Barometer No. 10724004

Actual Mercury Barometer Read	Ambient Temp.	Temperature Correction Factor	Adjusted Mercury Barometer Read	Initial Aneroid Barometer Read	Difference ($P_{ba} - P_{bm}$)
28.99	82	.136	28.85	28.85	0

Has this barometer shown any consistent problems with calibration? Yes/No. If yes, explain. NO

Has problem been alleviated? Yes/No. How? _____

Note: Aneroid barometers will be calibrated periodically against a mercury column barometer. The aneroid barometer to be calibrated should be placed in close proximity to the mercury barometer and left to equilibrate for 20 - 30 minutes before calibrating. Aneroid barometer will be calibrated to the adjusted mercury barometer readings.

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Stack Sampling Department - QA
Aneroid Barometer Calibration Sheet

Date 12-26-95
Technician Mark Isachen
Mercury Column Barometer No. Lab 1
Aneroid Barometer No. 21029004

Actual Mercury Barometer Read	Ambient Temp.	Temperature Correction Factor	Adjusted Mercury Barometer Read	Initial Aneroid Barometer Read	Difference ($P_{ba} - P_{bn}$)
29.080	80	.131	28.949	28.95	.001

Has this barometer shown any consistent problems with calibration? Yes/No. If yes, explain. _____

Has problem been alleviated? Yes/No. How? _____

Note: Aneroid barometers will be calibrated periodically against a mercury column barometer. The aneroid barometer to be calibrated should be placed in close proximity to the mercury barometer and left to equilibrate for 20 - 30 minutes before calibrating. Aneroid barometer will be calibrated to the adjusted mercury barometer readings.

INTERPOLL LABORATORIES

(612)786-6020

Stack Sampling Department - QA
Aneroid Barometer Calibration Sheet

Date 1-10-96
Technician E. Trowbridge
Mercury Column Barometer No. ULTIMETER MODEL 12
Aneroid Barometer No. SN - P1002005

Actual Mercury Barometer Read	Ambient Temp.	Temperature Correction Factor	Adjusted Mercury Barometer Read	Initial Aneroid Barometer Read	Difference (Pba-Pbm)
29.164	72	.116	29.05	29.05	-0-

Has this barometer shown any consistent problems with calibration? Yes/No. If
yes, explain. No

Has problem been alleviated? Yes/No. How? _____

*Note

Aneroid barometers will be calibrated periodically against a mercury column barometer. The aneroid barometer to be calibrated should be placed in close proximity to the mercury barometer and left to equilibrate for 20-30 minutes before calibrating. Aneroid barometer will be calibrated to the adjusted mercury barometer readings.

INTERPOL LABORATORIES, INC.
(612) 786-6020

Stack Sampling Department - QA
Aneroid Barometer Calibration Sheet

Date
Technician
Mercury Column Barometer No.
Aneroid Barometer No.

12/8/95
D. VAN HOEVER
LAB
DUT'S

Actual Mercury Barometer Read	Ambient Temp.	Temperature Correction Factor	Adjusted Mercury Barometer Read	Initial Aneroid Barometer Read	Difference ($P_{ba} - P_{bm}$)
29.14	82	.142	28.998	28.94	.058

Has this barometer shown any consistent problems with calibration? Yes/No No If yes, explain. _____

Has problem been alleviated? Yes/No. How? _____

Note: Aneroid barometers will be calibrated periodically against a mercury column barometer. The aneroid barometer to be calibrated should be placed in close proximity to the mercury barometer and left to equilibrate for 20 - 30 minutes before calibrating. Aneroid barometer will be calibrated to the adjusted mercury barometer readings.

INTERPOLL LABORATORIES, INC.
(612) 786-6020

Stack Sampling Department - QA
Aneroid Barometer Calibration Sheet

Date
Technician
Mercury Column Barometer No.
Aneroid Barometer No.

10-17-95
R.R.
NOVA-1
560209

Actual Mercury Barometer Read	Ambient Temp.	Temperature Correction Factor	Adjusted Mercury Barometer Read	Initial Aneroid Barometer Read	Difference ($P_{ba} - P_{bm}$)
28.91	82	.14	28.77	28.76	.01

Has this barometer shown any consistent problems with calibration? Yes/No. If yes, explain.

BAROMETER HAS BEEN REPAIRED

Has problem been alleviated? Yes/No. How?

Note: Aneroid barometers will be calibrated periodically against a mercury column barometer. The aneroid barometer to be calibrated should be placed in close proximity to the mercury barometer and left to equilibrate for 20 - 30 minutes before calibrating. Aneroid barometer will be calibrated to the adjusted mercury barometer readings.